



## Overview

---

Cisco Data Center Network Manager (DCNM) is a management system for Cisco NXOS-based storage fabrics. In addition to provisioning, monitoring, and troubleshooting the data center network infrastructure, the Cisco DCNM provides a comprehensive feature-set that meets the routing, switching, and storage administration needs of data centers. It streamlines the provisioning for the Programmable Fabric and monitors the SAN components.

Cisco DCNM provides a high level of visibility and control through a single web-based management console for Cisco Nexus Series Switches, Cisco MDS, and Cisco Unified Computing System (UCS) products. Cisco DCNM also includes Cisco DCNM-SAN client and Device Manager functionality.

This section contains the following sections:

- [Introduction, on page 1](#)
- [Installation Options, on page 2](#)
- [Deployment Options, on page 2](#)
- [root and sysadmin User Privileges, on page 3](#)
- [Upgrading to Cisco DCNM Release 11.5\(1\), on page 3](#)
- [System Requirements, on page 4](#)

## Introduction

Cisco DCNM provides an alternative to the command-line interface (CLI) for switch configuration commands.

Cisco DCNM includes these management applications:

### **Cisco DCNM Web UI**

Cisco DCNM Web UI allows operators to monitor and obtain reports for Cisco MDS and Nexus events, performance, and inventory from a remote location using a web browser. Licensing and discovery are part of the Cisco DCNM Web UI.

### **Performance Manager**

Performance Manager presents detailed traffic analysis by capturing data with SNMP. This data is compiled into various graphs and charts that can be viewed on the Cisco DCNM Web UI.

# Installation Options

Cisco DCNM software images are packaged with the Cisco DCNM installer, signature certificate, and signature verification script. Unzip the desired Cisco DCNM installer image ZIP file to a directory. Verify the image signature by following the steps in the README file. The installer from this package installs the Cisco DCNM software.

## DCNM Open Virtual Appliance (OVA) Installer

This installer is available as an Open Virtual Appliance file (.ova). The installer contains a pre-installed OS, DCNM, and other applications needed for programmable fabric.

## DCNM ISO Virtual Appliance (ISO) Installer

This installer is available as an ISO image file (.iso). The installer is a bundle of OS, DCNM, and other applications needed for dynamic fabric automation.



---

**Note** If you are installing Cisco DCNM on SE, install the DCNM ISO Virtual Appliance (.iso) installer.

---

# Deployment Options

You can deploy the Cisco DCNM installer in one of the following modes:

## Supported Latency

The supported latency for Cisco DCNM Media Controller deployment is defined below:

- Between Native HA Primary and Secondary appliances, latency is 50ms.
- Between DCNM Native HA Primary appliance to Switches, latency is 50ms.

## Standalone Server

All types of installers are packaged along with PostgreSQL database. The default installation steps for the respective installers result in this mode of deployment.



---

**Note** We recommend that you deploy Cisco DCNM in Native HA Mode.

---

## High Availability for Virtual Appliances

You can deploy the DCNM Virtual appliances, both OVA and ISO, in High Availability mode to have resilience in case of application or OS failures.

# root and sysadmin User Privileges

The following table summarizes the user privileges differences between DCNM 11.5 and previous releases.



**Note** This is applicable to Cisco DCNM OVA/ISO deployments only.

Description	Functionality in DCNM 11.5 Release	Functionality in DCNM 11.4(1) and 11.3(1) Releases	Remarks
<b>su</b> command	Requires local <b>root</b> password. <b>sysadmin</b> user can't run <b>sudo su</b> command	Requires <b>sysadmin</b> password <b>su</b> is an alias for <b>sudo su</b>	The <b>su</b> command requires the local password even when the remote authentication is configured.
<b>appmgr change_pwd ssh root</b> command	Only <b>root</b> user can run this command.	<b>sysadmin</b> can also run this command.	-
<b>appmgr root-access {permit deny ...}</b> command	Only <b>root</b> user can run this command	<b>sysadmin</b> user can also run this command	-
<b>appmgr remote-auth</b> command	Only <b>root</b> user can run this command	Not available	-
Other <b>appmgr</b> commands	<b>root</b> or <b>sysadmin</b> user can run these commands	<b>root</b> or <b>sysadmin</b> user can run these commands	-

## Upgrading to Cisco DCNM Release 11.5(1)

Before Cisco DCNM Release 11.0(1), DCNM OVA, and ISO supported SAN functionality. From Cisco DCNM Release 11.3(1), you can install Cisco DCNM for SAN Deployment on both OVA and ISO virtual appliances.

The following table summarizes the type of upgrade that you must follow to upgrade to Release 11.5(1).

**Table 1: Type of Upgrade for IP for Media (IPFM) deployments**

Current Release Number	Upgrade type to upgrade to Release 11.5(1)
11.4(1)	Inline Upgrade
11.3(1)	Inline Upgrade
11.2(1)	Inline Upgrade

Current Release Number	Upgrade type to upgrade to Release 11.5(1)
11.1(1)	11.1(1) → 11.2(1) → 11.5(1) 11.1(1) → 11.3(1) → 11.5(1) 11.1(1) → 11.4(1) → 11.5(1) → represents an Inline Upgrade

## System Requirements

This section describes the various system requirements for proper functioning of your Cisco DCNM Release 11.5(1).



**Note** We recommend that you do not upgrade any underlying third-party software separately. All the necessary software components will be updated during the inline upgrade procedure. Upgrading the components outside of DCNM upgrade causes performance issues.

- [Java Requirements, on page 4](#)
- [Server Requirements, on page 4](#)
- [Supported Latency](#)
- [Database Requirements, on page 5](#)
- [Hypervisors, on page 5](#)
- [Server Resource \(CPU/Memory\) Requirements, on page 5](#)
- [VMware Snapshot Support for Cisco DCNM, on page 6](#)
- [Supported Web Browsers, on page 7](#)
- [Other Supported Software, on page 8](#)

### Java Requirements

The Cisco DCNM server is distributed with JRE 11.0.8 into the following directory:

```
DCNM_root_directory/java/jdk11
```

### Server Requirements

Cisco DCNM Release 11.5(1), supports the Cisco DCNM server on these 64-bit operating systems:

- **IP for Media, and LAN Fabric Deployments:**
  - Open Virtual Appliance (OVA) with an integrated CentOS Linux release 7.8
  - ISO Virtual Appliance (ISO) with an integrated CentOS Linux release 7.8

### Supported Latency

The supported latency for Cisco DCNM Media Controller deployment is defined below:

- Between Native HA Primary and Secondary appliances, latency is 50ms.
- Between DCNM Native HA Primary appliance to Switches, latency is 50ms.

### Database Requirements

Cisco DCNM Release 11.5(1) supports the following databases:

- PostgreSQL 10.15 - For OVA/ISO deployments




---

**Note** The ISO and OVA installations support only the embedded PostgreSQL database.

---

### Hypervisors

Cisco DCNM supports the ISO installation on a bare-metal server, no hypervisor, on the following server platforms:

Server	Product ID (PID)	Recommended minimum memory, drive capacity, and CPU count
Cisco UCS C240M4	UCSC-C240-M4S	32G / 500G 16 vCPUs
Cisco UCS C240M4	UCSC-C240-M4L	32G / 500G 16 vCPUs
Cisco UCS C240 M5S	UCSC-C240-M5SX	32G / 500G 16 vCPUs
Cisco UCS C220 M5L	UCSC-C220-M5L	32G / 500G 16 vCPUs




---

**Note** Cisco DCNM can work on an alternative computing hardware with appropriate specifications, despite Cisco is only testing on Cisco UCS.

---

### Server Resource (CPU/Memory) Requirements




---

**Note** If you install Cisco DCNM on a virtual machine, you must reserve resources equal to the server resource requirements to ensure a baseline with the physical machines.

---

Table 2: System Requirements for Cisco DCNM IPFM Deployment

Deployment Type	Small (Lab or POC)	Large (Production)
OVA/ISO	CPU: 8 vCPUs RAM: 24 GB DISK: 500 GB	CPU: 16 vCPUs RAM: 32 GB DISK: 500 GB



**Note** For Huge and Compute deployments, you can add extra disk. The size of the disk can range from a minimum of 32GB to a maximum of 1.5TB.

Allocate sufficient disk space to the root partition to complete DCNM installation and for stable continuous operation of the DCNM applications. Refer to the applications' User guides for disk space requirements. You can mount another disk where the `/tmp` directory can be mounted during the installation or upgrade. You can also add additional disk space and the disk file system using `appmgr system scan-disks-and-extend-fs` command.

#### VMware Snapshot Support for Cisco DCNM

VMware vSphere Hypervisor (ESXi)	6.0	6.5	6.7	6.7 P01	7.0
VMware vCenter Server	6.0	6.5	6.7	6.7 P01	7.0



**Note** You need VMware vCenter server to deploy Cisco DCNM OVA Installer. However, to install DCNM directly on VMware ESXi without vCenter, you can choose DCNM ISO deployment. Ensure that correct CPU, Memory, Disk, and NIC resources are allocated to that VM.

To take a snapshot on the VM, perform the following steps:

1. Right-click the virtual machine the inventory and select **Snapshots > Take Snapshot**.
2. In the **Take Snapshot** dialog box, enter a name and description for the snapshot.
3. Click **OK** to save the snapshot.

The following snapshots are available for VMs.

- When VM is powered off.
- When VM is powered on, and active.



**Note** Cisco DCNM supports snapshots when VM is either powered on or powered off. DCNM doesn't support snapshots when the Virtual Machine memory option is selected.

Ensure that **Snapshot the Virtual Machine's memory** check box must not be selected, as shown in the following figure. However, it is grayed out when the VM is powered off.

Take Snapshot
dcnm-va.11.X.1
✕

Name VM Snapshot taken powered on 12/8/2019,

Description

Snapshot the virtual machine's memory

Quiesce guest file system (Needs VMware Tools installed)

CANCEL

OK

You can restore VM to the state in a Snapshot.

Manage Snapshots
dcnm1111
✕

- ▼ dcnm1111
- ▼ VM Snapshot 12%252f12%252f2019, 11:56:07 AM
- ▼ 1131 Snapshot 12%252f12%252f2019, 3:04:31 PM
- ▼ VM Snapshot 12%252f16%252f2019, 6:55:02 ...
- 📍 You are here

Name	VM Snapshot 12%252f16%252f2019, 6:55:02 AM
Created	12/15/2019, 11:55:31 PM
Disk usage	510.03 MB
Snapshot the virtual machine's memory	No
Quiesce guest file system	No

EDIT

DELETE ALL

DELETE

REVERT TO

DONE

Right-click on the Virtual Machine and select **Manage Snapshot**. Select the snapshot to restore, and click **Done**.

### Supported Web Browsers

Cisco DCNM supports the following web browsers:

Overview

7

- Google Chrome version: 86.0.4240.198
- Mozilla Firefox version: 82.0.3 (64-bit)
- Microsoft Edge version: 86.0.622.63

### Other Supported Software

The following table lists the other software that is supported by Cisco DCNM Release 11.5(1).

**Table 3: Other Supported Software**

Component	Features
Security	<ul style="list-style-type: none"> <li>• ACS versions 4.0, 5.1, 5.5, and 5.8</li> <li>• ISE version 2.6</li> <li>• ISE version 3.0</li> <li>• Telnet Disabled: SSH Version 1, SSH Version 2, Global Enforce SNMP Privacy Encryption.</li> <li>• Web Client Encryption: HTTPS with TLS 1, 1.1 and 1.2</li> <li>• TLS 1.3</li> </ul>
OVA\ISO Installers	CentOS 7.8/Linux Kernel 3.10.x

Also, Cisco DCNM supports call-home events, fabric change events, and events that are forwarded by traps and email.