



## disable-early-media through dualtone

---

- [disable-early-media 180](#), on page 2
- [disable service-settings](#), on page 4
- [disc\\_pi\\_off](#), on page 5
- [disconnect-ack](#), on page 6
- [dnis \(DNIS group\)](#), on page 7
- [dnis-map](#), on page 9
- [dns-a-override](#), on page 11
- [domain-name \(annex G\)](#), on page 12
- [drop-last-conferee](#), on page 13
- [ds0 busyout \(voice\)](#), on page 15
- [ds0-group \(E1\)](#), on page 17
- [ds0-group \(T1\)](#), on page 23
- [ds0-num](#), on page 30
- [dscp media](#), on page 31
- [dscp-profile](#), on page 35
- [dsn](#), on page 36
- [dsp allocation signaling dspid](#), on page 39
- [dsp services dspfarm](#), on page 40
- [dspfarm \(DSP farm\)](#), on page 42
- [dspfarm \(voice-card\)](#), on page 44
- [dspfarm confbridge maximum](#), on page 46
- [dspfarm connection interval](#), on page 48
- [dspfarm profile](#), on page 49
- [dspfarm rtp timeout](#), on page 53
- [dspfarm transcoder maximum sessions](#), on page 54
- [dspint dspfarm](#), on page 56
- [dtmf-interworking](#), on page 58
- [dtmf timer inter-digit](#), on page 60
- [dtmf-relay \(Voice over Frame Relay\)](#), on page 61
- [dtmf-relay \(Voice over IP\)](#), on page 63
- [dualtone](#), on page 67

# disable-early-media 180

To specify which call treatment, early media or local ringback, is provided for 180 responses with 180 responses with Session Description Protocol (SDP), use the **disable-early-media 180** command in sip-ua configuration mode or voice class tenant configuration mode. To enable early media cut-through for 180 messages with SDP, use the **no** form of this command.

**disable-early-media 180 system**  
**no disable-early-media 180**

<b>Syntax Description</b>	<table border="1"> <tr> <td><b>system</b></td> <td>Specifies that the disable-early-media method use the global sip-ua value. This keyword is available only for the tenant mode to allow it to fallback to the global configurations</td> </tr> </table>	<b>system</b>	Specifies that the disable-early-media method use the global sip-ua value. This keyword is available only for the tenant mode to allow it to fallback to the global configurations
<b>system</b>	Specifies that the disable-early-media method use the global sip-ua value. This keyword is available only for the tenant mode to allow it to fallback to the global configurations		

**Command Default** Early media cut-through for 180 responses with SDP is enabled.

**Command Modes** SIP UA configuration (config-sip-ua)  
 Voice class tenant configuration (config-class)

Command History	Release	Modification
	12.2(13)T	This command was introduced.
	IOS Release XE 2.5	This command was integrated into Cisco IOS XE Release 2.5.
	15.6(2)T and IOS XE Denali 16.3.1	This command was modified to include the keyword: <b>system</b> . This command is now available under voice class tenants.
	Cisco IOS XE Dublin 17.10.1a	Introduced support for YANG models.

**Usage Guidelines** This command provides the ability to enable or disable early media cut-through on Cisco IOS gateways for SIP 180 responses with SDP. Use the **disable-early-media 180** command to configure the gateway to ignore the SDP message and provide local ringback. To restore the default treatment, early media cut-through, use the **no disable-early-media 180** command.

**Examples** The following example disables early media cut-through for SIP 180 responses with SDP:

```
Router(config-sip-ua)# disable-early-media 180
```

The following example shows how to disable early media cut-through for SIP 180 responses in the voice class tenant configuration mode:

```
Router(config-class)# disable-early-media 180 system
```

Related Commands	Command	Description
	<b>show sip-ua retry</b>	Displays SIP retry statistics.
	<b>show sip-ua statistics</b>	Displays response, traffic, and retry SIP statistics.

<b>Command</b>	<b>Description</b>
<b>show sip-ua timers</b>	Displays the current settings for SIP-UA timers.
<b>sip-ua</b>	Enables the SIP-UA configuration commands.

# disable service-settings

To disable the service settings configured on a Cisco Unified Communications Manager (CUCM), use the **disable service-settings** command in phone proxy configuration mode. To enable the service settings configured on a CUCM, use the **no** form of the command.

**disable service-settings**  
**no disable service-settings**

<b>Syntax Description</b>	This command has no arguments or keywords.				
<b>Command Default</b>	The service settings on a CUCM are enabled.				
<b>Command Modes</b>	Phone proxy configuration mode (config-phone-proxy)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>15.3(3)M</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	15.3(3)M	This command was introduced.
Release	Modification				
15.3(3)M	This command was introduced.				

**Usage Guidelines** The **disable service-setting** command disables the service settings configured on a CUCM. PC Port, Gratuitous ARP, Voice VLAN access, Web access, and Span to PC Port are the services enabled by default on a CUCM.

## Example

```
Device(config)# voice-phone-proxy first-pp
Device(config-phone-proxy)# disable service-settings
```

# disc\_pi\_off

To enable an H.323 gateway to disconnect a call when it receives a disconnect message with a progress indicator (PI) value, use the **disc\_pi\_off** command in voice-port configuration mode. To restore the default state, use the **no** form of this command.

**disc\_pi\_off**  
**no disc\_pi\_off**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The gateway does not disconnect a call when it receives a disconnect message with a PI value.

**Command Modes** Voice-port configuration (config-voiceport)

Release	Modification
12.1(5)T	This command was introduced on the following platforms: Cisco 2600 series, Cisco 3600 series, Cisco 7200 series, Cisco 7500 series, Cisco AS5300, Cisco AS5800, and Cisco MC3810.
12.2(2)XA	This command was implemented on the Cisco AS5400 and Cisco AS5350.
12.2(2)XB1	This command was implemented on the Cisco AS5850.
12.2(11)T	This command was integrated into the Cisco IOS Release 12.2(11)T.

**Usage Guidelines** The **disc\_pi\_off** voice-port command is valid only if the disconnect with PI is received on the inbound call leg. For example, if this command is enabled on the voice port of the originating gateway, and a disconnect message with PI is received from the terminating switch, the disconnect message is converted to a disconnect message. But if this command is enabled on the voice port of the terminating gateway, and a disconnect message with PI is received from the terminating switch, the disconnect message is not converted to a standard disconnect message because the disconnect message is received on the outbound call leg.



**Note** The **disc\_pi\_off** voice-port configuration command is valid only for the default session application; it does not work for interactive voice response (IVR) applications.

## Examples

The following example handles a disconnect message with a PI value in the same way as a standard disconnect message for voice port 0:23:

```
voice-port 0:D
disc_pi_off
```

Command	Description
<b>isdn t306</b>	Sets a timer for disconnect messages.

# disconnect-ack

To configure a Foreign Exchange Station (FXS) voice port to return an acknowledgment upon receipt of a disconnect signal, use the **disconnect-ack** command in voice-port configuration mode. To disable the acknowledgment, use the **no** form of this command.

**disconnect-ack**  
**no disconnect-ack**

**Syntax Description** This command has no arguments or keywords.

**Command Default** FXS voice ports return an acknowledgment upon receipt of a disconnect signal

**Command Modes** Voice-port configuration (config-voiceport)

Release	Modification
11.3(1)MA	This command was introduced on the Cisco MC3810.
12.0(7)XK	This command was implemented on the Cisco 2600 series and Cisco 3600 series.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.

**Usage Guidelines** The **disconnect-ack** command configures an FXS voice port to remove line power if the equipment on an FXS loop-start trunk disconnects first.

**Examples** The following example, which begins in global configuration mode, disables the disconnect acknowledgment signal on voice port 1/1/0:

```
voice-port 1/0/0
no disconnect-ack
```

Command	Description
<b>show voice port</b>	Displays voice port configuration information.

## dnis (DNIS group)

To add a dialed number identification service (DNIS) number to a DNIS map, use the **dnis** command in DNIS-map configuration mode. To delete a DNIS number, use the no form of this command.

```
dnis telephone-number [url url]  
no dnis
```

Syntax Description	
<i>telephone-number</i>	Adds a user-selected DNIS number to a DNIS map.
<b>url</b> <i>url</i>	(Optional) URL that links a DNIS number to a specific VoiceXML document. If a URL is not entered, the DNIS number is linked to the VoiceXML application in the dial peer, which must be configured using the <b>application</b> command. This keyword is not valid for Tool Command Language (TCL) applications.

**Command Default** If no URL is entered, the DNIS number links to the VoiceXML application that is configured in the dial peer with the **application** command.

**Command Modes** DNIS-map configuration

Command History	Release	Modification
	12.2(2)XB	This command was introduced on the Cisco AS5300, Cisco AS5350, and Cisco AS5400.
	12.2(11)T	This command was implemented on the Cisco 3640 and Cisco 3660.

**Usage Guidelines**

To enter DNIS-map configuration mode for the **dnis** command, use the **voice dnis-map** command.

Enter the **dnis** command once for each telephone number that you want to map to a voice application. A separate entry must be made for each telephone number in a DNIS map. Wildcards are not supported.

URLs in DNIS entries are used only by VoiceXML applications. When an incoming called number matches a DNIS entry, it loads the VoiceXML document that is specified by the URL, provided that a VoiceXML application is configured in the dial peer with the **application** command configured.

Non-VoiceXML applications, such as TCL applications, ignore the URLs in DNIS maps and link a call to the TCL application that is configured in the dial peer using the **application** command.

For a DNIS map to be applied to an outbound dial peer, a VoiceXML application must be configured with the **application out-bound** command. Otherwise, the call is not handed off to the application that is specified in the URL of the DNIS map.

The number of allowable DNIS entries is limited by the amount of available configuration memory on the gateway. As a general rule, DNIS maps that contain more than several hundred DNIS entries should be maintained in an external text file.

To associate a DNIS map with a dial peer, use the **dnis-map** command.

## Examples

The first line in the following example shows how the **voice dnis-map** command is used to create a DNIS map named dmap1. The last two lines show how the dnis command is used to enter DNIS entries.

The first DNIS entry specifies the location of a VoiceXML document. The second DNIS entry does not specify a URL. A DNIS number without a URL is, by default, matched to the URL of the application that is configured in the dial peer by the configured application command.

```
voice dnis-map dmap1
  dnis 5550105 url tftp://blue/sky/test.vxml
  dnis 5550188
```

## Related Commands

Command	Description
<b>dnis -map</b>	Associates a DNIS map with a dial peer.
<b>show voice dnis -map</b>	Displays configuration information about DNIS maps.
<b>voice dnis -map</b>	Enters DNIS-map configuration mode to create a DNIS map.
<b>voice dnis -map load</b>	Reloads a DNIS map that has changed since the previous load.



# dnis-map

To associate a dialed number identification service (DNIS) map with a dial peer, use the **dnis-map** command in dial peer configuration mode. To remove a DNIS map from the dial peer, use the **no** form of this command.

**dnis-map** *map-name*  
**no dnis-map**

## Syntax Description

<i>map-name</i>	Name of the configured DNIS map.
-----------------	----------------------------------

## Command Default

No default behavior or values

## Command Modes

Dial peer configuration

## Command History

Release	Modification
12.2(2)XB	This command was introduced on the Cisco AS5300, Cisco AS5350, and Cisco AS5400.
12.2(11)T	This command was implemented on the Cisco 3640 and Cisco 3660.

## Usage Guidelines

A DNIS map is a table of destination numbers with optional URLs that link to specific VoiceXML documents. When configured in a dial peer, a DNIS map enables you to link multiple called numbers to a single Tool Command Language (TCL) application or to individual VoiceXML documents.

The **dnis-map** command must be used with the **application** command.

Only one DNIS map can be configured in each dial peer.

To create a DNIS map, use the **voice dnis-map** command to enter DNIS-map configuration mode, and then use the **dnis** command to add entries to the DNIS map. Or you can create an external text file of DNIS entries and link to its URL by using the **voice dnis-map** command.

To display the configuration information for DNIS maps, use the **show voice dnis-map** command.

A URL configured for a DNIS number is ignored by a TCL application; the TCL script that is configured for the application is used instead.



**Note** For a DNIS map to be applied to an outbound dial peer, the call application must be configured as an outbound application. That is, a VoiceXML application must be configured by with the **application out-bound** command. Otherwise, the call is not handed off to the application that is specified in the URL of the DNIS map.

## Examples

In the following example the DNIS map named "dmap1" is associated with the VoIP dial peer 3. The outbound application "vapptest1" is associated through this dial peer with DNIS map "dmap1."

```
dial-peer voice 3 voip
dnis-map dmap1
application vapptest1 outbound
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>dnis</b>	Adds a DNIS number to a DNIS map.
<b>show voice dnis -map</b>	Displays configuration information about DNIS maps.
<b>voice dnis -map</b>	Enters DNIS-map configuration mode to create a DNIS map.
<b>voice dnis -map load</b>	Reloads a DNIS map that has changed since the previous load.

## dns-a-override

To skip querying Domain Name System (DNS) IPv4 and IPv6 address records (A and AAAA) if a service record (SRV) query times out, use the **dns-a-override** command in voice service SIP configuration mode or voice class tenant configuration mode. To disable this functionality, use the **no** form of this command.

**dns-a-override system**

**no dns-a-override**

**Command Default** If an SRV query times out, DNS IPv4 and IPv6 records are queried.

**Command Modes** Voice service SIP configuration (conf-serv-sip)  
Voice class tenant configuration (config-class)

Command History	Release	Modification
	15.3(1)T	This command was introduced.
	15.6(2)T and IOS XE Denali 16.3.1	This command was modified to include the keyword: <b>system</b> . This command is now available under voice class tenants.

**Usage Guidelines** Use the **dns-a-override** command if you do not want the Cisco Unified Border Element (Cisco UBE) to query the A and AAAA records on the DNS server when the SRV query times out.

### Example

The following example shows how to skip querying the DNS A and AAAA records when an SRV query times out:

```
Device> enable
Device# configure terminal
Device(config)# voice service voip
Device(conf-voi-serv)# sip
Device(conf-serv-sip)# dns-a-override
```

The following example shows how to skip querying in the voice class tenant configuration mode:

```
Router(config-class)# dns-a-override system
```

## domain-name (annex G)

To set the domain name that is reported in service relationships, use the **domain name** command in annex G neighbor configuration mode. To remove the domain name, use the **no** form of this command.

**domain-name** *id*  
**no domain-name** *id*

### Syntax Description

<i>id</i>	Domain name that is reported in service relationships.
-----------	--

### Command Default

No default behavior or values

### Command Modes

Annex G neighbor configuration mode

### Command History

Release	Modification
12.2(11)T	This command was introduced.

### Usage Guidelines

Use this command to set the domain name that is reported in service relationships.

### Examples

The following example shows how to set a domain name to "boston1":

```
Router(config-annexg-neigh)# domain-name sample1
```

### Related Commands

Command	Description
<b>access-policy</b>	Requires that a neighbor be explicitly configured.

# drop-last-conferee

To define a Feature Access Code (FAC) to access the Drop Last Conferee feature in feature mode on analog phones controlled by Cisco Unified Communications Manager Express (CME), use the **drop-last-conferee** command in STC application feature-mode call-control configuration mode. To return the code to its default, use the **no** form of this command.

**drop-last-conferee** *keypad-character*  
**no drop-last-conferee**

## Syntax Description

<i>keypad-character</i>	Character string of one to four characters that can be dialed on a telephone keypad (0-9, *, #). Default is #4.
-------------------------	---

## Command Default

The default value is #4.

## Command Modes

STC application feature-mode call-control configuration (config-stcapp-fmcode)

## Command History

Release	Modification
15.0(1)M	This command was introduced.

## Usage Guidelines

This command changes the value of the FAC for the Drop Last Conferee feature from the default (#4) to the specified value.

If you attempt to configure this command with a value that is already configured for another FAC in feature mode, you receive a message. This message will not prevent you from configuring the feature code. If you configure a duplicate FAC, the system implements the first feature it matches in the order of precedence as determined by the value for each FAC (#1 to #5).

If you attempt to configure this command with a value that precludes or is precluded by another FAC in feature mode, you receive a message. If you configure a FAC to a value that precludes or is precluded by another FAC in feature mode, the system always executes the call feature with the shortest code and ignores the longer code. For example, 1 will always preclude 12 and 123. These messages will not prevent you from configuring the feature code. You must configure a new value for the precluded code in order to enable phone user access to that feature.



**Note** This command does not change the user experience for Drop Last Conferee if the Cisco call-control system is Cisco Unified Communications Manager.

## Examples

The following example shows how to change the value of the feature code for the Drop Last Conferee feature from the default (#4). With this configuration, a phone user in a three-party conference on an analog phone controlled by Cisco Unified CME presses hook flash to get the feature tone and then dials 44 to drop the last active party. The conference becomes a basic call to the second call party.

```

Router(config)# stcapp call-control mode feature
Router(config-stcapp-fmcode)# drop-last-conferee 44
Router(config-stcapp-fmcode)# exit

```

#### Related Commands

Command	Description
<b>conference</b>	Defines FAC in Feature Mode to initiate a three-party conference.
<b>hangup-last-active-call</b>	Defines FAC in feature mode to drop last active call during a three-party conference.
<b>toggle-between-two-calls</b>	Defines FAC in feature mode to toggle between two active calls.
<b>transfer</b>	Defines FAC in feature mode to connect a call to a third party that the phone user dials.

## ds0 busyout (voice)

To force a DS0 time slot on a controller into the busyout state, use the **ds0 busyout** command in controller configuration mode. To remove the DS0 time slot from the busyout state, use the **no** form of this command.

```
ds0 busyout ds0-time-slot
no ds0 busyout ds0-time-slot
```

### Syntax Description

<i>ds0 -time-slot</i>	DS0 time slots to be forced into the busyout state. Range is from 1 to 24 and can include any combination of time slots.
-----------------------	--

### Command Default

DS0 time slots are not in the busyout state.

### Command Modes

Controller configuration

### Command History

Release	Modification
12.0(7)XK	This command was introduced on the Cisco MC3810 and Cisco 2600 series and the Cisco 3600 series.
12.1(2)T	This command was integrated into Cisco IOS Release 12.1(2)T.

### Usage Guidelines

The **ds0 busyout** command affects only DS0 time slots that are configured into a DS0 group and that function as part of a digital voice port. If multiple DS0 groups are configured on a controller, any combination of DS0 time slots can be busied out, provided that each DS0 time slot to be busied out is part of a DS0 group.

If a DS0 time slot is in the busyout state, only the **no ds0 busyout** command can restore the DS0 time slot to service.

To avoid conflicting interaction of command-line interface (CLI) commands, do not use the **ds0 busyout** command and the **busyout forced** command on the same controller.

### Examples

The following example configures DS0 time slot 6 on controller T1 0 to be forced into the busyout state:

```
controller t1 0
 ds0 busyout 6
```

The following example configures DS0 time slots 1, 3, 4, 5, 6, and 24 on controller E1 1 to be forced into the busyout state:

```
controller e1 1
 ds0 busyout 1,3-6,24
```

### Related Commands

Command	Description
<b>busyout seize</b>	Changes the busyout seize procedure for a voice port.

Command	Description
<b>show running configuration</b>	Displays the contents of the currently running configuration file or the configuration for a specific class map, interface, map class, policy map, or virtual circuit (VC) class.



## ds0-group (E1)

To specify the DS0 time slots that make up a logical voice port on an E1 controller, specify the signaling type by which the router communicates with the PBX or PSTN, and define E1 channels for compressed voice calls and the channel-associated signaling (CAS) method by which the router connects to the PBX or PSTN, use the **ds0-group** command in controller configuration mode. To remove the group and signaling setting, use the **no** form of this command.

### Cisco IOS Release 12.2 and Later Releases-Cisco 1750 and Cisco 1751

```
ds0-group ds0-group-number timeslots timeslot-list {service service-type} [type e&m-fgb | e&m-fgd
| e&m-immediate-start | fgd-eana | fgd-os | fxs-ground-start | fxs-loop-start | none | r1-itu | r1-modified
| r1-turkey]}
no ds0-group ds0-group-number
```

### Cisco IOS Release 12.1 and Earlier Releases- Cisco 1750 and Cisco 1751

```
ds0-group ds0-group-number timeslots timeslot-list {[service service-type]} [type e&m-fgb | e&m-fgd
| em-immediate-start | fgd-eana | fgd-os | fxs-ground-start | fxs-loop-start | none | r1-itu | r1-modified |
r1-turkey | sas-ground-start | sas-loop-start]}
no ds0-group ds0-group-number
```

### Cisco 2600 Series (Except Cisco 2691), Cisco 3600 Series (Except Cisco 3660)

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial | e&m-immediate-start |
e&m-melcas-delay | e&m-melcas-immed | e&m-melcas-wink | e&m-wink-start | ext-sig | fgd-eana |
fxo-ground-start | fxo-loop-start | fxo-melcas | fxs-ground-start | fxs-loop-start | fxs-melcas | r2-analog
| r2-digital | r2-pulse}
no ds0-group ds0-group-number
```

### Cisco 2691, Cisco 2600XM Series, Cisco 2800 Series (Except Cisco 2801), Cisco 3660, Cisco 3700 Series, Cisco 3800 Series

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial | e&m-immediate-start |
e&m-lmr | e&m-melcas-delay | e&m-melcas-immed | e&m-melcas-wink | e&m-wink-start | ext-sig |
fgd-eana | fxo-ground-start | fxo-loop-start | fxo-melcas | fxs-ground-start | fxs-loop-start | fxs-melcas |
r2-analog | r2-digital | r2-pulse}
no ds0-group ds0-group-number
```

### Cisco 7200 Series and Cisco 7500 Series Voice Ports

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial | e&m-fgd |
e&m-immediate-start | e&m-wink-start | fxo-ground-start | fxo-loop-start | fxs-ground-start |
fxs-loop-start}
no ds0-group ds0-group-number
```

### Cisco 7700 Series Voice Ports

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial | e&m-immediate-start |
e&m-wink-start | fxs-ground-start | fxs-loop-start | fxo-ground-start | fxo-loop-start}
no ds0-group ds0-group-number
```

### Cisco AS5300 and Cisco AS5400

```
ds0-group ds0-group-number timeslots timeslot-list type {none | p7 | r2-analog | r2-digital |
r2-lsv181-digital | r2-pulse}
```

**no ds0-group** *ds0-group-number*

### Syntax Description

<i>ds0</i> <i>-group-number</i>	A value that identifies the DS0 group. Range is from 0 to 14 and 16 to 30; 15 is reserved.
<b>timeslots</b> <i>timeslot -list</i>	Lists time slots in the DS0 group. The <i>timeslot-list</i> argument is a single time-slot number, a single range of numbers, or multiple ranges of numbers separated by commas. Range is from 1 through 31. Examples are as follows: <ul style="list-style-type: none"> <li>• 2</li> <li>• 1-15,17-24</li> <li>• 1-23</li> <li>• 2,4,6-12</li> </ul>
<b>type</b>	Specifies the type of signaling for the DS0 group. The signaling method selection for the type keyword depends on the connection that you are making. The ear and mouth (E&M) interface allows connection for PBX trunk lines (tie lines) and telephone equipment. The Foreign Exchange Station (FXS) interface allows connection of basic telephone equipment and a PBX. The Foreign Exchange Office (FXO) interface is for connecting the central office (CO) to a standard PBX interface where permitted by local regulations; it is often used for off-premise extensions (OPXs). Types are as follows: <ul style="list-style-type: none"> <li>• <b>e&amp;m -delay-dial</b>--The originating endpoint sends an off-hook signal and then waits for an off-hook signal followed by an on-hook signal from the destination.</li> <li>• <b>e&amp;m-fgb</b>--E&amp;M Type II Feature Group B.</li> <li>• <b>e&amp;m-fgd</b>--E&amp;M Type II Feature Group D.</li> <li>• <b>e&amp;m -immediate-start</b>--E&amp;M immediate start.</li> <li>• <b>e&amp;m-lmr</b> --E&amp;M Land Mobile Radio (LMR).</li> <li>• <b>e&amp;m -melcas-delay</b>--E&amp;M MELCAS delay-start signaling support.</li> <li>• <b>e&amp;m -melcas-immed</b>--E&amp;M MELCAS immediate-start signaling support.</li> </ul>

	<ul style="list-style-type: none"> <li>• <b>e&amp;m -melcas-wink</b>--E&amp;M MELCAS wink-start signaling support.</li> <li>• <b>e&amp;m -wink-start</b>--The originating endpoint sends an off-hook signal and waits for a wink-start from the destination.</li> <li>• <b>fgd -eana</b>--<b>Feature Group D exchange access North American.</b></li> <li>• fgd-os--Feature Group D operator services.</li> <li>• <b>fxo -ground-start</b>--<b>FXO ground-start signaling.</b></li> <li>• <b>fxo -loop-start</b>--<b>FXO loop-start signaling.</b></li> <li>• <b>fxo -melcas</b>--<b>FXO MELCAS signaling.</b></li> <li>• <b>fxs -ground-start</b>--<b>FXS ground-start signaling.</b></li> <li>• <b>fxs -loop-start</b>--<b>FXS loop-start signaling.</b></li> <li>• <b>fxs -melcas</b>--<b>FXS MELCAS signaling.</b></li> <li>• <b>none</b> --Null signaling for external call control.</li> <li>• p7--Specifies the p7 switch type.</li> <li>• r1-itu--Line signaling based on international signaling standards.</li> <li>• r1-modified--An international signaling standard that is common to channelized T1/E1 networks.</li> <li>• <b>r1 -turkey</b>--A signaling standard used in Turkey.</li> <li>• <b>r2 -analog</b>--<b>R2 analog line signaling.</b></li> <li>• <b>r2 -digital</b>--<b>R2 digital line signaling.</b></li> <li>• r2-lsv181-digital--Specifies a specific R2 digital line.</li> <li>• <b>r2 -pulse</b>--<b>7-pulse line signaling, a transmitted pulse that indicates a change in the line state.</b></li> <li>• <b>sas-ground-start</b> --<b>Single attachment station (SAS) ground-start.</b></li> <li>• <b>sas-loop-start</b> --<b>SAS loop-start.</b></li> </ul>
<p><b>service</b> <i>service -type</i></p>	<p>(Optional) Specifies the type of service</p> <ul style="list-style-type: none"> <li>• <b>data</b> --data service</li> <li>• <b>fax</b> -- store-and-forward fax service</li> <li>• <b>voice</b> --voice service (for FGD-OS service)</li> <li>• <b>mgcp</b> --Media Gateway Control Protocol (MGCP) service</li> </ul>

**Command Default**

There is no DS0 group. Calls are allowed in both directions.

**Command Modes**

Controller configuration (config-controller)

## Command History

Release	Modification
11.2	This command was introduced for the Cisco AS5300 as the <b>cas-group</b> command.
11.3(1)MA	The command was introduced as the voice-group command for the Cisco MC3810.
12.0(1)T	This command was integrated into Cisco IOS Release 12.0(1)T, and the cas-group command was implemented on the Cisco 3600 series routers.
12.0(5)T	The command was renamed ds0-group on the Cisco AS5300 and Cisco 2600 series and Cisco 3600 series routers. Some keyword modifications were implemented.
12.0(5)XE	This command was implemented on the Cisco 7200 series.
12.0(7)XK	Support for this command was implemented on the Cisco MC3810. When the ds0-group command became available on the Cisco MC3810, the voice-group command was removed and no longer supported.
12.0(7)XR	The mgcp service type was added.
12.1(2)XH	The e&m-fgd and fgd-eana keywords were added for Feature Group D signaling.
12.1(5)XM	The <b>sgcp</b> keyword was removed.
12.1(3)T	This command was modified for Cisco 7500 series routers. The fgd-os signaling type and the voice service type were added.
12.2	The command was modified to exclude sas keywords. The Single Attachment Station (SAS) CAS options of sas-loop-start and sas-ground-start are not supported as a type of signaling for the DS0 group.
12.2(2)XA	This command was implemented on the Cisco AS5300.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T and implemented on the Cisco 7200 series.
12.2(4)T	Support for the Cisco AS5300, Cisco AS5350, and Cisco AS5400 is not included in this release.
12.2(2)XB1	This command was implemented on the Cisco AS5850.
12.2(4)XM	This command was implemented on Cisco 1750 and Cisco 1751 routers. Support for other Cisco platforms is not included in this release.
12.2(2)XN	Support for the <b>mgcp</b> keyword was added to Cisco CallManager Version 3.1 for the Cisco 2600 series, Cisco 3600 series, and Cisco VG200.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T and implemented on the Cisco 7200 series. Support for the Cisco AS5300, Cisco AS5350, Cisco AS5400, and Cisco AS5850 is not included in this release.
12.2(11)T	This command was supported with Cisco IOS Release 12.2(11)T and Cisco CallManager Version 3.2. This command is supported on the Cisco IAD2420 series, Cisco AS5300, Cisco AS5350, Cisco AS5400, Cisco AS5850 in this release.

Release	Modification
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T. The Cisco 1750 and Cisco 1751 do not support T1 and E1 voice and data cards in Cisco IOS Release 12.2(13)T. The Cisco 17xx platforms can support only HC DSP firmware images in this release.
12.3(8)T	Documentation of the <b>ds0-group</b> command was divided into the individual <b>ds0-group (E1)</b> and <b>ds0-group (T1)</b> commands.
12.4(2)T1	Support was added for the <b>e&amp;m-lmr</b> signaling type on the Cisco 2691, Cisco 2600XM series, Cisco 2800 series (except Cisco 2801), Cisco 3660, Cisco 3700 series, and Cisco 3800 series.

### Usage Guidelines

The **ds0-group** command automatically creates a logical voice port that is numbered as follows:



**Note** This command does not support the extended echo canceller (EC) feature on the Cisco AS5x00 series.

Although only one voice port is created for each group, applicable calls are routed to any channel in the group.

Be sure you take the following into account when you are configuring DS0 groups:

- Channel groups, CAS voice groups, DS0 groups, and time-division multiplexing (TDM) groups all use group numbers. All group numbers configured for channel groups, CAS voice groups, DS0 groups, and TDM groups must be unique on the local router. For example, you cannot use the same group number for a channel group and for a TDM group.
- The keywords available for the **ds0-group** command are dependent upon the Cisco IOS software release that you are using. For the most current information, go to the Cisco Feature Navigator home page at the following URL: <http://www.cisco.com/go/fn>
- When you are using command-line interface (CLI) help, the keywords for the **ds0-group** command are configuration specific. For example, if MGCP is configured, you see the **mgcp** keyword. If you are not using MGCP, you do not see the **mgcp** keyword.
- Cisco IOS Releases later than 12.2 do not support the Single Attachment Station (SAS) CAS options of **sas-loop-start** and **sas-ground-start**.

### Examples

The following example shows ranges of E1 controller time slots configured for FXS ground-start and FXO loop-start signaling:

```
E1 1/0
 framing esf
 linecode b8zs
 ds0-group 1 timeslots 1-10 type fxs-ground-start
 ds0-group 2 timeslots 11-24 type fxo-loop-start
```

The following example shows ranges of T1 controller time slots configured for FXS ground-start signaling:

```
controller E1 1/0
 ds0-group 1 timeslots 1-4 type fxs-ground-start
```

The following example illustrates setting the E1 channels for Signaling System 7 (SS7) service on any trunking gateway using the **mgcp** keyword:

```
Router(config-controller)# ds0-group 0 timeslots 1-24 type none service mgcp
```

In the following example, the time slot maximum is 12 and the time slot is 1, so two voice-ports are created successfully.

```
controller E1 0/0
 ds0-group 0 timeslots 1-4 type e&m-immediate-start
 ds0-group 1 timeslots 6-12 type e&m-immediate-start
```

If a third DS0 group is added, the voice-port is rejected even though the total number of voice channels is fewer than 16.

```
ds0-group 2 timeslots 17-18 type e&m-immediate-start
```

In the following example, the signaling type is set to E&M-LMR:

```
ds0-group 0 timeslots 1-10 type e&m-lmr
```

#### Related Commands

Command	Description
<b>cas-group</b>	Configures channelized T1 time slots with robbed bit signaling.
<b>codec</b>	Specifies the voice coder rate of speech for a dial peer.
<b>codec complexity</b>	Specifies call density and codec complexity based on the codec standard that you are using.

## ds0-group (T1)

To specify the DS0 time slots that make up a logical voice port on a T1 controller, to specify the signaling type by which the router communicates with the PBX or PSTN, and to define T1 channels for compressed voice calls and the channel-associated signaling (CAS) method by which the router connects to the PBX or PSTN, use the **ds0-group** command in controller configuration mode. To remove the group and signaling setting, use the **no** form of this command.

### Cisco IOS Release 12.2 and Later Releases- Cisco 1750 and Cisco 1751

```
ds0-group ds0-group-number timeslots timeslot-list [service service-type] type {e&m-fgb|e&m-fgd
|e&m-immediate-start|fgd-eana|fgd-os|fxs-ground-start|fxs-loop-start|none|r1-itu|r1-modified
|r1-turkey}
no ds0-group ds0-group-number
```

### Cisco IOS Release 12.1 and Earlier Releases - Cisco 1750 and Cisco 1751

```
ds0-group ds0-group-number timeslots timeslot-list [service service-type] type {e&m-fgb|e&m-fgd
|e&m-immediate-start|fgd-eana|fgd-os|fxs-ground-start|fxs-loop-start|none|r1-itu|r1-modified
|r1-turkey|sas-ground-start|sas-loop-start}
no ds0-group ds0-group-number
```

### Cisco 2600 Series (Except Cisco 2691), Cisco 3600 Series (Except Cisco 3660), and Cisco VG 200

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial|em-fgd|
e&m-immediate-start|e&m-wink-start|ext-sig|fgd-eana|fxo-ground-start|fxo-loop-start|
fxs-ground-start|fxs-loop-start}
no ds0-group ds0-group-number
```

### Cisco 2691, Cisco 2600XM Series, Cisco 2800 Series (Except Cisco 2801), Cisco 3660, Cisco 3700 Series, Cisco 3800 Series

```
ds0-group ds0-group-number timeslots timeslot-list type {em-delay-dial|em-fgd|
e&m-immediate-start|e&m-lmr|e&m-wink-start|ext-sig|fgd-eana|fgd-emf [mf] [ani-pani] [ani]
|fxo-ground-start|fxo-loop-start|fxs-ground-start|fxs-loop-start}
no ds0-group ds0-group-number
```

### Cisco 7200 Series and Cisco 7500 Series

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial|e&m-fgd|
e&m-immediate-start|e&m-wink-start|fxo-ground-start|fxo-loop-start|fxs-ground-start|
fxs-loop-start}
no ds0-group ds0-group-number
```

### Cisco 7700 Series Voice Ports

```
ds0-group ds0-group-number timeslots timeslot-list type {e&m-delay-dial|e&m-immediate-start|
e&m-wink-start|fxo-ground-start|fxo-loop-start|fxs-ground-start|fxs-loop-start}
no ds0-group ds0-group-number
```

### Cisco IOS Release 12.2 and Later Releases for Cisco AS5300, Cisco AS5350, and Cisco AS5400

```
ds0-group ds0-group-number timeslots timeslot-list [service service-type] [type e&m-fgd [dtmf|
mf [dnis|ani-dnis [info-digits-no-strip]|fgd-emf [ani-pani] [ani]|service service-type]|
e&m-immediate-start|fxs-ground-start|fxs-loop-start|fgd-eana [ani-dnis|mf]|fgd-os [dnis-ani|
mf]|none]]
```

**no ds0-group** *ds0-group-number*

#### Cisco AS5850

**ds0-group** *ds0-group-number* **timeslots** *timeslot-list* [**service** *service-type*] [**type** **e&m-fgd** [**dtmf** | **mf** [**dnis** | **ani-dnis** [**info-digits-no-strip**] | **fgd-emf** [**ani-pani**] [**ani**] | **service** *service-type*] | **e&m-immediate-start** | **fxs-ground-start** | **fxs-loop-start** | **fgd-eana** [**ani-dnis** | **mf**] | **fgd-os** [**dnis-ani** | **mf**] | **r1-itu** [**dnis**] | **none**]]

**no ds0-group** *ds0-group-number*

#### Cisco IOS Release 12.1 and Earlier Releases - Cisco AS5300, Cisco AS5350, and Cisco AS5400

**ds0-group** *ds0-group-number* **timeslots** *timeslot-list* [**service** *service-type*] [**type** **e&m-fgd** [**dtmf** | **mf** [**dnis** | **ani-dnis** [**info-digits-no-strip**] | **fgd-emf** [**ani-pani**] [**ani**] | **service** *service-type*] | **e&m-immediate-start** | **fxs-ground-start** | **fxs-loop-start** | **fgd-eana** [**ani-dnis** | **mf**] | **fgd-os** [**dnis-ani** | **mf**] | **sas-ground-start** | **sas-loop-start** | **none**]]

**no ds0-group** *ds0-group-number*

#### Cisco AS5850

**ds0-group** *ds0-group-number* **timeslots** *timeslot-list* [**service** *service-type*] [**type** **e&m-fgd** [**dtmf** | **mf** [**dnis** | **ani-dnis** [**info-digits-no-strip**] | **fgd-emf** [**ani-pani**] [**ani**] | **service** *service-type*] | **e&m-immediate-start** | **fxs-ground-start** | **fxs-loop-start** | **fgd-eana** [**ani-dnis** | **mf**] | **fgd-os** [**dnis-ani** | **mf**] | **sas-ground-start** | **sas-loop-start** | **none**]]

**no ds0-group** *ds0-group-number*

### Syntax Description

<i>ds0-group-number</i>	A value that identifies the DS0 group. Range is from 0 to 23.
<b>timeslots</b> <i>timeslot-list</i>	Lists time slots in the DS0 group. The <i>timeslot-list</i> argument is a single time-slot number, a single range of numbers, or multiple ranges of numbers separated by commas. Range is from 1 to 24. Examples are as follows: <ul style="list-style-type: none"> <li>• 2</li> <li>• 1-15,17-24</li> <li>• 1-23</li> <li>• 2,4,6-12</li> </ul>



<p><b>typenone</b></p>	<p>Specifies the type of signaling for the DS0 group. The signaling method selection for the type keyword depends on the connection that you are making. The ear and mouth (E&amp;M) interface allows connection for PBX trunk lines (tie lines) and telephone equipment. The Foreign Exchange Station (FXS) interface allows connection of basic telephone equipment and a PBX interface. The Foreign Exchange Office (FXO) interface is for connecting the central office (CO) to a standard PBX interface where permitted by local regulations; it is often used for off-premise extensions (OPXs). Types are as follows:</p> <ul style="list-style-type: none"> <li>• <b>e&amp;m-delay-dial</b> --The originating endpoint sends an off-hook signal and then waits for an off-hook signal followed by an on-hook signal from the destination.</li> <li>• <b>e&amp;m-fgb</b> --E&amp;M Type II Feature Group B.</li> <li>• <b>e&amp;m-fgd</b> --E&amp;M Type II Feature Group D.</li> <li>• <b>e&amp;m-immediate-start</b> --E&amp;M immediate start.</li> <li>• <b>e&amp;m-lmr</b> --E&amp;M Land Mobile Radio (LMR).</li> <li>• <b>e&amp;m-wink-start</b> --The originating endpoint sends an off-hook signal and waits for a wink-start from the destination.</li> <li>• <b>ext-sig</b> --The external signaling interface specifies that the signaling traffic comes from an outside source.</li> <li>• <b>fgd-eana</b> --<b>Feature Group D exchange access North American.</b></li> <li>• <b>fgd-emf</b>-- FGD Enhanced MF.</li> <li>• <b>fgd-os</b> --Feature Group D operator services.</li> <li>• <b>fxo-ground-start</b> --<b>FXO ground-start signaling.</b></li> <li>• <b>fxo-loop-start</b> --<b>FXO loop-start signaling.</b></li> <li>• <b>fxs-ground-start</b> --<b>FXS ground-start signaling.</b></li> <li>• <b>fxs-loop-start</b> --<b>FXS loop-start signaling.</b></li> <li>• <b>none</b> --Null signaling for external call control.</li> <li>• <b>r1-itu</b> --Line signaling based on international signaling standards. (This signaling type is not supported on the Cisco AS5300, Cisco AS5350, and Cisco AS5400 platforms.)</li> <li>• <b>r1-modified</b> --An international signaling standard that is common to channelized T1/E1 networks.</li> </ul>
	<ul style="list-style-type: none"> <li>• <b>r1-turkey</b> --A signaling standard used in Turkey.</li> <li>• <b>sas-ground-start</b> --Single attachment station (SAS) ground-start.</li> <li>• <b>sas-loop-start</b> --SAS loop-start.</li> </ul>

<b>service</b> <i>service</i> <i>-type</i>	(Optional) Specifies the type of service: <ul style="list-style-type: none"> <li>• <b>data</b> --Data service.</li> <li>• <b>fax</b> -- Store-and-forward fax service.</li> <li>• <b>mgcp</b> --Media Gateway Control Protocol (MGCP) service. Used only with the type none keywords on the Cisco AS5x00 platforms.</li> <li>• <b>sccp</b> --Simple Gateway Control Protocol (SCCP) service.</li> <li>• <b>voice</b> --Voice service (for FGD-OS service).</li> </ul>
<b>dtmf</b>	(Optional) Specifies dual tone multifrequency (DTMF) tone signaling.
<b>mf</b>	(Optional) Specifies multifrequency (MF) tone signaling
<b>ani</b>	(Optional) Provisions ANI address information.
<b>ani-dnis</b>	(Optional) Specifies automatic number identification (ANI) and dialed number identification service (DNIS) address information provisioning for FGD OS.
<b>ani-pani</b>	(Optional) Provisions ANI and PANI address information.
<b>dnis-ani</b>	(Optional) Specifies ANI and DNIS address information provisioning for FGD EANA.
<b>dnis</b>	(Optional) Specifies DNIS address information provisioning.
<b>info-digits-no-strip</b>	(Optional) Retains information digits on the Cisco AS5x00 platforms.

**Command Default**

There is no DS0 group. Calls are allowed in both directions.

**Command Modes**

Controller configuration

**Command History**

Release	Modification
11.2	This command was introduced for the Cisco AS5300 as the <b>cas-group</b> command.
11.3(1)MA	The command was introduced as the <b>voice-group</b> command for the Cisco MC3810.
12.0(1)T	This command was integrated into Cisco IOS Release 12.0(1)T, and the <b>cas-group</b> command was implemented on the Cisco 3600 series routers.
12.0(5)T	The command was renamed <b>ds0-group</b> on the Cisco AS5300 and Cisco 2600 series and Cisco 3600 series routers. Some keyword modifications were implemented.
12.0(5)XE	This command was implemented on the Cisco 7200 series.
12.0(7)XK	Support for this command was implemented on the Cisco MC3810. When the <b>ds0-group</b> command became available on the Cisco MC3810, the <b>voice-group</b> command was removed and no longer supported. The <b>ext-sig</b> keyword replaced the <b>ext-sig-master</b> and <b>ext-sig-slave</b> keywords that were available with the <b>voice-group</b> command.
12.0(7)XR	The <b>mgcp</b> service type was added.

Release	Modification
12.1(2)XH	The <b>e&amp;m-fgd</b> and <b>fgd-eana</b> keywords were added for Feature Group D signaling.
12.1(5)XM	The <b>sgcp</b> keyword was removed.
12.1(3)T	This command was modified for Cisco 7500 series routers. The <b>fgd-os</b> signaling type and the <b>voice</b> service type were added.
12.2(2)XA	This command was implemented on the Cisco AS5300.
12.2	The command was modified to exclude sas keywords. The Single Attachment Station (SAS) CAS options of sas-loop-start and sas-ground-start are not supported as a type of signaling for the DS0 group.
12.2(2)T	This command was integrated into Cisco IOS Release 12.2(2)T and implemented on the Cisco 7200 series.
12.2(4)T	Support for the Cisco AS5300, Cisco AS5350, and Cisco AS5400 is not included in this release.
12.2(2)XB1	This command was implemented on the Cisco AS5850.
12.2(4)XM	This command was implemented on Cisco 1750 and Cisco 1751 routers. Support for other Cisco platforms is not included in this release.
12.2(2)XN	Support for the <b>mgcp</b> keyword was added to Cisco CallManager Version 3.1 for the Cisco 2600 series, Cisco 3600 series, and Cisco VG200.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T and implemented on the Cisco 7200 series. Support for the Cisco AS5300, Cisco AS5350, Cisco AS5400, and Cisco AS5850 is not included in this release.
12.2(11)T	This command was supported in Cisco IOS Release 12.2(11)T and Cisco CallManager Version 3.2. This command is supported on the Cisco IAD2420 series, Cisco AS5300, Cisco AS5350, Cisco AS5400, Cisco AS5850 in this release.
12.2(13)T	This command was integrated into Cisco IOS Release 12.2(13)T. The Cisco 1750 and Cisco 1751 do not support T1 and E1 voice and data cards in Cisco IOS Release 12.2(13)T. The Cisco 17xx platforms can support only HC DSP firmware images in this release.
12.2(15)T	This command was implemented on the Cisco 2600XM, Cisco 3725, and Cisco 3745.
12.3(4)XD	This command was modified for the Cisco 3725 and Cisco 3745. The <b>e&amp;m-lmr</b> signaling type was added.
12.3(7)T	This command was integrated into Cisco IOS Release 12.3(7)T.
12.3(8)T	Documentation of the <b>ds0-group</b> command was divided into the individual <b>ds0-group(E1)</b> and <b>ds0-group(T1)</b> commands.
12.3(10)	The <b>info-digits-no-strip</b> keyword was added for use on the Cisco AS5x00 platforms.
12.4(9)T	This command was integrated into Cisco IOS Release 12.4(9)T. The <b>fgd-emf</b> , <b>ani-pani</b> , and <b>ani</b> keywords were added for the Cisco 2800 and Cisco AS5x00 platforms.

**Usage Guidelines**

The **ds0-group** command automatically creates a logical voice port that is numbered as follows:

- Cisco 2600 series, Cisco 2600XM, Cisco 3660, Cisco 3725, Cisco 3745, and Cisco 7200 series:
  - *slot/port : ds0-group-number*
- Cisco AS5300, Cisco AS5350, and Cisco AS5400 with a T1 controller:
  - *slot/port*
- Cisco AS5850 with a T1 controller:
  - *slot/port : ds0-group-number*

Although only one voice port is created for each group, applicable calls are routed to any channel in the group.

Be sure that you take the following into account when you are configuring DS0 groups:

- Channel groups, CAS voice groups, DS0 groups, and time-division multiplexing (TDM) groups all use group numbers. All group numbers configured for channel groups, CAS voice groups, DS0 groups, and TDM groups must be unique on the local router. For example, you cannot use the same group number for a channel group and for a TDM group.
- The keywords available for the **ds0-group** command are dependent upon the Cisco IOS software release that you are using. For the most current information, go to the Cisco Feature Navigator home page at the following URL:

<http://www.cisco.com/go/fn>

- When you are using command-line interface (CLI) help, the keywords for the **ds0-group** command are configuration specific. For example, if MGCP is configured, you see the **mgcp** keyword. If you are not using MGCP, you do not see the **mgcp** keyword.




---

**Note** This command does not support the extended echo canceller (EC) feature on the Cisco AS5x00 series.

---




---

**Note** The signaling type R1-ITU is not supported on the Cisco AS5300, Cisco AS5350, and Cisco AS5400 platforms.

---

**Examples**

The following example shows ranges of T1 controller time slots configured for FXS ground-start and FXO loop-start signaling:

```
controller T1 1/0
 framing esf
 linecode b8zs
 ds0-group 1 timeslots 1-10 type fxs-ground-start
 ds0-group 2 timeslots 11-24 type fxo-loop-start
```

The following example shows ranges of T1 controller time slots configured for FXS ground-start signaling:

```
controller T1 1/0
 ds0-group 1 timeslots 1-4 type fxs-ground-start
```

The following example illustrates setting the T1 channels for Signaling System 7 (SS7) service on any trunking gateway using the **mgcp** keyword:

```
ds0-group 0 timeslots 1-24 service mgcp type none
```

In the following example, the time slot maximum is 12 and the time slot is 1, so two voice ports are created successfully:

```
controller T1 0/0
 ds0-group 0 timeslots 1-4 type e&m-immediate-start
 ds0-group 1 timeslots 6-12 type e&m-immediate-start
```

If a third DS0 group is added, the voice port is rejected even though the total number of voice channels is fewer than 16.

```
ds0-group 2 timeslots 17-18 type e&m-immediate-start
```

In the following example, the signaling type is set to E&M LMR:

```
ds0-group 0 timeslots 1-10 type e&m-lmr
```

You have the option to retain info digits when you are configuring E&M Type II Feature Group D with MF signaling and ANI/DNIS for calls being sent over IP. Info digits denote the subscriber type, and the **info-digits** keyword prepends info digits to the calling number.

On inbound calls from a T1 FGD voice-port with MF ANI/DNIS, when ANI information is obtained, it is passed unaltered to the next matching dial peer, either POTS or VoIP. The addition of the **info-digits-no-strip** keyword allows you to retain the info digits portion of the ANI information; the modified ANI is then passed to the next matching dial peer. Ordinarily, info digits are not valid for calls going over IP and are, therefore, stripped off. The ability to retain info digits is particularly useful for calls that are not leaving the PSTN network and are just being hairpinned back.

In the following example, the E&M Type II Feature Group D is configured with MF signaling and ANI/DNIS over IP while retaining info digits:

```
ds0-group 0 timeslots 1-24 type e&m-fgd mf ani-dnis info-digits-no-strip
```

The following example enables FGD EMF:

```
ds0-group 11 timeslots 11 type fgd-emf ani
 ds0-group 11 timeslots 11 type fgd-emf ani-pani
```

**Related Commands**

Command	Description
<b>cas-group</b>	Configures channelized T1 time slots with robbed bit signaling.
<b>codec</b>	Specifies the voice coder rate of speech for a dial peer.
<b>codec complexity</b>	Specifies call density and codec complexity based on the codec standard that you are using.

# ds0-num

To add B-channel information in outgoing Session Initiation Protocol (SIP) messages, use the **ds0-num** command in SIP voice service configuration mode. To return to the default setting, use the **no** form of this command.

**ds0-num**  
**no ds0-num**

**Syntax Description** This command has no arguments or keywords.

**Command Default** B channel information is disabled.

**Command Modes** SIP voice service configuration (conf-serv-sip)

Release	Modification
12.3(7)T	This command was introduced.

**Usage Guidelines** This command enables the SIP application to receive B-channel information of incoming ISDN calls. The B-channel information appears in the Via header of an Invite request. Information acquired from the Via header can be used during call transfer or to route a call.

**Examples** The following example adds B-channel information to outgoing SIP messages:

```
Router(config)# voice service voip
Router(conf-voi-serv)# sip
Router(conf-serv-sip)# ds0-num
```

Command	Description
<b>sip</b>	Enables SIP voice service configuration commands.
<b>voice service voip</b>	Specifies the voice encapsulation type as VoIP.

## dscp media

To specify the resource priority header (RPH) to differentiated services code point (DSCP) mapping, use the **dscp media** command in voice class configuration mode. To disable the configuration, use the **no** form of this command.

```
dscp media {audio | video} {flah-override-override | flash-override | flsh | immediate | priority |
routine} {dscp-valueset-afset-cs | ef | zero}
no dscp media {audio | video} {flah-override-override | flash-override | flsh | immediate | priority |
routine} {dscp-valueset-afset-cs | ef | zero}
```

### Syntax Description

<b>audio</b>	Applies DSCP to audio payload packets.
<b>video</b>	Applies DSCP to video payload packets.
<b>flah-override-override</b>	Applies flash-override-override RPH priority.
<b>flash-override</b>	Applies flash-override RPH priority.
<b>flsh</b>	Applies flash RPH priority.
<b>immediate</b>	Applies immediate RPH priority.
<b>priority</b>	Applies priority RPH priority.
<b>routine</b>	Applies routine RPH priority.
<i>dscp-value</i>	DSCP value. Valid values are from 0 to 63.

<i>set-af</i>	<p>An assured forwarding bit pattern as the DSCP value:</p> <ul style="list-style-type: none"> <li>• <b>af11</b> —bit pattern 001010</li> <li>• <b>af12</b> —bit pattern 001100</li> <li>• <b>af13</b> —bit pattern 001110</li> <li>• <b>af21</b> —bit pattern 010010</li> <li>• <b>af22</b> —bit pattern 010100</li> <li>• <b>af23</b> —bit pattern 010110</li> <li>• <b>af31</b> —bit pattern 011010</li> <li>• <b>af32</b> —bit pattern 011100</li> <li>• <b>af33</b> —bit pattern 011110</li> <li>• <b>af41</b> —bit pattern 100010</li> <li>• <b>af42</b> —bit pattern 100100</li> <li>• <b>af43</b> —bit pattern 100110</li> </ul>
<i>set-cs</i>	<p>Class-selector code point as the DSCP value:</p> <ul style="list-style-type: none"> <li>• <b>cs1</b> —code point 1 (precedence 1)</li> <li>• <b>cs2</b> —code point 2 (precedence 2)</li> <li>• <b>cs3</b> —code point 3 (precedence 3)</li> <li>• <b>cs4</b> —code point 4 (precedence 4)</li> <li>• <b>cs5</b> —code point 5 (precedence 5)</li> <li>• <b>cs6</b> —code point 6 (precedence 6)</li> <li>• <b>cs7</b> —code point 7 (precedence 7)</li> </ul>
<b>ef</b>	<p>Specifies the expedited forwarding bit pattern 101110 as the DSCP value.</p>
<b>zero</b>	<p>Specifies the default bit pattern 000000 as the DSCP value.</p>



**Command Default** See the Usage Guidelines section.

**Command Modes** Voice class configuration (config-class)

Release	Modification
15.2(2)T	This command was introduced.

**Usage Guidelines** You can use the **dscp media** command to configure RPH to DSCP mapping for audio and video calls. The following table lists the default values for the **dscp media** command:

Granular Service Class	Priority or Precedence	DSCP Base10 Value	DSCP Binary Value
Voice	Audio Call	46	101110
	Flash	43	101011
	Flash Override	41	101001
	Flash Override Override	40	101000
	Immediate	45	101101
	Priority	47	101111
	Routine	49	110001
Video	Flash Override	33	100001
	Flash	35	100011
	Flash Override Override	32	100000
	Immediate	37	100101
	Priority	39	100111
	Routine	51	110011
	Video Call	34	100111

### Examples

The following example shows how to specify RPH to DSCP mapping after you configure the DSCP profile:

```
Router> enable
Router# configure terminal
Router(config)# voice class dscp-profile 1
Router(config-class)# dscp media audio routine ef
```

---

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>syslog violation</b>	Specifies the action that needs to be performed on any violation in the DSCP policy.

# dscp-profile

To apply a differentiated services code point (DSCP) profile globally, use the **dscp-profile** command in voice service SIP configuration mode or voice class tenant configuration mode. To disable the configuration, use the **no** form of this command.

**dscp-profile** *tag*  
**no dscp-profile**

<b>Syntax Description</b>	<i>tag</i> DSCP profile tag. The range is from 1 to 10000.
---------------------------	--

**Command Default** A DSCP profile is not applied.

**Command Modes** Voice service SIP configuration (conf-serv-sip)  
 Voice class tenant configuration (config-class)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	15.2(2)T	This command was introduced.
	15.6(2)T and IOS XE Denali 16.3.1	This command is now available under voice class tenants.

**Usage Guidelines** You can use the **dscp-profile** command to apply a DSCP profile that is configured using the **dscp media** command at the global level.

**Examples** The following example shows how to configure a DSCP profile at the global level:

```
Router> enable
Router# configure terminal
Router(config)# voice service voip
Router(conf-voi-serv)# sip
Router(conf-serv-sip)# dscp-profile 1
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>dscp media</b>	Specifies the RPH to DSCP mapping.
	<b>voice service voip</b>	Enters voice service configuration mode.
	<b>sip</b>	Enters service SIP configuration mode.

# dsn

To specify that a delivery status notice (DSN) be delivered to the sender, use the **dsn** command in dial-peer configuration mode. To cancel a specific DSN option, use the **no** form of this command.

```
dsn {delay | failure | success}
no dsn {delay | failure | success}
```

## Syntax Description

<b>delay</b>	Defines the delay for each mailer.
<b>failure</b>	Requests that a failed message be sent to the FROM address. This is the default.
<b>success</b>	Requests that a message be sent to the FROM address saying that the mail message was delivered successfully to the recipient.

## Command Default

The default is to send a nondelivery message in the event of a failure.

## Command Modes

Dial peer configuration

## Command History

Release	Modification
12.0(4)XJ	This command was introduced.
12.1(1)T	This command was integrated into Cisco IOS Release 12.1(1)T.
12.2(4)T	This command was implemented on the Cisco 1750.
12.2(8)T	This command was implemented on the Cisco 1751, Cisco 2600 series and Cisco 3600 series, Cisco 3725, and Cisco 3745.

## Usage Guidelines

When the delay keyword is selected, the next-hop mailer sends a message to the FROM address saying that the mail message was delayed. The definition of the delay keyword is made by each mailer and is not controlled by the sender. Each mailer in the path to the recipient that supports the DSN extension receives the same request.

When the failure keyword is selected, the next-hop mailer sends a message to the FROM address that the mail message delivery failed. Each mailer in the path to the recipient that supports the DSN extension receives the same request.

When the success keyword is selected, the next-hop mailer sends a message to the FROM address saying that the mail message was successfully delivered to the recipient. Each mailer in the path to the recipient that supports the DSN extension receives the same request.



**Note** In the absence of any other DSN settings (for example, no dsn, or a mailer in the path that does not support the DSN extension), a failure to deliver message always causes a nondelivery message to be generated. This nondelivery message is called a bounce.

This command is applicable to Multimedia Mail over Internet Protocol (MMoIP) dial peers.

DSNs are messages or responses that are automatically generated and sent to the sender or originator of an e-mail message by the Simple Mail Transfer Protocol (SMTP) server, notifying the sender of the status of the e-mail message. Specifications for DSN are described in RFC 1891, RFC 1892, RFC 1893, and RFC 1894.

The on-ramp DSN request is included as part of the fax-mail message sent by the on-ramp gateway when the matching MMoIP dial peer has been configured. The on-ramp DSN response is generated by the SMTP server when the fax-mail message is accepted. The DSN is sent back to the user defined by the **mta send mail-from** command. The off-ramp DSN is requested by the e-mail client. The DSN response is generated by the SMTP server when it receives a request as part of the fax-mail message.




---

**Note** DSNs are generated only if the mail client on the SMTP server is capable of responding to a DSN request.

---

Because the SMTP server generates the DSNs, you need to configure both mail from: and rcpt to: on the server for the DSN feature to work. For example:

```
mail from: <user@mail-server.sample.com>
rcpt to: <fax=555-0112@sample.com> NOTIFY=SUCCESS,FAILURE,DELAY
```

Three different states can be reported back to the sender:

- Delay--Indicates that the message was delayed in being delivered to the recipient or mailbox.
- Success--Indicates that the message was successfully delivered to the recipient or mailbox.
- Failure--Indicates that the SMTP server was unable to deliver the message to the recipient or mailbox.

Because these delivery states are not mutually exclusive, you can configure store-and-forward fax to generate these messages for all or any combination of these events.

DSN messages notify the sender of the status of a particular e-mail message that contains a fax TIFF image. Use the **dsn** command to specify which notification messages are sent to the user.

The **dsn** command allows you to select more than one notification option by reissuing the command and specifying a different notification option each time. To discontinue a specific notification option, use the **no** form of the command for that specific keyword.

If the **failure** keyword is not included when DSN is configured, the sender receives no notification of message delivery failure. Because a failure is usually significant, care should be taken to always include the **failure** keyword as part of the **dsn** command configuration.

This command applies to on-ramp store-and-forward fax functions.

## Examples

The following example specifies that a DSN message be returned to the sender when the e-mail message that contains the fax has been successfully delivered to the recipient or if the message that contains the fax has failed to be delivered:

```
dial-peer voice 10 mmoip
  dsn success
  dsn failure
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>mta send mail -from hostname</b>	Specifies the originator (host-name portion) of the e-mail fax message.
<b>mta send mail -from username</b>	Specifies the originator (username portion) of the e-mail fax message.

# dsp allocation signaling dspid

To change the digital signal processor (DSP) selection for signaling channel allocation from the default (DSP weight-based) to the DSP ID number, use the **dsp allocation signaling dspid** command in voice-card configuration mode. To return to the default behavior, use the **no** form of this command.

**dsp allocation signaling dspid**  
**no dsp allocation signaling dspid**

**Syntax Description** This command has no arguments or keywords.

**Command Default** Selection of a DSP for signaling channel allocation is based on the internal weighted value assigned to the DSPs.

**Command Modes** Voice-card configuration (config-voicecard)

**Command History**

Release	Modification
12.4(15)T9	This command was introduced.

**Usage Guidelines** The **dsp allocation signaling dspid** command takes effect only after a reload of the router. The command should be enabled and saved into the startup-config file.

The default signal channel allocation method (by weight) may not be suitable for some network implementations. The default allocation method selects the DSPs based on the DSP weight, and you cannot control the selection of the DSP for specific configuration even if the order of the packet voice data modules (PVDMs) is changed. Enable the **dsp allocation signaling dspid** command to change the selection order to the DSP ID number. This command is more useful when there is a PVDM2-8 module in the network configuration.

**Examples** The following example shows how to change the default for DSP allocation from the DSP weight to the DSP ID number:

```
voice card 1
 dsp allocation signaling dspid
```

**Related Commands**

Command	Description
<b>show voice dsp</b>	Displays the current status or selective statistics of DSP voice channels.
<b>voice-card</b>	Enters voice-card configuration mode.

# dsp services dspfarm

To enable digital-signal-processor (DSP) farm services for a particular voice network module, use the **dsp services dspfarm** command in voice card configuration mode. To disable services, use the **no** form of this command.

**dsp services dspfarm**  
**no dsp services dspfarm**

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** Voice-card configuration (config-voicecard)

## Command History

Release	Modification
12.2(13)T	This command was introduced.
Cisco IOS XE Release 3.2S	Support for this command was added on Cisco ASR 1000 Series Routers.

## Usage Guidelines

The router must be equipped with one or more voice network modules that provide DSP resources. DSP resources are used only if this command is configured under the particular voice card.

The number of voice network modules that must be enabled for DSP-farm services depends on the number of DSPs on the module and on the maximum number of transcoding and conferencing sessions configured for the DSP farm.



**Note** Use this command before enabling DSP-farm services with the **dspfarm** command for an NM-HDV or NM-HDV-FARM.

### Cisco ASR 1000 Series Router

The SPA-DSPs on a Cisco ASR 1000 Series Routers are installed in a subslot on a SIP. Hence, when referring to a SPA-DSP the **voice-card** command is used.

## Examples

The following example enables DSP-farm services on an NM-HDV2 or NM-HD-1V/2V/2VE:

```
Router(config)# voice-card 2
Router(config-voicecard)# dsp services dspfarm
Router(config-voicecard)# exit
```

The following example enables DSP-farm services on an NM-HDV or NM-HDV-FARM:

```
Router(config)# voice-card 2
Router(config-voicecard)# dsp services dspfarm
Router(config-voicecard)# exit
```



The following example enables DSP-farm services on SPA-DSP for a Cisco ASR 1000 Series Router:

```
Router(config)# voice-card 1/1
Router(config-voicecard)# dsp services dspfarm
Router(config-voicecard)# exit
```

**Related Commands**

Command	Description
<b>dsp services dspfarm</b>	Enables the DSP farm services.
<b>dspfarm profile</b>	Enters the DSP farm profile configuration mode, and defines a profile for the DSP farm services.
<b>show voice dsp (SPA-DSP)</b>	Displays the DSP current status or the selective statistics of the DSP voice channels.

## dspfarm (DSP farm)

To enable digital signal processor (DSP) farm service, use the **dspfarm** command in global configuration mode. To disable the service, use the **no** form of this command.

**dspfarm**  
**no dspfarm**

**Syntax Description** This command has no arguments or keywords.

**Command Default** DSP-farm service is disabled.

**Command Modes** Global configuration (config)

Release	Modification
12.1(5)YH	This command was introduced on the Cisco VG200.
12.2(13)T	This command was implemented on the Cisco 2600 series, Cisco 3620, Cisco 3640, Cisco 3660, and Cisco 3700 series.

**Usage Guidelines** The router on which this command is used must be equipped with one or more digital T1/E1 packet voice trunk network modules (NM-HDVs) or high-density voice (HDV) transcoding/conferencing DSP farms (NM-HDV-FARMS) to provide DSP resources.

Before enabling DSP-farm services, you must configure the NM-HDV or NM-HDV-FARM on which DSP-farm services are to be enabled using the **dsp services dspfarm** command. You must also specify the maximum number of transcoding sessions to be supported by the DSP farm using the **dspfarm transcoder maximum sessions** command.

This command causes the system to download new firmware into the DSPs, start up the required subsystems, and wait for a service request from the transcoding and conferencing applications.

### Examples

The following example configures an NM-HDV or NM-HDV-FARM, specifies the maximum number of transcoding sessions, and enables DSP-farm services:

```
Router# configure terminal
Router(config)# no dspfarm
Router(config)# voice-card 2
Router(config-voicecard)# dsp services dspfarm
Router(config-voicecard)# exit
Router(config)# dspfarm transcoder maximum sessions 15
Router(config)# dspfarm
```

Command	Description
<b>dsp services dspfarm</b>	Specifies the NM-HDV or NM-HDV-FARM on which DSP-farm services are to be enabled.

Command	Description
<b>dspfarm transcoder maximum sessions</b>	Specifies the maximum number of transcoding sessions to be supported by a DSP farm.
<b>show dspfarm</b>	Displays summary information about DSP resources.

## dspfarm (voice-card)

To add a specified voice card to those participating in a digital signal processor (DSP) resource pool, use the **dspfarm** command in voice-card configuration mode. To remove the specified card from participation in the DSP resource pool, use the **no** form of this command.

**dspfarm**  
**no dspfarm**

**Syntax Description** This command has no arguments or keywords.

**Command Default** A card participates in the DSP resource pool.

**Command Modes** Voicecard configuration (config-voicecard)

### Command History

Release	Modification
12.1(5)XM	This command was introduced on the Cisco 3660.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T.
12.2(2)XB	This command was implemented on the Cisco 2600 series routers.
12.2(8)T	This command was integrated into Cisco IOS Release 12.2(8)T.
12.2(15)T	This command was implemented on the Cisco 2600XM, Cisco 3725, and Cisco 3745.

### Usage Guidelines

DSP mapping occurs when DSP resources on one AIM or network module are available for processing of voice time-division multiplexing (TDM) streams on a different network module or on a voice/WAN interface card (VWIC). This command is used on Cisco 3660 routers with multiservice interchange (MIX) modules installed or on Cisco 2600 series routers with AIMS installed.

To reach voice-card configuration mode for a particular voice card, from global configuration mode enter the **voice-card** command and the slot number for the AIM or network module that you want to add to the pool. See the **voice-card** command page for details on slot numbering.

The assignment of DSP pool resources to particular TDM streams is based on the order in which the streams are configured with the **ds0-group** command for T1/E1 channel-associated signaling (CAS) or with the **pri-group** command for ISDN PRI.

The assignment of DSP pool resources does not occur dynamically during call signaling.

### Examples

The following example adds to the DSP resource map the DSP resources on the network module in slot 5 on a Cisco 3660 with a MIX module:

```
voice-card 5
 dspfarm
```

The following example makes available the DSP resources on an AIM on a modular access router:

```
voice-card 0
dspfarm
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>ds0-group</b>	Specifies the DS0 time slots that make up a logical voice port on a T1 or E1 controller, Specifies the signaling type by which the router communicates with the PBX or PSTN, Defines T1 or E1 channels for compressed voice calls and the CAS method by which the router connects to the PBX or PSTN.
<b>pri-group</b>	Specifies ISDN PRI on a channelized T1 or E1 controller.
<b>voice-card</b>	Enters voice-card configuration mode.

## dspfarm confbridge maximum

To specify the maximum number of concurrent conference sessions for which digital signal processor (DSP) farm resources should be allocated, use the **dspfarm confbridge maximum** command in global configuration mode. To reset to the default, use the **no** form of this command.

**dspfarm confbridge maximum** {**mixed-mode sessions** | **sessions**} *number*  
**no dspfarm confbridge maximum** {**mixed-mode sessions** | **sessions**} *number*

### Syntax Description

<b>mixed-mode</b>	Specifies the maximum number of transcoding sessions for mixed-mode conferencing.
<b>sessions</b>	Specifies the conferencing maximum sessions parameter value.
<i>number</i>	Number of conference sessions. A single DSP supports one conference session with up to six participants.

### Command Default

No DSP farm resources are allocated for the sessions.

### Command Modes

Global configuration (config)

### Command History

Release	Modification
12.1(5)YH	This command was introduced on the Cisco VG200.
12.2(13)T	This command was modified. This command was implemented on the Cisco 2600 series, Cisco 3620, Cisco 3640, Cisco 3660, and Cisco 3700 series.
15.0(1)M	This command was modified. The <b>mixed-mode</b> keyword was added.

### Usage Guidelines

The router on which this command is used must be equipped with one or more digital T1/E1 packet voice trunk network modules (NM-HDVs) or high-density voice (HDV) transcoding/conferencing DSP farms (NM-HDV-FARMS) to provide DSP resources.

Before using this command, you must disable DSP-farm service using the **no dspfarm** command.

The maximum number of conference sessions depends upon DSP availability in the DSP farm. A single DSP supports one conference session with up to six participants. However, you may need to allocate additional DSP resources for transcoding to support conferences. If all participants use G.711 or G.729 codecs, you need not allocate any additional DSP resources because transcoding is done in the conferencing DSP.

When you use this command, take into consideration the number of DSPs allocated for transcoding services with the **dspfarm transcoder maximum sessions** command.

### Examples

The following example sets the maximum number of transcoding sessions for mixed-mode conferencing to 8:

```
Router# dspfarm confbridge maximum mixed-mode sessions 8
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>dspfarm (DSP farm)</b>	Enables DSP-farm service.
<b>dspfarm transcoder maximum sessions</b>	Specifies the maximum number of transcoding sessions to be supported by a DSP farm.
<b>show dspfarm</b>	Displays summary information about DSP resources.

# dspfarm connection interval

To specify the time interval during which to monitor Real-Time Transport Protocol (RTP) inactivity before deleting an RTP stream, use the **dspfarm connection interval** command in global configuration mode. To reset to the default, use the **no** form of this command.

**dspfarm connection interval** *seconds*  
**no dspfarm connection interval** *seconds*

<b>Syntax Description</b>	<i>seconds</i>	Interval, in seconds, during which to monitor RTP inactivity. Range is from 60 to 10800. Default is 600.
---------------------------	----------------	--

**Command Default** 600 seconds

**Command Modes** Global configuration (config)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.1(5)YH	This command was introduced on the Cisco VG200.
	12.2(13)T	This command was implemented on the Cisco 2600 series, Cisco 3620, Cisco 3640, Cisco 3660, and Cisco 3700 series.

**Usage Guidelines** The router on which this command is used must be equipped with one or more digital T1/E1 packet voice trunk network modules (NM-HDVs) or high-density voice (HDV) transcoding/conferencing DSP farms (NM-HDV-FARMS) to provide digital signal processor (DSP) resources.

After each interval, RTP streams are checked for inactivity. If all RTP streams for a particular call are inactive, the RTP timer, as set with the **dspfarm rtp timeout** command, is started. When the RTP timer expires, the call is deleted.

**Examples** The following example sets the connection interval to 60 seconds:

```
Router(config)# dspfarm connection interval 60
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>dspfarm rtp timeout</b>	Specifies the RTP timeout interval used to clear hanging connections.



# dspfarm profile

To enter DSP farm profile configuration mode and define a profile for digital signal processor (DSP) farm services, use the **dspfarm profile** command in global configuration mode. To delete a disabled profile, use the **no** form of this command.

## Cisco Unified Border Element

```
dspfarm profile profile-identifier {conference | mtp | transcode} [security]
no dspfarm profile profile-identifier
```

## Cisco Unified Border Element (Enterprise) Cisco ASR 1000 Series Router

```
dspfarm profile profile-identifier transcode
no dspfarm profile profile-identifier
```

## Cisco Integrated Services Routers Generation 2 (Cisco ISR G2)

```
dspfarm profile profile-identifier {conference [video [homogeneous | heterogeneous |
guaranteed-audio]] | mtp | transcode [video | universal]} [security]
no dspfarm profile profile-identifier
```

### Syntax Description

<i>profile identifier</i>	Number that uniquely identifies a profile. Range is 1 to 65535. There is no default.
<b>conference</b>	Enables a profile for conferencing.
<b>mtp</b>	Enables a profile for Media Termination Point (MTP).
<b>transcode</b>	Enables a profile for transcoding.
<b>security</b>	Enables a profile for secure DSP farm services.
<b>video</b>	(Optional) Enables a profile for video conferencing or transcoding.
<b>homogeneous</b>	(Optional) Specifies that all video participants use the one video format that is configured in this profile. DSP resources are reserved to support the conference at configuration time.  <b>Note</b> The homogeneous profiles only support one video codec.
<b>heterogeneous</b>	(Optional) Specifies that video participants can use the different video formats that are configured in the profile. You can configure up to 10 video codecs in the heterogeneous profile. DSP resources are reserved to support the different configurations at configuration time.
<b>guaranteed-audio</b>	(Optional) Specifies that video participants in a heterogeneous conference will at least have an audio connection. You can configure up to 10 video codecs in the guaranteed-audio profile. The DSP resources for audio streams are reserved at configuration time, but DSP resources to support video conferences are not reserved. If the video endpoint supports the video format specified in the profile and DSP resources are available when the participant joins the conference, the participant joins as a video conferee in the video conference.

**Command Default**

If this command is not entered, no profiles are defined for the DSP farm services.

**Command Modes**

Global configuration (config)

**Command History**

Release	Modification
12.3(8)T	This command was introduced.
12.4(11)XW	The <b>security</b> keyword was added.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.
12.4(22)T	Support for IPv6 was added.
15.0(1)M2 15.1(1)T	Support was modified for the Cisco IAD 2430, IAD 2431, IAD 2432, and IAD 2435, and the Cisco VG 202, VG 204, and VG 224 platforms.
Cisco IOS XE Release 3.2S	This command was modified. Support was added to the Cisco ASR 1000 Series Router. The <b>conference</b> , <b>mtp</b> , & <b>security</b> keywords are not supported on the Cisco ASR 1000 Series Router in this release.
15.1(4)M	This command was modified. The <b>video</b> keyword was added.
Cisco IOS XE Release 3.2S	This command was integrated into Cisco IOS XE Release 3.3S.
Cisco IOS XE Cupertino 17.7.1a	Introduced support for YANG models.

**Usage Guidelines**

Use this command to create a new profile or delete a disabled profile. After you create a new profile in dspfarm profile configuration mode, use the **no shutdown** command to enable the profile configuration, allocate resources and associate the profile with the application(s). If the profile cannot be enabled due to lack of resources, the system prompts you with a message "Can not enable the profile due to insufficient resources, resources available to support X sessions; please modify the configuration and retry."

If the DSP farm profile is successfully created, you enter the DSP farm profile configuration mode. You can configure multiple profiles for the same service.

Use the **no dspfarm profile** command to delete a profile from the system. If the profile is active, you cannot delete it; you must first disable it using the **shutdown** command. To modify a DSP farm profile, use the **shutdown** command in dspfarm profile configuration mode before you begin configuration.

The *profile identifier* uniquely identifies a profile. If the service type and *profile identifier* are not unique, the user is prompted with a message to choose a different profile identifier.

You must use the **security** keyword in order to enable secure DSP farm services such as secure transcoding.

Effective with Cisco IOS Releases 15.0(1)M2 and 15.1(1)T, platform support for the Cisco IAD 2430, IAD 2431, IAD 2432, and IAD 2435, and the Cisco VG 202, VG 204, and VG 225 is modified. These platforms are designed as TDM-IP devices and are not expandable to install extra DSP resources. So even though the **conference** keyword appears in the command syntax, this DSP service is not configurable on these platforms. If you try to configure conferencing on these platforms, the command-line interface displays the following message: "%This platform does not support Conferencing feature. "

The **transcode** keyword also appears in the command syntax, but this DSP service is not available on the Cisco VG 202, VG 204, and VG 224 platforms. If you try to configure transcoding on these platforms, the CLI displays the following message: "%This platform does not support Transcoding feature."

**Cisco ASR 1000 Series Router**

The support for dspfarm profile command was added on Cisco ASR 1000 Series Router from Cisco IOS XE Release 3.2 and later releases. The command is used to create a dspfarm profile for different services.



**Note** The secure DSP farm services is always enabled for SPA-DSP on Cisco ASR 1000 Series Router. Only **transcode** keyword is supported on Cisco ASR 1000 Series Router for Cisco IOS XE Release 3.2s. The **conference**, **media**, and **security** keywords are not supported on Cisco ASR 1000 Series Router for Cisco IOS XE Release 3.2s.

In order to configure a video dspfarm profile, you must set **voice-service dsp-reservation** command to be less than 100 percent.

To enable dspfarm profiles for voice services, you must use the dsp services dspfarmcommand **under the voice-card** **submode**.

**Examples**

The following example enables DSP farm services profile 20 for conferencing:

```
Router(config)# dspfarm profile 20 conference
```

Note the response if the profile is already being used:

```
Router(config)# dspfarm profile 6 conference
Profile id 6 is being used for service TRANSCODING
please select a different profile id
```

The following example enables DSP farm services profile 1 for transcoding:

```
Router(config)# dspfarm profile 1 transcode
```

**Video Conferences**

The following example enables DSP farm services profile 99 for homogeneous video. The conference supports four participants under one format (Video codec H.263, qcif resolution, and a frame-rate of 15 f/s).

```
Router(config)# dspfarm profile 99 conference video homogeneous
Router(config-dspfarm-profile)# codec h263 qcif frame-rate 15

Router(config-dspfarm-profile)# maximum conference-participant 4
```

**Related Commands**

Command	Description
<b>dsp service dspfarm</b>	Configures the DSP farm services for a specified voice card.
<b>shutdown (DSP farm profile)</b>	Disables the DSP farm profile.

<b>Command</b>	<b>Description</b>
<b>voice-card</b>	Enters voice card configuration mode
<b>voice-service dsp-reservation</b>	Configures the percentage of DSP resources are reserved for voice services and enables video services to use the remaining DSP resources.

# dspfarm rtp timeout

To specify the Real-Time Transport Protocol (RTP) timeout interval used to clear hanging connections, use the **dspfarm rtp timeout** command in global configuration mode. To reset to the default, use the **no** form of this command.

**dspfarm rtp timeout** *seconds*  
**no dspfarm rtp timeout**

<b>Syntax Description</b>	<i>seconds</i> RTP timeout interval, in seconds. Range is from 10 to 7200. Default is 1200.
---------------------------	---

**Command Default** 1200 seconds (20 minutes)

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.1(5)YH	This command was introduced on the Cisco VG200.
	12.2(13)T	This command was implemented on the Cisco 2600 series, Cisco 3620, Cisco 3640, Cisco 3660, and Cisco 3700 series.

**Usage Guidelines** The router on which this command is used must be equipped with one or more digital T1/E1 packet voice trunk network modules (NM-HDVs) or high-density voice (HDV) transcoding/conferencing DSP farms (NM-HDV-FARMS) to provide digital signal processor (DSP) resources.

Use this command to set the RTP timeout interval for when the error condition "RTP port unreachable" occurs.

**Examples** The following example sets the RTP timeout value to 600 seconds (10 minutes):

```
Router# dspfarm rtp timeout 600
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>dspfarm (DSP farm)</b>	Enables DSP-farm service.
	<b>dspfarm connection interval</b>	Specifies the time interval during which to monitor RTP inactivity before deleting an RTP stream.
	<b>show dspfarm</b>	Displays summary information about DSP resources.

# dspfarm transcoder maximum sessions

To specify the maximum number of transcoding sessions to be supported by the digital signal processor (DSP) farm, use the **dspfarm transcoder maximum sessions** command in global configuration mode. To reset to the default, use the **no** form of this command.

**dspfarm transcoder maximum sessions** *number*  
**no dspfarm transcoder maximum sessions**

<b>Syntax Description</b>	<i>number</i> Number of transcoding sessions.
---------------------------	---

**Command Default** 0 sessions

**Command Modes** Global configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	12.1(5)YH	This command was introduced on the Cisco VG200.
	12.2(13)T	This command was implemented on the Cisco 2600 series, Cisco 3620, Cisco 3640, Cisco 3660, and Cisco 3700 series.

**Usage Guidelines** The router on which this command is used must be equipped with one or more digital T1/E1 packet voice trunk network modules (NM-HDVs) or high-density voice (HDV) transcoding/conferencing DSP farms (NM-HDV-FARMS) to provide DSP resources.

Before using this command, you must disable DSP-farm service using the **no dspfarm** command.

Use this command in conjunction with the **dspfarm confbridge maximum sessions** commands.

The maximum number of transcoding sessions depends upon DSP availability in the DSP farm. A single DSP supports four transcoding sessions transmitted to and from G.711 and G.729 codecs.

## Examples

The following example configures an NM-HDV or NM-HDV-FARM, specifies the maximum number of transcoding sessions, and enables DSP-farm services:

```
Router# configure terminal
Router(config)# no dspfarm
Router(config)# voice-card 2
Router(config-voicecard)# dsp services dspfarm
Router(config-voicecard)# exit
Router(config)# dspfarm transcoder maximum sessions 15
Router(config)# dspfarm
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>dspfarm (DSP farm)</b>	Enables DSP-farm service.

Command	Description
<b>dspfarm confbridge maximum sessions</b>	Specifies the maximum number of conferencing sessions to be supported by a DSP farm.
<b>dsp services dspfarm</b>	Specifies the NM-HDV or NM-HDV-FARM on which DSP-farm services are to be enabled.
<b>show dspfarm</b>	Displays summary information about DSP resources.

# dspint dspfarm

To enable the digital signal processor (DSP) interface, use the **dspint dspfarm** command in global configuration mode. This command does not have a no form.

**dspint dspfarm** *slot/port*

Syntax Description	
<i>slot</i>	Slot number of the interface.
<i>port</i>	Port number of the interface.

**Command Default** Enabled

**Command Modes** Global configuration

Command History	Release	Modification
	12.0(5)XE	This command was introduced on the Cisco 7200 series routers.
	12.1(1)T	This command was integrated into Cisco IOS Release 12.1(1)T.
	12.2(13)T	This command was implemented on the Cisco 7200 series.

**Usage Guidelines** DSP mapping occurs when DSP resources on one advanced interface module (AIM) or network module are available for processing of voice time-division multiplexing (TDM) streams on a different network module or on a voice/WAN interface card (VWIC). This command is used on Cisco 3660 routers with multiservice interchange (MIX) modules installed or on Cisco 2600 series routers with AIMS installed.

To enter voice-card configuration mode for a particular voice card, from global configuration mode enter the **voice-card** command and the slot number for the AIM or network module that you want to add to the pool. See the **voice-card** command page for details on slot numbering.

The assignment of DSP pool resources to particular TDM streams is based on the order in which the streams are configured using the **ds0-group** command for T1/E1 channel-associated signaling (CAS) or using the **pri-group** command for ISDN PRI.

The assignment of DSP pool resources does not occur dynamically during call signaling.

To disable the interface use the **no shutdown** command.

## Examples

The following example creates a DSP farm interface with a slot number of 1 and a port number of 0:

```
dspint dspfarm 1/0
```

To change codec complexity on the Cisco 7200 series, you must enter the following commands:

```
Router# configure terminal
Router(config)# dspint dspfarm 2/0
Router(config-dspfarm)# codec medium | high ecan-extended
```



**Related Commands**

<b>Command</b>	<b>Description</b>
<b>ds0-group</b>	Specifies the DS0 time slots that make up a logical voice port on a T1 or E1 controller.
<b>no shutdown</b>	Disables the interface.
<b>pri-group</b>	Specifies an ISDN PRI on a channelized T1 or E1 controller
<b>show interfaces dspfarm dsp</b>	Displays information about the DSP interface.
<b>voice-card</b>	Enters voice-card configuration mode.

# dtmf-interworking

To enable a delay between the dtmf-digit begin and dtmf-digit end events in the RFC 2833 packets sent from Cisco Unified Border Element (Cisco UBE) or Cisco Unified Communications Manager Express (Cisco Unified CME) or to generate RFC 4733 compliance RTP Named Telephony Event (NTE) packets from CUBE, use the **dtmf-interworking** command in voice service or dial peer voice configuration mode. To remove the delay interval, use the **no** form of this command.

```
dtmf-interworking {rtp-nte | standard | system}
no dtmf-interworking
```

## Syntax Description

<b>rtp-nte</b>	Enables a delay between the dtmf-digit begin and dtmf-digit end events of RTP NTE packets.
<b>standard</b>	Generates RTP NTE packets that are RFC 4733 compliant.
<b>system</b>	Specifies the default global dual tone multifrequency (DTMF) interworking configuration. This keyword is available only in dial peer voice configuration mode.

## Command Default

RFC 2833 packet is sent in a single burst of three dtmf-digit begin events, one duration equaling 50 ms, and three dtmf-digit end events with a duration of 100 ms.

## Command Modes

Voice service configuration (config-voi-serv)  
Dial peer voice configuration (config-dial-peer)

## Command History

Release	Modification
12.4(15)XZ	This command was introduced.
12.4(20)T	This command was integrated into Cisco IOS Release 12.4(20)T.
15.1(2)T5	This command was modified. The <b>standard</b> and <b>system</b> keywords were added.
Cisco IOS XE Cupertino 17.7.1a	Introduced support for YANG models.

## Usage Guidelines

- **dtmf-interworking rtp-nte**—If your system is configured for RFC 2833 DTMF interworking and if the remote system cannot handle RFC 2833 packets sent in a single burst, use this command to introduce a delay between the dtmf-digit begin and end events in the RFC 2833 packet.
- **dtmf-interworking standard**—When the remote system needs RFC 4733 packets, then use this command to generate RFC 4733 compliance. In this configuration, one dtmf-digit begin event is initiated when CUBE receives start event.
- **dtmf-interworking system**—When this command is configured in dial peer voice configuration mode then the global level dtmf-interworking configuration is applicable. This is the default configuration under the dial peer.

## Examples

The following example shows configuration of a delay between the dtmf-digit and events:

```
Device> enable
Device# configure terminal
Device(config)# voice service voip
Device(config-voi-serv)# dtmf-interworking rtp-nte
Device(config-voi-serv)# end
```

The following example shows the generation of RTP NTE packets that are RFC 4733 compliant:

```
Device> enable
Device# configure terminal
Device(config)# voice service voip
Device(config-voi-serv)# dtmf-interworking standard
Device(config-voi-serv)# end
```

#### Related Commands

Command	Description
<b>keypad-normalize</b>	Ensures that the delay configured for a dtmf-end event is always honored.
<b>n-te-end-digit-delay</b>	Specifies the length of delay for each digit in a dtmf-digit end event.

## dtmf timer inter-digit

To configure the dual tone multifrequency (DTMF) interdigit timer for a DS0 group, use the **dtmf timer inter-digit** command in T1 controller configuration mode. To restore the timer to its default value, use the **no** form of this command.

**dtmf timer inter-digit** *milliseconds*  
**no dtmf timer inter-digit**

<b>Syntax Description</b>	<i>milliseconds</i>	DTMF interdigit timer duration, in milliseconds. Range is from 250 to 3000. The default is 3000.
---------------------------	---------------------	--

**Command Default** 3000 milliseconds

**Command Modes** T1 controller configuration

<b>Command History</b>	Release	Modification
	12.1(3)T	This command was introduced on the Cisco AS5300.

**Usage Guidelines** Use the **dtmf timer inter-digit** command to specify the duration in milliseconds the router waits to detect the end of DTMF digits. After this period, the router expects no more digits to arrive and establishes the call.

**Examples** The following example, beginning in global configuration mode, sets the DTMF interdigit timer value to 250 milliseconds:

```
controller T1 2
 ds0-group 2 timeslots 4-10 type e&m-fgb dtmf dnis
 cas-custom 2
 dtmf timer inter-digit 250
```

<b>Related Commands</b>	Command	Description
	<b>cas-custom</b>	Customizes E1 R2 signaling parameters for a particular E1 channel group on a channelized E1 line.
	<b>ds0-group</b>	Configures channelized T1 time slots, which enables a Cisco AS5300 modem to answer and send an analog call.

## dtmf-relay (Voice over Frame Relay)

To enable the generation of FRF.11 Annex A frames for a dial peer, use the **dtmf-relay** command in dial-peer configuration mode. To disable the generation of FRF.11 Annex A frames and return to the default handling of dial digits, use the **no** form of this command.

**dtmf-relay**  
**no dtmf-relay**

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** Dial peer configuration

Release	Modification
12.0(3)XG	This command was introduced on the Cisco 2600 series, Cisco 3600 series, and Cisco MC3810.
12.0(4)T	This command was integrated into Cisco IOS Release 12.0(4)T, and implemented on the Cisco 7200 series router.

**Usage Guidelines** Cisco recommends that this command be used with low bit-rate codecs.

When **dtmf-relay** (VoFR) is enabled, the digital signal processor (DSP) generates Annex A frames instead of passing a dual tone multifrequency (DTMF) tone through the network as a voice sample. For information about the payload format of FRF.11 Annex A frames, see the Cisco IOS Wide-Area Networking Configuration Guide.

**Examples** The following example shows how to enable FRF.11 Annex A frames for VoFR dial peer 200, starting from global configuration mode:

```
dial-peer voice 200 vofr
 dtmf-relay
```

Command	Description
<b>called-number (dial peer)</b>	Enables an incoming VoFR call leg to get bridged to the correct POTS call leg when using a static FRF.11 trunk connection.
<b>codec (dial peer)</b>	Specifies the voice coder rate of speech for a VoFR dial peer.
<b>connection</b>	Specifies a connection mode for a voice port.
<b>eptune</b>	Specifies a regional analog voice interface-related tone, ring, and cadence setting.

<b>Command</b>	<b>Description</b>
<b>destination-pattern</b>	Specifies the prefix, the full E.164 telephone number, or an ISDN directory number (depending on the dial plan) to be used for a dial peer.
<b>preference</b>	Indicates the preferred order of a dial peer within a rotary hunt group.
<b>session protocol</b>	Establishes a session protocol for calls between the local and remote routers via the packet network.
<b>session target</b>	Specifies a network-specific address for a specified dial peer or destination gatekeeper.
<b>signal-type</b>	Sets the signaling type to be used when connecting to a dial peer.

## dtmf-relay (Voice over IP)

To specify how an H.323 or Session Initiation Protocol (SIP) gateway relays dual tone multifrequency (DTMF) tones between telephony interfaces and an IP network, use the **dtmf-relay** command in dial peer voice configuration mode. To remove all signaling options and send the DTMF tones as part of the audio stream, use the **no** form of this command.

```
dtmf-relay [cisco-rtp] [h245-alphanumeric] [h245-signal] [rtp-nte [digit-drop]] [sip-notify] [sip-info]
[sip-kpml]
no dtmf-relay
```

### Syntax Description

<b>cisco -rtp</b>	Forwards DTMF tones by using Real-Time Transport Protocol (RTP) with a Cisco proprietary payload type.
<b>h245 -alphanumeric</b>	Forwards DTMF tones by using the H.245 "alphanumeric" User Input Indication method. Supports tones from 0 to 9, *, #, and from A to D.
<b>h245 -signal</b>	Forwards DTMF tones by using the H.245 "signal" User Input Indication method. Supports tones from 0 to 9, *, #, and from A to D.
<b>rtp -nte</b>	Forwards DTMF tones by using RTP with the Named Telephone Event (NTE) payload type.
<b>digit-drop</b>	Passes digits out-of-band and drops in-band digits.  <b>Note</b> The <b>digit-drop</b> keyword is only available when the <b>rtp-nte</b> keyword is configured.
<b>sip-info</b>	Forwards DTMF tones using SIP INFO messages. This keyword is available only if the VoIP dial peer is configured for SIP.
<b>sip-kpml</b>	Forwards DTMF tones using SIP KPML over SIP SUBSCRIBE/NOTIFY messages. This keyword is available only if the VoIP dial peer is configured for SIP.
<b>sip-notify</b>	Forwards DTMF tones using SIP NOTIFY messages. This keyword is available only if the VoIP dial peer is configured for SIP.

### Command Default

DTMF tones are disabled and sent in-band. That is, they are left in the audio stream.

### Command Modes

Dial peer voice configuration

### Command History

Release	Modification
11.3(2)NA	This command was introduced on the Cisco AS5300.
12.0(2)XH	The <b>cisco-rtp</b> , <b>h245-alphanumeric</b> , and <b>h245-signal</b> keywords were added.
12.0(5)T	This command was integrated into Cisco IOS Release 12.0(5)T.
12.0(7)XK	This command was first supported for VoIP on the MC3810.

Release	Modification
12.1(2)T	Changes made in Cisco IOS Release 12.0(7)XK were integrated into Cisco IOS Release 12.1(2)T.
12.2(8)T	This command was implemented on the Cisco 1751, Cisco 2600 series and Cisco 3600 series, Cisco 3725, and Cisco 3745.
12.1(5)XM2	This command was implemented on the Cisco AS5350 and Cisco AS5400.
12.2(4)T	This command was integrated into Cisco IOS Release 12.2(4)T. Support for the Cisco AS5300, Cisco AS5350, and Cisco AS5400 was not included in this release.
12.2(2)XB1	This command was implemented on the Cisco AS5850 platform.
12.2(11)T	This command was integrated into Cisco IOS Release 12.2(11)T.
12.2(15)ZJ	The <b>sip-notify</b> keyword was added.
12.3(4)T	This command was integrated into Cisco IOS Release 12.3(4)T.
12.3(11)T	The <b>digit-drop</b> keyword was added.
15.3(3)M	This command was modified. The <b>sip-info</b> and <b>sip-kpml</b> keywords were added.
Cisco IOS XE Amsterdam 17.2.1r	Introduced support for YANG models.

## Usage Guidelines

DTMF is the tone generated when you press a button on a touch-tone phone. This tone is compressed at one end of a call; when the tone is decompressed at the other end, it can become distorted, depending on the codec used. The DTMF relay feature transports DTMF tones generated after call establishment out-of-band using either a standard H.323 out-of-band method or a proprietary RTP-based mechanism. For SIP calls, the most appropriate method to transport DTMF tones is RTP-NTE or SIP-NOTIFY.

This command specifies how an H.323 or SIP gateway relays DTMF tones between telephony interfaces and an IP network.

You must include one or more keywords when using this command.

To avoid sending both in-band and out-of-band tones to the outgoing leg when sending IP-to-IP gateway calls in-band (rtp-nte) to out-of-band (h245-alphanumeric), configure the **dtmf-relay** command using the **rtp-nte** and **digit-drop** keywords on the incoming SIP dial peer. On the H.323 side, and for H.323 to SIP calls, configure this command using either the **h245-alphanumeric** or **h245-signal** keyword.

The SIP-NOTIFY method sends NOTIFY messages bidirectionally between the originating and terminating gateways for a DTMF event during a call. If multiple DTMF relay mechanisms are enabled on a SIP dial peer and are negotiated successfully, the SIP-NOTIFY method takes precedence.

SIP NOTIFY messages are advertised in an invite message to the remote end only if the **dtmf-relay** command is set.

You can configure **dtmf-relay sip-info** only if the **allow-connections sip to sip** command is enabled at the global level.

For SIP, the gateway chooses the format according to the following priority:



1. sip-notify (highest priority)
2. rtp-nte
3. None--DTMF sent in-band

The gateway sends DTMF tones only in the format that you specify if the remote device supports it. If the H.323 remote device supports multiple formats, the gateway chooses the format according to the following priority:

1. cisco-rtp (highest priority)
2. h245-signal
3. h245-alphanumeric
4. rtp-nte
5. None--DTMF sent in-band

The principal advantage of the **dtmf-relay** command is that it sends DTMF tones with greater fidelity than is possible in-band for most low-bandwidth codecs, such as G.729 and G.723. Without the use of DTMF relay, calls established with low-bandwidth codecs may have trouble accessing automated DTMF-based systems, such as voice mail, menu-based Automatic Call Distributor (ACD) systems, and automated banking systems.




---

**Note** The **cisco-rtp** keyword supports a proprietary Cisco implementation and operates only between two Cisco 2600 series or Cisco 3600 series routers running Cisco IOS Release 12.0(2)XH or later. Otherwise, the DTMF relay feature does not function, and the gateway sends DTMF tones in-band.

---

- The **cisco-rtp** keyword is supported on Cisco 7200 series routers.
- The **sip-notify** keyword is available only if the VoIP dial peer is configured for SIP.
- The **digit-drop** keyword is available only when the **rtp-nte** keyword is configured.

## Examples

The following example configures DTMF relay with the **cisco-rtp** keyword when DTMF tones are sent to dial peer 103:

```
dial-peer voice 103 voip
 dtmf-relay cisco-rtp
```

The following example configures DTMF relay with the **cisco-rtp** and **h245-signal** keywords when DTMF tones are sent to dial peer 103:

```
dial-peer voice 103 voip
 dtmf-relay cisco-rtp h245-signal
```

The following example configures the gateway to send DTMF in-band (the default) when DTMF tones to are sent dial peer 103:

```
dial-peer voice 103 voip
 no dtmf-relay
```

The following example configures DTMF relay with the **digit-drop** keyword to avoid both in-band and out-of band tones being sent to the outgoing leg on H.323 to H.323 or H.323 to SIP calls:

```
dial-peer voice 1 voip
  session protocol sipv2
  dtmf-relay h245-alphanumeric rtp-nte digit-drop
```

The following example configures DTMF relay with the **rtp-nte** keyword when DTMF tones are sent to dial peer 103:

```
dial-peer voice 103 voip
  dtmf-relay rtp-nte
```

The following example configures the gateway to send DTMF tones using SIP NOTIFY messages to dial peer 103:

```
dial-peer voice 103 voip
  session protocol sipv2
  dtmf-relay sip-notify
```

The following example configures the gateway to send DTMF tones using SIP INFO messages to dial peer 10:

```
dial-peer voice 10 voip
  dtmf-relay sip-info
```

#### Related Commands

Command	Description
<b>notify telephone-event</b>	Configures the maximum interval between two consecutive NOTIFY messages for a particular telephone event.

# dualtone

To enter cp-dualtone configuration mode for specifying a custom call-progress tone, use the **dualtone** command in custom-cptone voice-class configuration mode. To configure the custom-cptone voice class not to detect a call-progress tone, use the **no** form of this command.

**dualtone** {**busy** | **conference** | **disconnect** | **number-unobtainable** | **out-of-service** | **reorder** | **ringback**}  
**no dualtone** {**busy** | **conference** | **disconnect** | **number-unobtainable** | **out-of-service** | **reorder** | **ringback**}

## Syntax Description

<b>busy</b>	Configure busy tone.
<b>conference</b>	Configure conference join and leave tones.
<b>disconnect</b>	Configure disconnect tone.
<b>number -unobtainable</b>	Configure number-unavailable tone.
<b>out -of-service</b>	Configure out-of-service tone.
<b>reorder</b>	Configure reorder tone.
<b>ringback</b>	Configure ringback tone.

## Command Default

No call-progress tones are defined within the custom-cptone voice class.

## Command Modes

Custom-cptone voice-class configuration

## Command History

Release	Modification
12.1(5)XM	This command was introduced on the Cisco 2600 and Cisco 3600 series and on the Cisco MC3810.
12.2(2)T	This command was implemented on the Cisco 1750 router and integrated into Cisco IOS Release 12.2(2)T.
12.4(11)XJ2	The <b>conference</b> keyword was added.
12.4(15)T	This command was integrated into Cisco IOS Release 12.4(15)T.

## Usage Guidelines

The **dualtone** command enters cp-dualtone configuration mode and specifies a call-progress tone to be detected. You can specify additional call-progress tones without exiting cp-dualtone configuration mode.

Any call-progress tones that are not specified are not detected.

To delete a call-progress tone from this custom-cptone voice class, use the **no** form of this command and the keyword for the tone that should not be detected; for example, **no dualtone busy**.

You must associate the class of custom call-progress tones with a voice port for this command to affect tone detection.

Use the **dualtone conference** command to define custom join and leave tones for hardware conferences.

## Examples

The following example enters cp-dualtone configuration mode and specifies busy tone and ringback tone in the custom-cptone voice class country-x:

```
Router(config)# voice class custom-cptone country-x
Router(cfg-cptone)# dualtone busy
Router(cfg-cp-dualtone)# frequency 440 480
Router(cfg-cp-dualtone)# cadence 500 500
Router(cfg-cp-dualtone)# exit
Router(cfg-cptone)# dualtone ringback
Router(cfg-cp-dualtone)# frequency 400 440
Router(cfg-cp-dualtone)# cadence 2000 4000
```

The following example deletes ringback tone from the custom-cptone voice class country-x:

```
Router(config)# voice class custom-cptone country-x
Router(cfg-cptone)# no dualtone ringback
```

The following example configures a conference leave tone. The configured leave tone must be associated with a digital signal processor (DSP) farm profile:

```
Router(config)# voice class custom-cptone leavetone
Router(cfg-cptone)# dualtone conference
Router(cfg-cp-dualtone)# frequency 500 500
Router(cfg-cp-dualtone)# cadence 100 100 100 100 100
```

## Related Commands

Command	Description
<b>cadence</b>	Defines the tone on and off durations for a call-progress tone.
<b>conference-join custom-cptone</b>	Defines a custom call-progress tone to indicate joining a conference.
<b>conference-leave custom-cptone</b>	Defines a custom call-progress tone to indicate leaving a conference.
<b>dspfarm profile</b>	Enters DSP farm profile configuration mode and defines a profile for DSP farm services.
<b>frequency</b>	Defines the frequency components for a call-progress tone.
<b>supervisory custom-cptone</b>	Associates a class of custom call-progress tones with a voice port.
<b>voice class custom-cptone</b>	Creates a voice class for defining custom call-progress tones.