



# Hardware Module Commands

---

This module lists the Cisco IOS XR Interfaces commands on the Cisco 8000 Series Routers.

For detailed information about the hardware module configuration tasks and examples, refer to the *Interface and Hardware Components Configuration Guide for Cisco 8000 Series Routers*.

- [Hardware Module Commands, on page 2](#)

# Hardware Module Commands

## GRE Tunnel Interface Commands

- `hw-module profile cef ttl tunnel-ip decrement disable`
- `hw-module profile gue`
- `hw-module profile gue underlay-hash enable`