



MACsec Commands

This module describes the commands used to configure MACsec.



Note All commands applicable for the Cisco NCS 5500 Series Router are also supported on the Cisco NCS 540 Series Router that is introduced from Cisco IOS XR Release 6.3.2. References to earlier releases in Command History tables apply to only the Cisco NCS 5500 Series Router.

For detailed information about keychain management concepts, configuration tasks, and examples, see the Implementing MACsec encryption chapter in the *System Security Configuration Guide for Cisco NCS 5500 Series Routers*.

- [allow \(MACsec\)](#), on page 3
- [cipher-suite](#), on page 4
- [conf-offset](#), on page 5
- [crypto-sks-kme](#) , on page 6
- [cryptographic-algorithm \(MACsec\)](#), on page 7
- [enable-legacy-fallback](#), on page 9
- [fallback-psk-keychain](#) , on page 10
- [impose-overhead-on-bundle](#), on page 11
- [key](#) , on page 12
- [key chain](#), on page 13
- [key-string](#) , on page 14
- [key-server-priority](#), on page 16
- [lifetime](#), on page 17
- [macsec](#), on page 19
- [macsec-policy](#), on page 21
- [macsec shutdown](#), on page 22
- [show macsec mka summary](#) , on page 23
- [show macsec mka session](#) , on page 24
- [show macsec mka interface detail](#), on page 26
- [show macsec mka statistics](#), on page 28
- [show macsec mka client](#), on page 30
- [show macsec mka standby](#), on page 31
- [show macsec mka trace](#) , on page 32

- [show macsec secy](#), on page 34
- [show macsec ea](#) , on page 35
- [show macsec open-config](#), on page 37
- [show macsec platform hardware](#), on page 39
- [show macsec platform idb](#), on page 41
- [show macsec platform stats](#), on page 43
- [show macsec platform trace](#), on page 45
- [sak-rekey-interval](#), on page 47
- [security-policy](#), on page 48
- [show crypto sks profile](#), on page 49
- [window-size](#), on page 51

allow (MACsec)

To specify MACsec policy exception to allow packets in clear text, use **allow** command under MACsec policy configuration mode. To remove this configuration, use the **no** form of this command.

allow lacp-in-clear

Syntax Description	lacp-in-clear Allows Link Aggregation Control Plane protocol (LACP) packets in clear text.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	MACsec policy configuration mode
----------------------	----------------------------------

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

Usage Guidelines	The policy-exception lacp-in-clear command under MACsec policy configuration mode is deprecated. Hence, it is recommended to use the allow lacp-in-clear command instead, to allow LACP packets in clear-text format.
-------------------------	---

Task ID	Task ID	Operations
	system	read, write

Examples	This example shows how to create a MACsec policy exception to allow LACP packets in clear text:
-----------------	---

```
Router#configure
Router(config)#macsec-policy test-macsec-policy
Router(config-macsec-policy)#allow lacp-in-clear
Router(config-macsec-policy)#commit
```

cipher-suite

Configures the cipher suite for encrypting traffic with MACsec in the MACsec policy configuration mode.

The first portion of the cipher name indicates the encryption method, the second portion indicates the hash or integrity algorithm, and the third portion indicates the length of the cipher (128/256).

To disable this feature, use the **no** form of this command.

cipher-suite *encryption_suite*

Syntax Description

encryption_suite The GCM encryption method that uses the AES encryption algorithm. The available encryption suites are:

- GCM-AES-128
- GCM-AES-256
- GCM-AES-XPB-128
- GCM-AES-XPB-256

Command Default

The default cipher suite chosen for encryption is GCM-AES-XPB-256.

Command Modes

MACsec policy configuration.

Command History

Release	Modification
Release 5.3.2	This command was introduced.

Task ID

Task ID	Operations
system	read, write

Examples

The following example shows how to use the **cipher-suite** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# macsec-policy mac_policy
RP/0/RP0/CPU0:router(config-mac_policy)# cipher-suite GCM-AES-XPB-256
RP/0/RP0/CPU0:router(config-mac_policy)#
```

conf-offset

Configures the confidentiality offset for MACsec encryption in the MACsec policy configuration mode.

To disable this feature, use the **no** form of this command.

conf-offset *offset_value*

Syntax Description

offset_value Configures the offset value. The options are:

- CONF-OFFSET-0 : Does not offset the encryption
- CONF-OFFSET-30: Offsets the encryption by 30 characters
- CONF-OFFSET-50: Offsets the encryption by 50 characters.

Command Default

Default value is 0.

Command Modes

MACsec policy configuration.

Command History

Release	Modification
Release 5.3.2	This command was introduced.

Task ID

Task ID	Operations
system	read, write

Examples

The following example shows how to use the **conf-offset** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# macsec-policy mac_policy
RP/0/RP0/CPU0:router(config-mac_policy)# conf-offset CONF-OFFSET-30
RP/0/RP0/CPU0:router(config-mac_policy)#
```

crypto-sks-kme

To display details of the Quantum Key Distribution (QKD) server, use the **crypto-sks-kme** command in EXEC mode.

```
crypto-sks-kme profile-name { entropy | capability }
```

Syntax Description	
<i>profile-name</i>	Specifies the key string in clear-text form.
entropy	Specifies the key in encrypted form.
capability	Specifies the key in Type 6 encrypted form.

Command Default	None
------------------------	------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	system read, write	

Examples

The following examples shows how to use the **crypto-sks-kme** command:

```
Router# crypto sks kme remote_qkd_prof1 entropy
Entropy Details:
Key details Dump: 0000 - 406b004c9c7f0000000000000000000000280c71794fa6f029d0ee2f6c4cd01b46
Key : 406b004c9c7f0000000000000000000000280c71794fa6f029d0ee2f6c4cd01b46
Entropy Length: 32

Router# crypto sks kme QkdIP capability
Capability Details:
  Entropy supported : False
  Key supported     : False
  Algorithm         : QKD
  Local identifier  : Alicel
  Remote identifier : Alicel, Bob1,
```



```
RP/0/RP0/CPU0:router# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec) # key 1234abcd5678
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678) # key-string
1234567812345678123456781234567812345678123456781234567812345678 cryptographic-algorithm
aes-256-cmac
```


enable-legacy-fallback

To enable interoperability with peer devices that do not support MACsec active fallback feature, use the **enable-legacy-fallback** command in MACsec policy configuration mode. To remove the configuration, use the **no** form of this command.

enable-legacy-fallback

Syntax Description This command has no keywords or arguments.

Command Default Disabled, by default.

Command Modes MACsec policy configuration mode

Command History	Release	Modification
	Release 7.1.2	This command was introduced.

Usage Guidelines For more details on MACsec active fallback feature, see the *Fallback PSK* section in the *Configuring MACsec Encryption* chapter in the *System Security Configuration Guide for Cisco NCS 5500 Series Routers*.

Task ID	Task ID	Operation
	system read, write	

This example shows how to enable interoperability with peer devices that do not support MACsec active fallback feature:

```
Router#configure
Router(config)#macsec-policy P1
Router(config-macsec-policy)#enable-legacy-fallback
Router(config-macsec-policy)#commit
```

fallback-psk-keychain

To create or modify a fallback psk keychain key, use the **fallback-psk-keychain** command in keychain-key configuration mode.

To disable this feature, use the **no** form of this command.

fallback-psk-keychain *key-id*

Syntax Description *key-id* 64-character hexadecimal string.

Command Default No default behavior or values.

Command Modes Key chain configuration

Usage Guidelines The key must be of even number of characters. Entering an odd number of characters will exit the MACsec configuration mode.

Task ID	Task ID	Operations
	system	read, write

Examples The following example shows how to use the **key** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# fallback-psk-keychain fallback_mac_chain
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678
```

impose-overhead-on-bundle

To impose the MACsec overhead on the bundle interface, use **impose-overhead-on-bundle** command under MACsec policy configuration mode.

impose-overhead-on-bundle

Syntax Description	impose-overhead-on-bundle Applies macsec overhead on the bundle interface.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	MACsec policy configuration mode
----------------------	----------------------------------

Command History	Release	Modification
	Release 24.1.1	This command was introduced.

Usage Guidelines	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	system	read, write

Examples

This example shows how to configure MACsec policy exception to apply macsec overhead on the bundle interface:

```
Router#configure
Router(config)#macsec-policy test-macsec-policy
Router(config-macsec-policy)#impose-overhead-on-bundle
Router(config-macsec-policy)#commit
```

key

To create or modify a keychain key, use the **key** command in keychain-key configuration mode. To disable this feature, use the **no** form of this command.

key *key-id*

Syntax Description

key-id 64-character hexadecimal string.

Command Default

No default behavior or values.

Command Modes

Key chain configuration

Usage Guidelines

The key must be of even number of characters. Entering an odd number of characters will exit the MACsec configuration mode.

Task ID

Task ID	Operations
system	read, write

Examples

The following example shows how to use the **key** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678
```

key chain

To create or modify a keychain, use the **key chain** command in the key chain configuration mode.

To disable this feature, use the **no** form of this command.

key chain *key-chain-name*

Syntax Description	<p><i>key-chain-name</i> Specifies the name of the keychain. The maximum length is 32 (128-bit encryption)/64 (256-bit encryption) character hexadecimal string.</p> <p>Note If you are configuring MACsec to interoperate with a MACsec server that is running software prior to IOS XR 6.1.3, then ensure that the MACsec key length is of 64 characters. If the key length is lesser than 64 characters, authentication will fail.</p>				
Command Modes	Key chain configuration				
Command Default	No default behavior or values				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>system</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	system	read, write
Task ID	Operations				
system	read, write				

Examples

The following example shows how you can configure a key chain for MACsec encryption:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)#
```

key-string

To specify the text string for the key, use the **key-string** command in keychain-key configuration mode.

To disable this feature, use the **no** form of this command.

key-string [**clear** | **password**] *key-string-text*

Syntax Description		
clear		Specifies the key string in clear-text form.
password <i>password</i>		Specifies the key in encrypted form.
<i>key-string-text</i>		Text string for the key, which is encrypted by the parser process before being saved to the configuration. The text string has the following character limitations: <ul style="list-style-type: none"> • Plain-text key strings—Minimum of 1 character and a maximum of 32 (128-bit encryption)/64 (256-bit encryption) characters (hexadecimal string). • Encrypted key strings—Minimum of 4 characters and no maximum.

Command Default The default value is clear.

Command Modes Key chain configuration

Usage Guidelines For an encrypted password to be valid, the following statements must be true:

- String must contain an even number of characters, with a minimum of four.
- The first two characters in the password string must be decimal numbers and the rest must be hexadecimals.
- The first two digits must not be a number greater than 53.

Either of the following examples would be valid encrypted passwords:

1234abcd

or

50aefd

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **keystring** command:

! For AES 128-bit encryption

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678
```

```
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)# key-string  
12345678123456781234567812345678 cryptographic-algorithm AES-128-CMAC
```

! For AES 256-bit encryption

```
RP/0/RP0/CPU0:router# configure  
RP/0/RP0/CPU0:router(config)# key chain mac_chain macsec  
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678  
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)# key-string  
1234567812345678123456781234567812345678123456781234567812345678  
AES-256-CMAC
```

key-server-priority

Configures the preference for a device to serve as the key server for MACsec encryption in the MACsec policy configuration mode. To disable this feature, use the **no** form of this command.

key-server-priority *value*

Syntax Description	<i>value</i> Indicates the priority for a device to become the key server. Lower the value, higher the preference. The range is 0-255.
---------------------------	--

Command Default	Default value is 16.
------------------------	----------------------

Command Modes	MACsec policy configuration.
----------------------	------------------------------

Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **key-server-priority** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# macsec-policy mac_policy
RP/0/RP0/CPU0:router(config-mac_policy)# key-server-priority 16
RP/0/RP0/CPU0:router(config-mac_policy)#
```


lifetime

Configures the validity period for the MACsec key or CKN in the Keychain-key configuration mode. To disable this feature, use the **no** form of this command.

The lifetime period can be configured with a duration in seconds, as a validity period between two dates (for example, Jan 01 2014 to Dec 31 2014), or with an infinite validity.

The key is valid from the time you configure in HH:MM:SS format. Duration is configured in seconds.

When a key has expired, the MACsec session is torn down and running the **show macsec mka session** command does not display any information. If you run the **show macsec mka interface** and **show macsec mka interface detail** commands, you can see that the session is unsecured.

```
lifetime start_time start_date
{
end_time end_date |
duration validity | infinite
}
```

Syntax Description		
<i>start-time</i>		Start time in hh:mm:ss from which the key becomes valid. The range is from 0:0:0 to 23:59:59.
<i>end-time</i>		End time in hh:mm:ss at which point the key becomes invalid. The range is from 0:0:0 to 23:59:59.
<i>start_date</i>		The date in DD month YYYY format that the key becomes valid.
<i>end_date</i>		The date in DD month YYYY format that the key becomes invalid.
duration <i>validity</i>		The key chain is valid for the duration you configure. You can configure duration in seconds.
infinite		The key chain is valid indefinitely.

Command Default No default behavior or values

Command Modes Keychain-key configuration

Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **lifetime** command:

! For AES 128-bit encryption

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)# key-string
12345678123456781234567812345678 cryptographic-algorithm AES-128-CMAC
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)# lifetime 05:00:00 20 february
2015 12:00:00 30 september 2016
```

! For AES 256-bit encryption

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)# key-string
1234567812345678123456781234567812345678123456781234567812345678 cryptographic-algorithm
AES-256-CMAC
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)# lifetime 05:00:00 20 february
2015 12:00:00 30 september 2016
```

macsec

Enables MACsec on the router in the keychain configuration mode. To disable this feature, use the **no** form of this command.

macsec [**key** *key-id*]

Syntax Description	<i>key-id</i> The key can be up to 64 bytes in length. The configured key is the CKN that is exchanged between the peers.								
Command Default	No default behavior or values.								
Command Modes	Keychain configuration								
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.3.2</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 7.1.2</td> <td>The <i>key-id</i> values are made case insensitive, and are stored as uppercase letters.</td> </tr> <tr> <td>Release 7.2.1</td> <td></td> </tr> </tbody> </table>	Release	Modification	Release 5.3.2	This command was introduced.	Release 7.1.2	The <i>key-id</i> values are made case insensitive, and are stored as uppercase letters.	Release 7.2.1	
Release	Modification								
Release 5.3.2	This command was introduced.								
Release 7.1.2	The <i>key-id</i> values are made case insensitive, and are stored as uppercase letters.								
Release 7.2.1									

Usage Guidelines

From Cisco IOS XR Software Release 7.1.2 , Release 7.2.1 and later, the MACsec key IDs are considered to be case insensitive. These key IDs are stored as uppercase letters. For example, a key ID of value 'FF' and of value 'ff' are considered to be the same, and both these key IDs are now stored in uppercase as 'FF'. Whereas, prior to Release 7.1.2 and Release 7.2.1, both these values were treated as case sensitive, and hence considered as two separate key IDs. However, the support for this case insensitive IDs is applicable only for the configurations done through CLI, and not for configurations done through Netconf protocol. Hence, it is recommended to have unique strings as key IDs for a MACsec key chain to avoid flapping of MACsec sessions.

For example, the key IDs ('FF' and 'ff') in this example are not unique (although one is in uppercase and other is in lowercase), and hence this might cause a MACsec session flap.

```
key chain 1
 macsec
  key FF
    lifetime 02:01:01 may 18 2020 infinite
  !
  key ff
    lifetime 01:01:01 may 18 2020 infinite
```

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **macsec** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# key chain mac_chain macsec
RP/0/RP0/CPU0:router(config-mac_chain-MacSec)# key 1234abcd5678
RP/0/RP0/CPU0:router(config-mac_chain-MacSec-1234abcd5678)#
```

macsec-policy

Creates a MACsec policy for MACsec encryption in XR Config mode. To disable this feature, use the **no** form of this command.

macsec-policy *policy_name*

Syntax Description	<i>policy_name</i> Name of the MACsec policy for encryption.
---------------------------	--

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	XR Config mode
----------------------	----------------

Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Task ID	Task ID	Operations
	system	read, write

Examples The following example shows how to use the **macsec-policy** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# macsec-policy mac_policy
RP/0/RP0/CPU0:router(config-mac_policy)#
```

macsec shutdown

To enable MACsec shutdown, use the **macsec shutdown** command in XR Config mode. To disable MACsec shutdown, use the **no** form of the command.

macsec shutdown

Syntax Description

This command has no keywords or arguments.

Command Default The **macsec shutdown** command is disabled by default.

Command Modes XR Config mode

Command History	Release	Modification
	Release 6.3.3	This command was introduced.

Usage Guidelines Enabling the **macsec shutdown** command, brings down all macsec sessions on the MACsec-enabled interfaces and resets ports to non-macsec mode. The already existing MACsec configurations remain unaffected by enabling this feature.

Disabling the **macsec shutdown** command, brings up MACsec sessions for the configured interfaces and enforces MACsec policy on the port.



Warning Configuring **macsec shutdown** command disables MACsec on all data ports, system wide. Execute **clear** command to erase cached configuration or **commit** command to continue.

Task ID	Task ID	Operation
		system read, write

Example

The following example shows how to enable MACsec shutdown:

```
RP/0/RSP0/CPU0:router# configure terminal
RP/0/RSP0/CPU0:router(config)# macsec shutdown
```

show macsec mka summary

To display the Summary of MACsec Sessions, use the **show macsec mka summary** command in EXEC mode.

show macsec mka summary

Syntax Description

This command has no keywords or arguments.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec mka summary** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows how to view MACsec mka summary information for a specific interface.

```
Router# show macsec mka summary
Fri Dec 15 06:41:13.299 UTC
```

```
NODE: node0_RP0_CPU0
```

Interface-Name	Status	Cipher-Suite	KeyChain	PSK/EAP	CKN
TF0/0/0/24	Secured	GCM-AES-XPB-256	kc1	PRIMARY	1111
TF0/0/0/25	Secured	GCM-AES-XPB-256	kc1	PRIMARY	1111
TF0/0/0/26	Secured	GCM-AES-XPB-256	kc1	PRIMARY	1111
TF0/0/0/27	Secured	GCM-AES-XPB-256	kc1	PRIMARY	1111

```
Total MACSec Sessions : 4
Secured Sessions      : 4
Pending Sessions      : 0
Suspended Sessions    : 0
Active Sessions       : 0
```

show macsec mka session

To display the detailed Information of MACsec Sessions, use the **show macsec mka session** command in EXEC mode.

show macsec mka session interface *interface name* **location** *location name* **detail**

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	location	Specifies the node location to enable the MACsec details.
	<i>location name</i>	Enables MACsec mode for a specific node.
	detail	(Optional) Detailed information specific to session.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec mka session** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows how to view MACsec mka session information for a specific interface.

```
Router# show macsec mka session
Fri Dec 15 06:31:38.457 UTC

NODE: node0_RP0_CPU0
=====
```

Interface-Name	Local-TxSCI	#Peers	Status	Key-Server	PSK/EAP	CKN
TF0/0/0/24	ac3a.67ee.281c/0001	1	Secured	YES	PRIMARY	1111
TF0/0/0/25	ac3a.67ee.281d/0001	1	Secured	YES	PRIMARY	1111
TF0/0/0/26	ac3a.67ee.281e/0001	1	Secured	YES	PRIMARY	1111
TF0/0/0/27	ac3a.67ee.281f/0001	1	Secured	YES	PRIMARY	1111

show macsec mka interface detail

To display detailed information on MACsec interfaces, use the **show macsec mka interface detail** command in the EXEC mode.

show macsec mka interface *interface name* **detail**

Syntax Description	<i>interface name</i>	Specifies the name of the interface for which you want to view the MACsec details.
---------------------------	-----------------------	--

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines

The **show macsec mka interface detail** command is available only with the installation of the k9sec rpm.

The **show macsec mka interface detail** command displays information about all MACsec-enabled interfaces across all nodes. If you need MACsec information for a specific interface, use the **show macsec mka interface *interface name* detail** command.

Task ID	Task ID	Operation
	system read	

This example shows how to view the MACsec information for a specific interface:

```
Router# show macsec mka interface detail
Fri Dec 15 09:03:02.553 UTC

Number of interfaces on node node0_RP0_CPU0 : 4
-----

Interface Name : TwentyFiveGigE0/0/0/24
  Interface Namestring      : TwentyFiveGigE0/0/0/24
  Interface short name     : TF0/0/0/24
  Interface handle        : 0x3c000060
  Interface number       : 0x3c000060
  MacSecControlledIfh    : 0x3c0081b0
  MacSecUnControlledIfh  : 0x3c0081b8
  Interface MAC           : ac3a.67ee.281c
  Ethertype               : 888E
  EAPoL Destination Addr  : 0180.c200.0003
  MACsec Shutdown        : FALSE
  Config Received         : TRUE
  IM notify Complete      : TRUE
  MACsec Power Status     : N/A
  Interface CAPS Add      : TRUE
  RxSA CAPS Add          : TRUE
  TxSA CAPS Add          : TRUE
```

```

Principal Actor          : Primary
MKA PSK Info
  Key Chain Name        : kc1
  MKA Cipher Suite      : AES-128-CMAC
  CKN                   : 11 11
MKA fallback_PSK Info
  fallback keychain Name : - NA -
Policy                   : DEFAULT-POLICY
SKS Profile              : N/A
Traffic Status           : Protected
Rx SC 1
  Rx SCI                 : ac4a6730061c0001
  Rx SSCI                : 1
  Peer MAC               : ac:4a:67:30:06:1c
  Is XPN                 : YES
  SC State               : Provisioned
  SAK State[0]           : Provisioned
  Rx SA Program Req[0]   : 2023 Dec 13 09:26:12.110
  Rx SA Program Rsp[0]  : 2023 Dec 13 09:26:12.172
SAK Data
  SAK[0]                 : ***
  SAK Len                : 32
  SAK Version            : 1
  HashKey[0]             : ***
  HashKey Len           : 16
  Conf offset            : 0
  Cipher Suite           : GCM-AES-XPB-256
  CtxSalt[0]             : ea ae af 7a b4 8b 1f 60 dd e9 60 a9
  CtxSalt Len           : 12
  ssci                   : 1

```

This example shows how to view the MACsec information for a interface:

```

router#show macsec mka interface
Fri Dec 15 06:45:25.738 UTC
=====
Interface-Name      KeyChain-Name      Fallback-KeyChain      Policy Name
=====
TF0/0/0/24          kc1                 - NA -                  DEFAULT-POLICY
TF0/0/0/25          kc1                 - NA -                  DEFAULT-POLICY
TF0/0/0/26          kc1                 - NA -                  DEFAULT-POLICY
TF0/0/0/27          kc1                 - NA -                  DEFAULT-POLICY

```

show macsec mka statistics

To display MKA interface and session statistics, use the **show macsec mka statistics** command in EXEC mode.

show macsec mka statistics [**interface** *interface name* | **location** *location name*]

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	location <i>location name</i>	(Optional) Location of the node to view global statistics of the MKA instance.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec mka statistics** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows the output for **show macsec mka statistics**:

```
Router# show macsec mka statistics location 0/RP0/CPU0
Fri Dec 15 06:43:21.985 UTC
```

```
MKA Global Statistics
=====
MKA Session Totals
  Secured..... 10
  Reauthentication Attempts.. 0

  Deleted (Secured)..... 6
  Keepalive Timeouts..... 0

CA Statistics
  Pairwise CAKs Derived..... 0
  Pairwise CAK Rekeys..... 0
  Group CAKs Generated..... 0
  Group CAKs Received..... 0

SA Statistics
  SAKs Generated..... 10
  SAKs Rekeyed..... 0
  SAKs Received..... 0
```

```
SAK Responses Received..... 10
PPK Tuple Generated..... 0
PPK Retrieved..... 0

MKPDU Statistics
MKPDUs Validated & Rx..... 480156
  "Distributed SAK"..... 0
  "Distributed CAK"..... 0
  "Distributed PPK"..... 0
  "PPK Capable"..... 0
MKPDUs Transmitted..... 480167
  "Distributed SAK"..... 10
  "Distributed CAK"..... 0
  "Distributed PPK"..... 0
  "PPK Capable"..... 0
```

show macsec mka client

To display MACsec MKA client traces, use the **show macsec mka client** command in EXEC mode.

show macsec mka client [trace {all | errors | events | info}]

Syntax Description	
all	(Optional) Show all MACsec MKA client traces for the specified node, or the current node if none is specified.
errors	(Optional) Show MACsec MKA client error traces for the specified node, or the current node if none is specified.
events	(Optional) Show MACsec MKA client event traces for the specified node, or the current node if none is specified.
info	(Optional) Show MACsec MKA client info traces for the specified node, or the current node if none is specified.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec mka trace** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows the output for **show macsec mka client trace all**:

```
Router# show macsec mka client trace all
Tue Dec  5 10:32:14.266 UTC
1 wrapping entries (10432 possible, 192 allocated, 0 filtered, 1 total)
Dec  4 09:56:25.544 macsec_mka/client/events 0/RP0/CPU0 t5544 TP257:aipc, server:driver,
client:default, init from pid:4779
```

show macsec mka standby

To display MACsec MKA information from hot standby node, use the **show macsec mka standby** command in EXEC mode.

show macsec mka standby [**interface** | **session** | **statistics**] { *interface name* **detail** } [**summary**]

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	detail	(Optional) detailed information specific to Interface/Session

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec mka standby** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows the output for **show macsec mka standby summary**:

```
Router# show macsec mka standby summary
Tue Dec  5 10:38:29.004 UTC

Total MACSec Sessions : 0
  Secured Sessions    : 0
  Pending Sessions    : 0
  Suspended Sessions  : 0
  Active Sessions     : 0
```

show macsec mka trace

To display MACsec MKA traces, use the **show macsec mka trace** command in EXEC mode.

show macsec mka trace [all | base | config | errors | events | new-errors | new-events]

Syntax Description	
all	(Optional) Show all MACsec MKA traces for the specified node, or the current node if none is specified.
base	(Optional) Show MACsec MKA base traces for the specified node, or the current node if none is specified.
config	(Optional) Show MACsec MKA config traces for the specified node, or the current node if none is specified.
errors	(Optional) Show MACsec MKA error traces for the specified node, or the current node if none is specified.
events	(Optional) Show MACsec MKA event traces for the specified node, or the current node if none is specified.
new-errors	(Optional) Show MACsec MKA new-errors traces for the specified node, or the current node if none is specified.
new-events	(Optional) Show MACsec MKA new-event traces for the specified node, or the current node if none is specified.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec mka trace** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows the output for **show macsec mka trace all**:

```
Router# show macsec mka trace all
Fri Dec 15 06:42:04.919 UTC
2385 wrapping entries (8576 possible, 3968 allocated, 0 filtered, 2385 total)
Dec 12 15:12:30.077 macsec_mka/base 0/RP0/CPU0 t10778 TP1002: ***** MacSec MKA(10778)
  init start *****.
Dec 12 15:12:30.077 macsec_mka/new_events 0/RP0/CPU0 t10778 TP1002: ***** MacSec
MKA(10778) init start *****.
```



```
Dec 12 15:12:30.077 macsec_mka/events 0/RP0/CPU0 t10778 TP18: MKA_EVENT: Successfully created
mka event queue
Dec 12 15:12:30.077 macsec_mka/base 0/RP0/CPU0 t10778 TP10: Timer init Success
Dec 12 15:12:30.077 macsec_mka/base 0/RP0/CPU0 t10778 TP801: process respawn_count:1
Dec 12 15:12:30.080 macsec_mka/base 0/RP0/CPU0 t10778 TP164: platform_capa : macsec:1,
macsec-service:0, macsec-subif:0, if_capa:1, ddp:1, secy_intf:1
Dec 12 15:12:30.080 macsec_mka/base 0/RP0/CPU0 t10778 TP164: platform_capa : ea_ha:0,
driver_ha:1, ea_retry:1, plt_sci:0, persist:0, max_an:3, no_secure_loc:1
Dec 12 15:12:30.080 macsec_mka/base 0/RP0/CPU0 t10778 TP164: platform_capa : issu:0,
ppk_support:1, pl_if_data:0, power_status:0, hot_stdbby:0
Dec 12 15:12:30.080 macsec_mka/base 0/RP0/CPU0 t10778 TP1341: HA role: Active
```

show macsec secy

To display Interface based MACsec dataplane (SecY) statistics, use the **show macsec secy** command in EXEC mode.

```
show macsec secy [ stats { interface interface name sc } ]
```

Syntax Description	Parameter	Description
	<i>interface name</i>	MACsec enabled Interface to be specified..
	sc	(Optional) Display Secure Channel Statistics for both Rx-SC,SA and Tx-SC,SA specific to the given interface

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec secy** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows the output for **show macsec secy**:

```
Router# show macsec mka secy stats interface HundredGigE 0/0/0/29 sc
Interface Stats
  InPktsUntagged      : 0
  InPktsNoTag         : 0
  InPktsBadTag        : 0
  InPktsUnknownSCI   : 0
  InPktsNoSCI         : 0
  InPktsOverrun       : 0
  InOctetsValidated   : 0
  InOctetsDecrypted   : 3510182
  OutPktsUntagged     : 0
  OutPktsTooLong      : 0
  OutOctetsProtected  : 0
  OutOctetsEncrypted  : 1827580
```

show macsec ea

To display MACsec programming details for each interface, use the **show macsec ea** command in EXEC mode.

show macsec ea [**idb** { **interface** *interface name* | | **location** *location name* } | **trace** {**all** | **errors** | **events** | **base**}

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	location	Specifies the node location to enable the MACsec details.
	<i>location name</i>	Enables MACsec mode for a specific node.
	all	(Optional) Show all MACsec EA traces for the specified node, or the current node if none is specified.
	base	(Optional) Show MACsec EA base traces for the specified node, or the current node if none is specified.
	errors	(Optional) Show MACsec EA error traces for the specified node, or the current node if none is specified.
	events	(Optional) Show MACsec EA event traces for the specified node, or the current node if none is specified.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec ea** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows how to view MACsec information for a specific interface located on location 0/RP0/CPU0.

```
Router# show macsec ea idb location 0/RP0/CPU0
Mon Dec 4 03:59:07.481 UTC
```

```

IDB Details:
  if_sname           : TF0/0/0/23
  if_handle          : 0x3c000068
  MacSecControlledIfh : 0x3c008120
  MacSecUnControlledIfh : 0x3c008128
  Replay window size : 64
  Local MAC          : ac:4a:67:30:06:1b
  Rx SC Option(s)    : Validate-Frames Replay-Protect
  Tx SC Option(s)    : Protect-Frames Always-Include-SCI
  Security Policy     : MUST SECURE
  Delay Protection    : FALSE
  Sectag offset      : 0
  db_init Req        : 2023 Dec 03 09:36:22.656
  db_init Rsp        : 2023 Dec 03 09:36:22.662
  if_enable Req      : 2023 Dec 03 09:36:22.663
  if_enable Rsp      : 2023 Dec 03 09:36:23.127
  Rx SC 1
  Rx SCI             : ac3a67ee281b0001
  Peer MAC           : ac:3a:67:ee:28:1b
  Stale              : NO
  SAK Data
  SAK[2]             : ***
  SAK Len            : 32
  SAK Version        : 1
  HashKey[2]         : ***
  HashKey Len        : 16
  Conf offset        : 0
  Cipher Suite       : GCM-AES-XPB-256
  CtxSalt[2]         : e8 5c ca 8f b3 7a 9d 65 2a 35 ac f8
  ssci               : 2
  Rx SA Program Req[2]: 2023 Dec 03 09:36:27.632
  Rx SA Program Rsp[2]: 2023 Dec 03 09:36:27.712

```

This example shows how to view events associated with the MACsec ea command.

```
Router#show macsec ea trace events
```

```

Mon Dec  4 03:57:58.463 UTC
59 wrapping entries (18496 possible, 320 allocated, 0 filtered, 59 total)
Dec  3 09:36:02.903 macsec_ea/events 0/RP0/CPU0 t6945 TP155: ***** MacSec EA(0x1b21)
process START *****.
Dec  3 09:36:02.926 macsec_ea/events 0/RP0/CPU0 t6945 TP180: macsec_ea_programming_conn_up_cb
received.
Dec  3 09:36:02.966 macsec_ea/events 0/RP0/CPU0 t6945 TP191: macsec_ea_platform_init success
Dec  3 09:36:03.050 macsec_ea/events 0/RP0/CPU0 t6945 TP208: ea_plat_cb_evq:
event_async_attach success, pulse_code:0x7c
Dec  3 09:36:03.050 macsec_ea/events 0/RP0/CPU0 t6945 TP211: ea_plat_cb_evq: created
successfully
Dec  3 09:36:03.083 macsec_ea/events 0/RP0/CPU0 t6945 TP121: ***** Started MacSec
EA(0x1b21) Successfully *****.

```

show macsec open-config

To display Open-config MACSEC traces, use the **show macsec open-config** command in EXEC mode.

show macsec opwn-config trace

Syntax Description

This command has no keywords or arguments.

Command Default	No default behavior or values.
------------------------	--------------------------------

Command Modes	EXEC mode
----------------------	-----------

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines	The show macsec open-config command is available only with the installation of the k9sec rpm.
-------------------------	--

Task ID	Task ID	Operation
	cisco-support	read

This example shows the output for **show macsec open-config trace**:

```
Router#show macsec open-config trace
Fri Dec 15 09:08:37.760 UTC
20 wrapping entries (320 possible, 64 allocated, 0 filtered, 20 total)
Dec 12 12:42:43.823 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_edm_open:313, Successful
Dec 12 12:42:43.823 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_mka_oper_gl_sysdb_bind:173,
sysdb_bind successful
Dec 12 12:42:43.823 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_if_sysdb_bind:315, sysdb bind
successful
Dec 12 12:42:43.827 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_mka_sysdb_bind:343, sysdb
bind: success
Dec 12 12:42:43.827 oc_macsec/all 0/RP0/CPU0 t16252
oc_macsec_mka_gl_stats_oper_sysdb_bind:372, sysdb_bind success
Dec 12 12:42:43.847 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_reg_cfg_notif:250, Successful
Dec 12 15:12:31.317 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_20: notif macsec_if_config, create/update
Dec 12 15:13:52.560 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_21: notif macsec_if_config, create/update
Dec 12 15:16:41.447 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_22: notif macsec_if_config, create/update
Dec 12 15:18:12.700 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_23: notif macsec_if_config, create/update
Dec 12 15:47:30.887 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TenGigE0_0_0_24: notif macsec_if_config, create/update
Dec 13 08:39:35.878 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TenGigE0_0_0_24: notif macsec_if_config, delete
Dec 13 08:46:15.995 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_20: notif macsec_if_config, delete
Dec 13 08:46:15.995 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
```

show macsec open-config

```
TwentyFiveGigE0_0_0_21: notif macsec_if_config, delete
Dec 13 08:46:15.995 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_22: notif macsec_if_config, delete
Dec 13 08:46:15.995 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_23: notif macsec_if_config, delete
Dec 13 09:25:40.478 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_24: notif macsec_if_config, create/update
Dec 13 09:27:59.242 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_25: notif macsec_if_config, create/update
Dec 13 09:29:32.355 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_26: notif macsec_if_config, create/update
Dec 13 09:31:03.658 oc_macsec/all 0/RP0/CPU0 t16252 oc_macsec_notify_if_macsec:74,
TwentyFiveGigE0_0_0_27: notif macsec_if_config, create/update
```

show macsec platform hardware

To display hardware-specific details for MACsec on each interface, use the **show macsec platform hardware** command in EXEC mode.

```
show macsec platform hardware [flow | sa | stats] { interface interface name | location location name
}
```

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	location	Specifies the node location to enable the MACsec details.
	<i>location name</i>	Enables MACsec mode for a specific node.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec platform hardware** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows how to view MACsec platform hardware information for a specific interface located on location 0/RP0/CPU0.

```
Router# show macsec platform hardware flow location 0/RP0/CPU0
Wed Dec 20 08:39:18.958 UTC
-----
Interface : TwentyFiveGigE0_0_0_27

-----
Interface : TwentyFiveGigE0_0_0_26

-----
Interface : TwentyFiveGigE0_0_0_25

-----
```

```
show macsec platform hardware
```

```
Interface : TwentyFiveGigE0_0_0_24
```


show macsec platform idb

To display interface database (IDB) details specific to MACsec, use the **show macsec platform idb** command in EXEC mode.

```
show macsec platform idb { interface interface name | location location name }
```

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	location	Specifies the node location to enable the MACsec details.
	<i>location name</i>	Enables MACsec mode for a specific node.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec platform idb** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows how to view MACsec platform idb information for a specific interface located on location 0/RP0/CPU0.

```
Router# show macsec platform idb location 0/RP0/CPU0
Wed Dec 20 08:55:47.745 UTC
```

```
-----
EA IDB Details:
```

```
-----
IF Handle           : 0x3c000048
IF Name             : TF0/0/0/27
```

```
-----
EA IDB Details:
```

```
-----
IF Handle           : 0x3c000050
IF Name             : TF0/0/0/26
```

```
-----
EA IDB Details:
```

```
show macsec platform idb
```

```
-----  
IF Handle      : 0x3c000058  
IF Name       : TF0/0/0/25  
-----
```

```
EA IDB Details:  
-----
```

```
IF Handle      : 0x3c000060  
IF Name       : TF0/0/0/24
```

show macsec platform stats

To display MACsec platform statistics, use the **show macsec platform stats** command in EXEC mode.

show macsec platform stats { **interface** *interface name* | **location** *location name* }

Syntax Description

interface	Specifies the interface name to view MACsec details.
<i>interface name</i>	Enables MACsec mode for a specified interface.
location	Specifies the node location to enable the MACsec details.
<i>location name</i>	Enables MACsec mode for a specific node.

Command Default

No default behavior or values.

Command Modes

EXEC mode

Command History

Release	Modification
Release 7.0.1	This command was introduced.

Usage Guidelines

The **show macsec platform stats** command is available only with the installation of the k9sec rpm.

Task ID

Task ID	Operation
interface	read

This example shows how to view MACsec platform statistics information for a specific interface located on location 0/RP0/CPU0.

```
Router# show macsec platform stats location 0/RP0/CPU0
Wed Dec 20 08:56:13.285 UTC
```

```
-----
Interface : TwentyFiveGigE0_0_0_27
```

```
-----
Global Statistics: Ingress
```

```
-----
Rx Ctrl Pkts           : 47300
Rx Ctrl Octets        : 6905732
Rx Data Pkts          : 13
Rx Data Octets        : 894
Rx OverSized Pkts     : 0
Rx Pkts Bad Tag       : 0
Rx Pkts No SCI        : 0
Rx Pkts No Tag        : 0
Rx Pkts Tagged        : 0
Rx Pkts Untagged     : 0
```

show macsec platform stats

```
Rx Pkts Unknown SCI           : 0
Rx Pkts Untagged Miss        : 0
Rx Transform Error Pkts      : 0
Rx Pkts SA Not In Use       : 0
```

Global Statistics: Egress

```
Tx Ctrl Pkts                  : 47308
Tx Ctrl Octets                : 6906216
Tx Data Pkts                  : 16
Tx Data Octets                : 894
Tx Pkts SA Not In Use        : 0
Tx Untagged Pkts             : 0
Tx Transform Error Pkts      : 0
```

SA Statistics:Ingress

```
Index                         : 0
SCI                           : ac3a67ee281f0001
Current AN                     : 0
Port                           : 27
Rx Data Pkts Decrypted         : 13
Rx Data Octets Decrypted       : 894
Rx Pkts Delayed                : 0
Rx Pkts Invalid                : 0
Rx Pkts Late                   : 0
Rx Pkts Not Using SA          : 0
Rx Pkts Not Valid              : 0
Rx Pkts Unchecked              : 0
Rx Pkts Untagged Hit          : 0
Rx Pkts Unused SA              : 0
```

show macsec platform trace

To display MACsec platform trace logs, use the **show macsec platform trace** command in EXEC mode.

show macsec platform hardware trace [**all** | **detail** | **errors** | **events**] { **interface** *interface name* | **location** *location name* }

Syntax Description	Parameter	Description
	interface	Specifies the interface name to view MACsec details.
	<i>interface name</i>	Enables MACsec mode for a specified interface.
	location	Specifies the node location to enable the MACsec details.
	<i>location name</i>	Enables MACsec mode for a specific node.
	all	(Optional) Show all MACsec Platform traces for the specified node, or the current node if none is specified.
	detail	(Optional) Show MACsec Platform detail traces for the specified node, or the current node if none is specified.
	errors	Optional) Show MACsec Platform error traces for the specified node, or the current node if none is specified.
	events	(Optional) Show MACsec Platform event traces for the specified node, or the current node if none is specified.

Command Default No default behavior or values.

Command Modes EXEC mode

Command History	Release	Modification
	Release 7.0.1	This command was introduced.

Usage Guidelines The **show macsec platform trace** command is available only with the installation of the k9sec rpm.

Task ID	Task ID	Operation
	interface	read

This example shows how to view MACsec platform trace information for a specific interface located on location 0/RP0/CPU0.

```
Router# show macsec platform trace detail location 0/RP0/CPU0
Wed Dec 20 08:57:03.178 UTC
2023-12-19:06.28.09.556530212:34390:secdrv_client_camui_ipc_common_fvt_init:COMMJ_IPC_DET_36:secdrv_client_camui_ipc_common_fvt_init
```

show macsec platform trace

```
called
2023-12-19:06.28.09.556530980:34390:secydrv_client_commu_ipc_fvt_init:COMMU_IPC_DET_53:secydrv_client_commu_ipc_fvt_init
called
2023-12-19:06.28.09.558317574:34390:secydrv_commu_ipc_platform_init:COMMU_IPC_DET_83:secydrv_commu_ipc_platform_init
called
2023-12-19:06.28.10.579426302:34390:secydrv_commu_ipc_resync_start:COMMU_IPC_DET_106:secydrv_commu_ipc_resync_start
called
2023-12-19:06.28.10.596378984:34390:secydrv_commu_ipc_resync_stop:COMMU_IPC_DET_129:secydrv_commu_ipc_resync_stop
called
2023-12-19:06.28.19.598852376:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.28.29.598939886:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.28.39.599043710:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.28.49.599136368:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.28.59.599221556:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.29.09.599315246:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.29.19.599396186:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.29.29.599470492:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.29.39.599542858:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.29.49.599616712:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.29.59.599691262:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.30.09.599768752:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.30.19.599842944:34390:macsec_ea_platform_poll_pn_exceeded:EAPD_DET_3192:PN
Threshold Check:No active sessions
2023-12-19:06.30.27.011625732:34390:macsec_ea_platform_idb_init:EAPD_DET_1026:IDB Init:
ifh: 0x3c000060, if_name TF0/0/0/24, slot 0
2023-12-19:06.30.27.011632184:34390:secydrv_commu_ipc_if_init:COMMU_IPC_DET_151:secydrv_commu_ipc_if_init
called
```

sak-rekey-interval

To set a timer value to rekey the MACsec secure association key (SAK) at a specified interval, use the **sak-rekey-interval** command in the macsec-policy configuration mode. To disable this feature, use the **no** form of this command.

sak-rekey-interval *timer-value*

Syntax Description	<i>timer-value</i> Specifies the timer value, in seconds. Range is 60 to 2592000.				
Command Default	The timer is set to OFF, by default				
Command Modes	MACsec policy configuration.				
Command History	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.3.3</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.3.3	This command was introduced.
Release	Modification				
Release 6.3.3	This command was introduced.				
Task ID	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>system</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	system	read, write
Task ID	Operations				
system	read, write				

Examples

This example shows how to set a timer value to rekey the MACsec SAK:

```
Router#configure
Router(config)#macsec-policy test-policy
Router(config-macsec-policy)#sak-rekey-interval 120
Router(config-macsec-policy)#commit
```

security-policy

Configures the type of data that is allowed to transit out of the interface configured with MACsec in the MACsec policy configuration mode. To disable this feature, use the **no** form of this command.

security-policy {**should-secure** | **must-secure**}

Syntax Description	
should-secure	Configures the interface on which the MACsec policy is applied, to permit all data.
must-secure	Configures the interface on which the MACsec policy is applied, to permit only MACsec encrypted data.

Command Default Default value is **must-secure**.

Command Modes MACsec policy configuration.

Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **security-policy** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# macsec-policy mac_policy
RP/0/RP0/CPU0:router(config-mac_policy)# security-policy must-secure
RP/0/RP0/CPU0:router(config-mac_policy)#
```


show crypto sks profile

To display the details or statistics of the Session Key Service (SKS) profiles in the router, use the **show crypto sks profile** command in the XR EXEC mode.

```
show crypto sks profile { profile-name | all } [ stats ]
```

Syntax Description	Parameter	Description
	<i>profile name</i>	Specifies the name of the SKS profile.
	all	Specifies all the SKS profiles in the router.
	stats	Displays the statistics of the SKS profiles.

Command Default None

Command Modes XR EXEC mode

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task	Operation
	system	read

The following example shows how to view the SKS profile details in a router:

```
Router(config)# show crypto sks profile all
Profile Name      :ProfileR1toR2
Myidentifier      :Router1
Type              :Remote
Reg Client Count  :1

Server
IP                :192.0.2.35
Port              :10001
Vrf               :Notconfigured
Source Interface  :Notconfigured
Status            :Connected
Entropy           :true
Key               :true
Algorithm         :QKD
Local identifier  :Alice
Remote identifier :Alice

Peerlist
QKD ID           :Bob
State            :Connected
```

```
Peerlist
QKD ID           :Alice
State            :Connected
```

The following example shows how to view the SKS profile statistics in a router:

```
Router# show crypto sks profile all stats
Profile Name      : ProfileR1toR2
My identifier     : Router1
Server
  IP              : 192.0.2.35
  Port            : 10001
  Status          : connected
Counters
  Capability request      : 1
  Key request            : 3
  Key-id request         : 0
  Entropy request        : 0
  Capability response     : 1
  Key response           : 3
  Key-id response        : 0
  Entropy response       : 0
  Total request          : 4
  Request failed         : 0
  Request success       : 4
  Total response         : 4
  Response failed        : 0
  Response success       : 4
  Retry count            : 0
  Response Ignored       : 0
  Cancelled count        : 0
Response time
  Max Time              : 100 ms
  Avg Time               : 10 ms
  Min Time               : 50 ms
Last transaction
  Transaction Id         : 9
  Transaction type       : Get key
  Transaction status     : Response data received, successfully
  Http code              : 200 OK (200)
```

window-size

Configures the replay protection window size in MACsec policy configuration mode. To disable this feature, use the **no** form of this command.

The replay protection window size indicates the number of out-of-sequence frames that can be accepted at the interface configured with MACsec, without being dropped.

window-size *value*

Syntax Description *value* Number of out-of-sequence frames that can be accepted at the interface without being dropped. The range is 0-1024.

Command Default Default value is 64.

Command Modes MACsec policy configuration.

Command History	Release	Modification
	Release 5.3.2	This command was introduced.

Task ID	Task ID	Operations
	system	read, write

Examples

The following example shows how to use the **window-size** command:

```
RP/0/RP0/CPU0:router# configure t
RP/0/RP0/CPU0:router(config)# macsec-policy mac_policy
RP/0/RP0/CPU0:router(config-mac_policy)# window-size 64
```

■ window-size