



# IPv6 Tunnel Commands

---

This chapter contains the following sections:

- [interface tunnel, on page 2](#)
- [tunnel destination, on page 3](#)
- [tunnel isatap solicitation-interval, on page 4](#)
- [tunnel isatap robustness, on page 5](#)
- [show ipv6 tunnel, on page 6](#)

# interface tunnel

To enter into the Interface Configuration (Tunnel) mode, use the **interface tunnel** command in Global Configuration mode.

## Syntax

**interface tunnel *number***

## Parameters

- ***number***—Specifies the tunnel number.

## Command Mode

Global Configuration mode

## Example

The following example enters the Interface Configuration (Tunnel) mode.

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-if)# tunnel source auto
switchxxxxxx(config-if)# exit
```

# tunnel destination

To specify the destination IPv4 address for the manual tunnel interface, use the **tunnel destination** command in Interface (Tunnel) Configuration mode. To remove the destination IPv4 address, use the **no** form of this command.

## Syntax

**tunnel destination** {*host-name* | *ip-address*}

no tunnel destination

## Parameters

- *host-name*—DNS name of the remote host.
- *ip-address*—IPv4 address of the remote host.

## Default Configuration

No tunnel interface destination is specified.

## Command Mode

Interface (Tunnel) Configuration mode

## User Guidelines

You cannot configure two tunnels to use the same encapsulation mode with exactly the same source and destination address.

## Example

The following example shows how to configure the tunnel destination address for Manual IPv6 tunnel:

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip address 10.0.0.1 255.255.255.0
switchxxxxxx(config-if)# exit
switchxxxxxx(config)# interface tunnell1
switchxxxxxx(config-if)# ipv6 address 3ffe:b00:c18:1::3/127
switchxxxxxx(config-if)# tunnel source vlan1
switchxxxxxx(config-if)# tunnel destination 192.168.30.1
switchxxxxxx(config-if)# tunnel mode ipv6ip
switchxxxxxx(config-if)# exit
```

```
tunnel isatap solicitation-interval
```

# tunnel isatap solicitation-interval

To set the time interval between unsolicited router solicitation messages, use the **tunnel isatap solicitation-interval** command in Global Configuration mode. To restore the default configuration, use the **no** form of this command.

## Syntax

```
tunnel isatap solicitation-interval seconds
```

```
no tunnel isatap solicitation-interval
```

## Parameters

- *seconds*—Specifies the time interval in seconds between ISATAP router solicitation messages. (Range: 10–3600).

## Default Configuration

The default time interval between ISATAP router solicitation messages is 10 seconds.

## Command Mode

Global Configuration mode

## User Guidelines

This command determines the interval between unsolicited router solicitation messages sent to discovery an ISATAP router.

## Example

The following example sets the time interval between ISATAP router solicitation messages to 30 seconds.

```
switchxxxxxx(config)# tunnel isatap solicitation-interval 30
```

# tunnel isatap robustness

To configure the number of router solicitation refresh messages that the device sends, use the **tunnel isatap robustness** command in Global Configuration mode. To restore the default configuration, use the **no** form of this command.

## Syntax

**tunnel isatap robustness *number***

**no tunnel isatap robustness**

## Parameters

- **number**—Specifies the number router solicitation refresh messages that the device sends. (Range: 1–20).

## Default Configuration

The default number of router solicitation refresh messages that the device sends is 3.

## Command Mode

Global Configuration mode

## User Guidelines

The router solicitation interval (when there is an active ISATAP router) is the minimum-router-lifetime that is received from the ISATAP router, divided by (Robustness + 1).

## Example

The following example sets the number of router solicitation refresh messages that the device sends to 5.

```
switchxxxxxx(config)# tunnel isatap robustness 5
```

**show ipv6 tunnel**

# show ipv6 tunnel

To display information on IPv6 tunnels, use the **show ipv6 tunnel** command in User EXEC mode.

## Syntax

**show ipv6 tunnel [all]**

## Parameters

- **all**—(Optional) The switch displays all parameters of the tunnel. If the keyword is not configured only the tunnel parameters corresponding to its type are displayed.

## Command Mode

User EXEC mode

**Example 1.** The following example displays information on the ISATAP tunnel, when the **all** keyword is not configured:

```
switchxxxxxx# show ipv6 tunnel
Tunnel 1
  Tunnel type : Manual
  Tunnel status : UP
  Tunnel Local address type : VLAN 100
  Tunnel Local Ipv4 address : 192.1.3.4
  Tunnel Remote Ipv4 address : 192.3.4.5
Tunnel 2
  Tunnel type : ISATAP
  Tunnel status : UP
  Tunnel Local address type : auto
  Tunnel Local Ipv4 address : 192.1.3.4
  Router DNS name : ISATAP
  Router IPv4 addresses
    1.1.1.1      Detected
    100.1.1.1    Detected
    14.1.100.1   Not Detected
  Router Solicitation interval : 10 seconds
  Robustness : 2
Tunnel 3
  Tunnel type : 6to4
  Tunnel status : UP
  Tunnel Local address type : auto
  Tunnel Local Ipv4 address : 192.1.3.4
```

**Example 2.** The following example displays information when the **all** keyword is configured:

```
switchxxxxxx# show ipv6 tunnel all
Tunnel 1
  Tunnel type : Manual
  Tunnel status : UP
  Tunnel Local address type : VLAN 100
  Tunnel Local Ipv4 address : 192.1.3.4
  Manual parameters
    Tunnel Remote Ipv4 address : 192.3.4.5
  ISATAP Parameters
    Router DNS name : ISATAP
```

```
Router Solicitation interval : 10 seconds
Robustness : 2

Tunnel 2
  Tunnel type : Manual
  Tunnel status : DOWN
  Tunnel Local address type : auto
  Manual parameters
    Tunnel Remote Ipv4 address : 0.0.0.0
  ISATAP Parameters
    Tunnel Local Ipv4 address : 0.0.0.0
    Router DNS name : ISATAP
    Router Solicitation interval : 10 seconds
  Robustness : 2

Tunnel 3
  Tunnel type : ISATAP
  Tunnel status : UP
  Tunnel Local address type : auto
  Manual parameters
    Tunnel Remote Ipv4 address : 0.0.0.0
  ISATAP Parameters
    Tunnel Local Ipv4 address : 192.1.3.4
    Router DNS name : ISATAP
    Router IPv4 addresses
      1.1.1.1       Detected
      100.1.1.1     Detected
      14.1.100.1    Not Detected
    Router Solicitation interval : 10 seconds
  Robustness : 2
```

```
show ipv6 tunnel
```