

# **Configuring RFC 5580 Location Attributes**

- Feature History for RFC 5580 Location Attributes, on page 1
- Information About RFC 5580 Location Attributes , on page 2
- Information About Location-Capable Attribute, on page 4
- Restriction for Configuring RFC 5580 Location Attributes, on page 4
- Configuring Location Delivery Based on Out-of-Band Agreement (CLI), on page 4
- Configuring Location-Capable Attribute (CLI), on page 5
- Creating Location Attributes, on page 5
- Associating Location Attributes with User Location (CLI), on page 9
- Associating Location Attributes with the NAS Location (CLI), on page 10
- Verifying RFC 5580 Location Attribute Configuration, on page 11

### Feature History for RFC 5580 Location Attributes

This table provides release and related information for the feature explained in this module.

This feature is also available in all the releases subsequent to the one in which they are introduced in, unless noted otherwise.

Release	Feature	Feature Information
Cisco IOS XE Cupertino 17.9.1	Support for RFC 5580 Location Attributes in the Controller	This feature uses the RFC 5580 location attributes to convey location-related information for authentication and accounting exchanges.
		The controller supports the following RFC 5580-related attributes:
		Location-Information
		Location-Data CIVIC Profile: Country
		Location-Data CIVIC Profile: CAtype 1 (State)
		Location-Data CIVIC Profile: CAtype 3 (City)
		Location-Data CIVIC Profile: CAtype 23 (Venue Name)
		Location-Data CIVIC Profile: CAtype 24 (Zip Code)
		Location-Data GEO Profile (Longitude, Latitude, and Altitude)
		Operator Name

### **Information About RFC 5580 Location Attributes**

The RFC 5580 location attributes convey location-related information for authentication and accounting exchanges.

The location information is useful in several scenarios. Wireless networks are deployed in public places, such as shopping malls, airports, hotels, and coffee shops by a diverse set of operators, such as wireless internet service providers (WISPs), cellular network operators, and fixed broadband networks. In all these scenarios, the network may need to know the user location to enable location-aware authorization, billing, or services.

To preserve user privacy, the location information must be protected against unauthorized access and distribution.

The RFC 5580 defines two types of location:

• User location: This location is more specific to users.

**Note** The user location is configured in AP.

• NAS location: This is the common location to host all the users. For instance, suppose you configure user location at AP1, other users connecting to AP1 will also have the same user location. Now other users coming from AP2 will have a different user location. Thus, if AP1 and AP2 are connected to the controller, and you configure a NAS location, then users from AP1 and AP2 are connected to the same NAS location.

Note The NAS location is configured in AAA.

You can define certain profiles in each location. Profile refers to the attributes used to define the location. Each location has two profiles, namely, Civic and Geo.

The following are the location profiles:

- **Civic Profile**: In this profile, the location is described in terms of attributes such as Country, State, City, Area, and Postal Code.
- Geo Profile: In this profile, the location is described in terms of attributes such as Latitude, Longitude, and Altitude.

For users with both user location and NAS location, you can set their location in both Civic and Geo profile formats. Such users have the following locations:

- Civic User location
- Civic NAS location
- Geo User location
- · Geo NAS location

Each location information, for instance, the civic user location, is sent using the following attributes:

- Location-Information
- Location-Data

The controller supports the following RFC 5580-related attributes:

- Location-Information
- Location-Data CIVIC Profile: Country
- Location-Data CIVIC Profile: CAtype 1 (State)
- Location-Data CIVIC Profile: CAtype 3 (City)
- Location-Data CIVIC Profile: CAtype 23 (Venue Name)
- Location-Data CIVIC Profile: CAtype 24 (Zip Code)
- Location-Data GEO Profile (Longitude, Latitude, and Altitude)
- Operator Name

Thus, a user can have four locations and one operator name.

To transfer location information, the Out-of-Band Agreement (Flow 1) delivery method mentioned in RFC 5580 is supported.

This is applicable only if the feature is enabled and location information is configured.

### **Information About Location-Capable Attribute**

Cisco IOS-XE Dublin 17.11.1 supports the Location-Capable feature attribute from RFC 5580. This attribute is sent only in the network access requests. To enable the Location-Capable attribute, configure the **radius-server attribute wireless location delivery out-of-band include-location-capable** command. This attribute informs the RADIUS server that this device can send location information.

The RFC5580 supports three flows or modes of location delivery. As per the RFC, the Location-Capable attribute should be sent in Flow-2, which is location delivery based on Initial-Request. The above-mentioned configuration enables sending this attribute in Flow-1, which is Location delivery based on Out-of-Band agreement as well.

When an authentication or authorization request is received, the Location-Capable feature attribute is added to the request along with other location attributes as per the configuration (explained in the other section). This is applicable only for wireless clients. The RADIUS server might use this information to provide network access.

# **Restriction for Configuring RFC 5580 Location Attributes**

This feature is supported only for 802.1X users.

# **Configuring Location Delivery Based on Out-of-Band Agreement** (CLI)

	ſ	
	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	radius-server attribute wireless location delivery out-of-band	Configures RFC 5580 Out-of-Band location support.
	Example:	
	<pre>Device(config)# radius-server attribute wireless location delivery out-of-band</pre>	
Step 3	end	Returns to privileged EXEC mode.
	Example:	
	Device(config)# end	

# **Configuring Location-Capable Attribute (CLI)**

Use the **radius-server attribute wireless location delivery out-of-band** command to enable the feature globally.

You can use the **radius-server attribute wireless location delivery out-of-band include-location-capable** command to include the location-capable attribute along with other location attributes.

#### Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	<b>Example:</b> Device# configure terminal	
Step 2	<pre>radius-server attribute wireless location delivery out-of-band include-location-capable Example: Device(config)# radius-server attribute wireless location delivery out-of-band include-location-capable</pre>	Configures RFC 5580 out-of-band location attributes along with enabling the location-capable attribute to be part of the access request.
Step 3	end Example: Device(config)# end	Returns to privileged EXEC mode.

# **Creating Location Attributes**

### **Configuring a Civic Profile (CLI)**

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	location civic-location identifier	Configures the civic profile for User location.
	civic_identifier	Here, <i>civic_identifier</i> refers to the civic location
	Example:	identifier string. It can take up to 215 characters.
	Device(config)# location civic-location	You can enter a total of 250 bytes to configure
	identifier USER_C_1	civic address attributes. Cisco reserves 50 bytes
		for internal information. Therefore, the

	Command or Action	Purpo	se
		remain user-c	ning 200 bytes can be used for onfigured civic location.
		Note	You can configure the following types of civic attributes and add them to the RADIUS requests:
			• Country
			• City
			• State
			Postal Code
			• Name
Step 3	country country_ID	Sets th	ne country ID.
	Example:	Note	Only two-letter ISO 3166 country
	Device(config-civic)# country IN		codes are accepted.
Step 4	city city_name	Sets th	ne city name.
	Example:		
	Device(config-civic)# city Bangalore		
Step 5	state state_name	Sets th	ne state name.
	Example:		
	Device(config-civic)# state Karnataka		
Step 6	postal-code postal_code	Sets th	ne postal code.
	Example:		
	Device(config-civic) # postal-code 562016		
Step 7	name residence_name	Sets th	ne residence name.
	Example:		
	Device(config-civic)# name Nivas		
Step 8	end	Return	ns to privileged EXEC mode.
	Example:		
	Device(config-civic)# end		

### Configuring a Geo Profile (CLI)

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	<b>Example:</b> Device# configure terminal	
Step 2	location geo-location identifier <i>geo_identifier</i>	Configures a Geo profile for user location.
	Device(config)# location geo-location identifier USER_G_1	location identifier string. It can take up to 215 characters.
Step 3	latitude latitude_in_degrees resolution [resolution_value]	Sets the latitude information. The optional parameters are documented within square brackets.
	<b>Example:</b> Device(config-geo)# latitude "34 12 15"	While configuring the latitude, you can specify the resolution, in meters. If you do not specify any resolution, a default value of 10 meters is used.
Step 4	longitude longitude_in_degrees resolution resolution_value	Sets the longitude information. The optional parameters are documented within square brackets.
	Device(config-geo)# longitude "111 59 44"	While configuring the longitude, you can specify the resolution, in meters. If you do not specify any resolution, a default value of 10 meters is used.
Step 5	<b>altitude</b> <i>altitude_value</i> { <b>feet resolution</b> <i>resolution_value</i>   <b>floor</b>   <b>meters resolution</b> <i>resolution_value</i> }	Configures the altitude for the geographic location. The optional parameters are documented within square brackets.
	<pre>Example: Device(config-geo)# altitude 10 meters resolution 10</pre>	• <i>altitude_value</i> : Refers to the altitude, in feet, floors, or meters.
		• <i>resolution_value</i> : Refers to the resolution, in feet or meters.
		<b>Note</b> Both the altitude and the altitude resolution must be in the same unit.
Step 6	resolution resolution_value	Specifies a single common resolution for latitude and longitude.
	Device(config-geo)# resolution 30	

	Command or Action	Purpose
Step 7	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-geo)# end	

## **Configuring an Operator Name (CLI)**

#### Procedure

	Command or Action	Purpose
Step 1	configure terminal	Enters global configuration mode.
	Example:	
	Device# configure terminal	
Step 2	<pre>location operator identifier identifier_name Example: Device(config)# location operator identifier USER_0_1</pre>	Configures an operator name for the user location. Here, <i>identifier_name</i> supports strings up to 215 characters in length.
Step 3	name operator-name	Configures the location operator name.
	<b>Example:</b> Device(config-operator)# name ACT	Here, <i>operator-name</i> supports strings up to 248 characters in length.
Step 4	<pre>namespace-id {E212   ICC   REALM   TADIG} Example: Device(config-operator)# namespace-id ICC</pre>	<ul> <li>Configures the namespace for a location.</li> <li>The following are the namespace options:</li> <li>E212: Refers to the Mobile Country Code (MCC) and Mobile Network Code (MNC).</li> <li>ICC: Refers to the International Telecommunication Union Carrier Codes (ICC).</li> <li>REALM: Refers to any registered domain name.</li> <li>TADIG: Refers to the Transferred Account Data Interchange Group (TADIG) code.</li> </ul>

	Command or Action	Purpose
		<ul> <li>Note</li> <li>If you have not configured any namespace, REALM is used as the default value.</li> <li>The operator name can be associated with both NAS-Location and USER-Location. When an operator name is configured at both the locations, the operator name that is configured in USER-Location takes precedence.</li> </ul>
Step 5	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-operator)# end	

# **Associating Location Attributes with User Location (CLI)**

#### Procedure

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	ap location name location_name	Configures a location name for an AP.	
	Example:		
	Device(config)# ap location name OFFICE		
Step 3	ap-eth-mac AP_Ethernet_MAC	Adds the AP to the location.	
	Example:	Here, AP_Ethernet_MAC refers to the AP	
	Device(config-ap-location)# ap-eth-mac 0a0b.0cf0.0001	Ethernet MAC address.	
Step 4	location civic-location-id identifier_name	Associates the civic location attribute with the	
	Example:	user location.	
	Device(config-ap-location)# location civic-location-id USER_C_1		
Step 5	location geo-location-id identifier_name	Associates the geographic location attribute	
	Example:	with the user location.	
	Device(config-ap-location)# location geo-location-id USER_G_1		

	Command or Action	Purpose
Step 6	location operator-id identifier_name	Associates the operator location attribute with
	<b>Example:</b> the user location	the user location.
	Device(config-ap-location) # location operator-id USER_0_1	
Step 7	end	Returns to privileged EXEC mode.
	Example:	
	Device(config-ap-location)# end	

# Associating Location Attributes with the NAS Location (CLI)

	Command or Action	Purpose	
Step 1	configure terminal	Enters global configuration mode.	
	Example:		
	Device# configure terminal		
Step 2	radius-server attribute wireless location civic-location-id identifier_name	Associates the civic location attribute with the NAS location.	
	Example:	Here, <i>identifier_name</i> supports strings up to	
	<pre>Device(config)# radius-server attribute wireless location civic-location-id NAS_C_1</pre>	215 characters in length.	
Step 3	radius-server attribute wireless location geo-location-id identifier_name	Associates the geographic location attribute with the NAS location.	
	Example:	Here, <i>identifier_name</i> supports strings up to	
	<pre>Device(config)# radius-server attribute wireless location geo-location-id NAS_G_1</pre>	215 characters in length. Enter a valid or existing identifier name.	
Step 4	radius-server attribute wireless location operator-id identifier_name	Associates the operator location attribute with the NAS location.	
	Example:		
	Device(config)# radius-server attribute wireless location operator-id NAS_0_1		
Step 5	end	Returns to privileged EXEC mode.	
	Example:		
	Device(config)# end		

L

### Verifying RFC 5580 Location Attribute Configuration

To verify the location attributes associated with a given location, use the following command:

```
Device# show ap location details AAA_location
Location Name.....: AAA_location
Location description.....: AAA_location
Location description.....: default-policy-tag
Site tag.....: default-site-tag
RF tag.....: default-rf-tag
AAA Location Status .....: Enabled
Civic Location Identifier : NAS_C_1
Geo Location Identifier : NAS_G_1
Operator Name Identifier : NAS_O_1
```

Configured list of APs 38ed.18ca.5a20

To verify the Cisco AP location, use the following command:

Device# show ap name AP38ED.18CA.5A20 config general Cisco AP Name : AP38ED.18CA.5A20

Cisco AP Identifier	:	38ed.18cb.cf00		
	·	Multiple counciles :	000 11	6.0
Regulatory Domain Allowed by Country	:	802.11bg: 802.11a: 8	302.11	6GHz:
AP Country Code	:	US -		
AP Regulatory Domain				
802.11bg	:	-A		
802.11a	:	-A		
MAC Address	:	38ed.18ca.5a20		
IP Address Configuration	:	Static IP assigned		
IP Address	:	9.4.172.111		
IP Netmask	:	255.255.255.0		
Gateway IP Address	:	9.4.172.1		
Fallback IP Address Being Used	:			
Domain	:			
Name Server	:			
CAPWAP Path MTU	:	1485		
Capwap Active Window Size	:	1		
Telnet State	:	Disabled		
СРИ Туре	:	ARMv7 Processor rev 0	(v7l)	
Memory Type	:	DDR3		
Memory Size	:	995328 KB		
SSH State	:	Disabled		
Cisco AP Location	:	AAA_location		
-				
-				

To verify the location attributes associated with a given MAC address, use the following command:

Device# show wireless client mac 0080.5222.545c detail

Client MAC Address : 0080.5222.545c Client MAC Type : Universally Administered Address Client DUID: NA Client IPv4 Address : AP MAC Address : 38ed.18cb.cf00 AP Name: AP38ED.18CA.5A20 AP slot : 1 Client State : Associated

```
Policy Profile : default-policy-profile
Flex Profile : N/A
...
Civic Location Identifier : NAS_C_1
Geo Location Identifier : NAS_G_1
Operator Name Identifier : NAS_O_1
```

```
Note
```

You will be able to view this output only if the RFC 5580 feature is enabled.

To verify the Civic location details, use the following command:

```
Device# show location civic-location identifier TEST1
Civic location information
------
Identifier : TEST1
Name : home
City : Morges
State : Vaud
Postal code : 1110
Country : CH
```

To verify the Geo location details, use the following command:

```
Device# show location geo-location identifier TEST4
Geo location information
------
Identifier : TEST4
Latitude : 46.5112700
Longitude : 6.4985400
Altitude : 380 meters Resolution : 10
Resolution : 100
```

To verify the Operator location details, use the following command:

```
Device# show location operator-location identifier myoperator
Operator location information
------
Operator Identifier : myoperator
Operator Name : myoperator
Operator Namespace : REALM
```