

Instalação da localização do telefone no telefone IP 7841

Contents

[Introduction](#)

[Prerequisites](#)

[Requirements](#)

[Componentes Utilizados](#)

[Informações de Apoio](#)

[Configurar](#)

[Configurações](#)

[Verificar](#)

[Troubleshoot](#)

Introduction

Este documento descreve como instalar a localização do telefone em um telefone IP da série Cisco 7841.

Prerequisites

Requirements

Não existem requisitos específicos para este documento.

Componentes Utilizados

As informações neste documento são baseadas nestas versões de software e hardware:

- Cisco Unified Communications Manager 12.x
- Telefone IP 7841 da Cisco

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. Se a rede estiver ativa, certifique-se de que você entenda o impacto potencial de qualquer comando.

Informações de Apoio


O Cisco Unified Communications Manager (CUCM) fornece suporte de localização definido pelo sistema para 12 idiomas, incluindo inglês e 16 países, incluindo os Estados Unidos. As localidades de rede especificam os tons e cadências específicos do país; localidades do usuário especificam o idioma a ser usado para exibições de texto.

Configurar

Configurações

Este é o procedimento para executar uma reinicialização de fábrica do telefone:

Etapa 1. Faça o download da localidade do site da Cisco.




Downloads Home / Collaboration Endpoints / IP Phones / IP Phone 7800 Series / IP Phone 7841 / Unified Communications Manager Endpoints Locale Installer- 12.1(1.1000)

IP Phone 7841
Release 12.1(1.1000)
Notifications

Related Links and Documentation
- No related links or documentation -

File Information	Release Date	Size	
Cisco Unified Communications Locale Installer 12.1.1.1000 Arabic (United Arab Emirates) for Cisco Unified IP Phones FW 12.1(1) po-locale-ar_AE-k3-12.1.1.1000-1.cop.sgn	27-MAR-2018	2.89 MB	Download
Cisco Unified Communications Locale Installer 12.1.1.1000 Arabic (Bahrain) for Cisco Unified IP Phones FW 12.1(1) po-locale-ar_BH-k3-12.1.1.1000-1.cop.sgn	27-MAR-2018	2.88 MB	Download
Cisco Unified Communications Locale Installer 12.1.1.1000 Arabic (Algeria) for Cisco Unified IP Phones	27-MAR-2018	2.88 MB	Download

Etapa 2. Navegue até OS Administration > Software Upgrades > Install/Upgrade.



Cisco Unified Operating System Administration
For Cisco Unified Communications Solutions

Show Settings Security Software Upgrades Services Help

Install/Upgrade

WARNING: It is recommended to perform a successful backup. Please verify backup configuration.

Cisco Unified Communications Administration

System version: 12.0.0.99834-4

VMware Installation: 2 vCPU Intel(R) Xeon(R) CPU ES-2697A v4 @ 2.60GHz, disk 1: 110Gbytes, 8192Mbytes RAM, ERROR: UNSUPPORTED: Partitions unaligned
WARNING: DNS unreachable

User admin last logged in to this cluster on Friday, June 29, 2018 3:39:36 PM IST, to node 10.106.111.182, from 10.196.121.10 using HTTPS
User admin failed to log in 1 times!
Most recent failure Sunday, July 1, 2018 5:26:34 PM IST, to 10.106.111.182, from 10.65.43.63 using HTTPS

Copyright © 1999 - 2017 Cisco Systems, Inc.
All rights reserved.

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply that exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with applicable laws and regulations, you should not use this product.

A summary of U.S. laws governing Cisco cryptographic products may be found at our [Export Compliance Product Report](#) web site.

For information about Cisco Unified Communications Manager please visit our [Unified Communications System Documentation](#) web site.

For Cisco Technical Support please visit our [Technical Support](#) web site.

Etapa 3. Como mostrado na imagem, insira as credenciais do servidor SFTP.



Cisco Unified Operating System Administration

For Cisco Unified Communications Solutions

Show ▾ Settings ▾ Security ▾ Software Upgrades ▾ Services ▾ Help ▾

Software Installation/Upgrade

Cancel Next

- Status


Status: Ready

- Software Location


Source*	<input type="text" value="Remote Filesystem"/>
Directory*	<input type="text" value="/"/>
Server*	<input type="text" value="192.168.0.5"/>
User Name*	<input type="text" value="cisco"/>
User Password*	<input type="password" value="•••••"/>
Transfer Protocol*	<input type="text" value="SFTP"/>
SMTP Server	<input type="text"/>
Email Destination	<input type="text"/>

*- indicates required item.

Etapa 4. Selecione a localização no menu suspenso **Opções/Atualizações** e clique em **Avançar**, como mostrado na imagem. A instalação do local é iniciada.



5. Clique em **Avançar**, conforme mostrado na imagem, depois que **Checksum Details** for verificado.



Etapa 6. A instalação do local foi bem-sucedida

Cisco Unified Operating System Administration
For Cisco Unified Communications Solutions

Show Settings Security Software Upgrades Services Help

Software Installation/Upgrade

Install Another

Installation Status

File po-locale-ca_ES-k3-12.1.1.1000-1.cop.sgn
 Start Time Mon Jul 02 13:19:26 IST 2018
 Status Complete

Installation Log

```

[18/07/02_13:19:57] locale_install.sh: Publisher: Starting installdb...
/bin/su -l informix -s /bin/sh -c
"source /usr/local/cm/db/dblenv.bash /usr/local/cm ;
source /usr/local/cm/db/informix/local/ids.env ;
nice /usr/local/cm/bin/installdb -x /usr/local/cm/db/xml/xml"
    
```

Install Another

i *- indicates required item.

Passo 7. Redefina o serviço Cisco TFTP em todos os nós que o executam enquanto você navega para **Servicability Page > Tools > Control Center Feature services**. Selecione o serviço Cisco TFTP e clique em **reiniciar**, como mostrado na imagem.

Cisco Unified Serviceability
For Cisco Unified Communications Solutions

Alarm Trace Tools Snmp CallHome Help

Control Center - Feature Services

Start Stop Restart Refresh Page

Status:
Ready

Select Server
Server* 10.106.111.182--CUCM Voice/Video Go

Performance and Monitoring Services

Service Name	Status:
Cisco Serviceability Reporter	Started
Cisco CallManager SNMP Service	Started

Directory Services

Service Name	Status:
Cisco DirSync	Started

CM Services

Service Name	Status:
Cisco CallManager	Started
Cisco Unified Mobile Voice Access Service	Started
Cisco IP Voice Media Streaming App	Started
Cisco CTIManager	Started
Cisco Extension Mobility	Started
Cisco DHCP Monitor Service	Started
Cisco Intercluster Lookup Service	Started
Cisco Location Bandwidth Manager	Started
Cisco Directory Number Alias Sync	Started
Cisco Directory Number Alias Lookup	Started
Cisco Dialed Number Analyzer Server	Started
Cisco Dialed Number Analyzer	Started
Cisco Tftp	Started

Etapa 8. Navegue até o telefone.

System ▾ Call Routing ▾ Media Resources ▾ Advanced Features ▾ Device ▾ Application ▾ User Management ▾ Bulk Administration ▾ Help ▾

Find and List Phones Related Links: [Actively Logged In Device Report](#)

[+](#) Add New [Select All](#) [Clear All](#) [Delete Selected](#) [Reset Selected](#) [Apply Config to Selected](#)

Status
1 records found

Query Information
Searching on a directory number may show the same device name multiple times depending on the number of lines configured per device.

Phone (1 - 1 of 1) Rows per Page 50 ▾

Find Phone where: Directory Number ▾ begins with ▾ 1006

Select item or enter search text ▾

<input type="checkbox"/>	Device Name(1 line)	Description	Device Pool	Extension	Partition	Device Protocol	Status	IPv4 Address	Copy	Super Copy
<input type="checkbox"/>	SEP5C5015458F33(1)	Auto 1006	Default	1006		SIP	Registered with 10.106.113.72	10.106.113.89	<input type="button" value="i"/>	<input type="button" value="⬆"/>

Etapa 9. Em **Local do usuário**, selecione a localização que você acabou de baixar.

MAC Address* 5C5015458F33

Description Auto 1006

Device Pool* Default [View Details](#)

Common Device Configuration < None > [View Details](#)

Phone Button Template* SEP5C5015458F33-SIP-Individual Template

Softkey Template < None >

Common Phone Profile* Standard Common Phone Profile [View Details](#)

Calling Search Space < None >

AAR Calling Search Space < None >

Media Resource Group List < None >

User Hold MOH Audio Source < None >

Network Hold MOH Audio Source < None >

Location* Hub_None

AAR Group < None >

User Locale < None >

Network Locale < None >

Built In Bridge* English, United States


Privacy* **Català, Reino de España**

English(British), United Kingdom

Etapa 10. Salve, aplique a configuração e reinicie o telefone .

Verificar

Se a localização for instalada com êxito, você poderá ver os softleys no idioma nativo como mostrado na imagem:



Troubleshoot

Atualmente, não existem informações disponíveis específicas sobre Troubleshooting para esta configuração.