

建立或將ESA連線到沒有PTR記錄的群集

目錄

[簡介](#)

[必要條件](#)

[背景資訊](#)

[設定](#)

簡介

本文描述在嘗試建立或加入群集時，思科郵件安全裝置(ESA)在出現「超時」錯誤時(如果DNS指標(PTR)記錄不可用)，以及如何解決該問題。

必要條件

本文中的資訊係根據以下軟體和硬體版本：

- AsyncOS for Email Security 8.0及更新版本

背景資訊

使用Cluster Communication Security(CSS)或Secure Shell(SSH)使用IP地址加入群集時，需要PTR記錄，否則ESA將提示「超時」錯誤，群集加入將失敗。

有時，為了正確建立PTR記錄，DNS記錄更改可能是不可能或不允許的。

下列情況可能適用：

- 裝置的IP地址使用內部IP地址
- 兩台裝置均沒有PTR記錄
- 根DNS或本地DNS無法解析兩個本地主機名
- 無法編輯或修改根DNS或本地DNS
- 埠22(SSH)和埠2222(CSS)都在兩端開啟
- 兩端都出現「超時」錯誤
- 無法在根DNS上為這些IP地址配置NXDOMAIN

設定

存在將本地ESA用作DNS源的解決方法。從裝置CLI新增本地DNS解析。例如，如果存在無法解析PTR記錄的裝置esa1.example.com(192.168.10.1)和esa2.example.com(192.168.10.2)，請執行以下操作：

```
esa1.example.com> dnsconfig
```

Choose the operation you want to perform:

- NEW - Add a new server.
- EDIT - Edit a server
- DELETE - Remove a server
- SETUP - Configure general settings.

[]> **new**

Currently using the local DNS cache servers:

1. Priority: 0 192.168.1.53

Do you want to add a new local DNS cache server or an alternate domain server?

- 1. Add a new local DNS cache server.
- 2. Add a new alternate domain server.

[]> **2**

Please enter the domain this server is authoritative for. (Ex: "com").

[]> **2.10.168.192.in-addr.arpa** [enter the in-addr-arpa which serves as PTR, in this example for esa2]

Please enter the fully qualified hostname of the DNS server for the domain "1.10.10.10.in-addr.arpa".

(Ex: "dns.example.168.192.in-addr.arpa").

[]> **esa1.example.com** [enter the hostname of the ESA you are configuring this on]

Please enter the IP address of machinea.example.com.

[]> **192.168.10.1** [enter the IP of the ESA you are configuring this on]

esa2.example.com> dnsconfig

Choose the operation you want to perform:

- NEW - Add a new server.
- EDIT - Edit a server
- DELETE - Remove a server
- SETUP - Configure general settings.

[]> **new**

Currently using the local DNS cache servers:

1. Priority: 0 192.168.1.53

Do you want to add a new local DNS cache server or an alternate domain server?

- 1. Add a new local DNS cache server.
- 2. Add a new alternate domain server.

[]> **2**

Please enter the domain this server is authoritative for. (Ex: "com").

[]> **1.10.168.192.in-addr.arpa** [enter the in-addr-arpa which serves as PTR, in this example esa1]

Please enter the fully qualified hostname of the DNS server for the domain "1.10.10.10.in-addr.arpa".

(Ex: "dns.example.168.192.in-addr.arpa").

[]> **esa2.example.com** [enter the hostname of the ESA you are configuring this on]

Please enter the IP address of machinea.example.com.

[]> **192.168.10.2** [enter the IP of the ESA you are configuring this on]

按下<Enter>鍵，直到進入主提示並運行**commit**以儲存和啟用配置更改。

附註：在上述示例中，為Please enter the domain this server is authoritative for is the reverse DNS lookup or IP address 192.168.10.1 and 192.168.10.2 (請輸入此伺服器有權訪

問的域) 輸入的上述域。請確保已配置IP地址on *esa1.example.com*和*esa2.example.com*並且可訪問。