



Cisco Catalyst PON Series Switches OLT Command Reference

First Published: 2020-11-09

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020 Cisco Systems, Inc. All rights reserved.



CONTENTS

CHAPTER 1	Using the Command-Line Interface	1
	Using the Command-Line Interface	2
	Understanding Command Modes	2
	Understanding the Help System	4
	Understanding Abbreviated Commands	5
	Understanding no Forms of Commands	5
	Understanding CLI Error Messages	5
	Using Editing Features	6
	Editing Commands through Keystrokes	6
	Editing Command Lines that Wrap	7
	Searching and Filtering Output of show and more Commands	8
	Accessing the CLI through a Console Connection or through Telnet	9

CHAPTER 2	New and Changed Information	11
	New and Changed Information	12

PART I	Getting Started With OLT Network	17
---------------	---	-----------

CHAPTER 3	Getting Started With OLT Network	19
	add inner-vlan	21
	aim	22
	alarm ont register-record	24
	crypto key	25
	default vlan	26
	delete aim	27
	deploy profile	28

description	29
device type	30
ds car bandwidth	31
flow port default	32
flow port etype	33
flow port transparent	35
flow port vlan	36
gemport	38
gemport traffic-mode	40
load keyfile	41
mapping	42
mapping mode	44
no shutdown	45
ont-find distance	46
ont-find interface gpon	48
ont-find interval-time	49
ont-find list-age	50
ont-silent auth-fail	52
ont-silent offline	53
ont auto-config	54
permit loid-lopw	55
permit loid	56
permit lopw	57
permit pw	58
permit sn-pw	59
permit sn	60
show alarm ont register-record	61
show keyfile	62
show ont-find config	63
show ont-find list	64
show ont-silent config	65
show ont-silent list	66
show ont brief count	67
show ont description	68

show ont info	69
show ssh	70
show ssh limit	71
show telnet	72
sip agent	73
sip digitmap	74
sip user	75
sip user mode	76
snmp-server	77
ssh	78
ssh limit	79
stop telnet client	80
stop vty	81
tecont tecont_id	82
telnet disable	83
telnet enable	84
telnet limit	85
telnet server-ip	86
telnetclient timeout	87
timeout	88
translate old-vlan	89
type 1 fix	90
type 2	91
type 3	92
type 4	93
type 5	94
upload keyfile	95
us car	96
us queue	97

PART II**Managing Users 99**

CHAPTER 4**Managing Users 101**

aaa 103

auth-secret-key	104
default domain-name	105
domain	106
login-access-list	107
muser local	108
muser radius	109
muser tacacs+	110
radius host	111
radius host binding	112
service password-encryption	113
show domain	114
show login-access-list	115
show muser	116
show running-config oam	117
show tacacs+	118
show username	119
show username privilege-auth	120
show username silent	121
show users	122
state active	123
state block	124
stop	125
tacacs+	126
tacacs+ authentication-type	127
tacacs+ encrypt-key	128
tacacs+ preemption-time	129
timeout	130
username	131
username change-password	133
username change-privilege-pwd	134
username failmax	135
username online-max	136
username privilege-auth-remote-user	137
username privilege-auth	138

username silent-time 139

PART III

OLT Port Configuration 141

CHAPTER 5

OLT Port Configuration 143

channel-group group_id 144

channel-group load-balance 145

channel-group group_id mode 146

clear channel-group 147

clear interface 148

interface range ethernet 149

lACP port-priority 150

lACP system-priority 151

port-control mode primary 152

port-control mode secondary 153

port-isolation 154

port-rate-statistics interval 155

psg group-id force-switch 156

psg group-id type-b 157

show description 158

show interface sfp 159

show lACP internal 160

show lACP neighbor 161

show lACP sys-id 162

show port-control mode 163

show port-isolation 164

show psg 165

show statistics interface ethernet 166

show statistics 167

show statistics channel-group 168

show statistics dynamic interface 169

show utilization interface 170

speed 171

PART IV

VLAN Configuration 173

CHAPTER 6

VLAN Configuration 175

- description 176
- ingress acceptable-frame 177
- ingress filtering 178
- interface ethernet 179
- priority 180
- show ingress interface 181
- show interface brief ethernet 182
- show interface ethernet 183
- switchport default vlan 184
- switchport ethernet 185
- switchport hybrid 186
- switchport mode 187
- switchport trunk 188
- vlan 189

PART V

OLT Network Configuration 191

CHAPTER 7

OLT Network Configuration 193

- arp 196
- arp aging-time 197
- description interface-name 198
- dhcp-snooping 199
- dhcp-snooping trust 200
- dhcpv6-snooping 201
- dhcpv6 snooping port-down-action fast-remove 202
- dhcpv6-snooping trust 203
- dlf forward 204
- clear dhcpv6-snooping 205
- interface 206
- interface loopback-interface 208

interface vlan-interface	209
ip-source-guard	210
ip-source-guard filter	211
ip address	212
ip address mask-ip-address	213
ip address range	214
ip icmp mask-reply	215
ip icmp unreachable	216
ipv6 address	217
ipv6 address link-local	218
ipv6 enable	219
ipv6 icmpv6 multicast-echo-reply	220
ipv6 nd dad attempts	221
ipv6 nd ns retrans-time	222
ipv6 nd reachable-time	223
ipv6 neighbors max-learning-num	224
ipv6 path	225
ipv6 route	226
no ipv6 neighbor	227
mac-address-table	228
mac-address-table learning	229
mac-address-table age-time	230
mac-address-table blackhole	231
mac-address-table max-mac-count	232
mirror destination-interface	233
mirror source-interface	234
show arp	235
show dhcp-snooping clients	236
show dhcp-snooping interface	237
show dhcpv6-snooping clients	239
show dhcpv6-snooping interface	240
show dhcpv6-snooping vlan	241
show dlf-forward	242
show ip interface	243

show ip source guard	244
show ipv6 interface	245
show ipv6 nd dad attempts	246
show ipv6 nd ns retrans-time	247
show ipv6 nd reachable-time	248
show ipv6 neighbors	249
show ipv6 route	250
show mac-address-table age-time	251
show mac-address-table	252
show mirror	254
show snmp community	255
show snmp contact	256
show snmp engineid	257
show snmp group	258
show snmp host	259
show snmp location	260
show snmp mib	261
show snmp name	262
show snmp notify	263
show snmp user	264
show snmp view	265
shutdown	266
snmp-server	267
snmp-server community	268
snmp-server community encrypt	269
snmp-server contact	270
snmp-server encrypt	271
snmp-server engineid	272
snmp-server group	273
snmp-server host	274
snmp-server location	276
snmp-server max-packet-length	277
snmp-server name	278
snmp-server trap-source	279

snmp-server user 280
 snmp-server view 282

PART VI
Quality of Service 283

CHAPTER 8
Quality of Service 285

bandwidth egress rate 286
 clear traffic-statistic 287
 queue-scheduler cos-map 288
 queue-scheduler strict-priority 289
 queue-scheduler sp-wrr 290
 queue-scheduler wrr 291
 queue-scheduler dscp-map 292
 rate-limit 293
 show bandwidth egress 294
 show qos-info all 295
 show qos-interface 297
 show queue-scheduler 298
 storm-control 300
 traffic-copy-to-cpu 301
 traffic-redirect 302
 traffic-statistic 303

PART VII
Security 305

CHAPTER 9
Security 307

absolute time-range 309
 access-limit 310
 access-list match-order 311
 access-group 312
 access-list numbered standard 313
 access-list standard 314
 accounting-on 315
 acct-secret-key 316

anti-dos ip fragment	317
anti-dos ip ttl	318
arp anti-spoofing	319
arp anti-spoofing deny-disguiser	320
arp anti-spoofing unknown	321
arp anti-spoofing valid-check	322
arp anti-flood	323
channel-group spanning-tree cost	325
clear cpu-classification	326
clear cpu-statistics	327
cpu-car	328
cpu-limit	329
dhcp anti-attack	330
discard-bpdu	332
access-list extended name	333
access-list numbered extended	334
host-guard bind ip	336
ip route	337
access-list link name	338
access-list link number	339
local-user	341
nas-ipaddress	342
no ip route static all	343
periodic time-range	344
preemption-time	345
{primary-acct-ip second-acct-ip}	346
{primary-auth-ip second-auth-ip}	347
radius	348
realtime-account	351
no access-list	352
scheme	353
show access-list config	354
show access-list runtime	355
show anti-dos	356

show arp anti-flood	357
show arp anti interface	359
show cpu-car	360
show cpu-classification	361
show cpu-limit	362
show cpu-statistics	363
show cpu-utilization	364
show dhcp anti-attack	365
show discard-bpdu	366
show dot1x	367
show ip route	372
show radius	373
show shutdown-control interface	375
show spanning-tree interface	376
shutdown-control-recover	378
spanning-tree (global configuration)	379
spanning-tree (interface configuration)	382
time-range	385
username-format	386

PART VIII
Multicast Configuration 387

CHAPTER 10
Multicast Configuration 389

igmp-snooping	391
igmp-snooping drop	392
igmp-snooping fast-leave	393
igmp-snooping group-limit action	394
igmp-snooping group-limit	395
igmp-snooping general-query source-ip	396
igmp-snooping host-aging-time	397
igmp-snooping max-response-time	398
igmp-snooping multicast vlan	399
igmp-snooping {permit deny}	400
igmp-snooping profile refer	401

igmp-snooping profile	402
igmp-snooping {permit deny} group-range	403
igmp-snooping query-interval	404
igmp-snooping querier version	405
igmp-snooping querier-vlan	406
igmp-snooping query-max-respond	407
igmp-snooping record-host	408
igmp-snooping router-port-age	409
igmp-snooping route-port forward	410
igmp-snooping report-supression	411
igmp-snooping route-port vlan	412
ip range	413
mac range	414
mld-snooping	415
mld-snooping fast-leave	416
mld-snooping group-limit	417
mld-snooping host-aging-time	418
mld-snooping max-response-time	419
mld-snooping multicast vlan	420
mld-snooping {permit deny} {group vlan}	421
mld-snooping permit deny group MAC vlan	422
mld-snooping {permit deny} group-range	423
mld-snooping querier	424
mld-snooping querier-vlan	425
mld-snooping query-interval	426
mld-snooping query-max-respond	427
mld-snooping route-port forward	428
mld-snooping route-port vlan	429
mld-snooping router-port-age	430
mld-snooping record-host	431
multicast	432
multicast ds-tag add	433
multicast ds-tag remove	434
multicast ds-tag translate	435

multicast fast-leave disable	436
multicast group-limit	437
multicast interface	438
multicast mode igmp-snooping	439
multicast proxy-interval	440
multicast proxy-port	441
multicast us-tag add	442
multicast us-tag translate	443
profile limit	444
show igmp-snooping	445
show igmp-snooping profile	446
show igmp-snooping record-host	447
show igmp-snooping router-dynamic	448
show igmp-snooping router-static	449
show mld-snooping	450
show mld-snooping router-dynamic	451
show mld-snooping router-static	452
show multicast mld-snooping	453
show multicast igmp-snooping	456
show ont multicast	457
show running-config mld_snooping	458

PART IX
System Management 459

CHAPTER 11
System Management 461

alarm all-packets	463
alarm all-packets threshold	464
alarm cpu	465
alarm cpu threshold	466
buildrun mode	467
clear startup-config	468
clock summer-time	469
clock timezone	470
copy running-config startup-config	471

copy startup-config running-config	472
load ftp	473
load tftp	474
load xmodem	475
local fec	476
ntp access	477
ntp authentication	478
ntp broadcast	479
ntp disable	480
ntp max-dynamic-sessions	481
ntp multicast	482
ntp unicast peer	483
ntp unicast server	484
show alarm all-packets	485
show alarm cpu	486
show clock	487
show ntp access	488
show ntp authentication	489
show ntp broadcast server	490
show ntp disable	491
show ntp max-dynamic-sessions	492
show ntp multicast server	493
show ntp sessions	494
show ntp status	495
show ntp unicast peer	496
show ntp unicast server	497
show running-config	498
show sntp client	499
show startup-config	500
sntp client	501
sntp client authenticate	502
sntp client authentication-key	503
sntp client broadcastdelay	504
sntp client mode	505

sntp client poll-interval	506
sntp client retransmit-interval	507
sntp client retransmit	508
sntp client valid-server	509
sntp server	510
sntp trusted-key	511
upload automatically configuration ftp	512
upload automatically configuration tftp	513
upload ftp	514
upload tftp	515

PART X
ONT Device Configuration 517

CHAPTER 12
ONT Device Configuration 519

alarm profile refer	520
clear ont-logging buffer	521
local bandwidth egress	522
local loop-detect	523
local mac-address-table	524
local neg-mode	525
local ranging-balance	526
local shutdown	527
local switch	528
ont-logging	529
ont-logging buffer	530
ont-logging monitor	531
ont-logging prefix	532
ont-logging timestamps	533
ont active	534
ont deactivate	535
ont neg-mode	536
ont reboot	537
ont shutdown	538
ont upgrade	539

optical power rx threshold	540
show ont-logging	541
show ont-logging buffer	542
show ont mac-address-table	543
show ont port-status	544
show ont statistics	545
show ont upgrade-status	546
show ont version	547



Using the Command-Line Interface

This chapter contains the following topics:

- [Using the Command-Line Interface, on page 2](#)

Using the Command-Line Interface

This chapter describes the command-line interface (CLI) and how to use it to configure your device.

Understanding Command Modes

The user interface is divided into many different modes. The commands available to you depend on which mode you are currently in. Enter a question mark (?) at the system prompt to obtain a list of commands available for each command mode.

When you start a session on the switch, you begin in user mode, often called user EXEC mode. Only a limited subset of the commands are available in user EXEC mode. For example, most of the user EXEC commands are one-time commands, such as **show** commands, which show the current configuration status, and **clear** commands, which clear counters or interfaces. The user EXEC commands are not saved when the switch reboots.

To have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From this mode, you can enter any privileged EXEC command or enter global configuration mode.

Using the configuration modes (global and interface), you can make changes to the running configuration. If you save the configuration, these commands are stored and used when the device reboots. To access the various configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and line configuration mode.

This table describes the main command modes, how to access each one, the prompt you see in that mode, and how to exit the mode. The examples in the table use the hostname *Device*.

Table 1: Command Mode Summary

Mode	Access Method	Prompt	Exit Method	About This Mode
User EXEC	Begin a session with your device.	Device>	Enter exit or quit .	Use this mode to <ul style="list-style-type: none"> • Change terminal settings. • Perform basic tests. • Display system information.

Mode	Access Method	Prompt	Exit Method	About This Mode
Privileged EXEC	While in user EXEC mode, enter the enable command.	Device#	Enter exit to exit.	Use this mode to verify commands that you have entered. Use a password to protect access to this mode.
Global configuration	While in privileged EXEC mode, enter the configure command.	Device (config) #	To exit to privileged EXEC mode, enter exit or end , or press Ctrl-Z .	Use this mode to configure parameters that apply to the entire switch.
Ethernet interface configuration	While in global configuration mode, enter the interface ethernet command (with a specific interface).	Device (config-if-ethernet-1/1) #	To exit to global configuration mode, enter exit . To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure parameters for the Ethernet ports.
VLAN configuration	While in global configuration mode, enter the vlan vlan-id command.	Device (config-if-vlan) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure VLAN parameters.
AAA configuration	While in global configuration mode, enter the aaa command.	Device (config-aaa) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to setup the domain.

Mode	Access Method	Prompt	Exit Method	About This Mode
RADIUS configuration	While in global configuration mode, enter the radius host <i>radius-name</i> command.	Device (config-radius-r1) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure RADIUS parameters.
VLAN interface configuration	While in global configuration mode, enter the interface vlan-interface <i>vlan-id</i> command.	Device (config-if-vlaninterface-22) #	To exit to global configuration mode, enter the exit command. To return to privileged EXEC mode, press Ctrl-Z or enter end .	Use this mode to configure VLAN Layer 3 interface

Understanding the Help System

You can enter a question mark (?) at the system prompt to display a list of commands available for each command mode. You can also obtain a list of associated keywords and arguments for any command.

Table 2: Help Summary

Command	Purpose
help	Obtains a brief description of the help system in any command mode.
<i>abbreviated-command-entry</i> ? Device# cl? clear clock cls	Obtains a list of commands that begin with a particular character string.
<i>abbreviated-command-entry</i> <Tab> Device# sh cl <tab> Device# show clock	Completes a partial command name.
? Device> ?	Lists all commands available for a particular command mode.

Command	Purpose
<code>command ?</code> Device <code>show ?</code>	Lists the associated keywords for a command.
<code>command keyword ?</code> Device(config)# <code>clock timezone ?</code> STRING<1-32> name of timezone	Lists the associated arguments for a keyword.

Understanding Abbreviated Commands

You need to enter only enough characters for the switch to recognize the command as unique.

This example shows how to enter the `show version` command in an abbreviated form:

```
Device# show ver
```

Understanding no Forms of Commands

Almost every configuration command also has a **no** form. In general, use the **no** form to disable a feature or function or reverse the action of a command. For example, the **no shutdown** interface configuration command reverses the shutdown of an interface. Use the command without the keyword **no** to re-enable a disabled feature or to enable a feature that is disabled by default.

Understanding CLI Error Messages

This table lists some error messages that you might encounter while using the CLI to configure your device.

Table 3: Common CLI Error Messages

Error Message	Meaning	How to Get Help
% Incomplete command.	You did not enter all the keywords or values required by this command.	Re-enter the command followed by a question mark (?) with a space between the command and the question mark. The possible keywords that you can enter with the command appear.
% Invalid input detected at '^' marker.	You entered the command incorrectly. The caret (^) marks the point of the error.	Enter a question mark (?) to display all the commands that are available in this command mode. The possible keywords that you can enter with the command appear.

Using Editing Features

This section describes the editing features that can help you manipulate the command line.

Editing Commands through Keystrokes

This table shows the keystrokes that you need to edit command lines. These keystrokes are optional.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

Table 4: Editing Commands through Keystrokes

Capability	Keystroke	Purpose
Move around the command line to make changes or corrections.	Press Ctrl-B , or press the left arrow key.	Moves the cursor back one character.
	Press Ctrl-F , or press the right arrow key.	Moves the cursor forward one character.
	Press Ctrl-A .	Moves the cursor to the beginning of the command line.
	Press Ctrl-E .	Moves the cursor to the end of the command line.
	Press Esc B .	Moves the cursor back one word.
	Press Esc F .	Moves the cursor forward one word.
	Press Ctrl-T .	Transposes the character to the left of the cursor with the character located at the cursor.
Recall commands from the buffer and paste them in the command line. The switch provides a buffer with the last ten items that you deleted.	Press Ctrl-Y .	Recalls the most recent entry in the buffer.
	Press Esc Y .	Recalls the next buffer entry. The buffer contains only the last 10 items that you have deleted or cut. If you press Esc Y more than ten times, you cycle to the first buffer entry.
Delete entries if you make a mistake or change your mind.	Press the Delete or Backspace key.	Erases the character to the left of the cursor.

Capability	Keystroke	Purpose
	Press Ctrl-D .	Deletes the character at the cursor.
	Press Ctrl-K .	Deletes all characters from the cursor to the end of the command line.
	Press Ctrl-U or Ctrl-X .	Deletes all characters from the cursor to the beginning of the command line.
	Press Ctrl-W .	Deletes the word to the left of the cursor.
	Press Esc D .	Deletes from the cursor to the end of the word.
Capitalize or lowercase words or capitalize a set of letters.	Press Esc C .	Capitalizes at the cursor.
	Press Esc L .	Changes the word at the cursor to lowercase.
	Press Esc U .	Capitalizes letters from the cursor to the end of the word.
Designate a particular keystroke as an executable command, perhaps as a shortcut.	Press Ctrl-V or Esc Q .	
<p>Scroll down a line or screen on displays that are longer than the terminal screen can display.</p> <p>Note The More prompt is used for any output that has more lines than can be displayed on the terminal screen, including show command output. You can use the Return and Space bar keystrokes whenever you see the More prompt.</p>	Press the Return key.	Scrolls down one line.
	Press the Space bar.	Scrolls down one screen.
Redisplay the current command line if the switch suddenly sends a message to your screen.	Press Ctrl-L or Ctrl-R .	Redisplays the current command line.

Editing Command Lines that Wrap

You can use a wraparound feature for commands that extend beyond a single line on the screen. When the cursor reaches the right margin, the command line shifts ten spaces to the left. You cannot see the first ten

characters of the line, but you can scroll back and check the syntax at the beginning of the command. The keystroke actions are optional.

To scroll back to the beginning of the command entry, press **Ctrl-B** or the left arrow key repeatedly. You can also press **Ctrl-A** to immediately move to the beginning of the line.



Note The arrow keys function only on ANSI-compatible terminals such as VT100s.

In this example, the **access-list** global configuration command entry extends beyond one line. When the cursor first reaches the end of the line, the line is shifted ten spaces to the left and redisplayed. The dollar sign (\$) shows that the line has been scrolled to the left. Each time the cursor reaches the end of the line, the line is again shifted ten spaces to the left.

```
Device(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1
Device(config)# $ 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.25
Device(config)# $t tcp 131.108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq
Device(config)# $108.2.5 255.255.255.0 131.108.1.20 255.255.255.0 eq 45
```

After you complete the entry, press **Ctrl-A** to check the complete syntax before pressing the **Return** key to execute the command. The dollar sign (\$) appears at the end of the line to show that the line has been scrolled to the right:

```
Device(config)# access-list 101 permit tcp 131.108.2.5 255.255.255.0 131.108.1$
```

The software assumes that you have a terminal screen that is 80 columns wide. If you have a width other than that, use the **terminal width** privileged EXEC command to set the width of your terminal.

Use line wrapping with the command history feature to recall and modify previous complex command entries.

Searching and Filtering Output of show and more Commands

You can search and filter the output for **show** and **more** commands. This is useful when you need to sort through large amounts of output or if you want to exclude output that you do not need to see. Using these commands is optional.

To use this functionality, enter a **show** or **more** command followed by the pipe character (|), one of the keywords **begin**, **include**, or **exclude**, and an expression that you want to search for or filter out:

```
command | {begin | include | exclude} regular-expression
```

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* appear.

This example shows how to include in the output display only lines where the expression *protocol* appears:

```
Device# show interfaces | include protocol
Vlan1 is up, line protocol is up
Vlan10 is up, line protocol is down
GigabitEthernet1/0/1 is up, line protocol is down
GigabitEthernet1/0/2 is up, line protocol is up
```

Accessing the CLI through a Console Connection or through Telnet

Before you can access the CLI, you must connect a terminal or a PC to the device console or connect a PC to the Ethernet management port and then power on the device, as described in the hardware installation guide that shipped with your device.

CLI access is available before device setup. After your device is configured, you can access the CLI through a remote Telnet session or SSH client.

You can use one of these methods to establish a connection with the device:

- Connect the device console port to a management station or dial-up modem, or connect the Ethernet management port to a PC. For information about connecting to the console or Ethernet management port, see the device hardware installation guide.
- Use any Telnet TCP/IP or encrypted Secure Shell (SSH) package from a remote management station. The device must have network connectivity with the Telnet or SSH client, and the device must have an enable secret password configured.

The device supports up to 16 simultaneous Telnet sessions. Changes made by one Telnet user are reflected in all other Telnet sessions.

The device supports up to five simultaneous secure SSH sessions.

After you connect through the console port, through the Ethernet management port, through a Telnet session or through an SSH session, the user EXEC prompt appears on the management station.



New and Changed Information

- [New and Changed Information](#), on page 12

New and Changed Information

This table provides release and related information for features explained in this module.

These features are available on all releases subsequent to the one they were introduced in, unless noted otherwise.

Release	Modification
OLT v1.2.2.0	<p>The following commands are deprecated:</p> <ul style="list-style-type: none">• sntp client summer-time daily• sntp client summer-time weekly <p>The following changes are introduced for the sip user mode command:</p> <ul style="list-style-type: none">• New keywords primary-dns and secondary-dns added to replace the bias terms.• The <i>host id</i> for a unique profile is fixed at a value of 1. <p>The gempport command has a new encrypt keyword.</p>

Release	Modification
	<p>The following commands are introduced:</p> <ul style="list-style-type: none"> • clock summer-time • clear dhcpv6 snooping • dhcpv6 snooping • dhcpv6 snooping max-clients • dhcpv6 snooping port down action fast remove • dhcpv6 snooping trust • show dhcpv6 snooping clients • show dhcpv6 snooping interface • show dhcpv6 snooping vlan • host-guard bind ip • ntp access • ntp authentication • ntp max-dynamic-sessions • ntp reference-clock • ntp unicast • show ntp access • show ntp authentication • show ntp broadcast-server • show ntp disable • show ntp max-dynamic-sessions • show ntp multicast-server • show ntp reference-clock • show ntp sessions • show ntp status • show ntp unicast-peer • show ntp unicast-server • mld-snooping • mld-snooping host-aging-time • mld-snooping fast-leave

Release	Modification
	<ul style="list-style-type: none">• mld-snooping group-limit• mld-snooping {permit deny}• mld-snooping querier• mld-snooping query-interval• mld-snooping query-max-respond• mld-snooping querier-vlan• mld-snooping route-port forward• mld-snooping max-response-time• mld-snooping multicast vlan• mld-snooping record-host• mld-snooping route-port• mld-snooping router-port-age• show mld-snooping• show mld-snooping router-dynamic• show mld-snooping router-static• show multicast mld-snooping interface• show running-config mld_snooping

Release	Modification
	<ul style="list-style-type: none"> • ipv6 address • ipv6 address link-local • ipv6 enable • ipv6 icmpv6 multicast-echo-reply • ipv6 nd dad attempts • ipv6 nd ns retrans-time • ipv6 nd reachable-time • ipv6 neighbors max-learning-num • ipv6 path • ipv6 route • no ipv6 neighbor • show ipv6 interface • show ipv6 nd dad attempts • show ipv6 nd ns retrans-time • show ipv6 nd reachable-time • show ipv6 neighbors • show ipv6 route
OLT v1.2.1.17	Introductory release for OLT.



PART I

Getting Started With OLT Network

- [Getting Started With OLT Network, on page 19](#)



Getting Started With OLT Network

- [add inner-vlan, on page 21](#)
- [aim, on page 22](#)
- [alarm ont register-record, on page 24](#)
- [crypto key, on page 25](#)
- [default vlan, on page 26](#)
- [delete aim, on page 27](#)
- [deploy profile, on page 28](#)
- [description, on page 29](#)
- [device type, on page 30](#)
- [ds car bandwidth, on page 31](#)
- [flow port default, on page 32](#)
- [flow port etype, on page 33](#)
- [flow port transparent, on page 35](#)
- [flow port vlan, on page 36](#)
- [gemport, on page 38](#)
- [gemport traffic-mode, on page 40](#)
- [load keyfile, on page 41](#)
- [mapping, on page 42](#)
- [mapping mode, on page 44](#)
- [no shutdown, on page 45](#)
- [ont-find distance, on page 46](#)
- [ont-find interface gpon, on page 48](#)
- [ont-find interval-time, on page 49](#)
- [ont-find list-age, on page 50](#)
- [ont-silent auth-fail, on page 52](#)
- [ont-silent offline, on page 53](#)
- [ont auto-config, on page 54](#)
- [permit loid-lopw, on page 55](#)
- [permit loid, on page 56](#)
- [permit lopw, on page 57](#)
- [permit pw, on page 58](#)
- [permit sn-pw, on page 59](#)
- [permit sn, on page 60](#)

- show alarm ont register-record, on page 61
- show keyfile, on page 62
- show ont-find config, on page 63
- show ont-find list , on page 64
- show ont-silent config, on page 65
- show ont-silent list, on page 66
- show ont brief count, on page 67
- show ont description, on page 68
- show ont info, on page 69
- show ssh, on page 70
- show ssh limit, on page 71
- show telnet, on page 72
- sip agent, on page 73
- sip digitmap, on page 74
- sip user, on page 75
- sip user mode, on page 76
- snmp-server, on page 77
- ssh, on page 78
- ssh limit, on page 79
- stop telnet client, on page 80
- stop vty, on page 81
- tcont *tcont_id*, on page 82
- telnet disable, on page 83
- telnet enable, on page 84
- telnet limit, on page 85
- telnet *server-ip*, on page 86
- telnetclient timeout, on page 87
- timeout, on page 88
- translate old-vlan, on page 89
- type 1 fix, on page 90
- type 2, on page 91
- type 3, on page 92
- type 4, on page 93
- type 5, on page 94
- upload keyfile, on page 95
- us car, on page 96
- us queue, on page 97

add inner-vlan

To configure VLAN stacking rule, use the **add inner-vlan** command in VLAN profile configuration mode. To delete the VLAN stacking rule, use the **no add inner-vlan** command.

add inner-vlan *inner-vlan-id* [*priority* | **outer-vlan** *outer-vlan-id* [*priority*]]

no add inner-vlan *inner-vlan-id* [*priority*]

Syntax Description		
<i>inner-vlan-id</i>		The inner VLAN ID. The range is from 0 to 4094.
<i>outer-vlan-id</i>		The outer VLAN ID. The range is from 0 to 4094.
<i>priority</i>		The 802.1 priority value. The range is from 0 to 7.

Command Modes VLAN profile configuration (deploy-profile-vlan)

Usage Guidelines A VLAN profile type must be configured.
Modifying and activating the VLAN template will cause the ONT that references the template to go online again.

Examples This example shows how to configure VLAN stacking rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)# add inner-vlan 2 3 outer-vlan 2 3
Device(deploy-profile-vlan-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

aim

To create profile based aim. use the **aim** command in profile configuration mode.

For alarm, dba, line, downstream traffic, upstream traffic and VLAN profile configuration modes

```
aim {index_number | name name}
```

For rule and unique profile configuration modes

```
aim {slot-num/pon-num/ont-num | name name}
```

Syntax Description

<i>index_number</i>	The profile index number. The range is from 0 to 1023.
<i>name</i>	The profile name. The format is string. The string length range is from 1 to 100.
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 100. • <i>ont-num</i>: The ONT number. The range is from 1 to 100.

Command Modes

Profile configuration (deploy-profile)

Usage Guidelines

A profile type must be configured.

Examples

This example shows how to create a VLAN aim.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)#
```

Example

This example shows how to create a unique aim.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)#
```


Related Commands

Command	Description
delete aim	Deletes profile based aim.

alarm ont register-record

To enable ONT register record alarm and set an alarm threshold, use the **alarm ont register-record** command in global configuration mode. To disable the alarm, use the **no alarm ont register-record** command.

alarm ont register-record [**threshold**]*threshold_value*

no alarm ont register-record [**threshold**]*threshold_value*

Syntax Description	<i>threshold_value</i>	The threshold value. The range is from 1 to 128. The default is 64.
---------------------------	------------------------	--

Command Modes Global configuration (config)

Usage Guidelines You can limit the number of ONTs that can be registered on the PON port by setting a threshold value. If the number of ONTs on the PON port exceeds the threshold value, an alarm is generated. The alarm is cancelled once the number of ONTs is less than the threshold value.

Examples

This example shows how to set an ONT register record alarm threshold value.

```
Device> enable
Device# configure terminal
Device(config)# alarm ont register-record threshold 80
```

Related Commands

Command	Description
show alarm ont register-record	Displays information about register record alarm of an ONT

crypto key

To configure or remove a key, use the **crypto key** command in privileged EXEC mode.

crypto key {**generate rsa** | **refresh** | **zeroize rsa**}

Syntax Description

generate rsa	Configures a default key.
refresh	Activates the key.
zeroize rsa	Removes the key.

Command Modes

Privileged EXEC (#)

Usage Guidelines

SSH must be enabled on the device.

Examples

This example shows how to configure a default key.

```
Device> enable
Device# crypto key generate rsa
Generate default SSH key successfully.
```

This example shows how to activate the key.

```
Device> enable
Device# crypto key refresh
Refresh SSH key successfully.
```

Example

This example shows how to remove the key.

```
Device> enable
Device# crypto key zeroize rsa
Zeroize SSH key successfully.
```

Related Commands

Command	Description
ssh	Enables SSH on an OLT.

default vlan

To configure the VLAN tagging rule, use the **default vlan** command in VLAN profile configuration mode. To delete the VLAN tagging rule, use the **no default vlan** command.

default vlan *vlan_id* [*priority*]

Syntax Description		
<i>vlan_id</i>		The VLAN ID. The range is from 1 to 4094.
<i>priority</i>		The 802.1 priority value. The range is from 0 to 7.

Command Modes VLAN profile configuration (deploy-profile-vlan)

Usage Guidelines A VLAN profile type must be configured.
Modifying and activating the VLAN template will cause the ONT that references the template to go online again.

Examples This example shows how to configure the VLAN tagging rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)# default vlan 5 5
Device(deploy-profile-vlan-5)# active
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

delete aim

To delete profile based aim, use the **delete aim** command in profile configuration mode.

For alarm, dba, line, downstream traffic, upstream traffic and VLAN profile configuration modes

```
delete aim {profile_list | name name}
```

For rule and unique profile configuration modes

```
delete aim {slot-num/pon-num/ont-num | name name}
```

Syntax Description		
<i>index_number</i>	The profile index number. The range is from 0 to 1023.	
<i>name</i>	The profile name. The format is string. The string length range is fr	
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is fr • <i>ont-num</i>: The ONT number. The range is fr 	

Command Modes Profile configuration (deploy-profile)

Usage Guidelines A profile type and profile based aim must be created on the device.

Examples This example show how to delete a VLAN aim configuration.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# delete aim 5
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

deploy profile

To deploy a profile type, use the **deploy profile** command in global configuration mode.

deploy profile {alarm | dba | ds-traffic | line | rule | unique | us-traffic | vlan}

Syntax	Description
alarm	The alarm profile.
dba	The DBA profile.
ds-traffic	The downstream traffic profile.
line	The line profile.
rule	The rule profile.
unique	The unique profile.
us-traffic	The upstream traffic profile.
vlan	The VLAN profile.

Command Modes Global configuration (config)

Examples This example shows how to deploy a line profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
```

Related Commands	Command	Description
	aim	Creates aim based on the profile.

description

To configure an ONT description, use the **description** *ont_description* command in unique profile configuration mode. To delete an ONT description, use the **no description** *ont_description* command.

description *ont_description*

no description *ont_description*

Syntax Description

ont_description

The ONT description.

Command Modes

Unique profile configuration (deploy-profile-unique)

Usage Guidelines

A unique profile type must be configured.

Examples

This example shows how to configure an ONT description.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# description cisco
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

device type

To configure a device type, use the **device type** *type* command in line profile configuration mode.

device type *type*

Syntax Description	<i>type</i>	The ONT device type name. The name of the ONT device type should conform to the ONT device type specification formulated.
--------------------	-------------	---

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure a device type.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# device type c40-100
Device(deploy-profile-line-5)# active
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

ds car bandwidth

To configure committed access rate (CAR) downlink of a GEM port, use the **ds car bandwidth** command in downlink traffic profile configuration mode.

ds car bandwidth *bandwidth_rate*

Syntax Description	<i>bandwidth_rate</i>	The downstream bandwidth in kbps. The value range is from 64 to 2608832.
---------------------------	-----------------------	---

Command Modes Downlink traffic profile (deploy-profile-ds-traffic)

Usage Guidelines A downlink profile type must be configured.
Modifying and activating the downlink traffic profile will cause the ONT that references the template to go online again.

Examples This example shows how to configure a GEM port

```
Device> enable
Device# configure terminal
Device(config)# deploy profile ds-traffic
Device(deploy-profile-ds-traffic)# aim 5
Device(deploy-profile-ds-traffic-5)# ds car bandwidth 1024
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

flow port default

To create a default flow rule, use the **flow** *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **default** command. To delete a default VLAN flow rule, use the **no** form of this command.

flow *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **default** **vlan** *destination_vlan_id* [*priority*]

no flow *flow_id*

Syntax	Description
<i>flow_id</i>	The flow index. The range is from 0 to 63.
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
default	Specifies the default configuration.
<i>destination_vlan_id</i>	The destination VLAN ID The range is from 1 to 4094.
<i>priority</i>	The VLAN priority. The range is from 0 to 7.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.
Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples This example shows how to create a default VLAN flow rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port eth 3 default vlan 3 3
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

flow port etype

To create a flow rule based on ethernet frame type, use the **flow** *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **etype** {**arp** | **ipoe** | **pppoe**} {**default** **vlan** *source_vlan_id* *priority* | **transparent** | **vlan** *source_vlan_id* {*priority* | **add** **vlan** *destination_vlan_id* [*priority*] | **keep** | **translate** **vlan** *destination_vlan_id* [*priority*]}}

flow *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **etype** {**arp** | **ipoe** | **pppoe**} {**default** **vlan** *source_vlan_id* *priority* | **transparent** | **vlan** *source_vlan_id* {*priority* | **add** **vlan** *destination_vlan_id* [*priority*] | **keep** | **translate** **vlan** *destination_vlan_id* [*priority*]}}

no **flow** *flow_id*

Syntax	Description
<i>flow_id</i>	The flow index. The range is from 0 to 63.
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
default	Specifies the default configuration.
<i>destination_vlan_id</i>	The destination VLAN ID The range is from 1 to 4094.
<i>priority</i>	The VLAN priority. The range is from 0 to 7.
etype	Specifies user ethernet frame type a
arp	Specifies ARP as the filter type.
ipoe	Specifies IPoE as the filter type.
pppoe	Specifies PPPOE as the filter type.
<i>source_vlan_id</i>	The source VLAN ID The range is from 1 to 4094.
transparent	Specifies the service type as transpa
add	Adds outer service VLAN
keep	Adds trunk as the service type.
translate	Add translate as the service type.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a translate flow rule based on ethernet frame type.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port iphost etype arp vlan 3 translate vlan 4 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

flow port transparent

To create a transparent flow rule, use the **flow *flow_id* port {eth *port-id* | veip | iphost} transparent** command.
To delete a transparent flow rule, use the **no** form of this command.

flow *flow_id* port {eth *port-id* | veip | iphost} transparent

no flow *flow_id*

Syntax Description		
<i>flow_id</i>		The flow index. The range is from 0 to 63.
<i>port-id</i>		The ONT Ethernet port ID. The range is from 1 to 24.
transparent		Specifies the service type as transpa

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a transparent flow rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port eth 3 transparent
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

flow port vlan

To create a VLAN flow rule, use the **flow** *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **vlan** command. To delete a VLAN flow rule, use the **no** form of this command.

flow *flow_id* **port** {**eth** *port-id* | **veip** | **iphost**} **vlan** *source_vlan_id* {*priority* | **add** **vlan** *destination_vlan_id* [*priority*] | **keep** | **translate** **vlan** *destination_vlan_id* [*priority*]}

no **flow** *flow_id*

Syntax	Description
<i>flow_id</i>	The flow index. The range is from 0 to 63.
<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
<i>destination_vlan_id</i>	The destination VLAN ID The range is from 1 to 4094.
<i>priority</i>	The VLAN priority. The range is from 0 to 7.
<i>source_vlan_id</i>	The source VLAN ID The range is from 1 to 4094.
add	Adds outer service VLAN
keep	Adds trunk as the service type.
translate	Add translate as the service type.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a VLAN keep flow rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# flow 2 port eth 3 vlan 2 keep
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

gempport

To create a GEM port and configure the parameters, use the **gempport** *gem_index* **tcont** *tcont_id* command in line profile configuration mode.

For line profile configuration mode

```
gempport gem_index tcont tcont_id { encrypt | vlan-profile | us-traffic-profile | ds-traffic-profile }
{ index_number | name name }
```

For unique profile configuration mode.

```
gempport gem_index { vlan-profile | us-traffic-profile | ds-traffic-profile } { index_number | name name }
```

Syntax Description

<i>gem_index</i>	The GEM port index number. The range is from 1 to 1024. Current ports can be created in each line profile.
<i>tcont_id</i>	The T-CONT ID to bind to the GEM port. The range is from 1 to M.
encrypt	Enables Advanced Encryption Standard (AES) encryption.
vlan-profile	The VLAN profile.
us-traffic-profile	The upstream traffic profile.
ds-traffic-profile	The downstream traffic profile.
<i>index_number</i>	The index of the template. The range is from 0 to M, where M is the number of ONUs supported by the whole machine.
<i>name</i>	The name of the template.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile causes the ONT that references the template to go online again.

Examples

This example shows how to create a gempport and configure a T-CONT to the gempport.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
GPON(deploy-profile-line-5)# device type n40-100-1
GPON(deploy-profile-line-5)# tcont 2 profile dba 1
Device(deploy-profile-line-5)# gempport traffic-mode car
Device(deploy-profile-line-5)# gempport 2 tcont 2 vlan-profile 1
```


Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.
gemport traffic-mode	Configures the GEM traffic mode

gemport traffic-mode

To configure the GEM traffic mode, use the **gemport traffic-mode** command in line profile configuration mode.

gemport traffic-mode {**car** | **queue**}

Syntax Description	car	Specifies committed access rate (CAR) as GEM traffic mode.
	queue	Specifies priority scheduling queue as GEM traffic mode.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines A line profile type must be configured.
 Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure the GEM port traffic mode based on queue.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# gemport traffic-mode queue
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

load keyfile

To download the key from the external key server, use the **load keyfile** command in privileged EXEC mode.

Download from a TFTP server

```
load keyfile {public | private} tftp {inet | inet6} server_ip filename
```

Download from a FTP server

```
load keyfile {public | private} ftp {inet | inet6} server_ip filename username password
```

Syntax Description

public	The public SSH key file
private	The private SSH key file
tftp	Loads the file from the TFTP server.
ftp	Loads the file from FTP server.
inet	The IPv4 address family.
inet6	The IPv6 address family
<i>server_ip</i>	The server IP address
<i>filename</i>	The key filename.
<i>username</i>	The FTP username
<i>password</i>	The FTP password.

Command Modes

Privileged EXEC (#)

Usage Guidelines

SSH must be enabled on the device.

Examples

This example shows how to download the public key from the FTP server

```
Device> enable
Device# load keyfile public ftp inet 100.100.100.11 mykey admin 123456
```

Related Commands

Command	Description
ssh	Enables SSH on an OLT.
upload keyfile	Uploads the local key to the key server.

mapping

To create GEM port mapping, use the **mapping** *index_number* in line profile configuration mode. To disable GEM port mapping, use the **no mapping** *index_number* command.

mapping *index_number* {**port** {**eth** *port_id* | **veip** | **iphost**} | **priority** *priority_value* | **vlan** *vlan_id*} **gemport** *gemport_index*

no mapping *index_number*

Syntax Description

<i>index_number</i>	The mapping index number. The value range is from 0 to 47.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
eth	The ONT Ethernet interface. Optional for SFU
veip	The ONT WAN interface. Optional for HGU
iphost	The ONT voice IP interface.
<i>gemport_index</i>	The GEM Port index number. The ranges is from 1 to 1024. Currently, only 24 GEM Ports can be configured in a line profile.
<i>priority</i>	The 802.1P. The range is from 0 to 7.
<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create GEM port mapping using ethernet port.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# mapping 2 port eth 3 gemport 3
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

mapping mode

To configure the GEM port mapping mode, use the **mapping mode** command in line profile configuration mode.

mapping mode {**port** | **port-priority** | **port-vlan** | **port-vlan-priority** | **priority** | **vlan** | **vlan-priority**}

Syntax Description

port	Configures port as the mapping mode.
port-priority	Configures port and 802.1p priority as the mapping mode.
port-vlan	Configures port and VLAN as the mapping mode.
port-vlan-priority	Configures port, VLAN and 802.1p priority as the mapping mode.
priority	Configures 802.1p priority as the mapping mode.
vlan	Configures VLAN as the mapping mode.
vlan-priority	Configures VLAN and 802.1p priority as the mapping mode.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure the GEM port mapping mode as VLAN

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# mapping mode vlan
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

no shutdown

To enable a shutdown port, use the **no shutdown** command in interface configuration mode. To disable a port use the **shutdown** command.

no shutdown

shutdown

Command Modes

Interface configuration (config-if)

Examples

This example shows how to enable a shutdown port.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# no shutdown
```

ont-find distance

To configure the ONT logical distance, use the **ont-find distance** command to global configuration mode. To disable the logical distance, use the **no ont-find distance** command.

ont-find distance min *minimum_distance* **max** *maximum_distance* **interface gpon** {*slot-number/port-number* | **all**}

no ont-find distance interface gpon {*slot-number/port-number* | **all**}

Syntax Description		
min <i>minimum_distance</i>		The minimum distance. The range is from 0 to 40. The default is 10.
max <i>maximum_distance</i>		The maximum distance. The distance range is from 0 to 60. The default is 30.
<i>slot-number/port-number</i>		<i>slot-number/port-number</i> : The port identifier. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1 to 24. • 10GE Ethernet: The value is 25 to 48. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 24. • GE Ethernet: The range is from 1 to 24. • 10GE Ethernet: The range is from 1 to 24.
all		All ports.

Command Modes Global configuration (config)

Examples This example shows how to configure the ONT logical distance.

```
Device> enable
Device# configure terminal
Device(config)# ont-find distance min 10 max 30 interface gpon 0/1
Change the logic distance will reset the PON port, are you sure(y/n)?[n]y
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-find interface gpon	Enables auto-discover configuration.
ont-find interval-time	Configures the auto-discover interval time.

Command	Description
ont-find list-age	Configures the auto-discover aging time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.
show ont-find list	Displays information about ONT find list.

ont-find interface gpon

To enable auto-discover configuration, use the **ont-find interface gpon** command in global configuration mode. To disable the logical distance, use the **no ont-find interface gpon** command.

ont-find interface gpon {*slot-number/port-number* | **all**}

no ont-find interface gpon {*slot-number/port-number* | **all**}

Syntax Description

slot-number/port-number

slot-number/port-number : The port

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is
- 10GE Ethernet: The value

- *port-number*:

- GPON: The range is from
- GE Ethernet: The range is
- 10GE Ethernet: The range

all

All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to enable auto-discover configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont-find interface gpon 0/1
```

Related Commands

Command	Description
ont-find distance	Configures the ONT logical distance.
ont-find interval-time	Configures the auto-discover interval time.
ont-find list-age	Configures the auto-discover aging time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.
show ont-find list	Displays information about ONT find list.

ont-find interval-time

To configure the auto-discover interval time, use the **ont-find interval-time** command in global configuration mode. To disable the auto-discover interval time, use the **no ont-find interval-time** command.

ont-find interval-time *interval_time* **interface gpon** {*slot-number/port-number* | **all**}

no ont-find interface gpon {*slot-number/port-number* | **all**}

Syntax Description

<i>interval_time</i>	The interval time. The range is from 3 to 30. The default is 10.
all	All ports.
<i>slot-number/port-number</i>	<i>slot-number/port-number</i> : The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 4.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the ONT auto-discover interval time.

```
Device> enable
Device# configure terminal
Device(config)# ont-find interval-time 20 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-find interface gpon	Enables auto-discover configuration.
ont-find distance	Configures the ONT logical distance.
ont-find list-age	Configures the auto-discover aging time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.
show ont-find list	Displays information about ONT find list.

ont-find list-age

To configure the auto-discover aging time, use the **ont-find list-age time** command in global configuration mode. Use the **no ont-find list-age time** command.

ont-find list-age time *aging_time* **interface gpon** {*slot-number/port-number* | **all**}

no ont-find list-age interface gpon {*slot-number/port-number* | **all**}

Syntax Description

<i>aging_time</i>	The discovery mode timeout time. The unit is hour. The value is 168.
<i>slot-number/port-number</i>	<p><i>slot-number/port-number</i> : The port ID.</p> <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all	All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the auto-discover aging time.

```
Device> enable
Device# configure terminal
Device(config)# ont-find list-age time 600 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-find interface gpon	Enables auto-discover configuration.
ont-find distance	Configures the ONT logical distance.
ont-find interval-time	Configures the auto-discover interval time.
show ont-find config	Displays information about ONT auto find configuration and other related parameters.

Command	Description
show ont-find list	Displays information about ONT find list.

ont-silent auth-fail

To enable the ONT auth-fail silent configuration, use the **ont-silent auth-fail** command in global configuration mode. To disable the ONT auth-fail silent configuration, use the **no ont-silent auth-fail** command.

ont-silent auth-fail {**time** *silence_period* | **interface gpon** {*slot-number/port-number* | **all**}}

no ont-silent auth-fail interface gpon {*slot-number/port-number* | **all**}

Syntax Description

silence_period

The silent period after a failed authentication.

The unit in seconds. The range is from 1 to 86400. The c

slot-number/port-number

slot-number/port-number : The port ID.

- *slot-number*:

- GPON: The value is 0.

- GE Ethernet: The value is 1.

- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 8.

- GE Ethernet: The range is from 1 to 4.

- 10GE Ethernet: The range is from 1 to 2.

all

All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to enable the ONT auth-fail silent configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont-silent auth-fail time 40 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-silent offline	Enables auto-discover configuration.

ont-silent offline

To enable the ONT offline silent configuration, use the **ont-silent offline** command in global configuration mode. To disable the ONT offline silent configuration, use the **no ont-silent offline** command.

ont-silent offline {*time silence_period* | **interface gpon** {*slot-number/port-number* | **all**}}

no ont-silent offline interface gpon {*slot-number/port-number* | **all**}

Syntax Description

silence_period

The silent period after a failed authentication.

The unit in seconds. The range is from 1 to 86400. T

slot-number/port-number

slot-number/port-number : The port ID.

• *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

• *port-number*:

- GPON: The range is from 1 to 8.
- GE Ethernet: The range is from 1 to 4.
- 10GE Ethernet: The range is from 1 to 2.

all

All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to enable the ONT offline silent configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont-silent offline time 40 interface gpon 0/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont-silent auth-fail	Enables ONT auth-fail silent configuration

ont auto-config

To enable ONT auto-configuration, use the **ont auto-config** command in global configuration mode. To disable ONT auto-configuration, use the **no ont auto-config** command.

ont auto-config [*index_number* **name** *name* | **name** *name*] {**all-ont** | **device-type** *device_type*}

no ont auto-config [*index_number* **name** *name* | **name** *name*] {**all-ont** | **device-type** *device_type*}

Syntax Description		
<i>index_number</i>		The index of the template. The range is from 0 to M, where M is the number of ONUs supported by the whole machine.
<i>name</i>		The name of the template.
all-ont		All ONTs.
device-type <i>device_type</i>		The device identifier. The format is in string. The range is 1 to M.

Command Modes Global configuration (config)

Examples

This example shows how to enable auto-configuration.

```
Device> enable
Device# configure terminal
Device(config)# ont auto-config
Device(config)# ont auto-config 1 device-type n40-428-1h line 1
```


permit loid-lopw

To create a logical ONT ID and logical ONT ID password permit profile, use the **permit loid-lopw** command in rule profile configuration mode.

```
permit loid-lopw lopw loid line {profile_line_list | name name} {default line {index_number | name name} | once-on {no-aging | aging-time time}}
```

Syntax Description		
<i>lopw</i>		The logical ONT ID password.
<i>loid</i>		The logical ONT ID.
<i>profile_line_list</i>		The profile line list number.
<i>index_number</i>		The profile index number. The range is from 0 to 1023.
<i>name</i>		The profile name. The format is string. The string length is 1 to 32 characters.
no-aging		Configures no timeout for discovery.
aging-time <i>time</i>		Configures timeout for discovery. The unit is hour. The range is from 1 to 24.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples This example shows how to create a logical ONT ID permit profile and logical ONT ID password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit loid-lopw logical1 password1 line 1 default line
1 once-on no-aging
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

permit loid

To create a logical ONT ID permit profile, use the **permit loid** command in rule profile configuration mode.

```
permit loid loid line {profile_line_list | name name} {default line {index_number | name name} | once-on
{no-aging | aging-time time}}
```

Syntax Description		
	<i>loid</i>	The logical ONT ID.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length
	no-aging	Configures no timeout for discovery m
	aging-time <i>time</i>	Configures timeout for discovery mod The unit is hour. The range is from 1 to

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples This example shows how to create a logical ONT ID permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit loid logical1 line 1 default line 1 once-on
no-aging
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

permit lopw

To create a logical ONT ID password permit profile, use the **permit lopw** command in rule profile configuration mode.

```
permit lopw lopw line {profile_line_list | name name} {default line {index_number | name name} | once-on {no-aging | aging-time time}}
```

Syntax Description		
	<i>lopw</i>	The logical ONT ID password.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length is 1 to 32 characters.
	no-aging	Configures no timeout for discovery.
	aging-time <i>time</i>	Configures timeout for discovery. The unit is hour. The range is from 1 to 24.

Command Modes Rule profile configuration (deploy-profile-rule)

Examples

This example shows how to create a logical ONT ID password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit lopw password1 line 1 default line 1 once-on
no-aging
```

permit pw

To create a password permit profile, use the **permit pw** command in rule profile configuration mode.

permit pw {string *string_password* | hex *hex_password*} **line** {*profile_line_list* | **name** *name*} {**default** **line** {*index_number* | **name** *name*} | **once-on** {**no-aging** | **aging-time** *time*}}

Syntax Description

<i>string_password</i>	The ONT password in Hex.
<i>hex_password</i>	The ONT password in string.
<i>profile_line_list</i>	The profile line list number.
<i>index_number</i>	The profile index number. The range is from 0 to 1023.
<i>name</i>	The profile name. The format is string. The string length is 1 to 32 characters.
no-aging	Configures no timeout for discovery mode.
aging-time <i>time</i>	Configures timeout for discovery mode. The unit is hour. The range is from 1 to 24.

Command Modes

Rule profile configuration (deploy-profile-rule)

Usage Guidelines

A rule profile type must be configured.

Examples

This example shows how to create a password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit pw string password1 line 1 default line 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

permit sn-pw

To create a serial number and password permit profile, use the **permit sn-pw** command in rule profile configuration mode.

```
permit sn-pw {string-hex string_serial_number | hex hex_serial_number} {string string_password | hex hex_password}line {profile_line_list | name name}default line {index_number | name name}
```

Syntax Description		
	<i>hex_serial_number</i>	The ONT serial number in Hex.
	<i>string_serial_number</i>	The ONT serial number in string.
	<i>string_password</i>	The ONT password in Hex.
	<i>hex_password</i>	The ONT password in string.
	<i>profile_line_list</i>	The profile line list number.
	<i>index_number</i>	The profile index number. The range is from 0 to 1023.
	<i>name</i>	The profile name. The format is string. The string length is 1 to 32 characters.

Command Modes Rule profile configuration (deploy-profile-rule)

Usage Guidelines A rule profile type must be configured.

Examples This example shows how to create a serial number and password permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit sn-pw string-hex GPON-1790032e string password1
line 1 default line 1
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

permit sn

To create a serial number permit profile, use the **permit sn** command in rule profile configuration mode.

permit sn {string-hex *string_serial_number* | hex *hex_serial_number*} **line** {*profile_line_list* | **name** *name*} **default line** {*index_number* | **name** *name*}

Syntax Description

<i>hex_serial_number</i>	The ONT serial number in Hex.
<i>string_serial_number</i>	The ONT serial number in string.
<i>profile_line_list</i>	The profile line list number.
<i>index_number</i>	The profile index number. The range is from 0 to 1023.
<i>name</i>	The profile name. The format is string. The string length

Command Modes

Rule profile configuration (deploy-profile-rule)

Usage Guidelines

A rule profile type must be configured.

Examples

This example shows how to create a ONT serial number permit profile.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile rule
Device(deploy-profile-rule)# aim 0/1/1
Device(deploy-profile-rule-0/1/1)# permit sn string-hex GPON-1790032e line 1 default line 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

show alarm ont register-record

To display information about register record alarm of an ONT, use the **show alarm ont register-record** command in privileged EXEC or global configuration mode.

show alarm ont register-record

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about register record alarm of an ONT

```
Device> enable
Device# configure terminal
Device(config)# show alarm ont register-record
register ont record threshold alarm status : enable
register ont record threshold value       : 64
register ont record current value         :
gpon port 0/1 : 1(normal)
gpon port 0/2 : 0(normal)
gpon port 0/3 : 0(normal)
gpon port 0/4 : 0(normal)
gpon port 0/5 : 0(normal)
gpon port 0/6 : 0(normal)
gpon port 0/7 : 0(normal)
gpon port 0/8 : 0(normal)
```

show keyfile

To display the key file information, use the **show keyfile** command in privileged EXEC or global configuration mode.

show keyfile {public | private}

Syntax Description		
	public	The SSH public key file.
	private	The SSH private key file.

Command Modes

- Privileged EXEC (#)
- Global configuration (config)

Examples

This example shows how to view the key file information

```
Device> enable
Device# show keyfile public
```


show ont-find config

To display information about ONT auto find configuration, use the **show ont-find config** command in privileged EXEC or global configuration mode.

```
show ont-find config interface gpon {port_list | all}
```

Syntax Description		
	<i>port_list</i>	The GPON port.
	all	All ports.

Command Modes

Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to view information about ONT auto find configuration.

```
Device> enable
Device# configure terminal
Device(config)# show ont-find config interface gpon 0/1
Port  Find    Find-interval  Age    Aging-time  D-min  D-max
g0/1  enable  10             enable  600         0      20
```

show ont-find list

To display information about ONT find list, use the **show ont-find list** command in privileged EXEC or global configuration mode.

```
show ont-find list {interface gpon {slot-number/port-number | all} | sn {string-hex string_serial_number | hex hex_serial_number}}
```

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is

- *port-number*:

- GPON: The range is from 1 to
- GE Ethernet: The range is from
- 10GE Ethernet: The range is

all

All ports.

hex_serial_number

The ONT serial number in Hex.

string_serial_number

The ONT serial number in string.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about ONT find list

```
Device> enable
Device# configure terminal
Device(config)# show ont-find list interface gpon 0/1
```

show ont-silent config

To display information about ONT silent function, use the **show ont-silent config** command in privileged EXEC or global configuration mode.

show ont-silent config interface gpon *{port_list | all}*

Syntax	Description
<i>port_list</i>	The GPON port.
all	All ports.

Command Modes

- Privileged EXEC (#)
- Global configuration (config)

Examples

This example shows how to view the information about ONT silent function.

```
Device> enable
Device# configure terminal
Device(config)# show ont-silent config interface gpon 0/1
Port Auth-fail time Offline time
g0/1 enable 40 disable -
```

show ont-silent list

To display information about silent ONT, use the **show ont-silent list** command in privileged EXEC or global configuration mode.

```
show ont-silent list {interface gpon {slot-number/port-number | all} | sn {string-hex string_serial_number | hex hex_serial_number}}
```

Syntax Description

<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 t • GE Ethernet: The range is fro • 10GE Ethernet: The range is
all	All ports.
<i>hex_serial_number</i>	The ONT serial number in Hex.
<i>string_serial_number</i>	The ONT serial number in string.

Command Modes

Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to view the information about silent ONT.

```
Device> enable
Device# configure terminal
Device(config)# show ont-silent list interface gpon 0/1
```

show ont brief count

To display brief information about an ONT interface, use the **show ont brief count** command in privileged EXEC or global configuration mode.

show ont brief count interface interface gpon {*slot-number/port-number* | **all**}

Syntax Description		
<i>slot-number/port-number</i>		The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 16. • GE Ethernet: The range is from 1 to 24. • 10GE Ethernet: The range is from 1 to 24.
all		All ports.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the brief information about an ONT interface.

```
Device> enable
Device# configure terminal
Device(config)# show ont brief count interface gpon 0/1
Port Online-num Offline-num Total
g0/1 1 4 5
Total entries: 1.
```

show ont description

To display the description of an ONT, use the **show ont description** command in privileged EXEC or global configuration mode.

show ont description {*slot-num/pon-num/ont-num* | **interface gpon** *slot-number/port-number* }

Syntax Description

slot-num/pon-num/ont-num

The ONT ID.

- *slot-num*: The slot number. The value is 0.
- *pon-num*: The PON number. The range is from 1 to 8.
- *ont-num*: The ONT number. The range is from 1 to 16.

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 8.
 - GE Ethernet: The range is from 1 to 4.
 - 10GE Ethernet: The range is from 1 to 2.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the description of an ONT

```
Device> enable
Device# configure terminal
Device(config)# show ont description interface gpon 0/1
```

show ont info

To display detailed information about an ONT, use the **show ont info** command in privileged EXEC or global configuration mode.

show ont info *slot-num/pon-num/ont-num*

Syntax Description	<i>slot-num/pon-num/ont-num</i>	The ONT ID.
		<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from • <i>ont-num</i>: The ONT number. The range is from

Command Modes	Privileged EXEC (#) Global configuration (config)
---------------	--

Examples

This example shows how to view detailed information about an ONT

```
Device> enable
Device# configure terminal
Device(config)# show ont info 0/1/5
ONT : 0/1/5
Description : -
TYPE : -
Status : online
Distance (m) : 3
Vendor ID : CSCO
Software Version : 1.1.2.5/1.1.2.6
Firmware Version : N40-428-1
Equipment ID : 4GE-POE-2POTS-CATV
SN : GPON-5aa7012a
Password : 123456
LOID : 000a5aa7012a
LOID Password : a7012a
Uplink PON ports : 1
ETH/POTS/TDM/MOCA ports : 4/2/0/0
CATV ANI/UNI ports : 0/1
T-CONTs/GEM ports : 31/127
Traffic Schedulers : 31
PQs in T-CONT 1-8 : 8/8/8/8/8/8/8/8
DBA method : NSR
IP configuration : not support
Type of flow control : GEMPORT CAR and PQ SCHEDULED
TX power cut off : Not Support
Online/Offline time : 05:04:03 2001/12/08
Up/Down time : 1 day(s) 17 hour(s) 34 minute(s)
```

show ssh

To display SSH configuration, use the **show ssh** command in privileged EXEC or global configuration mode.

show ssh

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the SSH configuration

```
Device> enable
Device# show ssh
ssh version   : 2.0
ssh state     : on
ssh key file  : available
```


show ssh limit

To display the maximum number of the users, use the **show ssh limit** command in privileged EXEC or global configuration mode.

show ssh limit

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the maximum number of the users.

```
Device> enable
Device# show ssh limit
SSH user limit is 5, current is 0.
```

show telnet

To display the telnet information, use the **show telnet** command in privileged EXEC or global configuration mode.

show telnet

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to display the telnet information.

```
Device> enable
Device# configure terminal
Device(config)# show telnet
Telnet service port is 23, using port is 23, user limit is 5, current is 1.
```

sip agent

To configure the SIP proxy server, use the **sip agent proxy-server** command in unique profile configuration mode. To disable the SIP proxy server, use the **no sip agent proxy-server** command.

```
sip agent proxy-server proxy_server_uri {outbound-proxy | registrar-server | signal-port}proxy_server_uri
```

```
no sip agent
```

Syntax Description		
	<i>proxy_server_uri</i>	The proxy server URI.
	outbound-proxy	The outbound proxy.
	registrar-server	The registrar server.
	signal-port	The signal port.

Command Modes Unique profile configuration (deploy-profile-unique)

Usage Guidelines A unique profile type must be configured.

Examples This example shows how to configure the SIP proxy server.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip agent proxy-server 2
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

sip digitmap

To configure the SIP digit map, use the **sip digitmap** command in unique profile configuration mode.

sip digitmap dial-plan-id *dial_plan_id* **dial-plan-token** *token*

Syntax Description		
<i>dial_plan_id</i>		The digit map index The range is from 1 to 10.
<i>token</i>		The token

Command Modes Unique profile configuration (deploy-profile-unique)

Usage Guidelines A unique profile type must be configured.

Examples This example shows how to configure the SIP digit map.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip digitmap dial-plan-id 3 dial-plan-token token1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

sip user

To configure the SIP users, use the **sip user** *user_id* command in unique profile configuration mode. To disable SIP users, use the **no sip user** *user_id* command.

sip user *pots_number* {**name** *username* **password** *password* | **telno** *telephone_number*}

no sip user *pots_number*

Syntax	Description
<i>pots_number</i>	The ONT POTS port number. The value range is from 1 to 2
<i>username</i>	The SIP username. The username length is from 1 to 25.
<i>password</i>	The SIP password. The password length is from 1 to 25
<i>telephone_number</i>	The ONT local phone number. The digit length is from 1 to 25.

Command Modes Unique profile configuration (deploy-profile-unique)

Usage Guidelines A unique profile type must be configured.

Examples This example shows how to configure the SIP users

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip user 2 name user 1 password 123
```

Related Commands	Command	Description
	deploy profile	Deploys a profile type
	aim	Creates aim based on the profile.

sip user mode

To configure a SIP interface, use the **sip user mode** command in unique profile configuration mode. To disable a SIP interface, use the **no sip user mode** command.

```
sip user mode { static ip-address ip_address mask mask gateway gateway_address primary-dns
primary_dns_address secondary-dns secondary_dns_address | dhcp } vlan vlan_id priority host
host_number
```

no sip user mode

Syntax Description

ip-address <i>ip_address</i>	The IP address.
mask <i>mask</i>	The IP network mask.
gateway <i>gateway_address</i>	The gateway IP address.
primary-dns <i>primary_dns_address</i>	The primary DNS server IP address.
secondary-dns <i>secondary_dns_address</i>	The secondary DNS server IP address.
vlan <i>vlan_id</i>	The VLAN ID.
priority	The priority range is 1 to 255.
host <i>host_number</i>	The host number range is 1 to 255.

Command Modes

Unique profile configuration (deploy-profile-unique)

Usage Guidelines

A unique profile type must be configured.

Examples

This example shows how to configure an SIP interface

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# sip user mode dhcp vlan 2 4 host 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

snmp-server

To enable the snmp server to send traps or disable the snmp server, use the **snmp-server** command in global configuration mode.

```
snmp-server {enable | disable}
```

Syntax	Description
enable	Enables the snmp server to send traps.
disable	Disables the snp server.

Command Modes Global configuration (config)

Examples

This example shows how to disable the snmp server.

```
Device> enable
Device# configure terminal
Device(config)# snmp-server disable
```

ssh

To enable SSH, use the **ssh** command in global configuration mode. To disable SSH, use the **no ssh** command.

ssh

no ssh

Command Modes

Global configuration (config)

Examples

This example shows how to enable SSH.

```
Device> enable
Device# configure terminal
Device(config)# ssh
Config SSH state successfully.
```

Related Commands

Command	Description
ssh limit <i>value</i>	Limits the number of user logins on SSH.
stop vty { <i>vty_list</i> all }	Removes logged in users.
crypto key	Configures or removes a key.
upload keyfile	Uploads the local key to the key server
load keyfile	Downloads the key from the external key server

ssh limit

To limit the number of user logins on SSH, use the **ssh limit** command in global configuration mode.

ssh limit *value*

Syntax Description

value

The user login limit value.

The range is 0-5.

Command Modes

Global configuration (config)

Usage Guidelines

SSH must be enabled on the device.

Examples

This example shows how to limit the number of user logins on SSH.

```
Device> enable
Device# configure terminal
Device(config)# ssh limit 5
```

Related Commands

Command	Description
aim	Creates .

stop telnet client

To remove logged in Telnet clients, use the **stop telnet client** command in privileged EXEC mode.

stop telnet client {*terminal_id* | **all**}

Syntax Description		
	<i>terminal_id</i>	Telnet clients logged in through a particular terminal
	all	All Telnet clients.

Command Modes Privileged EXEC (#)

Usage Guidelines Use this command on the OLT configured as the Telnet server.

Examples

This example shows how to remove logged in Telnet clients

```
Device> enable
Device# stop telnet client all
Stop all telnet clients successfully.
```

Related Commands

Command	Description
telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

stop vty

To remove logged in users, use the **stop vty** command in privileged EXEC mode.

stop vty {*vtty_list* | **all**}

Syntax Description		
	<i>vtty_list</i>	Users on the vty list only
	all	All logged in users.

Command Modes Privileged EXEC (#)

Usage Guidelines SSH must be enabled on the device.

Examples This example shows how to remove logged in users.

```
Device> enable
Device# stop vty 3
```

Related Commands	Command	Description
	ssh	Enables SSH on an OLT.

tcont *tcont_id*

To create a transmission container (T-CONT), use the **tcont** *tcont_id* command in line profile configuration mode. To delete a T-CONT, use the **no tcont** *tcont_id* command.

tcont *tcont_id* **profile dba** {*index_number* | **name** *name*}

no tcont *tcont_id*

Syntax Description

<i>tcont_id</i>	The T-CONT ID. The range is from 1 to 8.
<i>index_number</i>	The index of the template. The range is from 0 to M, where M supported by the whole machine.
<i>name</i>	The name of the template.

Command Modes

Line profile configuration (deploy-profile-line)

Usage Guidelines

A line profile type must be configured.

Modifying and activating the line traffic profile will cause the ONT that references the template to go online again.

Examples

This example shows how to create a T-CONT.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# tcont 6 profile dba 100
Device(deploy-profile-line-5)# active
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

telnet disable

To disable Telnet on an OLT, use the **telnet disable** command in global configuration mode.

telnet disable

Command Modes Global configuration (config)

Usage Guidelines Use this command on the OLT configured as the Telnet server.

Examples This example shows how to disable Telnet on an OLT.

```
Device> enable
Device# configure terminal
Device(config)# telnet disable
```

Related Commands

Command	Description
telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

telnet enable

To enable Telnet on an OLT and configures the OLT as the Telnet server , use the **telnet enable** command in global configuration mode.

telnet enable

Command Modes Global configuration (config)

Examples This example shows how to enable Telnet on an OLT

```
Device> enable
Device# configure terminal
Device(config)# telnet enable
```

Related Commands

Command	Description
telnet disable	Disables Telnet on an OLT.
telnet limit <i>value</i>	Limits the number of users that can login to the Telnet server.
timeout <i>value</i>	Enables the client timeout and configures the timeout value.
stop telnet client { <i>terminal_id</i> all }	Removes logged in Telnet clients.

telnet limit

To limit the number of users that can login to the Telnet server, use the **telnet limit** command in global configuration mode.

telnet limit *value*

Syntax Description	<i>value</i>	The limit of the number of users. The range is 0-5.
--------------------	--------------	--

Command Modes Global configuration (config)

Usage Guidelines Use this command on the OLT configured as the Telnet server.

Examples This example shows how to limit the number of users that can login to the Telnet server.

```
Device> enable
Device# configure terminal
Device(config)# telnet limit 3
```

Related Commands	Command	Description
	telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

telnet *server-ip*

To login to the Telnet server, use the **telnet** *server-ip* command in Privileged EXEC mode.

telnet *server-ip* [*port-number* | **/localecho**]

Syntax Description		
	<i>server-ip</i>	The Telnet server IP address
	<i>port-number</i>	The port number.
	/localecho	

Command Modes Privileged EXEC (#)

Examples

This example shows how to login to the Telnet server.

```
Device> enable
Device# telnet 100.100.100.1
```

Related Commands

Command	Description
telnetclient timeout <i>value</i>	Enables client timeout and configures the timeout interval.

telnetclient timeout

To enable client timeout, use the **telnetclient timeout** command in global configuration mode. To disable client timeout, use the **no telnetclient timeout** command.

telnetclient timeout [*value*]

no telnetclient timeout

Syntax Description	<i>value</i>	The system idle timeout value. The unit is minutes. The range is from 1 to 480.
---------------------------	--------------	--

Command Modes Global configuration (config)

Usage Guidelines Use this command on the OLT configured as the Telnet client. To enable client timeout, use the **telnetclient** command in global configuration mode. To configure the timeout interval, use the **telnetclient value** command.

Examples This example shows how to enable client timeout.

```
Device> enable
Device# configure terminal
Device(config)# telnetclient timeout
```

Related Commands	Command	Description
	telnet <i>server-ip</i>	Logins to the Telnet server

timeout

To enable the client timeout, use the **timeout** command in privileged EXEC mode. To disable the client timeout function, use the **no timeout** command.

timeout *value*

no timeout

Syntax Description	<i>value</i>	The system idle timeout value. The unit is minutes. The range is from 1 to 480.
---------------------------	--------------	--

Command Modes Privileged EXEC (#)

Usage Guidelines Use this command on the OLT configured as the Telnet server. To enable the client timeout, use the **timeout** command. To configure the client timeout value, use the **timeout value** command.

Examples

This example shows how to configure a client timeout interval of 30 minutes.

```
Device> enable
Device# timeout 30
```

Related Commands

Command	Description
telnet enable	Enables Telnet on a OLT and configures the OLT as the Telnet server.

translate old-vlan

To configure the VLAN translate rule, use the **translate old-vlan** command in VLAN profile configuration mode. To disable the **no translate old-vlan** command.

```
translate old-vlan vlan_id [priority | new-vlan vlan_id [priority]]
```

```
no translate old-vlan vlan_id [priority]
```

Syntax Description

<i>priority</i>	The priority value. The range is from 0 to 7.
<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.

Command Modes

VLAN profile configuration (deploy-profile-vlan)

Usage Guidelines

A VLAN profile type must be configured.

Modifying and activating the VLAN template will cause the ONT that references the template to go online again.

Examples

This example shows how to configure the VLAN translate rule

```
Device> enable
Device# configure terminal
Device(config)# deploy profile vlan
Device(deploy-profile-vlan)# aim 5
Device(deploy-profile-vlan-5)# translate old-vlan 2 2 new-vlan 10 5
Device(deploy-profile-vlan-5)# active
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 1 fix

To configure only a fixed bandwidth, use the **type 1 fix** *fixed_bandwidth* command in DBA profile configuration mode.

type 1 fix *fixed_bandwidth*

Syntax Description	<i>fixed_bandwidth</i>	The fixed bandwidth in kbps. The range is from 64 to 1024. The fixed bandwidth must be divisible by 64 kbps.
---------------------------	------------------------	---

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 1 T-CONT is preferred for services that are sensitive to the data forwarding delay. For example, VoIP services.

A DBA profile type must be configured.

Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure type 1 T-CONT.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 1 fix 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 2

To configure only the assured bandwidth, use the **type 2 assured** *assured_bandwidth* command in DBA profile configuration mode.

type 2 assured *assured_bandwidth*

Syntax Description	<i>assured_bandwidth</i>	The assured bandwidth in kbps. The range is 1 to 1000000. The assured bandwidth must be divisible by 100.
---------------------------	--------------------------	---

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 2 T-CONT is preferred for services without strict delay and jitter requirements. For example, IPTV multicast services.

A DBA profile type must be configured.

Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example shows how to configure type 2 T-CONT.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 2 assured 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 3

To configure both assured bandwidth and non-assured bandwidth, use the **type 3 assured** *assured_bandwidth* **max** *max_bandwidth* command in DBA profile configuration mode.

type 3 assured *assured_bandwidth* **max** *max_bandwidth*

Syntax Description		
	<i>assured_bandwidth</i>	The assured bandwidth in kbps. The range is The assured bandwidth must be divisible by
	<i>max_bandwidth</i>	The maximum bandwidth in kbps. The range is The maximum bandwidth must be divisible by

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 3 T-CONT is preferred for services with variable-rate burst traffic.
A DBA profile type must be configured.
Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example show how to configure both assured bandwidth and non-assured bandwidth.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 3 assured 1024 max 2500
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 4

To configure the optimum bandwidth, use the **type 4 max *max_bandwidth*** command in DBA profile configuration mode.

type 4 max *max_bandwidth*

Syntax Description	<i>max_bandwidth</i>	The maximum bandwidth in kbps. The range is 1 to 1024. The maximum bandwidth must be divisible by 10.
--------------------	----------------------	---

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 4 T-CONT is preferred for services with variable-rate burst traffic which does not exhibit delay sensitivity. For example, internet data services.

A DBA profile type must be configured.

Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example show how to configure the optimum bandwidth.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 4 max 1024
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

type 5

To configure a combination of fixed, assured and best-effort bandwidth, use the **type 5 fix** *fixed_bandwidth* **assured** *assured_bandwidth* **max** *max_bandwidth* command in DBA profile configuration mode.

type 5 fix *fixed_bandwidth* **assured** *assured_bandwidth* **max** *max_bandwidth*

Syntax Description		
	<i>fixed_bandwidth</i>	The fixed bandwidth in kbps. The range is 1 to 1000000. The fixed bandwidth must be divisible by 100.
	<i>assured_bandwidth</i>	The assured bandwidth in kbps. The range is 1 to 1000000. The assured bandwidth must be divisible by 100.
	<i>max_bandwidth</i>	The maximum bandwidth in kbps. The range is 1 to 1000000. The maximum bandwidth must be divisible by 100.

Command Modes DBA profile configuration (deploy-profile-dba)

Usage Guidelines Type 5 T-CONT is preferred for services with general traffic.
A DBA profile type must be configured.
Modifying and activating the DBA profile will cause the ONT that references the template to go online again.

Examples

This example show how to configure a combination of fixed, assured and best-effort bandwidth

```
Device> enable
Device# configure terminal
Device(config)# deploy profile dba
Device(deploy-profile-dba)# aim 5
Device(deploy-profile-dba-5)# type 5 fix 1024 assured 1024 max 2048
Device(deploy-profile-dba-5)# active
```

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

upload keyfile

To upload the local key to the key server, use the **upload keyfile** command in privileged EXEC mode.

Upload to a TFTP server

```
upload keyfile {public | private} tftp {inet | inet6} server_ip filename
```

Upload to a FTP server

```
upload keyfile {public | private} ftp {inet | inet6} server_ip filename
```

Syntax Description

public	The public SSH key file
private	The private SSH key file
tftp	Loads the file from the TFTP server.
ftp	Loads the file from FTP server.
inet	The IPv4 address family.
inet6	The IPv6 address family
<i>server_ip</i>	The server IP address
<i>filename</i>	The key filename.

Command Modes

Privileged EXEC (#)

Usage Guidelines

SSH must be enabled on the device.

Examples

This example shows how to upload the local key to the FTP server

```
Device> enable
Device# upload keyfile public ftp inet 100.100.100.1 mykey admin 123456
```

Related Commands

Command	Description
ssh	Enables SSH on an OLT.
load keyfile	Downloads the key from the external key server

us car

To configure GEM port traffic control, use the **us car cir cbs cbs pir pir pbs pbs** command in uplink traffic profile configuration mode.

us car cir cbs cbs pir pir pbs pbs

Syntax Description		
cir <i>cir</i>		The committed information rate in kbps. The range is from 64 to 800000.
cbs <i>cbs</i>		The committed burst size in KB. The range is from 2 to 25000.
pir <i>pir</i>		The peak information rate in kbps. The range is from 64 to 1024000.
pbs <i>pbs</i>		The peak burst size in KB. The range is from 2 to 25000.

Command Modes Uplink traffic profile (deploy-profile-us-traffic)

Usage Guidelines An uplink profile type must be configured.
The peak information rate requirement is greater than or equal to committed information rate.
Modifying and activating the uplink traffic profile will cause the ONT that references the template to go online again.

Examples This example shows how to configure GEM port traffic control.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile us-traffic
Device(deploy-profile-us-traffic)# aim 5
Device(deploy-profile-us-traffic-5)# us queue 1
Device(deploy-profile-us-traffic-5)# us car cir 128 cbs 1024 pir 128 pbs 24
Device(deploy-profile-us-traffic-5)# active
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.

us queue

To configure GEM port queue priority, use the **us queue** command in uplink traffic profile configuration mode.

us queue *priority_queue*

Syntax Description

priority_queue

The priority queue.

The range is from 0 to 7.

Command Modes

Uplink traffic profile (deploy-profile-us-traffic)

Usage Guidelines

An uplink profile type must be configured.

Examples

This example shows how to configure GEM port queue priority

```
Device> enable
Device# configure terminal
Device(config)# deploy profile us-traffic
Device(deploy-profile-us-traffic)# aim 5
Device(deploy-profile-us-traffic-5)# us queue 1
```

Related Commands

Command	Description
deploy profile	Deploys a profile type
aim	Creates aim based on the profile.



PART II

Managing Users

- [Managing Users, on page 101](#)



Managing Users

- `aaa`, on page 103
- `auth-secret-key`, on page 104
- `default domain-name`, on page 105
- `domain`, on page 106
- `login-access-list`, on page 107
- `muser local`, on page 108
- `muser radius`, on page 109
- `muser tacacs+`, on page 110
- `radius host`, on page 111
- `radius host binding`, on page 112
- `service password-encryption`, on page 113
- `show domain`, on page 114
- `show login-access-list`, on page 115
- `show muser`, on page 116
- `show running-config oam`, on page 117
- `show tacacs+`, on page 118
- `show username`, on page 119
- `show username privilege-auth`, on page 120
- `show username silent`, on page 121
- `show users`, on page 122
- `state active`, on page 123
- `state block`, on page 124
- `stop`, on page 125
- `tacacs+`, on page 126
- `tacacs+ authentication-type`, on page 127
- `tacacs+ encrypt-key`, on page 128
- `tacacs+ preemption-time`, on page 129
- `timeout`, on page 130
- `username`, on page 131
- `username change-password`, on page 133
- `username change-privilege-pwd`, on page 134
- `username failmax`, on page 135
- `username online-max`, on page 136

- [username privilege-auth-remote-user](#), on page 137
- [username privilege-auth](#), on page 138
- [username silent-time](#), on page 139

aaa

To enter Authentication Authorization and Accounting (AAA) configuration mode, use the **aaa** command in global configuration mode.

aaa

Command Modes

Global configuration (config)

Examples

This example shows how to enter AAA configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)#
```

Related Commands

Command	Description
auth-secret-key	Configures a RADIUS authentication key
default domain-name	Enables or disables the default domain
domain <i>domain_name</i>	Specifies a RADIUS domain name

auth-secret-key

To configure a RADIUS authentication key, use the **auth-secret-key** command in AAA configuration mode. To delete the configured RADIUS authentication key, use the **no** form of the command.

auth-secret-key *key*
no auth-secret-key

Syntax Description	
<i>key</i>	The secret key.

Command Modes AAA configuration (config-aaa)

Usage Guidelines Use this command in the AAA configuration mode.

Examples This example shows how to configure a RADIUS authentication key

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# auth-secret-key key1
```

Related Commands	Command	Description
	aaa	Enters AAA configuration mode

default domain-name

To enable or disable the default domain, use the **default domain-name** command in AAA configuration mode.

default domain-name {**enable** *domain-name* | **disable**}

Syntax Description		
enable		Enables the default domain.
<i>domain-name</i>		The default domain name The format is string.
disable		Disables the default domain.

Command Modes AAA configuration (config-aaa)

Usage Guidelines Use this command in the AAA configuration mode.

Examples

This example shows how to configure the default domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain default1
Device(config-aaa-domain-default1)# radius host binding cisco
Device(config-aaa-domain-default1)# state active
Device(config-aaa-domain-default1)# exit
Device(config-aaa)# default domain-name enable domain1
Succeed in setting default domain.
```

Related Commands	Command	Description
	aaa	Enters AAA configuration mode

domain

To specify a RADIUS domain name, use the **domain** *domain_name* command in AAA configuration mode.

domain *domain_name*

Syntax Description

domain_name

The name of the domain.

The format is string.

Command Modes

AAA configuration (config-aaa)

Usage Guidelines

Use this command in the AAA configuration mode.

Examples

This example shows how to specify the RADIUS domain name

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain domain1
Device(config-aaa-domain-domain1)#
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode

login-access-list

To allow access for specific IP addresses, use the **login-access-list** {snmp | ssh | telnet} command in global configuration mode. To block all IP addresses, use the **no login-access-list** command.

login-access-list {snmp *ip_address mask* | ssh *ip_address mask* | telnet *ip_address mask* | telnet-limit *max_user_number*}

no login-access-list {snmp {all | *ip_address mask*} | ssh {all | *ip_address mask*} | telnet {all | *ip_address mask*} | telnet-limit *max_user_number*}

Syntax	Description
snmp	The SNMP client.
ssh	The SSH client.
telnet	The Telnet client.
all	Deletes all IP addresses.
<i>ip_address</i>	The IP address.
<i>mask</i>	The IP address mask.
telnet-limit <i>max_user_number</i>	Limit the number of Telnet users. The range is 1 to 16.

Command Modes Global configuration (config)

Usage Guidelines Use the **no login-access-list** {snmp | ssh | telnet} all command to block all IP access.

Use the **login-access-list** {snmp | ssh | telnet} 0.0.0.0 [0.0.0.0 | 255.255.255.255] command to allow all IP access.

Examples This example shows how to delete all IP addresses from the SNMP client.

```
Device> enable
Device# configure terminal
Device(config)# no login-access-list snmp all
Delete access ip address successfully.
```

Related Commands	Command	Description
	show login-access-list	Displays the list of allowed IP addresses.

muser local

To enable local authentication mode, use the **muser local** command in global configuration mode.

muser local

Command Modes Global configuration (config)

Examples This example shows how to enable local authentication mode

```
Device> enable
Device# configure terminal
Device(config)# muser local
Config manager user authentication successfully.
```

Related Commands

Command	Description
show muser	Displays the authentication configuration

muser radius

To enable RADIUS remote authentication, use the **muser radius** *radius_name* command in global configuration mode.

muser radius *radius_name* {**pap** | **chap**} {**account** | **local**}

Syntax Description

<i>radius_name</i>	The RADIUS host name. The format is string. The range is from 1 to 32 characters.
pap	The password authentication protocol (PAP).
chap	The challenge handshake authentication protocol (CHAP).
account	Manages login accounting through the RADIUS server.
local	Allows local authentication when the remote RADIUS server is unavailable.

Command Modes

Global configuration (config)

Examples

This example shows how to enable RADIUS remote authentication.

```
Device> enable
Device# configure terminal
Device(config)# muser radius cisco pap local
```

Related Commands

Command	Description
show muser	Displays the authentication configuration

muser tacacs+

To enable TACACS+ remote authentication mode, use the **muser tacacs+** command in global configuration mode.

muser tacacs+ {**author** | **account** | **command-account** | **local**}

Syntax Description

author	Allows login authorization through the TACACS+ server.
account	Manages login accounting through the TACACS+ server.
command-account	Forwards all the command lines to the TACACS+ server.
local	Allows local authentication when the remote authentication fails.

Command Modes

Global configuration (config)

Examples

This example shows how to enable TACACS+ remote authentication.

```
Device> enable
Device# configure terminal
Device(config)# muser tacacs+
```

Related Commands

Command	Description
show muser	Displays the authentication configuration.

radius host

To configure a RADIUS server name, use the **radius host** command in AAA configuration mode.

radius host *radius_name*

Syntax Description	<i>radius_name</i>	The name of the RADIUS serve
---------------------------	--------------------	------------------------------

Command Modes	AAA configuration (config-aaa)
----------------------	--------------------------------

Usage Guidelines	Use this command in the AAA configuration mode.
-------------------------	---

Examples	This example shows how to configure a RADIUS server name
-----------------	--

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
```

Related Commands	Command	Description
	aaa	Enters AAA configuration mode
	show radius host	Displays the RADIUS host configuration

radius host binding

To bind a domain to the RADIUS server name, use the **radius host binding** command in AAA configuration mode.

radius host binding *radius-name*

Syntax Description

radius-name

The RADIUS name server.

The format is string.

Command Modes

AAA configuration (config-aaa)

Usage Guidelines

Use this command in the AAA configuration mode.

Examples

This example shows how to bind the RADIUS host to the domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain radius1
Device(config-aaa-domain-radius1)# radius host binding cisco
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode
show radius host	Displays the RADIUS host configuration

service password-encryption

To save a password in cipher text, use the **service password-encryption** command in global configuration mode.

service password-encryption

Command Modes

Global configuration (config)

Examples

This example shows how to save a password in cipher text

```
Device> enable
Device# configure terminal
Device(config)# service password-encryption
```

show domain

To display the domain configuration, use the **show domain** command in privileged EXEC or global configuration mode.

show domain [*domain_name*]

Syntax	Description
<i>domain_name</i>	The name of the domain. The format is string.

Command Modes	Description
Privileged EXEC (#)	
Global configuration (config)	

Examples

This example shows how to display the domain configuration.

```
Device> enable
Device# configure terminal
Device(config)# show domain domain1
Default domain name : domain1
DomainName          : domain1
RADIUSServerName    : cisco
Access-limit        : disabled
AccessedNum         : 0
Scheme              : radius
State               : Block
```

Total [1] item(s).

show login-access-list

To display the list of allowed IP addresses, use the **show login-access-list** command in privileged EXEC or global configuration mode.

show login-access-list

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the list of allowed IP addresses.

```
Device> enable
Device# configure terminal
Device(config)# show login-access-list
sno  ipAddress  wildcard bits  terminal
1    0.0.0.0    255.255.255.255 telnet
2    0.0.0.0    255.255.255.255 ssh
```

Related Commands

Command	Description
login-access-list {snmp ssh telnet}	Allows access for specific IP addresses

show muser

To display the authentication configuration, use the **show muser** command in privileged EXEC or global configuration mode.

show muser

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the authentication configuration.

```
Device> enable
Device# configure terminal
Device(config)# show muser
Show manager user authentication.
Authentication type : local
Admin-Remote-Auth: Disable
```

show running-config oam

To display the timeout configuration, use the **show running-config oam** command in privileged EXEC or global configuration mode.

show running-config oam

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the timeout configuration.

```
Device> enable
Device# configure terminal
Device(config)# show running-config oam
![OAM]
no login-access-list snmp 0.0.0.0 255.255.255.255
service password-encryption
username text privilege 0 password 7 884863d2
banner
screen-rows per-page 55
hostname 2
telnet limit 3
exit
timeout 100
configure terminal
telnetclient timeout 2
ip icmp mask-reply
```

show tacacs+

To display the TACACS+ configuration, use the **show tacacs+** command in privileged EXEC or global configuration mode.

show tacacs+

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the TACACS+ configuration.

```
Device> enable
Device# configure terminal
Device(config)# show tacacs+
Primary Server Configurations:
IP address: : 192.168.1.10
Connection port: : 49
Connection timeout: : 5
Key: : 123456

Secondary Server Configurations:
IP address: : 192.168.1.11
Connection port: : 49
Connection timeout: : 5
Key: : 123456
```


show username

To display the user information, use the **show username** command in privileged EXEC or global configuration mode.

show username *username*

Syntax Description

<i>username</i>	The user name.
-----------------	----------------

Command Modes

Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to view the user information.

```
Device> enable
Device# configure terminal
Device(config)# show username admin
display user information
Terminal type: C=Console, T=Telnet, S=SSH, W=Web
Global Failmax: n/a
User Name          Role      Terminal  FailMax  Fail    OnLineMax  OnLine
-----
admin              ADMIN    CTSW      n/a      0       n/a        1
```

Related Commands

Command	Description
username <i>username</i>	Adds a user

show username privilege-auth

To display the privilege password authentication configuration, use the **show username privilege-auth** command in privileged EXEC or global configuration mode.

show username privilege-auth

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the configuration of second-tier password authentication

```
Device> enable
Device# configure terminal
Device(config)# show username privilege-auth
Privilege-password authentication
  switch: OFF
  remote-user name: remote_admin
  password not configured
```

Related Commands

Command	Description
username privilege-auth	Enables privilege password authentication for a local user

show username silent

To display a user silent period information, use the **show username silent** command in privileged EXEC or global configuration mode.

show username silent

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view a user silent period information

```
Device> enable
Device# configure terminal
Device(config)# show username silent
display user silent period information
Silent Time: 2 minutes
User Name          State      Silent End Time
-----
admin              Off       n/a
text               Off       n/a
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
username silent-time	Configures the silent time
show username	Displays the user information

show users

To display the online users, use the **show users** command in privileged EXEC or global configuration mode.

show users

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the online users.

```
Device> enable
Device# configure terminal
Device(config)# show users
Only 5 users logged in by telnet are allowed to be in privileged mode.
Now 1 users logged in by telnet have been in privileged mode.

User "admin" logged in at time 2001/12/09 16:53:44
Time passed after login: 0 days 0 hours 12 minutes 32 seconds
Time no operation: 0 minutes 0 seconds
Terminal: telnet 1
Transport: telnet
User's IP address: 10.65.75.54
Authentication: local
Radius hostname: N/A
```

state active

To activate a domain, use the **state active** command in AAA configuration mode.

state active

Command Modes AAA configuration (config-aaa)

Examples

This example shows to activate a configured domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain default1
Device(config-aaa-domain-default1)# radius host binding cisco
Device(config-aaa-domain-default1)# state active
Device(config-aaa-domain-default1)# exit
```

Related Commands

Command	Description
state block	Deactivates a domain

state block

To deactivate a domain, use the **state block** command in AAA configuration mode.

state block

Command Modes

AAA configuration mode

Examples

This example shows how to deactivate a domain.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain default1
Device(config-aaa-domain-default1)# state block
```

Related Commands

Command	Description
state active	Activates a domain

stop

To force user or users to go offline, use the **stop** command in privileged EXEC mode.

```
stop {username | vty {all vty_list} | telnet {all terminal_id}}
```

Syntax Description

<i>username</i>	The username
all	Stops all.
<i>vty_list</i>	The VTY list.
<i>terminal_id</i>	The terminal ID The range is from 0 to 5.

Command Modes

Privileged EXEC (#)

Examples

This example shows how to force a user offline

```
Device> enable  
Device# stop Jerry
```

tacacs+

To configure the TACACS + server, use the **tacacs+** command in global configuration mode.

tacacs+ {**primary** | **secondary**} **server** *ip_address* [**encrypt-key** *value* | **key** *key* | **port** *port* | **timeout** *value*]

Syntax Description		
primary		Configures the primary server.
secondary		Configures the secondary server.
server <i>ip_address</i>		The server IP address.
encrypt-key <i>value</i>		The server key encryption.
key <i>key</i>		The server key configuration.
port <i>port</i>		The TCP port. The range is from 1 to 65535.
timeout <i>value</i>		The connection timeout. The range is from 1 to 70. The o

Command Modes Global configuration (config)

Examples

This example shows how to configure the TACACS + primary server

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ primary server 192.168.1.10 key 123456
```

Related Commands

Command	Description
show tacacs+	Displays the TACACS+ configuration

tacacs+ authentication-type

To configure an authentication type, use the **tacacs+ authentication-type** command in global configuration mode.

tacacs+ authentication-type {ascii | chap | pap}

Syntax Description	ascii	Configures the ASCII authentication type.
	chap	Configures the Challenge Handshake Authentication Protocol (CHAP).
	pap	Configures the Password Authentication Protocol (PAP) authentication type.

Command Modes Global configuration (config)

Examples

This example shows how to configure an ASCII authentication type

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ authentication-type ascii
```

Related Commands	Command	Description
	show tacacs+	Displays the TACACS+ configuration

tacacs+ encrypt-key

To enable password encryption, use the **tacacs+ encrypt-key** command in global configuration mode. To disable password encryption, use the **no tacacs+ encrypt-key** command.

tacacs+ encrypt-key

no tacacs+ encrypt-key

Command Modes

Global configuration (config)

Examples

This example shows how to enable password encryption

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ encrypt-key
```

Related Commands

Command	Description
show tacacs+	Displays the TACACS+ configuration

tacacs+ preemption-time

To configure the recovery time to switch to the TACACS+ primary server, use the **tacacs+ preemption-time** command in global configuration mode.

tacacs+ preemption-time *time*

Syntax Description	<i>time</i>	The preemption time The unit in minutes. The range is from 0 to 1440. The default value is 0
--------------------	-------------	--

Command Modes Global configuration (config)

Examples

This example shows how to configure the recovery time to switch to the TACACS+ primary server.

```
Device> enable
Device# configure terminal
Device(config)# tacacs+ preemption-time 200
```

Related Commands	Command	Description
	show tacacs+	Displays the TACACS+ configuration

timeout

To configure the system idle timeout, use the **timeout** command in privileged Exec mode. To disable the system idle timeout, use the **no timeout** command.

timeout *value*

no timeout

Syntax Description	<i>value</i>	The system idle timeout value. The range is 1-480. The default timeout value is 20m.
--------------------	--------------	---

Command Modes Privileged Exec (#)

Examples

This example shows how to configure the system idle timeout

```
Device> enable
Device# timeout 100
The idle time is : 100 minutes!
```

username

To add a user or modify an existing user privilege level, use the **username** *username* command in global configuration mode. To remove a user, use the **no username** *username* command.

username *username* {**password** {**0** | **7**}*password* | **privilege** *privilege_level* **password** {**0** | **7**}*password* | **terminal** {**all** | **console** | **none** | **ssh** | **telnet** | **web**}}

no username *username*

Syntax Description

<i>username</i>	The username.
password 0 7	The password encryption time. <ul style="list-style-type: none"> • A value of 0 means the password is encrypted in plain text. • A value of 7 means the password is encrypted using SHA-256.
<i>password</i>	The password.
<i>privilege_level</i>	The privilege level. <ul style="list-style-type: none"> • A privilege value of 0 or 1. • A privilege value between 2 and 7. • Super user (admin) requires a privilege value of 15.
terminal	The login mode. <p>The options are</p> <ul style="list-style-type: none"> • console • none • SSH • Telnet • Web

Command Modes

Global configuration (config)

Usage Guidelines

If you do not enter a permission value when you create a user, the system will automatically assign it with normal permissions.

Configure the password encryption type as 0 for a new user. When you configure the **service password-encryption** command, a password configured in plain text (0) is decrypted in de-compilation and the decrypted password type changes to 7

Examples

This example shows how to add a new user.

```

Device> enable
Device# configure terminal
Device(config)# username mark privilege 0 password 0 mark@123
Add user successfully.

```

Related Commands

Command	Description
show username	Displays the user information
username change-password	Modifies the user password
username change-privilege-pwd	Configures the second-tier password authentication
username failmax	Configures a limit on the consecutive failed login attempts
username online-max	Configures the duration users are online at the same time
username silent-time	Configures the silent time

username change-password

To modify the user password, use the **username change-password** command in global configuration mode.

username change-password

Command Modes

Global configuration (config)

Examples

This example shows how to modify the user password

```
Device> enable
Device# configure terminal
Device(config)# username change-password
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username change-privilege-pwd

To configure the second-tier password authentication, use the **username change-privilege-pwd** command in global configuration mode.

username change-privilege-pwd {0 | 7}

Syntax Description

{ 0 | 7 }

- A value of 0 means the password is not encrypted.
- A value of 7 means the password is encrypted.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the second-tier password authentication.

```
Device> enable
Device# configure terminal
Device(config)# username change-privilege-pwd 0 123456
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username failmax

To configure a limit on the consecutive failed login attempts, use the **username failmax** command in global configuration mode. To disable the limit on the consecutive failed login attempts, use the **no username failmax** command.

username failmax *{fail_value | username fail_value}*

no username failmax

Syntax Description

<i>fail_value</i>	The fail value. The range is from 1 to 100.
<i>username</i>	The username.

Command Modes

Global configuration (config)

Examples

This example shows how to configure a limit on the consecutive failed login attempts.

```
Device> enable
Device# configure terminal
Device(config)# username failmax 5
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username online-max

To configure the duration users are online at the same time, use the **username online-max** command in global configuration mode.

username online-max *username value*

Syntax Description		
	<i>username</i>	The username.
	<i>value</i>	The duration users are online at the same time The range is from 1 to 100.

Command Modes Global configuration (config)

Examples

This example shows how to configure the duration users are online at the same time.

```
Device> enable
Device# configure terminal
Device(config)# username online-max mark 100
```

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username privilege-auth-remote-user

To enable privilege password authentication for a remote user, use the **username privilege-auth-remote-user** command in global configuration mode. To disable user privilege password authentication, use the **no username privilege-auth** command.

username privilege-auth-remote-user *username*

no username privilege-auth-remote-user

Syntax Description

<i>username</i>	The username.
-----------------	---------------

Command Modes

Global configuration (config)

Examples

This example shows how to enable privilege password authentication.

```
Device> enable
Device# configure terminal
Device(config)# username privilege-auth-remote-user mark
Enable Privilege-password authentication OK!
```

Related Commands

Command	Description
show username	Displays the user information

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information

username privilege-auth

To enable privilege password authentication for a user, use the **username privilege-auth** command in global configuration mode. To disable user privilege password authentication, use the **no username privilege-auth** command.

username privilege-auth [*always*]

no username privilege-auth

Syntax Description	always	Configures privilege password authentication for all users.
--------------------	--------	---

Command Modes	Global configuration (config)
---------------	-------------------------------

Examples

This example shows how to enable user privilege password authentication.

```
Device> enable
Device# configure terminal
Device(config)# username privilege-auth
Enable Privilege-password authentication OK!
```

Related Commands

Command	Description
show username	Displays the user information.

Related Commands

Command	Description
username <i>username</i>	Adds a user.
show username	Displays the user information.
show username privilege-auth	Displays the privilege password authentication configuration.

username silent-time

To configure the silent time, use the **username silent-time** command in global configuration mode.

username silent-time *silent_time*

Syntax Description

silent_time

The silence period time.

The range is from 2 to 1440.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the silent time

```
Device> enable
Device# configure terminal
Device(config)# username silent-time 100
```

Related Commands

Command	Description
show username	Displays the user information

Related Commands

Command	Description
username <i>username</i>	Adds a user
show username	Displays the user information
show username silent	Displays a user silent period information



PART **III**

OLT Port Configuration

- [OLT Port Configuration, on page 143](#)



OLT Port Configuration

- [channel-group group_id](#), on page 144
- [channel-group load-balance](#), on page 145
- [channel-group group_id mode](#), on page 146
- [clear channel-group](#), on page 147
- [clear interface](#) , on page 148
- [interface range ethernet](#), on page 149
- [lacp port-priority](#), on page 150
- [lacp system-priority](#), on page 151
- [port-control mode primary](#), on page 152
- [port-control mode secondary](#), on page 153
- [port-isolation](#), on page 154
- [port-rate-statistics interval](#), on page 155
- [psg group-id force-switch](#), on page 156
- [psg group-id type-b](#), on page 157
- [show description](#), on page 158
- [show interface sfp](#), on page 159
- [show lacp internal](#) , on page 160
- [show lacp neighbor](#), on page 161
- [show lacp sys-id](#), on page 162
- [show port-control mode](#), on page 163
- [show port-isolation](#), on page 164
- [show psg](#), on page 165
- [show statistics interface ethernet](#) , on page 166
- [show statistics](#) , on page 167
- [show statistics channel-group](#), on page 168
- [show statistics dynamic interface](#), on page 169
- [show utilization interface](#), on page 170
- [speed](#), on page 171

channel-group group_id

To configure the aggregation group ID, use the **channel-group** *channel_group_id* command in global configuration mode. To disable the aggregation group ID, use the **no channel-group** *channel_group_id* command.

channel-group *channel_group_id*

no channel-group *channel_group_id*

Syntax Description

channel_group_id

The channel group ID.

The range is 0-5.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the aggregation group ID

```
Device> enable
Device# configure terminal
Device(config)# channel-group 4
```

channel-group load-balance

To configure a load balance policy, use the **channel-group load-balance** command in global configuration mode. To disable a load balance policy, use the **no channel-group load-balance** form of this command.

channel-group load-balance {**dst-ip** | **dst-mac** | **src-dst-ip** | **src-dst-mac** | **src-ip** | **src-mac**}

no channel-group load-balance

Syntax Description		
	dst-ip	Configures the load balance policy based on destination IP address.
	dst-mac	Configures the load balance policy based on destination MAC address.
	src-dst-ip	Configures the load balance policy based on source and destination IP address.
	src-dst-mac	Configures the load balance policy based on source and destination MAC address.
	src-ip	Configures the load balance policy based on source IP address.
	src-mac	Configures the load balance policy based on source MAC address.

Command Modes

Global configuration (config)

Examples

This example shows how to configure a load balance policy based on source MAC.

```
Device> enable
Device# configure terminal
Device(config)# channel-group load-balance src-mac
```

channel-group group_id mode

To add a port to an aggregation group, use the **channel-group *channel_group_id* mode** command in interface configuration mode. To disable the aggregation group ID, use the **no channel-group *channel_group_id* mode** command.

channel-group *channel_group_id* mode {**on** | **active** | **passive**}

no channel-group *channel_group_id* mode

Syntax Description		
	<i>channel_group_id</i>	The channel group ID. The range is 0-5.
	on	Configures the LACP static mode.
	active	Configures the LACP active mode
	passive	Configures the LACP passive mode

Command Modes Interface configuration (config-if)

Examples

This example shows how to add a port to an aggregation group.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# channel-group 2 mode active
```

clear channel-group

To clear the LACP statistical information, use the **clear channel-group** *channel_group_id* command in global configuration mode.

```
clear channel-group [channel_group_id]
```

Syntax Description

channel_group_id

The channel group ID.

The range is 0-5.

Command Modes

Global configuration (config)

Examples

This example shows how to clear the LACP statistical information.

```
Device> enable  
Device# configure terminal  
Device(config)# clear channel-group  
Clear channel group statistics information record successfully.
```

clear interface

To clear interface statistics information, use the **clear interface** command in global configuration mode.

clear interface {*slot-number* | **ethernet** *slot-number/port-number* | **gpon** *slot-number/port-number* }

Syntax Description

slot-number

The slot number.

The range is from 0 to 3.

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.

- GE Ethernet: The value is 1.

- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 3.

- GE Ethernet: The range is from 1 to 3.

- 10GE Ethernet: The range is from 1 to 3.

Command Modes

Global configuration (config)

Examples

This example shows how to clear interface statistics information

```
Device> enable
Device# configure terminal
Device(config)# clear interface ethernet 0/1
clear ports statistics information record successfully.
```

interface range ethernet

To configure port mode in bulk, use the **interface range ethernet** command in interface configuration mode.

interface range ethernet *slot-number/port-number to ethernet slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.

- GE Ethernet: The value is 1.

- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 24.

- GE Ethernet: The range is from 1 to 24.

- 10GE Ethernet: The range is from 1 to 24.

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure port mode in bulk

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# interface range ethernet 1/1 to ethernet 1/4
Device(config-if-range)#
```

lACP port-priority

To configure port priority, use the **lACP port-priority** command in interface configuration mode. To disable port priority, use the **no lACP port-priority** command.

lACP port-priority *priority_value*

no lACP port-priority

Syntax Description

priority_value

The priority value.

The range is from 1 to 65535.

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure port priority.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# lACP port-priority 8
```


lACP system-priority

To configure system priority, use the **lACP system-priority** command in global configuration mode. To disable port priority, use the **no lACP system-priority** command.

lACP system-priority *priority_value*

no lACP system-priority

Syntax Description

priority_value

The priority value.

The range is from 1 to 65535.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the system priority.

```
Device> enable
Device# configure terminal
Device(config)# lACP system-priority 3
```

port-control mode primary

To configure the primary mode, use the **port-control mode primary** command in interface configuration mode. To disable the primary mode, use the **no port-control mode** command.

port-control mode primary
no port-control mode

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure the primary mode.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# port-control mode primary
```

port-control mode secondary

To configure the secondary mode, use the **port-control mode secondary** command in interface configuration mode. To disable the secondary mode, use the **no port-control mode** command.

port-control mode secondary
no port-control mode

Command Modes

Interface configuration (config-if)

Examples

This example shows how to configure the secondary mode.

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# port-control mode secondary
```

port-isolation

To configure port isolation, use the **port-isolation** command in global configuration mode. To disable port isolation, use the **no port-isolation** command.

port-isolation ethernet *slot-number/port-number*

no port-isolation ethernet *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 255.
- GE Ethernet: The range is from 1 to 255.
- 10GE Ethernet: The range is from 1 to 255.

Command Modes

Global configuration (config)

Examples

This example shows how to configure port isolation.

```
Device> enable
Device# configure terminal
Device(config)# port-isolation ethernet 1/1
Add port isolation downlink port successfully.
```

Related Commands

Command	Description
show port-isolation	Displays the isolation port

port-rate-statistics interval

To configure port interface statistic interval, use the **port-rate-statistics interval** *value* command in global configuration mode. To restore the default value, use the **no** form of this command.

port-rate-statistics interval *value*

no port-rate-statistics interval

Syntax Description

value

The time interval range.

The range is from 1 to 5. The unit is minutes. The d

Command Modes

Global configuration (config)

Examples

This example shows how to configure port interface statistic interval.

```
Device> enable
Device# configure terminal
Device(config)# port-rate-statistics interval 3
Port rate statistics interval has been changed, and will
restart calculating port average rate!
```

psg group-id force-switch

To force a port changeover, use the **psg group-id force-switch** command in global configuration mode

psg group-id force-switch

Syntax Description	<i>group-id</i> The protection switch group ID. The range is 0 to 7.
---------------------------	---

Command Modes	Global configuration (config)
----------------------	-------------------------------

Examples	This example shows how to force a switch changeover.
-----------------	--

```
Device> enable
Device# configure terminal
Device(config)# psg 1 type-b primary interface gpon 0/3 secondary interface gpon 0/1
Config success.
Device(config)# psg 1 force-switch
Switch success.
```

psg group-id type-b

To configure a protection switch group, use the **psg group-id type-b primary interface gpon slot-number/port-number secondary interface gpon slot-number/port-number** command in global configuration mode. To remove the protection switch group, use the **no psg group-id** command.

```
psg group-id type-b primary interface gpon slot-number/port-number secondary interface gpon
slot-number/port-number
no psg group-id
```

Syntax Description

<i>group-id</i>	The protection switch group ID. The range is from 0 to 7.
<i>slot-number/port-number</i>	<ul style="list-style-type: none"> • <i>slot-number</i>: The GPON slot number. The value is 0. • <i>port-number</i>: The GPON port number. The range is from 1 to 8.

Command Modes

Global configuration (config)

Examples

This example shows how to configure a protection switch group.

```
Device> enable
Device# configure terminal
Device(config)# psg 1 type-b primary interface gpon 0/3 secondary interface gpon 0/1
Config success.
```

show description

To display the interface description, use the **show description** command in privileged EXEC or global configuration mode.

show description interface ethernet *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 24.
- GE Ethernet: The range is from 1 to 24.
- 10GE Ethernet: The range is from 1 to 24.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the interface description.

```
Device> enable
Device# configure terminal
Device(config)# show description interface ethernet 1/1
Port      description
e1/1      text
Total entries: 1.
```


show interface sfp

To display information about SFP parameters, use the **show interface sfp** command in privileged EXEC or global configuration mode.

show interface sfp {**ethernet** | **gpon**} *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 24.
- GE Ethernet: The range is from 1 to 24.
- 10GE Ethernet: The range is from 1 to 24.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the information about SFP parameters

```
Device> enable
Device# configure terminal
Device(config)# show interface sfp ethernet 1/1
```

show lacp internal

To display information of the aggregation group, use the **show lacp internal** command in privileged EXEC or global configuration mode.

show lacp internal [*channel_group_id*]

Syntax Description	<i>channel_group_id</i>	The channel group ID. The range is from 0 to 5.
--------------------	-------------------------	--

Command Modes	Privileged EXEC (#) Global configuration (config)
---------------	--

Examples

This example shows how to view information about the aggregation group.

```
Device> enable
Device# configure terminal
Device(config)# show lacp internal
Load balance: dst-ip

Channel: 2, static channel
Port   State   A-Key  O-Key  Priority  Logic-port  Actor-state
e1/1   down    -      -      -         9           -

Channel: 4, dynamic channel
Port   State   A-Key  O-Key  Priority  Logic-port  Actor-state

actor-state: activity/timeout/aggregation/synchronization
              collecting/distributing/defaulted/expired
```

show lacp neighbor

To display the neighbor information of the aggregation group, use the **show lacp neighbor** command in privileged EXEC or global configuration mode.

```
show lacp neighbor [channel_group_id]
```

Syntax Description		
	<i>channel_group_id</i>	The channel group ID. The range is from 0 to 5.

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to view the neighbor information of the aggregation group

```
Device> enable
Device# configure terminal
Device(config)# show lacp neighbor

Channel: 4
Local Port  Key  Pri  ID          Timeout  Nei-state
nei-state: activity/timeout/aggregation/synchronization
           collecting/distributing/defaulted/expired
```

show lacp sys-id

To display the system priority configuration, use the **show lacp sys-id** command in privileged EXEC or global configuration mode.

show lacp sys-id

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the system priority configuration.

```
Device> enable
Device# configure terminal
Device(config)# show lacp sys-id

3,000a5a9b1815
```

show port-control mode

To display the configured port-control mode, use the **show port-control mode** command in privileged EXEC or global configuration mode.

show port-control mode

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the configured port-control mode.

```
Device> enable
Device# configure terminal
Device(config)# show port-control mode
port  negotiate-flag  port-control-mode
e1/1  enable          auto
e1/2  enable          auto
e1/3  enable          auto
e1/4  enable          auto
```

show port-isolation

To display the isolation port, use the **show port-isolation** command in privileged EXEC or global configuration mode.

show port-isolation

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view isolation port configuration.

```
Device> enable
Device# configure terminal
Device(config)# show port-isolation
Port isolation downlink port :
e1/2-e1/4.
```

Related Commands

Command	Description
port-isolation	Configures port isolation

show psg

To display the protection switch group configurations, use the **show psg** *group-id* command in privileged EXEC or global configuration mode.

```
show psg { group-id | all }
```

Syntax Description	
<i>group-id</i>	The protection switch group ID. The range is from 0 to 7.
all	All protection switch groups

Command Modes	
	Privileged EXEC (#)
	Global configuration (config)

Examples

This example shows how to configure a protection switch group.

```
Device> enable
Device# configure terminal
Device(config)# show psg 0
GroupID  Member  Role      State
0         0/1      PRIMARY  WORKING
          0/2      SECONDARY STANDBY
Total: 1.
```

show statistics interface ethernet

To display the port rate statistics information, use the **show statistics interface** command in privileged EXEC or global configuration mode.

show statistics interface ethernet *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 2.
 - GE Ethernet: The range is from 1 to 2.
 - 10GE Ethernet: The range is from 1 to 2.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the port rate statistics information.

```
evic> enable
Device# configure terminal
Device(config)# show statistics interface ethernet 1/3
Port number : e1/3
last 5 minutes input rate 24784 bits/sec, 37 packets/sec
last 5 minutes output rate 1120 bits/sec, 1 packets/sec
64 byte packets:455394067
65-127 byte packets:302514090
128-255 byte packets:17535520
256-511 byte packets:20599116
512-1023 byte packets:4737262
1024-1518 byte packets:475868
788888610 packets input, 69778227468 bytes , 312945536 discarded packets
18800297 unicasts, 270957185 multicasts, 499131128 broadcasts
0 input errors, 0 FCS error, 0 symbol error, 0 false carrier
0 runts, 0 giants
12367313 packets output, 1245119790 bytes, 256 discarded packets
8303627 unicasts, 3620977 multicasts, 442709 broadcasts
0 output errors, 0 deferred, 0 collisions
0 late collisions
Total entries: 1.
```


show statistics

To display port rate statistics information, use the **show statistics interface ethernet** command in privileged EXEC or global configuration mode.

show statistics interface ethernet *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value is 1.
 - 10GE Ethernet: The value is 2.
- *port-number*:
 - GPON: The range is from 1 to 24.
 - GE Ethernet: The range is from 1 to 24.
 - 10GE Ethernet: The range is from 1 to 24.

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example show how to view the port rate statistics information.

```
Device> enable
Device# configure terminal
Device(config)# show statistics interface ethernet 1/1
Port number : e1/1
last 5 minutes input rate 0 bits/sec, 0 packets/sec
last 5 minutes output rate 0 bits/sec, 0 packets/sec
64 byte packets:0
65-127 byte packets:0
128-255 byte packets:0
256-511 byte packets:0
512-1023 byte packets:0
1024-1518 byte packets:0
0 packets input, 0 bytes , 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 input errors, 0 FCS error, 0 symbol error, 0 false carrier
0 runts, 0 giants
0 packets output, 0 bytes, 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 output errors, 0 deferred, 0 collisions
0 late collisions
Total entries: 1.
```

show statistics channel-group

To display LACP statistical information, use the **show statistics channel-group** command in privileged EXEC or global configuration mode.

show statistics channel-group [*channel_group_id*]

Syntax Description	<i>channel_group_id</i>	The channel group ID. The range is from 0 to 5.
--------------------	-------------------------	--

Command Modes	Privileged EXEC (#) Global configuration (config)
---------------	--

Examples

This example shows how to view the LACP statistical information

```
Device> enable
Device# configure terminal
Device(config)# show statistics channel-group
Channel group : 2
last 5 minutes input rate 0 bits/sec, 0 packets/sec
last 5 minutes output rate 0 bits/sec, 0 packets/sec
64 byte packets:0
65-127 byte packets:0
128-255 byte packets:0
256-511 byte packets:0
512-1023 byte packets:0
1024-1518 byte packets:0
0 packets input, 0 bytes , 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 input errors, 0 FCS error, 0 symbol error, 0 false carrier
0 runts, 0 giants
0 packets output, 0 bytes, 0 discarded packets
0 unicasts, 0 multicasts, 0 broadcasts
0 output errors, 0 deferred, 0 collisions
0 late collisions

Channel group : 4

This channel group does not include any ports!

Total entries: 2.
```

show statistics dynamic interface

To display the real-time statistic information of an interface, use the **show statistics dynamic interface** command in privileged EXEC or global configuration mode.

show statistics dynamic interface

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the real-time statistic information of an interface.

```
Device> enable
Device# configure terminal
Device(config)# show statistics dynamic interface
Port Statistics                               Sun Dec 9 17:40:29 2001
port  link  Tx Pkt  Tx Byte  Rx Pkt  Rx Byte  Rx      Rx
      Status Count  Count    Count   Count   Count   Bcast  Mcast
=====
g0/1   up    1427776E3 122120178E3 3230173 579417376 279481 171727
g0/2   down  0         0         0         0         0       0
g0/3   down  0         0         0         0         0       0
g0/4   down  0         0         0         0         0       0
g0/5   down  0         0         0         0         0       0
g0/6   down  0         0         0         0         0       0
g0/7   down  0         0         0         0         0       0
g0/8   down  0         0         0         0         0       0
e1/1   down  0         0         0         0         0       0
e1/2   down  0         0         0         0         0       0
e1/3   up    12366419 1245034896 788871832 69776674248 499122592 270949818
e1/4   down  2         210       4         256       0       4
e2/1   down  0         0         0         0         0       0
e2/2   down  0         0         0         0         0       0
=====0->Clear Counters U->page up D->page down CR->exit=====
```

Notes: If you see a E number, you can use the command "line width" to get more information.

show utilization interface

To display the interface utilization, use the **show utilization interface** command in privileged EXEC or global configuration mode.

show utilization interface

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view the interface utilization.

```
Device> enable
Device# configure terminal
Device(config)# show utilization interface
Link Utilization Averages          Tue Dec 4 19:06:53 2001
port  link    Receive   Peak Rx   Transmit  Peak Tx
      Status  pkts/sec  pkts/sec pkts/sec  pkts/sec
=====
g0/1  up        0          0         16        16
g0/2  down      0          0          0          0
g0/3  down      0          0          0          0
g0/4  down      0          0          0          0
g0/5  down      0          0          0          0
g0/6  down      0          0          0          0
g0/7  down      0          0          0          0
g0/8  down      0          0          0          0
e1/1  down      0          0          0          0
e1/2  down      0          0          0          0
e1/3  up        37         37         2          2
e1/4  down      0          0          0          0
e2/1  down      0          0          0          0
e2/2  down      0          0          0          0
=====spacebar->toggle screen U->page up D->page down CR->exit=====
```

speed

To configure the interface speed, use the **speed** command in interface configuration mode. To disable the interface speed, use the **no speed** command.

speed {1000 | 10000 | auto}

no speed

Syntax	Description
1000	Port speed is 1000Mbps
10000	Port speed is 10000Mbps
auto	Port speed is automatic

Command Modes Interface configuration (config-if)

Examples

This example shows how to configure the interface speed

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1
Device(config-if-ethernet-1/1)# speed 1000
```

■ speed



PART **IV**

VLAN Configuration

- [VLAN Configuration, on page 175](#)



VLAN Configuration

- [description](#), on page 176
- [ingress acceptable-frame](#), on page 177
- [ingress filtering](#), on page 178
- [interface ethernet](#), on page 179
- [priority](#), on page 180
- [show ingress interface](#), on page 181
- [show interface brief ethernet](#), on page 182
- [show interface ethernet](#), on page 183
- [switchport default vlan](#), on page 184
- [switchport ethernet](#), on page 185
- [switchport hybrid](#), on page 186
- [switchport mode](#), on page 187
- [switchport trunk](#), on page 188
- [vlan](#), on page 189

description

To add a VLAN name or a description for the VLAN use the **description** command in the VLAN configuration mode.

description *string*

Syntax Description	<i>string</i> Specifies a name or a description for the VLAN. The range is 1-32 characters.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	VLAN Configuration
----------------------	--------------------

Examples	<pre>Device(config)# vlan 11 Device(config-if-vlan)# switchport ethernet 1/3 Device(config-if-vlan)# description "vlan1"</pre>
-----------------	---

ingress acceptable-frame

To configure the type of frames or VLAN packets that are acceptable on the port, use the `ingress acceptable-frame` command in the Interface configuration mode.

ingress acceptable-frame { **all** | **tagged** }

Syntax Description	all Allows the port to receive tagged and untagged VLAN
	tagged Allows the port to receive only tagged VLAN packets.

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

This example shows how to configure the **ingress acceptable-frame** command:

```
Device(config)#interface ethernet 1/1
Device(config-if-ethernet-1/1)#ingress acceptable-frame tagged
Config acceptable-frame type successfully!
```

ingress filtering

To enable the forwarding of VLAN packets at the ingress of an interface, use the **ingress filtering** command in the Interface configuration mode. To disable ingress filtering use the **no** form of the command.

ingress filtering
no ingress filtering

Syntax Description

ingress filtering enables ingress filtering of VLAN packets.

Command Default

Ingress filtering is enabled by default

Command Modes

Interface configuration mode

Examples

This example shows how to disable ingress filtering for a port:

```
Device(config)# interface ethernet 1/4  
Device(config-if-ethernet-1/4)# no ingress filtering
```

interface ethernet

To enter interface configuration mode for an Ethernet IEEE 802.3 interface, use the interface ethernet command in the global configuration mode.

interface ethernet *port-number*

Syntax Description	<i>port-number</i> Specifies the port number within a particular slot.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Examples	The following example shows how to enter interface configuration mode.
-----------------	--

```
Device(config)# interface ethernet1/4
```

priority

To assign a priority value to a port use the **priority** command in the interface configuration mode. To restore the port priority to the default value use the **no** form of the command.

priority *port-priority*

no priority

Syntax Description	<i>port-priority</i> Assigns a priority value to the port. The value can range from 0-7.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Examples

The following example shows how to configure the priority value of a port.

```
Device(config)# interface ethernet1/4  
Device(config-if-ethernet-1/4)# priority 2
```

show ingress interface

To display the status of filtering on the ingress port use the **show ingress interface** command in the privileged EXEC mode or global configuration mode.

show ingress interface { **ethernet** *port-number* | **gpon** *port-number* }

Syntax Description	
ethernet	Displays information about ethernet port.
gpon	Displays information about gpon port

Command Modes
Privileged EXEC
Global configuration (config)

Examples

The following is sample output for the `show ingress interface` command.

```
Device(config)#show ingress interface ethernet 1/4
Port      Filtering  Acceptable-frame
e1/4      enable     all
Total entries: 1
```

show interface brief ethernet

To display the configurations of a port in brief use the **show interface brief ethernet** command in the privileged EXEC mode.

show interface brief ethernet *port-number*

Syntax Description	<i>port-number</i> Specifies the port for which the configurations will be displayed.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Examples

This example shows the sample output for the **show interface brief ethernet** command:

```
Device# show interface brief ethernet 1/4
Port   Desc   Link shutdn Speed      Pri PVID Mode TagVlan  UtVlan
e1/4   down  false  auto      2    1   acc    1
Total entries: 1 .
```


show interface ethernet

To display the configurations of a port in detail use the **show interface ethernet** command in the privileged EXEC mode.

show interface ethernet *port-number*

Syntax Description	<i>port-number</i> Specifies the port for which the configurations will be displayed.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Privileged EXEC
----------------------	-----------------

Examples

The following examples displays the output of the **show interface ethernet** command for the port ethernet 1 / 4 :

```
Device# show interface ethernet 1/4
Gigabit Ethernet e1/4 current state: enabled, port link is down
Hardware address is 00:0a:5a:9b:18:15
SetSpeed is auto, ActualSpeed is unknown, Duplex mode is unknown
Current port type: 1000BASE-T
Priority is 2
Flow control is disabled
Broadcast storm control target rate is 49984pps
PVID is 1
Port mode: access
Untagged VLAN ID: 1
Input  : 0 packets, 0 bytes
         0 broadcasts, 0 multicasts, 0 unicasts
Output : 0 packets, 0 bytes
         0 broadcasts, 0 multicasts, 0 unicasts
```

switchport default vlan

To configure a VLAN as the default VLAN use the **switchport default vlan** command in the interface configuration mode. To restore the default vlan to port 1 use the **no** form of the command.

switchport default vlan*vlan-id*

no switchport default vlan

Syntax Description	<i>vlan-id</i> Specifies the VLAN id that will be used as the default VLAN.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration mode
----------------------	------------------------------

Examples This example shows how to configure a default vlan:

```
Device(config)# interface ethernet 1/1  
Device(config-if-ethernet-1/1)# switchport mode access  
Device(config-if-ethernet-1/1)# switchport default vlan 100
```

switchport ethernet

To add an VLAN interface to a designated port or to all ports use the **switchport ethernet** command in the VLAN configuration mode.

switchport {**ethernet** *port-number* | **all**}

Syntax Description	all	Specifies that all the ports will be added to the VLAN interface.
	<i>port-number</i>	Specifies the port numbers that will be added to the VLAN interface.

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples

This example shows how to add a VLAN to an ethernet port:

```
Device(config-if-vlan)# switchport ethernet 1/4
```

switchport hybrid

To allow the packets from specified VLANs to pass through the hybrid port, use the **switchport hybrid** command in the interface configuration mode. To prevent the packets from specified VLANs passing through the hybrid port use the **no** form of the command.

switchport hybrid { **tagged** | **untagged** } **vlan** { *vlan-list* | **all** }

no switchport hybrid { **tagged** | **untagged** } **vlan** { *vlan-list* | **all** }

Syntax Description

tagged	Specifies the VLAN packets as tagged.
untagged	Specifies the VLAN packets as untagged.
vlan	Specifies the VLANs whose packets will be allowed to pass through the hybrid port.
<i>vlan-list</i>	Specifies a list of VLANs whose packets will be allowed to pass through the hybrid port.
all	Specifies that packets from all VLANs will be allowed to pass through the hybrid port.

Command Default

None

Command Modes

Interface configuration mode

Examples

This example shows how to allow the packets from the specified VLANs to pass through the hybrid port:

```
Device(config-if-ethernet-1/4)# switchport mode hybrid
Device(config-if-ethernet-1/4)# switchport hybrid tagged 2-4
```

switchport mode

To configure the VLAN mode for the interface use the **switchport mode** command in the interface configuration mode. You can set the VLAN mode to access, hybrid or trunk. The mode is set to hybrid by default.

switchport mode { **access** | **hybrid** | **trunk** }

Syntax Description	
access	Specifies that the interface is in access mode.
hybrid	Specifies that the interface is in hybrid mode.
trunk	Specifies that the interface is in trunk mode.

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

This example shows how to configure the VLAN mode to trunk on an interface:

```
Device(config)# interface ethernet1/4  
Device(config-if-ethernet-1/4)# switchport mode trunk
```

switchport trunk

To allow the packets from specified VLANs to pass through the trunk port, use the **switchport trunk** command in the interface configuration mode. To prevent the packets from specified VLANs passing through the hybrid port use the **no** form of the command.

switchport trunk allowed vlan { *vlan-list* | **all** }

no switchport trunk allowed vlan { *vlan-list* | **all** }

Syntax Description	
allowed	Configures the VLANs whose packets will be allowed to pass through the trunk port.
vlan	Specifies the VLANs whose packets will be allowed to pass through the trunk port.
<i>vlan-list</i>	Specifies VLAN IDs of the allowed VLANs when the interface is in trunking mode.
all	Specifies all VLANs to be added to the current list.

Command Default None

Command Modes Interface configuration

Examples This example shows how to allow the packets from the specified VLANs to pass through a trunk port:

```
Device(config-if-ethernet-1/4)# switchport mode trunk
Device(config-if-ethernet-1/4)# switchport trunk allowed vlan 2-4
```

vlan

To add a VLAN and to enter the VLAN configuration mode, use the **vlan** command in global configuration mode. To delete the VLAN, use the **no** form of this command.

vlan *vlan list*

no vlan *vlan list*

Syntax Description	<i>vlan list</i> List of VLAN to be added and configured. The range is 1 to 4094. You can enter a single VLAN ID, a series of VLAN IDs separated by commas, or a range of VLAN IDs separated by hyphens.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global Configuration
----------------------	----------------------

Examples

This example shows how to create a VLAN and enter the VLAN configuration mode:

```
Device(config)# vlan 1
```




PART **V**

OLT Network Configuration

- [OLT Network Configuration, on page 193](#)



OLT Network Configuration

- [arp](#) , on page 196
- [arp aging-time](#), on page 197
- [description *interface-name*](#), on page 198
- [dhcp-snooping](#) , on page 199
- [dhcp-snooping trust](#) , on page 200
- [dhcpv6-snooping](#) , on page 201
- [dhcpv6 snooping port-down-action fast-remove](#), on page 202
- [dhcpv6-snooping trust](#) , on page 203
- [dlf forward](#), on page 204
- [clear dhcpv6-snooping](#), on page 205
- [interface](#), on page 206
- [interface loopback-interface](#), on page 208
- [interface vlan-interface](#), on page 209
- [ip-source-guard](#), on page 210
- [ip-source-guard filter](#), on page 211
- [ip address](#), on page 212
- [ip address *mask-ip-address*](#), on page 213
- [ip address range](#), on page 214
- [ip icmp mask-reply](#), on page 215
- [ip icmp unreachable](#), on page 216
- [ipv6 address](#), on page 217
- [ipv6 address link-local](#), on page 218
- [ipv6 enable](#), on page 219
- [ipv6 icmpv6 multicast-echo-reply](#), on page 220
- [ipv6 nd dad attempts](#), on page 221
- [ipv6 nd ns retrans-time](#), on page 222
- [ipv6 nd reachable-time](#) , on page 223
- [ipv6 neighbors max-learning-num](#) , on page 224
- [ipv6 path](#), on page 225
- [ipv6 route](#), on page 226
- [no ipv6 neighbor](#), on page 227
- [mac-address-table](#), on page 228
- [mac-address-table learning](#), on page 229

- `mac-address-table age-time`, on page 230
- `mac-address-table blackhole`, on page 231
- `mac-address-table max-mac-count`, on page 232
- `mirror destination-interface`, on page 233
- `mirror source-interface`, on page 234
- `show arp`, on page 235
- `show dhcp-snooping clients`, on page 236
- `show dhcp-snooping interface`, on page 237
- `show dhcpv6-snooping clients`, on page 239
- `show dhcpv6-snooping interface`, on page 240
- `show dhcpv6-snooping vlan`, on page 241
- `show dlf-forward`, on page 242
- `show ip interface`, on page 243
- `show ip source guard`, on page 244
- `show ipv6 interface`, on page 245
- `show ipv6 nd dad attempts`, on page 246
- `show ipv6 nd ns retrans-time`, on page 247
- `show ipv6 nd reachable-time`, on page 248
- `show ipv6 neighbors`, on page 249
- `show ipv6 route`, on page 250
- `show mac-address-table age-time`, on page 251
- `show mac-address-table`, on page 252
- `show mirror`, on page 254
- `show snmp community`, on page 255
- `show snmp contact`, on page 256
- `show snmp engineid`, on page 257
- `show snmp group`, on page 258
- `show snmp host`, on page 259
- `show snmp location`, on page 260
- `show snmp mib`, on page 261
- `show snmp name`, on page 262
- `show snmp notify`, on page 263
- `show snmp user`, on page 264
- `show snmp view`, on page 265
- `shutdown`, on page 266
- `snmp-server`, on page 267
- `snmp-server community`, on page 268
- `snmp-server community encrypt`, on page 269
- `snmp-server contact`, on page 270
- `snmp-server encrypt`, on page 271
- `snmp-server engineid`, on page 272
- `snmp-server group`, on page 273
- `snmp-server host`, on page 274
- `snmp-server location`, on page 276
- `snmp-server max-packet-length`, on page 277
- `snmp-server name`, on page 278

- [snmp-server trap-source, on page 279](#)
- [snmp-server user, on page 280](#)
- [snmp-server view, on page 282](#)

arp

To add a static entry in the Address Resolution Protocol (ARP) table, use the **arp** command in the global configuration mode. To remove an entry from the ARP table, use the **no** form of the command.

```
[no] arp ip-address mac mac-address [vid vlan-id | port port-id]
```

Syntax Description

<i>ip-address</i>	IPv4 address for which a permanent entry is added to the ARP table. Enter the IPv4 address in a four-part dotted-decimal format that corresponds to the local data-link address (a 32-bit address)
mac <i>mac-address</i>	Hardware MAC address that the IPv4 address is linked to. Enter the MAC address in dotted-hexadecimal notation.
vid <i>vlan-id</i>	(Optional) Specifies the configured VLAN.
port <i>port-id</i>	(Optional) Specifies the configured port

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

You can manually configure and maintain a static ARP entry. It cannot be aged or overwritten by dynamic ARP entry. A static ARP entry can be a long or a short entry. A static ARP entry comprises IP address and the corresponding MAC address. A long static ARP entry comprises the VLAN and egress interface details along with the IP address and MAC address. Long Static ARP entries can be directly used for packet forwarding.

When you manually configure a Long Static ARP entry, the IP address in the entry must be in the same network segment as the IP address of the VLAN interface on which the egress interface resides.

A short static ARP entry comprises the IP Address and the MAC Address. A short static ARP entry cannot be directly used for packet forwarding. A short static ARP request packet is sent by the host. If the source IP address and the source MAC address in the received response packet are the same as the configured IP address and MAC address, the ARP entry will be completed. Then it can be used for packet forwarding.

Example

This example shows how to configure a short static ARP entry:

```
Device> enable
Device# configure terminal
Device(config)# arp 192.168.1.19 mac 00:02:9a:3b:94:d9
```

arp aging-time

To specify how long an entry can exist in an ARP table, use the **arp aging-time** command in the global configuration mode.

arp aging-time *aging-time*

Syntax Description	<i>aging-time</i> Specify the timeout period in seconds.
---------------------------	--

Command Default	The default timeout of an ARP table entry is 20 minutes.
------------------------	--

Command Modes	Global configuration (config)
----------------------	-------------------------------

Example

This example shows how to configure the aging time for ARP table entries:

```
Device> enable
Device# configure terminal
Device(config)# arp aging-time 300
```

description *interface-name*

To configure the interface description, use the **description** *interface name* in the VLAN configuration mode. You can delete the interface description by using the **no** form of the command.

description *interface-name*

no description *interface-name*

Syntax Description	<i>interface-name</i> Adds a description for the interface.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples

The following example shows how to configure the IP interface description

```
Device(config-if-vlanif)# description interface1
```


dhcp-snooping

To enable Dynamic Host Control Protocol (DHCP) snooping feature on a device, use the **dhcp-snooping** command in the global configuration mode.

dhcp-snooping [**port-down-action fast-remove**]

Syntax Description

port-down-action fast-remove Configures the link down operation on the port.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

When DHCP Snooping is enabled on your device, it monitors and validates the DHCP packets that it receives. Untrusted ports drop the DHCP-ACK and DHCP-OFFER packets that are received from DHCP servers. Trusted ports forward the received DHCP packets to DHCP clients.

To configure DHCP Snooping feature, use the **dhcp-snooping** command.

When a link in the network goes down, use the **dhcp-snooping port-down-action fast remove** command to remove the corresponding entry from the DHCP binding database.

Example

This example shows how to configure DHCP Snooping on a device:

```
Device> enable
Device# configure terminal
Device(config)# dhcp-snooping
```

dhcp-snooping trust

To configure an interface as trusted for Dynamic Host Control Protocol (DHCP) snooping operations, use the **dhcp-snooping trust** command in the interface configuration mode.

dhcp-snooping trust

Command Default

None

Command Modes

Global configuration (config)

Example

This example shows how to configure a trusted interface for DHCP Snooping:

```
Device> enable
Device# configure terminal
Device(config)# interface g0/1
Device(config-if)# dhcp-snooping trust
```

dhcpv6-snooping

To enable Dynamic Host Control Protocol version 6 (DHCPv6) snooping feature on a device, use the **dhcpv6-snooping** command in the global configuration mode.

dhcpv6-snooping [**port-down-action fast-remove**]

Syntax Description

port-down-action fast-remove Configures the link down operation on the port.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

When DHCPv6 Snooping is enabled on your device, it monitors and validates the DHCP packets that it receives. Untrusted ports drop the DHCP-ACK and DHCP-OFFER packets that are received from DHCP servers. Trusted ports forward the received DHCP packets to DHCP clients.

To configure DHCPv6 Snooping feature, use the **dhcpv6-snooping** command.

When a link in the network goes down, use the **dhcpv6-snooping port-down-action fast remove** command to remove the corresponding entry from the DHCP binding database.

Example

This example shows how to configure DHCPv6 Snooping on a device:

```
Device> enable
Device# configure terminal
Device(config)# dhcpv6-snooping
```

dhcpv6 snooping port-down-action fast-remove

To configure the link-down operation on the port, use the **dhcp-snooping port-down-action fast-remove** command in the interface configuration mode.

dhcp-snooping port-down-action fast remove

Command Default None

Command Modes Global configuration (config)

Example

This example shows how to configure the link-down operation on the port:

```
Device> enable
Device# configure terminal
Device(config)# dhcp-snooping port-down-action fast-remove
```

dhcpv6-snooping trust

To configure an interface as trusted for DHCPv6 snooping operations, use the **dhcpv6-snooping trust** command in the interface configuration mode.

dhcpv6-snooping trust

Command Default None

Command Modes Global configuration (config)

Example

This example shows how to configure a trusted interface for DHCPv6 Snooping:

```
Device> enable
Device# configure terminal
Device(config)# interface g0/1
Device(config-if)# dhcpv6-snooping trust
```

dlf forward

To enable the forwarding of Destination Lookup Failure (DLF) unicast or multicast packets, use the **dlf forward** command. To enable DLF forwarding on egress packets of all ports, use the command in the global configuration mode. To enable DLF forwarding on the egress packets of a specific port, use the command in the interface configuration mode. DLF Forwarding is disabled by default. To disable it use the **no** form of the command.

dlf-forward { unicast | multicast }

no dlf-forward { unicast | multicast }

Syntax Description	
	<i>unicast</i> Enables the forwarding function of DLF unicast packets
	<i>multicast</i> Enables the forwarding function of DLF multicast packets

Command Default DLF forwarding is disabled by default.

Command Modes Global configuration mode.
Interface configuration mode.

Examples

The following example shows how to configure DLF forwarding for unicast packets for all egress ports:

```
Device(config)# dlf-forward unicast
```

The following example shows how to configure DLF forwarding for unicast packets on a specific port:

```
Device(config)# interface ethernet 1/4
Device(config-if)# dlf-forward unicast
```

The following example shows how to configure DLF forwarding for multicast packets for all egress ports:

```
Device(config)# dlf-forward multicast
```

The following example shows how to configure DLF forwarding for multicast packets on a specific port:

```
Device(config)# interface ethernet 1/4
Device(config-if)# dlf-forward multicast
```

clear dhcpv6-snooping

To delete the dynamic entries that is recorded by DHCPv6 Snooping, use the **clear dhcpv6-snooping** command in global configuration mode.

```
clear dhcpv6-snooping { ip address | mac mac_address | vlan vlan_id | interface ethernet  
slot-num/pon-num/ont-num }
```

Syntax Description		
	<i>address</i>	Specifies the IPv6 address entry
	<i>mac_address</i>	Specified the MAC address entry
	<i>vlan_id</i>	Specifies the VLAN ID entry
	<i>slot-num/pon-num/ont-num</i>	Specifies the ethernet port entry

Command Default None

Command Modes Global Configuration (config)

Example

The following example shows a sample format of the output of this command:

```
Device(config)# clear dhcpv6-snooping
```

interface

To configure an interface and enter into Interface configuration mode, use the **interface** command in the global configuration mode.

interface { *port-id* | **ethernet** *slot-num/port-num* | **gpon** *slot-num/port-num* | **loopback-interface** *loopback-int-number* | **meth-interface** *meth-int-number* | **range** { **ethernet** *port-num/slot-num* | **gpon** *port-num/slot-num* } | **vlan-interface** *vlan-id* }

Syntax Description		
	<i>port-id</i>	Specifies the port to be configured. It is a string consisting of 4 to 14 characters.
	ethernet <i>slot-num/port-num</i>	Enables you to configure Ethernet ports. For a Gigabit Ethernet port, <i>slot-num</i> is 1 and <i>port-num</i> ranges from 1 through 4. For a Ten Gigabit Ethernet port, <i>slot-num</i> is 2 and <i>port-num</i> ranges from 1 through 2.
	gpon <i>slot-num/port-num</i>	Enables you to configure GPON ports. <i>slot-num</i> is 0 and <i>port-num</i> ranges from 1 through 8.
	loopback-interface <i>loopback-int-number</i>	Enables you to configure a loopback interface. <i>loopback-int-number</i> number can be 0 or 1.
	meth-interface <i>meth-int-number</i>	Enables you to configure the Management Interface, MEth, that allows you to log in and perform configurations.
	range { ethernet <i>port-num/slot-num</i> gpon <i>port-num/slot-num</i> }	Enables you to configure a range of ethernet interfaces or a range of GPON interfaces.
	vlan-interface <i>vlan-id</i>	Enables you to configure a VLAN interface. <i>vlan-id</i> specifies the VLAN id. Values range from 1 through 4094.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **interface** command to enter the Interface Configuration mode and configure the interface.

To configure a range of interfaces at once, use the **interface range** command. In the interface range configuration mode, all entered commands are applicable to all interfaces within that range.

Example

The following example configures an Ethernet interface:

```
Device#configure terminal
Device(config)#interface ethernet 1/1
Device(config-if-ethernet-1/1)#
```


The following example configures a range of GPON interfaces:

```
Device#configure terminal  
Device(config)#interface range gpon 0/1 to gpon 0/3
```

interface loopback-interface

To create a loopback interface and to enter the loopback interface configuration mode, use the **interface loopback-interface** command in the Global configuration mode.

To disable a loopback interface use the **no** form of the command.

interface loopback-interface *interface-number*

no interface loopback-interface

Syntax Description	
loopback-interface	Configures a loopback interface.
<i>interface-number</i>	Configures the loopback interface number.

Command Default None

Command Modes Global configuration mode

Examples

The following example shows how to configure a loopback interface:

```
Device(config)# interface loopback-interface 1
```

interface vlan-interface

To create a VLAN interface and enter interface configuration mode, use the **interface vlan-interface** command in the global configuration mode. To remove a VLAN interface, use the **no** form of the command.

interfacevlan-interface *vlan-id*

no interfacevlan-interface

Syntax Description	<i>vlan-id</i> Sets the VLAN for the interface. The range is from 1-4094.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure an interface VLAN:

```
Device(config)# interface vlan-interface 1
```

ip-source-guard

To enable IP Source Guard feature on a device, use the **ip-source-guard** command in the global configuration mode.

```
ip-source-guard { vlan vlan-list | permit igmp | bind ip ip-address [mac mac-address interface { ethernet | gpon } interface-id vlan vlan-id] }
```

Syntax Description

vlan <i>vlan-list</i>	Configures IP Source Guard on the VLANs listed by <i>vlan-list</i> .
permit igmp	Configures IP Source Guard to allow Internet Group Management Protocol (IGMP) packets to pass through.
bind ip <i>ip-address</i>	Configures an entry in the static IP source binding table.
mac <i>mac-address</i>	The MAC address that is bound to the IP address.
interface	Specifies the interface to be configured.
ethernet	Specifies the Ethernet interface
gpon	Specifies the GPON interface
vlan <i>vlan-id</i>	Specifies the VLAN to which the interface belongs.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

IP Source Guard feature filters the source IP address on a Layer 2 port to prevent a malicious host from impersonating a legitimate host.

You can enable the IP Source Guard feature only on untrusted ports. For IP Source Guard to function, enable DHCP Snooping.

Use the **ip-source-guard bind** command to configure an IP source binding.

Use the **ip-source-guard vlan** *vlan-list* command to configure IP Source Guard on the listed VLANs.

Use the **ip-source-guard permit igmp** command to allow IGMP packets to pass through.

Example

The following example shows how to configure an entry in the IP source binding table:

```
Device> enable
Device# configure terminal
Device(config)# ip-source-guard bind ip 192.168.11.2
```

The following example shows how to configure ip source guard on three VLANs:

```
Device(config)# ip-source-guard vlan 7,8,10
```

ip-source-guard filter

To configure the port filtering mode for an interface, use the **ip-source-guard** command in the interface configuration mode.

```
ip-source-guard [ip | ip-mac | ip-mac-vlan]
```

Syntax Description	ip	ip-mac	ip-mac-vlan
	Specifies that the port filter packets are based on source IP, regardless of the MAC address and the VLAN ID.	Specifies that the port filters packets based on the source IP address and the MAC address of the packet.	Specifies that the port filters packets based on source IP address, MAC address, and VLAN ID.

Command Default None

Command Modes Interface Configuration (config-if)

Usage Guidelines

IP Source Guard feature filters the source IP address on a Layer 2 port to prevent a malicious host from impersonating a legitimate host.

You can enable the IP Source Guard feature only on untrusted ports. For IP Source Guard to function, enable DHCP Snooping.

Use the **ip-source-guard ip** command on the interface to filter packets are based on source IP, regardless of the MAC address and the VLAN ID.

Use the **ip-source-guard ip-mac vlan-list** command on the interface to filter packets are based on source IP and MAC address, regardless of the VLAN ID.

Use the **ip-source-guard ip-mac-vlan** command on the interface to filter packets are based on source IP, MAC address, and VLAN ID.

If you don't specify the port filtering mode, the port filters packets based on the source IP address, MAC address, and VLAN ID.

Example

The following example shows how to configure the port to filter packets based on the source IP address and MAC address:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/1

Device(config-if-ethernet-1/1)# ip-source-guard ip-mac
Config IP source guard mode of port successfully.
```

ip address

To configure the primary IP address for the VLAN interface, use the **ip address** command in the VLAN configuration mode.

```
ip address { ip-address mask ip-address override | primary ip-address }
```

Syntax Description	Override Overrides the IP address of the VLAN interface.
	primary Configures the primary IP address for the VLAN interface.

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples	The following example shows how to configure the primary IP address for an interface:
-----------------	---

```
Device(config-if-vlan)# ip address primary 192.0.2.1
```

ip address *mask-ip-address*

To configure a loopback interface for the IP address, use the **ip address *mask-ip-address*** command in the loopback interface configuration mode.

To disable the loopback loopback interface for the IP address, use the **no** form of the command.

ip address*ip-address mask-ip-address*

no ip address*ip-address mask-ip-address*

Syntax Description	<i>ip-address</i> It is the IP address of the interface
	<i>mask-ip-address</i> Configures the loopback IP address for the interface.

Command Default	None
------------------------	------

Command Modes	Loopback interface configuration mode
----------------------	---------------------------------------

Examples

The following example shows how to configure a loopback interface for the IP address

```
Device(config-if-loopbackinterface)# ip address 192.0.2.1 255.255.255.0
```

ip address range

To configure the range of IP addresses for the VLAN interface, use the **ip address range** command in the the VLAN configuration mode. You can delete the range of IP addresses for the VLAN interface using the **no** form of the command.

ip address range { *start-ip-address end-ip-address* }

no ip address range { *start-ip-address end-ip-address* }

Syntax Description		
range		Configures the range of IP addresses for the VLAN interface
<i>start-ip-address</i>		Configures the starting IP address of the range.
<i>end-ip-address</i>		Configures the ending IP address of the range.

Command Default None

Command Modes VLAN configuration mode

Examples

The following example shows how to configure a range of IP addresses for the interface:

```
Device(config-if-vlan)# ip address range 192.0.2.254 192.0.2.255
```


ip icmp mask-reply

To enable the ICMP address mask reply packet, use the **ip icmp mask-reply** command in the global configuration mode. To disable the ICMP address mask reply packet, use the **no** form of the command.

ip icmp mask-reply

no ip icmp mask-reply

Syntax Description	mask-reply Enables the ICMP address mask reply packet.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration mode
----------------------	---------------------------

Examples

The following example shows how to enable ICMP address mask reply packet:

```
Device(config)# ip icmp mask-reply
```

ip icmp unreachable

To enable the sending of ICMP destination unreachable packets, use the **ip icmp unreachable** command in the VLAN configuration mode. To disable the sending of ICMP destination unreachable packets, use the **no** form of the command.

ip icmp unreachable

no ip icmp unreachable

Syntax Description	unreachable Enables the sending of ICMP destination unreachable packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	VLAN configuration mode
----------------------	-------------------------

Examples The following example shows how to enable the sending of ICMP destination unreachable packets.

```
Device(config-if-vlanif)# ip icmp unreacheable
```

ipv6 address

To configure the IPv6 address for the VLAN interface, use the **ipv6 address** command in the VLAN configuration mode. To delete the IPv6 address use the **no** form of the command.

ipv6 address { *ipv6-address-mask ipv6-address/prefixlength* | **autoconfig** }

no ipv6 address { *ipv6-address-mask ipv6-address/prefixlength* | **autoconfig** }

Syntax Description	<i>ipv6-address/prefixlength</i>	Specifies the IPv6 prefix for the VLAN interface.
	<i>ipv6-address-mask</i>	Specifies the IPv6 destination address for the VLAN interface.
	autoconfig	Enables stateless autoconfiguration.

Command Default None.

Command Modes VLAN configuration

Examples

The following example shows how to configure the IPv6 address for an interface:

```
Device> enable
Device# configure terminal
Device(config)# interface vlan-interface 100
Device(config-if-vlan)# ipv6 address 2001::100/64
```

ipv6 address link-local

To specify the link local address manually on a VLAN interface, use the **ipv6 address link-local** command in the VLAN configuration mode. The link-local is automatically formed by default.

ipv6 address *ipv6-address* **link-local**

Syntax Description	<i>ipv6-address</i>	Specifies the IPv6 prefix for the VLAN interface.
	link-local	Configures a link-local IPv6 address.
Command Default	The link-local is automatically formed by default.	
Command Modes	VLAN configuration	

The following example shows how to configure a link-local IPv6 address on a VLAN interface using the **ipv6 address link-local** command.

```
Device> enable
Device#configure terminal
Device(config)# ipv6 enable
Device(config)# interface vlan-interface 1
Device(config-vlan-if)# ipv6 address FE80:1::100 link-local
```

ipv6 enable

To enable IPv6 forwarding, use the **ipv6 enable** command in global configuration mode. To disable IPv6 forwarding, use the **ipv6 disable** command in global configuration mode.

ipv6 { **enable** | **disable** }

Syntax Description	enable	Disables IPv6 forwarding.
	disable	Disables IPv6 forwarding.

Command Modes Global configuration (config)

The following example shows how to enable IPv6 forwarding using the **ipv6 enable** command:

```
Device> enable
Device# configure terminal
Device(config)# ipv6 enable
```

ipv6 icmpv6 multicast-echo-reply

To enable an echo-reply for an echo request, use the **ipv6 icmpv6 multicast-echo-reply** command in global configuration mode. You can use the **no ipv6 icmpv6 multicast-echo-reply** command to disable reply for multicast packets.

ipv6 icmpv6 multicast-echo-reply enable

no ipv6 icmpv6 multicast-echo-reply

Syntax Description	<i>enable</i>	Enables echo reply for multicast packets
Command Default	None.	
Command Modes	Global configuration mode (config)	

The following example shows how to enable echo reply for multicast packets by using the **ipv6 icmpv6 multicast-echo-reply enable** command in global configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# ipv6 icmpv6 multicast-echo-reply enable
```

ipv6 nd dad attempts

To configure the number of times Neighbor Solicitation (NS) messages will be sent for duplicate address detection, use the **ipv6 nd dad attempts** command in global configuration mode. You can use the **no ipv6 nd dad attempts** command to configure the number of NS messages sent to the value of 0.

ipv6 nd dad attempts *value*

no ipv6 nd dad attempts

Syntax Description	<i>value</i>	Configures the number of times NS messages are sent for duplicate address detection. The value ranges from 0 to 20. the default value for the number of NS messages sent is 1. When value is 0, it implies duplicate address detection is disabled
Command Default	None.	
Command Modes	Global configuration mode (config)	

The following example shows how to configure the number of NS messages sent for duplicate address detection to 10, using the **ipv6 nd dad attempts** command in global configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# ipv6 nd dad attempts 10
```

ipv6 nd ns retrans-time

To set the time interval for retransmitting the Neighbor Solicitation (NS) message, use the **ipv6 nd ns retrans-time** command in global configuration mode. You can use the **no ipv6 nd ns retrans-time** command to disable the retransmission timer.

ipv6 nd ns retrans-time *value*

no ipv6 nd ns retrans-time

Syntax Description	<i>value</i>	Sets the time interval for retransmitting the NS message. The value ranges from 1 to 3600 seconds. The default value for retransmitting the NS message is 1 second.
Command Default	None.	
Command Modes	Global configuration mode (config)	

The following example shows how to set the time interval for retransmitting the NS message to 60 seconds using the **ipv6 nd ns retrans-time** command in global configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# ipv6 nd ns retrans-time 60
```


ipv6 nd reachable-time

To configure the time for which a neighbor is considered to be in a reachable state, use the **ipv6 nd reachable-time** command in the global configuration mode. You can use the **no ipv6 nd reachable-time** command to reset the reachable time to its default value of 30 seconds.

ipv6 nd reachable-time *value*

no ipv6 nd reachable-time

Syntax Description	<i>value</i>	Configures the time for which a neighbor is considered to be in a reachable state. The value ranges from 1-3600 seconds. The default value is 30 seconds.
---------------------------	--------------	---

Command Default The default value of the reachable time is 30 seconds.

Command Modes Global configuration mode (config)

The following example shows how to configure the reachable-time to 60 seconds, using the **ipv6 nd reachable-time** command in global configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# ipv6 nd reachable-time 60
```

ipv6 neighbors max-learning-num

To configure the maximum number of neighbors that can access an IPv6 address, use the **ipv6 neighbors max-learning-num** command in the global configuration mode. The maximum neighbor number includes both static and dynamic neighbors. You can use the **no ipv6 neighbors max-learning-num** command to reset the maximum number of neighbors to the default value of 64.

ipv6 neighbors max-learning-num *number*

no ipv6 neighbors max-learning-num

Syntax Description	<i>number</i>	Configures the maximum number of neighbors for an IPv6 address. The range for the number is 1 to 2560. The default maximum number of neighbors is 64.
---------------------------	---------------	---

Command Default The default maximum number of neighbors is 64.

Command Modes Global configuration mode (config)

The following example shows how to configure the maximum neighbor number to 1000 using the **ipv6 neighbors max-learning num** command in global configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# ipv6 neighbors max-learning-num 1000
```

ipv6 path

To configure the Maximum Transmission Unit (MTU) value for an IPv6 interface, use the **ipv6 path** command in the VLAN interface configuration mode. You can use the **no ipv6 path** command to reset the MTU value to its default value of 1500.

ipv6 path *mtu-value*

no ipv6 path *mtu-value*

Syntax Description	<i>mtu-value</i>	Configures the MTU for the IPv6 interface. The MTU value ranges from 1280-1500. The default MTU value is 1500.
---------------------------	------------------	--

Command Default	The default MTU value is 1500 .
------------------------	---------------------------------

Command Modes	VLAN configuration
----------------------	--------------------

The following example shows how to set the MTU value to 2000 for an IPv6 interface, using the **ipv6 path** command in VLAN configuration mode.

```
Device> enable
Device# configure terminal
Device(config)# interface vlan-interface 100
Device(config-vlan_if)# ipv6 path 2000
```

ipv6 route

To configure a static route with the IPv6 address, use the **ipv6 route** command in global configuration mode. To disable static route, use the **no** form of the command.

ipv6 route { *ipv6-address/prefixlength ipv6-address/prefixlength* } *next-hop-address*

no ipv6 route { *ipv6-address/prefixlength ipv6-address/prefixlength* } *next-hop-address*

Syntax Description	
<i>ipv6-address/prefixlength</i>	Specifies the IPv6 prefix.
<i>ipv6-address/prefixlength</i>	Specifies the IPv6 destination address.
<i>next-hop-address</i>	Specifies the IPv6 next hop address.

Command Default None.

Command Modes Global configuration (config)

Examples

The following example shows how to configure a static route using the **ipv6 route** command:

```
Device> enable
Device# configure terminal
Device(config)# ipv6 route 2001:DB8:1::0/64 2001:DB8:0:ABCD::1
```

no ipv6 neighbor

To delete neighbors from the ipv6 neighbors list, use the **no ipv6 neighbor** command in global configuration mode.

no ipv6 neighbor { **dynamic** | **static** | **all** }

Syntax Description		
	dynamic	Deletes the dynamic neighbors from the IPv6 neighbor list.
	static	Deletes the static neighbors from the IPv6 neighbor list.
	all	Deletes all the neighbors from the IPv6 neighbor list.

Command Default None.

Command Modes Global configuration (config)

The following example shows how to all the dynamic neighbors from the IPv6 neighbor list by using the **no ipv6 neighbor** command in the global configuration mode.

```
Device> enable
Device#configure terminal
Device(config)# no ipv6 neighbor dynamic
```

mac-address-table

To add a MAC address manually to the MAC address table, use the **mac-address-table** command in the global configuration mode. To remove a MAC address from the table, use the **no** form of the command.

mac-address-table { **static** | **permanent** | **dynamic** } *mac-address* **interface ethernet***interface-number* **vlan** *vlan-id*

no mac-address-table { **static** | **permanent** | **dynamic** } *mac-address* **interface ethernet***interface-number* **vlan** *vlan-id*

Syntax Description

static	Adds a static MAC address to the MAC address table.
permanent	Adds a MAC address permanently to the MAC address table.
dynamic	Adds a dynamic MAC address to the MAC address table.

Command Default

None

Command Modes

Global configuration

Examples

The following examples shows how to add a static MAC address to a MAC address table:

```
Device(config)# mac-address-table static 00:50:3e:8d:64:00 interface ethernet
1/4 vlan 3
```

mac-address-table learning

To disable dynamic MAC address learning, use the **no mac-address-table learning** command. To disable MAC address learning on all ports use the command in the global configuration mode. To disable MAC address learning on specific ports use the command in the interface configuration mode. MAC address learning is enabled by default.

mac-address-table learning

no mac-address-table learning

Syntax Description	learning Enables or disables MAC address learning.
---------------------------	---

Command Default	MAC address learning is enabled by default.
------------------------	---

Command Modes	Global configuration Interface configuration
----------------------	---

Examples	The following example shows how to disable MAC address learning on an ethernet port:
-----------------	--

```
Device(config)# interface ethernet 1/4  
Device(config-if-ethernet-1/4)# no mac-address-table learning
```

mac-address-table age-time

To configure the aging time for entries in the MAC address table, use the **mac-address-table age-time** command in the global configuration mode. To disable the aging process use the **disable** keyword.

mac-address-table age-time { *seconds* | **disable** }

Syntax Description

disable Disables the ageing process for the MAC address table.

seconds Configures the ageing time for the MAC address table in seconds.

Command Default

None

Command Modes

Global configuration

Examples

The following example shows how to configure ageing time for a MAC address table:

```
Device(config)# mac-address-table age-time 120
```


mac-address-table blackhole

To add the MAC address of an untrusted user as a Blackhole MAC address, use the **mac-address-table blackhole** command in the global configuration mode. To remove a MAC address as a Blackhole MAC address use the **no** form of the command.

mac-address-tableblackhole *mac-address* **vlan** *vlan-id*

no mac-address-tableblackhole *mac-address* **vlan** *vlan-id*

Syntax Description	blackhole Adds a MAC address as a Blackhole MAC address.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to add a MAC address as a Blackhole MAC address:

```
Device(config)# mac-address-table blackhole 00:05:00:05:00:05 vlan 1
```

mac-address-table max-mac-count

To configure the maximum number of MAC addresses that will be learnt by the MAC Address Table on a port, use the **mac-address-table max-mac-count** command in the interface configuration mode. To keep the number of MAC addresses learnt as unlimited use the **no** form of the command. By default, the number of MAC addresses that are dynamically learnt by the MAC Address Table are unlimited.

mac-address-table max-mac-count *integer*

no mac-address-table max-mac-count *integer*

Syntax Description

max-mac-count *integer* Enables a limit on the number of dynamically learnt MAC addresses added to the table

Command Default

The number of learnt MAC addresses are unlimited by default

Command Modes

Interface configuration

Examples

The following example shows how to enable a maximum learnt MAC address count on a port:

```
Device(config)# interface ethernet 1/4
Device(config-if-ethernet-1/4)# mac-address-table max-mac-count 500
```

mirror destination-interface

To configure a port as destination port for mirroring, use the `mirror destination-interface` command in the global configuration mode. To remove the mirroring configuration, use the **no** form of the command.

[no] **mirror destination-interface** {**ethernet** *slot/port* | **gpon** *slot/port*}

Syntax Description	ethernet <i>slot/port</i>	Specifies the ethernet interface that can be configured as the destination for port mirroring
	gpon <i>slot/port</i>	Specifies the GPON interface as the destination for port mirroring.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines Use this command to configure the destination port that receives the mirrored packets. Port mirroring duplicates the data packets on the monitored (source) port and sends the packets to a destination port for monitoring or analysis. You can mirror inbound packets or outbound packets or both types of packets on the source port.

A port configured as a destination port cannot be used as a normal port.

For a switch, you can configure only one port as destination port.

Example

The following example sets the ethernet port 2/1 as the destination for mirroring.

```
Device#configure terminal
Device(config)#mirror source-interface ethernet 1/1 both
Device(config)#mirror destination-interface ethernet 2/1
```

mirror source-interface

To configure a port to act as a source port for mirroring, use the **mirror source-interface** command in the global configuration mode. To remove the mirroring configuration, use the **no** form of the command.

[no] **mirror source-interface** {**ethernet** *slot/port* | **cpu** | **gpon** *slot/port* } {**ingress** | **egress** | **both**}

Syntax Description		
ethernet <i>slot/port</i>	Specifies the ethernet interface that can be configured as the source for port mirroring	
cpu	Specifies the CPU as the source for port mirroring	
gpon <i>slot/port</i>	Specifies the GPON interface as the source for port mirroring.	
ingress	Specifies that the packets at the ingress of the specified port, which are inbound, are mirrored.	
egress	Specifies that packets at the egress of the specified port, which are outbound, are mirrored.	
both	Specifies that the packets at both the ingress and egress interfaces are mirrored.	

Command Default None

Command Modes Global configuration (config)

Usage Guidelines Use this command to configure the source port for mirroring the packets at the port. You can mirror inbound packets or outbound packets or both types of packets.

Port mirroring duplicates the data packets on the monitored (source) port and sends the packets to a destination port for monitoring or analysis.

You can configure multiple ports as source port for mirroring.

Example

The following example sets the ethernet port 1/1 as the source for mirroring the packets.

```
Device#configure terminal
Device(config)#mirror source-interface ethernet 1/1 both
```

show arp

To display the Address Resolution Protocol (ARP) table entries, use the **show arp** command in privileged or global configuration mode.

show arp { **dynamic** | **static** | **all** }

Syntax Description	
dynamic	Displays all the dynamic ARP table entries
static	Displays all the static ARP table entries
all	Displays all the entries from the ARP table

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Usage Guidelines The **show arp dynamic** command displays all mappings and information about each entry in the ARP table, including the aging time, VLAN instance, and port.

Example

```
Device#show arp dynamic
Informations of ARP
d - days, h - hours, m - minutes, s - seconds
IpAddress      Mac_Address    Vlan  Port    VPTag  Type      ExpireTime  Status
10.75.171.1    00:23:5d:fd:94:00  100  e1/3    0      dynamic  18m34s     valid
10.75.171.71   00:50:56:92:1d:fb  100  e1/3    0      dynamic  10m51s     valid
10.75.171.79   00:0c:29:80:8b:59  100  e1/3    0      dynamic  17m43s     valid
10.75.171.91   00:0c:29:71:b1:4f  100  e1/3    0      dynamic  10m59s     valid
10.75.171.138  00:0c:29:f9:35:c3  100  e1/3    0      dynamic  11m07s     valid

Total entries:5
```

Table 5: Description of the show arp dynamic Command Output

IpAddress	Specifies the IP address of the ARP table entry
MAC_Address	Specifies the MAC address associated with the IP address
Vlan	Specifies the VLAN to which this interface belongs
Port	Specifies the port that has learnt the ARP entry
VPTag	Specifies the virtual port for GPON routing
Type	Specifies whether it is a dynamic or a static entry
Expire Time	Displays the time remaining before the ARP entry expires
Status	Specifies whether the entry is valid or not.

show dhcp-snooping clients

To display binding between the IP address and the MAC address that is recorded by DHCP Snooping, use the **show dhcp-snooping clients** command in privileged or global configuration mode.

show dhcp-snooping clients

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following example shows a sample format of the output of this command:

```
Device#show dhcp-snooping clients
DHCP client information:
d - days, h - hours, m - minutes, s - seconds
IPAddress      mac                vlan port      LeaseTime      ExceedTime

Total entries: 0. Printed entries: 0.
```

Related Commands

Command	Description
dhcp-snooping	Enables DHCP Snooping on the device.

show dhcp-snooping interface

To display the details of DHCP Snooping on an interface, use the **show dhcp-snooping interface** command in privileged or global configuration mode.

```
show dhcp-snooping interface [ ethernet | gpon ] [ interface-id ]
```

Command Default None

Command Modes Privileged (#)

Global Configuration (config)

Usage Guidelines

This command displays the DHCP Snooping enabled state, information on the trusted port, the number of DHCP clients allowed on the physical port, and the number of currently connected DHCP clients.

Example

```
Device#show dhcp-snooping interface
Config information of DHCP Snooping:
DHCP Snooping status:Enable
DHCP Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
g0/1          untrust   2048        0             0
g0/2          untrust   2048        0             0
g0/3          untrust   2048        0             0
g0/4          untrust   2048        0             0
g0/5          untrust   2048        0             0
g0/6          untrust   2048        0             0
g0/7          untrust   2048        0             0
g0/8          untrust   2048        0             0
e1/1          untrust   2048        0             0
e1/2          untrust   2048        0             0
e1/3          untrust   2048        0             0
e1/4          untrust   2048        0             0
e2/1          untrust   2048        0             0
e2/2          untrust   2048        0             0
```

```
Device#show dhcp-snooping interface gpon 0/1

Config information of DHCP Snooping:
DHCP Snooping status:Enable
DHCP Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
g0/1          untrust   2048        0             0
```

```
Device#show dhcp-snooping interface ethernet 1/1

Config information of DHCP Snooping:
DHCP Snooping status:Enable
DHCP Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
```

show dhcp-snooping interface

```
e1/1      untrust  2048      0          0
```


show dhcpv6-snooping clients

To display binding between the IP address and the MAC address that is recorded by DHCPv6 Snooping, use the **show dhcpv6-snooping clients** command in privileged or global configuration mode.

show dhcpv6-snooping clients

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following example shows a sample format of the output of this command:

```
Device#show dhcpv6-snooping clients
DHCPv6 client information:
d - days, h - hours, m - minutes, s - seconds
IPAddress      mac                vlan port      LeaseTime      ExceedTime

Total entries: 0. Printed entries: 0.
```

Related Commands

Command	Description
dhcpv6-snooping	Enables DHCPv6 Snooping on the device.

show dhcpv6-snooping interface

To display the details of DHCPv6 Snooping on an interface, use the **show dhcpv6-snooping interface** command in privileged or global configuration mode.

show dhcpv6-snooping interface [ethernet | gpon] [interface-id]

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Usage Guidelines

This command displays the DHCPv6 Snooping enabled state, information on the trusted port, the number of DHCPv6 clients allowed on the physical port, and the number of currently connected DHCPv6 clients.

Example

```
Device#show dhcpv6-snooping interface
Config information of DHCPv6 Snooping:
DHCPv6 Snooping status:Enable
DHCPv6 Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
g0/1          untrust   2048        0             0
g0/2          untrust   2048        0             0
g0/3          untrust   2048        0             0
g0/4          untrust   2048        0             0
g0/5          untrust   2048        0             0
g0/6          untrust   2048        0             0
g0/7          untrust   2048        0             0
g0/8          untrust   2048        0             0
e1/1          untrust   2048        0             0
e1/2          untrust   2048        0             0
e1/3          untrust   2048        0             0
e1/4          untrust   2048        0             0
e2/1          untrust   2048        0             0
e2/2          untrust   2048        0             0
```

show dhcpv6-snooping vlan

To display the details of DHCPv6 Snooping on a VLAN, use the **show dhcpv6-snooping vlan** command in privileged or global configuration mode.

show dhcpv6-snooping vlan *vlan_id*

Command Default None

Command Modes Global Configuration (config)

Usage Guidelines This command displays the DHCPv6 Snooping enabled state, information on the trusted port, the number of DHCPv6 clients allowed on the physical port, and the number of currently connected DHCPv6 clients.

Example

```
Device#show dhcpv6-snooping vlan 1
Config information of DHCPv6 Snooping:
DHCPv6 Snooping status:Enable
DHCPv6 Snooping port-down-action fast-remove:Enable
Port information:
Port          mode      maxclients  clients(ack)  clients(unack)
g0/1          untrust   2048        0             0
g0/2          untrust   2048        0             0
g0/3          untrust   2048        0             0
g0/4          untrust   2048        0             0
g0/5          untrust   2048        0             0
g0/6          untrust   2048        0             0
g0/7          untrust   2048        0             0
g0/8          untrust   2048        0             0
e1/1          untrust   2048        0             0
e1/2          untrust   2048        0             0
e1/3          untrust   2048        0             0
e1/4          untrust   2048        0             0
e2/1          untrust   2048        0             0
e2/2          untrust   2048        0             0
```

show dlf-forward

To display the DLF forwarding configuration for a port, use the **show dlf-forward** command in the EXEC mode.

show dlf-forward interface { **ethernet** *port-number* | **gpon** *port-number* }

Syntax Description	
ethernet <i>port-number</i>	Displays the DLF Forwarding configuration for the ethernet port.
gpon <i>port-number</i>	Displays the DLF Forwarding configuration for the gpon port.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows how to display the DLF forwarding configuration for an ethernet port

```
Device# show dlf-forward interface ethernet 1/1
Forwarding unknown unicast packets global status: disable
Forwarding unknown multicast packets global status: disable
Port      Forwarding Unknown Unicast      Forwarding Unknown Multicast
e1/1      disable                          disable
```

Examples

The following example shows how to display the DLF forwarding configuration for a GPON port

```
Device# show dlf-forward interface gpon 0/1
Forwarding unknown unicast packets global status: disable
Forwarding unknown multicast packets global status: disable
Port      Forwarding Unknown Unicast      Forwarding Unknown Multicast
g0/1      disable                          disable
```

show ip interface

To display the IP interface configuration for the Layer 3 device, use the **show ip interface** command in the EXEC mode.

show ip interface { **loopback-interface** *loopback-interface-number* | **vlan-interface** *vlan-interface-number* | **meth-interface** *meth-interface-number* }

Syntax Description	
<i>loopback-interface-number</i>	Displays information for the loopback interface.
<i>vlan-interface-number</i>	Displays information for the VLAN interface.
<i>meth-interface-number</i>	Displays information for the meth interface.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows a sample output of a loopback interface:

```
Device# show ip interface loopback-interface 1
Show informations of interface
The mac-address of interface is 00:0a:5a:9b:18:15
Interface name      : LOOPBACK-IF1
Primary ipaddress   : None
Secondary ipaddress : None
Interface status    : Up
```

Total entries: 1 interface.

The following example shows a sample output of a VLAN interface:

```
Device# show ip interface vlan-interface 1
Show informations of interface
The mac-address of interface is 00:0a:5a:9b:18:15
Interface description : interface1
Interface name        : VLAN-IF1
Primary ipaddress     : None
Secondary ipaddress   : None
VLAN                  : 1
Address-range         : 192.0.2.254-192.0.2.255,
Interface status      : Up
```

Total entries: 1 interface.

show ip source guard

To display the status and port filter applied on each port, use the **show ip-source-guard** command in privileged or global configuration mode.

```
show ip-source-guard [bind | permit | vlan]
```

Syntax Description	bind	Displays the entries of the static IP source binding table.
	permit	Displays the whether Internet Group Management Protocol (IGMP) packets are permitted or not.
	vlan ip <i>ip-address</i>	Displays VLAN information.

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show ip-source-guard
Port      Status  FilterType
g0/1      disable N/A
g0/2      disable N/A
g0/3      disable N/A
g0/4      disable N/A
g0/5      disable N/A
g0/6      disable N/A
g0/7      disable N/A
g0/8      disable N/A
e1/1      enable  ip+mac+vlan
e1/2      disable N/A
e1/3      disable N/A
e1/4      disable N/A
e2/1      disable N/A
e2/2      disable N/A
```

Total entries:14

The following example displays the status of port filtering on IGMP packets:

```
Device#show ip-source-guard permit igmp
IP source guard permit igmp status:disable
```

Related Commands

Command	Description
ip-source-guard	Configures the IP source guard function on the ports of the device.

show ipv6 interface

To display the IP interface configuration for the Layer 3 device, use the **show ipv6 interface** command in the EXEC mode.

```
show ipv6 interface { loopback-interface loopback-interface-number | vlan-interface vlan-interface-number | meth-interface meth-interface-number }
```

Syntax Description	
<i>loopback-interface-number</i>	Displays information for the loopback interface.
<i>vlan-interface-number</i>	Displays information for the VLAN interface.
<i>meth-interface-number</i>	Displays information for the meth interface.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows a sample output of a loopback interface:

```
Device# show ipv6 interface loopback-interface 1
Show informations of interface
The mac-address of interface is 00:0a:5a:9b:18:15
Interface name      : LOOPBACK-IF1
Primary ipaddress   : None
Secondary ipaddress : None
Interface status    : Up
```

Total entries: 1 interface.

The following example shows a sample output of a VLAN interface:

```
Device# show ipv6 interface vlan-interface 1
Show informations of interface
The mac-address of interface is 00:0a:5a:9b:18:15
Interface description : interface1
Interface name        : VLAN-IF1
Primary ipaddress     : None
Secondary ipaddress   : None
VLAN                  : 1
Address-range         : 192.0.2.254-192.0.2.255,
Interface status      : Up
```

Total entries: 1 interface.

show ipv6 nd dad attempts

To display the number of times Neighbor Solicitation (NS) messages are being sent for duplicate address detection, use the **show ipv6 nd dad attempts** command in EXEC mode.

show ipv6 nd dad attempts

Syntax Description	attempts	Displays the number of times NS messages are being sent for duplicate address detection.
Command Default	None	
Command Modes	User EXEC Privileged EXEC	

The following example shows a sample output of the **show ipv6 nd dad attempts** command.

```
Device#show ipv6 nd dad attempts
Global duplicate address detection times configuration is: 1
Interface specific configurations are as follows:
Interface : DAD times

Total entries:0
```


show ipv6 nd ns retrans-time

To display the interval at which the Neighbor Solicitation (NS) messages are being sent for duplicate address detection, use the **show ipv6 nd ns retrans-time** command in EXEC mode.

show ipv6 nd ns retrans-time

Syntax Description	retrans-time	Displays the interval at which the NS messages are being sent for duplicate address detection.
Command Default	None	
Command Modes	User EXEC Privileged EXEC	

The following example shows a sample out of the show ipv6 nd ns retrans-time command.

```
Device#show ipv6 nd ns retrans-time
Global neighbor solicitation retransmit time configuration is: 1 s
Interface specific configurations are as follows:
Interface : Retransmit time(s)

Total entries:0
```

show ipv6 nd reachable-time

To display the reachable time configured on an interface, use the **show ipv6 nd reachable-time** command in EXEC mode. Reachable time is the time for which a neighbor is considered to be in a reachable state.

show ipv6 nd reachable-time

Syntax Description	reachable-time	Displays the reachable time configured on an interface.
Command Default	None.	
Command Modes	User EXEC Privileged EXEC	

The following example displays a sample output for the **show ipv6 nd reachable-time** command.

```
Device#show ipv6 nd reachable-time
Global reachable time configuration is: 30 s
Interface specific configurations are as follows:
Interface : Reachable time(s)
```

show ipv6 neighbors

To display the list of IPv6 neighbors for an interface, use the **show ipv6 neighbors** command in the EXEC mode.

```
show ipv6 neighbors { ipv6-address | all | dynamic | static | mac mac-address | max-learning-num }
```

Syntax Description	<i>ipv6-address</i>	Specifies the IPv6 address of the neighbor.
	all	Displays a list of all the IPv6 neighbors.
	dynamic	Displays a list of all the dynamic IPv6 neighbors.
	static	Displays a list of all the static IPv6 neighbors.
	mac	Displays the MAC address of all the IPv6 neighbors.
	max-learning-num	Displays the maximum number of neighbors the interface is allowed to learn.
Command Default	None.	
Command Modes	User EXEC Privileged EXEC	

show ipv6 route

To display the IPv6 static route configuration, use the **show ipv6 route** command in the EXEC mode.

show ipv6 route [*ospf*]

Syntax Description	<i>ospf</i> Displays information of the OSPF routing configuration.
---------------------------	---

Command Default	None.
------------------------	-------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows a sample output of the **show ipv6 route** command:

```
Device# show ipv6 route
Show ip route information

INET6 route table - vr: 0, table: 254
Route flag: U - up, G - gateway, H - host, R - reject, C - clone, S - static
Destination          Gateway              Flags    Use    Interface
Metric MTU
::                   link#1              UHRS     0     lo0
0                   0
::1                  ::1                 UH       0     lo0
0                   0
FE80::%lo0/64       link#1              UC       0     lo0
0                   0
FE80::%sw0/64       link#2              UC      1067  VLAN-IF100
0                   0
FE80::%meth0/64     link#514            UC       0     METH-IF0
0                   0
FE80::1%lo0         link#1              UH       0     lo0
0                   0
FE80::20A:5AFF:FE94:804C%sw0 link#1              UH       0     lo0
0                   0
FE80::20A:5AFF:FE94:804C%meth0 link#1              UH       0     lo0
0                   0

Total entries: 8. Printed entries: 8.
```

show mac-address-table age-time

To display the aging time of the MAC address table, use the **show mac-address-table age-time** command in the EXEC mode.

show mac-address-table age-time

Syntax Description	age-time Displays the aging time of the MAC address table.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows how to display the aging time for a MAC address table:

```
Device# show mac-address-table age-time
mac address table agingtime is 300 seconds.
```

show mac-address-table

To display information about the MAC address table, use the **show mac-address-table** command in the EXEC mode.

show mac-address-table { **static** | **permanent** | **dynamic** } **blackhole** **learning** **interface ethernet** *interface-number* **vlan** *vlan-id*

Syntax	Description
static	Displays the static MAC address table.
permanent	Displays the permanent entries in the MAC address table.
dynamic	Displays the dynamic MAC address table.
blackhole	Displays the blackhole MAC address table.
learning	Displays the MAC address learning status.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows how to display the dynamic MAC address table:

```
Device# show mac-address-table dynamic
Show ARL table information
MAC Address      VLAN ID  port  status
00:0a:5a:a7:01:34 100     g0/1  dynamic
00:0b:ab:82:2d:82 100     e1/3  dynamic
00:0c:29:07:b6:9b 100     e1/3  dynamic
00:0c:29:15:9e:10 100     e1/3  dynamic
00:0c:29:3c:3b:08 100     e1/3  dynamic
00:0c:29:3c:3b:12 100     e1/3  dynamic
00:0c:29:71:b1:4f 100     e1/3  dynamic
00:0c:29:71:b1:59 100     e1/3  dynamic
00:0c:29:b8:0f:0b 100     e1/3  dynamic
00:0c:29:b8:0f:15 100     e1/3  dynamic
00:11:32:47:9a:30 100     e1/3  dynamic
00:19:bb:2f:5a:81 100     e1/3  dynamic
00:19:bb:30:70:97 100     e1/3  dynamic
00:19:bb:30:a0:6b 100     e1/3  dynamic
00:1f:26:35:7a:9f 100     e1/3  dynamic
00:21:5a:a9:53:14 100     e1/3  dynamic
00:23:5d:fd:94:00 100     e1/3  dynamic
00:30:18:cc:7b:02 100     e1/3  dynamic
00:50:56:92:0a:09 100     e1/3  dynamic
00:50:56:92:88:2f 100     e1/3  dynamic
00:50:56:95:41:5e 100     e1/3  dynamic
00:50:56:bd:2b:cf 100     e1/3  dynamic
00:61:56:60:93:84 100     e1/3  dynamic
00:d0:0a:0b:ea:1c 100     e1/3  dynamic
00:e0:4c:86:70:01 100     e1/3  dynamic
00:eb:d5:5e:02:a0 100     e1/3  dynamic
0c:f5:a4:ba:44:9f 100     e1/3  dynamic
2c:ab:eb:22:76:8d 100     e1/3  dynamic
```

```
40:a6:e8:e6:52:de 100 e1/3 dynamic
40:a6:e8:e6:b5:5c 100 e1/3 dynamic
44:8a:5b:98:e9:60 100 e1/3 dynamic
5c:71:0d:bb:35:8b 100 e1/3 dynamic
5c:71:0d:bb:3c:19 100 e1/3 dynamic
5c:71:0d:bb:60:fa 100 e1/3 dynamic
68:9c:e2:a0:7d:3e 100 e1/3 dynamic
68:9c:e2:a0:7d:5e 100 e1/3 dynamic
68:ca:e4:3a:3d:e0 100 e1/3 dynamic
68:ef:bd:f0:d1:08 100 e1/3 dynamic
b0:7d:47:3f:47:ae 100 e1/3 dynamic
c8:f9:f9:45:12:5b 100 e1/3 dynamic
e4:1f:13:43:41:0a 100 e1/3 dynamic
e4:1f:13:77:9f:06 100 e1/3 dynamic
e4:1f:13:77:a0:c8 100 e1/3 dynamic
Total entries: 43 .
```

Examples

The following example shows how to display the static MAC address table:

```
Device# show mac-address-table static
Show ARL table information
MAC Address      VLAN ID  port  status
00:0a:5a:9b:18:15 1        cpu  static
00:0a:5a:9b:18:15 100     cpu  static
Total entries: 2 .
```

Examples

The following example shows how to display the MAC address table learning status:

```
Device# show mac-address-table learning interface ethernet 1/1
Port      Mac learning status
e1/1     enable
Total entries: 1 .
```

show mirror

To see the port mirror configuration, use the **show mirror** command in privileged or global configuration mode.

```
show mirror
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show mirror
Information about mirror port(s)
The monitor port           : e1/4
The mirrored egress ports  : cpu,e1/1-e1/2.
The mirrored ingress ports : cpu,e1/1-e1/2.
```


show snmp community

To display the SNMP community strings configured on the switch, use the **show snmp community** command in privileged or global configuration mode.

```
show snmp community
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp community
Show snmp community information
Encryption status: OFF
index  community  priority  state  view-name
1      public      ro       permit iso
2      private     rw       permit iso
```

Related Commands

Command	Description
snmp-server community	Sets the SNMP community string

show snmp contact

To display the SNMP contact string, use the **show snmp contact** command in privileged or global configuration mode.

```
show snmp contact
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp contact  
Manager contact information : http://
```

Related Commands

Command	Description
snmp-server contact	Sets the SNMP manager contact information

show snmp engineid

To display the identification of the local SNMP engine and all remote engines that have been configured on the device, use the **show snmp engineid** command in privileged or global configuration mode.

```
show snmp engineid {local | remote }[engineid]
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following is a sample output of the **show snmp engineid local** command

```
Device#show snmp engineid local
Local engine id: : 134640000000000000000000
```

Related Commands

Command	Description
snmp-server engineid	Configures engine ID on the device.

show snmp group

To display the different SNMP group configurations, use the **show snmp group** command in privileged or global configuration mode.

```
show snmp group
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Usage Guidelines Use this command to view the names of configured SNMP groups, the security models being used, and the different views configured under each group.

Example

```
Device#show snmp group
groupname: g3
securitymodel: 3 auth
readview: iso
writeview: iso
notifyview: no specified notifyview
context: default value(NULL)

groupname: initial
securitymodel: 3 noauthpriv
readview: iso
writeview: iso
notifyview: iso
context: default value(NULL)

groupname: initial
securitymodel: 3 auth
readview: iso
writeview: iso
notifyview: iso
context: default value(NULL)

group snmp3 number:3
```

Related Commands

Command	Description
snmp-server group	Configures an SNMP group

show snmp host

To display the recipient details for the SNMP trap notifications, use the **show snmp host** command in privileged or global configuration mode.

```
show snmp host
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp host
Show SNMP trap host information
SNMP host ip security version
10.75.166.19 public 2c
```

Related Commands

Command	Description
snmp-server host	Configures the recipient for the SNMP notifications.

show snmp location

To display the SNMP manager location string, use the **show snmp location** command in privileged or global configuration mode.

```
show snmp location
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp location  
Switch location information : sample sysLocation factory default
```

Related Commands

Command	Description
snmp-server location	Sets the SNMP manager location string.

show snmp mib

To display the Management Information Base (MIB) module instance identifiers, use the **show snmp mib** command in privileged or global configuration mode.

```
show snmp mib [module module-name]
```

Syntax Description	module <i>module-name</i>	Specifies the MIB module object instance identifier
Command Default	None	
Command Modes	Privileged (#) Global Configuration (config)	
Usage Guidelines	SNMP MIB is a repository for information about device parameters and network data. Collections of related objects are defined in MIB modules. The show snmp mib command displays the instance identifiers for all the MIB objects on the system. The MIB module table names are registered when the system initializes.	



Note The **show snmp mib** command generates a high volume of output if SNMP is enabled on your system.

Example

The following is a sample output that shows the details of the **gbnL2PppoePlus** MIB module:

```
Device#show snmp mib module gbnL2PppoePlus

gbnL2PppoePlus:pppoeplusType-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.2.0]
gbnL2PppoePlus:pppoeplusFormat-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.3.0]
gbnL2PppoePlus:pppoeplusDelimiter-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.4.0]
gbnL2PppoePlus:pppoeplusCircuitidOrder-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.5.0]
gbnL2PppoePlus:pppoeplusCircuitidString-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.6.0]
gbnL2PppoePlus:pppoeplusRemoteidOrder-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.7.0]
gbnL2PppoePlus:pppoeplusRemoteidString-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.8.0]
gbnL2PppoePlus:pppoeplusPortsIndex-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.1.1]
gbnL2PppoePlus:pppoeplusPortsOnOff-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.2.1]
gbnL2PppoePlus:pppoeplusPortsTrust-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.3.1]
gbnL2PppoePlus:pppoeplusPortsDropPadi-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.4.1]
gbnL2PppoePlus:pppoeplusPortsDropPado-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.5.1]
gbnL2PppoePlus:pppoeplusPortsStrategy-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.6.1]
gbnL2PppoePlus:pppoeplusPortsCircuit-[1.3.6.1.4.1.9.6.1.120.1.2.4.6.9.1.7.1]
```

show snmp name

To display the SNMP system name, use the **show snmp name** command in privileged or global configuration mode.

```
show snmp name
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp name  
system name : 2
```

Related Commands

Command	Description
snmp-server name	Sets the SNMP system name.

show snmp notify

To display the configured SNMP notifications on the system, use the **show snmp notify** command in privileged or global configuration mode.

```
show snmp notify
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp notify
Name      Type  State
bridge    trap  enabled
gbn       trap  enabled
gbnsavecfg trap  enabled
interfaces trap  enabled
rmon      trap  enabled
snmp      trap  enabled
if-ethernet Link-Trap
g0/1      enabled
g0/2      enabled
g0/3      enabled
g0/4      enabled
g0/5      enabled
g0/6      enabled
g0/7      enabled
g0/8      enabled
e1/1      enabled
e1/2      enabled
e1/3      enabled
e1/4      enabled
e2/1      enabled
e2/2      enabled
```

Related Commands	Command	Description
	snmp-server trap-source	Configures an the interface that originates SNMP traps.
	snmp-server enable	Enables SNMP notifications

show snmp user

To display information about the configured SNMP users, use the **show snmp user** command in privileged or global configuration mode.

```
show snmp user
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp user
User name: u3
Engine ID: 13464000000000000000000000000000
Authentication Protocol: HMACMD5AuthProtocol
Group-name: g3
Validation: valid

User name: initialmd5
Engine ID: 13464000000000000000000000000000
Authentication Protocol: HMACMD5AuthProtocol
Group-name: initial
Validation: valid

User name: initialsha
Engine ID: 13464000000000000000000000000000
Authentication Protocol: HMACSHAAuthProtocol
Group-name: initial
Validation: valid

User name: initialnone
Engine ID: 13464000000000000000000000000000
Authentication Protocol: NoauthProtocol
Group-name: initial
Validation: valid

user number:4
```

Related Commands

Command	Description
snmp-server user	Configures an SNMP user in a group.

show snmp view

To display the details of an SNMP view, use the **show snmp view** command in privileged or global configuration mode.

```
show snmp view[view-name]
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

```
Device#show snmp view
View Name  Type      Subtree
iso        Include   1
sysview    Include   1.3.6.1.2.1.1
internet   Include   1.3.6.1

view number:3
```

Related Commands

Command	Description
snmp-server view	Configures an SNMP view

shutdown

To shut down a VLAN interface, use the **shutdown** command in the VLAN configuration mode. You can cancel the shutdown of the VLAN interface by using the **no** form of the command.

shutdown

no shutdown

Syntax Description	shutdown Shuts down the VLAN interface.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	VLAN configuration
----------------------	--------------------

Examples

The following example shows how to shut down a VLAN interface:

```
Device(config-if-vlanif) # shutdown
```

snmp-server

To enable or disable Simple Network Management Protocol (SNMP) on a device use the **snmp-server** command in the global configuration mode.

```
snmp-server {enable [informs |traps][bridge | gbn | gbnsavecfg | interfaces
| rmon | snmp]] | disable}
```

Syntax Description

enable	Enables SNMP traps on the device
disable	Disables the SNMP server
informs	Configures SNMP inform request
traps	Configures SNMP trap notifications
<ul style="list-style-type: none"> • bridge Specifies the type of SNMP informs or traps notifications to be enabled. • gbn If you do not specify the type of SNMP inform or trap, all traps and informs that are configured on your system are enabled. • gbnsavecfg • interfaces • rmon • snmp 	

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

The **snmp-server enable** command is optional. SNMP traps and informs are enabled by default, on the device. Use the **snmp-server disable** command to disable SNMP traps or informs on the device.

Example

```
Device#configure terminal
Device(config)#snmp-server enable traps gbn
```

snmp-server community

To set up the community access string to permit access to the Simple Network Management Protocol (SNMP) use the **snmp-server community** command in the global configuration mode. To remove the configured community string, use the **no** form of the command.

```
[no] snmp-server community {name|md5 }{ro|rw}{deny|permit}[view view-name]
```

Syntax Description

name	SNMP community name that consists of 1 to 32 characters
md5	Uses md5 for authentication
ro	Specifies read-only access. Authorized management stations can retrieve only MIB objects
rw	Specifies read-write access. Authorized management stations can both retrieve and modify MIB objects.
permit	Specifies community name string is active
deny	Specifies community name string is not activated
view <i>view-name</i>	(Optional) Specifies a previously defined view. The view defines the objects available to the SNMP community. Default view is ISO.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

The SNMP community name authenticates access to MIB objects. In order for the NMS to access the switch, the community name definitions on the NMS must match at least one of the community name definitions on the switch.

Examples

The following example shows how to set the read/write community string to group1:

```
Device#configure terminal
Device(config)#snmp-server community group1 rw permit
```

The following example shows how to assign the string manager to SNMP and allow read-only access to the objects in the view called restricted:

```
Device(config)#snmp-server community group1 ro permit view restricted
```

The following example shows how to remove the community 1:

```
Device(config)#no snmp-server community 1
```

snmp-server community encrypt

To enable or disable encryption of community access string, use the **snmp-server community encrypt** command in the global configuration mode.

```
snmp-server community encrypt {enable|disable }
```

Syntax Description	enable Enables encryption of the community name string
---------------------------	---

	disable Disables encryption of community name string
--	---

Command Default	The community name string is not encrypted.
------------------------	---

Command Modes	Global configuration (config)
----------------------	-------------------------------

Example

```
Device#configure terminal  
Device(config)#snmp-server community encrypt enable
```

snmp-server contact

To configure the SNMP manager contact information, use the **snmp-server contact** command in the global configuration mode. To remove the SNMP manager contact information, use the **no** form of the command.

```
snmp-server contact contact-information
```

Syntax Description	<i>contact-information</i> Specifies the SNMP manager contact details
---------------------------	---

Command Default	SNMP manager contact string is not set.
------------------------	---

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Example

```
Device(config)#snmp-server contact SystemOperator
```


snmp-server encrypt

To enable or disable the encryption of the password for a user, use the **snmp-server encrypt** command in the global configuration mode.

A password is encrypted by default.

```
snmp-server encrypt {enable|disable}
```

Syntax Description	enable Enables the encryption of password
	disable Disables the encryption of password
Command Default	None
Command Modes	Global configuration (config)

Example

```
Device#configure terminal  
Device(config)#snmp-server encrypt disable
```

snmp-server engineid

To configure the Simple Network Management Protocol (SNMP) engine ID on a local device or a remote device, use the **snmp-server** command in the global configuration mode.

```
snmp-server engineid local engineid | remote ip-address [udp-portport-num] engineid
```

Syntax Description	
local <i>engineid</i>	Specifies the engine ID of the local device
remote <i>ip-address</i>	Specifies the engine ID of the local device
udp-port <i>port-num</i>	Specifies the UDP port on the remote device

Command Default None

Command Modes Global configuration (config)

Usage Guidelines An SNMP engine ID is a unique string that identifies the device, for administrative purposes.

The engine ID of the local SNMP device is 134640000000000000000000. You can modify the local engine ID, but not delete it. You can create and delete the engine ID of a remote SNMP device. If you delete a remote engine ID, the corresponding users are also deleted. You can configure a maximum number of 32 remote engine IDs.

Example

```
Device#configure terminal
Device(config)#snmp-server engineid remote 172.16.20.4 1
```

snmp-server group

To configure an SNMP group that enables authentication for the members of a specified view, use the **snmp-server group** command in the global configuration mode. To remove the configured authentication for the SNMP group, use the **no** form of the command.

```
[no] snmp-server group group-name3 [auth |noauthpriv |priv] read read-view
write write-view notify notify-view
```

Syntax Description	
auth	Specifies that packets are authenticated but not encrypted.
noauthpriv	Specifies that packets are not authenticated.
priv	Specifies that packets are authenticated and not encrypted.
read <i>read-view</i>	(Optional) Specifies a read view for the SNMP group. This view enables you to view only the contents of the agent. If a <i>read-view</i> is not specified, it defaults to the iso view and auth security level.
write <i>write-view</i>	(Optional) Specifies a write view for the SNMP group. This view enables you to enter data and configure the contents of the agent. write-view does not have defaults. Hence it is mandatory to specify it if write is configured.
notify <i>notify-view</i>	(Optional) Specifies a notify view for the SNMP group. This view enables you to specify a notification or a trap. notify-view does not have defaults. Hence it is mandatory to specify <i>notify-view</i> if notify is configured.
Command Default	None
Command Modes	Global configuration (config)

Examples

```
Device#configure terminal
Device(config)#snmp-server group gl 3 priv write dept-view
```

snmp-server host

To configure the recipient of an SNMP notification operation, use the **snmp-server host** command in the global configuration mode. To remove the configured recipient for the SNMP group, use the **no** form of the command.

```
[no] snmp-server host {inet6 ipv6-address | ipv4-address} {version {1 | 2c | 3{auth
| noauthpriv | priv }}} security-name [udp-port udp-port-num] [ notify-type[bridge
| gbn | gbnsavecfg | interfaces | rmon | snmp] ]
```

Syntax Description

inet6 <i>ipv6-address</i>	Specifies the IPv6 address of the recipient of SNMP traps
<i>ipv4-address</i>	Specifies the IPv4 address of the recipient of SNMP traps
version {1 2c 3{ auth noauthpriv priv }	Specifies the SNMP version: 1, 2c, 3. If you specify SNMP version 3, ensure that you specify the security levels too: <ul style="list-style-type: none"> • auth: Enables MD5 and SHA packet authentication • noauth: Specifies that the noAuthNoPriv security level applies to this host. This is the default security level for SNMPv3. • priv: Enables Data Encryption Standard (DES) packet encryption.
<i>security-name</i>	Defines a name for this configuration.
udp-port <i>udp-port-num</i>	Specifies the UDP port on the host device.
notify-type	Specifies the type of notification to be sent to the host: <ul style="list-style-type: none"> • bridge • gbn • gbnsavecfg • interfaces • rmon • snmp

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

Use the **snmp-server host** command to configure a recipient for the SNMP notifications. If this command is not configured, no notifications are sent. **snmp-server host** command is used in conjunction with the **snmp-server enable** command. For a host to receive most notifications, at least one **snmp-server enable** command and the **snmp-server host** command for that host must be enabled.

Examples

```
Device#configure terminal  
Device(config)#snmp-server host 192.168.5.1 version 2c test-sec udp-port 4
```

snmp-server location

To set the SNMP server location string, use the **snmp-server location** command in the global configuration mode. To remove the SNMP server location information, use the **no** form of the command.

```
[no] snmp-server location syslocation
```

Syntax Description	<i>syslocation</i> String that describes the SNMP server location
---------------------------	---

Command Default	No system location string is set.
------------------------	-----------------------------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Example

```
Device(config)#snmp-server location Building13
```

snmp-server max-packet-length

To configure the maximum size of SNMP packets, use the **snmp-server max-packet-length** command in the global configuration mode. To remove the maximum packet length configuration for SNMP packets, use the **no** form of the command.

```
[no] snmp-server max-packet-length length
```

Syntax Description

length Specifies the maximum packet length for SNMP packets. The value ranges from 484 bytes through 8000 bytes.

Default value is 1000 bytes.

Command Default

Maximum packet length is set to 1000 bytes.

Command Modes

Global Configuration (config)

Example

```
Device(config)#snmp-server max-packet-length 1200
```

snmp-server name

To set the SNMP system name string, use the **snmp-server name** command in the global configuration mode. To remove the SNMP server name information, use the **no** form of the command.

```
[no] snmp-server name sysname
```

Syntax Description	<i>sysname</i> String that describes the SNMP server name
---------------------------	---

Command Default	No system name string is set.
------------------------	-------------------------------

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Example

```
Device(config)#snmp-server name Building13Server
```


snmp-server trap-source

To specify the interface from which the Simple Network Management Protocol (SNMP) trap should originate, use the **snmp-server trap-source** command in the global configuration mode. To remove the source of SNMP trap, use the **no** form of the command.

```
snmp-server trap-source {inet6 | vlan-interface vlan-id | loopback-interface interface | vlan-interface vlan-id}
```

Syntax Description		
	inet6	Specifies the IPv6 address family
	vlan-interface <i>vlan-id</i>	Specifies the VLAN id to which the VLAN interfaces that originate the traps, belong.
	loopback-interface <i>interface</i>	Specifies the loopback interface that is configured as the origin of the traps.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines Use this command to monitor notifications from a particular interface.

An SNMP trap or inform that is sent from an SNMP server has a notification address of the interface it went out of at that time.

Example

```
Device#configure terminal
Device(config)#snmp-server trap-source vlan-interface 3
```

snmp-server user

To configure a new user to an SNMP group, use the **snmp-server user** command in the global configuration mode. To remove a configured user from an SNMP group, use the **no** form of this command.

```
[no]snmp-server user username group-name [remote ipaddress [udp-port port-number ]
] [auth {md5 |sha } {auth-password {authpassword |encrypt-authpassword
password} |auth-key{authkey | encrypt-authkeypassword}}][privdes {priv-key{key|
encrypt-privkeykey}| priv-password{password | encrypt-privpasswordprivpassword}
} ] ]
```

Syntax Description	
<i>username</i>	Name of the user created
<i>group-name</i>	Name of the SNMP group to which the user belongs
remote	(Optional) A remote SNMP entity to which the user belongs
<i>ipaddress</i>	(Optional) IP address of the remote SNMP host.
udp-port <i>port-number</i>	(Optional) UDP port on the remote port
auth	(Optional) Specifies which authentication level should be used.
md5	(Optional) Specifies the HMAC-MD5-96 authentication level
sha	(Optional) Specifies the HMAC-SHA-96 authentication level
auth-password <i>authpassword</i>	Specifies the authentication password
auth-key <i>authkey</i>	Specifies the authentication key
priv	(Optional) Specifies the use of the User-based Security Model (USM) for SNMP version 3 for SNMP message level security.
des	(Optional) Specifies the use of the 56-bit Digital Encryption Standard (DES) algorithm for encryption.
<i>priv-key</i>	(Optional) String that specifies the privacy user password.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines The **snmp-server user** command configures a user for a local engine or a remote engine.

The following three users exist by default and they are reserved as the system users:

- initialmd5
- initialsha
- initialnone

To configure a remote engine user, specify remote ipaddress. If you do not specify remote ipaddress, a local engine user is configured.

For a remote user, the default port number is 162. To configure a different remote port, specify a udp-port port-number .

Three levels of user privileges can be specified:

- **noauthpriv** : Authentication and password encryption are not required. It is the default configuration.
- **auth**: Authentication is required but password encryption is not required.
- **authpriv**: Authentication and password encryption, both are required.



Note The user security level should be the same as the corresponding group security level.

Example

```
Device#configure terminal
Device(config)#snmp-server user u3 g3 auth md5 auth-password password1
```

snmp-server view

To create or update an SNMP server view, use the **snmp-server view** command in the global configuration mode. To remove the configured SNMP server view, use the **no** form of the command.

```
[no] snmp-server view view-name oid-subtree {include | exclude}
```

Syntax Description

oid-subtree Object identifier (OID) of the ASN.1 subtree that is either included or excluded from the view.
A string that can have upto to 64 characters.

view-name Name of the SNMP view that is to be created.

exclude Excludes the OID specified in the *oid-subtree* argument from the SNMP view.

include Includes the OID specified in the *oid-subtree* argument in the SNMP view.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

Use this command to create a view that is a list of SNMP object trees, which you can access. The **iso**, **internet** and **sysview** views exist by default. You cannot delete or modify the **internet** view.

Examples

The following example creates a view named **oneview** and excludes all objects of the subtree:

```
Device#configure terminal
Device(config)#snmp-server view oneview 1.3 exclude
```



PART VI

Quality of Service

- [Quality of Service, on page 285](#)



Quality of Service

- [bandwidth egress rate](#), on page 286
- [clear traffic-statistic](#), on page 287
- [queue-scheduler cos-map](#), on page 288
- [queue-scheduler strict-priority](#), on page 289
- [queue-scheduler sp-wrr](#), on page 290
- [queue-scheduler wrr](#), on page 291
- [queue-scheduler dscp-map](#), on page 292
- [rate-limit](#), on page 293
- [show bandwidth egress](#), on page 294
- [show qos-info all](#), on page 295
- [show qos-interface](#) , on page 297
- [show queue-scheduler](#), on page 298
- [storm-control](#), on page 300
- [traffic-copy-to-cpu](#), on page 301
- [traffic-redirect](#), on page 302
- [traffic-statistic](#), on page 303

bandwidth egress rate

To set the bandwidth limit on the outbound traffic on a port, use the **bandwidth egress rate** command in the interface configuration mode. To remove the configured bandwidth limit, use the **no** form of the command.

```
[no]bandwidth egress target-rate [ target-burst-rate ]
```

Syntax Description

target-rate

Specifies the bandwidth limit in Kbps.

The target rate must be a multiple of 64K and should range between 2048 and 2608832 Kbps:

It should be 2048 to 1024000 Kbps for a GE port, 2048 to 2608832 Kbps for a PON port, and 2048 to 10240000 for a 10GE port.

target-burst-rate

Specifies the burst transmission rate.

Target burst rate (Kbps) must be a multiple of 64K. Values can range between 2048 through 2608832.

Command Default

None

Command Modes

Interface Configuration (config-if)

Example

```
Device#configure terminal
Device(config)#interface e1/1

Device(config-if-ethernet-1/1)#bandwidth egress 2048
```


clear traffic-statistic

To remove the traffic statistics records, use the **clear traffic-statistic** command in the global configuration mode.

```
clear traffic-statistic { [all | [ip-group {num | name} [subitem subitem] ] ] [link-group {num | name} [subitem subitem] ] ] }
```

ip-group { num name }	Specifies a standard or extended ACL.
link-group { num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **clear traffic-statistic all** command to remove all traffic statistics records.

Use the **clear traffic-statistic ip-group** or **clear traffic-statistic link-group** command to remove the traffic statistics records that are generated for the specified access control list.

Example

```
Device#configure terminal
Device(config)#clear traffic-statistic ip-group 3
```

queue-scheduler cos-map

To map the 802.1p priorities to the hardware queue, use the **queue-scheduler cos-map** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler cos-map [queue-class] [priority]
```

Syntax Description	<i>queue-class</i>	Specifies the hardware queue value which ranges from 0 through 7.
	<i>priority</i>	Specifies the 802.1p priority. The value ranges from 0 to 7.

Command Default Strict Priority scheduling is followed by default.

Command Modes Global configuration (config)

Usage Guidelines 802.1p is used to classify the outgoing traffic at the egress port based on the 802.1p priority. For each message that enters the switch, the system maps the specific hardware queue priority according to the 802.1p priority of the message.

Changing the mapping relation between 802.1p priority and hardware queues changes the mapping relation between 802.1p priorities and output queues.

If two 802.1p priorities are mapped to the same hardware priority queue, messages of the two 802.1p priorities cannot be forwarded with 1:1 forwarding.

Use the **queue-scheduler cos-map** command to set the 802.1p mapping with hardware queue priority.

Example

The following example shows how to map packets with priority 0 to queue 1:

```
Device#configure terminal
Device(config)#queue-scheduler cos-map 1 0
Config successfully.
```

queue-scheduler strict-priority

To configure the strict priority queue scheduling algorithm on the queue scheduler, use the **queue-scheduler strict-priority** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler strict-priority
```

Command Default Strict Priority scheduling is followed by default.

Command Modes Global configuration (config)

Usage Guidelines Strict-Priority Queuing is designed for critical business applications wherein the services are prioritized in order to reduce the latency of response when a congestion occurs. The priority queue classifies all messages into eight class: 7,6,5,4,3,2,1, and 0, in the order of priority. The group of critical services is put into the higher priority queue and non-critical business group is put into the lower priority queue. The higher priority queue is first emptied before the messages in the lower priority queue are sent. Messages in the group of non-critical business are transmitted in the idle gap of handling critical business data.

Example

```
Device#configure terminal
Device(config)#queue-scheduler strict-priority
```

queue-scheduler sp-wrr

To configure strict priority and weighted round robin (WRR) queue scheduling algorithm on the queue scheduler, use the **queue-scheduler sp-wrr** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler sp-wrr {w1| w2| w3| w4| w5| w6| w7| w8}
```

Syntax Description

wx

Specifies the weight of the queue represented by *x*.

where *x* can be 1, 2, 3, 4, 5, 6, 7,8

For example, *w1* represents the weight of the first queue. *w2* represents the weight of the second queue.

Command Default

Strict Priority scheduling is followed by default.

Command Modes

Global configuration (config)

Usage Guidelines

Strict-Priority and WRR queue scheduling combines the algorithms of strict-priority and Weighted round robin scheduling. If the weight of the queue is set to 0, the queue follows the Strict-Priority queuing algorithm to send messages. A non-zero value of the weight puts the queue to the WRR scheduling mechanism.

Example

```
Device#configure terminal
Device(config)#queue-scheduler sp-wrr 1 2 3 4 5 6 7 8
```

queue-scheduler wrr

To configure the weighted round robin (WRR) queue scheduling algorithm on the queue scheduler, use the **queue-scheduler wrr** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler wrr{ w1| w2| w3| w4| w5| w6| w7| w8}
```

Syntax Description

<code>wx</code>	Specifies the weight of the queue represented by x.
where x can be 1, 2, 3, 4, 5, 6, 7,8	For example, w1 represents the weight of the first queue. w2 represents the weight of the second queue.

Command Default

Strict Priority scheduling is followed by default.

Command Modes

Global configuration (config)

Usage Guidelines

Weighted Round Robin (WRR) queue scheduling divides each port into eight output queues: 7, 6, 5, 4, 3, 2, 1, and 0, in the that order of priority, with 7 being the highest priority. All the queues are scheduled by turns and each queue gets a certain service time. Each queue of WRR can be configured with weighted values of w7, w6, w5, w4, w3, w2, w1, or w0. The weighted value represents the weight of the resource.

An advantage of WRR queuing is that although multiple queues are scheduled by polling, each queue is not assigned a fixed time slot. If a queue is empty, it immediately switches to the next queue schedule. So, the bandwidth and resources of that queue can be fully utilized

Example

```
Device#configure terminal
Device(config)#queue-scheduler wrr 1 2 3 4 5 6 7 8
```

queue-scheduler dscp-map

To configure the strict priority queue scheduling algorithm on the queue scheduler, use the **queue-scheduler dscp-map** command in the global configuration mode. To restore the default queue scheduler settings, use the **no** form of the command.

```
[no ]queue-scheduler dscp-map [dscp-value] [priority]
```

Syntax Description

<i>dscp-value</i>	Specifies the DSCP value which ranges from 0 through 63.
<i>priority</i>	Specifies the 802.1p priority. The value ranges from 0 to 7.

Command Default

Strict Priority scheduling is followed by default.

Command Modes

Global configuration (config)

Usage Guidelines

DSCP mapping is disabled by default. To enable DSCP mapping use the **queue-scheduler dscp-map** command. DSCP allows 64 priority values whereas 802.1p (hardware queue) allows only eight priority values. By default, the following is the mapping between DSCP and 802.1p:

DSCP	802.1p
0-7	0
8-15	1
16-23	2
24-31	3
32-39	4
40-47	5
48-55	6
56-63	7

Example

The following example shows how to map DSCP 56 to 802.1p priority 6:

```
Device#configure terminal
Device(config)#queue-scheduler dscp-map

Device(config)#queue-scheduler dscp-map 56 6
```

rate-limit

To set the traffic rate limit in inbound or outbound direction, use the **rate-limit** command in the global configuration mode. To remove the rate limit, use the **no** form of the command.

```
[no]rate-limit {input | output} { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} [subitem subitem] ] }target-rate
```

input	Specifies the rate limit in inbound direction.
output	Specifies the rate limit in outbound direction.
ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.
<i>target-rate</i>	Specifies target rate which is the traffic rate limit in Kbps. Target rate should be a multiple of 64, and can range from 64 to 1048512.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **rate-limit input** command to limit the traffic rate in the inbound direction.

Use the **rate-limit output** command to limit the traffic rate in the outbound direction.

Use this command to monitor the rate of traffic that enters a device. If the traffic exceeds a certain threshold, you can define policies to take suitable measures.

Example

The following example sets the inbound traffic rate limit to 100 Kbps:

```
Device#configure terminal
Device(config)#rate-limit input ip-group 3 100
```

show bandwidth egress

To display the rate limit and the burst rate that are set for the egress interface, use the **show bandwidth egress** command in privileged or global configuration mode.

```
show bandwidth egress[ interface {ethernet | gpon }port-num]
```

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Example

The following is a sample output of the **show bandwidth** command.

```
Device(config)#show bandwidth egress
g0/1: bandwidth egress
    limit rate: / Kbps      burst: / Kbps

g0/2: bandwidth egress
    limit rate: / Kbps      burst: / Kbps

g0/3: bandwidth egress
    limit rate: / Kbps      burst: / Kbps
....
...
e2/2: bandwidth egress
    limit rate: / Kbps      burst: / Kbps
```

Related Commands

Command	Description
bandwidth egress rate	Sets the bandwidth limit on the outbound traffic on a port.

show qos-info all

To display the parameters that are set for Quality of Service (QoS), use the **show qos-info** command in privileged or global configuration mode.

```
show qos-info {all| traffic-copy-to-cpu | mirrored-to | traffic-priority
| traffic-redirect | traffic-statistic| statistic }
```

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Usage Guidelines

Use the **show qos-info all** command to display all the configured QoS parameters.

Use the **show qos-info statistic** command to display all the statistics for QoS parameters.

Use the **show qos-info traffic-copy-to-cpu** command to display the parameter settings for copying messages to the CPU.

Use the **show qos-info mirrored-to** command to display the parameter settings for traffic mirroring.

Use the **show qos-info traffic-priority** command to display the parameter settings for traffic priority.

Use the **show qos-info traffic-redirect** command to display the parameter settings for message redirection.

Example

```
Device#show qos-info all
mirrored-to(max 3 dest port):
traffic-priority:
traffic-redirect:
traffic-statistic:
traffic-copy-to-cpu:
```

Here is a sample output for the **show qos-info statistic** command:

```
Device#show qos-info statistic
mirrored-to:
total mirrored-to rules          : 0 rules

traffic-priority:
total traffic-priority rules     : 0 rules

traffic-redirect:
total traffic-redirect rules     : 0 rules

traffic-statistic:
total traffic-statistic rules    : 0 rules

traffic-copy-to-cpu:
total traffic-copy-to-cpu rules  : 0 rules

total mirrored-to rules          : 0 rules
total traffic-priority rules     : 0 rules
```

show qos-info all

```
total traffic-redirect rules      : 0 rules
total traffic-statistic rules    : 0 rules
total traffic-copy-to-cpu rules  : 0 rules
total qos-info rules             : 0 rules
```

Related Commands

Command	Description
traffic-copy-to-cpu	Copies all packets to the CPU.
traffic-statistic	Configures the system to collect the traffic statistics
traffic-redirect	Redirects the traffic to a specified interface or to the CPU.

show qos-interface

To display all the policies set for Quality of Service (QoS) on the interface, use the **show qos-interface** command in privileged or global configuration mode.

```
show qos-interface {all| rate-limit | statistic
```

Command Default

None

Command Modes

Privileged (#)

Global Configuration (config)

Usage Guidelines

Use the **show qos-interface all** command to display all the QoS parameters for the interface.

Use the **show qos-interface rate-limit** command to display the rate limit parameters for the interface.

Use the **show qos-interface statistic** command to display the statistics of rate limit for all interfaces.

Example

The following is a sample output of the **show qos-interface all** command:

```
Device#show qos-interface all
total qos-interface rules : 0 rules
```

The following is a sample output of the **show qos-interface rate-limit** command:

```
Device#show qos-interface rate-limit
total rate-limit rules : 0 rules
```

The following is a sample output of the **show qos-interface statistic** command:

```
Device#show qos-interface satistic
total qos-interface rules : 0 rules
```

show queue-scheduler

To display information about the queue scheduler, use the **show queue-scheduler** command in privileged or global configuration mode.

```
show queue-scheduler [ cos-map | dscp-map ]
```

Syntax Description	cos-map	Specifies the 802.1p and hardware queue mapping.
	dscp-map	Specifies the DSCP and 802.1p value mapping.

Command Default None

Command Modes Privileged (#)
Global Configuration (config)

Usage Guidelines Use the **show queue-scheduler** command to display information about the queue scheduler parameters.

Use the **show queue-scheduler cos-map** command to display information about the mapping between 802.1p and hardware.

Use the **show queue-scheduler dscp-map** command to display information about the mapping between 802.1p values and DSCP.

Examples

Following are sample outputs for the **show queue-scheduler** commands.

```
Device#show queue-scheduler
Queue scheduler status : enable
Queue scheduler mode   : SP (Strict Priority)
```

```
Device#show queue-scheduler cos-map
Information about map of cos:
802.1P Priority  Queue of class
-----
0                0
1                1
2                2
3                3
4                4
5                5
6                6
7                7
```

```
Device#show queue-scheduler dscp-map
dscp-pri has been disabled.
```

Related Commands

Command	Description
queue-scheduler wrr	Configures the weighted round robin scheduling mode.

Command	Description
queue-scheduler strict-priority	Configures the strict priority scheduling mode.
queue-scheduler dscp-map	Maps DSCP values to hardware priority values.
queue-scheduler cos-map	Maps 802.1p values to hardware queue map.

storm-control

To enable traffic storm control on an interface and to configure a threshold for the number of packets on the port, use the **storm-control** command in the interface configuration mode. To remove the storm control configuration on an interface, use the **no** form of the command.

```
[no]storm-control {broadcast | multicast | unicast } target-rate
```

Syntax Description		
	broadcast	Specifies broadcast traffic for storm control.
	multicast	Specifies multicast traffic for storm control.
	unicast	Specifies unicast traffic for storm control.
	<i>target-rate</i>	Specifies a threshold limit for the number of packets on the port. Value can range from 64 to 32000000 packets per second (pps) Default value is 49984 pps

Command Default None

Command Modes Interface Configuration (config-if)

Example

```
Device#configure terminal
Device(config)#interface e1/1

Device(config-if-ethernet-1/1)#storm-control unicast 512
Device(config-if-ethernet-1/1)#storm-control multicast 256
Device(config-if-ethernet-1/1)#storm-control broadcast 128
```

traffic-copy-to-cpu

To copy the packets that match an ACL to CPU, use the **traffic-copy-to-cpu** command in the global configuration mode. To remove the traffic copy configuration, use the **no** form of the command.

```
[no] traffic-copy-to-cpu { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} [subitem subitem] ] }
```

ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.

Command Modes Global Configuration (config)

Command Default None

Example

The following example shows how to copy packets that match the subitem number 2 of ACL numbered 3 to CPU:

```
Device#configure terminal
Device(config)#traffic-copy-to-cpu ip-group 3 subitem 2
```

traffic-redirect

To redirect the messages sent to a port, use the **traffic-redirect** command in the global configuration mode. To remove the redirect configuration, use the **no** form of the command.

```
[no] traffic-redirect { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} [subitem subitem] ] [interface interface-num | cpu] }
```

ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem subitem	Specifies the sub item in the ACL.
interface interface-num	Specifies the interface to which the traffic is redirected.
cpu	Specifies that the traffic is redirected to the CPU.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use the **traffic-redirect** command to forward the traffic to an egress port or a CPU, using the specified access control list (ACL) sub items.

Example

The following example shows how to redirect traffic to the ethernet 1/1 interface:

```
Device#configure terminal
Device(config)#traffic-redirect link-group link1 interface ethernet 1/1
```


traffic-statistic

To configure a device to collect traffic statistics, use the **traffic-statistic** command in in global configuration mode. To remove the traffic statistic configuration, use the **no** form of the command.

```
[no] traffic-statistic { [ip-group {num | name} [subitem subitem] ] [link-group {num | name} ] [subitem subitem] ] }
```

ip-group {num name }	Specifies a standard or extended ACL.
link-group {num name }	Specifies a Layer 2 ACL.
subitem <i>subitem</i>	Specifies the sub item in the ACL.

Command Modes Global Configuration (config)

Command Default None

Usage Guidelines Use this command to configure the device to collect traffic statistics. This command displays a cumulative value of the count of the number of packets that matched the ACL rule.

If you reconfigure traffic statistics, the previous information is lost.

Example

```
Device#configure terminal
Device(config)#traffic-statistic ip-group 3
```




PART **VII**

Security

- [Security](#), on page 307



Security

- [absolute time-range](#), on page 309
- [access-limit](#), on page 310
- [access-list match-order](#), on page 311
- [access-group](#), on page 312
- [access-list numbered standard](#), on page 313
- [access-list standard](#), on page 314
- [accounting-on](#), on page 315
- [acct-secret-key](#), on page 316
- [anti-dos ip fragment](#), on page 317
- [anti-dos ip ttl](#), on page 318
- [arp anti-spoofing](#), on page 319
- [arp anti-spoofing deny-disguiser](#), on page 320
- [arp anti-spoofing unknown](#), on page 321
- [arp anti-spoofing valid-check](#), on page 322
- [arp anti-flood](#), on page 323
- [channel-group spanning-tree cost](#), on page 325
- [clear cpu-classification](#), on page 326
- [clear cpu-statistics](#), on page 327
- [cpu-car](#), on page 328
- [cpu-limit](#), on page 329
- [dhcp anti-attack](#), on page 330
- [discard-bpdu](#), on page 332
- [access-list extended name](#), on page 333
- [access-list numbered extended](#), on page 334
- [host-guard bind ip](#), on page 336
- [ip route](#), on page 337
- [access-list link name](#), on page 338
- [access-list link number](#), on page 339
- [local-user](#), on page 341
- [nas-ipaddress](#), on page 342
- [no ip route static all](#), on page 343
- [periodic time-range](#), on page 344
- [preemption-time](#), on page 345

- {primary-acct-ip | second-acct-ip}, on page 346
- {primary-auth-ip | second-auth-ip}, on page 347
- radius, on page 348
- realtime-account, on page 351
- no access-list , on page 352
- scheme, on page 353
- show access-list config, on page 354
- show access-list runtime, on page 355
- show anti-dos, on page 356
- show arp anti-flood, on page 357
- show arp anti interface, on page 359
- show cpu-car, on page 360
- show cpu-classification, on page 361
- show cpu-limit, on page 362
- show cpu-statistics, on page 363
- show cpu-utilization, on page 364
- show dhcp anti-attack, on page 365
- show discard-bpdu, on page 366
- show dot1x, on page 367
- show ip route, on page 372
- show radius, on page 373
- show shutdown-control interface, on page 375
- show spanning-tree interface, on page 376
- shutdown-control-recover, on page 378
- spanning-tree (global configuration), on page 379
- spanning-tree (interface configuration), on page 382
- time-range, on page 385
- username-format, on page 386

absolute time-range

To configure an absolute time range that specifies when an access control list (ACL) is in effect, use the **absolute** command in the time-range configuration mode. To remove the absolute time-range, use the **no** form of the command.

```
[no]absolute [start time-range ][endtime-range ]
```

Syntax Description	<i>time-range</i>	Specifies the time in the format of HH:MM:SS YYYY/MM/DD
Command Modes	Global Configuration (config)	
Command Default	None	

Example

```
Device#configure terminal  
Device(config)#time-range weekends  
Device(config-timerange-weekends)#absolute start 04:50:30 2020/04/01 end 09:50:40 2020/04/30
```

access-limit

To enable or disable the number limit of authentication users in the domain and set the number limit of allowed users, use the **access-limit** command in AAA configuration mode.

access-limit { **enable** *allowed-user-number-limit* | **disable** }

Syntax Description		
enable		Enables the number limit of authentication users in the domain.
<i>allowed-user-number-limit</i>		Sets the number limit of allowed users in the domain. The range is from 1 to 640.
disable		Disables the number limit of authentication users in the domain.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to enable the number limit of authentication users in the domain and set the number limit of allowed users:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# exit
Device(config-aaa)# default domain-name enable eee
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# access-limit enable 3
Succeed to set MaxLinks of domain.
```

Example

This example shows how to disable the number limit of authentication users in the domain and set the number limit of allowed users:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# default domain-name enable eee
Succeed in setting default domain.
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# access-limit disable
Succeed to disable access limit of domain.
```


access-list match-order

To configure the access control list (ACL) matching order, use the **access-list match-order** command in the global configuration mode. The matching order decides which rule is executed.

```
access-list acl-num match-order {auto | config}
```

Syntax Description

auto Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

config Matches the ACL rules according to the configuration order.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

An ACL consists of multiple permit or deny rules. The rules may overlap or conflict. In such cases, the matching order decides which rule is executed.

Example

```
Device#configure terminal
Device(config)#access-list 2 match-order config
```

access-group

To activate an access control list that is already defined, use the **access-group** command in the global configuration mode.

```
access-group [ip-group [name | number ] ] [link-group [name | number ] ] [subitem number]
```

Syntax Description

ip-group [*name* | *number*] Specifies a predefined Standard ACL or Extended ACL.

link-group [*name* | *number*] Specifies a predefined Layer 2 ACL.
]

subitem *number* Specifies the sub item number in the ACL

Command Modes

Global Configuration (config)

Command Default

None

Usage Guidelines

After defining an Access Control List (ACL), it has to be activated to take effect. Use the **access-group ip-group** command to activate a Standard ACL or an Extended ACL. Use the **access-group link-group** command to activate a Layer 2 ACL.

Example

The following example creates a standard access control list (ACL), 10, and activates the subitem number 1 of the ACL.

```
Device#configure terminal
Device(config)#access-list 10 deny any

Device(config)#access-list 10 permit 10.1.1.5 0
Device(config)#access-group ip-group 10
```

access-list numbered standard

To define a numbered Standard Access Control List (ACL), use the **access-list** *number* command in the global configuration mode.

```
access-list num{permit |deny} { source-ipv4 | ipv6-source-prefix | any | ipv6any}
[ time-range timerange-name]
```

Syntax Description

permit	Specifies that the rule defined by the ACL is permitted.
deny	Specifies that the rule defined by the ACL is not permitted.
<i>source-ipv4</i>	Specifies the IPv4 address of the source host.
<i>ipv6-source-prefix</i>	Specifies the IPv6 prefix of the source host.
ipv6any	Specifies any IPv6 host
any	Specifies any IPv4 host
time-range <i>timerange-name</i>	Defines the specific time range to implement the ACL.

Command Default

None

Command Modes

Global configuration (config)

Usage Guidelines

The ACL is identified by the number assigned to it. You can create an ACL and assign a number to it. If you don't specify a number, the system assigns a number to the created ACL. For a Standard ACL, the numbers range from 1 through 99. You can create up to 99 Standard ACLs.

Example

```
Device#configure terminal
Device(config)#access-list 10 permit any
```

access-list standard

To create a named Standard Access Control List, use the **access-list standard** command in the global configuration mode.

```
access-list standard {num|name} [ match-order { auto | config }]
```

Syntax Description

<i>num</i>	Specifies a standard ACL. Values can range from 1 through 99.
<i>name</i>	Specifies a name for the ACL. The name is a string of alphanumeric characters, upto 32 characters in length.
match-order	Defines a matching order for the entries in the ACL.
config	Matches the ACL rules according to the configuration order in the list.
auto	Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

Command Default

None

Command Modes

Global configuration (config)

Example

```
Device#configure terminal
Device(config)#access-list standard stdacl
```

accounting-on

To configure accounting-on function, use the **accounting-on** command in AAA configuration mode.

accounting-on {**enable** *packet-number* | **disable**}

Syntax Description		
	enable	Enables accounting-on function.
	<i>packet-number</i>	The number of accounting-on packets. The range is 1 to 255.
	disable	Disables accounting-on function.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to enable the accounting-on function:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# accounting-on enable 10
Device(config-aaa)# configure success
```

acct-secret-key

To configure the shared key of the secondary RADIUS server, use the **acct-secret-key** command in AAA configuration mode. To delete the configured shared key of the secondary RADIUS server, use the **no** form of the command.

acct-secret-key*key*

no acct-secret-key

Syntax Description	Description
<i>key</i>	The shared secret key.

Command Modes	Configuration Mode
	AAA Configuration (config-aaa)

Example

This example shows how to configure the shared key of a secondary RADIUS server using the **acct-secret-key** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# acct-secret-key 1
Modify secret key of RADIUS configuration successfully
```

anti-dos ip fragment

To configure a new threshold value for IP fragmentations, use the **anti-dos ip fragment** command in global configuration mode. To restore the default threshold value, use the **no** form of the command.

anti-dos ip fragment *threshold-value*

no anti-dos ip fragment

Syntax Description		
	<i>threshold-value</i>	The maximum number of allowed The range is 0 to 800. The default value is 800.

Command Modes Global Configuration (config)

Example

This example shows how to configure a new threshold value for IP fragmentations using the **anti-dos ip fragment** command:

```
Device> enable
Device# configure terminal
Device(config)# anti-dos ip fragment 100
```

anti-dos ip ttl

To enable TTL monitoring and anti-TTL attack, use the **anti-dos ip ttl** command in global configuration mode. To disable TTL monitoring and anti-TTL attack, use the **no** form of the command.

anti-dos ip ttl

no anti-dos ip ttl

Command Default

Messages with TTL with a value of 0 are discarded.

Command Modes

Global Configuration (config)

Example

This example shows how to enable TTL monitoring using the **anti-dos ip ttl** command:

```
Device> enable
Device# configure terminal
Device(config)# anti-dos ip ttl
```


arp anti-spoofing

To enable ARP anti-spoofing, use the **arp anti-spoofing** command in global configuration mode. To disable ARP anti-spoofing, use the **no** form of the command.

arp anti-spoofing

no arp anti-spoofing

Command Modes

Global Configuration (config)

Example

This example shows how to enable ARP anti-spoofing using the **arp anti-spoofing** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing
Device(config)#
```

arp anti-spoofing deny-disguiser

To enable ARP gateway anti-spoofing, use the **arp anti-spoofing deny-disguiser** command in global configuration mode. To disable ARP gateway anti-spoofing, use the **no** form of the command.

arp anti-spoofing deny-disguiser

no arp anti-spoofing deny-disguiser

Command Modes

Global Configuration (config)

Example

This example shows how to enable ARP gateway anti-spoofing using the **arp anti-spoofing deny-disguiser** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing deny-disguiser
Device(config)#
```

arp anti-spoofing unknown

To enable ARP anti-spoofing and configure the device to flood or disable unknown packets, use the **arp anti-spoofing unknown** command in global configuration mode.

```
arp anti-spoofing unknown {flood | disable}
```

Syntax Description		
	flood	Floods the unknown packets.
	disable	Disables the unknown packets.

Command Modes Global Configuration (config)

Example

This example shows how to flood the unknown packets using the **arp anti-spoofing unknown flood** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing unknown flood
Device(config)#
```

Example

This example shows how to disable the unknown packets using the **arp anti-spoofing unknown disable** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing unknown disable
Device(config)#
```

arp anti-spoofing valid-check

To enable ARP anti-spoofing and configure source MAC address consistency inspection, use the **arp anti-spoofing valid-check** command in global configuration mode. To disable source MAC address consistency inspection, use the **no** form of the command.

arp anti-spoofing valid-check

no arp anti-spoofing valid-check

Command Modes

Global Configuration (config)

Example

This example shows how to enable source MAC address consistency inspection using the **arp anti-spoofing valid-check** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-spoofing valid-check
Device(config)#
```

arp anti-flood

To enable ARP anti-flooding attack and configure its parameters on all ports, use the **arp anti-flood** command in global configuration mode.

To enable ARP anti-flooding attack and configure its parameters on a specific port, use the **arp anti-flood** command in interface configuration mode.

To disable ARP anti-flooding attack, use the **no** form of the command.

```
arp anti-flood [ [action {deny-all | deny-arp}] [threshold threshold-value] | recover {mac-address | all} | recover-time time]
```

```
no arp anti-flood [recover-time | threshold]
```

Syntax Description

action deny-all	Adds the host to a blackhole address. The host will not receive any packets.
action deny-arp	Adds the host to a blackhole address. The host will not receive any ARP packets.
threshold <i>threshold-value</i>	Configures the ARP anti-flood threshold. The default value is 16 packets per second.
recover <i>mac-address</i>	Manually restores the host with the specified MAC address to transmit again.
recover all	Manually restores all the hosts to transmit again.
recover-time <i>time</i>	Defines the recovery time interval allowed to transmit again. The recovery interval is 0 to 1440 minutes. The default value is 10 minutes.

Command Modes

Global configuration (config)
Interface configuration (config-if)

Example

This example shows how to configure ARP anti-flooding attack using the **arp anti-flood** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood
Device(config)#
```

Example

This example shows how to add the host to a blackhole address list and discard all packets using the **arp anti-flood action deny-all** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood action deny-all
Device(config)#
```

Example

This example shows how to configure ARP anti-flooding threshold value using the **arp anti-flood threshold *threshold-value*** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood threshold 30
Device(config)#
```

Example

This example shows how to manually restore the host to transmit again using the **arp anti-flood recover** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood recover 00:00:00:00:32:33
Device(config)#
```

Example

This example shows how to define the recovery time interval after which a host is allowed to transmit again using the **arp anti-flood recover-time *time*** command:

```
Device> enable
Device# configure terminal
Device(config)# arp anti-flood recover-time 100
Device(config)#
```

channel-group spanning-tree cost

To configure the path cost of an STP aggregation group, use the **channel-group *group-id* spanning-tree cost** command in global configuration mode. To restore the default path cost of an STP aggregation group, use the **no** form of the command.

channel-group *group-id* spanning-tree cost *path-cost*

no channel-group *group-id* spanning-tree cost

Syntax Description

<i>group-id</i>	The channel group ID. The range is 0 to 5.
<i>path-cost</i>	The path cost of the aggregation group. The range is 1 to 200000000.

Command Modes

Global configuration (config)

Example

This example shows how to configure the path cost of an aggregation group using the **channel-group *group-id* spanning-tree cost** command:

```
Device> enable
Device# configure terminal
Device(config)# channel-group 1 spanning-tree cost 2000
Device(config)#
```

clear cpu-classification

To clear the CPU packet classification statistics, run the **clear cpu-classification** command in global configuration mode.

clear cpu-classification interface {**ethernet** | **gpon**} *slot-number/port-number*

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 255.
- GE Ethernet: The range is from 1 to 255.
- 10GE Ethernet: The range is from 1 to 255.

Command Default

None

Command Modes

Global configuration (config)

Example

This example shows how to clear the CPU packet classification statistics:

```
Device> enable
Device# configure terminal
Device(config)# clear cpu-classification interface ethernet 1/3
Clear packets sent to cpu classification statistics successfully
```


clear cpu-statistics

To clear the port statistics, use the **clear cpu-statistics** command in privileged EXEC and global configuration modes.

clear cpu-statistics

Command Default None

Command Modes Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to clear the port statistics.

```
Device> enable
Device# configure terminal
Device(config)# clear cpu-statistics
Clear packet sent to cpu statistic information successfully
```

cpu-car

To configure the CPU-car rate limit for packets, use the **cpu-car** command in global configuration mode. To restore the default CPU-car rate limit, use the **no** form of the command.

cpu-car *rate-limit*

no **cpu-car**

Syntax Description	Description
<i>rate-limit</i>	Configures the CPU-car rate limit. The range is 1 to 10000 packets per second. The default value is 4000 packets per second.

Command Modes Global configuration (config)

Example

This example shows how to configure real time accounting using the **realtime-account** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# realtime-account interval 25
Modify realtime_acct configuration of radius server successfully.
```

cpu-limit

To configure the CPU limit rate for packet types, use the **cpu-limit** command in global configuration mode. To restore the default CPU limit rate for packet types, use the **no** form of the command.

```
cpu-limit { arp | bpdu | broadcast | dhcp | icmp | igmp | mld | ospf | other | rip | snmp |  
ssh | switch-dst-mac | telnet } rate
```

```
no cpu-limit
```

Syntax Description

rate Configures the CPU-limit rate.
The range is 1 to 10000 packets per second.

Command Default

By default, no limit is configured.

Command Modes

Global configuration (config)

Example

This example shows how to configure CPU limit rate for ARP packets:

```
Device> enable  
Device# configure terminal  
Device(config)# cpu-limit arp 100
```

dhcp anti-attack

To enable DHCP packet monitoring and configure the monitoring parameters on all ports, use the **dhcp anti-attack** command in global configuration mode.

To enable DHCP packet monitoring and configure the monitoring parameters on a specific port, use the **dhcp anti-attack** command in interface configuration mode.

To disable DHCP packet monitoring and restore the parameters to their default values, use the **no** form of the command.

```
dhcp anti-attack [ [action {deny-all | deny-dhcp}] [threshold threshold-value] | [bind blackhole
| recover] {mac-address | all} | recover-time time]
```

```
no dhcp anti-attack [recover-time | threshold]
```

Syntax Description

action deny-all	Adds the host to a blackhole address list for all DHCP packets.
action deny-dhcp	Adds the host to a blackhole address list for all DHCP packets.
threshold <i>threshold-value</i>	Configures the rate threshold for DHCP packets. The default value is 16 packets per second.
bind blackhole <i>mac-address</i>	Binds the dynamic MAC address generated by the switch to the static MAC address for the specified MAC address in the blackhole address list.
bind blackhole all	Binds the dynamic MAC address generated by the switch to the static MAC address for all the MAC addresses in the blackhole address list.
recover <i>mac-address</i>	Manually restores the table items for the specified MAC address.
recover all	Manually restores the table items for all the MAC addresses in the blackhole address list.
recover-time <i>time</i>	Defines the recovery time interval. The recovery interval is 0 to 1440 minutes. The default value is 10 minutes.

Command Modes

Global configuration (config)
Interface configuration (config-if)

Example

This example shows how to configure DHCP packet monitoring using the **dhcp anti-attack** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack
Device(config)#
```

Example

This example shows how to configure DHCP packet monitoring and discard all packets using the **dhcp anti-attack action deny-all** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack action deny-all
Device(config)#
```

Example

This example shows how to configure the threshold value for DHCP packet globally using the **dhcp anti-attack threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack threshold 10
Device(config)#
```

Example

This example shows how to manually restore the table items for the host using the **dhcp anti-attack recover** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack recover all
Device(config)#
```

Example

This example shows how to configure recovery time interval using the **dhcp anti-attack recover-time** command:

```
Device> enable
Device# configure terminal
Device(config)# dhcp anti-attack recover-time 100
Device(config)#
```

discard-bpdu

To enable the local discard of external BPDU messages, use the **discard-bpdu** command in global configuration mode. To disable the local discard of external BPDU messages, use the **no** form of the command.

discard-bpdu

no discard-bpdu

Command Modes

Global configuration (config)

Example

This example shows how to enable the local discard of external BPDU messages using the **discard-bpdu** command:

```
Device> enable
Device# configure terminal
Device(config)# discard-bpdu
Enable discard bpdu successfully.
```

access-list extended name

To create a named Extended Access Control List, use the **access-list extended** command in the global configuration mode.

```
access-list extended {num|name }[ match-order { auto | config }]
```

Syntax Description

<i>num</i>	Specifies an extended ACL. Values can range from 100 through 199.
<i>name</i>	Specifies a name for the ACL. The name is a string of alphanumeric characters, upto 32 characters in length.
match-order	Defines a matching order for the entries in the ACL.
config	Matches the ACL rules according to the configuration order in the list.
auto	Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

Command Default

None

Command Modes

Global configuration (config)

Example

```
Device#configure terminal
Device(config)#access-list extended extacl match-order auto
```

access-list numbered extended

To define a numbered Extended Access Control List (ACL), use the **access-list** *number* command in the global configuration mode.

```
access-list number {permit |deny} [protocol ] [established] { source-ipv4 |
ipv6-source-prefix | any | ipv6any}[source-port-wildcard]{ dest-ipv4 | ipv6-dest-prefix | any
| ipv6any}[dest-port-wildcard][ icmp type icmp-code][igmp-type] [ traffic-class traffic-class
][ precedence precedence][ tos tos][ dscp dscp][ fragments ][ time-range
time-range ]
```

Syntax Description		
permit		Specifies that the rule defined by the ACL is permitted.
deny		Specifies that the rule defined by the ACL is not permitted.
<i>protocol</i>		Specifies the type of Layer 2 protocol. It is in the range of 1 through 255 by number. Select from GRE, ICMP, IGMP, IPinIP, OSPF, TCP, UDP, and ICMPv6 to specify the protocol by name.
established		Defines the SYN flag in TCP. A value 1 indicates that the flag is active. This is applicable only if the <i>protocol</i> is tcp.
<i>source-ipv4</i>		Specifies the IPv4 address of the source host.
<i>ipv6-source-prefix</i>		Specifies the IPv6 prefix of the source host.
ipv6any		Specifies any IPv6 host
<i>dest-ipv4</i>		Specifies the IPv4 address of the destination host.
<i>ipv6-dest-prefix</i>		Specifies the IPv6 prefix of the destination host.
any		Specifies any host.
<i>icmp type icmp-code</i>		Specifies the type of ICMP protocol packet. It is valid only when protocol is configured as icmp or icmpv6 .
<i>igmp-type</i>		Specifies the type of IGMP protocol packet. It is valid only when protocol is configured as igmp .
traffic-class		Specifies the traffic class for IPv6.
precedence		Specifies the precedence priority. IP precedence ranges from 0 through 7.
tos		Specifies the Type of Service (ToS) priority. The values range from 0 through 15.
dscp		Specifies the Differentiated Services Code Point (DSCP) priority value.
fragments		Specifies that the ACL rule is valid for non-first fragmented packets. This helps prevent fragment packet attacks.

time-range *timerange-name* Defines the specific time range to implement the ACL.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines The ACL is identified by the number assigned to it. You can create an ACL and assign a number to it. If you don't specify a number, the system assigns a number to the created ACL. For an Extended ACL, the numbers range from 100 through 199. You can create up to 100 Extended ACLs.

Example

```
Device#configure terminal
Device(config)#access-list 101 permit tcp 10.0.0.1 0 ftp any
```

host-guard bind ip

To configure host protection on a port, use the **host-guard bind ip** command in global configuration mode. To disable host protection on a port, use the **no** form of the command.

```
host-guard bind ip ip-address interface { ethernet slot_number/port_number | gpon
slot_number/port_number } [ to | ethernet slot_number/port_number | gpon slot_number/port_number ]
```

```
no host-guard bind ip ip-address interface { ethernet slot_number/port_number | gpon
slot_number/port_number } [ to | ethernet slot_number/port_number | gpon slot_number/port_number ]
```

Syntax Description		
	to	Displays the information for a range of ports. If you use the to keyword, specify the same port type as the keyword.
	<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 255. • GE Ethernet: The range is from 1 to 255. • 10GE Ethernet: The range is from 1 to 255.

Command Modes Global configuration (config)

Examples

This example shows how to configure host protection on a port using the **host-guard bind ip** command:

```
Device> enable
Device# configure terminal
Device(config)# host-guard bind ip 10.10.10.1 interface ethernet 1/3
Add host guard entry successfully.
```

ip route

To add a static IP route to the routing table, use the **ip route** command in the global configuration mode. To remove a static IP route from the routing table, use the **no** form of the command.

ip route *dest-ip mask* [*gate-ip*]

no ip route *dest-ip mask* [*gate-ip*]

Syntax Description		
<i>dest-ip</i>		The destination address of the static route added.
<i>mask</i>		The mask of the destination address.
<i>gate-ip</i>		The next-hop address of the static route.

Command Modes Global configuration (config)

Example

This example shows how to add a static IP route to the routing table using the **ip route** command:

```
Device> enable
Device# configure terminal
Device(config)# ip route 10.10.10.10 255.255.0.0 10.0.11.254
```

access-list link name

To create a named Layer 2 Access Control List (ACL), use the **access-list link** command in the global configuration mode.

```
access-list link {num|name} [ match-order { auto | config }]
```

Syntax Description

<i>num</i>	Specifies an extended ACL. Values can range from 200 through 299.
<i>name</i>	Specifies a name for the ACL. The name is a string of alphanumeric characters, upto 32 characters in length.
match-order	Defines a matching order for the entries in the ACL.
config	Matches the ACL rules according to the configuration order in the list.
auto	Matches the ACL rules according to the depth-first rule, wherein the longest subitem in a rule takes priority. The longest subset of a rule is matched first before the rule.

Command Default

None

Command Modes

Global configuration (config)

Example

```
Device#configure terminal
Device(config)#access-list link laye2acl match-order auto
```

access-list link number

To define a numbered Layer 2 Access Control List (ACL), use the **access-list** *number* command in the global configuration mode.

```
access-list number {permit |deny} [protocol ] [cos vlan-priority] ingress { {
[inner-vid] [start-vlan-id end-vlan-id ] [source-mac-addr source-mac-wildcard] [interface
interface-number ]} |any } egress { { [dest-mac-addr dest-mac-wildcard ] [interface
interface-num | cpu]} | any}[ time-range time-range ]
```

Syntax Description		
permit		Specifies that the rule defined by the ACL is permitted.
deny		Specifies that the rule defined by the ACL is not permitted.
<i>protocol</i>		Specifies the type of protocol packet carried by the Ethernet frame. In hexadecimal notation, the range is 0 through FFFF. It is optional in case of ARP, IP, RARP.
cos		Defines the SYN flag in TCP. A value 1 indicates that the flag is active. This is applicable only if the <i>protocol</i> is tcp.
ingress		Specifies the rule for the incoming packets at the ingress port.
inner-vid		Specifies the inner VLAN ID of a double-tagged packet.
<i>start-vlan-id end-vlan-id</i>		Specifies the range of VLANs. For a double-tagged packet, it is the VLAN ID of the outer tag.
<i>source-mac-addr</i> <i>source-mac-wildcard</i>		Specifies the source MAC address options. <i>source-mac-wildcard</i> indicates the source MAC range.
interface <i>interface-num</i>		Specifies the physical port number. It can be either the ingress port or the egress port.
CPU		Indicates that the data will be forwarded to the CPU.
any		Specifies any address which can be at ingress or egress directions.
time-range <i>name</i>		Specifies the time range in which the ACL rule takes effect.
time-range <i>timerange-name</i>		Defines the specific time range to implement the ACL.

Command Default None

Command Modes Global configuration (config)

Usage Guidelines The ACL is identified by the number assigned to it. You can create an ACL and assign a number to it. If you don't specify a number, the system assigns a number to the created ACL. For an Extended ACL, the numbers range from 200 through 299. You can create upto 100 Layer 2 ACLs.

Example

```
Device# configure terminal
```

```
Device(config)# access-list 201 permit arp ingress 00:00:00:00:01:01 0 egress any
```

local-user

To configure a local user, use the **local-user** command in the AAA configuration mode. To delete all local users, use the **no** form of the command.

```
local-user username username password password [vlan vlan-id]
```

```
no local-user {all | user username}
```

Syntax Description		
	<i>username</i>	Username of the local user.
	<i>password</i>	Password of the local user.
	<i>vlan-id</i>	The VLAN ID. The range is 1 to 4094.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to configure a local user using the **local-user** command:

```
Device> enable  
Device# configure terminal  
Device(config)# aaa  
Device(config-aaa)# local-user username name1 password pass1 vlan 220  
Device(config-aaa)#
```

nas-ipaddress

To configure the NAS client IP address for a RADIUS server, use the **nas-ipaddress** command in AAA configuration mode. To delete the configured NAS client IP address for a RADIUS server, use the **no** form of the command.

nas-ipaddress *ip-address*

no nas-ipaddress

Syntax Description	<i>ip-address</i>	IP address of RADIUS client.
--------------------	-------------------	------------------------------

Command Modes	AAA configuration (config-aaa)
---------------	--------------------------------

Example

This example shows how to configure the NAS client IP address for a RADIUS server:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# nas 10.1.1.10
```


no ip route static all

To delete all static IP routes from the routing table, use the **no ip route static all** command in global configuration mode.

no ip route static all

Command Modes

Global configuration (config)

Example

This example shows how to delete all static IP routes from the routing table using the **no ip route static all** command:

```
Device> enable
Device# configure terminal
Device(config)# no ip route static all
```

periodic time-range

To configure a time period that specifies when an access control list (ACL) is in effect, use the **periodic** command in the time-range configuration mode. To remove the absolute time-range, use the **no** form of the command.

```
[no]periodic [days-of-week] HH:MM:SS to [days-of-week ] HH:MM:SS
```

Syntax Description	<i>days-of-week</i>	Specifies the period, which are the days of the week: mon, tue, wed, thu, fri, sat, sun, weekdays , daily weekdays are Monday to Friday.
	<i>HH:MM:SS</i>	Specifies the time in <i>hours:minutes:seconds</i> format.
Command Modes	Global Configuration (config)	
Command Default	None	

Example

```
Device#configure terminal
Device(config)#time-range days
Device(config-timerange-days)#periodic daily 04:50:30 to 09:50:40
```

preemption-time

To configure the recovery time to switch to the primary server, use the **preemption-time** command in AAA configuration mode.

preemption-time *time*

Syntax Description	<i>time</i>	The preemption time The unit in minutes. The range is from 0 to 1440. The default value is c0
--------------------	-------------	---

Command Modes AAA configuration (config-aaa)

Usage Guidelines Use this command in the AAA configuration mode.

Examples

This example shows how to configure the recovery time to switch to the primary server.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# preemption-time 200
```

Related Commands

Command	Description
aaa	Enters AAA configuration mode

{primary-acct-ip | second-acct-ip}

To configure the primary and secondary accounting servers, use the **{primary-acct-ip |second-acct-ip}** *ip_address port* command in AAA configuration mode. To disable the configured primary and secondary accounting servers, use the **no** form of the command.

{primary-acct-ip | second-acct-ip} *ip_address port*

no **{primary-acct-ip | second-acct-ip}**

Syntax	Description
primary-acct-ip	The primary accounting server.
second-acct-ip	The secondary accounting server.
<i>ip_address</i>	The IP address of the server.
<i>port</i>	The accounting port The range is from 1 to 65535.

Command Modes AAA configuration (config-aaa)

Examples

This example shows how to configure the primary and secondary accounting server.

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# primary-acct-ip 10.1.1.10 333
Device(config-aaa-radius-radius1)# second-acct-ip 10.1.1.11 350
```

{primary-auth-ip | second-auth-ip}

To configure the primary and secondary RADIUS servers, use the **{primary-auth-ip |second-auth-ip}** *ip_address port* command in AAA configuration mode. To disable the configured primary and secondary RADIUS servers, use the **no** form of the command.

```
{primary-auth-ip | second-auth-ip} ip_address port
```

```
no {primary-auth-ip | second-auth-ip}
```

Syntax Description		
	primary-auth-ip	The primary RADIUS server.
	second-auth-ip	The secondary RADIUS server.
	<i>ip_address</i>	The IP address of the server.
	<i>port</i>	The server port The range is from 1 to 65535.

Command Default None

Command Modes AAA configuration (config-aaa)

Examples

This example shows how to configure the primary and secondary accounting server

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# primary-auth-ip 10.2.1.10 80
Device(config-aaa-radius-radius1)# second-auth-ip 10.2.1.11 90
```

radius

To configure the RADIUS server parameters, use the **radius** command in AAA configuration mode. To restore the default RADIUS server settings, use the **no** version of the command.

```
radius {8021p enable | accounting | attribute client-version | bandwidth-limit enable |
config-attribute {access-bandwidth {downlink vendor-type | unit {bps | kbps} |
uplink vendor-type} | dscp vendor-type | mac-address-number vendor-type} | host host-name |
mac-address-number enable | server-disconnect drop1x | vlan enable}
```

```
no radius {8021p | accounting | attribute client-version | bandwidth-limit enable | host
host-name | mac-address-number | server-disconnect drop1x | vlan}
```

Syntax	Description
8021p enable	Configures RADIUS to distribute port...
accounting	Enables accounting function.
attribute client-version	Send the H3C client's version to radiu...
bandwidth limit-enable	Configures RADIUS to distribute ban...
config-attribute	Configures the RADIUS attribute type...
access-bandwidth	Configures the RADIUS access bandw...
downlink	Configures the RADIUS downlink att...
uplink	Configures the RADIUS uplink attrib...
unit bps	Configures the RADIUS ACL bandw... per second.
unit kbps	Configures the RADIUS ACL bandw... kilobits per second.
dscp	Configures the RADIUS DSCP attrib...
config-attribute mac-address-number	Configures the maximum MAC addre... learned for the RADIUS server.
<i>vendor-type</i>	The vendor type. The range is from 1 to 500.
mac-address-number enable	Configures RADIUS to distribute num... address.
host <i>host-name</i>	Creates a RADIUS scheme and enters... mode for the specified host name.
server-disconnect drop1x	Configures the device to shut the user... accounting packet does not respond.

vlan enable

Configures RADIUS to distribute

Command Modes

AAA configuration (config-aaa)

Example

This example shows how to configure RADIUS to distribute port priority:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius 8021p enable
Configure successfully.
```

Example

This example shows how to enable accounting function:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius accounting
Modify accounting configuration of radius server successfully.
```

Example

This example shows how to send the H3C client's version to radius server:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius attribute client-version
Device(config-aaa)#
```

Example

This example shows how to configure RADIUS to distribute bandwidth control:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius bandwidth limit-enable
Configure successfully.
```

Example

This example shows how to configure the RADIUS access bandwidth and downlink attribute:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius config-attribute access-bandwidth downlink 400
Configure successfully.
```

Example

This example shows how to configure the RADIUS DSCP attribute:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius config-attribute dscp 1
Configure successfully.
```

Example

This example shows how to create a RADIUS scheme and enters RADIUS scheme mode:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host hostname1
Device(config-aaa-radius-hostname1)#
```

Example

This example shows how to configure RADIUS to distribute number limit of MAC address:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius mac-address-number enable
Configure successfully.
```

Example

This example shows how to shut the user down if the accounting packet does not respond:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius server-disconnect drop 1x
Configure successfully.
```

Example

This example shows how to configure RADIUS to distribute port PVID:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius vlan enable
Configure successfully.
```


realtime-account

To configure realtime accounting and its time interval, use the **realtime-account** command in AAA configuration mode. To disable realtime accounting, use the **no** form of the command.

realtime-account *interval* *time*

no realtime-account

Syntax Description	interval <i>time</i>	Configures the realtime accounting interval. The range is 1 to 255 minutes.
---------------------------	-----------------------------	--

Command Modes	AAA configuration (config-aaa)
----------------------	--------------------------------

Example

This example shows how to configure real time accounting using the **realtime-account** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# realtime-account interval 25
Modify realtime_acct configuration of radius server successfully.
```

no access-list

To remove an entry or all entries from the Access Control List (ACL), use the **no access-list** command in the global configuration mode.

```
no access-list {number | name | all}
```

Syntax Description	<i>number</i> Specifies that numbered ACL to delete
---------------------------	---

name	Specifies the name of the ACL to delete.
-------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration (config)
----------------------	-------------------------------

Example

```
Device#configure terminal  
Device(config)#no access-list 10
```

scheme

To configure the server authentication scheme, use the **scheme** command in AAA configuration mode.

```
scheme {local | radius [local] }
```

Syntax	Description
local	Configures to use local user authentication.
radius	Configures to use RADIUS server authentication.
radius local	Configures to use local user authentication if the RADIUS server authentication fails.

Command Modes AAA configuration (config-aaa)

Example

This example shows how to configure a server authentication scheme using the **scheme** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# domain eee
Device(config-aaa-domain-eee)# scheme radius
Device(config-aaa-domain-eee)#
```

show access-list config

To display the Access Controlled List (ACL) configurations, use the **show access-list config** command in the EXEC mode

show access-list config {*number* | **all** | **name** | **statistic** }

Syntax Description		
	<i>number</i>	Specifies the numbered ACL. Numbers 1 to 99 represent standard ACL. Numbers 100 to 199 represent extended ACL. Numbers 200 to 299 represent Layer 2 ACL.
	all	Specifies all ACLs.
	name	Specifies an ACL by name.
	statistic	Specifies ACL statistics.

Command Modes EXEC

Command Default None

Usage Guidelines

- Use the **show access-list config statistic** command to see the statistics of the ACL rules usage.
- Use the **show access-list config name** command to see the ACL specified by name.
- Use the **show access-list config all** command to all see the ACLs.

Examples

```
Device> enable
Device# show access-list config 1
Standard IP Access List 1, match-order is config, 2 rule:
 0 deny any
permit 1.1.1.1 0.0.0.0
```

show access-list runtime

To display the Access Controlled List (ACL) at run time, use the **show access-list runtime** command in the EXEC mode

show access-list runtime { *number* | **all** | **name** | **statistic** }

Syntax Description		
	<i>number</i>	Specifies the numbered ACL. Numbers 1 to 99 represent standard A Numbers 100 to 199 represent extend Numbers 200 to 299 represent Layer 1
	all	Specifies all ACLs.
	name	Specifies an ACL by name.
	statistic	Specifies ACL statistics.

Command Modes EXEC

Command Default None

Usage Guidelines

- Use the **show access-list runtime statistic** command to see the statistics of the ACL rules usage.
- Use the **show access-list runtime name** command to see the ACL specified by name.
- Use the **show access-list runtime all** command to all see the ACLs.

Examples

```
Device> enable
Device# show access-list runtime 1
Standard IP Access List 1, match-order is config, 1 rule:
 0 deny any
```

show anti-dos

To display the anti-DDOS configuration information, use the **show anti-dos** command in privileged EXEC or global configuration modes.

show anti-dos

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show anti-dos** command:

```
Device> enable
Device# configure terminal
Device(config)# show anti-dos
Informations of AntiDos:
Ip fragment max number:800
Ip fragment number now:0
TTL=0 packet traffic to CPU is disable.
```

show arp anti-flood

To display the ARP anti-flood configuration and attackers list, use the **show arp anti-flood** command in privileged EXEC or global configuration modes.

```
show arp anti-floodport-threshold [ { ethernet | gpon } slot-number/port-number [ to { ethernet | gpon } slot-number/port-number ] ]
```

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value
 - 10GE Ethernet: The val
- *port-number*:
 - GPON: The range is from
 - GE Ethernet: The range
 - 10GE Ethernet: The rang

to

Displays the information for a range. If you use the **to** keyword, specify the same port ID as the keyword.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show arp anti-flood** command:

```
Device> enable
Device# configure terminal
Device(config)# show arp anti-flood
Arp anti-flood: disabled
Arp rate limit:25pps
User recovery time:234 minutes
Reject type:DenyAll
DeniedSrcMAC      SourceIP      Port      Vlan  DenyType  RemainAgingTime(m)
Total entry:0.
```

Example

This example shows a sample output for the **show arp anti-flood port-threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# show arp anti-flood port-threshold
Arp anti-flood: disabled
Arp rate limit:25pps
User recovery time:234 minutes
Reject type:DenyAll
Port          Port-threshold
g0/1          16
g0/2          16
g0/3          16
g0/4          16
g0/5          16
g0/6          16
g0/7          16
g0/8          16
e1/1          16
e1/2          16
e1/3          16
e1/4          16
e2/1          16
e2/2          16
```


show arp anti interface

To display the state of the interface, use the **show arp anti interface** command in privileged EXEC or global configuration modes.

```
show arp anti interface [ { ethernet | gpon } slot-number/port-number ]
```

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:
 - GPON: The value is 0.
 - GE Ethernet: The value
 - 10GE Ethernet: The val
- *port-number*:
 - GPON: The range is from
 - GE Ethernet: The range
 - 10GE Ethernet: The rang

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show arp anti interface** command:

```
Device> enable
Device# configure terminal
Device(config)# show arp anti interface
Port          mode          threshold(anti-flood)
g0/1          untrust      -
g0/2          untrust      -
g0/3          untrust      -
g0/4          untrust      -
g0/5          untrust      -
g0/6          untrust      -
g0/7          untrust      -
g0/8          untrust      -
e1/1          untrust      -
e1/2          untrust      -
e1/3          untrust      -
e1/4          untrust      -
e2/1          untrust      -
e2/2          untrust      -
```

show cpu-car

To display the CPU-car performance, use the **show cpu-car** command in privileged EXEC or global configuration modes.

show cpu-car

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show cpu-car** command:

```
Device> enable
Device# configure terminal
Device(config)# show cpu-car
Send packet to cpu rate = 4000 pps.
```

show cpu-classification

To display CPU receiving packet classification statistics, run the **show cpu-classification** command in privileged EXEC or global configuration modes.

show cpu-classification [**interface** {**ethernet** | **gpon**}*slot-number/port-number*]

Syntax Description	<i>slot-number/port-number</i>	<p>The port ID.</p> <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 255. • GE Ethernet: The range is from 1 to 255. • 10GE Ethernet: The range is from 1 to 255.
---------------------------	--------------------------------	--

Command Default None

Command Modes Privileged EXEC(#)
Global Configuration(config)

Examples

This example shows how to view CPU receiving packet classification statistics.

```
Device> enable
Device# configure terminal
Device(config)# show cpu-classification
Type          Count      Percent (%)
Total         460699064  100

BPDU          8237424    1
ARP           378164060  82
IGMP          607189     0
ICMP          699125     0
OSPF          0           0
RIP           139        0
DHCP          12658100   2
SNMP          4079818    0
Telnet        122166     0
SSH           10788      0
Other         56120236   12
```

show cpu-limit

To display the packet types and the speed of each packet type, use the **show cpu-limit** command in privileged EXEC or global configuration modes.

show cpu-limit

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show cpu-limit** command:

```
Device> enable
Device# configure terminal
Device(config)# show cpu-limit
packet-type      speed(pps)
other            200
broadcast        200
switch-dst-mac  1000
icmp             200
mld              200
igmp             200
ssh              200
dhcp             200
snmp             100
arp              100
ospf             200
rip              200
telnet           100
bpdu             200
```

show cpu-statistics

To display CPU receiving packet port statistics, use the **show cpu-statistics** command in privileged EXEC and global configuration modes.

```
show cpu-statistics [ channel-group channel-group-number | { gpon | ethernet } slot-number/port-number ]
[ to { channel-group channel-group-number | { gpon | ethernet } slot-number/port-number } ]
```

Syntax Description	channel-group <i>channel-group-number</i>	The LACP channel group.
	<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 255. • GE Ethernet: The range is from 1 to 255. • 10GE Ethernet: The range is from 1 to 255.
	to	Displays the information for a range of ports of the same port type before and after the specified port.
Command Default	None	
Command Modes	Privileged EXEC (#) Global configuration (config)	

Examples

This example shows how to view CPU receiving packet port statistics.

```
Device> enable
Device# configure terminal
Device(config)# show cpu-statistics ethernet 1/1
Show packets sent to cpu statistic information
port 64Byte 128Byte 256Byte 512Byte 1024Byte 2048Byte
e1/1 0 0 0 0 0 0
```

show cpu-utilization

To display CPU utilization, use the **show cpu-utilization** command in global configuration mode.

show cpu-utilization

Command Default None

Command Modes Global configuration (config)

Examples This example shows how to view CPU utilization.

```
Device> enable
Device# configure terminal
Device(config)# show cpu-utilization
CPU Information:
CPU Idle : 79 %
```

show dhcp anti-attack

To display the DHCP anti-attack configuration, use the **show dhcp anti-attack** command in privileged EXEC and global configuration modes.

```
show dhcp anti-attack [interface{ethernet | gpon} slot-number/port-number [to {ethernet | gpon} slot-number/port-number ] ]
```

Syntax Description		
to		Displays the information for a range of ports. If the to keyword, specify the same port ID as the keyword.
<i>slot-number/port-number</i>		The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 255. • GE Ethernet: The range is from 1 to 255. • 10GE Ethernet: The range is from 1 to 255.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show dhcp anti-attack** command:

```
Device> enable
Device# configure terminal
Device(config)# show dhcp anti-attack
Dhcp anti-attack: enabled
Dhcp rate limit:1pps
User recovery time:3 minutes
Reject type:DenyDHCP
DeniedSrcMAC Port Vlan DenyType RemainAgingTime(m)
00:00:00:01:11:23 e1/1 2 DenyDHCP 3
Total entry: 1.
#After 3 minutes, the attack entry is aged out
```

show discard-bpdu

To display the BPDU status, use the **show discard-bpdu** command in privileged EXEC and global configuration modes.

show discard-bpdu

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show discard-bpdu** command:

```
Device> enable
Device# configure terminal
Device(config)# show discard-bpdu
Discard BPDU global status: disable
Discard BPDU enable port:
```

Notes: Once global status is on, the switch will discard all BPDUs.
If want to enable on some ports only, need to disable global function and choose another commands.

show dot1x

To display the 802.1x authentication function details, run the **show dot1x** command in privileged EXEC and global configuration modes.

```
show dot1x [[daemon | detect | eapol-relay | guest-vlan] [interface {ethernet | gpon}
slot-number/port-number] [to {ethernet | gpon} slot-number/port-number] | max-reauth |
max-req | port-auth | quiet-period-value | session [interface {ethernet | gpon}
slot-number/port-number] [to {ethernet | gpon} slot-number/port-number] | mac-address
mac-address-value ] ]
```

Syntax	Description
daemon	Displays the configuration of 802.1x interface watch function.
detect	Displays heartbeat detection configuration.
eapol-relay	Displays EAPOL pass through configuration.
guest-vlan	Displays guest VLAN information.
interface	Displays interface configuration, session control mode, re-authentication status of users for the interface authentication.
<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> <i>slot-number</i>: <ul style="list-style-type: none"> GPON: The value is 0. GE Ethernet: The value is 1 to 24. 10GE Ethernet: The value is 25 to 48. <i>port-number</i>: <ul style="list-style-type: none"> GPON: The range is from 1 to 16. GE Ethernet: The range is from 1 to 24. 10GE Ethernet: The range is from 1 to 24.
to	Displays the information for a range of ports. If you use the to keyword, specify the same port ID as the keyword.
max-reauth	Displays information about maximum re-authentication requests and identity packets sent by the server.
max-req	Displays information about the maximum number of re-authentication requests sent by the server.

port-auth	Displays whether the interface authentication is enabled or disabled.
quiet-period-value	Displays the quiet period.
session	Displays 802.1x session.
mac-address <i>mac-address-value</i>	Displays 802.1x session information for the specified MAC address.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows the sample output for the **show dot1x daemon**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x daemon
port  daemonstatus  daemontime(s)
g0/1  close          60
g0/2  close          60
g0/3  close          60
g0/4  close          60
g0/5  close          60
g0/6  close          60
g0/7  close          60
g0/8  close          60
e1/1  close          60
e1/2  close          60
e1/3  close          60
e1/4  close          60
e2/1  close          60
e2/2  close          60
```

Example

This example shows the sample output for the **show dot1x detect**

```
Device> enable
Device# configure terminal
Device(config)# show dot1x detect
the user detect interval is 25
port : detect
g0/1 : disable
g0/2 : disable
g0/3 : disable
g0/4 : disable
g0/5 : disable
g0/6 : disable
g0/7 : disable
g0/8 : disable
e1/1 : disable
e1/2 : disable
e1/3 : disable
e1/4 : disable
e2/1 : disable
```

```
e2/2 : disable  
  
Total [14] item(s), printed [14] item(s).
```

Example

This example shows the sample output for the **show dot1x eapol-relay**

```
Device> enable  
Device# configure terminal  
Device(config)# show dot1x eapol-relay  
Port  EapolRelay  EapolRelayUplink  
g0/1  disabled    false  
g0/2  disabled    false  
g0/3  disabled    false  
g0/4  disabled    false  
g0/5  disabled    false  
g0/6  disabled    false  
g0/7  disabled    false  
g0/8  disabled    false  
e1/1  disabled    false  
e1/2  disabled    false  
e1/3  disabled    false  
e1/4  disabled    false  
e2/1  disabled    false  
e2/2  disabled    false  
  
Total entries: 14.
```

Example

This example shows the sample output for the **show dot1x guest-vlan**

```
Device> enable  
Device# configure terminal  
Device(config)# show dot1x guest-vlan  
Port  GuestVlan  Status  
g0/1  disable    InConfigVlan  
g0/2  disable    InConfigVlan  
g0/3  disable    InConfigVlan  
g0/4  disable    InConfigVlan  
g0/5  disable    InConfigVlan  
g0/6  disable    InConfigVlan  
g0/7  disable    InConfigVlan  
g0/8  disable    InConfigVlan  
e1/1  44         InConfigVlan  
e1/2  disable    InConfigVlan  
e1/3  disable    InConfigVlan  
e1/4  disable    InConfigVlan  
e2/1  disable    InConfigVlan  
e2/2  disable    InConfigVlan  
  
Total entries: 14.
```

Example

This example shows the sample output for the **show dot1x interface**

```

Device> enable
Device# configure terminal
Device(config)# show dot1x interface ethernet 1/3
Authentication of system: disabled
Type of authentication: eap-finish

Total [0] item(s).

```

Example

This example shows the sample output for the **show dot1x max-reauth**

```

Device> enable
Device# configure terminal
Device(config)# show dot1x max-reauth
the max-reauth is 2.

```

Example

This example shows the sample output for the **show dot1x max-req**

```

Device> enable
Device# configure terminal
Device(config)# show dot1x max-req
the max-req is 2.

```

Example

This example shows the sample output for the **show dot1x port-auth**

```

Device> enable
Device# configure terminal
Device(config)# show dot1x port-auth
-----
port 1 auth is close
port 2 auth is close
port 3 auth is close
port 4 auth is close
port 5 auth is close
port 6 auth is close
port 7 auth is close
port 8 auth is close
port 9 auth is close
port 10 auth is close
port 11 auth is close
port 12 auth is close
port 13 auth is close
port 14 auth is close
-----

```

Example

This example shows the sample output for the **show dot1x quiet-period-value**

```

Device> enable
Device# configure terminal

```

```
Device(config)# show dot1x quiet-period-value  
the quiet-period-value is 0.
```

Example

This example shows the sample output for the **show dot1x session**

```
Device> enable  
Device# configure terminal  
Device(config)# show dot1x session  
Total [0] item(s).
```

show ip route

To display the related information of specified routes as well as static routes, use the **show ip route** command in privileged EXEC and global configuration modes.

show ip route [*ip-address* [*mask*] | **ospf** | **rip** | **static**]

Syntax Description		
	<i>ip-address</i>	The destination address.
	<i>mask</i>	The destination network segment present.
	ospf	Displays all OSPF routes.
	rip	Displays all RIP routes.
	static	Displays all static routes.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show ip route** command:

```
Device> enable
Device# configure terminal
Device(config)# show ip route
Show ip route information

INET route table - vr: 0, table: 254
Route flag: U - up, G - gateway, H - host, R - reject, C - clone, S - static
Destination      Gateway          Flags    Use    Interface      Proto
0.0.0.0/0        10.75.171.1     UGS      659    VLAN-IF100     static
10.75.171.0/24   10.75.171.17   UC       5      VLAN-IF100     local
10.75.171.17     10.75.171.17   UH       0      lo0             local
127.0.0.0/8      127.0.0.1      UR       0      lo0             local
127.0.0.1        127.0.0.1      UH       4      lo0             local
192.168.100.0/24 192.168.100.1  UC       0      METH-IF0       local
192.168.100.1    192.168.100.1  UH       0      lo0             local

Total entries: 7. Printed entries: 7.
```

show radius

To display the RADIUS server details, run the **show radius** command in privileged EXEC mode.

```
show radius {attribute | config-attribute | host [radius-server-name]}
```

Syntax Description	attribute	Displays the H3C client version in the RADIUSRADIU server.
	config-attribute	Displays the configured vendor-specific RADIUS attribute information.
	host	Displays RADIUS host configuration for all RADIUS servers.
	host radius-server-name	Displays RADIUS host configuration for the specified RADIUS server.

Command Modes	Privileged EXEC (#) Global Configuration (config)
---------------	--

Example

This example shows the sample output for the **show radius host** command:

```
Device> enable
Device# configure terminal
Device(config)# show radius host
-----
ServerName = binidng
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                PrimAcctPort = 1813
SecAuthPort = 1812                SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = r1
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                PrimAcctPort = 1813
SecAuthPort = 1812                SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP = 0.0.0.0
-----
ServerName = mmm
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP = 0.0.0.0          SecAcctServerIP = 0.0.0.0
PrimAuthPort = 1812                PrimAcctPort = 1813
SecAuthPort = 1812                SecAcctPort = 1813
Auth-secretKey = Switch            Acct-secretKey = Switch
```

```

UserNameFormat = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP  = 0.0.0.0
-----
ServerName = eee
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP  = 0.0.0.0          SecAcctServerIP  = 0.0.0.0
PrimAuthPort     = 1812              PrimAcctPort     = 1813
SecAuthPort      = 1812              SecAcctPort      = 1813
Auth-secretKey   = Switch            Acct-secretKey   = Switch
UserNameFormat   = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP   = 0.0.0.0
-----
ServerName = cisco
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP  = 0.0.0.0          SecAcctServerIP  = 0.0.0.0
PrimAuthPort     = 1812              PrimAcctPort     = 1813
SecAuthPort      = 1812              SecAcctPort      = 1813
Auth-secretKey   = Switch            Acct-secretKey   = Switch
UserNameFormat   = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP   = 0.0.0.0
-----
ServerName = 3
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 0.0.0.0
SecAuthServerIP  = 0.0.0.0          SecAcctServerIP  = 0.0.0.0
PrimAuthPort     = 1812              PrimAcctPort     = 1813
SecAuthPort      = 1812              SecAcctPort      = 1813
Auth-secretKey   = Switch            Acct-secretKey   = Switch
UserNameFormat   = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP   = 0.0.0.0
-----
ServerName = radius1
PrimAuthServerIP = 0.0.0.0          PrimAcctServerIP = 10.1.1.10
SecAuthServerIP  = 0.0.0.0          SecAcctServerIP  = 0.0.0.0
PrimAuthPort     = 1812              PrimAcctPort     = 333
SecAuthPort      = 1812              SecAcctPort      = 1813
Auth-secretKey   = Switch            Acct-secretKey   = Switch
UserNameFormat   = with-domain
RealTimeAcctSwitch = open          RealTimeAcctTime = 12
RadiusClientIP   = 0.0.0.0
-----
Total [7] item(s), printed [7] item(s).

```


show shutdown-control interface

To display the shutdown configuration, use the **show shutdown-control interface** command in privileged EXEC or global configuration mode.

show shutdown-control interface [**ethernet** *slot-number/port-number* [**to ethernet** *slot-number/port-number*]]

Syntax	Description
<i>slot-number/port-number</i>	The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value • 10GE Ethernet: The value • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from • GE Ethernet: The range • 10GE Ethernet: The range
to	Displays the information for a range of ports. If you use the to keyword, specify the same port ID as the keyword.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show shutdown-control interface** command:

```
Device> enable
Device# configure terminal
Device(config)# show shutdown-control interface
port shutdown control recover mode : manual
port shutdown control information :
PortID   Broadcast Broadcast Multicast Multicast Unicast Unicast
         status   value    status   value    status  value
e1/1     disable  -        disable  -        disable -
e1/2     disable  -        disable  -        disable -
e1/3     disable  -        disable  -        disable -
e1/4     disable  -        disable  -        disable -
e2/1     disable  -        disable  -        disable -
e2/2     disable  -        disable  -        disable -
Total entries: 6 .
```

show spanning-tree interface

To display the spanning tree configuration parameters, use the **show spanning-tree interface** command in the privileged EXEC and global configuration modes.

show spanning-tree interface [**brief**] { **ethernet** | **gpon** } *slot-number/port-number* [**to** { **ethernet** | **gpon** } *slot-number/port-number*]

Syntax Description

slot-number/port-number

The port ID.

- *slot-number*:

- GPON: The value is 0.
- GE Ethernet: The value is 1.
- 10GE Ethernet: The value is 2.

- *port-number*:

- GPON: The range is from 1 to 255.
- GE Ethernet: The range is from 1 to 255.
- 10GE Ethernet: The range is from 1 to 255.

to

Displays the information for a range of ports. If you use the **to** keyword, specify the same port type as the keyword.

Command Modes

Privileged EXEC (#)
Global Configuration (config)

Example

This example shows a sample output for the **show spanning-tree interface** command:

```
Device> enable
Device# configure terminal
Device(config)# show spanning-tree interface
Port g0/1 of bridge is Forwarding
  Spanning tree protocol is enabled
Port g0/2 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/3 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/4 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/5 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/6 of bridge is DOWN
  Spanning tree protocol is enabled
Port g0/7 of bridge is DOWN
  Spanning tree protocol is enabled
```

```
Port g0/8 of bridge is DOWN
  Spanning tree protocol is enabled
Port e1/1 of bridge is DOWN
  Spanning tree protocol is enabled
Port e1/2 of bridge is DOWN
  Spanning tree protocol is enabled
Port e1/3 of bridge is Forwarding
  Spanning tree protocol is enabled
Port e1/4 of bridge is DOWN
  Spanning tree protocol is enabled
Port e2/1 of bridge is DOWN
  Spanning tree protocol is enabled
Port e2/2 of bridge is DOWN
  Spanning tree protocol is enabled
```

shutdown-control-recover

To enable the port recovery mode and configure the port recovery parameters, use the **shutdown-control-recover** command in global configuration mode. To disable the port recovery mode and restore the default parameter values, use the **no** form of the command.

shutdown-control-recover {**automatic-open-time** *open-time* | **mode** {**automatic** | **manual**}}

no shutdown-control-recover {**automatic-open-time** | **mode**}

Syntax Description		
automatic-open-time <i>open-time</i>		Configures the time after which the port recovery time is expires.
mode automatic		Enables automatic recovery mode.
mode manual		Enables manual recovery mode.

Command Modes Global Configuration (config)

Example

This example shows how to configure automatic recovery mode on a port using the **shutdown-control-recover** command:

```
Device> enable
Device# configure terminal
Device(config)# shutdown-control-recover mode automatic
Device(config)#
```

spanning-tree (global configuration)

To enable spanning tree globally and configure the spanning tree parameters, use the **spanning-tree** command in global configuration mode. To disable spanning tree, use the **no** form of the command.

```
spanning-tree [forward-time delay-time | hello-time hello-time | max-age age-time | mode {rstp
| stp} | pathcost-standard {dot1d-1998 | dot1t} | priority priority-value | root-guard action
{block-port | drop-packets}]
```

```
no spanning-tree [forward-time | hello-time | max-age | mode | pathcost-standard | priority
| root-guard action]
```

Syntax Description		
forward-time <i>delay-time</i>		Configures the forwarding delay of the spanning tree. The range is 4 to 30 seconds.
hello-time <i>hello-time</i>		Configures the hello message time interval. The range is 1 to 10 seconds.
max-age <i>age-time</i>		Configures the aging time of the spanning tree. The range is 6 to 40 seconds.
mode rstp		Configures the RSTP spanning tree mode.
mode stp		Configures the STP spanning tree mode.
pathcost-standard dot1d-1998		Sets pathcost standard for dot1d-1998.
pathcost-standard dot1t		Sets pathcost standard for dot1t.
priority <i>priority-value</i>		Configures the switch priority. The range is from 0 to 61440, in increments of 4096.
root-guard action block-port		Enables root protection globally. BPDU configuration messages are not forwarded. packets are not forwarded.
root-guard action drop-packets		Enables root protection globally. BPDU configuration messages are forwarded. packets are forwarded.

Command Modes Global configuration (config)

Example

This example shows how to configure the forwarding delay of the system:

```
Device> enable
Device# configure terminal
```

```
Device(config)# spanning-tree forward-time 10
Device(config)#
```

Example

This example shows how to configure the hello message time interval:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree hello-time 5
Device(config)#
```

Example

This example shows how to configure the aging time of the system:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree max-age 10
Device(config)#
```

Example

This example shows how to configure RSTP spanning tree mode:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree mode rstp
Device(config)#
```

Example

This example shows how to configure STP spanning tree mode:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree mode stp
Device(config)#
```

Example

This example shows how to configure the pathcost standard:

```
Device> enable
Device# configure terminal
Device(config)# spanning-tree pathcost-standard dot1t
Device(config)#
```

Example

This example shows how to configure the switch priority:

```
Device> enable
Device# configure terminal
```

```
Device(config)# spanning-tree priority 3  
Device(config)#
```

Example

This example shows how to enable root guard protection globally and configure the data packets to not be forwarded:

```
Device> enable  
Device# configure terminal  
Device(config)# spanning-tree root-guard action block-port  
Device(config)#
```

spanning-tree (interface configuration)

To enable spanning tree on a specific interface and configure the spanning tree parameters, use the **spanning-tree** command in interface configuration mode. To disable spanning tree, use the **no** form of the command.

spanning-tree [**cost** *cost-value* | **loop-guard** | **mcheck** | **point-to-point** {**auto** | **forcefalse** | **forcetrue**} | **port-priority** *priority-value* | **portfast** | **root-guard** | **transit-limit** *value*]

no spanning-tree [**cost** | **loop-guard** | **point-to-point** | **port-priority** | **portfast** | **root-guard** | **transit-limit**]

Syntax Description		
cost <i>cost-value</i>		Modifies the path cost of the STP port. The range is 1 to 200000000.
loop-guard		Enables loop-guard on the port.
mcheck		Configures Mcheck on the port.
point-to-point auto		STP decides the point to point link.
point-to-point forcetrue		Enables the point to point link.
point-to-point forcefalse		Disables the point to point link.
port-priority <i>priority-value</i>		Configures the STP priority of the port. The range is 0 to 240.
portfast		Configures the port as an edge port.
root-guard		Enables root protection locally on the port.
transit-limit <i>value</i>		Configures the port to send the maximum number of BPDUs. The range is 1 to 255.

Command Modes Interface configuration (config-if)

Example

This example shows how to configure the path cost of an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree cost 1000
Device(config-if-ethernet-1/3)#
```


Example

This example shows how to enable loop guard on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree loop-guard
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure Mcheck on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree mcheck
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to enable point to point link on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree point-to-point forcetrue
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure the STP priority of an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree port-priority 3
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure the STP port as an edge port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree portfast
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to enable root protection on an STP port:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree root-guard
Device(config-if-ethernet-1/3)#
```

Example

This example shows how to configure an STP port to send the maximum rate of BPDU messages:

```
Device> enable
Device# configure terminal
Device(config)# interface ethernet 1/3
Device(config-if-ethernet-1/3)# spanning-tree transit-limit 200
Device(config-if-ethernet-1/3)#
```

time-range

To specify when an access control list (ACL) is in effect, use the **time-range** command in the global configuration mode. To remove the time range, use the **no** form of the command.

```
[no]time-range name
```

Syntax Description	<i>name</i>	Specifies a unique name for the time range. Name has to begin with an alphabetic character.
---------------------------	-------------	---

Command Modes	Global Configuration (config)
----------------------	-------------------------------

Command Default	None
------------------------	------

Example

```
Device#configure terminal  
Device(config)#time-range weekends
```

username-format

To configure a packet to carry the username when it is passed by the system to the RADIUS server, use the **username-format** command in AAA configuration module.

username-format { **with-domain** | **without-domain** }

Syntax Description		
	with-domain	Configures the packet to carry the username with domain.
	without-domain	Configures the packet to carry the username without domain.
Command Modes	AAA configuration (config-aaa)	

Example

This example shows how to configure the system to carry the user name when it passes a packet to the RADIUS server using the **username-format** command:

```
Device> enable
Device# configure terminal
Device(config)# aaa
Device(config-aaa)# radius host radius1
Device(config-aaa-radius-radius1)# username-format with-domain
Modify the username format of RADIUS configuration successfully
```



PART **VIII**

Multicast Configuration

- [Multicast Configuration, on page 389](#)



Multicast Configuration

- [igmp-snooping](#), on page 391
- [igmp-snooping drop](#), on page 392
- [igmp-snooping fast-leave](#), on page 393
- [igmp-snooping group-limit action](#), on page 394
- [igmp-snooping group-limit](#), on page 395
- [igmp-snooping general-query source-ip](#), on page 396
- [igmp-snooping host-aging-time](#), on page 397
- [igmp-snooping max-response-time](#), on page 398
- [igmp-snooping multicast vlan](#), on page 399
- [igmp-snooping {permit|deny}](#), on page 400
- [igmp-snooping profile refer](#), on page 401
- [igmp-snooping profile](#), on page 402
- [igmp-snooping {permit|deny} group-range](#), on page 403
- [igmp-snooping query-interval](#), on page 404
- [igmp-snooping querier version](#), on page 405
- [igmp-snooping querier-vlan](#), on page 406
- [igmp-snooping query-max-respond](#), on page 407
- [igmp-snooping record-host](#), on page 408
- [igmp-snooping router-port-age](#), on page 409
- [igmp-snooping route-port forward](#), on page 410
- [igmp-snooping report-suppression](#), on page 411
- [igmp-snooping route-port vlan](#), on page 412
- [ip range](#), on page 413
- [mac range](#), on page 414
- [mld-snooping](#), on page 415
- [mld-snooping fast-leave](#), on page 416
- [mld-snooping group-limit](#), on page 417
- [mld-snooping host-aging-time](#), on page 418
- [mld-snooping max-response-time](#), on page 419
- [mld-snooping multicast vlan](#), on page 420
- [mld-snooping {permit|deny} {group|vlan}](#), on page 421
- [mld-snooping permit deny group MAC vlan](#), on page 422
- [mld-snooping {permit|deny} group-range](#), on page 423

- `mld-snooping querier`, on page 424
- `mld-snooping querier-vlan`, on page 425
- `mld-snooping query-interval`, on page 426
- `mld-snooping query-max-respond`, on page 427
- `mld-snooping route-port forward`, on page 428
- `mld-snooping route-port vlan`, on page 429
- `mld-snooping router-port-age`, on page 430
- `mld-snooping record-host`, on page 431
- `multicast`, on page 432
- `multicast ds-tag add`, on page 433
- `multicast ds-tag remove`, on page 434
- `multicast ds-tag translate`, on page 435
- `multicast fast-leave disable`, on page 436
- `multicast group-limit`, on page 437
- `multicast interface`, on page 438
- `multicast mode igmp-snooping`, on page 439
- `multicast proxy-interval`, on page 440
- `multicast proxy-port`, on page 441
- `multicast us-tag add`, on page 442
- `multicast us-tag translate`, on page 443
- `profile limit`, on page 444
- `show igmp-snooping`, on page 445
- `show igmp-snooping profile`, on page 446
- `show igmp-snooping record-host`, on page 447
- `show igmp-snooping router-dynamic`, on page 448
- `show igmp-snooping router-static`, on page 449
- `show mld-snooping`, on page 450
- `show mld-snooping router-dynamic`, on page 451
- `show mld-snooping router-static`, on page 452
- `show multicast mld-snooping`, on page 453
- `show multicast igmp-snooping`, on page 456
- `show ont multicast`, on page 457
- `show running-config mld_snooping`, on page 458

igmp-snooping

To enable IGMP Snooping, use the **igmp-snooping** command in the global configuration mode. To disable IGMP Snooping, use the **no** form of the command.

igmp-snooping

no igmp-snooping

Syntax Description	igmp-snooping Enables IGMP Snooping.
---------------------------	---

Command Default	IGMP Snooping is enabled by default.
------------------------	--------------------------------------

Command Modes	Global configuration
----------------------	----------------------

Examples	The following example shows how to enable IGMP Snooping.
-----------------	--

```
Device(config)#igmp-snooping
```

igmp-snooping drop

To configure a port to drop query or report packets, use the **igmp-snooping drop** command in the interface configuration mode. To configure the port to start receiving IGMP query or report packets, use the **no** form of the command.

igmp-snooping drop { **query** | **report** }

no igmp-snooping drop

Syntax Description	query Configures the port to drop IGMP query packets.
	report Configures the port to drop IGMP report packets.

Command Default Packet dropping is not enabled by default.

Command Modes Interface configuration

Examples

The following example shows how to configure a port to drop query packets:

```
Device(config-if-ethernet-1/1)# igmp-snooping drop query
```

igmp-snooping fast-leave

To remove the port directly from the multicast group upon receiving an IGMP Leave message, use the **igmp-snooping fast-leave** command in the interface configuration mode. To disable fast leave use the **no** form of the command.

igmp-snooping fast-leave

no igmp-snooping fast-leave

Syntax Description	fast-leave Removes the port directly from the multicast group upon receiving an IGMP Leave message
---------------------------	---

Command Default	Fast leave is not configured by default.
------------------------	--

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to configure fast leave:

```
Device(config-if-ethernet-1/1)#igmp-snooping fast-leave
```

igmp-snooping group-limit action

To configure the action that the port will perform when it reaches the maximum number of multicast groups it can join, use the **igmp-snooping group-limit action** command in the interface configuration mode.

igmp-snooping group-limit action { **drop** | **replace** }

Syntax Description	drop Drops the multicast group. This is the default action.
	replace Replaces an old multicast group with the new group.

Command Default When the group limit is reached, the new group is dropped.

Command Modes Interface configuration

Examples This example shows how to configure the port to drop new multicast groups when it reaches the group limit

```
Device(config-if-ethernet-1/1)#igmp-snooping group-limit action drop
```

igmp-snooping group-limit

To configure the maximum number of multicast groups that an interface or a port can learn or join, use the **igmp-snooping group-limit** command in the interface configuration mode. To undo the limit on the maximum number of multicast groups that a port can join use the **no** form of the command.

igmp-snooping group-limit *number*

no igmp-snooping group-limit

Syntax Description

number Specifies the maximum number of multicast groups that a port can join. The range is 0-1024.

Command Default

No limit is configured by default.

Command Modes

Interface configuration

Examples

The following examples shows how to configure a group limit of 100:

```
Device(config-if-ethernet-1/4)#igmp-snooping group-limit 100
```

igmp-snooping general-query source-ip

To configure the source IP address for sending general query packets, use the **igmp-snooping general-query source-ip** command in the global configuration mode. To disable the source IP address for sending general query, use the **no** form of the command.

igmp-snooping general-query source-ip*ip-address*

no igmp-snooping general-query source-ip*ip-address*

Syntax Description	<i>ip-address</i> Configures the source IP address for sending general query packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples The following example shows how to configure a source IP address for sending general query packets:

```
Device(config)# igmp-snooping general-query source-ip 192.168.1.2
```

igmp-snooping host-aging-time

To configure the aging time of dynamic multicast members, use the **igmp-snooping host-aging-time** command in the global configuration mode. To disable aging time for dynamic multicast members use the **no** form of the command.

igmp-snooping host-aging-time*time*

no igmp-snooping host-aging-time

Syntax Description

time Specifies the aging time for dynamic multicast members. The range is from 10-1000000 seconds. The default value is 300 seconds.

Command Default

The aging time is set to 300 seconds.

Command Modes

Global configuration

Examples

The following example shows how to configure an aging time of 500 seconds:

```
Device(config)# igmp-snooping host-aging-time 500
```

igmp-snooping max-response-time

To configure the maximum waiting time for deleting group ports after receiving a leave packet, use the **igmp-snooping max-resposne-time** command in the global configuration mode. To disable a maximum waiting time use the **no** form of the command.

igmp-snooping max-response-time *time*

no igmp-snooping max-response-time *time*

Syntax Description	<i>time</i> Configures the maximum waiting time for deleting group ports after receiving a leave packet. The range is from 1-100 seconds. The default value is 10 seconds.
---------------------------	--

Command Default	The default maximum waiting time is 10 seconds.
------------------------	---

Command Modes	Global configuration
----------------------	----------------------

Examples	The following example shows how to configure a maximum response time of 20 seconds:
-----------------	---

```
Device(config)# igmp-snooping max-response-time 20
```


igmp-snooping multicast vlan

To configure multicast VLAN for IGMP packets, use the **igmp-snooping multicast vlan** command in the interface configuration mode. To disable multicast VLAN for IGMP packets, use the **no** form of the command.

igmp-snooping multicast vlan *vlan-id*

no igmp-snooping multicast vlan

Syntax Description	multicast vlan Configures multicast VLAN for the IGMP packets on the port.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to enable multicast VLAN for IGMP packets on VLANs 1-50:

```
Device(config-if-ethernet-1/1) # igmp-snooping multicast vlan 50
```

igmp-snooping {permit|deny}

To configure the default learning rule for multicast groups that are not in the blocked list or the allowed list, use the **igmp-snooping {permit|deny}** command in the global configuration mode. By default, the learning rule for all multicast groups that are not in the blocked list or the allowed list is to learn all multicast groups.

igmp-snooping { permit | deny } { group all | vlanvlan-id

Syntax Description

permit Configures the list of groups that are permitted to join by IGMP snooping.

deny Configures the list of groups that are denied to join by IGMP snooping.

Command Default

Default is to learn all multicast groups that are not in the blocked list or the allowed list

Command Modes

Global configuration

Examples

This example shows how to configure the rule to learn all multicast groups:

```
Device(config)#igmp-snooping permit group all
```

igmp-snooping profile refer

To configure a profile or a list of profiles as a reference for a port, use the **igmp-snooping profile refer** command in the interface configuration mode. You can disable the profile reference of a port using the **no** form of the command.

igmp-snooping profile refer*profile-list*

no igmp-snooping profile refer*profile-list*

Syntax Description	<i>profile-list</i> Configures a list of reference profiles for the port.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples The following example shows how to create reference profile for the port:

```
Device(config-if)# igmp-snooping profile refer 1-5
```

igmp-snooping profile

To create an IGMP Snooping profile, use the **igmp-snooping profile** command in the global configuration mode. To disable IGMP snooping profile use the **no** form of the command.

igmp-snooping profile *profile-id*

no igmp-snooping profile

Syntax Description	<i>profile-id</i> Functions as an identifier for an IGMP Snooping profile. The range is 1-128.
---------------------------	--

Command Default	IGMP Snooping profile is not enabled by default.
------------------------	--

Command Modes	Global configuration
----------------------	----------------------

Examples	The following example shows how to create an IGMP Snooping profile:
-----------------	---

```
Device(config)# igmp-snooping profile 1
```

igmp-snooping {permit|deny} group-range

To configure a port to learn (or not learn) a range of MAC addresses and VLAN ids, use the **igmp-snooping {permit|deny} group-range** command in the interface configuration mode.

igmp-snooping { permit | deny } group-range *MAC-address multi-count multi-count-number* **vlan** *vlan-list*

Syntax Description	multi-count <i>multi-count-number</i> Configures the number of MAC addresses in the group range.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to permit a group range of MAC addresses and VLAN ids:

```
Device(config-if-ethernet-1/1)# igmp-snooping permit group-range 01:00:5e:09:08:07 multi-count  
12 vlan 10
```

igmp-snooping query-interval

To configure the interval for sending general query packets, use the **igmp-snooping query-interval** command in the global configuration mode.

igmp-snooping query-interval *interval*

Syntax Description	<i>interval</i> Configures the interval for sending general query packets. The range is from 1 to 30000 seconds.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure the IGMP Snooping query interval to 500 seconds:

```
Device(config)# igmp-snooping query-interval 500
```

igmp-snooping querier version

To configure the version of the IGMP Snooping querier, use the **igmp-snooping querier version** command in the global configuration mode. The IGMP snooping querier version is set to 2 by default.

igmp-snooping querier version *version-id*

Syntax Description

version-id Configures the version of the IGMP Snooping querier. The range is 2-3. The default version is 2.

Command Default

the querier is set to version 2 by default.

Command Modes

Global configuration

Examples

The following example shows how to configure the IGMP Snooping querier version to version 3:

```
Device(config)# igmp-snooping querier version 3
```

igmp-snooping querier-vlan

To configure VLANs for general query packets, use the **igmp-snooping querier-vlan** command in the global configuration mode. To disable VLANs for query packets use the **no** form of the command.

igmp-snooping querier-vlan *vlan-list*

no igmp-snooping querier-vlan *vlan-list*

Syntax Description	querier-vlan Configures a list of VLANs for general query packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure VLANs for the IGMP-Snooping querier:

```
Device(config)# igmp-snooping querier-vlan 1-50
```


igmp-snooping query-max-respond

To configure the maximum response time for general query packets, use the **igmp-snooping query-max-respond** command in the global configuration mode. To disable a maximum response time, use the **no** form of the command.

igmp-snooping query-max-respond *time*

no igmp-snooping query-max-respond *time*

Syntax Description	<i>time</i> Configures the maximum response time for general query packets. The range is from 1 to 25 seconds.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure the maximum response time for general query packets to 10 seconds:

```
Device(config)# igmp-snooping query-max-respond 10
```

igmp-snooping record-host

To enable recording the MAC address of the source of an IGMP report packet, use the **igmp-snooping record-host** command in the interface configuration mode. To disable the recording of the host MAC address, use the **no** form of the command.

igmp-snooping record-host

no igmp-snooping record-host

Syntax Description	record-host Enables recording the MAC address of the source of an IGMP report packet
---------------------------	---

Command Default	recording is not enabled by default
------------------------	-------------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Examples The following example shows how to configure a port to record the host MAC address

```
Device(config-if-ethernet-1/1)# igmp-snooping record-host
```

igmp-snooping router-port-age

To configure the ageing time for the dynamic route port, use the **igmp-snooping router-port-age** command in the global configuration mode. To disable ageing time for the dynamic route port, use the **no** form of the command.

```
igmp-snooping router-port-age { on | off | age-time }
```

```
no igmp-snooping router-port-age { on | off | age-time }
```

Syntax Description

on Starts router port age

off Stops router port age.

age-time Sets router port age time in seconds. The range is 10-1000000 seconds. The default value is 300 seconds.

Command Default

The router port age is on by default.

Command Modes

Global configuration

Examples

The following example shows how to start the router port age:

```
Device(config)# igmp-snooping router-port-age on
```

igmp-snooping route-port forward

To configure a dynamic route port to forward multicast traffic packets, use the **igmp-snooping route-port forward** command in the global configuration mode. To disable the route port from forwarding multicast traffic packets, use the **no** form of the command.

igmp-snooping route-port forward

no igmp-snooping route-port forward

Syntax Description	forward Configures the port to forward multicast traffic packets.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure a dynamic route port to forward multicast traffic packets:

```
Device(config)# igmp-snooping route-port forward
```

igmp-snooping report-suppression

To enable IGMP Snooping suppression of multicast reports, use the **igmp-snooping report-suppression** command in the global configuration mode. To disable the suppression of multicast reports, use the **no** form of the command.

igmp-snooping report-suppression

no igmp-snooping report-suppression

Syntax Description

report-suppression Enables IGMP Snooping suppression of multicast reports.

Command Default

Report suppression is not enabled by default.

Command Modes

Global configuration

Examples

The following example shows how to enable IGMP Snooping report suppression:

```
Device(config)# igmp-snooping report-suppression
```

igmp-snooping route-port vlan

To configure a static route port, use the **igmp-snooping route-port vlan** command in the global configuration mode. You can disable the static route port by using the **no** form of the command.

igmp-snooping route-port vlan *vlan-id* **interface** { **all** | **channel-group** *channel-group-id* | **ethernet** *interface-number*

no igmp-snooping route-port vlan *vlan-id* **interface** { **all** | **channel-group** *channel-group-id* | **ethernet** *interface-number*

Syntax Description	<i>channel-group-id</i> Specifies the number of the channel group. The range is from 0-5.
	<i>interface-number</i> Specifies the ethernet interface number.

Command Default None.

Command Modes Global configuration

Examples

The following examples shows how to configure all the ports of an interface as static route ports:

```
Device(config)# igmp-snooping route-port vlan 50 interface all
```

ip range

To configure the range of IP addresses and VLAN IDs for an IGMP profile, use the **ip range** command in profile configuration mode.

ip range *start-ip-address end-ip-address* **vlan** *vlan-id*

Syntax Description

<i>start-ip-address</i>	Configures the start IP Address for the IGMP Snooping profile. The IP addresses range is from 224.0.0.1 to 239.255.255.254.
<i>end-ip-address</i>	Configures the end IP Address for the IGMP Snooping profile. The IP addresses range is from 224.0.0.1 to 239.255.255.254.
<i>vlan-id</i>	Configures the range of VLAN IDs for the IGMP Snooping profile. The VLAN id range is from 1 to 4094.

Command Default

None

Profile configuration mode

Examples

The following example shows how to configure the range of IP addresses and VLAN ids for an IGMP Snooping profile.

```
Device(config-igmp-profile-1)# ip range 224.0.0.1 239.255.255.254 vlan 50
```

mac range

To configure the range of MAC addresses and VLAN IDs for an IGMP profile, use the **mac range** command in profile configuration mode.

mac range *start-mac-address end-mac-address* **vlan** *vlan-id*

Syntax Description	
<i>start-mac-address</i>	Configures the start MAC Address for the IGMP Snooping profile. The MAC addresses range is 01:00:5e:H:H:H. .
<i>end-mac-address</i>	Configures the end MAC Address for the IGMP Snooping profile. The MAC addresses range is 01:00:5e:H:H:H.
<i>vlan-id</i>	Configures the range of VLAN IDs for the IGMP Snooping profile. The VLAN id range is from 1 to 4094.

Command Default None

Command Modes Profile configuration

Examples

The following example shows how to configure the range of MAC addresses and VLAN ids for an IGMP Snooping profile.

```
Device(config-igmp-profile-1)# mac range 01:00:5e:09:08:07 01:00:5e:09:09:08 vlan 50
```


mld-snooping

To enable MLD Snooping, use the **mld-snooping** command in the global configuration mode. To disable MLD Snooping, use the **no** form of the command.

mld-snooping

no mld-snooping

Command Default

MLD Snooping is disabled by default.

Command Modes

Global configuration

Examples

The following example shows how to enable MLD Snooping.

```
Device(config)# mld-snooping
```

mld-snooping fast-leave

To remove the port directly from the multicast group upon receiving a Leave message, use the **mld-snooping fast-leave** command in the interface configuration mode. To disable fast leave, use the **no** form of the command.

Command Default Fast leave is not configured by default.

Command Modes Interface configuration

Examples

The following example shows how to configure fast leave:

```
Device(config-if-ethernet-1/1)# mld-snooping fast-leave
```

mld-snooping group-limit

To configure the maximum number of IPv6 multicast groups that an interface or a port can learn or join, use the **mld-snooping group-limit** command in the interface configuration mode. To undo the limit on the maximum number of IPv6 multicast groups that a port can join use the **no** form of the command.

mld-snooping group-limit *number*

no mld-snooping group-limit

Syntax Description	<i>number</i> Specifies the maximum number of IPv6 multicast groups that a port can join. The range is 0-1024.
---------------------------	--

Command Default	No limit is configured by default.
------------------------	------------------------------------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to configure a group limit of 100:

```
Device(config-if-ethernet-1/4)# mld-snooping group-limit 100
```

mld-snooping host-aging-time

To configure the aging time of dynamic multicast ports, use the **mld-snooping host-aging-time** command in the global configuration mode. To disable aging time for dynamic multicast ports use the **no** form of the command.

mld-snooping host-aging-time *time*

no mld-snooping host-aging-time

Syntax Description	<i>time</i> Specifies the aging time for dynamic multicast ports. The range is from 10-1000000 seconds. The default value is 300 seconds.
---------------------------	---

Command Default	The aging time is set to 300 seconds.
------------------------	---------------------------------------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure an aging time of 500 seconds for a host:

```
Device(config)# mld-snooping host-aging-time 500
```

mld-snooping max-response-time

To configure the maximum response time of the leave packets, use the **mld-snooping max-resposne-time** command in the global configuration mode. To disable the maximum response time, use the **no** form of the command.

mld-snooping max-response-time *time*

no mld-snooping max-response-time *time*

Syntax Description

time Configures the maximum waiting time to send a response after receiving a leave packet. The range is from 1-100 seconds. The default value is 10 seconds.

Command Default

The default maximum waiting time is 10 seconds.

Command Modes

Global configuration

Examples

The following example shows how to configure a maximum response time of 20 seconds:

```
Device(config)# mld-snooping max-response-time 20
```

mld-snooping multicast vlan

To configure multicast VLAN with MLD snooping, use the **mld-snooping multicast vlan** command in the global configuration mode.

mld-snooping multicast vlan *vlan_id*

Syntax Description	<i>vlan_id</i>	The VLAN ID. The range is from 1 to 4094.
---------------------------	----------------	--

Command Default None

Command Modes Interface configuration (config-if)

Examples

This example shows how to configure multicast VLAN with MLD snooping:

```
Device> enable
Device# configure terminal
Device(config)# interface gpon 0/1
Device(config-if-gpon-0/1)# mld-snooping multicast vlan 1
```

mld-snooping {permit|deny}{group|vlan}

To specify a learning rule on the device for the multicast groups that are not part of a blocked list or an allowed list, use the **mld-snooping** { **permit** | **deny** } { **group** | **vlan** } command in the global configuration mode.

```
mld-snooping { permit | deny } { group all | vlan vlan-list }
```

Syntax Description

group all Specifies that the learning policy applies to all multicast groups.

vlan *vlan-list* Specifies the VLAN to which the learning policy applies.

Command Default

None

Command Modes

Global configuration

Examples

The following example shows how to permit the learning rule for all multicast groups.

```
Device(config)# mld-snooping permit group all
```

mld-snooping permit deny group MAC vlan

To configure a list of multicast groups that are permitted or denied by MLD snooping in a particular VLAN, use the **mld-snooping { permit | deny } group *MAC* vlan *vlan-id*** in the interface configuration mode.

mld-snooping { permit | deny } group *MAC-address* vlan *vlan-id*

Syntax Description	<i>MAC-address</i> Specifies the list of multicast groups that start at the <i>MAC-address</i>
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to permit a group of MAC addresses in VLAN 5:

```
Device(config-if-ethernet-1/1)# mld-snooping permit group 33:33:5e:09:08:07 vlan 5
```


mld-snooping {permit|deny} group-range

To configure a port to learn (or not learn) a range of MAC addresses and VLAN ids, use the **mld-snooping {permit|deny} group-range** command in the interface configuration mode.

mld-snooping { **permit** | **deny** } **group-range** *MAC-address* **multi-count** *multi-count-number* **vlan** *vlan-list*

Syntax Description	multi-count <i>multi-count-number</i> Configures the number of MAC addresses in the group range.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Interface configuration
----------------------	-------------------------

Examples

The following example shows how to permit a group range of MAC addresses and VLAN ids:

```
Device(config-if-ethernet-1/1)# mld-snooping permit group-range 33:33:5e:09:08:07 multi-count  
12 vlan 10
```

mld-snooping querier

To enable MLD Snooping querier to forward the source address, maximum response time, and query interval for sending general query messages, use the **mld-snooping querier** command in the global configuration mode. To disable MLD Snooping querier, use the **no** form of the command.

mld-snooping querier

Command Default MLD Snooping querier is disabled by default.

Command Modes Global configuration

Examples The following example shows how to enable MLD Snooping querier :

```
Device(config)# mld-snooping querier
```

mld-snooping querier-vlan

To configure VLANs for general query packets, use the **mld-snooping querier-vlan** command in the global configuration mode. To disable VLANs for query packets use the **no** form of the command.

mld-snooping querier-vlan *vlan-id*

no mld-snooping querier-vlan *vlan-id*

Syntax Description	<i>vlan-id</i> Specifies the VLAN that carries the general query packets. The range is 1 to 4094.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples	The following example shows how to configure a VLAN for the MLD Snooping querier: Device(config)# mld-snooping querier-vlan 50
-----------------	--

mld-snooping query-interval

To configure the interval for sending mld snooping general query packets, use the **mld-snooping query-interval** command in the global configuration mode.

mld-snooping query-interval *interval*

Syntax Description	<i>interval</i> Configures the interval for sending mld-snooping general query packets. The range is from 1 to 30000 seconds.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure the MLD Snooping query interval to 3000 seconds:

```
Device(config)# mld-snooping query-interval 3000
```

mld-snooping query-max-respond

To configure the maximum response time for general query packets, use the **mld-snooping query-max-respond** command in the global configuration mode. To disable a maximum response time, use the **no** form of the command

mld-snooping query-max-respond *time*

no mld-snooping query-max-respond *time*

Syntax Description

time Configures the maximum response time for general query packets. The range is from 1 to 25 seconds.

Command Default

None

Command Modes

Global configuration

Examples

The following example shows how to configure the maximum response time for general query packets to 10 seconds:

```
Device(config)# mld-snooping query-max-respond 10
```

mld-snooping route-port forward

To configure a dynamic route port to forward IPv6 multicast traffic packets, use the **mld-snooping route-port forward** command in the global configuration mode. To disable the route port from forwarding IPv6 multicast traffic packets, use the **no** form of the command.

mld-snooping route-port forward

no igmp-snooping route-port forward

Syntax Description	forward Configures the port to forward IPv6 multicast traffic packets.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Examples

The following example shows how to configure a dynamic route port to forward IPv6 multicast traffic packets:

```
Device(config)# mld-snooping route-port forward
```

mld-snooping route-port vlan

To configure a multicast router VLAN and specify the interface to the multicast router, use the **mld-snooping route-port vlan** command in the global configuration mode. You can disable the multicast router VLAN by using the **no** form of the command.

mld-snooping route-port vlan *vlan-id* **interface** { **all** | **ethernet** *interface-number*

no mld-snooping route-port vlan *vlan-id* **interface** { **all** | **ethernet** *interface-number*

Syntax Description

all	Specifies that all ports are multicast router interfaces.
ethernet <i>interface-number</i>	Specifies the ethernet interface number.

Command Default

None.

Command Modes

Global configuration

Examples

The following examples shows how to configure all the ports of an interface as multicast route ports:

```
Device(config)# mld-snooping route-port vlan 50 interface all
```

mld-snooping router-port-age

To configure the ageing time for the dynamic route port, use the **mld-snooping router-port-age** command in the global configuration mode. To disable ageing time for the dynamic route port, use the **no** form of the command.

mld-snooping router-port-age { **on** | **off** | *age-time* }

no mld-snooping router-port-age { **on** | **off** | *age-time* }

Syntax Description

on Starts router port age

off Stops router port age.

age-time Sets router port age time in seconds. The range is 10-1000000 seconds. The default value is 300 seconds.

Command Default

The router port age is on by default.

Command Modes

Global configuration

Examples

The following example shows how to start the router port age:

```
Device(config)# mld-snooping router-port-age on
```


mld-snooping record-host

To enable the port to record the host information, use the **mld-snooping record-host** command in the global configuration mode.

mld-snooping record-host

Command Default None

Command Modes Interface configuration (config-if)

Examples

This example shows how to enable the port to record the host information:

```
Device> enable
Device# configure terminal
Device(config)# interface gpon 0/1
Device(config-if-gpon-0/1)# mld-snooping record-host
```

multicast

To create a static multicast group, use the **multicast** command in the global configuration mode.

```
multicast { mac-address mac-address | ip-address ip-address } vlan vlan-id
```

Syntax Description	
<i>ip-address</i>	Configures the static multicast IP address. It can only be in the format 224.x.x.x.
<i>mac-address</i>	Configures the static multicast MAC address. It can only be in the format 01:00:5e:H:H:H.
<i>vlan-id</i>	Configures the VLANS for the static multicast group.

Command Default Multicast group is not configured by default.

Command Modes Global configuration

The following example shows how to configure a static multicast group:

```
Device(config)# multicast ip-address 224.0.0.3 vlan 50  
Adding multicast group successfully !
```

multicast ds-tag add

To configure the ONT downlink multicast VLAN tag adding rule, use the **multicast ds-tag add** command in line profile configuration mode.

To disable the ONT uplink multicast VLAN tag adding rule, use the **no multicast ds-tag add** command.

multicast ds-tag add *vlan_id* {*priority* | **port** *port_id*}

no multicast ds-tag port *port_id*

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT downlink multicast VLAN tag adding rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast ds-tag add 3
```

multicast ds-tag remove

To configure the ONT downlink multicast VLAN tag removing rule, use the **multicast ds-tag remove port** command in line profile configuration mode. To delete the ONT downlink multicast VLAN tag, use the **no multicast ds-tag port** command

```
multicast ds-tag remove [port port_id]
```

```
no multicast ds-tag [port port_id]
```

Syntax Description

port_id

The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT downlink multicast VLAN tag removing rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast ds-tag remove
```

multicast ds-tag translate

To configure the ONT downlink multicast VLAN tag translating rule, use the **multicast ds-tag translate** command in line profile configuration mode.

```
multicast ds-tag translate vlan_id [priority | port port_id]
```

Syntax Description		
	<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
	<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
	<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes Line profile configuration (deploy-profile-line)

Usage Guidelines You must configure a device type.

Examples

This example shows how to configure the ONT downlink multicast VLAN tag translating rule.

```
Device> enable  
Device# configure terminal  
Device(config)# deploy profile line  
Device(deploy-profile-line)# aim 5  
Device(deploy-profile-line-5)# multicast ds-tag translate 3
```

multicast fast-leave disable

To disable fast-leave, use the **multicast fast-leave disable** command in global configuration mode.

```
multicast fast-leave disable [port port_id]
```

```
no multicast fast-leave disable [port port_id]
```

Syntax Description

port_id

The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to disable fast-leave on a port.

```
Device> enable  
Device# configure terminal  
Device(config)# deploy profile line  
Device(deploy-profile-line)# aim 5  
Device(deploy-profile-line-5)# multicast fast-leave disable
```

multicast group-limit

To configure the limit of multicast groups, use the **multicast group-limit** *limit_number* command in line profile configuration mode. To disable the limit of multicast groups, use the **no multicast group-limit** *limit_number* command.

multicast group-limit *limit_number* [**port** *port_id*]

no multicast group-limit *limit_number* [**port** *port_id*]

Syntax Description

limit_number

The multicast group limit. The range is from 1 to 255.

port_id

The ONT Ethernet port ID. The range is from 1 to 255.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the limit of multicast groups.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast group-limit 4
```

multicast interface

To add a port to a static multicast group, use the **multicast interface** command in the global configuration mode.

multicast { **mac-address** *mac-address* | **ip-address** *ip-address* } **vlan** *vlan-id* **interface** { **all** | *interface-list* }

Syntax Description	<i>all</i> Adds all the ports of the interface to the static multicast group.
	<i>interface-list</i> Adds the specified ports of the interface to the static multicast group.
Command Default	None.
Command Modes	Global configuration

The following example shows how to add all the ports of an interface to a static multicast group:

```
Device(config)# multicast ip-address 224.0.0.11
vlan 1 interface all
```


multicast mode igmp-snooping

To enable Internet Group Management Protocol (IGMP) snooping, use the **multicast mode igmp-snooping** command in line profile configuration mode.

multicast mode igmp-snooping [**port** *port_id*]

Syntax Description

port_id

The ONT Ethernet port ID. The range is from 1 to

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable IGMP snooping on a port.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast mode igmp-snooping port 10
```

multicast proxy-interval

To configure the interval at which the device sends report packets to the multicast source through the proxy port, use the **multicast proxy-interval** command in the global configuration mode.

multicast proxy-interval *seconds*

Syntax Description	proxy-interval Configures the interval at which the device sends report packets to the multicast source through the proxy port.
	<i>seconds</i> Configures the proxy-interval in seconds. The range is from 1-300. The default is 10 seconds.
Command Default	The default interval is 10 seconds.
Command Modes	Global configuration

Example

The following example shows how to configure the proxy-interval to 100 seconds

```
Device(config)# multicast proxy-interval 100
```

multicast proxy-port

To configure a proxy-port for the static multicast group, use the **multicast proxy-port** command in the global configuration mode.

```
multicast { mac-address mac-address | ip-address ip-address } vlan vlan-id proxy-port ethernet port-id
```

Syntax Description	proxy-port Configures a proxy port to send the multicast report to the multicast source.
	<i>port-id</i> Configures the port that will act as the proxy port.
Command Default	None
Command Modes	Global configuration

The following example shows how to configure a proxy port for a static multicast group:

```
Device(config)# multicast ip-address 225.0.0.11 vlan 1 proxy-port ethernet 1/1
```

multicast us-tag add

To configure the ONT uplink multicast VLAN tag adding rule, use the **multicast us-tag add** command in line profile configuration mode. To disable the ONT uplink multicast VLAN tag adding rule, use the **no multicast us-tag add** command.

```
multicast us-tag add vlan_id {priority | port port_id}
```

```
no multicast us-tag port port_id
```

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT uplink multicast VLAN tag adding rule

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast us-tag add 3
```

multicast us-tag translate

To configure the ONT downlink multicast VLAN tag translating rule, use the **multicast us-tag translate** command in line profile configuration mode. To disable the ONT downlink multicast VLAN tag translating rule, use the **no multicast us-tag translate** command

```
multicast us-tag translate vlan_id {priority | port port_id}
```

```
no multicast us-tag port port_id
```

Syntax Description

<i>vlan_id</i>	The VLAN ID The range is from 1 to 4094.
<i>priority</i>	The 802.1 priority value. The range is from 0 to 7.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT uplink multicast VLAN tag translating rule.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# multicast us-tag translate 3
```

profile limit

To configure the IGMP snooping profile type as a permit or deny profile, use the **profile limit** command in the profile configuration mode.

profile limit { **permit** | **deny** }

Syntax Description	permit Configures a list of groups that are permitted by the IGMP Snooping profile.
	deny Configures a list of groups that are denied by the IGMP Snooping profile.

Command Default	None
------------------------	------

Command Modes	Profile configuration
----------------------	-----------------------

Examples

The following example shows how to configure a permit type profile:

```
Device(config-igmp-profile-1)# profile limit permit
```

show igmp-snooping

To displays IGMP Snooping configurations, use the **show igmp-snooping** command in the EXEC mode.

show igmp-snooping

Syntax Description	igmp-snooping Displays IGMP Snooping configurations.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows the output from **show igmp-snooping** command on an interface where IGMP Snooping is enabled:

```
Device# show igmp-snooping
Enable IGMP-Snooping
Disable IGMP-Snooping report-suppression
The max response time is 10 second(s)
The host aging time is 300 second(s).
Disable IGMP-Snooping route-port forward
The Router port timeout is 300 second(s), Currently aging is running
Denied VLAN:
Blocked list:
NULL
Allowed list:
NULL
Default group policy is permit
IGMP-Snooping Querier : ON
Querier vlan : 1
Querier Source IP 0.0.0.0 | Max Query Respond Time 10 sec | Query interval 60
sec | Igmp version 2
Port Information:
port  limit  action  fast-leave  mcast-vlan  igmp-profile  drop-type
p0/1   1024   drop   disabled   disabled   disabled      null
p0/2   1024   drop   disabled   disabled   disabled      null
p0/3   1024   drop   disabled   disabled   disabled      null
p0/4   1024   drop   disabled   disabled   disabled      null
p0/5   1024   drop   disabled   disabled   disabled      null
p0/6   1024   drop   disabled   disabled   disabled      null
p0/7   1024   drop   disabled   disabled   disabled      null
p0/8   1024   drop   disabled   disabled   disabled      null
e1/1   1024   drop   disabled   disabled   1             null
e1/2   1024   drop   disabled   disabled   disabled      null
e1/3   1024   drop   disabled   disabled   disabled      null
e1/4   1024   drop   disabled   disabled   disabled      null
e2/1   1024   drop   disabled   disabled   disabled      null
e2/2   1024   drop   disabled   disabled   disabled      null
```

show igmp-snooping profile

To display the details of an IGMP Snooping profile, use the **show igmp-snooping profile** command in the EXEC mode.

showigmp-snooping profile {*profile-id* | **interface** *port-id* | **vlan** *vlan-id*}

Syntax Description	
<i>profile-id</i>	Displays the details of the particular IGMP Snooping profile
<i>port-id</i>	Displays the IGMP Snooping profile details for the port.
<i>vlan-id</i>	Displays the IGMP Snooping profile details for the VLANs.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example displays the output of the **show igmp-snooping profile** command:

```
Device# show igmp-snooping profile 1

IGMP-Snooping profile 1
Profile description :
Profile limit       : permit
Profile referred    : e1/1.
start-address       end-address      vlan
224.0.0.1           239.255.255.254    any
Total ip range: 1, mac range: 0

Total profiles: 1, IP&MAC ranges: 1
```


show igmp-snooping record-host

To display the MAC address of the record host, use the **show igmp-snooping record-host** command in the EXEC mode.

```
show igmp-snooping record-host [interface-id]
```

Syntax Description	record-host Displays the MAC address of the record host.
	<i>interface-id</i> Displays the MAC address of the record host for the interface.

Command Default	None
------------------------	------

Command Modes	User EXEC Privileged EXEC
----------------------	------------------------------

Examples

The following example shows the output of the **show igmp-snooping record-host** command:

```
Device# show igmp-snooping record-host  
show host record information  
Total Record: 0
```

show igmp-snooping router-dynamic

To display the dynamic route ports, use the **show igmp-snooping router-dynamic** command in the EXEC mode.

show igmp-snooping router-dynamic

Syntax Description	router-dynamic	Displays the dynamic route ports.
--------------------	----------------	-----------------------------------

Command Default	None
-----------------	------

Command Modes	User EXEC Privileged EXEC
---------------	------------------------------

Examples

The following example shows the output from **show igmp-snooping router-dynamic** command on an interface where IGMP Snooping is enabled:

```
Device# show igmp-snooping router-dynamic
Port      VID      Age      Type
e1/3      100      237      { QUERY }
Total Record: 1
```

show igmp-snooping router-static

To display the static route ports on an interface or on a multicast VLAN, use the **show igmp-snooping router-static** command in the EXEC mode.

show igmp-snooping router-static [**interface** { **channel-group** *channel-group-id* | **ethernet** *port* } | **vlan** *vlan-id*]

Syntax Description	router-static	Displays the static router ports.
	<i>channel-group-id</i>	Displays the static ports for a LACP channel group. The range is 0-5.
	<i>vlan-id</i>	Displays the static ports for Multicast VLANs.

Command Default None

Command Modes User EXEC
Privileged EXEC

Examples

The following example shows the output from **show igmp-snooping router-static** command on an interface where IGMP Snooping is enabled:

```
Device# show igmp-snooping router-static interface channel-group 1
  Port      VID      Age      Type
Total Record: 0
```

show mld-snooping

To display information about MLD snooping related configuration, use the **show mld-snooping** command in privileged EXEC or global configuration mode.

show mld-snooping

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about MLD snooping.

```
Device> enable
Device# configure terminal
Device(config)# show mld-snooping
Enable MLD-Snooping
The max response time is 10 second(s)
The host port timeout is 300 second(s).
Enable MLD-Snooping route-port forward
The Router port timeout is 300 second(s), Currently aging is running
Denied VLAN
Blocked list:
NULL
Allowed list:
NULL
Default group policy is permit
MLD-Snooping Querier : ON
Querier vlan : 101
Max Respond Time 25 sec | Query interval 60 sec
Port Information:
port  groups-limit  fast-leave  mcast-vlan
p0/1  1024             enabled     disabled
p0/2  1024             disabled    disabled
p0/3  1024             disabled    disabled
p0/4  1024             disabled    disabled
p0/5  1024             disabled    disabled
p0/6  1024             disabled    disabled
p0/7  1024             disabled    disabled
p0/8  1024             disabled    disabled
p0/9  1024             disabled    disabled
p0/10 1024             disabled    disabled
p0/11 1024             disabled    disabled
p0/12 1024             disabled    disabled
p0/13 1024             disabled    disabled
p0/14 1024             disabled    disabled
p0/15 1024             disabled    disabled
p0/16 1024             disabled    disabled
e1/1  1024             disabled    disabled
e1/2  1024             disabled    disabled
e1/3  1024             disabled    disabled
e1/4  1024             disabled    disabled
e2/1  1024             disabled    disabled
e2/2  1024             disabled    disabled
```

show mld-snooping router-dynamic

To display the information of dynamic routing port, use the **show mld-snooping router-dynamic** command in privileged EXEC or global configuration mode.

show mld-snooping router-dynamic

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about dynamic routing port.

```
Device> enable
Device# configure terminal
Device(config)# show mld-snooping router-dynamic
  Port      VID      Age      Type
  e1/3      101      300     { QUERY }
Total Record: 1
```

show mld-snooping router-static

To display the information of static routing port, use the **show mld-snooping router-static** command in privileged EXEC or global configuration mode.

show mld-snooping router-static

Command Modes

Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about static routing port.

```
Device> enable
Device# configure terminal
Device(config)# show mld-snooping router-static
  Port      VID      Age      Type
Total Record: 0
```

show multicast mld-snooping

To display multicast information, use the **show multicast mld-snooping** command in privileged EXEC or global configuration mode.

show multicast mld-snooping interface { **ethernet** | **gpon** } *slot-num/port-num*

Syntax Description	<i>slot-num/port-num</i>	The port ID.
		<ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.

Command Modes Privileged EXEC (#)

Global configuration (config)

Examples

This example shows how to view information about multicast.

```
Device> enable
Device# configure terminal
Device(config)# show multicast mld-snooping interface gpon 0/1
show mld-snooping multicast table information

MAC Address   : 33:33:00:00:00:0c
IP Address    : FF02::C
VLAN ID       : 101
Age time      : 274
MLD Port      : g0/1
MLD Version   : V1,V2

MAC Address   : 33:33:00:00:00:fb
IP Address    : FF02::FB
VLAN ID       : 101
Age time      : 283
MLD Port      : g0/1
MLD Version   : V1,V2

MAC Address   : 33:33:00:01:00:03
IP Address    : FF02::1:3
VLAN ID       : 101
Age time      : 299
MLD Port      : g0/1
MLD Version   : V2
```

show multicast mld-snooping

MAC Address : 33:33:ff:00:00:90
IP Address : FF02::1:FF00:90
VLAN ID : 101
Age time : 265
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:00:01:01
IP Address : FF02::1:FF00:101
VLAN ID : 101
Age time : 283
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:01:04:46
IP Address : FF02::1:FF01:446
VLAN ID : 101
Age time : 272
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:0a:7d:ec
IP Address : FF02::1:FF0A:7DEC
VLAN ID : 101
Age time : 283
MLD Port : g0/1
MLD Version : V2

MAC Address : 33:33:ff:35:db:cf
IP Address : FF02::1:FF35:DBCF
VLAN ID : 101
Age time : 273
MLD Port : g0/1
MLD Version : V2

MAC Address : 33:33:ff:3d:30:3b
IP Address : FF02::1:FF3D:303B
VLAN ID : 101
Age time : 270
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:53:25:fe
IP Address : FF02::1:FF53:25FE
VLAN ID : 101
Age time : 283
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:87:2c:93
IP Address : FF02::1:FF87:2C93
VLAN ID : 101
Age time : 276
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:8d:03:30
IP Address : FF02::1:FF8D:330
VLAN ID : 101
Age time : 279
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:a2:7b:3e
IP Address : FF02::1:FFA2:7B3E
VLAN ID : 101
Age time : 270
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:ba:22:cb
IP Address : FF02::1:FFBA:22CB
VLAN ID : 101
Age time : 283
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:da:4e:79
IP Address : FF02::1:FFDA:4E79
VLAN ID : 101
Age time : 270
MLD Port : g0/1
MLD Version : V1,V2

MAC Address : 33:33:ff:e5:01:41
IP Address : FF02::1:FFE5:141
VLAN ID : 101
Age time : 283
MLD Port : g0/1
MLD Version : V1,V2

Total Record: 16

show multicast igmp-snooping

To display igmp-snooping multicast table information, use the **show multicast igmp-snooping** command in the EXEC mode.

```
show multicast igmp-snooping { interfaceinterface-id | ip-address ip-address }
```

Syntax Description

interface-id Displays the IGMP Snooping multicast table for the interface.

ip-address Displays the IGMP Snooping multicast table for the IP address.

Command Default

None

Command Modes

User EXEC
Privileged EXEC

Examples

The following example displays the output of the **show multicast igmp snooping** command for an interface:

```
Device# show multicast igmp-snooping interface ethernet 1/1  
show igmp-snooping multicast table information Total Record: 0
```

show ont multicast

To display information about the multicast learning table on an ONT, use the **show ont multicast** command in privileged EXEC or global configuration mode.

show ont multicast *slot-num/pon-num/ont-num* [**port** *port-id*]

Syntax Description		
	<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 0 to 255. • <i>ont-num</i>: The ONT number. The range is from 0 to 255.
	<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Privileged EXEC (#)
Global configuration (config)

Examples

This example shows how to view the information about the multicast learning table on an ONT.

```
Device> enable
Device# configure terminal
Device(config)# show ont multicast 0/1/1
```

show running-config mld_snooping

To display the running MLD Snooping configuration, use the **show running-config mld_snooping** command in the EXEC mode.

show running-config mld_snooping

Syntax Description	mld_snooping	Displays the running MLD snooping configuration.
Command Default	None.	
Command Modes	User EXEC Privileged EXEC	

The following example shows a sample output of the show running-config mld_snooping command.

```
Device#show running-config mld_snooping

! [MLD_SNOOPING]
mld-snooping
mld-snooping route-port forward
mld-snooping query-max-respond 25
mld-snooping querier
mld-snooping querier-vlan 101
interface gpon 0/1
mld-snooping fast-leave
mld-snooping record-host
mld-snooping multicast vlan 1
exit
```



PART **IX**

System Management

- [System Management, on page 461](#)



System Management

- [alarm all-packets, on page 463](#)
- [alarm all-packets threshold, on page 464](#)
- [alarm cpu, on page 465](#)
- [alarm cpu threshold, on page 466](#)
- [buildrun mode , on page 467](#)
- [clear startup-config, on page 468](#)
- [clock summer-time, on page 469](#)
- [clock timezone, on page 470](#)
- [copy running-config startup-config, on page 471](#)
- [copy startup-config running-config, on page 472](#)
- [load ftp, on page 473](#)
- [load tftp, on page 474](#)
- [load xmodem, on page 475](#)
- [local fec, on page 476](#)
- [ntp access, on page 477](#)
- [ntp authentication, on page 478](#)
- [ntp broadcast, on page 479](#)
- [ntp disable, on page 480](#)
- [ntp max-dynamic-sessions, on page 481](#)
- [ntp multicast, on page 482](#)
- [ntp unicast peer, on page 483](#)
- [ntp unicast server, on page 484](#)
- [show alarm all-packets, on page 485](#)
- [show alarm cpu, on page 486](#)
- [show clock, on page 487](#)
- [show ntp access, on page 488](#)
- [show ntp authentication, on page 489](#)
- [show ntp broadcast server, on page 490](#)
- [show ntp disable, on page 491](#)
- [show ntp max-dynamic-sessions, on page 492](#)
- [show ntp multicast server, on page 493](#)
- [show ntp sessions, on page 494](#)
- [show ntp status, on page 495](#)

- [show ntp unicast peer](#), on page 496
- [show ntp unicast server](#), on page 497
- [show running-config](#), on page 498
- [show sntp client](#), on page 499
- [show startup-config](#), on page 500
- [sntp client](#), on page 501
- [sntp client authenticate](#), on page 502
- [sntp client authentication-key](#), on page 503
- [sntp client broadcastdelay](#), on page 504
- [sntp client mode](#), on page 505
- [sntp client poll-interval](#), on page 506
- [sntp client retransmit-interval](#), on page 507
- [sntp client retransmit](#), on page 508
- [sntp client valid-server](#), on page 509
- [sntp server](#) , on page 510
- [sntp trusted-key](#), on page 511
- [upload automatically configuration ftp](#), on page 512
- [upload automatically configuration tftp](#), on page 513
- [upload ftp](#), on page 514
- [upload tftp](#), on page 515

alarm all-packets

To enable alarms on all ports, use the **alarm all-packets** command in global configuration mode.

To enable alarms on a specific port, use the **alarm all-packets** command in interface configuration mode.

alarm all-packets

no alarm all-packets

Command Modes

Global configuration (config)

Interface configuration (config-if)

Examples

The following example shows how to enable alarms on all ports of the device:

```
Device> enable
Device# configure terminal
Device(config)# alarm all-packets
Enable port alarm successfully.
```

alarm all-packets threshold

To configure the port threshold information for alarms, use the **alarm all-packets threshold** command in interface configuration mode.

alarm all-packets threshold {**normal** *normal-value* | **exceed** *exceed-value*}

Syntax Description		
normal <i>normal-value</i>		Sets the minimum port bandwidth utilization threshold for the port.
exceed <i>exceed-value</i>		Sets the maximum port bandwidth utilization threshold for the port.

Command Modes Interface configuration mode (config-if)

Examples

The following example shows how to set the port thresholds using the **alarm all-packets threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# interface gpon 0/1
Device(config-if-gpon-0/1)# alarm all-packets threshold exceed 34 normal 4
```

alarm cpu

To enable CPU alarms, use the **alarm cpu** command in global configuration mode.

alarm cpu
no alarm cpu

Command Modes

Global configuration mode (config)

Examples

The following example shows how to enable CPU alarms:

```
Device> enable
Device# configure terminal
Device(config)# alarm cpu
```

alarm cpu threshold

To configure the threshold information for CPU alarms, use the **alarm cpu threshold** command in global configuration mode.

alarm cpu threshold {*busy busy-value* | *unbusy unbusy-value*}

Syntax Description		
busy <i>busy-value</i>		Sets the minimum CPU utilization threshold.
unbusy <i>unbusy-value</i>		Sets the maximum CPU utilization threshold.

Command Modes Global configuration mode (config)

Examples

The following example shows how to set the CPU thresholds using the **alarm cpu threshold** command:

```
Device> enable
Device# configure terminal
Device(config)# alarm cpu threshold busy 63 unbusy 20
```

buildrun mode

To configure the file execution mode, use the **buildrun mode** command in privileged EXEC mode.

buildrun mode {**continue** | **stop**}

Syntax Description

continue	Sets the execution mode to non-interruptible.
stop	Sets the execution mode to interruptible.

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **buildrun mode stop** command:

```
Device> enable
Device# buildrun mode stop
```

clear startup-config

To clear the startup configuration, use the **clear startup-config** command in privileged EXEC mode.

clear startup-config

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **clear startup-config** command:

```
Device> enable
Device# clear startup-config
```

clock summer-time

To set the clock daylight savings time, use the **clock summer-time** command in global configuration mode.

```
clock summer-time { daily | weekly } start-time
```

Syntax Description

start-time

Specifies the start time for daylight savings. The daylight savings time format must be entered in hour, minutes and, seconds (HH:MM:SS).

Command Modes

Global configuration mode (config)

Examples

The following example shows how to configure the daylight savings using the **clock summer-time** command:

```
Device> enable  
Device# configure terminal  
Device(config)# clock summer-time daily 00:00:00 2021/03/12 00:00:00 2021/11/05
```

clock timezone

To configure the system time zone, use the **clock timezone** command in global configuration mode.

clock timezone *timezone-name* *hours-offset* *minutes-offset*
no clock timezone

Syntax Description		
	<i>timezone-name</i>	Specifies the timezone to the SNTP client.
	<i>hours-offset</i> <i>minutes-offset</i>	Specifies the hours and minutes offset from the timezone to the SNTP client.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure a timezone on the SNTP client using the **clock timezone** command:

```
Device> enable
Device# configure terminal
Device(config)# clock timezone ch 3 43
```


copy running-config startup-config

To copy the current configuration to the flash config file, use the **copy running-config startup-config** command in privileged EXEC mode.

copy running-config startup-config

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **copy running-config startup-config** command:

```
Device> enable
Device# copy running-config startup-config
Startup config in flash will be updated, are you sure(y/n)? [n]
```

copy startup-config running-config

To copy the startup configuration from the flash config file to the current configuration, use the **copy startup-config running-config** command in privileged EXEC mode.

copy startup-config running-config

Command Modes

Privileged EXEC (#)

Examples

The following is an example of the **copy startup-config running-config** command:

```
Device> enable
Device# copy startup-config running-config
Running config will be updated, are you sure(y/n)? [n]
```

load ftp

To download a file with the FTP server, use the **load ftp** command in privileged EXEC mode.

load {**application** | **configuration** | **edfa** | **epld** | **keyfile** {**private** | **public**} | **ont-image** | **whole-bootrom**} **ftp** {**inet** | **inet6**} *ftp-server-ip-address file-name ftp-username ftp-password*

Syntax Description		
	application	Specifies the host file.
	configuration	Specifies the configuration file.
	edfa	Specifies the EDFA file.
	epld	Specifies the EPLD file.
	keyfile	Specifies the SSH keyfile.
	private	Specifies the SSH private keyfile.
	public	Specifies the SSH public keyfile.
	ont-image	Specifies the ONT image file.
	whole-bootrom	Specifies the whole bootrom file.
	inet	Specifies IPv4 address family.
	inet6	Specifies IPv6 address family.
	<i>ftp-server-ip-address</i>	Specifies the IP address of the FTP server.
	<i>file-name</i>	Specifies the name of the file to be uploaded.
	<i>ftp-username</i>	Specifies the user name of the FTP server.
	<i>ftp-password</i>	Specifies the password of the FTP server.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to download a whole bootrom file with an FTP server using the **load ftp** command:

```
Device> enable
Device# load whole-bootrom tftp inet 10.23.13.1 bootrom1.bin
```

load tftp

To download a file with the TFTP server, use the **load tftp** command in privileged EXEC mode.

```
load {application | configuration | edfa | epld | keyfile {private | public} | ont-image | whole-bootrom} tftp
{inet | inet6} tftp-server-ip-address file-name
```

Syntax Description

application	Specifies the host file.
configuration	Specifies the configuration file.
edfa	Specifies the EDFA file.
epld	Specifies the EPLD file.
keyfile	Specifies the SSH keyfile.
private	Specifies the SSH private keyfile.
public	Specifies the SSH public keyfile.
ont-image	Specifies the ONT image file.
whole-bootrom	Specifies the whole bootrom file.
inet	Specifies IPv4 address family.
inet6	Specifies IPv6 address family.
<i>tftp-server-ip-address</i>	Specifies the IP address of the TFTP server.
<i>file-name</i>	Specifies the name of the file to be uploaded.

Command Modes

Privileged EXEC (#)

Examples

The following example shows how to download a whole bootrom file with a TFTP server using the **load tftp** command:

```
Device> enable
Device# load whole-bootrom tftp inet6 10:23::11:1 bootrom1.bin
```

load xmodem

To download a file with the XMODEM, use the **load ftp** command in privileged EXEC mode.

load {application | configuration | whole-bootrom}xmodem

Syntax Description		
	application	Specifies the host file.
	configuration	Specifies the configuration file.
	whole-bootrom	Specifies the whole bootrom file.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to download a whole bootrom file with an XMODEM using the **load xmodem** command:

```
Device> enable
Device# load whole-bootrom xmodem
```

local fec

To enable the ONT uplink FEC, use the **local fec** command in line profile configuration mode. To disable the ONT uplink FEC, use the **no local fec** command.

local fec

no local fec

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable the ONT uplink FEC

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(config-profile-line)# aim 5
Device(config-profile-line-5)# local fec
```

ntp access

To configure access control for Network Time Protocol (NTP) services, use the **ntp access** command in global configuration mode. To disable NTP settings, use the **no access** form of the command.

```
ntp access ip-address { permit | deny }
```

```
no ntp access ip-address { permit | deny }
```

Syntax Description

access <i>ip-address</i>	Specifies the control access for an IPv4 or IPv6 access list to the NTP services.
permit	Permits the NTP services.
deny	Denies the NTP services

Command Modes

Global configuration (config)

Examples

The following example shows how to enable NTP authentication using the **ntp access** command:

```
Device> enable  
Device# configure terminal  
Device(config)# ntp access 192.168.0.10 255.255.255.0 permit
```

ntp authentication

To enable NTP authentication and configure NTP settings, use the **ntp authentication** command in global configuration mode. To disable NTP settings, use the **no** form of the command.

ntp authentication authentication-keyid *key_id* **md5** *key_string*

no ntp authentication authentication-keyid *key_id* **md5** *key_string*

Syntax Description	authentication	Enables NTP authentication.
	authentication-keyid <i>key_id</i> md5 <i>key_string</i>	Specifies an authentication key for a trusted NTP source. <ul style="list-style-type: none"> • <i>key_id</i>: The authentication key. The range is from 1 to 65535. • md5: Message Digest 5 (MD5) algorithm authentication support • <i>key_string</i>: Key value. The maximum length is 32 characters.

Command Modes Global configuration (config)

Examples

The following example shows how to enable NTP authentication using the **ntp authentication** command:

```
Device> enable
Device# configure terminal
Device(config)# ntp authentication
```


ntp broadcast

To configure NTP broadcast mode, use the **ntp broadcast** command in interface configuration mode. To disable NTP settings, use the **no** form of the command.

```
ntp broadcast { server authentication-keyid key_id | client }
```

```
no ntp broadcast { server authentication-keyid key_id | client }
```

Syntax Description

authentication-keyid *key_id* Specifies an authentication key for a trusted NTP source.

key_id: The authentication key. The range is from 1 to 65535.

Command Modes

Interface configuration (config-if)

Examples

The following example shows how to configure the NTP broadcast mode using **ntp broadcast** command:

```
Device> enable  
Device# configure terminal  
Device(config)# interface vlan-interface 1  
Device(config-if-vlaninterface-1)# ntp broadcast server
```

ntp disable

To disable NTP incoming packets, use the **ntp disable** command in interface configuration mode. To disable NTP settings, use the **no** form of the command.

ntp disable

no ntp disable

Command Modes

Interface configuration (config-if)

Examples

The following example shows how to disable NTP incoming packets using the **ntp disable** command:

```
Device> enable
Device# configure terminal
Device(config)# interface vlan-interface 1
Device(config-if-vlaninterface-1)# ntp disable
```

ntp max-dynamic-sessions

To configure maximum number of dynamic NTP sessions, use the **ntpmax-dynamic-sessions** command in global configuration mode. To disable NTP settings, use the **no** form of the command.

```
ntp max-dynamic-sessions value
```

```
no ntp max-dynamic-sessions value
```

Syntax Description	max-dynamic-sessions <i>value</i>	Specifies the maximum number of dynamic sessions. <i>value</i> : The range is from 11 to 100.
---------------------------	---	--

Command Modes	Interface configuration (config-if)
----------------------	-------------------------------------

Examples

The following example shows how to configure maximum number of dynamic NTP sessions using the **ntp authentication** command:

```
Device> enable
Device# configure terminal
Device(config)# ntp max-dynamic-sessions 10
```

ntp multicast

To configure NTP multicast mode, use the **ntp multicast** command in global configuration mode. To disable NTP settings, use the **no** form of the command.

```
ntp multicast { server authentication-keyid key_id | client }
```

```
no ntp multicast { server authentication-keyid key_id | client }
```

Syntax Description

authentication-keyid *key_id* Specifies an authentication key for a trusted NTP source.

key_id: The authentication key. The range is from 1 to 65535.

Command Modes

Interface configuration (config-if)

Examples

The following example shows how to configure the NTP multicast mode using **ntp multicast** command:

```
Device> enable  
Device# configure terminal  
Device(config)# interface vlan-interface 1  
Device(config-if-vlaninterface-1)# ntp multicast server
```

ntp unicast peer

To configure synchronization to an NTP-configured peer device, use the **ntp unicast peer** command in global configuration mode. To disable NTP settings, use the **no** form of the command.

```
ntp unicast peer ip-address [ authentication-keyid key_id ]
```

```
no ntp unicast peer ip-address [ authentication-keyid key_id ]
```

Syntax Description

peer *ip-address* Specifies the system clock to synchronize a peer or to be synchronized by a peer
ip-address: IPv4 or IPv6 address of the peer device.

Command Modes

Global configuration (config)

Examples

The following example shows how to configure synchronization to an NTP-configured peer device using the **ntp unicast peer** command:

```
Device> enable  
Device# configure terminal  
Device(config)# ntp unicast peer 192.168.0.10
```

ntp unicast server

To configure client mode, use the **ntp unicast server** command in global configuration mode. To disable NTP settings, use the **no** form of the command.

```
ntp unicast server ip-address [ authentication-keyid key_id ]
```

```
no ntp unicast server ip-address [ authentication-keyid key_id ]
```

Syntax Description

server*ip-address* Specifies the system clock to be synchronized by a time server.
ip-address: IPv4 or IPv6 address of the time server.

Command Modes

Global configuration (config)

Examples

The following example shows how to configure client mode using the **ntp unicast server** command:

```
Device> enable  
Device# configure terminal  
Device(config)# ntp unicast server 192.168.0.11
```

show alarm all-packets

To display the port alarm information, use the **show alarm all-packets** command in global configuration mode or interface configuration mode.

```
show alarm all-packets [interface port-number]
```

Syntax Description	interface <i>port-number</i>	Specifies the interface.
---------------------------	-------------------------------------	--------------------------

Command Modes	Global configuration mode (config) Interface configuration mode (config-if)
----------------------	--

Examples	The following is a sample output of the show alarm all-packets command:
-----------------	--

show alarm cpu

To display the CPU alarm information, use the **show alarm all-packets** command in global configuration mode.

show alarm cpu

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show alarm cpu** command:

```
Device(config)# show alarm cpu
CPU status alarm : enable
CPU busy threshold(%) : 90
CPU unbusy threshold(%) : 85
CPU status : unbusy
```


show clock

To display the system clock, use the **show clock** command in global configuration mode.

show clock

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show clock** command:

```
Device> enable
Device# configure terminal
Device(config)# show clock
Mon 2020/4/30 04:25:07 CCT 08:00
```

show ntp access

To display the NTP access configuration, use the **show ntp access** command in global configuration mode.

show ntp access

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp access** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp access
```

show ntp authentication

To display NTP authentication configuration, use the **show ntp authentication** command in global configuration mode.

show ntp authentication

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp authentication** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp authentication
```

show ntp broadcast server

To display the NTP broadcast server configuration, use the **show ntp broadcast server** command in global configuration mode.

show ntp broadcast server

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp broadcast server** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp broadcast server
```

show ntp disable

To disable NTP configuration, use the **show ntp disable** command in global configuration mode.

show ntp disable

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp disable** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp disable
```

show ntp max-dynamic-sessions

To display the maximum number of dynamic sessions, use the **show ntp max-dynamic-sessions** command in global configuration mode.

show ntp max-dynamic-sessions

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp max-dynamic-sessions** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp max-dynamic-sessions
```

show ntp multicast server

To display the NTP multicast server configuration, use the **show ntp multicast server** command in global configuration mode.

show ntp multicast server

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp multicast server** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp multicast server
```

show ntp sessions

To display the NTP session details, use the **show ntp sessions** command in global configuration mode.

show ntp sessions

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp sessions** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp sessions
```


show ntp status

To display the NTP status configuration, use the **show ntp status** command in global configuration mode.

show ntp status

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp status** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp status
```

show ntp unicast peer

To display the NTP unicast peer configuration, use the **show ntp unicast peer** command in global configuration mode.

show ntp unicast peer

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp unicast peer** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp unicast peer
```

show ntp unicast server

To display the NTP unicast server configuration, use the **show ntp unicast server** command in global configuration mode.

show ntp unicast server

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show ntp unicast server** command:

```
Device> enable
Device# configure terminal
Device(config)# show ntp unicast server
```

show running-config

To display the current system configuration, use the **show running-config** command in the privileged EXEC mode or global configuration mode.

show running-config {*module* | **interface** {**ethernet** *port-id* | **gpon** *port-id* | **loopback-interface** *loopback-interface-number* | **vlan-interface** *vlan-id*}} **perlines** *lines-per-page*

Syntax Description		
	<i>module</i>	Specifies a module.
	interface	Specifies an interface.
	ethernet <i>port-id</i>	Displays the ethernet port configuration.
	gpon <i>port-id</i>	Displays the GPON port configuration.
	loopback-interface <i>loopback-interface-number</i>	Displays the loopback interface configuration.
	vlan-interface <i>vlan-id</i>	Displays the VLAN configuration.
	perlines <i>lines-per-page</i>	Specifies the number of lines displayed per page.

Command Modes Privileged EXEC (#)
Global configuration mode (config)

Examples

The following is a sample output from the **show running-config interface vlan-interface** command:

```
Device> enable
Device# show running-config interface vlan-interface

Building configuration...
![vlan-interface 1]
ip address range 192.0.2.254 192.0.2.255
description interface1
![vlan-interface 100]
ip address 10.75.171.17 255.255.255.0
end
```

show sntp client

To display SNTP client configurations, use the **show sntp client** command in global configuration mode.

show sntp client

Command Modes

Global configuration mode (config)

Examples

The following is a sample output of the **show sntp client** command:

```
Device> enable
Device# configure terminal
Device(config)# show sntp client
Clock state : synchronized          Current mode : anycast
Use server : 192.168.1.99           State : idle
Server state : synchronized         Server stratum : 1
Retrans-times: 3                    Retrans-interval: 30s
Authenticate : enable               Authentication-key: 1
Poll interval : 1000s
Last synchronized time: THU NOV 26 09:22:25 2015
```

show startup-config

To display the startup configuration, use the **show startup-config** command in the privileged EXEC mode or global configuration mode.

show startup-config {*module* | **interface** {**ethernet** *port-id* | **gpon** *port-id* | **loopback-interface** *loopback-interface-number* | **vlan-interface** *vlan-id*}} **perlines** *lines-per-page*

Syntax Description		
	<i>module</i>	Specifies a module.
	interface	Specifies an interface.
	ethernet <i>port-id</i>	Displays the ethernet port configuration.
	gpon <i>port-id</i>	Displays the GPON port configuration.
	loopback-interface <i>loopback-interface-number</i>	Displays the loopback interface configuration.
	vlan-interface <i>vlan-id</i>	Displays the VLAN configuration.
	perlines <i>lines-per-page</i>	Specifies the number of lines displayed per page.

Command Modes

Privileged EXEC (#)

Global configuration mode (config)

Examples

The following is a sample output from the **show startup-config interface ethernet** command:

```
Device> enable
Device# show startup-config interface ethernet

Building configuration...
![ethernet 1/1]
channel-group 2 mode on
lACP port-priority 8
description text
switchport hybrid untagged vlan 2-125
igmp-snooping record-host
ip-source-guard ip-mac-vlan
![ethernet 1/2]
switchport hybrid tagged vlan 35,335
switchport hybrid untagged vlan 2-34,36-125,2501-2502
![ethernet 1/3]
switchport default vlan 100
switchport hybrid untagged vlan 2-125
![ethernet 1/4]
priority 2
![ethernet 2/1]
switchport hybrid untagged vlan 2-125
![ethernet 2/2]
switchport hybrid untagged vlan 2-125
end
```

sntp client

To enable SNTP client, use the **sntp client** command in global configuration mode.

sntp client

no sntp client

Command Modes

Global configuration mode (config)

Examples

The following example shows how to enable SNTP client:

```
Device> enable
Device# configure terminal
Device(config)# sntp client
```

sntp client authenticate

To enable authentication of time sources, use the **sntp client authenticate** command in global configuration mode.

sntp client authenticate
no sntp client authenticate

Command Modes

Global configuration mode (config)

Examples

The following example shows how to enable SNTP client authentication using the **sntp client authenticate** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client authenticate
```


sntp client authentication-key

To configure the password for authentication for trusted time sources, use the **sntp client authentication-key** command in global configuration mode.

sntp client authentication-key *key-number* **md5** *md5-key*
no sntp client authentication-key *key-number*

Syntax Description		
	<i>key-number</i>	Specifies the authentication key for the SNTP client.
	md5 <i>md5-key</i>	Specifies the MD5 authentication key for the SNTP client.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure SNTP client authentication using the **sntp client authentication-key** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client authentication-key 3 md5 5
```

sntp client broadcastdelay

To configure the broadcast propagation delay for an SNTP client, use the **sntp client broadcastdelay** command in global configuration mode.

sntp client broadcastdelay *delay-time*

Syntax Description	<i>delay-time</i>	Specifies the round-trip broadcast delay for the SNTP client in milliseconds.
---------------------------	-------------------	---

Command Modes Global configuration mode (config)

Examples

The following example show how to configure the delay time for the SNTP client using the **sntp client broadcastdelay** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client broadcastdelay 15
```

snmp client mode

To configure the mode of function of the SNMP client, use the **snmp client mode** command in global configuration mode.

snmp client mode {**anycast** {[**key** *key-id*]} | **broadcast** | **multicast** | **unicast**}

Syntax Description		
anycast		Sets the SNMP client to work in anycast mode.
key <i>key-id</i>		Specifies the authentication key for anycast mode.
broadcast		Sets the SNMP client to work in broadcast mode.
multicast		Sets the SNMP client to work in multicast mode.
unicast		Sets the SNMP client to work in unicast mode.

Command Modes

Global configuration mode (config)

Examples

The following example show how to configure the SNMP client to unicast mode using the **snmp client mode** command:

```
Device> enable
Device# configure terminal
Device(config)# snmp client mode unicast
```

sntp client poll-interval

To configure the polling interval for an SNTP client, use the **sntp client poll-interval** command in global configuration mode.

sntp client poll-interval *poll-interval-time*

Syntax Description	<i>poll-interval-time</i>	Specifies the polling interval for the SNTP client in seconds.
---------------------------	---------------------------	--

Command Modes Global configuration mode (config)

Examples

The following example show how to configure the polling interval for the SNTP client using the **sntp client poll-interval** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client poll-interval 800
```

snmp client retransmit-interval

To configure the timeout retransmission interval for an SNMP client, use the **snmp client retransmit-interval** command in global configuration mode.

snmp client retransmit-interval *retransmit-interval-time*

Syntax Description	<i>retransmit-interval-time</i>	Specifies the timeout retransmission interval for the SNMP client in seconds.
---------------------------	---------------------------------	---

Command Modes	Global configuration mode (config)
----------------------	------------------------------------

Usage Guidelines	The configured timeout retransmission mechanism takes effect only when the SNMP client works in the unicast or anycast mode.
-------------------------	--

Examples

The following example show how to configure the retransmission interval for the SNMP client using the **snmp client retransmit-interval** command:

```
Device> enable
Device# configure terminal
Device(config)# snmp client retransmit-interval 8
```

sntp client retransmit

To configure the number of timeout retransmission attempts for an SNTP client, use the **sntp client retransmit** command in global configuration mode.

sntp client retransmit *number*

Syntax Description

number

Specifies the number of timeout retransmission attempts for the SNTP client.

Command Modes

Global configuration mode (config)

Usage Guidelines

The configured timeout retransmission mechanism takes effect only when the SNTP client works in the unicast or anycast mode.

Examples

The following example show how to configure the number of retransmission attempts for the SNTP client using the **sntp client retransmit-interval** command:

```
Device> enable
Device# configure terminal
Device(config)# sntp client retransmit 5
```

sntp client valid-server

To configure a legal server list for the SNTP client, use the **sntp client valid-server** command in global configuration mode.

```
sntp client valid-server ip-address wildcard-ip-address  
no sntp client valid-server {all | ip-address wildcard-ip-address}
```

Syntax Description		
	<i>ip-address</i>	Specifies the IP address of the valid SNTP server.
	<i>wildcard-ip-address</i>	Specifies the IP address of the wildcard SNTP server.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure the valid SNTP servers for an SNTP client using the **sntp client valid-server** command:

```
Device> enable  
Device# configure terminal  
Device(config)# sntp client valid-server 10.23.23.1 23.1.1.4
```

sntp server

To set SNTP server configurations, use the **sntp server** command in global configuration mode.

```
sntp server {ip-address | backup ip-address | key key-number}
```

Syntax Description		
	<i>ip-address</i>	Specifies the IP address of the SNTP server.
	backup <i>ip-address</i>	Specifies the IP address of the SNTP backup server.
	key <i>key-number</i>	Specifies the authentication key for the SNTP server.

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure the SNTP server using the **sntp server** command:

```
Device> enable  
Device# configure terminal  
Device(config)# sntp server 12.2.2.1
```


snmp trusted-key

To configure a trusted password for multicast and broadcast modes, use the **snmp trusted-key** command in global configuration mode.

```
snmp trusted-key key-number  
no snmp trusted-key key-number
```

Syntax Description	<i>key-number</i>	Specifies the trusted key for the SNMP client.
---------------------------	-------------------	--

Command Modes Global configuration mode (config)

Examples

The following example shows how to configure SNMP client trusted key authentication using the **snmp trusted-key** command:

```
Device> enable  
Device# configure terminal  
Device(config)# snmp trusted-key 243586
```

upload automatically configuration ftp

To automatically upload a configuration file at regular intervals with the FTP server, use the **upload automatically configuration ftp** command in privileged EXEC mode.

upload automatically configuration ftp {**inet** | **inet6**}*ftp-server-ip-address file-name ftp-username ftp-password***per hours** *hours* **minutes** *minutes*

Syntax Description		
	inet	Specifies IPv4 address family.
	inet6	Specifies IPv6 address family.
	<i>ftp-server-ip-address</i>	Specifies the IP address of the FTP server.
	<i>file-name</i>	Specifies the name of the file to be uploaded.
	<i>ftp-username</i>	Specifies the user name of the FTP server.
	<i>ftp-password</i>	Specifies the password of the FTP server.
	per hours <i>hours</i> minutes <i>minutes</i>	Specifies the time interval in hours and minutes after which the configuration file is to be automatically uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a configuration file using the **upload automatically configuration tftp** command:

```
Device> enable
Device# upload automatically configuration ftp inet 10.23.13.1 config3.txt per hours 12
minutes 10
```

upload automatically configuration tftp

To automatically upload a configuration file at regular intervals with the TFTP server, use the **upload automatically configuration tftp** command in privileged EXEC mode.

upload automatically configuration tftp {**inet** | **inet6**} *tftp-server-ip-address* *file-name* **per hours** *hours* **minutes** *minutes*

Syntax Description		
	inet	Specifies IPv4 address family.
	inet6	Specifies IPv6 address family.
	<i>tftp-server-ip-address</i>	Specifies the IP address of the TFTP server.
	<i>file-name</i>	Specifies the name of the file to be uploaded.
	per hours <i>hours</i> minutes <i>minutes</i>	Specifies the time interval in hours and minutes after which the configuration file is to be automatically uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a configuration file using the **upload automatically configuration tftp** command:

```
Device> enable
Device# upload automatically configuration tftp inet 10.23.13.1 config2.txt per hours 20
minutes 30
```

upload ftp

To upload a file with the FTP server, use the **upload ftp** command in privileged EXEC mode.

```
upload {application | configuration | keyfile {private | public} | logging}ftp {inet | inet6}ftp-server-ip-address file-name ftp-username ftp-password
```

Syntax Description		
application		Specifies the host file.
configuration		Specifies the configuration file.
keyfile		Specifies the SSH keyfile.
private		Specifies the SSH private keyfile.
public		Specifies the SSH public keyfile.
logging		Specifies the log file.
inet		Specifies IPv4 address family.
inet6		Specifies IPv6 address family.
<i>ftp-server-ip-address</i>		Specifies the IP address of the FTP server.
<i>file-name</i>		Specifies the name of the file to be uploaded.
<i>ftp-username</i>		Specifies the user name of the FTP server.
<i>ftp-password</i>		Specifies the password of the FTP server.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a host file with an FTP server using the **upload ftp** command:

```
Device> enable
Device# upload application ftp 192.168.1.99 host.arj rr 142
```

upload tftp

To upload a file with the TFTP server, use the **upload tftp** command in privileged EXEC mode.

```
upload {application | configuration | keyfile {private | public} | logging} tftp {inet | inet6} tftp-server-ip-address file-name
```

Syntax Description		
	application	Specifies the host file.
	configuration	Specifies the configuration file.
	keyfile	Specifies the SSH keyfile.
	private	Specifies the SSH private keyfile.
	public	Specifies the SSH public keyfile.
	logging	Specifies the log file.
	inet	Specifies IPv4 address family.
	inet6	Specifies IPv6 address family.
	<i>tftp-server-ip-address</i>	Specifies the IP address of the TFTP server.
	<i>file-name</i>	Specifies the name of the file to be uploaded.

Command Modes Privileged EXEC (#)

Examples

The following example shows how to upload a configuration file with a TFTP server using the **upload tftp** command:

```
Device> enable
Device# upload application tftp 192.168.1.99 text.txt
```




PART **X**

ONT Device Configuration

- [ONT Device Configuration, on page 519](#)



ONT Device Configuration

- [alarm profile refer](#), on page 520
- [clear ont-logging buffer](#), on page 521
- [local bandwidth egress](#), on page 522
- [local loop-detect](#), on page 523
- [local mac-address-table](#), on page 524
- [local neg-mode](#), on page 525
- [local ranging-balance](#), on page 526
- [local shutdown](#), on page 527
- [local switch](#), on page 528
- [ont-logging](#), on page 529
- [ont-logging buffer](#), on page 530
- [ont-logging monitor](#), on page 531
- [ont-logging prefix](#), on page 532
- [ont-logging timestamps](#), on page 533
- [ont active](#), on page 534
- [ont deactive](#), on page 535
- [ont neg-mode](#), on page 536
- [ont reboot](#), on page 537
- [ont shutdown](#), on page 538
- [ont upgrade](#), on page 539
- [optical power rx threshold](#) , on page 540
- [show ont-logging](#), on page 541
- [show ont-logging buffer](#), on page 542
- [show ont mac-address-table](#), on page 543
- [show ont port-status](#), on page 544
- [show ont statistics](#), on page 545
- [show ont upgrade-status](#), on page 546
- [show ont version](#), on page 547

alarm profile refer

To refer an alarm profile to a line profile, use the **alarm profile refer** command in line profile configuration mode.

alarm profile refer {*index_num* | **name** *name*}

Syntax Description		
<i>index_num</i>	The alarm profile index number. The range is from 1 to 127.	
<i>name</i>	The alarm profile name. The unit is string. The string length is from 1 to 127.	

Command Modes Line profile configuration (deploy-profile-line)

Examples

This example shows how to refer an alarm profile to a line profile

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# alarm profile refer 1
```

clear ont-logging buffer

To clear the ont logging buffer, use the **clear ont-logging buffer** command in global configuration mode.

```
clear ont-logging buffer {ont_id_list | all}
```

Syntax Description		
	<i>ont_id_list</i>	The list of ONT IDs.
	all	All ONTs.

Command Modes Global configuration (config)

Examples

This example shows how to clear the ONT log buffering

```
Device> enable  
Device# configure terminal  
Device(config)# clear ont-logging buffer all
```

local bandwidth egress

To configure the ONT bandwidth egress, use the **local bandwidth egress port *port_id* cir *cir* cbs *cbs* pir *pir* pbs *pbs*** command in line profile configuration mode. To disable the ONT bandwidth egress, use the **no local bandwidth egress port *port_id*** command.

local bandwidth egress port *port_id* cir *cir* cbs *cbs* pir *pir* pbs *pbs*

no local bandwidth egress port *port_id*

Syntax Description

<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
cir <i>cir</i>	The committed information rate in kbps. The value range is from
cbs <i>cbs</i>	The committed burst size in KB. The value range is from 2 to 320
pir <i>pir</i>	The peak information rate in kbps. The value range is from 64 to is greater than or equal to CIR.
pbs <i>pbs</i>	The peak burst size in KB. The value range is from 2 to 32000.

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT bandwidth egress.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local bandwidth egress port 3 cir 200 cbs 70 pir 1024 pbs
90
```

local loop-detect

To enable local loop-detect, use the **local loop-detect** command in line profile configuration mode. To disable local loop-detect, use the **no local loop-detect** command.

local loop-detect

no local loop-detect

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable local loop-detect

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local loop-detect
```

local mac-address-table

To configure the ONT maximum MAC count, use the **local mac-address-table** command in line profile configuration mode. To disable the ONT maximum MAC count, use the **no local mac-address-table** command.

local mac-address-table max-mac-count *max_mac_count* [**port** *port_id*]

no local mac-address-table

Syntax Description		
	<i>max_mac_count</i>	The maximum MAC address learning The range is from 1 to 255.
	<i>port_id</i>	The ONT Ethernet port ID. The range

Command Modes Line profile configuration (deploy-profile-line)

Examples

This example shows how to configure the ONT maximum MAC count.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local mac-address-table max-mac-count 12
```

local neg-mode

To configure the local Ethernet speed and duplex, use the **local neg-mode speed *speed* duplex *duplex_mode* port *port_id*** command in unique profile configuration mode.

local neg-mode speed *speed* duplex *duplex_mode* port *port_id*

Syntax	Description
<i>speed</i>	The ONT Ethernet port rate mode. The options are <ul style="list-style-type: none"> • 10M • 100M • 1000M • Auto-negotiation
<i>duplex_mode</i>	The ONT Ethernet port duplex mode. The options are <ul style="list-style-type: none"> • Full-duplex • Half-duplex • Auto-negotiation
<i>port_id</i>	The ONT Ethernet port ID. The range is from 0 to 3.

Command Modes Unique profile configuration (deploy-profile-unique)

Examples

This example shows how to configure the local Ethernet speed and duplex

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# local neg-mode speed 10 duplex half port 3
```

local ranging-balance

To configure ONT range compensation, use the **local ranging-balance** command in unique profile configuration mode. To disable the ONT range compensation, use the **no local ranging-balance** command.

local ranging-balance {**decrease** | **increase**} *balance_length*

no local ranging-balance

Syntax Description		
	decrease	Decreases the range compensation.
	increase	Increases the range compensation.
	<i>balance_length</i>	The ONT ranging compensation value The unit is meters. The range is from 1 to 100

Command Modes Unique profile configuration (deploy-profile-unique)

Examples

This example shows how to increase ONT range compensation

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# local ranging-balance increase 2000
```


local shutdown

To configure the ONT local shutdown, use the **local shutdown** command in unique profile configuration mode. To disable the ONT local shutdown, use the **no local shutdown** command.

local shutdown {port *port_id* | catv-port *catv_port_id*}

no local shutdown {port *port_id* | catv-port *catv_port_id*}

Syntax Description		
<i>port_id</i>		The ONT Ethernet UNI. The value range is from 1 to 24.
<i>catv_port_id</i>		The ONT RF interface ID. The value range is from 1 to 4.

Command Modes Unique profile configuration (deploy-profile-unique)

Examples

This example shows how to configure the ONT local shutdown.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile unique
Device(deploy-profile-unique)# aim 0/1/1
Device(deploy-profile-unique-0/1/1)# local shutdown port 2
```

local switch

To enable the ONT local switching, use the **local switch** command in line profile configuration mode. To disable the ONT local switching, use the **no local switch** command.

local switch

no local switch

Command Modes

Line profile configuration (deploy-profile-line)

Examples

This example shows how to enable the ONT local switching.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile line
Device(deploy-profile-line)# aim 5
Device(deploy-profile-line-5)# local switch
```

ont-logging

To enable ONT logging, use the **ont-logging** command in global configuration mode. To disable ONT logging, use the **no ont-logging** command.

ont-logging

no ont-logging

Command Modes

Global configuration (config)

Examples

This example shows how to enable ONT logging.

```
Device> enable
Device# configure terminal
Device(config)# ont-logging
```

ont-logging buffer

To save the ONT log to a buffer, use the **ont-logging buffer** command in global configuration mode. To disable the ONT logging buffer, use the **no ont-logging buffer** command.

ont-logging buffer {*ont_id_list* | **all**}

no ont-logging buffer

Syntax Description		
	<i>ont_id_list</i>	The list of ONT IDs.
	all	All ONTs.

Command Modes Global configuration (config)

Examples

This example shows how to enable the ONT log buffering.

```
Device> enable
Device# configure terminal
Device(config)# ont-logging buffer all
```

ont-logging monitor

To enable monitor for ONT logs, use the **ont-logging monitor** command in global configuration mode. To disable monitor for ONT logs, use the **no ont-logging monitor** command.

ont-logging monitor {*monitor_number* | **all**} {*ont_id_list* | **all**}

no ont-logging monitor {*monitor_number* | **all**} {*ont_id_list* | **all**}

Syntax Description

monitor_number

The monitor number.

The range is from 0 to 5, where 0 is the con

ont_id_list

The list of ONT IDs.

all

All ONTs.

Command Modes

Global configuration (config)

Examples

This example shows how to enable the ONT log monitor

```
Device> enable
Device# configure terminal
Device(config)# ont-logging monitor all all
```

ont-logging prefix

To configure log prefixes, use the **ont-logging prefix** command in global configuration mode. To disable log prefixing, use the **no ont-logging prefix** command.

ont-logging prefix {ontid | sn}

no ont-logging prefix

Syntax Description		
	ontid	The ONT IDs.
	sn	The ONT serial number.

Command Modes Global configuration (config)

Examples

This example shows how to enable the ONT log prefixing

```
Device> enable
Device# configure terminal
Device(config)# ont-logging prefix ontid
```

ont-logging timestamps

To enable log timestamps of an ONT, use the **ont-logging timestamps** command in global configuration mode.

```
ont-logging timestamps {uptime | notime | datetime}
```

Syntax Description

uptime	Configures logging with uptime duration.
notime	Configures logging with no time.
datetime	Configures logging with date and time

Command Modes

Global configuration (config)

Examples

This example shows how to enable log timestamps of an ONT

```
Device> enable
Device# configure terminal
Device(config)# ont-logging timestamps datetime
```

ont active

To activate the ONT, use the **ont active** *ont_id_list* command in global configuration mode.

ont active *ont_id_list*

Syntax Description

ont_id_list

The list of ONT IDs.

Command Modes

Global configuration (config)

Examples

This example show how to activate the ONT.

```
Device> enable
Device# configure terminal
Device(config)# ont active 0/1/1
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont deactivate	Deactivates the ONT.

ont deactivate

To deactivate the ONT, use the **ont deactivate** *ont_id_list* in global configuration mode.

```
ont deactivate ont_id_list
```

Syntax	Description
<i>ont_id_list</i>	The list of ONT IDs.

Command Modes	Global configuration (config)
---------------	-------------------------------

Examples

This example show how to deactivate the ONT.

```
Device> enable  
Device# configure terminal  
Device(config)# ont deactivate 0/1/1  
Config success: 1, failed: 0.
```

Related Commands

Command	Description
ont active	Activates the ONT.

ont neg-mode

To configure the ONT speed and duplex, use the **ont neg-mode speed *speed* duplex *duplex_mode* slot-num/pon-num/ont-num port *port_id*** command in global configuration mode.

ont neg-mode speed *speed* duplex *duplex_mode* slot-num/pon-num/ont-num port *port_id*

Syntax	Description
<i>speed</i>	The ONT Ethernet port rate mode. The options are <ul style="list-style-type: none"> • 10M • 100M • 1000M • Auto-negotiation
<i>duplex_mode</i>	The ONT Ethernet port duplex mode. The options are <ul style="list-style-type: none"> • Full-duplex • Half-duplex • Auto-negotiation
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 0 to 16. • <i>ont-num</i>: The ONT number. The range is from 0 to 255.
<i>port_id</i>	The ONT Ethernet port ID. The range is from 1 to 255.

Command Modes Global configuration (config)

Examples

This example shows how to configure the ONT speed and duplex

```
Device> enable
Device# configure terminal
Device(config)# ont neg-mode speed 10 duplex half 0/1/1 port 3
```

ont reboot

To reboot an ONT port, use the **ont reboot** command in global configuration mode.

ont reboot *slot-num/pon-num/ont-num*

Syntax Description

slot-num/pon-num/ont-num

The ONT ID.

- *slot-num*: The slot number. The value is 0.
- *pon-num*: The PON number. The range is from 0 to 1.
- *ont-num*: The ONT number. The range is from 0 to 1.

Command Modes

Global configuration (config)

Examples

This example shows how to reboot an ONT port.

```
Device> enable
Device# configure terminal
Device(config)# ont reboot 0/1/1
```

ont shutdown

To configure the ONT shutdown, use the **ont shutdown** command in global configuration mode. To disable ONT shutdown, use the **no ont shutdown** command.

ont shutdown *slot-num/pon-num/ont-num* **port** *port_id*

no ont shutdown *slot-num/pon-num/ont-num* **port** *port_id*

Syntax Description

slot-num/pon-num/ont-num

The ONT ID.

- *slot-num*: The slot number. The value is 0.
- *pon-num*: The PON number. The range is from 1 to 24.
- *ont-num*: The ONT number. The range is from 1 to 24.

port_id

The ONT Ethernet port ID. The range is from 1 to 24.

Command Modes

Global configuration (config)

Examples

This example shows how to configure the ONT shutdown.

```
Device> enable
Device# configure terminal
Device(config)# ont shutdown 0/1/1 port 1
```

ont upgrade

To configure an ONT for reboot, use the **ont upgrade** command in global configuration mode.

```
ont upgrade {auto-reboot | manual-reboot} {slot-num/pon-num/ont-num | {exclude | include} | {device-type
device_type | software-version version} | sn | {string-hex string_serial_number | hex hex_serial_number}}
```

Syntax	Description
auto-reboot	Automatically reboots the ONT.
manual-reboot	Manually reboots the ONT.
<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The • <i>pon-num</i>: The PON number. TH • <i>ont-num</i>: The ONT number. Th
exclude	Excludes the ONT.
include	Includes the ONT.
device-type <i>device_type</i>	The device identifier.
software-version <i>version</i>	The software identifier.
<i>hex_serial_number</i>	The ONT serial number in Hex.
<i>string_serial_number</i>	The ONT serial number in string.

Command Modes

Global configuration (config)

Examples

This example shows how to configure an ONT fo auto reboot

```
Device> enable
Device# configure terminal
Device(config)# ont upgrade auto-reboot 0/1/1
```

optical power rx threshold

To configure the threshold of the receive optical power, use the **optical power rx threshold** command in alarm profile configuration mode. To delete the threshold, use the **no optical power rx threshold** command.

optical power rx threshold {**high** *high_rx_power* | **low** *low_rx_power*}

no optical power rx threshold

Syntax Description		
	<i>high_rx_power</i>	The highest threshold value. The value must be in the range of -127 to 127. The unit is dBm. The range is from -127 to 127.
	<i>low_rx_power</i>	The lowest threshold value. The value must be in the range of -127 to 127. The unit is dBm. The range is from -127 to 127.

Command Modes Alarm profile configuration (deploy-profile-alarm)

Examples

This example shows how to configure the high threshold value of the receive optical power.

```
Device> enable
Device# configure terminal
Device(config)# deploy profile alarm
Device(deploy-profile-alarm)# aim 5
Device(deploy-profile-alarm-5)# optical power rx threshold high 10
```

show ont-logging

To display the ONT logs, use the **show ont-logging** command in global configuration mode

show ont-logging

Command Modes

Global configuration (config)

Examples

This example shows how to view the ONT logs

```
Device> enable
Device# configure terminal
Device(config)# show ont-logging
logging state: on
logging timestamps: uptime
logging prefix: ontid:on; sn:on
logging buffer: 0/1/1-0/8/128
logging monitor:
 0: 0/1/1-0/8/128
 1: 0/1/1-0/8/128
 2: 0/1/1-0/8/128
 3: 0/1/2-0/8/128
 4: 0/1/1-0/8/128
 5: 0/1/1-0/8/128
```

show ont-logging buffer

To display information about ONT logging buffer, use the **show ont-logging buffer** command in global configuration mode.

show ont-logging buffer {*slot-num/pon-num/ont-num* | **all**}

Syntax Description		
	<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 16. • <i>ont-num</i>: The ONT number. The range is from 1 to 16.
	all	All ONTs

Command Modes Global configuration (config)

Examples

This example shows how to view the information about ONT logging buffer

```
Device> enable
Device# configure terminal
Device(config)# show ont-logging buffer 0/1/1
32 day 04:28:34 0/1/1 GPON-5a946e77: offline, reason: LOSI.
32 day 04:28:34 0/1/1 GPON-5a946e77: LOAMi on.
32 day 04:28:34 0/1/1 GPON-5a946e77: LOFi on.
32 day 04:28:34 0/1/1 GPON-5a946e77: LOSi on.
32 day 04:28:31 0/1/1 GPON-5a946e77: eth port 1 los on.
32 day 02:58:03 0/1/1 GPON-5a946e77: eth port 1 los off.
32 day 02:58:00 0/1/1 GPON-5a946e77: eth port 1 los on.
31 day 23:28:51 0/1/1 GPON-5a946e77: eth port 1 los off.
31 day 23:28:47 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 07:26:06 0/1/1 GPON-5a946e77: eth port 1 los off.
26 day 07:26:04 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 04:14:38 0/1/1 GPON-5a946e77: eth port 1 los off.
26 day 04:14:36 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 03:57:30 0/1/1 GPON-5a946e77: eth port 1 los off.
26 day 03:57:27 0/1/1 GPON-5a946e77: eth port 1 los on.
26 day 03:57:15 0/1/1 GPON-5a946e77: eth port 1 los off.
25 day 05:33:41 0/1/1 GPON-5a946e77: eth port 1 los on.
25 day 05:33:31 0/1/1 GPON-5a946e77: eth port 1 los off.
25 day 05:33:30 0/1/1 GPON-5a946e77: eth port 1 los on.
24 day 23:51:33 0/1/1 GPON-5a946e77: eth port 1 los off.
24 day 23:51:30 0/1/1 GPON-5a946e77: eth port 1 los on.
24 day 23:51:17 0/1/1 GPON-5a946e77: eth port 1 los off.
21 day 08:12:36 0/1/1 GPON-5a946e77: eth port 1 los on.
21 day 08:12:28 0/1/1 GPON-5a946e77: eth port 1 los off.
!
!
!
output truncated
```


show ont mac-address-table

To display information about the MAC address table of an ONT, use the **show ont mac-address-table** command in global configuration mode.

show ont mac-address-table {*mac_address* | *slot-num/pon-num/ont-num* | **interface gpon** {*slot-number/port-number* | **all**}}

Syntax Description		
<i>mac_address</i>		The MAC address.
<i>slot-num/pon-num/ont-num</i>		The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 0 to 2. • <i>ont-num</i>: The ONT number. The range is from 0 to 255.
<i>slot-number/port-number</i>		The port ID. <ul style="list-style-type: none"> • <i>slot-number</i>: <ul style="list-style-type: none"> • GPON: The value is 0. • GE Ethernet: The value is 1. • 10GE Ethernet: The value is 2. • <i>port-number</i>: <ul style="list-style-type: none"> • GPON: The range is from 1 to 8. • GE Ethernet: The range is from 1 to 4. • 10GE Ethernet: The range is from 1 to 2.
all		All ports.

Command Modes

Global configuration (config)

Examples

This example shows how to view information about the MAC address table of an ONT

```
Device> enable
Device# configure terminal
Device(config)# show ont mac-address-table interface gpon 0/1
MAC-Address      VID  ONT-ID  SN          ID/GEM
00:0a:5a:a7:01:34 100  0/1/5   GPON-5aa7012a 4/355
Total entries: 1.
```

show ont port-status

To display status information of an ONT port, use the **show ont port-status** command in global configuration mode.

```
show ont port-status slot-num/pon-num/ont-num { port port_id | catv-port catv_port_id | pots-port pots-number }
```

Syntax Description		
<i>slot-num/pon-num/ont-num</i>	The ONT ID.	<ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 24. • <i>ont-num</i>: The ONT number. The range is from 1 to 24.
<i>port_id</i>	The ONT Ethernet UNI. The value range is from 1 to 24.	
<i>catv_port_id</i>	The ONT RF interface ID. The value range is from 1 to 4.	
<i>pots-number</i>	Specifies the POTS port. The value can be 1 or 2.	

Command Modes Global configuration (config)

Examples

This example shows how to view the status information of an ONT port.

```
Device> enable
Device# configure terminal
Device(config)# show ont port-status 0/1/5 port 2
Port status is Enable, Linkdown
```

show ont statistics

To display statistical information about an ONT, use the **show ont statistics** command in global configuration mode.

```
show ont statistics slot-num/pon-num/ont-num {gem {broadcast | multicast | unicast gem_index } | {port port-id } | traffic}
```

Syntax Description	<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 to 24. • <i>ont-num</i>: The ONT number. The range is from 1 to 24.
	gem	Displays statistical information about GEM port.
	broadcast	Displays statistical information about broadcast traffic.
	multicast	Displays statistical information about multicast traffic.
	unicast <i>gem_index</i>	Displays statistical information about unicast traffic. <i>gem_index</i> : The GEM port index number. The range is from 1 to 24.
	<i>port-id</i>	The ONT Ethernet port ID. The range is from 1 to 24.
	traffic	Displays statistical information about ONT uplink traffic.

Command Modes

Global configuration (config)

Examples

This example shows how to view the statistical information about an ONT.

```
Device> enable
Device# configure terminal
Device(config)# show ont statistics 0/1/1 port 1
Upstream frames : 0
Upstream bytes : 0
Downstream frames : 0
Downstream bytes : 0
Up traffic (kbps) : 0
Down traffic (kbps) : 0
```

show ont upgrade-status

To display the ONT upgrade status, use the **show ont upgrade-status** command in global configuration mode.

show ont upgrade-status {**image** | **xml**} {*slot-num/pon-num/ont-num* | **all**}

Syntax Description		
	<i>slot-num/pon-num/ont-num</i>	The ONT ID. <ul style="list-style-type: none"> • <i>slot-num</i>: The slot number. The value is 0. • <i>pon-num</i>: The PON number. The range is from 1 • <i>ont-num</i>: The ONT number. The range is from 1
	all	All ports.

Command Modes Global configuration (config)

Examples

This example shows how to view the ONT upgrade status

```
evlce> enable
Device# configure terminal
Device(config)# show ont upgrade-status image 0/1/1
ONT   Active-version Inactive-version Status
0/1/1 C01R544V00B09 C01R544V00B07 success
Total entries: 1.
```

show ont version

To display an ONT version, use the **show ont version** command in global configuration mode.

show ont version interface gpon *{port_list | all}*

Syntax	Description
<i>port_list</i>	The GPON port.
all	All ports.

Command Modes Global configuration (config)

Examples

This example shows how to view an ONT version

```
Device> enable
Device# configure terminal
Device(config)# show ont version interface gpon 0/1
ONT      SN                Software-version      Firmware-version
0/1/1    GPON-5a946e77      B01D001P010/B01D001P008  N40-428-1
0/1/2    GPON-5a95efca      C01R539V00B19/-        S40-401
0/1/3    GPON-5aa0e950      B01D001P010/B01D001P007  N40-428-1
0/1/4    GPON-5aa0e9e0      B01D001P007/B01D001P006  N40-428-1
0/1/5    GPON-5aa7012a      1.1.2.5/1.1.2.6         N40-428-1
Total entries: 5.
```

 show ont version