

# Fonctionnalité de mode WAN sur la plate-forme Cisco 867VAE

## Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Components Used](#)

[Configuration](#)

[Vérification](#)

[Dépannage](#)

## Introduction

Ce document décrit la fonctionnalité WAN Mode sur la plate-forme Cisco867VAE et les options qui activent les services Internet DSL.

## Conditions préalables

### Conditions requises

Aucune spécification déterminée n'est requise pour ce document.

### Components Used

Les informations de ce document sont basées sur la plate-forme Cisco867VAE.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

## Configuration

Voici la configuration pour activer les modes WAN sur la plate-forme CISCO867VAE :

```
Cisco867VAE(config)#wan mode ?  
dsl      WAN interface is DSL  
ethernet  WAN interface is ethernet
```

---

Ce mode permet de configurer vos paramètres DSL sur ATM ou Ethernet, mais pas sur une interface de couche 3, qui est Gigabitethernet 0 dans ce périphérique.

```
Cisco867VAE#sh ip int brief
```

| Interface        | IP-Address   | OK? | Method | Status                | Protocol |
|------------------|--------------|-----|--------|-----------------------|----------|
| ATM0             | unassigned   | YES | NVRAM  | administratively down | down     |
| Ethernet0        | unassigned   | YES | NVRAM  | administratively down | down     |
| FastEthernet0    | unassigned   | YES | unset  | up                    | up       |
| FastEthernet1    | unassigned   | YES | unset  | down                  | down     |
| FastEthernet2    | unassigned   | YES | unset  | down                  | down     |
| FastEthernet3    | unassigned   | YES | unset  | down                  | down     |
| GigabitEthernet0 | unassigned   | YES | NVRAM  | down                  | down     |
| vlan1            | 10.106.47.21 | YES | NVRAM  | up                    | up       |

Voici les messages d'erreur rencontrés en mode DSL :

```
Cisco867VAE(config)#wan mode dsl
```

```
% Ethernet WAN interface will be disabled.
```

```
Cisco867VAE(config)#+
```

```
*Jan 18 04:35:57.931: %LINK-5-CHANGED: Interface GigabitEthernet0, changed state to administratively down
```

```
Cisco867VAE(config)#int gig 0
```

```
Cisco867VAE(config-if)#no shut
```

```
% WAN interface is DSL
```

```
Cisco867VAE(config)#controller vdsl 0
```

```
Cisco867VAE(config-controller)#no shut
```

```
Cisco867VAE(config)#int eth0
```

```
Cisco867VAE(config-if)#no shut
```

```
*Jan 18 04:40:46.507: %LINK-3-UPDOWN: Interface Ethernet0, changed state to down
```

```
Cisco867VAE(config-if)#int atm 0
```

```
Cisco867VAE(config-if)#no shut
```

```
*Jan 18 04:40:58.771: %LINK-3-UPDOWN: Interface ATM0, changed state to down
```

## Mode Ethernet :

En mode Ethernet, vous ne pourrez pas configurer de paramètres DSL, mais vous pouvez utiliser l'interface Gigabit Ethernet de couche 3 pour un réseau externe.

```
Cisco867VAE#wan mode ethernet
```

```
% DSL interfaces will be disabled.
```

```
Cisco867VAE#
```

```
*Jan 18 04:12:48.687: %CONTROLLER-5-UPDOWN: Controller VDSL 0, changed state to administratively down
```

```
Cisco867VAE(config)#controller vdsl 0
```

```
Cisco867VAE(config-controller)#no shut
```

```
% Operation not allowed when wan mode is ethernet.
```

```
Cisco867VAE#sh ip int brief
```

| Interface        | IP-Address   | OK? | Method | Status                | Protocol |
|------------------|--------------|-----|--------|-----------------------|----------|
| ATM0             | unassigned   | YES | NVRAM  | administratively down | down     |
| Ethernet0        | unassigned   | YES | NVRAM  | administratively down | down     |
| FastEthernet0    | unassigned   | YES | unset  | up                    | up       |
| FastEthernet1    | unassigned   | YES | unset  | down                  | down     |
| FastEthernet2    | unassigned   | YES | unset  | down                  | down     |
| FastEthernet3    | unassigned   | YES | unset  | down                  | down     |
| GigabitEthernet0 | unassigned   | YES | NVRAM  | administratively down | down     |
| Vlan1            | 10.106.47.21 | YES | NVRAM  | up                    | up       |

```
Cisco867VAE#conf t
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

```
Cisco867VAE(config)#int atm0
```

```
Cisco867VAE(config-if)#no shut
```

```
% WAN interface is Ethernet.
```

```
Cisco867VAE(config-if)#int eth0
```

```
Cisco867VAE(config-if)#no shut  
  
% WAN interface is Ethernet.  
  
Cisco867VAE(config)#int gig 0  
  
Cisco867VAE(config-if)#no shut  
  
*Jan 18 04:30:08.851: %LINK-3-UPDOWN: Interface GigabitEthernet0, changed state to down  
Désactiver le mode WAN n'est pas possible lorsqu'il est en mode DSL comme mode par défaut dans la plate-forme CISCO 867.
```

Mais lorsqu'elle est désactivée en mode Ethernet, elle passe en mode DSL.

```
Cisco867VAE(config)#no wan mode dsl  
  
Cisco867VAE(config)#do sh run | sec wan  
  
wan mode dsl  
  
Cisco867VAE(config)#do sh run | sec wan  
  
wan mode ethernet  
  
Cisco867VAE(config)#no wan mode ethernet  
  
% Ethernet WAN interface will be disabled.
```

**Note:** Utilisez l'[Outil de recherche de commande \(clients inscrits seulement\) pour obtenir plus d'informations sur les commandes utilisées dans cette section.](#)

## Vérification

Référez-vous à cette section pour vous assurer du bon fonctionnement de votre configuration.

```
Cisco867VAE#sh run | inc wan mode
```

```
wan mode dsl
```

## Dépannage

Il n'existe actuellement aucune information de dépannage spécifique pour cette configuration.