

# Configuration de la fonction de mode WAN sur la plate-forme Cisco 867VAE

## Contenu

[Introduction](#)

[Conditions préalables](#)

[Conditions requises](#)

[Components Used](#)

[Configuration](#)

[Vérification](#)

[Dépannage](#)

## Introduction

Ce document décrit la fonctionnalité WAN Mode sur la plate-forme Cisco867VAE et les options qui activent les services Internet DSL.

## Conditions préalables

### Conditions requises

Aucune spécification déterminée n'est requise pour ce document.

### Components Used

Les informations de ce document sont basées sur la plate-forme Cisco867VAE.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

## Configuration

Voici la configuration pour activer les modes WAN sur la plate-forme CISCO867VAE :

```
Cisco867VAE(config)#wan mode ?  
dsl      WAN interface is DSL  
ethernet  WAN interface is ethernet
```

DSL Mode

Ce mode permet de configurer vos paramètres DSL sur ATM ou Ethernet, mais pas sur une

interface de couche 3, qui est Gigabitethernet 0 dans ce périphérique.

```
Cisco867VAE#sh ip int brief
```

Interface	IP-Address	OK?	Method	Status	Protocol
ATM0	unassigned	YES	NVRAM	administratively down	down
Ethernet0	unassigned	YES	NVRAM	administratively down	down
FastEthernet0	unassigned	YES	unset	up	up
FastEthernet1	unassigned	YES	unset	down	down
FastEthernet2	unassigned	YES	unset	down	down
FastEthernet3	unassigned	YES	unset	down	down
GigabitEthernet0	unassigned	YES	NVRAM	down	down
Vlan1	10.106.47.21	YES	NVRAM	up	up

Messages d'erreur rencontrés en mode DSL :

```
Cisco867VAE(config)#wan mode dsl
```

```
% Ethernet WAN interface will be disabled.
```

```
Cisco867VAE(config)#
```

```
*Jan 18 04:35:57.931: %LINK-5-CHANGED: Interface GigabitEthernet0, changed state to administratively down
```

```
Cisco867VAE(config)#int gig 0
```

```
Cisco867VAE(config-if)#no shut
```

```
% WAN interface is DSL
```

```
Cisco867VAE(config)#controller vdsl 0
```

```
Cisco867VAE(config-controller)#no shut
```

```
Cisco867VAE(config)#int eth0
```

```
Cisco867VAE(config-if)#no shut
```

```
*Jan 18 04:40:46.507: %LINK-3-UPDOWN: Interface Ethernet0, changed state to down
```

```
Cisco867VAE(config-if)#int atm 0
```

```
Cisco867VAE(config-if)#no shut
```

```
*Jan 18 04:40:58.771: %LINK-3-UPDOWN: Interface ATM0, changed state to down
```

## Mode Ethernet

En mode Ethernet, vous ne pourrez pas configurer de paramètres DSL, mais vous pouvez utiliser l'interface Gigabit Ethernet de couche 3 pour un réseau externe.

```
Cisco867VAE#wan mode ethernet

% DSL interfaces will be disabled.

Cisco867VAE#
*Jan 18 04:12:48.687: %CONTROLLER-5-UPDOWN: Controller VDSL 0, changed state to administratively
down

Cisco867VAE(config)#controller vdsl 0

Cisco867VAE(config-controller)#no shut

% Operation not allowed when wan mode is ethernet.

Cisco867VAE#sh ip int brief

Interface          IP-Address      OK? Method Status       Protocol
ATM0              unassigned     YES NVRAM  administratively down down
Ethernet0         unassigned     YES NVRAM  administratively down down
FastEthernet0     unassigned     YES unset   up           up
FastEthernet1     unassigned     YES unset   down        down
FastEthernet2     unassigned     YES unset   down        down
FastEthernet3     unassigned     YES unset   down        down
GigabitEthernet0 unassigned     YES NVRAM  administratively down down
Vlan1             10.106.47.21  YES NVRAM  up           up

Cisco867VAE#conf t
Enter configuration commands, one per line.  End with CNTL/Z.

Cisco867VAE(config)#int atm0
Cisco867VAE(config-if)#no shut

% WAN interface is Ethernet.

Cisco867VAE(config-if)#int eth0
Cisco867VAE(config-if)#no shut
```

```
% WAN interface is Ethernet.

Cisco867VAE(config)#int gig 0

Cisco867VAE(config-if)#no shut

*Jan 18 04:30:08.851: %LINK-3-UPDOWN: Interface GigabitEthernet0, changed state to down
Désactiver le mode WAN n'est pas possible lorsqu'il est en mode DSL comme mode par défaut
dans la plate-forme CISCO 867.
```

Mais lorsqu'elle est désactivée en mode Ethernet, elle passe en mode DSL.

```
Cisco867VAE(config)#no wan mode dsl

Cisco867VAE(config)#do sh run | sec wan

wan mode dsl

Cisco867VAE(config)#do sh run | sec wan

wan mode ethernet

Cisco867VAE(config)#no wan mode ethernet
```

% Ethernet WAN interface will be disabled.

**Note:** Utilisez l'[Outil de recherche de commande \(clients inscrits seulement\) pour obtenir plus d'informations sur les commandes utilisées dans cette section.](#)

## Vérification

Référez-vous à cette section pour vous assurer du bon fonctionnement de votre configuration.

```
Cisco867VAE#sh run | inc wan mode

wan mode dsl
```

## Dépannage

Il n'existe actuellement aucune information de dépannage spécifique pour cette configuration.