

Abilitare Multicast PassThru sull'adattatore per telefono analogico SPA800

Obiettivo

Il traffico multicast è il traffico che viene inviato solo a determinate destinazioni in una singola trasmissione, a differenza del traffico broadcast in cui i pacchetti vengono inviati a tutte le destinazioni disponibili. La funzione multicast pass-thru consente a SPA8000 di inoltrare pacchetti IP multicast al PC appropriato. In questo documento viene descritto come abilitare la funzione Multicast PassThru su SPA8000.

Dispositivo applicabile

- SPA8000

Versione del software

- 6.1.12

Multicast PassThru

Passaggio 1. Accedere all'utility di configurazione Web e scegliere **Avanzate > Rete > Applicazione**. Viene visualizzata la pagina *Applicazione*:

The screenshot shows the 'Application' configuration page in the SPA8000 web interface. The 'Network' tab is selected, and the 'Application' sub-tab is active. The page is divided into several sections:

- Port Forwarding Settings:** A table with columns for Enable, Service Name, Starting Port, Ending Port, Protocol, and Server IP Address. The table lists various services like sip2L1, sip2L2, tcp2, rtp2, etc., all with 'yes' in the 'Enable' column.
- DMZ Settings:** 'Enable DMZ' is set to 'no'. 'DMZ Host IP Address' is set to '192.168.2.0'.
- Miscellaneous Settings:** 'Multicast Passthru' is currently set to 'Disabled' (highlighted with a red circle). A dropdown menu is open, showing options: 'Disabled', 'Inbound Only', 'Outbound Only', and 'Inbound and Outbound'.
- System Reserved Ports Range:** 'Starting Port' is empty, and 'Num of Ports Reserved' is set to '256'.

At the bottom of the page, there are two buttons: 'Undo All Changes' and 'Submit All Changes'.

Passaggio 2. Scegliere un'opzione dall'elenco a discesa Multicast PassThru nell'area Impostazioni varie:

- Disabilitato — disabilita la password multicast. Il dispositivo non è in grado di inviare e ricevere traffico multicast.
- Solo in entrata: è consentito solo il traffico multicast in entrata da Internet.
- Solo in uscita: è consentito solo il traffico multicast in uscita dal dispositivo a Internet.
- In entrata e in uscita: è consentito il traffico multicast in entrata e in uscita.

Passaggio 3. Fare clic su **Sottometti tutte le modifiche** per salvare la configurazione.