

借助SPA500系列IP电话在SPA500S上配置话务台密钥LED模式

目标

话务台按键LED是SPA500系列IP电话话务台的一项功能。它帮助用户通过视觉指示区分一般状态和工作状态。当您输入某些特定字母或颜色模式以指示控制台的可视状态时，会配置控制台键LED。LED模式指示SPA500S话务台键的颜色和闪烁模式。

本文档的目的是向您展示如何在SPA500系列IP电话上配置话务台按键LED设置。

注意：SPA500DS不能与UC500系列统一通信设备配合使用，而只能与UC320统一通信设备配合使用。

适用设备

- SPA500系列IP电话
- SPA500S衰减器控制台

软件版本

- v8.6.0 [UC540]
- v3.2(1)[Cisco Configuration Assistant]
- v7-5-2a [SPA 525G IP电话]

LED脚本

LED脚本提供有关线路键LED的颜色和闪烁模式的信息。

·颜色脚本的格式为 $c = o / r / g$ 其中：

- o — 表示LED颜色选项已关闭。
- r — 表示红色。
- g — 表示绿色。

·闪烁模式的脚本格式为 $p = nb | sb | fb | ud$ 位置：

- nb — 表示不发生闪烁。
- sb — 表示缓慢闪烁。（ 1开和1关 ）
- fb — 表示快速闪烁。（ 100毫秒开启， 100毫秒关闭 ）
- ud — 表示用户定义的闪烁模式。

用户定义的闪烁模式的格式为 $u = 开/关/开/关$ ，其中每个值以秒为单位。

配置话务台Key LED模式（带Web界面）

步骤1.登录Web配置实用程序，然后选择Admin Login > Advanced > Attendant Console > Att Console Key LED Pattern。

Info	System	SIP	Provisioning	Regional	Phone	Ext 1	Ext 2	Ext 3	Ext 4	Ext 5	User	Att Console	TR-069
Attendant Console Status User Login basic advanced													
General													
Subscribe Expires:	1800			Subscribe Retry Interval:	30								
Unit 1 Enable:	yes			Subscribe Delay:	1								
Unit 2 Enable:	yes			Server Type:	Broadsoft								
Test Mode Enable:	no			Attendant Console Call Pickup Code:	*98								
Attendant Console Call Park Code:	*68			Attendant Console Call unPark Code:	*88								
BLF List URI:													
Call Pickup Audio Notification:	no			Attendant Console Font Size:	10								
Attendant Console LCD Contrast:	1												
Att Console Key LED Pattern													
Application LED:				Serv Subscribe Failed LED:									
Serv Subscribing LED:				SNRM Day Mode LED:									
SNRM Night Mode LED:				Parking Lot Idle LED:									
Parking Lot Busy LED:				BLF Idle LED:									
BLF Ringing LED:				BLF Busy LED:									
BLF Held LED:													

以下是线路键LED模式区域的各个字段。

Voice	Wi-Fi	Bluetooth	Personal Address Book	Call History	Speed Dials	Firmware Upgrade							
Info	System	SIP	Provisioning	Regional	Phone	Ext 1	Ext 2	Ext 3	Ext 4	Ext 5	User	Att Console	TR-069
Attendant Console Status User Login basic advanced													
General													
Subscribe Expires:	1800			Subscribe Retry Interval:	30								
Unit 1 Enable:	yes			Subscribe Delay:	1								
Unit 2 Enable:	yes			Server Type:	Broadsoft								
Test Mode Enable:	no			Attendant Console Call Pickup Code:	*98								
Attendant Console Call Park Code:	*68			Attendant Console Call unPark Code:	*88								
BLF List URI:													
Call Pickup Audio Notification:	no			Attendant Console Font Size:	12								
Attendant Console LCD Contrast:	10												
Att Console Key LED Pattern													
Application LED:				Serv Subscribe Failed LED:	u=.1/.1/.1/.1								
Serv Subscribing LED:	c=o			SNRM Day Mode LED:									
SNRM Night Mode LED:				Parking Lot Idle LED:									
Parking Lot Busy LED:				BLF Idle LED:	c=o,p=fb								
BLF Ringing LED:	c=g,p=sb			BLF Busy LED:	u=.1/.1/.9/.1								
BLF Held LED:													

- 应用LED — 表示LED功能。
- 服务订用失败LED — 表示话务台订用失败。空白字段表示默认颜色为绿色。
- 服务订用LED — 表示正在订用话务台。空白字段表示默认颜色为红色。
- SNRM Day Mode LED — 表示IP电话处于日模式。空白字段表示默认颜色为绿色。

·SNRM夜间模式LED — 表示IP电话处于夜间模式。空白字段表示默认颜色为红色。

·停车场空闲LED — 表示没有呼叫暂留，线路空闲。空白字段表示默认颜色为红色。

·停车场忙LED — 表示呼叫已暂留，线路忙。空白字段表示默认颜色为红色。

·BLF空闲LED — 表示连接到IP电话的另一条分机线路处于空闲状态。空白字段表示默认颜色为红色。

·BLF振铃LED — 表示连接到IP电话的另一条分机线路振铃。空白字段表示默认颜色为红色。

·BLF忙LED — 表示连接到IP电话的另一条分机线路忙。空白字段表示默认颜色为红色。

·BLF Held LED — 表示连接到IP电话的另一分机处于保持状态。空白字段表示默认颜色为红色。

步骤2.单击“**提交所有更改**”以保存设置。