

# ريغ تاطابرتا ددعتم PPP جوم ىلا ٥ جوم ةنم ازتملا

## المحتويات

- [المقدمة](#)
- [المتطلبات الأساسية](#)
- [المتطلبات](#)
- [المكونات المستخدمة](#)
- [الاصطلاحات](#)
- [النظرية الأساسية](#)
- [التكوين](#)
- [الرسم التخطيطي، للشبكة](#)
- [التكوينات](#)
- [الضبط والأوامر الاختبارية](#)
- [التحقق من الصحة](#)
- [نموذج عرض الإخراج](#)
- [استكشاف الأخطاء وإصلاحها](#)
- [اجراء استكشاف الأخطاء وإصلاحها](#)
- [أوامر استكشاف الأخطاء وإصلاحها](#)
- [إخراج تصحيح الأخطاء للعينة](#)
- [معلومات ذات صلة](#)

## [المقدمة](#)

يصف هذا التكوين وحدة Cisco 3640 عن بعد باستخدام بطاقة مودم تناظري داخليه ذات 8 منافذ (NM-8AM) متصلة بواجهة Cisco AS5300 باستخدام واجهة المعدل الأولى (PRI). يصف التكوين اتصالاً متعدد الارتباطات يتكون من خطين للهاتف التناظري في الموقع البعيد. يمكن تكوين المزيد من خطوط الهاتف لـ MP إذا كانت متوفرة.

## [المتطلبات الأساسية](#)

### [المتطلبات](#)

لا توجد متطلبات أساسية خاصة لهذا المستند.

## [المكونات المستخدمة](#)

تستند المعلومات الواردة في هذا المستند إلى إصدارات البرامج والمكونات المادية أدناه.

- Cisco 3640 يشغل برنامج CISCO IOS Software ، الإصدار (3)12.1
- Cisco AS5300 التي تشغّل برنامج Cisco IOS Software ، الإصدار (T)12.07

**ملاحظة:** تم إدخال بروتوكول MP لأول مرة في البرنامج Cisco IOS Software، الإصدار 11.0 (3).

تم إنشاء المعلومات المقدمة في هذا المستند من الأجهزة الموجودة في بيئة معملية خاصة. بدأت جميع الأجهزة المستخدمة في هذا المستند بتكوين ممسوح (افتراضي). إذا كنت تعمل في شبكة مباشرة، فتأكد من فهمك للتأثير المحتمل لأي أمر قبل استخدامه.

## الاصطلاحات

للحصول على مزيد من المعلومات حول اصطلاحات المستندات، راجع [اصطلاحات تلميحات Cisco التقنية](#).

## النظرية الأساسية

يسمح PPP متعدد الارتباطات (MP) للأجهزة بإرسال البيانات عبر إرتباطات بيانات متعددة من نقطة إلى نقطة إلى الوجهة نفسها من خلال تنفيذ إرتباط ظاهري. يحتوي اتصال MP على الحد الأقصى من النطاق الترددى الذى يساوى مجموعة عرض النطاق الترددى لارتباطات المكون. يمكن تكوين MP إما للروابط المتعددة، مثل ISDN وترحيل الإطارات، أو لخطوط متعددة غير متزامنة. راجع [RFC 1990](#) للحصول على مزيد من المعلومات حول MP.

**ملاحظة:** يشير RFC 1990 إلى PPP متعدد الارتباطات على أنه MP. ومن بين الأسماء الأخرى التي يعرف MP بها Multilink و MLP و PPP.

يمكن استخدام Async MP لتوصيل العملاء البعيدين بسرعة أكبر من المتاح من خلال اتصال تناطيри واحد. في Async MP، يستخدم العميل البعيد أجهزة مودم متعددة، وبالتالي خطوط هاتف متعددة، للاتصال بالموجه المركزي والوصول إلى الشبكة. نظراً لأن العديد من خطوط الهاتف غالباً ما تكون أرخص من خدمة واجهة المعدل الأساسي (BRI) لشبكة ISDN، يوفر بروتوكول Async MP طريقة فعالة لزيادة سرعات الاتصال للمستخدمين البعيدين مع التحكم في التكاليف في الوقت نفسه. كما أن Async MP هي طريقة فعالة للحصول على سرعات وصول أعلى للمناطق البعيدة التي لا يمكن معالجتها بواسطة ISDN.

يقوم MP غير المتزامن بتجميع إتصالات المودم المنفصلة بخادم Access معاً. يعمل برنامج PPP على كل نظير على تجزئة الحزم ثم يرسل الأجزاء إلى الجانب الآخر من خلال الاتصالات التناطيرية المتعددة. وتقوم الطرف المتلقى بجمع هذه الأجزاء من الاتصالات المنفصلة، وبناء على معلومات MP المضمنة فيها، تقوم بإعادة تجميع الأجزاء في حزم بيانات صالحة، مما يوفر إرتباطاً افتراضياً شاملًا بعرض نطاق ترددى أكبر. يمكن تكوين Async MP بين موجهين أو بين موجه وكمبيوتر عميل.


## التكوين

في هذا القسم، تُقدم لك معلومات تكوين الميزات الموضحة في هذا المستند.

**ملاحظة:** للعثور على معلومات إضافية عن الأوامر المستخدمة في هذا المستند، استخدم أداة بحث الأوامر

## الرسم التخطيطي للشبكة

يستخدم هذا المستند إعداد الشبكة الموضح في الرسم التخطيطي أدناه.



## التكوينات

يستخدم هذا المستند التكوينات الموضحة أدناه.

- [Cisco 3640](#) •
- [Cisco AS5300](#) •

```

Cisco 3640

clearlake-lan-01#show running-config
...Building configuration

:Current configuration
!
version 12.1
service timestamps debug datetime msec localtime show-
        timezone
service timestamps log datetime msec localtime show-
        timezone
!
hostname clearlake-lan-01
!
aaa new-model
    aaa authentication login default local
    aaa authentication ppp default if-needed local
    !
<username bobslake-nas-01 password <deleted>
    Remote router and password for CHAP ---!
    authentication. !--- Dialer interface must also be
    configured to use !--- this username and password.
username admin privilege 15 password <deleted> ! no ip
domain-lookup ! chat-script async-mPPP ABORT ERROR ABORT
    BUSY "" "ATZ" OK "ATDT \T" TIMEOUT 30 CONNECT \c !---!
    Chat script used for dialing out. ! interface Loopback0
        ip address 172.21.126.254 255.255.255.0 ! interface
        Ethernet0/0 ip address 172.21.125.1 255.255.255.0 !
            interface Group-Async1 !--- Interface to configure
            modems used for dialout. no ip address encapsulation ppp
                !--- Use PPP encapsulation for members of this !---!
                group-async interface. dialer in-band !--- Permit DDR on
                this interface. dialer pool-member 10 !--- All members
                of this group-async interface belong !--- to dialer pool
                10. ppp multilink !--- Enable PPP multilink on physical
                interface. group-range 33 34 !--- Assign async 33 and 34
                to this group-async interface. !--- This can be adjusted
                depending on the number of POTS lines available. !
                interface Dialer1 !--- Dialer interface to dialout to
                bobslake-nas-01. ip address negotiated !--- Obtain an IP
                address from central site. encapsulation ppp dialer

```

```

remote-name bobslake-nas-01 !--- Identify central site
    router for CHAP authentication. !--- Shared secret
    password is defined above. dialer pool 10 !--- Defines
    the pool of physical resources that the Dialer !---
    interface may use. dialer idle-timeout 600 !--- 
    Specifies number of seconds without interesting traffic
    that !--- the connection is kept up. dialer string
    5551212 !--- Number to be dialed; this number belongs to
    the PRI !--- of the central router. dialer load-
    threshold 15 either !--- Load level for either inbound
    or outbound traffic !--- at which additional lines will
    be added to the MP bundle. !--- Load level values range
    from 1 (unloaded) to 255 (fully loaded). dialer-group 8
    !--- Uses dialer-list 8 to determine interesting
    traffic. ppp authentication chap callin !--- Use CHAP
    authentication for incoming calls only !--- This router
    will not challenge remote routers for outgoing calls.
    ppp multilink !--- Activates the interface for MP
    operation. ppp timeout multilink link remove 300 !--- 
    Keeps the multilink connections up for 300 seconds !---
    after the load drops below the threshold. !--- This
    command should be used to control flapping. ! ip
    classless ip route 0.0.0.0 0.0.0.0 Dialer1 !--- Use
    Interface Dialer1 for all networks. no ip http server !
    access-list 188 remark define interesting traffic
    access-list 188 deny udp any any eq ntp access-list 188
    permit ip any any dialer-list 8 protocol ip list 188 !-- 
    - Assign access-list 188 to dialer-list 8. ! line con 0
    transport input none line 33 34 !--- Async lines to be
    used for dialout. !--- This number should match the
    group-range in the !--- Group-Async interface. script
    dialer async-mppe !--- Use chat script called async-mppe
    for dialout. modem InOut modem autoconfigure discovery
    transport preferred none transport input all line 35 40
    transport preferred none transport input all line aux 0
    line vty 0 4 ! ntp clock-period 17179871 ntp server
    172.22.255.1 prefer end

```

## Cisco AS5300

```

bobslake-nas-01#show running-config

...Building configuration

:Current configuration

version 12.0
service timestamps debug datetime msec localtime show-
    timezone
service timestamps log datetime msec localtime show-
    timezone
service password-encryption
service tcp-small-servers
!
hostname bobslake-nas-01
!
logging buffered 10000 debugging
    aaa new-model
        aaa authentication login default local
        aaa authentication ppp default if-needed local
        Authenticate for PPP if not authenticated during ---!
login. !--- Allows users with Terminal Window after Dial
        to initiate PPP. ! username clearlake-lan-01 password

```

```

<deleted> !--- Remote router and password for Challenge
Handshake !--- Authentication Protocol (CHAP)
authentication. !--- The password must be identical on
both sides. spe 1/0 1/7 firmware location
system:/ucode/mica_port_firmware ! resource-pool disable
! ip subnet-zero ! multilink virtual-template 1 !--- Use
virtual-template 1 for multilink connections. isdn
switch-type primary-5ess isdn voice-call-failure 0 !
controller T1 0 framing esf clock source line primary
linecode b8zs pri-group timeslots 1-24 ! interface
Loopback0 ip address 172.21.10.10 255.255.255.255 no ip
directed-broadcast ! interface Loopback1 ip address
172.21.104.254 255.255.255.0 !--- Summarizes addresses
in address pool. !--- Loopback 1 is in the same subnet
as the address pool. no ip directed-broadcast !
interface Virtual-Templatel description Template for
Multilink Users ip unnumbered Loopback0 no ip directed-
broadcast peer default ip address pool addr-pool !--- Use IP pool called addr-pool for incoming calls. ppp
authentication chap !--- Authenticate using CHAP. ppp
multilink !--- Allow multilink sessions. ! !--- Configure D channel on PRI. interface Serial0:23
description Headquarters 555-1212 active PRI line no ip
address no ip directed-broadcast isdn switch-type
primary-5ess isdn incoming-voice mode fair-queue 64 256
0 no cdp enable ! interface FastEthernet0 ip address
172.21.101.23 255.255.255.0 no ip directed-broadcast
duplex auto speed auto ! interface Group-Async1 ip
unnumbered Loopback0 no ip directed-broadcast
encapsulation ppp dialer in-band dialer idle-timeout 600
either !--- Specifies number of seconds without
interesting !--- traffic that the connection is kept up.
!--- Configure the same idle-timeout on both routers.
dialer map ip 172.21.125.1 name clearlake-nas-01 dialer-
group 5 !--- Uses dialer-list 5 to determine interesting
traffic. async mode interactive peer default ip address
pool addr-pool !--- Use IP pool called addr-pool for
incoming calls. ppp authentication chap callin !--- Issue CHAP challenges for dialin users only. ppp
multilink group-range 1 48 !--- Assign modems 1-48 to
the Group-Async 1 configuration template. ! router eigrp
1 passive-interface Group-Async1 !--- To prevent routing
traffic on async lines. network 172.21.0.0 ! ip local
pool addr-pool 172.21.104.1 172.21.104.48 !--- Define IP
address pool range for dialin clients. ip classless no
ip http server ! access-list 105 permit ip any any !--- Define interesting traffic. dialer-list 5 protocol ip
list 105 !--- Assign access list 105 to dialer list 5. !
line con 0 transport input none line 1 48 autoselect
during-login !--- Permits user login prompts after
dialin. autoselect ppp !--- Automatically launches PPP
on the line. modem InOut !--- Modems can be used to
dialin and dialout. transport preferred none transport
output telnet line aux 0 line vty 0 4 ! ntp clock-period
17180374 ntp update-calendar ntp server 172.22.255.1
prefer end

```

## الضبط والأوامر الاختيارية

يمكن استخدام الأوامر التالية لضبط سلوك اتصال MP. ومن شأن التعديل الدقيق لهذه البارامترات أن يساعد في التحكم في التكاليف بتجنب الاستخدام المسرف وغير الضروري للوصلات الخاصة بالبيانات.

- حمل حد حمل المتصل [الصادر / الوارد / إما] يمكن تكوين بروتوكول MP بحيث تظهر القنوات الإضافية مباشرة بعد إنشاء القناة الأساسية. لإعداد هذا السيناريو، قم بتعيين قيمة حد الحمل في أمر تحويل طاقة الحمل إلى 1 في المتصل. في هذه الحالة، يتم إنشاء القنوات الإضافية والاستمرار في العمل (أي أنها لا ترفرف). إذا تم تعيين حد الحمل على أي قيمة أخرى، فقد ترفرف القنوات المتعددة بناءً على الحمل عبر الارتباط. إذا كنت تريدين إضافة قنوات إضافية حسب الضرورة، حسب حركة المرور، قم بتعيين عتبة الحمل للقيمة المناسبة بين 1 و 255. على سبيل المثال، لكي تصل القنوات الإضافية إلى 50 في المئة، يجب تعيين الحد على 128 ( $128 = 50 * 255^{*}$ ). عند تحديد الحد، يجب مراعاة وقت الإعداد للمكالمات غير المتزامنة لأن أوقات الإعداد الأطول قد تتطلب حدودًا أقل. يمكن حساب الحمل استناداً إلى الصادر أو الوارد أو إما أعلى حركة المرور الواردة أو الصادرة على الواجهة. إذا قمت بتأسيس الحمل على الوارد أو إما، فتأكد من أن الموقع المركزي يحتوي على passive-interface Group- Async1 الذي تم تكوينه لذلك لا يتم إرسال تحديثات التوجيه من الأساسي عبر السطر غير المتزامن. منع حركة المرور التوجيه من المرور على الارتباط يوفر المزيد من النطاق الترددى للبيانات الأخرى على الخط.
- انتهاء مهلة PPP للارتباط المتعدد **ثوانٍ لإزالة الارتباط** قد يتم استخدام هذا الأمر لمنع إتصالات الارتباط المتعدد من الرفرفة عند تغيير الحمل. على سبيل المثال، عندما يتم تعيين حد الحمل على 15 (أي،  $15 = 255 / 15 * 6\%$ ) وتتجاوز حركة المرور الحد، يتم جلب خطوط إضافية. عندما تتحقق حركة المرور إلى أقل من الحد، يتم إسقاط الخطوط الإضافية. في الحالات التي تكون فيها معدلات البيانات متغيرة بدرجة كبيرة، من المفید للقنوات المتعددة أن تظل مستيقظة لفترة زمنية محددة حتى إذا كانت عتبة الحمل أقل من القيمة المحددة. قم بتعيين مهلة الارتباط المتعدد هذه لتكون أقل من تلك المحددة لـ المتصل خامل- timeout التي تحكم في المهلة لجميع الارتباطات.
- مهلة PPP للارتباط المتعدد **ثوانٍ إضافية** يمكن استخدامها لمنع إضافة إرتباطات متعددة إلى حزمة MP حتى يتم تلقي حركة مرور عالية لفترات زمنية محددة. وهذا يمكن أن يمنع دفعات حركة المرور من جلب خطوط إضافية دون لزوم.

## التحقق من الصحة

يتوفر هذا القسم معلومات يمكنك استخدامها للتأكد من أن التكوين يعمل بشكل صحيح.  
يتم دعم بعض أوامر العرض بواسطة أداة مترجم الإخراج، والتي تتيح لك عرض تحليل إخراج أمر العرض.

- **show ppp multilink** - لعرض المعلومات حول حزم الارتباط المتعدد النشطة. يجب استخدام هذا الأمر للتحقق من الاتصال متعدد الارتباطات.
- **show caller** - لعرض المعلومات حول المستخدمين الأفراد والموارد المستهلكة على وحدات التخزين المتصلة بالشبكة (NAS). يعرض هذا الأمر إحصائيات المكالمات النشطة للتجمعات الكبيرة من الاتصالات، ويبدي الأوقات المطلقة والخاملة لكل مستخدم. إذا لم يدعم إصدار برنامج Cisco IOS هذا الأمر، فاستخدم الأمر show user.
- **show caller user** - لإظهار معلومات المستخدم المعين مثل خط tty المستخدم، والواجهة غير المتزامنة (shelf/slot/port)، ورقم قناة DS0، ورقم المودم، وعنوان IP المعين، ومعلومات حزمة PPP و PPP، وما إلى ذلك. إذا لم يدعم إصدار برنامج Cisco IOS هذا الأمر، فاستخدم الأمر show user.

## نموذج عرض الإخراج

يتم أخذ مخرجات الأمر show التالية من Cisco 3640 الذي يتصل بـ AS5300. إنه يظهر أن اتصال الارتباط المتعدد قيد التشغيل

```
clearlake-lan-01#show ppp multilink
Virtual-Access1, bundle name is bobslake-nas-01
Virtualized MP bundle. Bundle name is derived from the !--- username used during ---!
authentication. Dialer interface is Dialer1 !--- This Virtual Access Interface used Interface
Dialer1. 0 lost fragments, 0 reordered, 0 unassigned 0 discarded, 0 lost received, 1/255 load
0x4 received sequence, 0x0 sent sequence Member links: 2 (max not set, min not set) Async34
Async33
Members of the MP bundle. clearlake-lan-01#show dialer ---!
```

```

As33 - dialer type = IN-BAND ASYNC NO-PARITY
Dialer pool 10, priority 0
Member of dialer pool 10. Idle timer (120 secs), Fast idle timer (20 secs) Wait for carrier ---!
(30 secs), Re-enable (15 secs) Dialer state is multilink member Dial reason: Multilink bundle overloaded

Interface was not the first link in the MP bundle. Interface bound to profile Dil Current ---!
call connected 00:00:54 !--- Current call duration Connected to <deleted>5551212 (boslake-nas-01) !--- Phone number that was dialed. As34 - dialer type = IN-BAND ASYNC NO-PARITY
Dialer pool 10, priority 0
Member of dialer pool 10. Idle timer (600 secs), Fast idle timer (20 secs) Wait for carrier ---!
(30 secs), Re-enable (15 secs) Dialer state is multilink member Dial reason: ip (s=172.21.125.1,
d=172.21.104.254) !--- Interface was the first link in the bundle, triggered by !--- interesting traffic. Interface bound to profile Dil Current call connected 00:00:54 !--- Current Call duration. Connected to 5551212 <deleted> (boslake-nas-01) !--- Phone number that was dialed.

Gr1 - dialer type = IN-BAND ASYNC NO-PARITY Idle timer (120 secs), Fast idle timer (20 secs)
Wait for carrier (30 secs), Re-enable (15 secs) Dialer state is idle Dial String Successes Failures Last DNIS Last status Dil - dialer type = DIALER PROFILE Load threshold for dialing additional calls is 15 !--- Load threshold. Idle timer (600 secs), Fast idle timer (20 secs)
Wait for carrier (30 secs), Re-enable (15 secs) Dialer state is data link layer up Number of active calls = 2 Dial String Successes Failures Last DNIS Last status 15 0 00:00:56 successful
Default clearlake-lan-01#show caller

      Active   Idle
      Line     User       Service    Time     Time
      con 0   tarpon     TTY        00:09:11  00:00:00
tty 33   -          Async      -          00:00:01
TTY 34   -          Async      -          00:00:06
As33     boslake-nas-01 PPP        00:00:24  00:00:00

Second connection. As34     boslake-nas-01     PPP        00:01:05  00:00:00 ---!
First connection. Vi1      boslake-nas-01     PPP     Bundle  00:01:05  00:01:04 ---!

MP bundle !--- boslake-nas-01 has two async lines, two TTY, and one virtual !--- interface ---!
bundle. clearlake-lan-01#show caller user boslake-nas-01

```

```

User: boslake-nas-01, line As33, service PPP
PPP setting for boslake-nas-01. Active time 00:00:34, Idle time 00:00:00 Timeouts: ---!
(Absolute Idle Limits: - - Disconnect in: - - PPP: LCP Open, multilink Open, CHAP (-> AAA
Multilink is up. Dialer: Connected 00:01:09 to <deleted>, outbound !--- Dialer interface ---!
was used to dialout. Type is IN-BAND ASYNC, group Dialer1 Cause: Multilink bundle overloaded
This interface was not the first member of the MP bundle. IP: Local 172.21.104.48/32 ---!
Bundle: Member of boslake-nas-01, last input 00:00:00 Counts: 59 packets input, 3529 bytes, 0
no buffer 0 input errors, 22 CRC, 0 frame, 0 overrun 31 packets output, 1515 bytes, 0 underruns
0 output errors, 0 collisions, 4 interface resets !--- Packets are passing through the
connection. User: boslake-nas-01, line As34, service PPP
PPP setting for user boslake-nas-01. Active time 00:01:15, Idle time 00:00:00 Timeouts: ---!
(Absolute Idle Limits: - - Disconnect in: - - PPP: LCP Open, multilink Open, CHAP (-> AAA
MP state is open. Dialer: Connected 00:01:10 to <deleted>, outbound Type is IN-BAND ASYNC, ---!
(group Dialer1 Cause: ip (s=172.21.125.1, d=172.21.104.254
Dialing cause was interesting traffic; this was the !--- first link in the bundle. IP: ---!
Local 172.21.104.48/32 Bundle: Member of boslake-nas-01, last input 00:00:00 Counts: 172
packets input, 20699 bytes, 0 no buffer 0 input errors, 81 CRC, 0 frame, 0 overrun 80 packets
output, 14347 bytes, 0 underruns 0 output errors, 0 collisions, 6 interface resets !--- Packets
are passing through the connection. User: boslake-nas-01, line Vi1, service PPP Bundle
Bundle information for user boslake-nas-01. Active time 00:01:16, Idle time 00:01:15 ---!
Timeouts: Absolute Idle Limits: - 00:10:00 Disconnect in: - 00:08:44 !--- Idle-timeout is 600
seconds(10 minutes). PPP: LCP Open, multilink Open, IPCP
Dialer: Connected 00:01:10 to <deleted>, outbound
Idle timer 600 secs, idle 75 secs
Type is IN-BAND SYNC, group Dialer1
IP: Local 172.21.104.48/32, remote 172.21.104.254
IP address assigned to the bundle and loopback address !--- of the remote router. Bundle: ---!
First link of boslake-nas-01, 2 links, last input 00:01:16 Counts: 23 packets input, 4758
bytes, 0 no buffer 0 input errors, 0 CRC, 0 frame, 0 overrun 7 packets output, 3734 bytes, 0
underruns 0 output errors, 0 collisions, 0 interface resets

```

بعض إظهارات مخرجات الأوامر من AS5300 موضحة أدناه. للحصول على مزيد من المخرجات، ارجع إلى المستند [اتصال PPP متعدد الارتباطات من وثائق عملاء Microsoft Windows](#). سيكون إخراج `debug show` من AS5300 (الموقع المركزي) مماثلاً لـ PC-Router Async MP والموجه Async MP.

```
bobslake-nas-01#show ppp multilink
```

```
Virtual-Access1, bundle name is clearlake-lan-01
lost fragments, 0 reordered, 0 unassigned, sequence 0x1/0x10 rcvd/sent 0
discarded, 0 lost received, 1/255 load 0
(Member links: 2 (max not set, min not set
Async47
Async45
```

```
bobslake-nas-01#show caller
```

Active	Idle		Service	Time	Time
Line	User				
TTY 45	clearlake-lan-01	Async		00:01:12	00:01:03
TTY 47	clearlake-lan-01	Async		00:01:51	00:00:06
vty 0	admin	VTY		00:11:02	00:00:00
As45	clearlake-lan-01	PPP		00:01:02	00:00:00
As47	clearlake-lan-01	PPP		00:01:49	00:00:00
vi1	clearlake-lan-01	PPP	Bundle	00:01:43	00:01:10

## استكشاف الأخطاء وإصلاحها

يوفر هذا القسم معلومات يمكنك استخدامها لاستكشاف أخطاء التكوين وإصلاحها.

### إجراءات استكشاف الأخطاء وإصلاحها

عند استكشاف أخطاء اتصال MP وإصلاحها، قم بالمتابعة بنفس الطريقة التي تم بها المكالمة:

يتم توفير [إخراج تصحيح الأخطاء](#) الذي تم وضع علامة عليه توضيحات حول ما يجب البحث عنه، أدناه.

عند إختبار تكوين MP، تأكد من أنك تقوم بإنشاء حركة مرور كافية عبر الارتباط لتشغيل حد الحمل. يمكنك ضبط قيمة حد الحمل أثناء الاختبار حسب الضرورة.

1. استخدم أوامر `debug chat` و `debug dialer` للتحقق من طلب المتصل بشكل صحيح.
2. تحقق من نجاح تفاوض PPP ومصادقة PPP. انتبه إلى تفاوض LCP حيث يتم التفاوض حول وحدة الاستلام القصوى لخط معلمات MP التي أعيد إنشاؤها (MRRU) ومحدد نقطة النهاية (EndpointDisc).
3. تتحقق من محاكاة الارتباط افتراضياً بشكل صحيح. سيتم إنشاء واجهة وصول افتراضية بواسطة برنامج Cisco IOS software لتمثيل حزمة MP.
4. تتحقق من نجاح تفاوض بروتوكول التحكم في بروتوكول الإنترنت (IPCP). لاحظ ما إذا تم تعين عناوين IP الصحيحة وما إذا كان قد تم تثبيت المسارات الصحيحة أم لا.

### أوامر استكشاف الأخطاء وإصلاحها

يتم دعم بعض أوامر العرض بواسطة أداة مترجم الإخراج، والتي تتيح لك عرض تحليل إخراج أمر العرض.

ملاحظة: قبل إصدار أوامر تصحيح الأخطاء، يرجى الاطلاع على [المعلومات المهمة في أوامر تصحيح الأخطاء](#).

- `debug vtemplate` - لعرض معلومات نسخ لواجهة وصول افتراضية من الوقت الذي يتم فيه نسخها من قالب ظاهري إلى الوقت الذي يتم سحبها فيه.
- `debug ppp multilink events` - لعرض معلومات حول الأحداث التي تؤثر على مجموعات الارتباطات المتعددة.

- **debug ppp negotiation** - لعرض معلومات حول حركة مرور وتبادل PPP أثناء التفاوض حول بروتوكول التحكم في الارتباط (LCP) والمصادقة وبروتوكول التحكم في الشبكة (NCP). إن تفاوض PPP الناجح سيقوم أولاً بفتح حالة LCP، ثم المصادقة، وأخيراً التفاوض على NCP. يتم إنشاء معلمات الارتباط المتعدد مثل وحدة الاستقبال المعاد إنشاؤها القصوى (MRRU) أثناء تفاوض LCP.
- **تصحيح أخطاء مصادقة PPP** - لعرض رسائل بروتوكول مصادقة PPP، بما في ذلك عمليات تبادل حزم بروتوكول المصادقة لتأكيد الاتصال بقيمة التحدي (CHAP) وعمليات تبادل بروتوكول مصادقة كلمة المرور (PAP).
- **خطأ في تصحيح أخطاء PPP** - لعرض أخطاء البروتوكول وإحصائيات الخطأ المقترنة بالتفاوض حول اتصال PPP وتشغيله.
- **تصحيح أخطاء المودم** - لعرض نشاط خط المودم على خادم Access.

## إخراج تصحيح الأخطاء للعينة

تم الحصول على المخرجات التالية من Cisco 3640 الذي يتصل PRI من ال AS5300 MP ويشير اتصال إلى [تصحيح الأخطاء من Microsoft Windows](#). على سبيل المثال، يشير إخراج تصحيح الأخطاء من [اتصال PPP متعدد الارتباطات من مستند عمالء Microsoft Windows](#).

```

clearlake-lan-01#debug dialer
Dial on demand events debugging is on
clearlake-lan-01#debug ppp negotiation
PPP protocol negotiation debugging is on
clearlake-lan-01#debug ppp authentication
PPP authentication debugging is on
clearlake-lan-01#debug vtemplate
Virtual Template debugging is on
clearlake-lan-01#debug ppp multilink events
clearlake-lan-01#show debug
:Dial on demand
Dial on demand events debugging is on
:PPP
PPP authentication debugging is on
PPP protocol negotiation debugging is on
Multilink events debugging is on
:VTEMPLATE
Virtual Template debugging is on
clearlake-lan-01#ping ip
Target IP address: 172.21.104.254
Repeat count [5]: 20
Datagram size [100]: 1200
:[Timeout in seconds [2
:[Extended commands [n
:[Sweep range of sizes [n
.Type escape sequence to abort
:Sending 20, 1200-byte ICMP Echos to 172.21.104.254, timeout is 2 seconds

[Jul 25 13:20:29.047 UTC: As34 DDR: rotor dialout [priority
,Jul 25 13:20:29.047 UTC: As34 DDR: Dialing cause ip (s=172.21.125.1
(d=172.21.104.254
Dialing Reason Jul 25 13:20:29.047 UTC: As34 DDR: Attempting to dial ---!
```

```

Number being dialed Jul 25 13:20:29.047 UTC: CHAT34: Attempting async line dialer script ---
Jul 25 13:20:29.047 UTC: CHAT34: Dialing using Modem script: async-mppp & System script: none !-
-- Using chat script async-mppp for dialout Jul 25 13:20:29.051 UTC: CHAT34: process started Jul
```

25 13:20:29.051 UTC: CHAT34: Asserting DTR Jul 25 13:20:29.051 UTC: CHAT34: Chat script async-mppp started !--- Call is being established; !--- note the time elapsed for call setup Jul 25 13:20:54.831 UTC: CHAT34: Chat script async-mppp finished, status = Success. Jul 25 13:20:56.831 UTC: %LINK-3-UPDOWN: Interface Async34, changed state to up :Jul 25 13:20:56.831 UTC  
Async34 DDR: Dialer statechange to up :Jul 25 13:20:56.831 UTC  
**DIALER-6-BIND: Interface As34 bound to profile Di1%**  
:Jul 25 13:20:56.831 UTC  
Async34 DDR: Dialer call has been placed  
*PPP negotiation begins* Jul 25 13:20:56.831 UTC: As34 PPP: Treating connection as a callout ---!  
Jul 25 13:20:56.831 UTC: As34 PPP: Phase is ESTABLISHING, Active Open Jul 25 13:20:56.831 UTC:  
As34 PPP: No remote authentication for call-out !--- CHAP challenge is configured for calling only !--- LCP negotiation begins; Multilink parameters are also negotiated Jul 25 13:20:56.835 UTC: As34 LCP: O CONFREQ [Closed] id 43 len 43 Jul 25 13:20:56.835 UTC: As34 LCP: ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:20:56.835 UTC: As34 LCP: MagicNumber 0x4395638E (0x05064395638E) Jul 25 13:20:56.835 UTC: As34 LCP: PFC (0x0702) Jul 25 13:20:56.835 UTC: As34 LCP: ACFC (0x0802) Jul 25 13:20:56.835 UTC: As34 LCP: MRRU 1524 (0x110405F4) !--- Negotiate Maximum Receive Reconstructed Unit (MRRU) !--- MRRU is the maximum packet size this end will reconstruct Jul 25 13:20:56.835 UTC: As34 LCP: EndpointDisc 1 Local Jul 25 13:20:56.835 UTC: As34 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:20:58.831 UTC: As34 LCP: TIMEout: State REQsent Jul 25 13:20:58.831 UTC: As34 LCP: O CONFREQ [REQsent] id 44 Len 43 Jul 25 13:20:58.831 UTC: As34 LCP: ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:20:58.831 UTC: As34 LCP: MagicNumber 0x4395638E (0x05064395638E) Jul 25 13:20:58.831 UTC: As34 LCP: PFC (0x0702) Jul 25 13:20:58.831 UTC: As34 LCP: ACFC (0x0802) Jul 25 13:20:58.831 UTC: As34 LCP: MRRU 1524 (0x110405F4) Jul 25 13:20:58.831 UTC: As34 LCP: EndpointDisc 1 Local Jul 25 13:20:58.831 UTC: As34 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:20:58.831 UTC: As34 LCP: (0x2D3031). Jul 25 13:21:00.831 UTC: As34 LCP: TIMEout: State REQsent Jul 25 13:21:00.831 UTC: As34 LCP: O CONFREQ [REQsent] id 45 Len 43 Jul 25 13:21:00.831 UTC: As34 LCP: ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:21:00.831 UTC: As34 LCP: MagicNumber 0x4395638E (0x05064395638E) Jul 25 13:21:00.831 UTC: As34 LCP: PFC (0x0702) Jul 25 13:21:00.831 UTC: As34 LCP: ACFC (0x0802) Jul 25 13:21:00.831 UTC: As34 LCP: MRRU 1524 (0x110405F4) Jul 25 13:21:00.831 UTC: As34 LCP: EndpointDisc 1 Local Jul 25 13:21:00.831 UTC: As34 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:21:01.135 UTC: **As34 LCP: I CONFACK [REQsent] id 45 Len 43**  
(Jul 25 13:21:01.135 UTC: As34 LCP: ACCM 0x000A0000 (0x0206000A0000)  
(Jul 25 13:21:01.135 UTC: As34 LCP: MagicNumber 0x4395638E (0x05064395638E)  
(Jul 25 13:21:01.135 UTC: As34 LCP: PFC (0x0702)  
(Jul 25 13:21:01.135 UTC: As34 LCP: ACFC (0x0802)  
(Jul 25 13:21:01.135 UTC: **As34 LCP: MRRU 1524 (0x110405F4)**  
Jul 25 13:21:01.135 UTC: As34 LCP: EndpointDisc 1 Local  
(Jul 25 13:21:01.135 UTC: As34 LCP: (0x131301636C6561726C616B652D6C616E)  
(Jul 25 13:21:01.135 UTC: As34 LCP: (0x2D3031)  
Jul 25 13:21:01.139 UTC: As34 LCP: I CONFREQ [ACKrcvd] id 6 Len 47  
(Jul 25 13:21:01.139 UTC: As34 LCP: ACCM 0x000A0000 (0x0206000A0000)  
(Jul 25 13:21:01.143 UTC: As34 LCP: AuthProto CHAP (0x0305C22305)  
(Jul 25 13:21:01.143 UTC: As34 LCP: MagicNumber 0xE16DFC8D (0x0506E16DFC8D)  
(Jul 25 13:21:01.143 UTC: As34 LCP: PFC (0x0702)  
(Jul 25 13:21:01.143 UTC: As34 LCP: ACFC (0x0802)  
(Jul 25 13:21:01.143 UTC: As34 LCP: MRRU 1524 (0x110405F4)  
Jul 25 13:21:01.143 UTC: As34 LCP: EndpointDisc 1 Local  
(Jul 25 13:21:01.143 UTC: As34 LCP: (0x131201626F62736C616B652D6E61732D)  
(Jul 25 13:21:01.143 UTC: As34 LCP: (0x3031)  
Jul 25 13:21:01.143 UTC: **As34 LCP: O CONFACK [ACKrcvd] id 6 Len 47**  
(Jul 25 13:21:01.143 UTC: As34 LCP: ACCM 0x000A0000 (0x0206000A0000)  
(Jul 25 13:21:01.143 UTC: As34 LCP: AuthProto CHAP (0x0305C22305)  
(Jul 25 13:21:01.143 UTC: As34 LCP: MagicNumber 0xE16DFC8D (0x0506E16DFC8D)  
(Jul 25 13:21:01.143 UTC: As34 LCP: PFC (0x0702)  
(Jul 25 13:21:01.143 UTC: As34 LCP: ACFC (0x0802)  
(Jul 25 13:21:01.143 UTC: **As34 LCP: MRRU 1524 (0x110405F4)**  
Jul 25 13:21:01.143 UTC: As34 LCP: EndpointDisc 1 Local  
(Jul 25 13:21:01.143 UTC: As34 LCP: (0x131201626F62736C616B652D6E61732D)  
(Jul 25 13:21:01.143 UTC: As34 LCP: (0x3031)  
Both sides have CONFACKed the parameters !--- MRRU of 1524 bytes and the Endpoint ---!

*Discriminator have been negotiated* Jul 25 13:21:01.143 UTC: As34 LCP: State is Open !--- LCP  
*negotiation complete* Jul 25 13:21:01.147 UTC: As34 PPP: Phase is AUTHENTICATING, by the peer !--!  
*- Received a challenge from the remote router* Jul 25 13:21:01.351 UTC: As34 CHAP: I CHALLENGE id  
 3 Len 36 from "boslake-nas-01" Jul 25 13:21:01.351 UTC: As34 CHAP: O RESPONSE id 3 Len Jul 25  
 13:21:01.539 UTC: As34 CHAP: I SUCCESS id 3 Len 4 !--- CHAP authentication successful Jul 25  
 13:21:01.539 UTC: As34 PPP: Phase is VIRTUALIZED !--- Virtualize Async 34 !--- Virtual Access  
*interface will represent the MP bundle* Jul 25 13:21:01.543 UTC: Vi1 VTEMLATE: Reuse Vi1,  
 recycle queue size 0 Jul 25 13:21:01.543 UTC: Vi1 VTEMLATE: Hardware address 0030.9401.f101 Jul  
 25 13:21:01.543 UTC: Vi1 PPP: Phase is DOWN, Setup Jul 25 13:21:01.543 UTC: %DIALER-6-BIND:  
 Interface Vi1 bound to profile Dil Jul 25 13:21:01.543 UTC: Vi1 VTEMLATE: Has a new cloneblk  
 dialer, now it has dialer Jul 25 13:21:01.547 UTC: %LINK-3-UPDOWN: Interface Virtual-Access1,  
 changed state to up Jul 25 13:21:01.547 UTC: Virtual-Access1 DDR: Dialer statechange to up !---  
*Virtual Access Interface is up !--- Negotiate LCP and PPP parameters for Virtual-Access*  
*Interface* Jul 25 13:21:01.547 UTC: Virtual-Access1 DDR: Dialer call has been placed Jul 25  
 13:21:01.547 UTC: Vi1 PPP: Treating connection as a callout Jul 25 13:21:01.547 UTC: Vi1 PPP:  
 Phase is ESTABLISHING, Active Open Jul 25 13:21:01.547 UTC: Vi1 PPP: No remote authentication  
 for call-out Jul 25 13:21:01.547 UTC: Vi1 LCP: O CONFREQ [Closed] id 1 Len 33 Jul 25  
 13:21:01.547 UTC: Vi1 LCP: MagicNumber 0x439575FC (0x0506439575FC) Jul 25 13:21:01.547 UTC: Vi1  
 LCP: MRRU 1524 (0x110405F4) Jul 25 13:21:01.551 UTC: Vi1 LCP: EndpointDisc 1 Local Jul 25  
 13:21:01.551 UTC: Vi1 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:21:01.551 UTC: Vi1  
 LCP: (0x2D3031) Jul 25 13:21:01.551 UTC: Vi1 PPP: Phase is UP Jul 25 13:21:01.551 UTC: Vi1 IPCP:  
 O CONFREQ [Closed] id 1 Len 10 Jul 25 13:21:01.551 UTC: Vi1 IPCP: Address 0.0.0.0  
 (0x030600000000) Jul 25 13:21:01.551 UTC: **As34 MLP: boslake-nas-01, multilink up, first link**  
*First multilink connection is virtualized* Jul 25 13:21:01.651 UTC: Vi1 IPCP: I CONFREQ ---!  
 [REQsent] id 1 Len 10 Jul 25 13:21:01.651 UTC: Vi1 IPCP: Address 172.21.104.254 (0x0306AC1568FE)  
 Jul 25 13:21:01.651 UTC: Vi1 IPCP: O CONFACK [REQsent] id 1 Len 10 Jul 25 13:21:01.651 UTC: Vi1  
 IPCP: Address 172.21.104.254 (0x0306AC1568FE) Jul 25 13:21:01.731 UTC: Vi1 IPCP: I CONFNAK  
 [ACKsent] id 1 Len 10 Jul 25 13:21:01.731 UTC: Vi1 IPCP: Address 172.21.104.48 (0x0306AC156830)  
 Jul 25 13:21:01.731 UTC: Vi1 IPCP: O CONFREQ [ACKsent] id 2 Len 10 Jul 25 13:21:01.731 UTC: Vi1  
 IPCP: Address 172.21.104.48 (0x0306AC156830) Jul 25 13:21:01.915 UTC: Vi1 IPCP: I CONFACK  
 [ACKsent] id 2 Len 10 Jul 25 13:21:01.915 UTC: Vi1 IPCP: Address 172.21.104.48 (0x0306AC156830)  
 Jul 25 13:21:01.915 UTC: vi1 IPCP: State is Open Jul 25 13:21:01.915 UTC: Dil IPCP: Install  
 negotiated IP interface address 172.21.104.48 !--- IP address is assigned to virtual-access  
*interface* Jul 25 13:21:01.919 UTC: Vi1 DDR: dialer protocol up Jul 25 13:21:01.919 UTC: Dil  
 IPCP: Install route to 172.21.104.254 !--- Route to loopback address of remote router Jul 25  
 ,13:21:02.539 UTC: %LINEPROTO-5-UPDOWN: Line protocol on Interface Async34  
*changed state to up*  
 :Jul 25 13:21:02.551 UTC  
**LINEPROTO-5-UPDOWN: Line protocol on Interface%**  
*Virtual-Access1, changed state to up*  
*Full connectivity with first async connection !--- Begin dialout using second async ---!*  
*interface* Jul 25 13:21:08.191 UTC: As33 DDR: rotor dialout [priority] Jul 25 13:21:08.191 UTC:  
**As33 DDR: Attempting to dial**

*Number to be dialed; this number is the PRI on the remote router* Jul 25 13:21:08.191 UTC: ---!  
 CHAT33: Attempting async line dialer script Jul 25 13:21:08.191 UTC: CHAT33: Dialing using Modem  
 script: async-mppp & System script: none !--- Use chat script async-mppp for dialout Jul 25  
 13:21:08.191 UTC: CHAT33: process started Jul 25 13:21:08.191 UTC: CHAT33: Asserting DTR Jul 25  
 13:21:08.191 UTC: CHAT33: Chat script async-mppp started Jul 25 13:21:33.859 UTC: CHAT33: Chat  
 script async-mppp finished, status = Success !--- Chat script successful Jul 25 13:21:35.859  
 UTC: %LINK-3-UPDOWN: Interface Async33, changed state to up Jul 25 13:21:35.859 UTC: Async33  
 DDR: Dialer statechange to up Jul 25 13:21:35.859 UTC: %DIALER-6-BIND: Interface As33 bound to  
 profile Dil Jul 25 13:21:35.859 UTC: Async33 DDR: Dialer call has been placed !--- PPP  
*negotiation begins* Jul 25 13:21:35.859 UTC: As33 PPP: Treating connection as a callout Jul 25  
 13:21:35.859 UTC: As33 PPP: Phase is ESTABLISHING, Active Open Jul 25 13:21:35.859 UTC: As33  
 PPP: No remote authentication for call-out !--- CHAP challenge is configured for callin only !--!  
*- LCP negotiation begins; Multilink parameters are also negotiated* Jul 25 13:21:35.863 UTC: As33  
 LCP: O CONFREQ [Closed] id 21 Len 43 Jul 25 13:21:35.863 UTC: As33 LCP: ACCM 0x000A0000  
 (0x0206000A0000) Jul 25 13:21:35.863 UTC: As33 LCP: MagicNumber 0x4395FC05(0x05064395FC05) Jul  
 25 13:21:35.863 UTC: As33 LCP: PFC (0x0702) Jul 25 13:21:35.863 UTC: As33 LCP: ACFC (0x0802) Jul

25 13:21:35.863 UTC: As33 LCP: MRRU 1524 (0x110405F4) !--- negotiate Maximum Receive Reconstructed Unit (MRRU) Jul 25 13:21:35.863 UTC: As33 LCP: EndpointDisc 1 Local Jul 25 13:21:35.863 UTC: As33 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:21:35.863 UTC: As33 LCP: (0x2D3031) Jul 25 13:21:37.859 UTC: As33 LCP: TIMEOUT: State REQsent Jul 25 13:21:37.859 UTC: As33 LCP: O CONFREQ [REQsent] id 22 Len 43 Jul 25 13:21:37.859 UTC: As33 LCP: ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:21:37.859 UTC: As33 LCP: MagicNumber 0x4395FC05 (0x05064395FC05) Jul 25 13:21:37.859 UTC: As33 LCP: PFC (0x0702) Jul 25 13:21:37.859 UTC: As33 LCP: ACFC (0x0802) Jul 25 13:21:37.859 UTC: As33 LCP: MRRU 1524 (0x110405F4) Jul 25 13:21:37.859 UTC: As33 LCP: EndpointDisc 1 Local Jul 25 13:21:37.859 UTC: As33 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:21:37.859 UTC: As33 LCP: (0x2D3031) Jul 25 13:21:39.859 UTC: As33 LCP: TIMEOUT: State REQsent Jul 25 13:21:39.859 UTC: As33 LCP: O CONFREQ [REQsent] id 23 Len 43 Jul 25 13:21:39.859 UTC: As33 LCP: ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:21:39.859 UTC: As33 LCP: MagicNumber 0x4395FC05 (0x05064395FC05) Jul 25 13:21:39.859 UTC: As33 LCP: PFC (0x0702) Jul 25 13:21:39.859 UTC: As33 LCP: ACFC (0x0802) Jul 25 13:21:39.859 UTC: As33 LCP: MRRU 1524 (0x110405F4) Jul 25 13:21:39.859 UTC: As33 LCP: EndpointDisc 1 Local Jul 25 13:21:39.859 UTC: As33 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:21:39.859 UTC: As33 LCP: (0x2D3031) Jul 25 13:21:40.199 UTC: As33 LCP: I CONFREQ [REQsent] id 6 Len 47 Jul 25 13:21:40.199 UTC: As33 LCP: ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:21:40.203 UTC: As33 LCP: AuthProto CHAP (0x0305C22305) Jul 25 13:21:40.203 UTC: As33 LCP: MagicNumber 0xE16E950F (0x0506E16E950F) Jul 25 13:21:40.203 UTC: As33 LCP: PFC (0x0702) Jul 25 13:21:40.203 UTC: As33 LCP: ACFC (0x0802) Jul 25 13:21:40.203 UTC: As33 LCP: EndpointDisc 1 Local Jul 25 13:21:40.203 UTC: As33 LCP: (0x131201626F62736C616B652D6E61732D) Jul 25 13:21:40.203 UTC: As33 LCP: (0x3031) Jul 25 13:21:40.203 UTC: As33 LCP: O CONFACK [REQsent] id 6 Len 47  
*PPP parameters are agreed on (CONFACKed) by both sides* Jul 25 13:21:40.203 UTC: As33 LCP: ---!  
 ACCM 0x000A0000 (0x0206000A0000) Jul 25 13:21:40.203 UTC: As33 LCP: AuthProto CHAP (0x0305C22305) Jul 25 13:21:40.203 UTC: As33 LCP: MagicNumber 0xE16E950F (0x0506E16E950F) Jul 25 13:21:40.203 UTC: As33 LCP: PFC (0x0702) Jul 25 13:21:40.203 UTC: As33 LCP: ACFC (0x0802) Jul 25 13:21:40.203 UTC: As33 LCP: MRRU 1524 (0x110405F4)  
*MRRU of 1524 bytes is accepted* Jul 25 13:21:40.203 UTC: As33 LCP: EndpointDisc 1 Local Jul ---!  
 25 13:21:40.203 UTC: As33 LCP: (0x131201626F62736C616B652D6E61732D) Jul 25 13:21:40.203 UTC: As33 LCP: (0x3031) Jul 25 13:21:40.207 UTC: As33 LCP: I CONFACK [ACKsent] id 23 Len 43  
*PPP parameters are agreed on (CONFACKed) by both sides* ---!  
 (Jul 25 13:21:40.207 UTC: As33 LCP: ACCM 0x000A0000 (0x0206000A0000)  
 (Jul 25 13:21:40.207 UTC: As33 LCP: MagicNumber 0x4395FC05 (0x05064395FC05)  
 (Jul 25 13:21:40.207 UTC: As33 LCP: PFC (0x0702)  
 (Jul 25 13:21:40.207 UTC: As33 LCP: ACFC (0x0802)  
 (Jul 25 13:21:40.207 UTC: As33 LCP: MRRU 1524 (0x110405F4)  
*MRRU of 1524 bytes is accepted* Jul 25 13:21:40.207 UTC: As33 LCP: EndpointDisc 1 Local Jul ---!  
 25 13:21:40.207 UTC: As33 LCP: (0x131301636C6561726C616B652D6C616E) Jul 25 13:21:40.207 UTC: As33 LCP: (0x2D3031) !--- LCP negotiation is complete Jul 25 13:21:40.207 UTC: As33 LCP: State is Open Jul 25 13:21:40.207 UTC: As33 PPP: Phase is AUTHENTICATING, by the peer !--- CHAP authentication begins Jul 25 13:21:40.419 UTC: As33 CHAP: I CHALLENGE id 3 Len 36 from "bobslake-nas-01" !--- Received challenge from bobslake-nas-01 Jul 25 13:21:40.423 UTC: As33 CHAP: O RESPONSE id 3 Len 37 from "clearlake-lan-01" Jul 25 13:21:42.528 UTC: As33 CHAP: I SUCCESS id 3 Len 4 !--- CHAP authentication is successful Jul 25 13:21:42.528 UTC: As33 PPP: Phase is VIRTUALIZED !--- Async 33 is added to Virtualized MP bundle Jul 25 13:21:42.528 UTC:  
**As33 MLP: bobslake-nas-01, multilink up**  
*Multilink connection is up* Jul 25 13:21:43.528 UTC: %LINEPROTO-5-UPDOWN: Line protocol on ---!  
 Interface Async33, changed state to up clearlake-lan-01# Jul 25 13:23:52.028 UTC: Vil MLP: Disabling particle-fastswitching in 'bobslake-nas-01' Jul 25 13:23:52.028 UTC: Vil MLP: Enabling particle-fastswitching on 'bobslake-nas-01' !--- Cisco IOS adjusting fast switching strategy to keep in step !--- with delivery of packet fragments Jul 25 13:23:53.872 UTC: Vil MLP: Disabling particle-fastswitching in 'bobslake-nas-01' Jul 25 13:23:53.884 UTC: Vil MLP: Enabling particle-fastswitching on 'bobslake-nas-01'

## معلومات ذات صلة

- **PPP متعدد الارتباطات ل DDR - التكون الأساسي والتحقق**
- **اتصال PPP متعدد الارتباطات غير المتزامن من عمالء Microsoft Windows**
- **PPP متعدد الارتباطات عبر واجهتين تسلسلتين من الطبقة المادة غير المتزامنة**
- **تكوين NAS للوصول الأساسي للطلب**

- [عرض إحصائيات المتصل](#)
- [تكوين واجهات الفواليب الظاهرة](#)
- [ميزات PPP للوصول الظاهري في Cisco IOS](#)
- [صفحات دعم PPP](#)
- [Cisco Systems - الدعم الفني](#)

## هـ لـ وـ لـ جـ رـ تـ لـ اـ هـ ذـ هـ

ةـ يـ لـ آـ لـ اـ تـ اـ يـ نـ قـ تـ لـ اـ نـ مـ مـ جـ مـ وـ عـ مـ اـ دـ خـ تـ سـ اـ بـ دـ نـ تـ سـ مـ لـ اـ اـ ذـ هـ تـ مـ جـ رـ تـ  
لـ اـ عـ لـ اـ ءـ اـ حـ نـ اـ عـ يـ مـ جـ يـ فـ نـ يـ مـ دـ خـ تـ سـ مـ لـ لـ مـ عـ دـ ئـ وـ تـ حـ مـ يـ دـ قـ تـ لـ ةـ يـ رـ شـ بـ لـ اـ وـ  
اـ مـ كـ ةـ قـ يـ قـ دـ نـ وـ كـ تـ نـ لـ ةـ يـ لـ آـ ةـ مـ جـ رـ تـ لـ ضـ فـ اـ نـ اـ ةـ ظـ حـ اـ لـ مـ ئـ جـ رـ يـ .ـ صـ اـ خـ لـ اـ مـ هـ تـ غـ لـ بـ  
يـ لـ خـ تـ .ـ فـ رـ تـ حـ مـ مـ جـ رـ تـ مـ اـ هـ دـ قـ يـ يـ تـ لـ اـ ةـ يـ فـ اـ رـ تـ حـ اـ لـ اـ ةـ مـ جـ رـ تـ لـ اـ عـ مـ لـ اـ حـ لـ اـ وـ  
ىـ لـ إـ أـ مـ ئـ اـ دـ عـ وـ جـ رـ لـ اـ بـ يـ صـ وـ تـ وـ تـ اـ مـ جـ رـ تـ لـ اـ هـ ذـ هـ ةـ قـ دـ نـ عـ اـ هـ تـ يـ لـ وـ ئـ سـ مـ  
(رـ فـ وـ تـ مـ طـ بـ اـ رـ لـ اـ)ـ يـ لـ صـ أـ لـ اـ يـ زـ يـ لـ جـ نـ إـ لـ اـ دـ نـ تـ سـ مـ لـ اـ).