

# RV110W ىلج WPS تادادعإ نىوكت

## فدهلا

فدهلا .ةنمآ ةيكلسال ةكبش ءاشنال ةعيرس ةقيرط (WPS) Wi-Fi Protected Setup دعى RV110W ىلج WPS تادادعإ نىوكت ةيفيك حرش وه ةلاقملا هذه نم

## قىبطلل ةلباقلا ةزهجالا

زارطلا RV110W

## ةيئارجا تاوطخ

WPS > ىكلسال رايئخال هجوملا نىوكتل ةدعاسملا ةادألا مدختسأ 1. ةوطخلا

### WPS

Wi-Fi Protected Setup™

SSID:

WPS:  Enable

Use one of the following for each Wi-Fi Protected Setup supported device:

1. If your client device has a Wi-Fi Protected Setup button, click or press that button and then click the button on the right.

OR

2. If your client device has a Wi-Fi protected Setup PIN number, enter that number here  and then click

OR

3. If your client asks for the Router's PIN number, enter this number **61443143** in your client device.

---

Wi-Fi Protected Setup Status: Unconfigured

Network Name (SSID): ciscosb1

Security: Disabled

Session Status: N/A

اهىلج WPS قىبطلل ةيكلسال ةكبش رتخأ، ةلدسنملا SSID ةمئاق نم 2. ةوطخلا

## WPS

### Wi-Fi Protected Setup™

SSID:

WPS:  Enable

Use one of the following for each Wi-Fi Protected Setup supported device:

1. If your client device has a Wi-Fi Protected Setup button, click or press that button and then click the button on the right.



OR

2. If your client device has a Wi-Fi protected Setup PIN number, enter that number here  and then click

OR

3. If your client asks for the Router's PIN number, enter this number **61443143** in your client device.

Wi-Fi Protected Setup Status:	Unconfigured
Network Name (SSID):	ciscosb1
Security:	Disabled
Session Status:	N/A

WPS تادادع| نيكمتلننيكمت رايتخالال ةناخ دح: WPS نيمي يلع 3. ةوطخال

ةكبشلا يلا ليمع زاهج ةفاضلا ةثالثلل تاراخال دح أذيفنتب مق 4. ةوطخال

## WPS



Configuration settings have been saved successfully

### Wi-Fi Protected Setup™

SSID:

WPS:  Enable

Use one of the following for each Wi-Fi Protected Setup supported device:

1. If your client device has a Wi-Fi Protected Setup button, click or press that button and then click the button on the right.



OR

2. If your client device has a Wi-Fi protected Setup PIN number, enter that number here  and then click

OR

3. If your client asks for the Router's PIN number, enter this number **61443143** in your client device.

Wi-Fi Protected Setup Status: Unconfigured

Network Name (SSID): ciscosb1

Security: Disabled

Session Status: N/A

WPS ةنوقيأ رقنا .رزلا طغضا ، WPS رز لي معلا يدل ناك اذا . 1. رايخلا .

## WPS



Configuration settings have been saved successfully

### Wi-Fi Protected Setup™

SSID:

WPS:  Enable

Use one of the following for each Wi-Fi Protected Setup supported device:

1. If your client device has a Wi-Fi Protected Setup button, click or press that button and then click the button on the right.



OR

2. If your client device has a Wi-Fi protected Setup PIN number, enter that number here  and then click

OR

3. If your client asks for the Router's PIN number, enter this number **61443143** in your client device.

Wi-Fi Protected Setup Status:	Unconfigured
Network Name (SSID):	ciscosb1
Security:	Disabled
Session Status:	N/A

لقح يف لقحلا يف PIN مقر لخدأف، WPS PIN مقر ليمعلا زاغ ىدل ناك اذا 2 رايخال:  
لجس ةقطقط "2 رايخال".

مقرلا ليمعلا لخددي. هجوملاب صاخلا PIN مقر ىلع لوصحلا ليمعلا بلطي 3 رايخال:  
ليمعلا زاغ يف 61443143.

ةمچرتل هذه ل و ح

ةلأل تاي نقتل ن م ة و مچ م ادخت ساب دن تسمل اذ ه Cisco ت مچرت  
ملاعلاء ن أ عي مچ ي ف ن ي م دخت سمل ل معد ي و تح م مي دقت ل ة ي رش ب ل و  
امك ة ق ي قد ن و ك ت ن ل ة ي ل أ ة مچرت ل ض ف أ ن أ ة ظ حال م ي ج ر ي . ة ص ا خ ل م ه ت غ ل ب  
Cisco ي ل خ ت . ف ر ت ح م مچرت م ا ه م د ق ي ي ت ل ا ة ي ف ا ر ت ح ا ل ا ة مچرت ل ا ع م ل ا ح ل ا و ه  
ي ل ا م ا د ع و ج ر ل ا ب ي ص و ت و ت ا مچرت ل ا ه ذ ه ة ق د ن ع ا ه ت ي ل و ئ س م Cisco  
Systems (رف و ت م ط بار ل ا) ي ل ص أ ل ا ي ز ي ل ج ن ا ل ا دن تسمل ا