

Adjust Volume Setting on SPA525G or SPA525G2

Objective

This shows how to adjust the volume setting for the incoming call ringer.

Applicable Devices

- SPA525G
- SPA525G2

Process

Ringer Volume Adjustments



Using the volume adjuster, scroll up and down to adjust the ringer volume to the desired volume.