

Subscriber Information on SPA100 Series Phone Adapter

Objective

The subscriber information is used in order to know who the users are on both ends of the line. By using this feature, communication between the two users becomes easier. This article explains how to configure the subscriber information on the SPA100 Series Analog Telephone Adapter.

Applicable Devices

- SPA112
- SPA122

Software Version

- 1.3.2 (014)

Subscriber Information Settings

Step 1. Log into the Phone Adapter Configuration Utility and choose **Voice > Line1** or **Line2**. The *Line 1* page opens:

The screenshot shows the 'Line 1' configuration page. The 'Subscriber Information' section is highlighted with a red box. The fields in this section are: Display Name, Password, Auth ID, User ID, Use Auth ID (set to 'no'), and Resident Online Number. Other sections include 'Call Feature Settings', 'Proxy and Registration', and 'Supplementary Service Subscription'.

Section	Field	Value
Call Feature Settings	Blind Attn-Xfer Enable:	no
	Xfer When Hangup Conf:	yes
	Conference Bridge Ports:	3
	Emergency Number:	
MOH Server:	MOH Server:	
	Conference Bridge URL:	
Enable IP Dialing:	Enable IP Dialing:	no
	Mailbox ID:	
Proxy and Registration	Proxy:	
	Outbound Proxy:	
	Use Outbound Proxy:	no
	Register:	yes
	Register Expires:	3600
	Use DNS SRV:	no
	Proxy Fallback Intvl:	3600
	Mailbox Subscribe URL:	
	Use OB Proxy In Dialog:	yes
	Make Call Without Reg:	no
Ans Call Without Reg:	no	
DNS SRV Auto Prefix:	no	
Proxy Redundancy Method:	Normal	
Mailbox Subscribe Expires:	2147483647	
Subscriber Information	Display Name:	
	Password:	
	Auth ID:	
User ID:	User ID:	
	Use Auth ID:	no
Resident Online Number:	Resident Online Number:	
Supplementary Service Subscription	Call Waiting Serv:	yes
	Block CID Serv:	yes

Note: The configuration of the subscriber information made on Line 1 are applicable to Line 2.

Subscriber Information			
Display Name:	<input type="text" value="User"/>	User ID:	<input type="text" value="12"/>
Password:	<input type="text" value="Pass1"/>	Use Auth ID:	<input type="text" value="yes"/>
Auth ID:	<input type="text" value="user1"/>	Resident Online Number:	<input type="text" value="555-0100"/>

Step 2. Enter the name of the Caller ID in the Display Name field.

Step 3. Enter the user ID in the User ID field .

Step 4. Enter the password in the Password field.

Step 5. (Optional) Choose **Yes** in the Use Auth ID drop-down list to enter the authentication ID and password for SIP authentication. Otherwise, choose **No** to use the user ID and password.

Note: If you choose No, skip to Step 7.

Step 6. Enter the authentication ID for SIP authentication in the Auth ID field.

Step 7. Enter a valid Skype Online Number in the Resident Online Number field so calls made to the Skype number will ring your phone.

Step 8. Click **Submit** if the required recommended settings have been done or click **Refresh** to see the new required information.