



Upgrading the Cisco cBR Series Converged Broadband Routers for Cisco IOS XE Dublin 17.15

First Published: 2024-10-31

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2024 Cisco Systems, Inc. All rights reserved.



CHAPTER 1

Upgrading the Cisco cBR-8 Router System to Cisco IOS XE Dublin 17.15.1w



Note Starting from Cisco IOS XE Bengaluru 17.6.1a, CBR-CCAP-LC-G2-R can only protect CBR-CCAP-LC-G2-R for linecard HA.



Note If you are using TACACS authentication, the TACACS configuration is automatically updated to the new version after upgrading to Cisco IOS XE Dublin 17.15.1w. This is a fix to [CSCvu62273](#) and you do not need to take any action regarding the TACACS configuration in the cBR-8 prior to the upgrade.

This section contains the upgrade procedures for the Cisco cBR-8 Router System.

By default, telnet is disabled on Cisco cBR-8. If you are going to use telnet to access the device, make sure the value of line **vtty transport** is correct and save the configuration in order to enable telnet.

```
Router# show run | begin line vty
line vty 0 4
  exec-timeout 0 0
  privilege level 15
  password 7 104D081B094410055F
  exec prompt timestamp
  transport input all
line vty 5 98
  exec-timeout 0 0
  privilege level 15
  password 7 02050D480809
  transport input all
line vty 99
  transport input all
!
```

The following table encompasses all versions are required to update to support Cisco IOS XE Dublin 17.15.1w. All other firmware versions are either not upgradable by the customer, or not required to be upgraded for Cisco IOS XE Dublin 17.15.1w support. Use the commands in the tables to verify the firmware versions. If you need to upgrade firmware first, refer to the steps in [Upgrading the Cisco cBR-8 Router Firmware](#).



Note If you want to upgrade Supervisor CPLD firmware, refer to [Upgrading Supervisor CPLD Firmware, on page 10](#).

Table 1: Firmware Versions

Internal Name	Component Name	Required Minimum Version	Command
Supervisor CPLD	CBR-CCAP-SUP-160G CPLD	16052011/19071712	show platform
	CBR-CCAP-SUP-250G CPLD	170724E0/190717E1	show platform
Supervisor ROMMON	CBR-CCAP-SUP-160G ROMMON and CBR-CCAP-SUP-250G ROMMON	16.7(9r)S	show platform
Line Card CPLD	CBR-CCAP-LC-40G CPLD	00000026	show platform diag
Docsis 3.1 downstream module Micro	CBR-CCAP-LC-40G Gemini2 Micro	3.1A	show platform diag
Docsis 3.1 downstream module FPGA	CBR-CCAP-LC-40G Gemini2 Apollo	4.484F	show platform diag
DPIC Uboot and FPGA	CBR-DPIC-8X10G Firmware	00010001	show platform diag
DPIC 100G Uboot and FPGA	CBR-DPIC-2X100G Firmware	00020006	show platform diag



Note If the user wants to upgrade Supervisor CPLD to version 19071712 and 190717E1, the chassis must be running with Cisco IOS XE Gibraltar 16.12.1w or later releases.



Note Cisco recommends that operators upgrade their On-Premise SSM Satellite software versions to v7.x or later releases, to ensure the compatibility with cBR-8.

- [Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Dublin 17.15.1w, on page 3](#)
- [Upgrading Supervisor CPLD Firmware, on page 10](#)
- [Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card, on page 15](#)

- [Upgrading Uboot For CBR-CCAP-LC-40G](#), on page 18
- [Manual ROMMON Upgrade](#), on page 19
- [Downstream-Controller Remapping \(CBR-CCAP-LC-G2-R with 8x10G DPIC\)](#), on page 20

Upgrading from Cisco IOS XE 16.x and later releases to Cisco IOS XE Dublin 17.15.1w

Prerequisites and Considerations

Manual ROMMON Upgrade

If you are upgrading from Cisco IOS XE Everest 16.8.1 or later, manual ROMMON upgrade is not required.

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Cupertino 17.15.1w, manual ROMMON upgrade is necessary. Refer to the Section [Manual ROMMON Upgrade](#), on page 19 for instructions.

Downstream-Controller Remapping (CBR-CCAP-LC-G2-R with 8x10G DPIC)

Starting with Cisco IOS XE Bengaluru 17.6.1, Cisco introduced a new feature on cBR-8 that provides initial support for 32 Video and 32 DOCSIS service groups per CBR-CCAP-LC-G2-R linecard. However, there are specific configuration considerations when using 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards.

If you are upgrading from Cisco IOS XE Amsterdam 17.3.1 or earlier, and you are using 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, see the section entitled [Downstream-Controller Remapping \(CBR-CCAP-LC-G2-R with 8x10G DPIC\)](#) below. Further, it is recommended that you contact your local Cisco representative for assistance before upgrading to Cisco IOS XE Cupertino 17.15.1w.

Upgrading using reload

Before you begin



Note If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Dublin 17.15.1w, perform [Manual ROMMON Upgrade](#) to upgrade SUP ROMMON manually before proceeding with IOS upgrading.

Upgrading from 17.6.1y or Earlier Images

If upgrading from 17.6.1y or earlier, you must copy .pkg files individually to the cBR-8. The tarball below contains all 20 packages and the packages.conf file that are required for upgrading. Before upgrading the system, make sure the following requirements are met:

- Download the 17.15.1w tarball file from [Cisco.com](https://software.cisco.com) Software Center to a local server, using the following URL: <https://software.cisco.com/download/home/286283913/type>

- IOS XE Software Version 17.15.01w: `cbrsup-universalk9.17.15.01w.SPA.pkgs.tar`.
- Untar the archive on the local server.

Procedure

Step 1 Create a new folder on the cBR-8: **harddisk:XE-1715-1w**.

```
mkdir harddisk:XE-1715-1w
```

Step 2 Create a new folder on the cBR-8: **stby-harddisk:XE-1715-1w**.

```
mkdir stby-harddisk:XE-1715-1w
```

Step 3 Copy the `.pkg` files and `packages.conf` individually to the cBR-8 from the local server.

```
copy <location>/cbrsup-cciomdsup.17.15.01w.SPA.pkg harddisk:/
XE-1715-1w/cbrsup-cciomdsup.17.15.01w.SPA.pkg
```

Repeat for all `.pkg` files and `packages.conf`. There should be 21 files in total.

Step 4 Copy the `.pkg` files and `packages.conf` individually from `harddisk` to `stby-harddisk`:

```
copy harddisk:/XE-1715-1w/cbrsup-cciomdsup.17.15.01w.SPA.pkg
stby-harddisk:/XE-1715-1w/cbrsup-cciomdsup.17.15.01w.SPA.pkg
```

Repeat for all `.pkg` files and `packages.conf`. There should be 21 files in total.

Step 5 Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:/XE-1715-1w/cbrsup-programmable_firmware.17.15.01w.SPA.pkg
```

Step 6 Configure the system to boot in sub-package mode.

```
conf t
no boot system
boot system harddisk:/XE-1715-1w/packages.conf
end
```

Step 7 Save the configuration

```
wr mem
```

Step 8 Reload the system

```
reload
```

Upgrading from 17.6.1z or Later Images

Before upgrading the system, make sure the following requirements are met.

- Download two files from the following Cisco.com Software Center URL.

<https://software.cisco.com/download/home/286283913/type>

- IOS XE Software Version 17.15.01w: **cbrsup-universalk9.17.15.01w.SPA.bin**

- IOS XE Hardware Programmable Devices Version 17.15.1w.
cbrsup-programmable_firmware.17.15.01w.SPA.pkg

Procedure

-
- Step 1** **Note** **Note** Ensure that you have Cisco IOS XE Bengaluru 17.6.1z or later installed before proceeding
- Copy the Cisco IOS XE Dublin 17.15.1w IOS image to harddisk: and stby-harddisk:
- ```
copy <location>/cbrsup-universalk9.17.15.01w.SPA.bin harddisk:
copy <location>/cbrsup-universalk9.17.15.01w.SPA.bin stby-harddisk:
```
- Step 2**     Verify the Cisco IOS XE Dublin 17.15.1w IOS image against the md5 hash as provided in the Cisco.com Software center. The md5 hash check may not support images greater than 2 GB in size.
- ```
verify /md5 harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
verify /md5 stby-harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
```
- Step 3** Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.
- ```
copy <location>/cbrsup-programmable_firmware.17.15.01w.SPA.pkg harddisk:
```
- Step 4**     Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.
- ```
verify /md5 harddisk:cbrsup-programmable_firmware.17.15.01w.SPA.pkg
```
- Step 5** Configure the system to boot with the Cisco IOS XE Dublin 17.15.1w image.
- ```
configure terminal
no boot system
boot system harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
end
```
- Step 6**     Save the configuration.
- ```
wr mem
```
- Step 7** Reload the system
- ```
reload
```
- 

### What to do next

Perform verification test to determine if the upgrade is successful, include.

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using **show facility-alarm status** command.
- Check the status of the power supplies using **show environment power** command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.

- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using **show log** command.

These **show** commands may be useful in the verification test.

- **show redundancy**
- **show platform**
- **show platform diag**
- **show environment**
- **show redundancy linecard all**
- **show isis neighbors**
- **show ip ospf neighbor**
- **show ip route rip**
- **show ip mroute**
- **show cops servers**
- **show cable modem voice**
- **show cable calls**
- **show cable metering verbose**
- **show cable licenses all**
- **show inventory**

## Upgrading with ISSU for I-CCAP Systems

### Before you begin



#### Note

- ISSU is not supported for Remote PHY systems.
- If you are upgrading from 17.6.1z1 to 17.15.1w with netconf enabled, the netconf-yang may not work after the upgrade. To resolve this, you need to re-configure the netconf-yang as below:

```
CBR8(config)#netconf-yang ssh server algorithm hostkey ssh-rsa
CBR8(config)#no netconf-yang
CBR8(config)#netconf-yang
CBR8(config)#end
```

- ISSU to Cisco IOS XE Dublin 17.15.1w is supported only from Cisco IOS XE Bengaluru 17.6.1z1 and later releases. If you are upgrading from Cisco IOS XE 17.6.1z or an earlier release, you must upgrade the cBR-8 system following the steps in [Upgrading using reload, on page 3](#).



Before upgrading the system, make sure the following requirements are met:

- The cBR-8 has two SUPs installed.

```
Router# show redundancy | include Location|state
 Active Location = slot 4
 Current Software state = ACTIVE
 Uptime in current state = 2 days, 21 hours, 37 minutes
 Standby Location = slot 5
 Current Software state = STANDBY HOT
 Uptime in current state = 2 days, 21 hours, 30 minutes
```

- Standby SUP must be in hot standby state.

```
Router# show redundancy | include Location|state
 Active Location = slot 4
 Current Software state = ACTIVE
 Uptime in current state = 2 days, 21 hours, 37 minutes
 Standby Location = slot 5
 Current Software state = STANDBY HOT
 Uptime in current state = 2 days, 21 hours, 30 minutes
```

- Line card redundancy is in stable state with state Active and Stdby warm.

```
Router# show redundancy linecard all
Load for five secs: 14%/1%; one minute: 8%; five minutes: 8%
Time source is NTP, 15:23:26.697 PST Thu Jan 17 2019
```

| Slot | Subslot | LC Group | My State | Peer State | Peer Slot | Peer Subslot | Role    | Mode      |
|------|---------|----------|----------|------------|-----------|--------------|---------|-----------|
| 1    | -       | 0        | Active   | Stdby Warm | 0         | -            | Active  | Primary   |
| 2    | -       | 0        | Active   | Stdby Warm | 0         | -            | Active  | Primary   |
| 3    | -       | 0        | Active   | Stdby Warm | 0         | -            | Active  | Primary   |
| 6    | -       | 0        | Active   | Stdby Warm | 0         | -            | Active  | Primary   |
| 0    | -       | 0        | -        | -          | Multiple  | None         | Standby | Secondary |

- Auto-boot is enabled.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019
```

```
BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
BOOTLDR variable does not exist
Configuration register is 0x2102
```

```
Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102
```

- Both SUPs are in the sub-package mode, running the same image from the same path.

```
Router# show bootvar
Load for five secs: 14%/0%; one minute: 14%; five minutes: 10%
Time source is NTP, 15:46:59.837 PST Thu Jan 17 2019
```

```
BOOT variable = harddisk:IOSXE/packages.conf,12;
CONFIG_FILE variable =
```

```

BOOTLDR variable does not exist
Configuration register is 0x2102

Standby BOOT variable = harddisk:IOSXE/packages.conf,12;
Standby CONFIG_FILE variable =
Standby BOOTLDR variable does not exist
Standby Configuration register is 0x2102

```

- The free space on boot device on both SUPs must be greater than 2.3GB.

```

Router# dir harddisk: | include bytes total

7804653568 bytes total (5691174912 bytes free)

```

- Download two files from the following Cisco.com Software Center URL:

<https://software.cisco.com/download/home/286283913/type>

- IOS XE Software Version 17.15.1w: **cbrsup-universalk9.17.15.01w.SPA.bin**
- IOS XE Hardware Programmable Devices Version 17.15.1w: **cbrsup-programmable\_firmware.17.15.01w.SPA.pkg**
- Copy the target consolidated image **cbrsup-universalk9.17.15.01w.SPA.bin** to the active SUP in the same directory of the **packages.conf** file that the system is booted up with.

## SUMMARY STEPS

1. Copy Cisco IOS XE Dublin 17.15.1w image to harddisk:.
2. Verify Cisco IOS XE Dublin 17.15.1w image against the md5 hash as provided in the Cisco.com Software center.
3. Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.
4. Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.
5. Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.
6. Perform ISSU.
7. To monitor the ISSU progress, use the command below.
8. Use these CLI to check status after ISSU.

## DETAILED STEPS

### Procedure

---

**Step 1** Copy Cisco IOS XE Dublin 17.15.1w image to harddisk:.

```
copy <location>/cbrsup-universalk9.17.15.01w.SPA.bin harddisk:<sub-pkg-dir>/
```

**Step 2** Verify Cisco IOS XE Dublin 17.15.1w image against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:<sub-pkg-dir>/cbrsup-universalk9.17.15.01w.SPA.bin
```

**Step 3** Copy the hardware programmable devices upgrade package to harddisk: if the file has not been copied already.

```
copy <location>/cbrsup-programmable_firmware.17.15.01w.SPA.pkg harddisk:
```

**Step 4** Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable_firmware.17.15.01w.SPA.pkg
```

**Step 5** Check system status prior to upgrade. Save the information to compare against the system status after upgrade. For the commands to use to check the status, see the **show** commands at the end of this section.

**Step 6** Perform ISSU.

```
request platform software package install node file harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
```

**Step 7** To monitor the ISSU progress, use the command below.

```
request platform software package install node attach
```

**Step 8** Use these CLI to check status after ISSU.

```
show version
show version r0 running
show version r1 running
show version r0 provisioned
show version r1 provisioned
```

---

### What to do next

Perform verification test to determine if the upgrade is successful, include:

- Verify the router is running the new IOS-XE release using **show version** command.
- Check facility alarms using **show facility-alarm status** command.
- Check the status of the power supplies using **show environment power** command.
- Check PS status using **show platform hardware slot P<0-5> mcu status** command.
- Complete trace routes to known good off-network IP address using the source address of customer CPE blocks to verify routing is working.
- Check logs for error messages using **show log** command.

These **show** commands may be useful in the verification test:

- **show redundancy**
- **show platform**

- **show platform diag**
- **show environment**
- **show redundancy linecard all**
- **show isis neighbors**
- **show ip ospf neighbor**
- **show ip route rip**
- **show ip mroute**
- **show cops servers**
- **show cable modem voice**
- **show cable calls**
- **show cable metering verbose**
- **show cable licenses all**
- **show inventory**

## Upgrading Supervisor CPLD Firmware

### Before you begin




---

**Note** If the supervisor SO CPLD version is lower than 1511\_1401 (SUP 160) or 15111401 (SUP 250), or, if the supervisor SIO CPLD version is lower than 1511\_1301 (SUP 160) or 15111301 (SUP 250), physically power cycle the chassis when upgrading the supervisor CPLD.

---

Before upgrading the firmware, make sure the following requirements are met:

- Cisco cBR-8 router is running with Cisco IOS XE Gibraltar 16.12.1w or later releases.
- 2 supervisors are running in the Cisco cBR-8 router and the redundancy is enabled.
- Download the file from the following Cisco.com Software Center URL:  
<https://software.cisco.com/download/home/286283913/type>
  - IOS XE Hardware Programmable Devices Version 17.15.01w:  
**cbrsup-programmable\_firmware.17.15.01w.SPA.pkg**
- Console access for both supervisors are required.
- Copy the new firmware package to the cBR-8 using FTP.

```
copy ftp://<location>/cbrsup-programmable_firmware.17.15.01w.SPA.pkg harddisk:
copy ftp://<location>/cbrsup-programmable_firmware.17.15.01w.SPA.pkg stby-harddisk:
```



---

**Note** When upgrading SUP0, run the CLI with the R0 setting while controlling SUP0. And when upgrading SUP1, run the CLI with the R1 setting.

---



---

**Note** This guide assumes SUP0 is in active state and SUP1 is in standby hot state at the beginning.

---

Perform step 1 to 4 using console connection of active SUP0:

## SUMMARY STEPS

1. Set the config register.
2. Run the following command to prepare for R0 upgrade.
3. Run the following command to prepare for R1 upgrade.
4. If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.
5. Set SUP0 to ROMMON using the following command.
6. Power cycle the SUP0 to set it to ROMMON.
7. Boot SUP0 into IOS XE using SUP0 console connection.
8. Set SUP1 to ROMMON using the following command.
9. Power cycle the SUP1 to set it to ROMMON.
10. Boot SUP1 into IOS XE using SUP1 console connection.
11. Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.
12. Reload the system by issuing **reload** command on the active SUP.
13. Power cycle both supervisors.
14. Verify if the new version matches the following on both SUPs.
15. Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.
16. Once the system is up and running, perform the following checks.

## DETAILED STEPS

### Procedure

---

**Step 1** Set the config register.

```
configure terminal
config-register 0x2102
end
write memory
```

**Step 2** Run the following command to prepare for R0 upgrade.

```
upgrade hw-programmable cable R0 viper pkg_name
/harddisk/cbrsup-programmable_firmware.17.15.01w.SPA.pkg
```

On SUP 250, you will see one of the following outputs:

- It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.  
You are upgrading Viper firmware using harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg image on SUP0, SUP0 is active.  
Upgrade from assigned pkg file harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg  
Using viper firmware /tmp/viper/mount/supve\_viper\_fpga\_psirt.bin  
Size of Viper Upgrade image: 16777216 bytes  
No.of parts: 65536  
Upgrading golden image...  
65536+0 records in  
65536+0 records out  
16777216 bytes (17 MB, 16 MiB) copied, 688.873 s, 24.4 kB/s  
Upgrading primary image...  
65536+0 records in  
65536+0 records out  
16777216 bytes (17 MB, 16 MiB) copied, 675.19 s, 24.8 kB/s  
Viper upgrade clean up 0  
Upgrade successfully. Please make sure Rommon version is matched.  
Please power cycle the chassis to let the new firmware take effect

- It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.  
You are upgrading Viper firmware using harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg image on SUP0, SUP0 is active.  
Upgrade from assigned pkg file harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg  
The golden viper is not compatible with assigned firmware  
/tmp/viper/mount/supve\_viper\_fpga\_psirt.bin, no upgrade will be performed  
Viper upgrade clean up 2

**Note** This output means the SUP already has the latest version it can support, skip the rest of the steps.

On SUP 160, you will see one of the following outputs:

- It takes about 10 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.  
You are upgrading Viper firmware using harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg image  
Upgrade from assigned pkg file /harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg  
Using viper firmware /tmp/viper/mount/viper\_fpga.bin  
Size of Viper Upgrade image: 16777216 bytes  
No.of parts: 65536  
65536+0 records in  
65536+0 records out  
Viper upgrade clean up 0  
Upgrade successfully. Please make sure Rommon version is matched.  
Please power cycle the chassis to let the new firmware take effect

- It takes 10~20 minutes to upgrade. Console would hung. Please don't do any operation during the upgrade.  
You are upgrading Viper firmware using harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg image on SUP0, SUP0 is active.  
Upgrade from assigned pkg file harddisk/cbrsup-programmable\_firmware.17.15.01w.SPA.pkg  
The golden viper is not compatible with assigned firmware  
/tmp/viper/mount/supve\_viper\_fpga\_psirt.bin, no upgrade will be performed  
Viper upgrade clean up 2

**Note** This output means the SUP already has the latest version it can support, skip the rest of the steps.

**Note** Do not power cycle the chassis in this step.

**Step 3** Run the following command to prepare for R1 upgrade.

```
upgrade hw-programmable cable R1 viper pkg_name
/harddisk/cbrsup-programmable_firmware.17.15.01w.SPA.pkg
```

You will see the similar output as the one in Step 2.

**Note** Do not power cycle the chassis in this step.

**Step 4** If the supervisor ViperSO CPLD version is 15111401 and the supervisor ViperSIO CPLD version is 15111301 on both supervisors, follow step 5 - 11 to do the upgrade. Otherwise proceed to step 12.

```
Router#show platform diag
Load for five secs: 6%/1%; one minute: 7%; five minutes: 8%
Time source is NTP, 16:05:43.546 PST Thu Feb 8 2018
Chassis type: CBR-8-CCAP-CHASS
<SNIP>
Slot: SUP0, CBR-CCAP-SUP-160G
 Physical insert detect time : 00:01:58 (1d03h ago)
 CPLD version : 16052011
 ViperSO CPLD version : 15111401
 ViperSIO CPLD version : 15111301
 Rommon version : 16.7(1r)S
 Blackbird version : 00000112
 Raptor ESI version : 0001003b
 Raptor MAC version : 00010031
 SUP-PIC CPLD version : 14071504
 SUP-DC CPLD version : 14072207
 DTI Client FPGA version : 00000005
 DTI Firmware version : 00000A03
 Cortina PHY version : 201402061607
 SUP PSOC 0 version : v4.0.9
 SUP PSOC 1 version : v4.0.8
 SUP PSOC 2 version : v4.1.0_IVB
 SUP PSOC 3 version : v4.0.6
 SUP-DC PSOC 0 version : v4.0.8
 SUP-DC PSOC 1 version : v4.0.5
 SUP-PIC PSOC 0 version : V2.0.6
 SUP-PIC PSOC 1 version : V2.0.6
<SNIP>
Slot: SUP1, CBR-CCAP-SUP-160G
 Physical insert detect time : 00:02:26 (1d03h ago)
 CPLD version : 16052011
 ViperSO CPLD version : 15111401
 ViperSIO CPLD version : 15111301
 Rommon version : 16.7(1r)S
 Blackbird version : 00000112
 Raptor ESI version : 0001003b
 Raptor MAC version : 00010031
 SUP-PIC CPLD version : 14071504
 SUP-DC CPLD version : 14072207
 DTI Client FPGA version : 00000005
 DTI Firmware version : 00000A03
 Cortina PHY version : 201402061607
 SUP PSOC 0 version : v4.0.9
 SUP PSOC 1 version : v4.0.8
 SUP PSOC 2 version : v4.1.0_IVB
 SUP PSOC 3 version : v4.0.6
```

```

SUP-DC PSOC 0 version : v4.0.9
SUP-DC PSOC 1 version : v4.0.5
SUP-PIC PSOC 0 version : V3.0.0
SUP-PIC PSOC 1 version : V3.0.0
<SNIP>

```

**Step 5** Set SUP0 to ROMMON using the following command.

```
redundancy force-switchover
```

Perform the following steps 6 to 7 using console connection of current active SUP1.

**Step 6** Power cycle the SUP0 to set it to ROMMON.

```
test platform hardware slot R0 oir power-cycle
```

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712

SUP 250 new version: 0x190717E1

**Step 7** Boot SUP0 into IOS XE using SUP0 console connection.

```
dir harddisk:
boot harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
```

Wait until SUP0 is in standby hot.

**Step 8** Set SUP1 to ROMMON using the following command.

```
redundancy force-switchover
```

Perform the following steps 9 to 11 using console connection of current active SUP0.

**Step 9** Power cycle the SUP1 to set it to ROMMON.

```
test platform hardware slot R1 oir power-cycle
```

This command will reset and re-initialize the ROMMON. The new version of the supervisor CPLD will now take effect. Verify if it matches the following new version.

SUP 160 new version: 0x19071712

SUP 250 new version: 0x190717E1

**Step 10** Boot SUP1 into IOS XE using SUP1 console connection.

```
dir harddisk:
boot harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
```

Wait until SUP1 is in standby hot.

**Step 11** Wait for the chassis to become SSO and settled down. Then go to step 16. If you skipped step 5 to 10, perform step 12 to 15.

**Note** You need physical access to the chassis to power cycle the chassis.



**Step 12** Reload the system by issuing **reload** command on the active SUP.

```
Router#reload
```

**Step 13** Power cycle both supervisors.

**Step 14** Verify if the new version matches the following on both SUPs.

```
SUP 160 new version: 0x19071712
```

```
SUP 250 new version: 0x190717E1
```

**Step 15** Boot both SUP0 and SUP1 into IOS XE using SUP0 and SUP1 console.

```
dir harddisk:
boot harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
```

Wait till SUP0 become standby hot.

**Step 16** Once the system is up and running, perform the following checks.

- Set config register to normal boot.

```
configure terminal
config-register 0x2102
end
write memory
```

- Execute **show redundancy** command to ensure both SUPs are listed, one is active and the other is standby hot.
- Execute **show proc CPU sorted | ex 0.00** command.
- Execute **show platform diag** command.

---

## Upgrading cBR CCAP 8x10G Remote PHY Digital Physical Interface Card

### Before you begin

Before upgrading the system, make sure the following requirements are met:

- Make sure the latest available IOS XE version is active in Cisco cBR-8 router.
- There are at least 20MB free space on the harddisk.



---

**Note** To make use of the new features, it is recommended to upgrade the cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) to the latest version 1.1.

---

**Procedure**

**Step 1** Boot up system, wait until IOS is ready.

**Step 2** Check current D-PIC version.

```
show hw-module subslot x/1 fpd
```

**Note** x/1 is D-PIC subslot number which needs upgrade.

**Example:**

```
Router#show hw-module subslot 9/1 fpd
```

```
====
Slot Card Type H/W Field Programmable Current Min. Required
Ver. Device: "ID-Name" Version Version
====
 9/1 CBR-DPIC-8X10G 1.0 46-CBR DIGI PIC 1.0 1.0
====
```

**Step 3** Upgrade D-PIC.

```
upgrade hw-module subslot x/1 fpd bundled reload
```

**Example:**

```
Router#upgrade hw-module subslot 9/1 fpd bundled reload
```

```
% The following FPD will be upgraded for CBR-DPIC-8X10G (H/W ver = 1.0) in subslot 9/1:
```

```
====
Field Programmable Current Upgrade Estimated
Device: "ID-Name" Version Version Upgrade Time
====
46-CBR DIGI PIC 1.0 1.1 00:05:00
====
```

```
% NOTES:
```

- Use 'show upgrade fpd progress' command to view the progress of the FPD upgrade.
- The target card will be automatically reloaded after the upgrade operation. This reload will interrupt normal operation of the card. If necessary, ensure that appropriate actions have been taken to redirect card traffic before starting the FPD upgrade.

```
% Are you sure that you want to perform this operation? [no]: yes
```

```
% Initiating the upgrade operation on the target card ...
```

```
(Use "show upgrade fpd progress" command to see upgrade progress)
```

**Step 4** Check if the upgrade process is finished. Upgrade progress will take about 1 to 2 minutes.

```
show upgrade fpd progress
```

**Example:**

Upgrade still ongoing:

Router#show upgrade fpd progress

FPD Image Upgrade Progress Table:

```

=====
Slot Card Type Field Programmable Approx.
 Device : "ID-Name" Time Elapsed
 Needed Time State
=====
 9/1 CBR-DPIC-8X10G 46-CBR DIGI PIC 00:05:00 00:00:13 Updating...
=====

```

Router# show upgrade fpd progress

FPD Image Upgrade Progress Table:

```

=====
Slot Card Type Field Programmable Approx.
 Device : "ID-Name" Time Elapsed
 Needed Time State
=====
 9/1 CBR-DPIC-8X10G 46-CBR DIGI PIC 00:05:00 00:00:26 Updating...
=====

```

Upgrade finished:

Router#show upgrade fpd progress

% There is no FPD image upgrade in progress.

**Step 5**

Check if the D-PIC status is ready.

show platform

**Example:**

```

Router#show platform
Chassis type: CBR-8-CCAP-CHASS

```

```

Slot Type State Insert time (ago)

2/1 CBR-RF-PROT-PIC ok 00:08:48
3 CBR-CCAP-LC-40G ok 00:12:46
3/1 CBR-RF-PIC ok 00:08:48
8/1 CBR-DPIC-8X10G ok 00:07:56
9 CBR-CCAP-LC-40G ok 00:12:46
9/1 CBR-DPIC-8X10G ok 00:07:54
SUP0 CBR-CCAP-SUP-160G inserted 00:12:46
R0 ok, active
F0 ok, active
4 ok, active
4/1 CBR-SUP-8X10G-PIC ok 00:07:55
SUP1 CBR-CCAP-SUP-160G inserted 00:12:22
R1 ok, standby
F1 ok, standby
5 ok, standby
5/1 CBR-SUP-8X10G-PIC ok 00:07:54
P0 PWR-3KW-AC-V2 ok 00:09:49
P1 PWR-3KW-AC-V2 ok 00:09:49
P2 PWR-3KW-AC-V2 ps, fail 00:09:49
P3 Unknown N/A never
P4 Unknown N/A never

```

```

P5 PWR-3KW-AC-V2 ok 00:09:49
P10 CBR-FAN-ASSEMBLY ok 00:09:39
P11 CBR-FAN-ASSEMBLY ok 00:09:39
P12 CBR-FAN-ASSEMBLY ok 00:09:39
P13 CBR-FAN-ASSEMBLY ok 00:09:39
P14 CBR-FAN-ASSEMBLY ok 00:09:39

```

```

Slot CPLD Version Rommon Version

3 00000025 2011.03.18
9 00000025 2011.03.18
SUP0 16052011 16.7(3r)S
SUP1 16052011 16.7(3r)S

```

**Step 6** Check if the new version works.

```
show hw-module subslot x/1 fpd
```

**Example:**

```
Router#show hw-module subslot 9/1 fpd
```

```

=====
Slot Card Type H/W Field Programmable Current Min. Required
Ver. Device: "ID-Name" Version Version Version
=====
 9/1 CBR-DPIC-8X10G 1.0 46-CBR DIGI PIC 1.1 1.0
=====

```

## Upgrading Uboot For CBR-CCAP-LC-40G

### Procedure

**Step 1** Copy the package file (cbrsup-programmable\_firmware.17.15.1w.SSA.pkg) to the active SUP's harddisk.

```
copy <location>/cbrsup-programmable_firmware.17.15.01w.SPA.pkg harddisk:
```

**Step 2** Upgrade Uboot using the following CLI command:

```
upgrade hw-programmable cable <slot#> rommon pkg_name
harddisk/cbrsup-programmable_firmware.17.15.01w.SSA.pkg
```

**Example:**

```

Router#upgrade hw-programmable cable <slot#> rommon pkg_name
harddisk/cbrsup-programmable_firmware.17.15.01w.SSA.pkg
UBOOT:
 FILE : /tmp/fpd/mount/uboot.bin.SPA
 VERSION : U-Boot 2011.03.19
 BYTES : 1441792
 Upgrade Field Region: SUCCESS! Please reload the card to let the new firmware take effect.

```

**Step 3** Reload Line Card using the following CLI command:

```
Router#hw-module slot <slot#> reload
```

**Step 4** Check the Uboot version after LC boot up using the following CLI command:

```
show platform diag
```

**Example:**

```
Router# show platform diag
...
Slot: 1, CBR-CCAP-LC-40G
 Running state : ok
 Internal state : online
 Internal operational state : ok
 Physical insert detect time : 00:03:11 (5d11h ago)
 Software declared up time : 00:07:46 (5d11h ago)
 CPLD version : 00000025
 Rommon version : 2011.03.19
 Basestar version : 00200057
 Raider version : 02010019
 dsphy0_fpga version : 4.484B
 dsphy0_micro version : 3.1A
 dsphy0_psoc version : 4.4
 dsphy0_cpld version : 0.7
 dsphyl_fpga version : 4.484B
 dsphyl_micro version : 3.1A
 dsphyl_psoc version : 4.4
 dsphyl_cpld version : 0.7
 Caprica version : 0002000a
 HA-PLL version : N/A
 PSOC 0 version : v4.6
 PSOC 1 version : v4.6
...
```

## Manual ROMMON Upgrade

### Before you begin

If you are upgrading from Cisco IOS XE Everest 16.6.x or Cisco IOS XE Fuji 16.7.x to Cisco IOS XE Dublin 17.15.1w, perform the following steps to upgrade SUP ROMMON manually.

### Procedure

**Step 1** Download hardware programmable devices upgrade package file **cbrsup-programmable\_firmware.17.15.01w.SPA.pkg** from the following Cisco.com Software Center URL: <https://software.cisco.com/download/home/286283913/type>

**Step 2** Verify the hardware programmable devices upgrade package against the md5 hash as provided in the Cisco.com Software center.

```
verify /md5 harddisk:cbrsup-programmable_firmware.17.15.01w.SPA.pkg
```

**Step 3** Upgrade SUP ROMMON.

```
Router#upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.15.01w.SPA.pkg r0
Wait for the following output on the console:
ROMMON upgrade complete.
To make the new ROMMON permanent, you must restart the RP
```

```
Router#upgrade rom-mon file harddisk:cbrsup-programmable_firmware.17.15.01w.SPA.pkg r1
Wait for the following output on the console:
```

ROMMON upgrade complete.  
To make the new ROMMON permanent, you must restart the RP

**Step 4** Reload both the SUPs.

## Downstream-Controller Remapping (CBR-CCAP-LC-G2-R with 8x10G DPIC)

### Before you begin

If you are using cBR CCAP 8x10G Remote PHY Digital Physical Interface Card (D-PIC) with CBR-CCAP-LC-G2-R linecards, contact your local Cisco representative before upgrading to Cisco IOS XE Dublin 17.15.1w.

Starting with in Cisco IOS XE Bengaluru 17.6.1, Cisco introduces a new feature on cBR-8 that provides initial support for 32 Video and 32 DOCSIS service groups per CBR-CCAP-LC-G2-R linecard. The implementation of this feature introduces new 8x10G DPIC port mapping constraints on existing 'Downstream-Cable' controllers. Cisco has prepared a python tool that can be used to determine if a cBR-8 running-configuration includes non-compliant controller mappings, and, to update the running-configuration to be compliant with the latest Cisco IOS XE Dublin 17.15.1w. Once you have the python tool, perform the following steps in order to predict and avoid downtime:

**Before you begin:** Special considerations must be taken when using SmartPHY. Contact your local Cisco representative if your installation includes SmartPHY.

### Procedure

**Step 1** Collect the following information from the target cBR-8 to upgrade.

```
Router#show cable rpd sum
Router#show cable modem sum
Router#show cable video session all sum
```

**Step 2** Save the running configuration to the harddisk of the cBR-8.

```
Router#copy running-config harddisk:SavedConfig.txt
```

**Step 3** Copy the saved running configuration from harddisk: to an offline server for editing using SCP.

```
Router#copy harddisk:SavedConfig.txt scp:<path>
```

**Step 4** Run the python tool to modify the controllers in the saved configuration.

- Option 1 - Renumber Downstream-Cable controllers only
  - a. Execute python script **kobol\_ph2\_controller\_migration.py**. This script is intended for customers who do not immediately intend to take advantage of the Downstream-Video controllers and expanded SG capacity on CBR-CCAP-LC-G2-R.

```
$ python kobol_ph2_controller_migration.py
Enter the name of the configuration file: SavedConfig.txt
```

- b. Output file appends **\_remap\_controller** to the file name.

```
Output file name: SavedConfig.txt_remap_controller
```

- c. Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.

- Option 2 - Renumber Downstream-Cable and utilize Downstream-Video controllers

- a. Execute python script **kobol\_ph2\_controller\_migration\_video.py**. This script is intended for customers who wish to utilize the new Downstream-Video controllers to free up existing Downstream-Cable controllers for expanded DOCSIS service groups.

```
$ python kobol_ph2_controller_migration_video.py
Enter the name of the configuration file: SavedConfig.txt
```

- b. Output file appends **\_remap\_controller\_video** to the file name.

```
Output file name: SavedConfig.txt_remap_controller_video
```

- c. Check to ensure that the script completed successfully. If no output file is created or the size of the output file is 0 byte, then check script output for error messages.

#### Step 5 Modify the remapped configuration file to specify the Cisco IOS XE Dublin 17.15.1w image in the boot parameter.

```
boot system harddisk:cbrsup-universalk9.17.15.01w.SPA.bin
```

#### Step 6 Copy the final remapped configuration file back to the cBR-8 harddisk.

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller harddisk:
```

or

```
Router#copy scp:<path>/SavedConfig.txt_remap_controller_video harddisk:
```

#### Step 7 Copy remapped configuration file to startup of the cBR-8.

```
Router#copy harddisk:SavedConfig.txt_remap_controller startup-config
```

or

```
Router#copy harddisk:SavedConfig.txt_remap_controller_video startup-config
```

After performing the remapping procedure, monitor the chassis for any of the following errors after reload:

```
Mismatches TE interface. DS controller should be */*/0~7, configuration failed.
Mismatches TE interface. DS controller should be */*/8~15, configuration failed.
Mismatches TE interface. DS controller should be */*/16~23, configuration failed.
Mismatches TE interface. DS controller should be */*/24~31, configuration failed.
```

