



## Managing Selected Region

---

- [Viewing Selected Region Settings, on page 1](#)
- [Updating Selected Region Settings, on page 1](#)

### Viewing Selected Region Settings

#### Procedure

---

- Step 1** Under **Cisco User Defined Network**, tap **Devices**.  
The **Settings** page is displayed.
- Step 2** Tap **Selected Region**.  
The **Settings** page is displayed.  
You get to view the selected region.
- 


### Updating Selected Region Settings

#### Procedure

---

- Step 1** Under **Cisco User Defined Network**, tap **Devices**.  
The **Settings** page is displayed.
- Step 2** Tap **Selected Region**.  
The **Settings** page is displayed.
- Step 3** Select a region of your choice.


*Figure 1: Selecting a Region Settings*



**Note** You will get to re-confirm the selected region.

**Step 4** Tap **Continue** to proceed with the selected region.

Figure 2: Selected Region Settings - Confirmation Dialogue



The **Settings** page is displayed.

**Note** If you choose a wrong region, the existing devices will not be visible.

