



Command-line Interface (CLIs) for Timing and Synchronization

The Cisco Command Reference Guide serves as a comprehensive resource, offering a catalog of command-line interface (CLI) commands for configuring and verifying Timing and Synchronization implementation.

What You'll Find in This Section

Cisco IOS XR supports configuring Timing and Synchronization using both traditional Command Line Interface (CLI) using commands as well as programmatically using YANG data models.

In this section, you'll find:

- [Reference to Command Reference Guide, on page 1](#)

Reference to Command Reference Guide

The Cisco Command Reference Guide serves as a comprehensive resource, offering a catalog of command-line interface (CLI) commands for configuring and verifying Timing and Synchronization settings.

To view the list of supported commands, refer [System Management Command Reference for Cisco 8000 Series Routers](#).

