



Performing a Reset

You can reset the Cisco VG410 Voice Gateway by using the reset button that is present on the I/O side of the device. To reset the device, press the reset button for more than 10 seconds. This action triggers a reload, removes the startup configuration, and recovers the process.

During the Cisco VG410 Voice Gateway manufacturing process, the `nvram:golden.cfg` is duplicated from the startup configuration.

When you perform a front panel reset in the field, the next router reload utilizes the information in the `nvram:gold.cfg` file for the router's startup configuration. If a `golden.cfg` file is not present, an empty startup configuration is used during startup, and the day0 autoinstall/pnp/initial configuration dialog appears.



Note When you press the reset button, it only affects the startup configuration. The contents in the bootflash: remains intact.
