



Network Protocol Values

Using the `AddProtocol` and `DeleteProtocol` commands, you can add protocols to or remove protocols from hosts. The following table details the available network protocol values.

Table A-1 **Network Protocol Values**

Value	Description
IP	Internet Protocol version 4
ARP	Address Resolution Protocol
BPDU(STP)	Bridge Protocol Data Unit (Spanning Tree Protocol)
RARP	Reverse Address Resolution Protocol
OldIPX	Internetwork Packet Exchange, older version
IP Version 6	Internet Protocol version 6
Loopback	Loopback
SNAP	Subnetwork Access Protocol
Novell NetWare	Novell NetWare
NetBIOS	Network Basic Input/Output System
NetBIOS (Response)	Network Basic Input/Output System response
IPX	Internetwork Packet Exchange
Intel ANS	Intel Advanced Network Services
DEC MOP Dump/Load Assistance	Digital Equipment Corporation Maintenance Operations Protocol dump/load assistance
DEC MOP Remote Console	Digital Equipment Corporation Maintenance Operations Protocol remote console
PPPoE Discovery	Point-to-Point over Ethernet discovery stage
PPPoE Session	Point-to-Point over Ethernet session stage

