



## Status

---

The **Status** menu in the Admin UI is used by administrators to view system information, such as installed system packages and their version, detailed logs, and available storage.

- [About, on page 1](#)
- [Backup Details, on page 2](#)
- [Logs, on page 3](#)
- [Storage, on page 3](#)

## About

You can view the installed packages and their version on the **System Version** page in the Admin UI.

---

**Step 1** Click the **Status** tab and choose **About** to open the **System Version** page.

Figure 1: System Version

The screenshot shows the 'System Version' page in the Threat Grid Appliance interface. The page title is 'ThreatGrid Appliance System Version'. Below the title, the release version is displayed as '2020.04.20201105T010610.srchash.0f8f86ad922.rel'. A table lists various installed packages and their versions.

Package	Version
acl	2.2.53-1
alsa-lib	1.1.9-1
aom	1.0.0.errata1-1
appliance-config	0.srchash.4ef5f4649087-1
appliance-firmware-update	0.0.1-1
appliance-recovery	2020.04.20201105T010610.srchash.6d4c012f6105.rel-1
appliance-release	2020.04.20201105T010610.srchash.0f8f86ad922.rel-1
archlinux-keyring	20190805-1
argon2	20190702-1
attr	2.4.48-1
audit	2.8.5-3
avahi	0.7+18+g1b5f401-2
bash	5.0.007-1
bind-tools	9.14.4-1
bro	2.6.1-6
broffi	1.0.7-1
btsp2	1.0.8-2
c-ares	1.15.0-1
ca-certificates	20181109-1
ca-certificates-mozilla	3.45-1
ca-certificates-utils	20181109-1
cairo	1.17.2+17+g52a7c79fd-1
catervisual	3.02a00-1

- Step 2** View the packages that are installed and their versions. The release version is shown in the upper portion of the page. To identify the build number and corresponding release version, see the [Cisco Threat Grid Appliance Version Lookup Table](#).

## Backup Details

You can view detailed backup information on the **Backup Details** page, which displays the most recent time at which complete, non-incremental (where applicable) backups of PostgreSQL, Elasticsearch, and Sand Castle freezer data were successfully completed.

Click the **Status** tab and choose **Backup Details** to open the **Backup Details** page.

Figure 2: Backup Details

The screenshot shows the 'Backup Details' page in the Threat Grid Appliance interface. The page title is 'ThreatGrid Appliance Backup Details'. Below the title, a message states: 'All components have been backed up on 2020-11-20 04:25:09'. A table lists the backup details for different components.


Name	Date
Elastic	2020-11-25 15:00:09 +0000
Postgres	2020-11-25 04:12:13 +0000
Freezer	2020-11-20 04:25:09 +0000

# Logs

You can view detailed log information, including historical system logs, on the **Notifications** page.

**Step 1** Click the **Status** menu and choose **Logs** to open the **Notifications** page.

*Figure 3: Notifications*



**Step 2** Filter the logs that are displayed by choosing the type of notification from the drop-down list, and specify the number of records to be displayed on the page.


Use the **Back** and **Forward** buttons to navigate between pages.

# Storage

You can view the available storage on the Threat Grid Appliance from the **Storage** page.

**Step 1** Click the **Status** tab and choose **Storage**.

Figure 4: Storage



**Step 2** View the size of the directories, amount of used storage, and the amount of available storage.