



## **Cisco Nexus 3548 Switch NX-OS Verified Scalability Guide, Release 7.0(3)I7(8)**

[Introduction](#) 2

[Verified Scalability Limits](#) 2

Revised: April 17, 2024

# Introduction

This document lists the Cisco verified limits for topologies that include Layer 2 and Layer 3 feature configurations.

In the following tables, the Verified Topology column lists the verified scaling capabilities with all listed features that are enabled at the same time. The numbers listed here exceed those used by most customers in their topologies. The scale numbers that are listed here are not the maximum verified values if each feature is viewed in isolation.

The Verified Maximum column lists the maximum scale capability that is tested for the corresponding feature individually. This number is the absolute maximum that is currently supported by the Cisco NX-OS Release software for the corresponding feature. If the hardware is capable of higher scale, future software releases may increase this verified maximum limit.



---

**Note** If your scale requirements exceed either the Verified Topology or the Verified Maximum limit, please contact your Cisco representative. Based on your requirements, it may be possible to validate support for your requirement, as long as the scale capability of the hardware is not exceeded.

---

## Verified Scalability Limits

The tables in this section list the verified scalability limits for Cisco NX-OS Release 7.0(3)I7(8).

**Table 1: Layer 2 and Layer 3 Topology Configuration Limits**

Feature	Verified Topology	Verified Maximum
Active VLANs per switch	507 (vPC - normal mode)	507 (with RSTP) 4000 (with MSTP)
BFD neighbors	0	32
EIGRP instances	0	4
MTU	9,216	9,216
STP logical interfaces	2,500	9,000
MST instances	63	64
MAC table size	8,192	40,000 (vPC, Normal mode) 65,532 (non-vPC, Normal mode) 8,192 (non-vPC, Warp mode)
Port Channels	40 vPC port-channels 8 non-vPC port-channels	40 vPC port-channels 24 non-vPC port-channels
Number of member ports per Port Channel	16	24

Feature	Verified Topology	Verified Maximum
Number of system logging destination ports	0	8
SPAN sessions	4 active sessions <a href="#">1</a>	4 active bi-directional sessions <sup>2</sup> 1 destination ports per session
Layer 3 physical interfaces	10	48
Layer 3 SVI, subinterfaces, EtherChannels	256	1,024
VRF	10	200
IPv4 hosts	4,096	65,535 <sup>3</sup>
IPv4 routes (LPM)	8,192 (vPC , Normal mode) 4,096 (non-vPC , Warp mode)	24,576 (vPC, Normal mode ) 24,576 (non-vPC, Normal mode ) 4,096 (non-vPC, Warp mode)
Multicast routes	4,000 (vPC, Normal mode) 7,990 (non-vPC, Warp mode)	4,000 (vPC, Normal mode) 8,192 (non-vPC, Normal mode)
IGMP Snooping groups	3,000	8,192
ECMP <sup>4</sup>	2-way	32-way
TCAM entries for ACL	384 ingress (Normal mode) 128 ingress (Warp mode)	3,000 ingress, 1,000 egress (Normal mode)
HSRP	256	500
VRRP	250 <sup>5</sup>	256 <sup>6</sup>
Configurable QoS groups	4	4
BGP neighbors	85	100
OSPF instances	4	4
OSPF neighbors	150 (in a single area, area 0)	150 (in a single area, area 0)
PIM neighbors	250	250
NAT translations	—	1023

<sup>1</sup> Allows same SPAN source in a single direction in 2 SPAN sessions with difference destinations.

<sup>2</sup> 4 active SPAN sessions regardless of the direction of the SPAN session.

<sup>3</sup> The host IP address pattern can lead to a hash collision in the host table and therefore the number of host routes programmed will be lesser than 65,535. To avoid a collision, use a different IP address range.

<sup>4</sup> Only supported in Normal Traffic Forwarding mode.

<sup>5</sup> A combination of HSRP and VRRP groups, where the total is 250.

<sup>6</sup> A combination of HSRP and VRRP groups, where the total is 250.



**Note** The following non-default CoPP values were used for some protocols for the verified topology scale numbers.

**Table 2: Non-Default CoPP Values Used for vPC Verified Topology**

Default Values	Non-Default Values
<pre>class copp-s-routingProto2   police pps 1300 class copp-s-routingProto1   police pps 1000 class copp-s-pimreg   police pps 200 class copp-s-lldp   police pps 500</pre>	<pre>class copp-s-routingProto2   police pps 500 class copp-s-routingProto1   police pps 1500 class copp-s-pimreg   police pps 600 class copp-s-lldp   police pps 800</pre>

**Table 3: Non-VPC Scale Numbers of Cisco Nexus N3548-X Switches**

Feature	Verified Topology	Verified Maximum
Active VLANs per switch	605 (MST Mode)	507 (RSTP Mode) 4013 (MSTP Mode)
BFD neighbors	16	32
MTU	9,216	9,216
STP logical interfaces	2,500	9,000
MST instances	1	64
MAC table size	7,375 (90% approx.)	65,532 (Non-warp Mode) 8,192 (Warp Mode)
Port Channels	7 Non-vPC port-channels	24
Number of member ports per Port Channel	9	24
Number of system logging destination ports	0	8
SPAN sessions	4 active sessions <a href="#">7</a>	4
Layer 3 physical interfaces	10	48
Layer 3 SVI, subinterfaces, EtherChannels	250	1,024

Feature	Verified Topology	Verified Maximum
VRF	11	200
IPv4 hosts	7,400 (90% approx.)	65,535 (Normal Mode) 8,196 (Warp Mode)
IPv4 routes (LPM)	3,700 (Non-vPC, WARP mode)	24,576 (Non-vPC, Normal Mode) 4,096 (Warp Mode)
Multicast routes	3,680 (Non-vPC, WARP mode)	8,192 (vPC Normal Mode) 4,096 (Non-vPC, Normal Mode)
IGMP Snooping groups	3,000	8,192
ECMP <a href="#">8</a>	2-way	32-way
TCAM entries for ACL	384 ingress (Normal mode) 128 ingress (WARP mode)	3,000 Ingress, 1000 Egress
HSRP	256	500
VRRP <a href="#">9</a>	250	256
Configurable QoS groups	4	4
BGP neighbors	10	100
OSPF neighbors	10 (in a single area, area 0)	150
PIM neighbors	100	250
NAT translations	10	1,023
Multicast Service Reflection sessions	400	1,023 (Regular mode) 2,047 (Fast Pass mode)

<sup>7</sup> Allows same SPAN source in a single direction in 2 SPAN sessions with difference destinations.

<sup>8</sup> Only supported in Normal Traffic Forwarding mode.

<sup>9</sup> A combination of HSRP and VRRP groups, where the total is 250.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS REFERENCED IN THIS DOCUMENTATION ARE SUBJECT TO CHANGE WITHOUT NOTICE. EXCEPT AS MAY OTHERWISE BE AGREED BY CISCO IN WRITING, ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS DOCUMENTATION ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED.

The Cisco End User License Agreement and any supplemental license terms govern your use of any Cisco software, including this product documentation, and are located at: <http://www.cisco.com/go/softwareterms>. Cisco product warranty information is available at <http://www.cisco.com/go/warranty>. US Federal Communications Commission Notices are found here <http://www.cisco.com/c/en/us/products/us-fcc-notice.html>.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any products and features described herein as in development or available at a future date remain in varying stages of development and will be offered on a when-and if-available basis. Any such product or feature roadmaps are subject to change at the sole discretion of Cisco and Cisco will have no liability for delay in the delivery or failure to deliver any products or feature roadmap items that may be set forth in this document.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

The documentation set for this product strives to use bias-free language. For the purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: [www.cisco.com go trademarks](http://www.cisco.com/go/trademarks). Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020 Cisco Systems, Inc. All rights reserved.



**Americas Headquarters**  
Cisco Systems, Inc.  
San Jose, CA 95134-1706  
USA

**Asia Pacific Headquarters**  
CiscoSystems(USA)Pte.Ltd.  
Singapore

**Europe Headquarters**  
CiscoSystemsInternationalBV  
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).