



INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({}), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-197](#)
 - showing the mode [2-502, 2-503](#)
- 802.1Q trunk ports and native VLANs [2-842](#)
- 802.1Q tunnel ports
 - configuring [2-786](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-154](#)
 - configuring for single host [2-154](#)
 - configuring multiple domains [2-154](#)
 - disabling port control [2-147](#)
 - enabling port control [2-147](#)
- 802.1X Critical Authentication
 - disabling on a port [2-148](#)
 - disabling on a VLAN [2-151](#)
- EAPOL

- disabling send success packets [2-149](#)
- enabling send success packets [2-149](#)
- enabling on a port [2-148](#)
- enabling on a VLAN [2-151](#)
- returning delay time to default setting [2-150](#)
- setting delay time on a port [2-150](#)
- 802.1X critical authentication
 - configure parameters [2-21](#)
- 802.1X critical recovery delay, configuring [2-21](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-104](#)
 - displaying port based authentication [2-482](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-165](#)
 - enabling guest VLAN [2-152](#)
 - enabling guest VLAN supplicant [2-146, 2-153](#)
 - enabling manual control of auth state [2-161](#)
 - enabling periodic re-authentication of the client [2-164](#)
 - initializing re-authentication of dot1x ports [2-163](#)
 - initializing state machines [2-156](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-159](#)
 - setting the reauthentication timer [2-166](#)

A

- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-18](#)
 - connecting to a remote module [2-414](#)
 - connecting to a specific remote module [2-426](#)
- access-group

- displaying mac interface [2-609](#)
- show mode interface [2-445, 2-662](#)
- access groups
 - IP [2-6, 2-142](#)
- access-list hardware capture mode command [2-8](#)
- access lists
 - clearing an access template [2-69](#)
 - defining ARP [2-17](#)
 - displaying ARP information [2-448](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-844](#)
- access-policies, applying using host-mode [2-25](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-192](#)
 - displaying mac access-group interface [2-609](#)
 - enabling hardware statistics [2-192](#)
 - using ACL naming conventions for MAC ACLs [2-308](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-380](#)
- adjacency
 - debugging the adjacency table [2-97](#)
 - disabling the debug facility [2-97](#)
 - displaying information about the adjacency table [2-446](#)
 - displaying IPC table entries [2-97](#)
- aggregate policer
 - displaying information [2-663](#)
- aging time
 - displaying MAC address aging time [2-612](#)
- alarms
 - displaying operational status [2-490](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- ARP
 - access list, displaying detailed information [2-448](#)
 - defining access-lists [2-17](#)
- ARP inspection
 - enforce certain types of checking [2-214](#)
- ARP packet
 - deny based on DHCP bindings [2-136](#)
 - permit based on DHCP bindings [2-359](#)
- authentication [2-21, 2-27](#)
 - changing the control-direction [2-19](#)
 - configure actions for events
 - configuring the actions [2-22](#)
 - configuring port-control [2-31](#)
 - enabling reauthentication [2-30](#)
 - enabling Webauth fallback [2-24](#)
 - host-mode configuration [2-25](#)
 - setting priority of methods [2-33](#)
 - setting the timer [2-35](#)
 - setting username [2-829](#)
 - specifying the order of methods [2-28](#)
 - using an MD5-type encryption method [2-829](#)
 - verifying MD5 signature [2-831](#)
 - verifying the checksum for Flash memory [2-831](#)
- authentication control-direction command [2-19](#)
- authentication critical recovery delay command [2-21](#)
- authentication event command [2-22](#)
- authentication fallback command [2-24](#)
- authentication host-mode [2-25](#)
- authentication methods, setting priority [2-33](#)
- authentication methods, specifying the order of attempts [2-28](#)
- authentication open command [2-27](#)
- authentication order command [2-28](#)
- authentication periodic command [2-30](#)
- authentication port-control command [2-31](#)
- authentication priority command [2-33](#)
- authentication timer, setting [2-35](#)

authentication timer command [2-35](#)

auth fail VLAN

- enable on a port [2-146](#)
- set max number of attempts [2-145](#)

Auth Manager

- configuring
 - authentication timer [2-35](#)

authorization state

- enabling manual control [2-161](#)

authorization state of a controlled port [2-161](#)

automatic installation

- displaying status [2-453](#)

automatic medium-dependent interface crossover

- See Auto-MDIX

Auto-MDIX

- disabling [2-341](#)
- enabling [2-341](#)

auto-negotiate interface speed

- example [2-763](#)

auto-QoS

- configuring for VoIP [2-37](#)
- displaying configuration [2-454](#)

B

baby giants

- displaying the system MTU setting [2-694](#)
- setting the maximum Layer 2 payload size [2-810](#)

BackboneFast

- displaying debugging messages [2-123](#)
- displaying spanning tree status [2-684](#)
- enabling debugging [2-123](#)

bandwidth command [2-41](#)

bindings

- store for DHCP snooping [2-225](#)

BOOT environment variable

- displaying information [2-457](#)

bootflash

- displaying information [2-455](#)

BPDUs

- debugging spanning tree activities [2-121](#)

bridge protocol data units

- See BPDUs

broadcast

- counters [2-94](#)

broadcast suppression level

- configuring [2-764, 2-766](#)
- enabling [2-764, 2-766](#)

C

cable diagnostics

- TDR
 - displaying test results [2-458](#)
 - testing conditions of copper cables [2-812](#)

call home

- displaying information [2-460](#)
- e-mailing output [2-49](#)
- entering configuration submode [2-44](#)
- executing [2-49](#)
- manually send test message [2-52](#)
- receiving information [2-47](#)
- sending alert group message [2-50](#)
- submitting information [2-47](#)

call home destination profiles

- displaying [2-462](#)

Catalyst 4507R [2-378](#)

CDP

- configuring tunneling encapsulation rate [2-296](#)
- displaying
 - neighbor information [2-465](#)
- enabling protocol tunneling for [2-291](#)
- set drop threshold for [2-294](#)

CEF

- displaying next-hop information [2-539](#)
- displaying VLAN configuration information [2-539](#)

chassis

- displaying

- chassis MAC address ranges [2-606](#)
 - current and peak traffic meter readings [2-606](#)
 - percentage of backplane utilization [2-606](#)
 - switching clock failure recovery mode [2-606](#)
 - cisco-desktop
 - macro apply [2-320](#)
 - Cisco Express Forwarding
 - See CEF
 - cisco-phone
 - macro apply [2-322](#)
 - cisco-router
 - macro apply [2-324](#)
 - cisco-switch
 - macro apply [2-326](#)
 - class-map command [2-60](#)
 - class maps
 - defining the match criteria [2-334](#)
 - clear commands
 - clearing Gigabit Ethernet interfaces [2-67](#)
 - clearing IGMP group cache entries [2-76](#)
 - clearing interface counters [2-62](#)
 - clearing IP access lists [2-69, 2-70](#)
 - clearing IP ARP inspection statistics VLAN [2-71](#)
 - clearing IP DHCP snooping database statistics [2-75](#)
 - clearing MFIB counters and routes [2-79](#)
 - clearing MFIB fastdrop entries [2-80](#)
 - clearing PAgP channel information [2-85](#)
 - clearing QoS aggregate counters [2-88](#)
 - clearing VLAN interfaces [2-68](#)
 - clear energywise neighbors command [2-64](#)
 - CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
 - command modes
 - accessing privileged EXEC mode [1-5](#)
 - exiting [1-5](#)
 - understanding user EXEC and configuration modes [1-5](#)
 - condition interface
 - debugging interface-related activities [2-99](#)
 - condition vlan
 - debugging VLAN output [2-102](#)
 - configuration, saving [1-11](#)
 - configuring
 - root as secondary [2-747](#)
 - configuring a SPAN session to monitor
 - limit SPAN source traffic [2-346](#)
 - configuring critical recovery [2-21](#)
 - configuring forward delay [2-743](#)
 - configuring root as primary [2-747](#)
 - CoPP
 - attaching
 - policy map to control plane [2-424](#)
 - displaying
 - policy-map class information [2-638](#)
 - entering configuration mode [2-92](#)
 - removing
 - service policy from control plane [2-424](#)
 - CoS
 - assigning to Layer 2 protocol packets [2-293](#)
 - counters
 - clearing interface counters [2-62](#)
 - critical authentication, configure 802.1X parameters [2-21](#)
 - critical recovery, configuring 802.1X parameter [2-21](#)
-
- D**
 - DAI
 - clear statistics [2-71](#)
 - DBL
 - displaying qos dbl [2-664](#)

- debug commands
 - debugging backup events [2-98](#)
 - debugging DHCP snooping events [2-109](#)
 - debugging DHCP snooping messages [2-110](#)
 - debugging EtherChannel/PAgP/shim [2-105](#)
 - debugging IPC activity [2-108](#)
 - debugging IP DHCP snooping security messages [2-111](#)
 - debugging NVRAM activities [2-114](#)
 - debugging PAgP activities [2-115](#)
 - debugging port manager activities [2-118](#)
 - debugging spanning tree activities [2-121](#)
 - debugging spanning tree backbonefast [2-123](#)
 - debugging spanning tree UplinkFast [2-126](#)
 - debugging supervisor redundancy [2-120](#)
 - debugging VLAN manager activities [2-127](#)
 - displaying monitor activity [2-113](#)
 - displaying the adjacency table [2-97](#)
 - enabling debug dot1x [2-104](#)
 - enabling debugging messages for ISL VLAN IDs [2-130](#)
 - enabling debugging messages for VTP [2-131](#)
 - enabling debugging of UDLD activity [2-132](#)
 - enabling switch shim debugging [2-124](#)
 - enabling VLAN manager file system error tests [2-128](#)
 - limiting debugging output for VLANs [2-102](#)
 - limiting interface debugging output [2-99](#)
 - limiting output for debugging standby state changes [2-100](#)
 - shortcut to the debug condition interface [2-107](#)
- debugging
 - activity monitoring [2-113](#)
 - DHCP snooping events [2-109](#)
 - DHCP snooping packets [2-110](#)
 - IPC activities [2-108](#)
 - IP DHCP snooping security packets [2-111](#)
 - NVRAM activities [2-114](#)
 - PAgP activities [2-115](#)
 - PAgP shim [2-105](#)
 - PM activities [2-118](#)
 - spanning tree BackboneFast events [2-123](#)
 - spanning tree switch shim [2-124](#)
 - spanning tree UplinkFast events [2-126](#)
 - VLAN manager activities [2-127](#)
 - VLAN manager IOS file system error tests [2-128](#)
 - VTP protocol debug messages [2-131](#)
- debug spanning tree switch [2-124](#)
- debug sw-vlan vtp [2-131](#)
- default form of a command, using [1-6](#)
- DHCP
 - clearing database statistics [2-75](#)
- DHCP bindings
 - configuring bindings [2-223](#)
 - deny ARP packet based on matches [2-136](#)
 - permit ARP packet based on matches [2-359](#)
- DHCP snooping
 - clearing binding entries [2-72](#)
 - clearing database [2-74](#)
 - displaying binding table [2-542](#)
 - displaying configuration information [2-540](#)
 - displaying status of DHCP database [2-545](#)
 - displaying status of error detection [2-493](#)
 - enabling DHCP globally [2-222](#)
 - enabling IP source guard [2-262](#)
 - enabling on a VLAN [2-232](#)
 - enabling option 82 [2-227](#), [2-229](#)
 - enabling option-82 [2-234](#)
 - enabling rate limiting on an interface [2-230](#)
 - enabling trust on an interface [2-231](#)
 - establishing binding configuration [2-223](#)
 - renew binding database [2-416](#)
 - store generated bindings [2-225](#)
- diagnostic fpga soft-error recover aggressive command [2-142](#)
- diagnostic test
 - bootup packet memory [2-476](#)
 - displaying attributes [2-470](#)
 - display module-based results [2-472](#)
 - running [2-144](#)

- show results for TDR [2-458](#)
- testing conditions of copper cables [2-812](#)
- displaying error disable recovery [2-494](#)
- displaying inline power status [2-653](#)
- displaying monitoring activity [2-113](#)
- displaying PoE policing and monitoring status [2-661](#)
- displaying SEEPROM information
 - GBIC [2-504](#)
- displaying SPAN session information [2-694, 2-766](#)
- document conventions [1-xx](#)
- document organization [1-xix](#)
- DoS
 - CoPP
 - attaching policy map to control plane [2-424](#)
 - displaying policy-map class information [2-638](#)
 - entering configuration mode [2-92](#)
 - removing service policy from control plane [2-424](#)
 - entering
 - CoPP configuration mode [2-92](#)
- DOS attack
 - protecting system's resources [2-209](#)
- drop threshold, Layer 2 protocol tunneling [2-294](#)
- dual-capable port
 - selecting a connector [2-343](#)
- duplex mode
 - configuring autonegotiation on an interface [2-168](#)
 - configuring full duplex on an interface [2-168](#)
 - configuring half duplex on an interface [2-168](#)
- dynamic ARP inspection
 - preventing [2-209](#)
- Dynamic Host Configuration Protocol
 - See DHCP
- filters
 - routing updates, preventing [2-356](#)
- enabling
 - debugging for UDLD [2-132](#)
 - voice VLANs [2-779](#)
- enabling open access [2-27](#)
- EnergyWise
 - display power information through queries [2-177](#)
 - display setting, status of entity and PoE ports [2-486](#)
 - on an entity
 - enable, assign to domain, and set password [2-175](#)
 - on an entity, enable and configure [2-170](#)
 - on a PoE port
 - configuring on PoE port [2-172](#)
- energywise (global configuration) command [2-170, 2-172](#)
- energywise domain command [2-175](#)
- EnergyWise neighbor table, deleting [2-64](#)
- energywise query command [2-177](#)
- environmental
 - alarms [2-490](#)
 - displaying information [2-490](#)
 - status [2-490](#)
 - temperature [2-490](#)
- erase a file [2-181](#)
- error disable detection
 - clearing error disable on an interface [2-65](#)
 - enabling error disable detection [2-65, 2-184](#)
 - enabling per-VLAN on BPDU guard [2-184](#)
- error-disabled state
 - displaying [2-523](#)
- error disable recovery
 - configuring recovery mechanism variables [2-186](#)
 - displaying recovery timer information [2-494](#)
 - enabling ARP inspection timeout [2-186](#)
 - specifying recovery cause [2-186](#)
- EtherChannel
 - assigning interfaces to EtherChannel groups [2-53](#)
 - debugging EtherChannel [2-105](#)
 - debugging PAgP shim [2-105](#)

- debugging spanning tree activities [2-121](#)
- displaying information for a channel [2-496](#)
- removing interfaces from EtherChannel groups [2-53](#)

EtherChannel guard

- detecting STP misconfiguration [2-733](#)

Explicit Host Tracking

- clearing the database [2-78](#)
- enabling per-VLAN [2-246](#)

expressions

- matching multiple expression occurrences [1-9](#)
- multiple-character patterns [1-8](#)
- multiplying pattern occurrence [1-11](#)
- single-character patterns [1-7](#)

Extensible Authentication Protocol

- See EAP

F

- fallback profile, specifying [2-24](#)
- field replaceable unit (FRU)
 - displaying status information [2-490](#)
- filters
 - EIGRP
 - routing updates, preventing [2-356](#)
- Flash memory file system
 - displaying file system information [2-455](#)
 - verifying checksum [2-831](#)
- flow control
 - configuring a gigabit interface for pause frames [2-189](#)
 - displaying per-interface statistics for flow control [2-500](#)

G

- GBIC
 - displaying SEEPROM information [2-504](#)
- Gigabit Ethernet interface
 - clearing the hardware logic [2-67](#)
- Gigabit Ethernet uplink

- selecting [2-197](#)
- showing the mode [2-502, 2-503](#)

global configuration mode

- using [1-5](#)

H

- hardware module
 - resetting a module by toggling the power [2-194](#)
- hardware statistics
 - disabling [2-192](#)
 - enabling [2-192](#)
- hardware uplink
 - selecting the mode [2-197](#)
 - showing the mode [2-502, 2-503](#)
- helper addresses, IP [2-560](#)
- hot standby protocol
 - debugging [2-100](#)
 - disabling debugging [2-100](#)
 - limiting output [2-100](#)
- hw-module uplink mode shared-backplane command [2-195](#)

I

- IDPROMs
 - displaying SEEPROM information
 - chassis [2-504](#)
 - clock module [2-504](#)
 - fan trays [2-504](#)
 - module [2-504](#)
 - mux buffer [2-504](#)
 - power supplies [2-504](#)
 - supervisor engine [2-504](#)
- ifIndex persistence
 - clearing SNMP ifIndex commands [2-717](#)
 - compress SNMP ifIndex table format [2-726](#)
 - disabling globally [2-725](#)
 - disabling on an interface [2-719](#)

- enabling globally [2-725](#)
- enabling on an interface [2-719](#)
- IGMP
 - applying filters for host joining on Layer 2 interfaces [2-236](#)
 - clearing IGMP group cache entries [2-76](#)
 - configuring frequency for IGMP host-query messages [2-239](#)
 - creating an IGMP profile [2-238](#)
 - displaying IGMP interface configuration information [2-547](#)
 - displaying profiles [2-549](#)
 - setting maximum group numbers [2-237](#)
- IGMP profiles
 - displaying [2-549](#)
- IGMP snooping
 - clearing the EHT database [2-78](#)
 - configuring a Layer 2 interface as a group member [2-252](#)
 - configuring a Layer 2 interface as a multicast router [2-250](#)
 - configuring a static VLAN interface [2-252](#)
 - displaying multicast information [2-556](#)
 - displaying VLAN information [2-550, 2-554, 2-557](#)
 - enabling [2-241](#)
 - enabling immediate-leave processing [2-248](#)
 - enabling on a VLAN [2-245](#)
 - enabling per-VLAN Explicit Host Tracking [2-246](#)
- informs
 - enabling [2-721](#)
- inline power
 - displaying inline power status [2-653](#)
- In Service Software Upgrade
 - See ISSU
- inspection log
 - clearing log buffer [2-70](#)
- interface
 - displaying suppressed multicast bytes [2-517](#)
- interface capabilities
 - displaying [2-513](#)
- interface configuration mode
 - summary [1-5](#)
- interface link
 - display cable disconnect time [2-520](#)
- interfaces
 - configuring dot1q tunnel ports [2-786](#)
 - creating an interface-range macro [2-135](#)
 - debugging output of interface related activities [2-99](#)
 - displaying description [2-519](#)
 - displaying error-disabled state [2-523](#)
 - displaying information when tunneling is enabled [2-600](#)
 - displaying status [2-519](#)
 - displaying traffic for a specific interface [2-510](#)
 - entering interface configuration mode [2-201](#)
 - executing a command on multiple ports in a range [2-204](#)
 - selecting an interface to configure [2-201](#)
 - setting a CoS value for Layer 2 packets [2-293](#)
 - setting drop threshold for Layer 2 packets [2-294](#)
 - setting the interface type [2-786](#)
- interface speed
 - configuring interface speed [2-761](#)
- interface transceiver
 - displaying diagnostic data [2-527](#)
- internal VLAN allocation
 - configuring [2-845](#)
 - default setting [2-845](#)
 - displaying allocation information [2-706](#)
- Internet Group Management Protocol
 - See IGMP
- IP ARP
 - applying ARP ACL to VLAN [2-207](#)
 - clearing inspection statistics [2-71](#)
 - clearing status of log buffer [2-70](#)
 - controlling packet logging [2-218](#)
 - enabling dynamic inspection [2-216](#)
 - limit rate of incoming requests [2-209](#)
 - set per-port config trust state [2-213](#)

- showing status of dynamic ARP inspection [2-534](#)
 - showing status of log buffer [2-537](#)
 - IPC
 - debugging IPC activities [2-108](#)
 - IP DHCP Snooping
 - See DHCP snooping
 - IP header validation
 - disabling [2-261](#)
 - enabling [2-261](#)
 - IP interfaces
 - displaying usability status [2-559](#)
 - IP multicast
 - displaying multicast routing table information [2-565](#)
 - IP phone and standard desktop
 - enabling Cisco-recommended features [2-322](#)
 - IP Port Security
 - enabling [2-262](#)
 - IP source binding
 - adding or deleting [2-258](#)
 - displaying bindingstagging [2-570](#)
 - IP source guard
 - debugging messages [2-111](#)
 - displaying configuration and filters [2-571](#)
 - enabling on DHCP snooping [2-262](#)
 - IPv6 MLD
 - configuring queries [2-268, 2-270](#)
 - configuring snooping
 - last-listener-query-intervals [2-270](#)
 - configuring snooping
 - listener-message-suppression [2-272](#)
 - configuring snooping robustness-variables [2-273](#)
 - configuring ten topology change notifications [2-275](#)
 - counting snooping last-listener-queries [2-268](#)
 - displaying information [2-576](#)
 - displaying ports for a switch or VLAN [2-578](#)
 - displaying querier information [2-579](#)
 - enabling snooping [2-266](#)
 - enabling snooping on a VLAN [2-276](#)
 - ISSU
 - canceling process [2-278](#)
 - configuring rollback timer [2-290](#)
 - displaying capability [2-581](#)
 - displaying client information [2-583](#)
 - displaying compatibility matrix [2-585](#)
 - displaying endpoint information [2-590](#)
 - displaying entities [2-591](#)
 - displaying FSM session [2-592](#)
 - displaying messages [2-593](#)
 - displaying negotiated [2-595](#)
 - displaying rollback-timer [2-596](#)
 - displaying session information [2-597](#)
 - displaying software version [2-598](#)
 - displaying state [2-598](#)
 - forcing switchover to standby supervisor engine [2-288](#)
 - initiating an automatic ISSU upgrade procedure [2-282](#)
 - loading new image [2-284](#)
 - starting process [2-286](#)
 - stopping rollback timer [2-280](#)
-
- ## J
- Jumbo frames
 - enabling jumbo frames [2-352](#)
-
- ## L
- LACP
 - deselecting channeling protocol [2-55](#)
 - enabling LACP on an interface [2-55](#)
 - setting channeling protocol [2-55](#)
 - lacp port-priority command [2-298](#)
 - lacp system-priority command [2-299](#)
 - Layer 2
 - displaying ACL configuration [2-609](#)
 - Layer 2 interface type

- specifying a nontrunking, nontagged single VLAN interface [2-786](#)
- specifying a trunking VLAN interface [2-786](#)
- Layer 2 protocol ports
 - displaying [2-600](#)
- Layer 2 protocol tunneling error recovery [2-296](#)
- Layer 2 switching
 - enabling voice VLANs [2-779](#)
 - modifying switching characteristics [2-779](#)
- Layer 2 traceroute
 - IP addresses [2-817](#)
- Layer 3 switching
 - displaying information about an adjacency table [2-446](#)
 - displaying port status [2-525](#)
 - displaying status of native VLAN tagging [2-525](#)
- link-status event messages
 - disabling
 - globally [2-300, 2-303](#)
 - on an interface [2-301, 2-304](#)
 - enabling
 - globally [2-300, 2-303](#)
 - on an interface [2-301, 2-304](#)
- log buffer
 - show status [2-537](#)
- logging
 - controlling IP ARP packets [2-218](#)

M

- MAB, display information [2-606](#)
- MAB, enable and configure [2-306](#)
- mab command [2-306](#)
- MAC Access Control Lists
 - See MAC ACLs
- MAC ACLs
 - defining extended MAC access list [2-308](#)
 - displaying MAC ACL information [2-703](#)
 - naming an ACL [2-308](#)
- MAC addresses
 - disabling MAC address learning per VLAN [2-315](#)
- MAC address filtering
 - configuring [2-319](#)
 - disabling [2-319](#)
 - enabling [2-319](#)
- MAC address learning on a VLAN, enabling [2-315](#)
- MAC address table
 - adding static entries [2-331](#)
 - clearing dynamic entries [2-82, 2-84](#)
 - displaying dynamic table entry information [2-616](#)
 - displaying entry count [2-614](#)
 - displaying information [2-610](#)
 - displaying interface-based information [2-618](#)
 - displaying multicast information [2-620](#)
 - displaying notification information [2-622](#)
 - displaying protocol-based information [2-624](#)
 - displaying static table entry information [2-626](#)
 - displaying the MAC address aging time [2-612](#)
 - displaying VLAN-based information [2-629](#)
 - enabling authentication bypass [2-157](#)
 - enabling notifications [2-317](#)
 - learning in the protocol buckets [2-312](#)
 - removing static entries [2-331](#)
- mac address-table learning vlan command [2-315](#)
- MAC address tables
 - adding static entries [2-319](#)
 - deleting secure or specific addresses [2-86](#)
 - disabling IGMP snooping on static MAC addresses [2-319](#)
 - removing static entries [2-319](#)
- mac-address-table static [2-319](#)
- MAC address unicast filtering
 - dropping unicast traffic [2-319](#)
- MAC authentication bypass (MAB), display information [2-606](#)
- MAC authorization bypass(MAB), enable and configure [2-306](#)
- macro
 - displaying descriptions [2-330](#)

- macro keywords
 - help strings [2-2](#)
- macros
 - adding a global description [2-330](#)
 - cisco global [2-328](#)
 - system-cpp [2-329](#)
- mapping secondary VLANs to MST instance [2-399](#)
- mapping VLAN(s) to an MST instance [2-199](#)
- match (class-map configuration) command [2-14](#), [2-138](#), [2-139](#), [2-140](#), [2-141](#), [2-334](#), [2-767](#), [2-769](#), [2-771](#), [2-773](#), [2-777](#)
- maximum transmission unit (MTU)
 - displaying the system MTU setting [2-694](#)
 - setting the maximum Layer 2 payload size [2-810](#)
- MD5
 - verifying MD5 signature [2-831](#)
- message digest 5
 - See MD5
- MFIB
 - clearing ip mfib counters [2-79](#)
 - clearing ip mfib fastdrop [2-80](#)
 - displaying all active MFIB routes [2-562](#)
 - displaying MFIB fastdrop table entries [2-564](#)
 - enabling IP MFIB fastdrops [2-255](#)
- MLD
 - configuring snooping
 - last-listener-query-intervals [2-270](#)
 - configuring snooping
 - listener-message-suppression [2-272](#)
 - configuring snooping robustness-variables [2-273](#)
 - configuring topology change notifications [2-275](#)
 - counting snooping last-listener-queries [2-268](#)
 - enabling snooping [2-266](#)
 - enabling snooping on a VLAN [2-276](#)
- MLD snooping
 - displaying [2-579](#)
- modes
 - access-group [2-6](#)
 - show access-group interface [2-445](#), [2-662](#)
 - switching between PVST+, MST, and Rapid PVST [2-738](#)
- See also command modes
- module password clearing [2-66](#)
- module reset
 - resetting a module by toggling the power [2-194](#)
- More-- prompt
 - filter [1-6](#)
 - search [1-7](#)
- MST
 - designating the primary and secondary root [2-747](#)
 - displaying MST protocol information [2-689](#)
 - displaying region configuration information [2-689](#)
 - displaying spanning tree information [2-689](#)
 - entering MST configuration submode [2-741](#)
 - setting configuration revision number [2-418](#)
 - setting path cost and port priority for instances [2-739](#)
 - setting the forward delay timer for all instances [2-743](#)
 - setting the hello-time delay timer for all instances [2-744](#)
 - setting the max-age timer for all instances [2-745](#)
 - setting the MST region name [2-353](#)
 - specifying the maximum number of hops [2-746](#)
 - switching between PVST+ and Rapid PVST [2-738](#)
 - using the MST configuration submode revision command [2-418](#)
 - using the submode name command [2-353](#)
- MTU
 - displaying global MTU settings [2-694](#)
- multi-auth, setting [2-25](#)
- Multicast Listener Discovery
 - See MLD
- multicast
 - counters [2-94](#)
 - enabling storm control [2-766](#)
- multicast/unicast packets
 - prevent forwarding [2-785](#)
- Multicast Forwarding Information Base
 - See MFIB
- multi-domain, setting [2-25](#)
- multiple-character patterns [1-8](#)

Multiple Spanning Tree

See MST

N

native VLAN

- controlling tagging of traffic [2-806](#)
- displaying ports eligible for native tagging [2-705](#)
- displaying ports eligible for tagging [2-705](#)
- enabling tagging on 802.1Q trunk ports [2-842](#)
- specifying the tagging of traffic [2-807](#)

NetFlow

- enabling NetFlow statistics [2-256](#)
- including infer fields in routing statistics [2-256](#)

next-hop

- displaying CEF VLAN information [2-539](#)

no form of a command, using [1-6](#)

NVRAM

- debugging NVRAM activities [2-114](#)

O

open access on a port, enabling [2-27](#)

output

- pattern searches [1-7](#)

P

packet forwarding

- prevent unknown packets [2-785](#)

packet memory failure

- direct switch action upon detection [2-143](#)

packet memory test

- bootup, displaying results [2-476, 2-478](#)
- ongoing, displaying results [2-480](#)

PACL

- access-group mode [2-6](#)

paging prompt

see --More-- prompt

PAGP

- clearing port channel information [2-85](#)
- debugging PAGP activity [2-115](#)
- deselecting channeling protocol [2-55](#)
- displaying port channel information [2-635](#)
- hot standby mode
 - returning to defaults [2-355](#)
 - selecting ports [2-355](#)
- input interface of incoming packets
 - learning [2-354](#)
 - returning to defaults [2-354](#)
- setting channeling protocol [2-55](#)

parentheses [1-11](#)

password

- clearing on an intelligent line module [2-66](#)
- establishing enhanced password security [2-829](#)
- setting username [2-829](#)

PBR

- displaying route maps [1-xx](#)
- redistributing route maps [1-xx](#)

PM activities

- debugging [2-118](#)
- disabling debugging [2-118](#)

PoE policing

- configure on an interface [2-386](#)

PoE policing and monitoring

- displaying status [2-661](#)

police (percent) command [2-366](#)

police (two rates) command [2-368, 2-370](#)

police command [2-361](#)

policing, configure PoE [2-386](#)

policing and monitoring status

- displaying PoE [2-661](#)

Policy Based Routing

See PBR

policy maps

- creating [2-374](#)
- marking [2-428](#)

- See also QoS, hierarchical policies
- traffic classification
 - defining the class
 - defining trust states [2-820](#)
- port, dual-capable
 - selecting the connector [2-343](#)
- Port Aggregation Protocol
 - See PAGP
- port-based authentication
 - displaying debug messages [2-104](#)
 - displaying statistics and status [2-482](#)
 - enabling 802.1X [2-161](#)
 - host modes [2-154](#)
 - manual control of authorization state [2-161](#)
 - periodic re-authentication
 - enabling [2-164](#)
 - re-authenticating 802.1X-enabled ports [2-163](#)
 - switch-to-client frame-retransmission number [2-159](#)
- port channel
 - accessing [2-203](#)
 - creating [2-203](#)
 - displaying information [2-635](#)
 - load distribution method
 - resetting to defaults [2-376](#)
 - setting [2-376](#)
- port control, changing from unidirectional or bidirectional [2-19](#)
- port-control value, configuring [2-31](#)
- port range
 - executing [2-204](#)
- port security
 - debugging ports security [2-119](#)
 - deleting secure or specific addresses [2-86](#)
 - displaying settings for an interface or switch [2-646](#)
 - enabling [2-791](#)
 - filter source IP and MAC addresses [2-262](#)
 - setting action upon security violation [2-791](#)
 - setting the rate limit for bad packets [2-791](#)
 - sticky port [2-791](#)
- Port Trust Device
 - displaying [2-665](#)
- power status
 - displaying inline power [2-653](#)
 - displaying power status [2-653](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-378](#)
 - configuring inline power [2-383](#)
 - configuring power consumption [2-378](#)
 - displaying the SEEPROM [2-504](#)
 - setting inline power state [2-382](#)
- priority command [2-390](#)
- priority-queue command [2-95](#)
- Private VLAN
 - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
 - system [1-5](#)
- protocol tunneling
 - configuring encapsulation rate [2-296](#)
 - disabling [2-291](#)
 - displaying port information [2-600](#)
 - enabling [2-291](#)
 - setting a CoS value for Layer 2 packets [2-293](#)
 - setting a drop threshold for Layer 2 packets [2-294](#)
- PVLANS
 - configuring isolated, primary, and community PVLANS [2-392](#)
 - controlling tagging of native VLAN traffic [2-806](#)
 - disabling sticky-ARP [2-259](#)
 - displaying map information for VLAN SVIs [2-522](#)
 - displaying PVLAN information [2-708](#)
 - enabling interface configuration mode [2-786](#)
 - enabling sticky-ARP [2-259](#)
 - mapping VLANs to the same SVI [2-396](#)
 - specifying host ports [2-786](#)
 - specifying promiscuous ports [2-786](#)
- PVST+

switching between PVST and MST [2-738](#)

Q

QoS

account Layer 2 encapsulation [2-402](#)
 attaching a policy-map to an interface [2-419](#)
 automatic configuration [2-37](#)
 class maps
 defining the match criteria [2-334](#)
 clearing aggregate counters [2-88](#)
 configuring auto [2-37](#)
 displaying aggregate policer information [2-663](#)
 displaying auto configuration [2-454](#)
 displaying class maps information [2-468](#)
 displaying configuration information [2-454](#)
 displaying configurations of policies [2-641](#)
 displaying policy map information [2-637, 2-644](#)
 displaying QoS information [2-662](#)
 displaying QoS map information [2-667](#)
 egress queue-sets
 enabling the priority queue [2-95](#)
 hierarchical policies
 average-rate traffic shaping on a class [2-441](#)
 bandwidth allocation for a class [2-41, 2-59](#)
 creating a service policy [2-422](#)
 marking [2-428](#)
 strict priority queueing (LLQ) [2-390](#)
 policy maps
 creating [2-374](#)
 marking [2-428](#)
 traffic classifications
 trust states [2-820](#)
 setting the trust state [2-404](#)
 specifying flow-based match criteria [2-337](#)
 Supervisor Engine 6-E
 setting CoS [2-430](#)
 setting DSCP [2-433](#)
 setting precedence values [2-436](#)

setting QoS group identifiers [2-439](#)

QoS CoS

configuring for tunneled Layer 2 protocol packets [2-293](#)

quality of service

See QoS

question command [1-1](#)

queueing information

displaying [2-665](#)

queue limiting

configuring packet limits [2-406](#)

R

Rapid PVST

switching between PVST and MST [2-738](#)

re-authenticating 802.1X-enabled ports [2-163](#)

re-authentication

periodic [2-164](#)

set the time [2-166](#)

reauthentication, enabling [2-30](#)

reboots

restoring bindings across [2-223](#)

redundancy

accessing the main CPU [2-408](#)

changing from active to standby supervisor engine [2-412](#)

displaying information [2-669](#)

displaying ISSU config-sync failure information [2-673](#)

displaying redundancy facility information [2-669](#)

displaying RF client list [2-669](#)

displaying RF operational counters [2-669](#)

displaying RF states [2-669](#)

enabling automatic synchronization [2-40](#)

forcing switchover to standby supervisor engine [2-412](#)

mismatched command listing [2-410](#)

set the mode [2-344](#)

- synchronizing the route processor configurations [2-331](#)
- related documentation [1-xix](#)
- remote SPAN
 - See RSPAN
- renew commands
 - ip dhcp snooping database [2-416](#)
- resetting PVLAN trunk
 - setting switchport to trunk [2-786](#)
- retry failed authentication, configuring [2-22](#)
- rj45 connector, selecting the connector [2-343](#)
- ROM monitor mode
 - summary [1-6](#)
- Route Processor Redundancy
 - See redundancy
- RPF
 - disabling IPv4 exists-only checks [2-264](#)
 - enabling IPv4 exists-only checks [2-264](#)
- RPR
 - set the redundancy mode [2-344](#)
- RSPAN
 - converting VLAN to RSPAN VLAN [2-415](#)
 - displaying list [2-710](#)

S

- saving configuration changes [1-11](#)
- secure address, configuring [2-378](#)
- secure ports, limitations [2-792](#)
- server (AAA) alive actions, configuring [2-22](#)
- server (AAA) dead actions, configuring [2-22](#)
- service-policy command (policy-map class) [2-422](#)
- session classification, defining [2-25](#)
- set the redundancy mode [2-344](#)
- sfp connector, selecting the connector [2-343](#)
- shape command [2-441](#)
- show authentication interface command [2-449](#)
- show authentication registration command [2-449](#)
- show authentication sessions command [2-449](#)

- show commands
 - filtering parameters [1-7](#)
 - searching and filtering [1-6](#)
 - show platform commands [1-11](#)
- show energywise command [2-486](#)
- show mab command [2-606](#)
- Simple Network Management Protocol
 - See SNMP
- single-character patterns
 - special characters [1-7](#)
- single-host, setting [2-25](#)
- slaveslot0
 - displaying information on the standby supervisor [2-680](#)
- slot0
 - displaying information about the system [2-682](#)
- SNMP
 - debugging spanning tree activities [2-121](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-717](#)
 - compress SNMP ifIndex table format [2-726](#)
 - disabling globally [2-725](#)
 - disabling on an interface [2-719](#)
 - enabling globally [2-725](#)
 - enabling on an interface [2-719](#)
- informs
 - disabling [2-721](#)
 - enabling [2-721](#)
- traps
 - configuring to send when storm occurs [2-764](#)
 - disabling [2-721](#)
 - enabling [2-721](#)
 - mac-notification
 - adding [2-727](#)
 - removing [2-727](#)
- SPAN commands
 - configuring a SPAN session to monitor [2-346](#)
 - displaying SPAN session information [2-694, 2-766](#)
- SPAN enhancements

- displaying status [2-633](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-633](#)
 - filter ACLs [2-346](#)
 - specify encap type [2-346](#)
 - turn off host learning based on ingress packets [2-346](#)
- special characters
 - anchoring, table [1-10](#)
- SSO [2-344](#)
- standard desktop
 - enabling Cisco-recommended features [2-320](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-322](#)
- sticky address, configuring [2-379](#)
- sticky-ARP
 - disabling on PVLANS [2-259](#)
 - enabling on PVLANS [2-259](#)
- sticky port
 - deleting [2-86](#)
 - enabling security [2-791](#)
- storm control
 - configuring for action when storm occurs [2-764](#)
 - disabling suppression mode [2-493](#)
 - displaying settings [2-692](#)
 - enabling [2-764](#)
 - enabling broadcast [2-764, 2-766](#)
 - enabling multicast [2-764, 2-766](#)
 - enabling suppression mode [2-493](#)
 - enabling timer to recover from error disable [2-186](#)
 - enabling unicast [2-764, 2-766](#)
 - multicast, enabling [2-766](#)
 - setting high and low levels [2-764](#)
 - setting suppression level [2-493](#)
- STP
 - configuring link type for a port [2-736](#)
 - configuring tunneling encapsulation rate [2-296](#)
 - debugging all activities [2-121](#)
 - debugging spanning tree activities [2-121](#)
 - debugging spanning tree BackboneFast events [2-123](#)
 - debugging spanning tree UplinkFast [2-126](#)
 - detecting misconfiguration [2-733](#)
 - displaying active interfaces only [2-684](#)
 - displaying BackboneFast status [2-684](#)
 - displaying bridge status and configuration [2-684](#)
 - displaying spanning tree debug messages [2-121](#)
 - displaying summary of interface information [2-684](#)
 - enabling BPDU filtering by default on all PortFast ports [2-752](#)
 - enabling BPDU filtering on an interface [2-729](#)
 - enabling BPDU guard by default on all PortFast ports [2-754](#)
 - enabling BPDU guard on an interface [2-731](#)
 - enabling extended system ID [2-734](#)
 - enabling loop guard as a default on all ports [2-737](#)
 - enabling PortFast by default on all access ports [2-755](#)
 - enabling PortFast mode [2-750](#)
 - enabling protocol tunneling for [2-291](#)
 - enabling root guard [2-735](#)
 - enabling spanning tree BackboneFast [2-728](#)
 - enabling spanning tree on a per VLAN basis [2-759](#)
 - enabling spanning tree UplinkFast [2-757](#)
 - setting an interface priority [2-756](#)
 - setting drop threshold for [2-294](#)
 - setting pathcost [2-732](#)
 - setting the default pathcost calculation method [2-749](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
 - creating a Layer 3 interface on a VLAN [2-206](#)
- switching characteristics
 - excluding from link-up calculation [2-783](#)
 - modifying [2-783](#)
 - returning to interfaces
 - capture function [2-783](#)
- switchport [2-807](#)
- switchport interfaces
 - displaying status of Layer 3 port [2-525](#)

- displaying status of native VLAN tagging [2-525](#)
- switch shim
 - debugging [2-124](#)
 - disabling debugging [2-124](#)
- switch to router connection
 - enabling Cisco-recommended features [2-324](#)
- switch to switch connection
 - enabling Cisco-recommended features [2-326](#)
- switch virtual interface
 - See SVI
- sw-vlan [2-127](#)
- system prompts [1-5](#)

T

- Tab key
 - command completion [1-1](#)
- tables
 - characters with special meaning [1-7](#)
 - mac access-list extended subcommands [2-308](#)
 - multipliers [1-9](#)
 - relationship between duplex and speed
 - commands [2-762](#)
 - show cable-diagnostics tdr command output
 - fields [2-459](#)
 - show cdp neighbors detail field descriptions [2-467](#)
 - show cdp neighbors field descriptions [2-466](#)
 - show ip dhcp snooping command output [2-450, 2-606](#)
 - show ip interface field descriptions [2-560](#)
 - show policy-map control-plane field
 - descriptions [2-640](#)
 - show vlan command output fields [2-709](#)
 - show vtp command output fields [2-714](#)
 - special characters [1-9](#)
 - special characters used for anchoring [1-10](#)
 - speed command options [2-337, 2-762](#)
 - valid interface types [2-201](#)
- TAC
 - displaying information useful to TAC [2-695](#)

- TCAM
 - debugging spanning tree activities [2-121](#)
- TDR
 - displaying cable diagnostic test results [2-458](#)
 - test condition of copper cables [2-812](#)
- temperature readings
 - displaying information [2-490](#)
- timer information [2-494](#)
- traffic monitor
 - display status [2-606](#)
- traffic shaping
 - enable on an interface [2-443](#)
- traps, enabling [2-721](#)
- trunk encapsulation
 - setting format [2-807](#)
- trunk interfaces
 - displaying trunk interfaces information [2-532](#)
- trust state
 - setting [2-213](#)
- tunnel ports
 - displaying information about Layer 2 protocol [2-600](#)
- TX queues
 - allocating bandwidth [2-822](#)
 - returning to default values [2-822](#)
 - setting priority to high [2-822](#)
 - specifying burst size [2-822](#)
 - specifying traffic rate [2-822](#)

- U
- UDLD
 - displaying administrative and operational
 - status [2-697](#)
 - enabling by default on all fiber interfaces [2-824](#)
 - enabling on an individual interface [2-826](#)
 - preventing a fiber interface from being enabled [2-826](#)
 - resetting all shutdown ports [2-828](#)
 - setting the message timer [2-824](#)
- unicast

counters [2-94](#)

Unidirectional Link Detection

See UDLD

unidirection port control, changing from bidirectional [2-19](#)

unknown multicast traffic, preventing [2-785](#)

unknown unicast traffic, preventing [2-785](#)

user EXEC mode, summary [1-5](#)

username

setting password and privilege level [2-829](#)

V

VACLs

access-group mode [2-6](#)

applying VLAN access maps [2-844](#)

displaying VLAN access map information [2-703](#)

specifying an action in a VLAN access map [2-13](#)

specifying the match clause for a VLAN access-map sequence [2-332](#)

using a VLAN filter [2-844](#)

VLAN

applying an ARP ACL [2-207](#)

configuring [2-833](#)

configuring service policies [2-838](#)

converting to RSPAN VLAN [2-415](#)

displaying CEF information [2-539](#)

displaying CEF next-hop information [2-539](#)

displaying information on switch interfaces [2-550, 2-554](#)

displaying information on VLAN switch interfaces [2-557](#)

displaying information sorted by group IP address [2-550, 2-554](#)

displaying IP address and version information [2-550, 2-554](#)

displaying Layer 2 VLAN information [2-699](#)

displaying statistical information [2-631](#)

displaying VLAN information [2-701](#)

enabling dynamic ARP inspection [2-216](#)

enabling Explicit Host Tracking [2-246](#)

enabling guest per-port [2-152](#)

enabling guest VLAN supplicant [2-146, 2-153](#)

entering VLAN configuration mode [2-838, 2-840](#)

native frames

enabling tagging on all 802.1Q trunk ports [2-842](#)

pruning the list for VTP [2-807](#)

setting the list of allowed [2-807](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

VLAN database

resetting [2-417](#)

VLAN debugging

limiting output [2-102](#)

VLAN link-up calculation

excluding a switch port [2-783](#)

including a switch port [2-783](#)

VLAN manager

debugging [2-127](#)

disabling debugging [2-127](#)

IOS file system error tests

debugging [2-128](#)

disabling debugging [2-128](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

debugging [2-134](#)

VLANs

clearing

counters [2-90](#)

clearing hardware logic [2-68](#)

configuring

internal allocation scheme [2-845](#)

displaying

internal VLAN allocation information [2-706](#)

RSPAN VLANs [2-710](#)

entering VLAN configuration mode [2-840](#)

VMPS

- configuring servers [2-849](#)
- reconfirming dynamic VLAN assignments [2-134](#),
[2-847](#)

voice VLANs

- enabling [2-779](#)

VoIP

- configuring auto-QoS [2-37](#)

VQP

- per-server retry count [2-848](#)
- reconfirming dynamic VLAN assignments [2-134](#),
[2-847](#)

VTP

- configuring the administrative domain name [2-853](#)
- configuring the device in VTP client mode [2-852](#)
- configuring the device in VTP server mode [2-856](#)
- configuring the device in VTP transparent mode [2-857](#)
- configuring tunnel encapsulation rate [2-296](#)
- creating a VTP domain password [2-854](#)
- displaying domain information [2-713](#)
- displaying statistics information [2-713](#)
- enabling protocol tunneling for [2-291](#)
- enabling pruning in the VLAN database [2-855](#)
- enabling VTP version 2 mode [2-858](#)
- modifying the VTP configuration storage file name [2-851](#)
- set drop threshold for [2-294](#)

VTP protocol code

- activating debug messages [2-131](#)
- deactivating debug messages [2-131](#)

W

- Webauth fallback, enabling [2-24](#)

