



INDEX

Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- * matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- _ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

Numerics

- 10-Gigabit Ethernet uplink
 - selecting [2-233](#)
 - showing the mode [2-641, 2-642](#)
- 802.1Q trunk ports and native VLANs [2-1024](#)
- 802.1Q tunnel ports
 - configuring [2-956](#)
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X
 - configuring for multiple hosts [2-182](#)
 - configuring for single host [2-182](#)
 - configuring multiple domains [2-182](#)
 - disabling port control [2-174](#)
 - enabling port control [2-174](#)
- 802.1X Critical Authentication
 - disabling on a port [2-176](#)
 - disabling on a VLAN [2-179](#)
- EAPOL

- disabling send success packets [2-177](#)
- enabling send success packets [2-177](#)
- enabling on a port [2-176](#)
- enabling on a VLAN [2-179](#)
- returning delay time to default setting [2-178](#)
- setting delay time on a port [2-178](#)
- 802.1X critical authentication
 - configure parameters [2-25](#)
- 802.1X critical recovery delay, configuring [2-25](#)
- 802.1X Port Based Authentication
 - debugging 802.1X Port Based Authentication [2-122](#)
 - displaying port based authentication [2-621](#)
 - enabling accounting for authentication sessions [2-4](#)
 - enabling authentication on the system [2-193](#)
 - enabling guest VLAN [2-180](#)
 - enabling guest VLAN supplicant [2-172, 2-181](#)
 - enabling manual control of auth state [2-189](#)
 - enabling periodic re-authentication of the client [2-192](#)
 - initializing re-authentication of dot1x ports [2-191](#)
 - initializing state machines [2-184](#)
 - receive session termination message upon reboot [2-5](#)
 - setting maximum number for EAP requests [2-187](#)
 - setting the reauthentication timer [2-194](#)

A

- aaa authorization network command [2-175](#)
- abbreviating commands
 - context-sensitive help [1-1](#)
- Access Gateway Module
 - connecting to a module [2-22](#)
 - connecting to a remote module [2-533](#)
 - connecting to a specific remote module [2-562](#)

- access-group
 - displaying mac interface [2-756](#)
 - show mode interface [2-475, 2-583, 2-823](#)
- access groups
 - IP [2-6, 2-169](#)
- access lists
 - clearing an access template [2-79](#)
 - defining ARP [2-21](#)
 - displaying ARP information [2-587](#)
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter [2-1026](#)
- access-node-identifier, setting for the switch [2-478](#)
- access-policies, applying using host-mode [2-30](#)
- ACLs
 - access-group mode [2-6](#)
 - balancing hardware regions [2-12](#)
 - capturing control packets [2-8](#)
 - determining ACL hardware programming [2-10](#)
 - disabling hardware statistics [2-227](#)
 - displaying mac access-group interface [2-756](#)
 - enabling hardware statistics [2-227](#)
 - using ACL naming conventions for MAC ACLs [2-358](#)
- action clause
 - specifying drop or forward action in a VACL [2-13](#)
- addresses, configuring a maximum [2-461](#)
- adjacency
 - debugging the adjacency table [2-115](#)
 - disabling the debug facility [2-115](#)
 - displaying information about the adjacency table [2-584](#)
 - displaying IPC table entries [2-115](#)
- aggregate policer
 - displaying information [2-824](#)
- aging time
 - displaying MAC address aging time [2-759](#)
 - MAC address table [2-361](#)
- alarms
 - displaying operational status [2-629](#)
- alternation
 - description [1-10](#)
- anchoring
 - description [1-10](#)
- anycp, show multicast [2-586](#)
- ANCP client
 - port identifier [2-16](#)
 - remote server [2-17](#)
 - set router to become [2-18](#)
- ARP
 - access list, displaying detailed information [2-587](#)
 - defining access-lists [2-21](#)
- ARP inspection
 - enforce certain types of checking [2-251](#)
- ARP packet
 - deny based on DHCP bindings [2-157](#)
 - permit based on DHCP bindings [2-439](#)
- authentication [2-25, 2-32](#)
 - changing the control-direction [2-23](#)
 - configure actions for events
 - configuring the actions [2-26](#)
 - configuring port-control [2-36](#)
 - enabling reauthentication [2-35](#)
 - enabling Webauth fallback [2-29](#)
 - host-mode configuration [2-30](#)
 - setting priority of methods [2-38](#)
 - setting the timer [2-40](#)
 - setting username [2-1011](#)
 - specifying the order of methods [2-33](#)
 - using an MD5-type encryption method [2-1011](#)
 - verifying MD5 signature [2-1013](#)
 - verifying the checksum for Flash memory [2-1013](#)
- authentication control-direction command [2-23](#)
- authentication critical recovery delay command [2-25](#)
- authentication event command [2-26](#)
- authentication fallback command [2-29](#)
- authentication host-mode [2-30](#)
- authentication methods, setting priority [2-38](#)

authentication methods, specifying the order of attempts [2-33](#)
 authentication open command [2-32](#)
 authentication order command [2-33](#)
 authentication periodic command [2-35](#)
 authentication port-control command [2-36](#)
 authentication priority command [2-38](#)
 authentication timer, setting [2-40](#)
 authentication timer command [2-40](#)
 authentication violation command [2-42](#)
 auth fail VLAN
 enable on a port [2-173](#)
 set max number of attempts [2-172](#)
 Auth Manager
 configuring
 authentication timer [2-40](#)
 authorization state
 enabling manual control [2-189](#)
 authorization state of a controlled port [2-189](#)
 automatic installation
 displaying status [2-592](#)
 automatic medium-dependent interface crossover
 See Auto-MDIX
 Auto-MDIX
 disabling [2-406](#)
 enabling [2-406](#)
 auto-negotiate interface speed
 example [2-933](#)
 auto-QoS
 configuring for VoIP [2-44](#)
 displaying configuration [2-593](#)
 average-packet-size (netflow-lite monitor submode) command [2-48](#)

B

baby giants
 displaying the system MTU setting [2-858](#)
 setting the maximum Layer 2 payload size [2-983](#)

BackboneFast
 displaying debugging messages [2-144](#)
 displaying spanning tree status [2-847](#)
 enabling debugging [2-144](#)
 bandwidth command [2-50](#)
 bindings
 store for DHCP snooping [2-263](#)
 BOOT environment variable
 displaying information [2-596](#)
 bootflash
 displaying information [2-594](#)
 BPDUs
 debugging spanning tree activities [2-142](#)
 bridge protocol data units
 See BPDUs
 broadcast suppression level
 configuring [2-934, 2-936](#)
 enabling [2-934, 2-936](#)

C

cable diagnostics
 TDR
 displaying test results [2-597](#)
 testing conditions of copper cables [2-987](#)
 call home
 displaying information [2-599](#)
 e-mailing output [2-58](#)
 entering configuration submode [2-53](#)
 executing [2-58](#)
 manually send test message [2-61](#)
 receiving information [2-56](#)
 sending alert group message [2-59](#)
 submitting information [2-56](#)
 call home destination profiles
 displaying [2-601](#)
 Catalyst 4507R [2-459](#)
 CDP
 configuring tunneling encapsulation rate [2-345](#)

- displaying
 - neighbor information [2-604](#)
- enabling protocol tunneling for [2-340](#)
- set drop threshold for [2-343](#)
- CEF
 - displaying next-hop information [2-678](#)
 - displaying VLAN configuration information [2-678](#)
- chassis
 - displaying
 - chassis MAC address ranges [2-753](#)
 - current and peak traffic meter readings [2-753](#)
 - percentage of backplane utilization [2-753](#)
 - switching clock failure recovery mode [2-753](#)
- circuit-id
 - setting for an interface [2-480](#)
- circuit-id, setting for an interface VLAN range [2-481](#)
- cisco-desktop
 - macro apply [2-370](#)
- Cisco Express Forwarding
 - See CEF
- cisco-phone
 - macro apply [2-372](#)
- cisco-router
 - macro apply [2-374](#)
- cisco-switch
 - macro apply [2-376](#)
- CISP
 - See Client Information Signalling Protocol
- cisp enable command [2-66](#)
- class maps
 - creating [2-70](#)
 - defining the match criteria [2-399](#)
- clear commands
 - clearing Gigabit Ethernet interfaces [2-77](#)
 - clearing IGMP group cache entries [2-86](#)
 - clearing interface counters [2-72](#)
 - clearing IP access lists [2-79, 2-80](#)
 - clearing IP ARP inspection statistics VLAN [2-81](#)
 - clearing IP DHCP snooping database statistics [2-85](#)
 - clearing MFIB counters and routes [2-89](#)
 - clearing MFIB fastdrop entries [2-90](#)
 - clearing PAgP channel information [2-99](#)
 - clearing QoS aggregate counters [2-103](#)
 - clearing VLAN interfaces [2-78](#)
- clear energywise neighbors command [2-74](#)
- clear ip wccp command [2-91](#)
- clear netflow-lite exporter statistics command [2-96](#)
- clear netflow-lite monitor statistics interface command [2-97](#)
- clear nmsp statistics command [2-98](#)
- Client Information Signalling Protocol [2-175](#)
- Client Information Signalling Protocol, enabling [2-66](#)
- CLI string search
 - anchoring [1-10](#)
 - expressions [1-7](#)
 - filtering [1-6](#)
 - multiple-character patterns [1-8](#)
 - multipliers [1-9](#)
 - parentheses for recall [1-11](#)
 - searching outputs [1-6](#)
 - single-character patterns [1-7](#)
 - using [1-6](#)
- command modes
 - accessing privileged EXEC mode [1-5](#)
 - exiting [1-5](#)
 - understanding user EXEC and configuration modes [1-5](#)
- condition interface
 - debugging interface-related activities [2-117](#)
- condition vlan
 - debugging VLAN output [2-120](#)
- configuration, saving [1-11](#)
- configuring
 - root as secondary [2-917](#)
- configuring a SPAN session to monitor
 - limit SPAN source traffic [2-411](#)
- configuring critical recovery [2-25](#)
- configuring forward delay [2-913](#)

- configuring root as primary [2-917](#)
 - CoPP
 - attaching
 - policy map to control plane [2-560](#)
 - displaying
 - policy-map class information [2-797](#)
 - entering configuration mode [2-107](#)
 - removing
 - service policy from control plane [2-560](#)
 - CoS
 - assigning to Layer 2 protocol packets [2-342](#)
 - cos (netflow-lite exporter submode) command [2-109](#)
 - CoS QoS default
 - defining value on an interface [2-509](#)
 - Cost of Service
 - See QoS CoS
 - counter command [2-111](#)
 - counters
 - clearing interface counters [2-72](#)
 - critical authentication, configure 802.1X parameters [2-25](#)
 - critical recovery, configuring 802.1X parameter [2-25](#)
-
- ## D
- DAI
 - clear statistics [2-81](#)
 - DBL
 - displaying qos dbl [2-825](#)
 - enabling DBL globally on the switch [2-510](#)
 - debug commands
 - debugging backup events [2-116](#)
 - debugging DHCP snooping events [2-127](#)
 - debugging DHCP snooping messages [2-128](#)
 - debugging EtherChannel/PAgP/shim [2-123](#)
 - debugging IPC activity [2-126](#)
 - debugging IP DHCP snooping security messages [2-129](#)
 - debugging NVRAM activities [2-133](#)
 - debugging PAgP activities [2-134](#)
 - debugging port manager activities [2-137](#)
 - debugging spanning tree activities [2-142](#)
 - debugging spanning tree backbonefast [2-144](#)
 - debugging spanning tree UplinkFast [2-147](#)
 - debugging supervisor redundancy [2-141](#)
 - debugging VLAN manager activities [2-148](#)
 - displaying monitor activity [2-131](#)
 - displaying the adjacency table [2-115](#)
 - enabling debug dot1x [2-122](#)
 - enabling debugging messages for ISL VLAN IDs [2-151](#)
 - enabling debugging messages for VTP [2-152](#)
 - enabling debugging of UDLD activity [2-153](#)
 - enabling switch shim debugging [2-145](#)
 - enabling VLAN manager file system error tests [2-149](#)
 - limiting debugging output for VLANs [2-120](#)
 - limiting interface debugging output [2-117](#)
 - limiting output for debugging standby state changes [2-118](#)
 - shortcut to the debug condition interface [2-125](#)
 - debugging
 - activity monitoring [2-131](#)
 - DHCP snooping events [2-127](#)
 - DHCP snooping packets [2-128](#)
 - IPC activities [2-126](#)
 - IP DHCP snooping security packets [2-129](#)
 - NVRAM activities [2-133](#)
 - PAgP activities [2-134](#)
 - PAgP shim [2-123](#)
 - PM activities [2-137](#)
 - PPPoE Intermediate Agent [2-139](#)
 - spanning tree BackboneFast events [2-144](#)
 - spanning tree switch shim [2-145](#)
 - spanning tree UplinkFast events [2-147](#)
 - VLAN manager activities [2-148](#)
 - VLAN manager IOS file system error tests [2-149](#)
 - VTP protocol debug messages [2-152](#)
 - debug nmsp command [2-132](#)
 - debug spanning tree switch [2-145](#)

- debug sw-vlan vtp [2-152](#)
 - default CoS value [2-509](#)
 - default form of a command, using [1-6](#)
 - defining egress DSCP-to-CoS mapping [2-516](#)
 - destination (netflow-lite exporter submode) command [2-159](#)
 - DHCP
 - clearing database statistics [2-85](#)
 - DHCP bindings
 - configuring bindings [2-261](#)
 - deny ARP packet based on matches [2-157](#)
 - permit ARP packet based on matches [2-439](#)
 - DHCP snooping
 - clearing binding entries [2-82](#)
 - clearing database [2-84](#)
 - displaying binding table [2-681](#)
 - displaying configuration information [2-679](#)
 - displaying status of DHCP database [2-684](#)
 - displaying status of error detection [2-632](#)
 - enabling DHCP globally [2-260](#)
 - enabling IP source guard [2-302](#)
 - enabling on a VLAN [2-270](#)
 - enabling option 82 [2-265, 2-267](#)
 - enabling option-82 [2-272](#)
 - enabling rate limiting on an interface [2-268](#)
 - enabling trust on an interface [2-269](#)
 - establishing binding configuration [2-261](#)
 - renew binding database [2-535](#)
 - store generated bindings [2-263](#)
 - diagnostic fpga soft-error recover command [2-169](#)
 - diagnostic test
 - bootup packet memory [2-615](#)
 - displaying attributes [2-609](#)
 - display module-based results [2-611](#)
 - running [2-171](#)
 - show results for TDR [2-597](#)
 - testing conditions of copper cables [2-987](#)
 - displaying error disable recovery [2-633](#)
 - displaying inline power status [2-812](#)
 - displaying monitoring activity [2-131](#)
 - displaying PoE policing and monitoring status [2-820](#)
 - displaying SEEPROM information
 - GBIC [2-643](#)
 - displaying SPAN session information [2-858, 2-936](#)
 - document conventions [1-xxii](#)
 - document organization [1-xxi](#)
 - DoS
 - CoPP
 - attaching policy map to control plane [2-560](#)
 - displaying policy-map class information [2-797](#)
 - entering configuration mode [2-107](#)
 - removing service policy from control plane [2-560](#)
 - entering
 - CoPP configuration mode [2-107](#)
 - DOS attack
 - protecting system's resources [2-246](#)
 - dot1x credentials (global configuration) command [2-175](#)
 - drop threshold, Layer 2 protocol tunneling [2-343](#)
 - dscp (netflow-lite exporter submode command [2-196](#)
 - DSCP rewrite for IP packets
 - enable [2-520](#)
 - dual-capable port
 - selecting a connector [2-408](#)
 - duplex mode
 - configuring autonegotiation on an interface [2-198](#)
 - configuring full duplex on an interface [2-198](#)
 - configuring half duplex on an interface [2-198](#)
 - dynamic ARP inspection
 - preventing [2-246](#)
 - Dynamic Buffer Limiting
 - See DBL
 - Dynamic Host Configuration Protocol
 - See DHCP
-
- ## E
- EAP
 - restarting authentication process [2-187](#)

- EDCS-587028 [2-588, 2-753](#)
 - EIGRP (Enhanced IGRP)
 - filters
 - routing updates, preventing [2-436](#)
 - enabling
 - debugging for UDLD [2-153](#)
 - voice VLANs [2-949](#)
 - enabling open access [2-32](#)
 - EnergyWise
 - display power information through queries [2-207](#)
 - display setting, status of entity and PoE ports [2-625](#)
 - on an entity
 - enable, assign to domain, and set password [2-205](#)
 - on an entity, enable and configure [2-200](#)
 - on a PoE port
 - configuring on PoE port [2-202](#)
 - energywise (global configuration) command [2-200, 2-202](#)
 - energywise domain command [2-205](#)
 - EnergyWise neighbor table, deleting [2-74](#)
 - energywise query command [2-207](#)
 - environmental
 - alarms [2-629](#)
 - displaying information [2-629](#)
 - status [2-629](#)
 - temperature [2-629](#)
 - epm access control command [2-211](#)
 - erase a file [2-212](#)
 - error disable detection
 - clearing error disable on an interface [2-75](#)
 - enabling error disable detection [2-75, 2-215](#)
 - enabling per-VLAN on BPDU guard [2-215](#)
 - error-disabled state
 - displaying [2-662](#)
 - error disable recovery
 - configuring recovery mechanism variables [2-217](#)
 - displaying recovery timer information [2-633](#)
 - enabling ARP inspection timeout [2-217](#)
 - specifying recovery cause [2-217](#)
 - EtherChannel
 - assigning interfaces to EtherChannel groups [2-62](#)
 - debugging EtherChannel [2-123](#)
 - debugging PAgP shim [2-123](#)
 - debugging spanning tree activities [2-142](#)
 - displaying information for a channel [2-635](#)
 - removing interfaces from EtherChannel groups [2-62](#)
 - EtherChannel guard
 - detecting STP misconfiguration [2-903](#)
 - Explicit Host Tracking
 - clearing the database [2-88](#)
 - enabling per-VLAN [2-284](#)
 - exporter (netflow-lite monitor submode) command [2-222](#)
 - expressions
 - matching multiple expression occurrences [1-9](#)
 - multiple-character patterns [1-8](#)
 - multiplying pattern occurrence [1-11](#)
 - single-character patterns [1-7](#)
 - Extensible Authentication Protocol
 - See EAP
-
- ## F
- fallback profile, specifying [2-29](#)
 - field replaceable unit (FRU)
 - displaying status information [2-629](#)
 - filters
 - EIGRP
 - routing updates, preventing [2-436](#)
 - Flash memory file system
 - displaying file system information [2-594](#)
 - verifying checksum [2-1013](#)
 - flow control
 - configuring a gigabit interface for pause frames [2-224](#)
 - displaying per-interface statistics for flow control [2-639](#)
-
- ## G
- GBIC

displaying SEEPROM information [2-643](#)
 generic-error-message, setting for the switch [2-478](#)
 Gigabit Ethernet interface
 clearing the hardware logic [2-77](#)
 Gigabit Ethernet uplink
 selecting [2-233](#)
 showing the mode [2-641, 2-642](#)
 global configuration mode
 using [1-5](#)

H

hardware module
 resetting a module by toggling the power [2-229](#)
 hardware statistics
 disabling [2-227](#)
 enabling [2-227](#)
 hardware uplink
 selecting the mode [2-233](#)
 showing the mode [2-641, 2-642](#)
 helper addresses, IP [2-699](#)
 hot standby protocol
 debugging [2-118](#)
 disabling debugging [2-118](#)
 limiting output [2-118](#)
 hw-module system max-queue-limit command [2-230](#)
 hw-module uplink mode shared-backplane
 command [2-231](#)

I

identifier-string, setting for the switch [2-478](#)
 ID mapping, creating an ANCP client [2-16](#)
 IDPROMs
 displaying SEEPROM information
 chassis [2-643](#)
 clock module [2-643](#)
 fan trays [2-643](#)
 module [2-643](#)

 mux buffer [2-643](#)
 power supplies [2-643](#)
 supervisor engine [2-643](#)
 ifIndex persistence
 clearing SNMP ifIndex commands [2-885](#)
 compress SNMP ifIndex table format [2-892](#)
 disabling globally [2-891](#)
 disabling on an interface [2-887](#)
 enabling globally [2-891](#)
 enabling on an interface [2-887](#)

IGMP

 applying filters for host joining on Layer 2
 interfaces [2-274](#)
 clearing IGMP group cache entries [2-86](#)
 configuring frequency for IGMP host-query
 messages [2-277](#)
 creating an IGMP profile [2-276](#)
 displaying IGMP interface configuration
 information [2-686](#)
 displaying profiles [2-688](#)
 setting maximum group numbers [2-275](#)

IGMP profiles

 displaying [2-688](#)

IGMP snooping

 clearing the EHT database [2-88](#)
 configuring a Layer 2 interface as a group
 member [2-290](#)
 configuring a Layer 2 interface as a multicast
 router [2-288](#)
 configuring a static VLAN interface [2-290](#)
 displaying multicast information [2-695](#)
 displaying VLAN information [2-689, 2-693, 2-696](#)
 enabling [2-279](#)
 enabling immediate-leave processing [2-286](#)
 enabling on a VLAN [2-283](#)
 enabling per-VLAN Explicit Host Tracking [2-284](#)

informs

 enabling [2-889](#)

inline power

 displaying inline power status [2-812](#)

- In Service Software Upgrade
 - See ISSU
- inspection log
 - clearing log buffer [2-80](#)
- interface
 - displaying suppressed multicast bytes [2-656](#)
- interface capabilities
 - displaying [2-652](#)
- interface configuration mode
 - summary [1-5](#)
- interface link
 - display cable disconnect time [2-659](#)
- interfaces
 - configuring dot1q tunnel ports [2-956](#)
 - creating an interface-range macro [2-156](#)
 - debugging output of interface related activities [2-117](#)
 - displaying description [2-658](#)
 - displaying error-disabled state [2-662](#)
 - displaying information when tunneling is enabled [2-747](#)
 - displaying status [2-658](#)
 - displaying traffic for a specific interface [2-649](#)
 - entering interface configuration mode [2-237](#)
 - executing a command on multiple ports in a range [2-240](#)
 - selecting an interface to configure [2-237](#)
 - setting a CoS value for Layer 2 packets [2-342](#)
 - setting drop threshold for Layer 2 packets [2-343](#)
 - setting the interface type [2-956](#)
- interface speed
 - configuring interface speed [2-931](#)
- interface transceiver
 - displaying diagnostic data [2-666](#)
- internal VLAN allocation
 - configuring [2-1029](#)
 - default setting [2-1029](#)
 - displaying allocation information [2-872](#)
- Internet Group Management Protocol
 - See IGMP
- IP address of remote ANCP server, setting [2-17](#)
- IP ARP
 - applying ARP ACL to VLAN [2-244](#)
 - clearing inspection statistics [2-81](#)
 - clearing status of log buffer [2-80](#)
 - controlling packet logging [2-255](#)
 - enabling dynamic inspection [2-253](#)
 - limit rate of incoming requests [2-246](#)
 - set per-port config trust state [2-250](#)
 - showing status of dynamic ARP inspection [2-673](#)
 - showing status of log buffer [2-676](#)
- IPC
 - debugging IPC activities [2-126](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-301](#)
 - enabling [2-301](#)
- IP interfaces
 - displaying usability status [2-698](#)
- IP multicast
 - displaying multicast routing table information [2-704](#)
- ip multicast multipath command [2-294](#)
- IP packets
 - enable DSCP rewrite [2-520](#)
- IP phone and standard desktop
 - enabling Cisco-recommended features [2-372](#)
- IP Port Security
 - enabling [2-302](#)
- IP source binding
 - adding or deleting [2-298](#)
 - displaying bindingstaggering [2-709](#)
- IP source guard
 - debugging messages [2-129](#)
 - displaying configuration and filters [2-710](#)
 - enabling on DHCP snooping [2-302](#)
- IPv4 statistics, enabling collection [2-111](#)
- IPv6 MLD
 - configuring queries [2-319, 2-321](#)

- configuring snooping
 - last-listener-query-intervals [2-321](#)
- configuring snooping
 - listener-message-suppression [2-323](#)
- configuring snooping robustness-variables [2-324](#)
- configuring tcn topology change notifications [2-326](#)
- counting snooping last-listener-queries [2-319](#)
- displaying information [2-722](#)
- displaying ports for a switch or VLAN [2-724](#)
- displaying querier information [2-725](#)
- enabling snooping [2-317](#)
- enabling snooping on a VLAN [2-327](#)
- IPv6 statistics, enabling collection [2-111](#)
- ip wccp check services all command [2-309](#)
- ip wccp command [2-306](#)
- ip wccp group-address command [2-306](#)
- ip wccp group-list command [2-306](#)
- ip wccp group-listen command [2-311](#)
- ip wccp password command [2-306, 2-308](#)
- ip wccp redirect command [2-313](#)
- ip wccp redirect exclude in command [2-315](#)
- ip wccp redirect-list command [2-306](#)
- ISSU
 - canceling process [2-329](#)
 - configuring rollback timer [2-339](#)
 - displaying capability [2-728](#)
 - displaying client information [2-730](#)
 - displaying compatibility matrix [2-732](#)
 - displaying endpoint information [2-737](#)
 - displaying entities [2-738](#)
 - displaying FSM session [2-739](#)
 - displaying messages [2-740](#)
 - displaying negotiated [2-742](#)
 - displaying rollback-timer [2-743](#)
 - displaying session information [2-744](#)
 - displaying software version [2-745](#)
 - displaying state [2-745](#)
 - forcing switchover to standby supervisor engine [2-337](#)
 - loading new image [2-333](#)

- starting process [2-335](#)
- stopping rollback timer [2-331](#)

J

- Jumbo frames
 - enabling jumbo frames [2-417](#)

L

- LACP
 - deselecting channeling protocol [2-64](#)
 - enabling LACP on an interface [2-64](#)
 - setting channeling protocol [2-64](#)
- lacp system-priority command [2-348](#)
- Layer 2
 - displaying ACL configuration [2-756](#)
- Layer 2 interface type
 - specifying a nontrunking, nontagged single VLAN interface [2-956](#)
 - specifying a trunking VLAN interface [2-956](#)
- Layer 2 protocol ports
 - displaying [2-747](#)
- Layer 2 protocol tunneling error recovery [2-345](#)
- Layer 2 switching
 - enabling voice VLANs [2-949](#)
 - modifying switching characteristics [2-949](#)
- Layer 2 traceroute
 - IP addresses [2-992](#)
- Layer 3 interface, assign counters [2-111](#)
- Layer 3 switching
 - displaying information about an adjacency table [2-584](#)
 - displaying port status [2-664](#)
 - displaying status of native VLAN tagging [2-664](#)
- link-status event messages
 - disabling
 - globally [2-350, 2-353](#)
 - on an interface [2-351, 2-354](#)

- enabling
 - globally [2-350, 2-353](#)
 - on an interface [2-351, 2-354](#)

LLDP

- enabling power negotiation [2-349](#)

lldp tlv-select power-management command [2-349](#)

log buffer

- show status [2-676](#)

logging

- controlling IP ARP packets [2-255](#)

M

MAB, display information [2-753](#)

MAB, enable and configure [2-356](#)

mab command [2-356](#)

MAC Access Control Lists

- See MAC ACLs

MAC ACLs

- defining extended MAC access list [2-358](#)
- displaying MAC ACL information [2-868](#)
- naming an ACL [2-358](#)

MAC addresses

- disabling MAC address learning per VLAN [2-365](#)
- displaying
 - notification settings [2-211, 2-727, 2-767](#)

MAC address filtering

- configuring [2-369](#)
- disabling [2-369](#)
- enabling [2-369](#)

MAC address learning on a VLAN, enabling [2-365](#)

MAC address table

- adding static entries [2-396](#)
- clearing dynamic entries [2-93, 2-95](#)
- configuring aging time [2-361](#)
- displaying dynamic table entry information [2-763](#)
- displaying entry count [2-761](#)
- displaying information [2-757](#)
- displaying interface-based information [2-765](#)

displaying multicast information [2-768](#)

displaying notification information [2-770](#)

displaying protocol-based information [2-772](#)

displaying static table entry information [2-774](#)

displaying the MAC address aging time [2-759](#)

displaying VLAN-based information [2-777](#)

enabling authentication bypass [2-185](#)

enabling notifications [2-367](#)

learning in the protocol buckets [2-362](#)

removing static entries [2-396](#)

mac address-table learning vlan command [2-365](#)

MAC address tables

- adding static entries [2-369](#)
- deleting secure or specific addresses [2-100](#)
- disabling IGMP snooping on static MAC addresses [2-369](#)
- removing static entries [2-369](#)

mac-address-table static [2-369](#)

MAC address unicast filtering

- dropping unicast traffic [2-369](#)

MAC authentication bypass (MAB), display information [2-753](#)

MAC authorization bypass(MAB), enable and configure [2-356](#)

macro

- displaying descriptions [2-395](#)

macro auto global processing command [2-378, 2-380, 2-383, 2-385, 2-387, 2-389, 2-390, 2-392, 2-779](#)

macro keywords

- help strings [2-2](#)

macros

- adding a global description [2-395](#)
- cisco global [2-393](#)
- system-cpp [2-394](#)

mapping secondary VLANs to MST instance [2-494](#)

mapping VLAN(s) to an MST instance [2-235](#)

match (class-map configuration) command [2-14, 2-161, 2-163, 2-165, 2-167, 2-399, 2-937, 2-939, 2-941, 2-943, 2-947](#)

maximum transmission unit (MTU)

- displaying the system MTU setting [2-858](#)

- setting the maximum Layer 2 payload size [2-983](#)
 - MD5
 - verifying MD5 signature [2-1013](#)
 - message digest 5
 - See MD5
 - MFIB
 - clearing ip mfib counters [2-89](#)
 - clearing ip mfib fastdrop [2-90](#)
 - displaying all active MFIB routes [2-701](#)
 - displaying MFIB fastdrop table entries [2-703](#)
 - enabling IP MFIB fastdrops [2-293](#)
 - MLD
 - configuring snooping
 - last-listener-query-intervals [2-321](#)
 - configuring snooping
 - listener-message-suppression [2-323](#)
 - configuring snooping robustness-variables [2-324](#)
 - configuring topology change notifications [2-326](#)
 - counting snooping last-listener-queries [2-319](#)
 - enabling snooping [2-317](#)
 - enabling snooping on a VLAN [2-327](#)
 - MLD snooping
 - displaying [2-725](#)
 - modes
 - access-group [2-6](#)
 - show access-group interface [2-475](#), [2-583](#), [2-823](#)
 - switching between PVST+, MST, and Rapid PVST [2-908](#)
 - See also command modes
 - module password clearing [2-76](#)
 - module reset
 - resetting a module by toggling the power [2-229](#)
 - More-- prompt
 - filter [1-6](#)
 - search [1-7](#)
 - MST
 - designating the primary and secondary root [2-917](#)
 - displaying MST protocol information [2-852](#)
 - displaying region configuration information [2-852](#)
 - displaying spanning tree information [2-852](#)
 - entering MST configuration submode [2-911](#)
 - setting configuration revision number [2-552](#)
 - setting path cost and port priority for instances [2-909](#)
 - setting the forward delay timer for all instances [2-913](#)
 - setting the hello-time delay timer for all instances [2-914](#)
 - setting the max-age timer for all instances [2-915](#)
 - setting the MST region name [2-418](#)
 - specifying the maximum number of hops [2-916](#)
 - switching between PVST+ and Rapid PVST [2-908](#)
 - using the MST configuration submode revision command [2-552](#)
 - using the submode name command [2-418](#)
 - MTU
 - displaying global MTU settings [2-858](#)
 - multi-auth, setting [2-30](#)
 - Multicast Listener Discovery
 - See MLD
 - multicast
 - enabling storm control [2-936](#)
 - show ancp [2-586](#)
 - multicast/unicast packets
 - prevent forwarding [2-955](#)
 - Multicast Forwarding Information Base
 - See MFIB
 - multi-domain, setting [2-30](#)
 - multiple-character patterns [1-8](#)
 - Multiple Spanning Tree
 - See MST
-
- ## N
- native VLAN
 - controlling tagging of traffic [2-976](#)
 - displaying ports eligible for native tagging [2-870](#)
 - displaying ports eligible for tagging [2-870](#)
 - enabling tagging on 802.1Q trunk ports [2-1024](#)
 - specifying the tagging of traffic [2-977](#)
 - NetFlow

- enabling NetFlow statistics [2-296](#)
- including infer fields in routing statistics [2-296](#)
- netflow-lite exporter command [2-419](#)
- netflow-lite monitor command [2-421](#)
- netflow-lite sampler command [2-423](#)
- next-hop
 - displaying CEF VLAN information [2-678](#)
- nmsp attachment suppress command [2-426](#)
- nmsp command [2-425](#)
- no form of a command, using [1-6](#)
- NVRAM
 - debugging NVRAM activities [2-133](#)

O

- open access on a port, enabling [2-32](#)
- options timeout (netflow-lite exporter submode) command [2-220, 2-427](#)
- output
 - pattern searches [1-7](#)

P

- packet counters (statistics)
 - clear for PPPoE Intermediate Agent [2-102](#)
- packet counters, display for PPPoE Intermediate Agent [2-821](#)
- packet forwarding
 - prevent unknown packets [2-955](#)
- packet memory failure
 - direct switch action upon detection [2-170](#)
- packet memory test
 - bootup, displaying results [2-615, 2-617](#)
 - ongoing, displaying results [2-619](#)
- packet-offset (netflow-lite sampler submode) command [2-429](#)
- packet rate (netflow-lite sampler submode) command [2-430](#)
- packet-section size (netflow-lite sampler submode) command [2-432](#)

- PACL
 - access-group mode [2-6](#)
- paging prompt
 - see --More-- prompt
- PAgP
 - clearing port channel information [2-99](#)
 - debugging PAgP activity [2-134](#)
 - deselecting channeling protocol [2-64](#)
 - displaying port channel information [2-794](#)
 - hot standby mode
 - returning to defaults [2-435](#)
 - selecting ports [2-435](#)
 - input interface of incoming packets
 - learning [2-434](#)
 - returning to defaults [2-434](#)
 - setting channeling protocol [2-64](#)
- parentheses [1-11](#)
- password
 - clearing on an intelligent line module [2-76](#)
 - establishing enhanced password security [2-1011](#)
 - setting username [2-1011](#)
- PBR
 - displaying route maps [1-xxii](#)
 - redistributing route maps [1-xxii](#)
- PM activities
 - debugging [2-137](#)
 - disabling debugging [2-137](#)
- PoE policing
 - configure on an interface [2-470](#)
- PoE policing and monitoring
 - displaying status [2-820](#)
- police (percent) command [2-446](#)
- police (two rates) command [2-448, 2-450](#)
- police command [2-441](#)
- policing, configure PoE [2-470](#)
- policing and monitoring status
 - displaying PoE [2-820](#)
- Policy Based Routing
 - See PBR

policy maps

- creating [2-454](#)

- marking [2-564](#)

- See also QoS, hierarchical policies

- traffic classification

- defining the class

- defining trust states [2-999](#)

port, dual-capable

- selecting the connector [2-408](#)

Port Aggregation Protocol

- See PAgP

port-based authentication

- displaying debug messages [2-122](#)

- displaying statistics and status [2-621](#)

- enabling 802.1X [2-189](#)

- host modes [2-182](#)

- manual control of authorization state [2-189](#)

- periodic re-authentication

- enabling [2-192](#)

- re-authenticating 802.1X-enabled ports [2-191](#)

- switch-to-client frame-retransmission number [2-187](#)

port channel

- accessing [2-239](#)

- creating [2-239](#)

- displaying information [2-794](#)

- load distribution method

- resetting to defaults [2-456](#)

- setting [2-456](#)

port-channel standalone-disable command [2-458](#)port control, changing from unidirectional or bidirectional [2-23](#)port-control value, configuring [2-36](#)

port range

- executing [2-240](#)

port security

- debugging ports security [2-138](#)

- deleting secure or specific addresses [2-100](#)

- displaying settings for an interface or switch [2-805](#)

- enabling [2-961](#)

- filter source IP and MAC addresses [2-302](#)

- setting action upon security violation [2-961](#)

- setting the rate limit for bad packets [2-961](#)

- sticky port [2-961](#)

Port Trust Device

- displaying [2-826](#)

- power efficient-ethernet auto command [2-464](#)

- power inline logging global command [2-469](#)

- power negotiation through LLDP, enabling [2-349](#)

- power status

- displaying inline power [2-812](#)

- displaying power status [2-812](#)

power supply

- configuring combined and redundant power on the Catalyst 4507R [2-459](#)

- configuring inline power [2-465](#)

- configuring power consumption [2-459](#)

- displaying the SEEPROM [2-643](#)

- setting inline power state [2-463](#)

PPPoE Discovery

- enable vendor-tag stripping on packets

- enable vendor-tag stripping on Discovery packets [2-484](#)

- PPPoE Discovery packets, limit rate arriving on an interface [2-482](#)

PPPoE Intermediate Agent

- clear statistics (packet counters) [2-102](#)

- debugging [2-139](#)

pppoe intermediate-agent

- enable intermediate agent on a switch [2-474](#)

- enable on an interface VLAN range [2-477](#)

- enable PPPoE Intermediate Agent on an interface [2-475](#)

- enable vendor-tag stripping of Discovery packets [2-484](#)

- format-type (global) [2-478](#)

- limit rate of PPPoE Discovery packets [2-482](#)

- set circuit-id or remote-id for an interface [2-480](#)

- set circuit-id or remote-id for an interface VLAN range [2-481](#)

- set trust configuration on an interface [2-482, 2-483](#)
 - PPPoE Intermediate Agent, display configuration and statistics (packet counters) [2-821](#)
 - priority command [2-485](#)
 - priority-queue command [2-113](#)
 - Private VLAN
 - See PVLANS
 - privileged EXEC mode, summary [1-5](#)
 - prompts
 - system [1-5](#)
 - protocol tunneling
 - configuring encapsulation rate [2-345](#)
 - disabling [2-340](#)
 - displaying port information [2-747](#)
 - enabling [2-340](#)
 - setting a CoS value for Layer 2 packets [2-342](#)
 - setting a drop threshold for Layer 2 packets [2-343](#)
 - PVLANS
 - configuring isolated, primary, and community PVLANS [2-487](#)
 - controlling tagging of native VLAN traffic [2-976](#)
 - disabling sticky-ARP [2-299](#)
 - displaying map information for VLAN SVIs [2-661](#)
 - displaying PVLAN information [2-876](#)
 - enabling interface configuration mode [2-956](#)
 - enabling sticky-ARP [2-299](#)
 - mapping VLANs to the same SVI [2-491](#)
 - specifying host ports [2-956](#)
 - specifying promiscuous ports [2-956](#)
 - PVST+
 - switching between PVST and MST [2-908](#)
-
- ## Q
- QoS
 - account Layer 2 encapsulation [2-501](#)
 - attaching a policy-map to an interface [2-555](#)
 - automatic configuration [2-44](#)
 - class maps
 - creating [2-70](#)
 - defining the match criteria [2-399](#)
 - clearing aggregate counters [2-103](#)
 - configuring auto [2-44](#)
 - defining a named aggregate policer [2-503](#)
 - defining default CoS value [2-509](#)
 - defining ingress CoS-to-DSCP mapping [2-514](#)
 - displaying aggregate policer information [2-824](#)
 - displaying auto configuration [2-593](#)
 - displaying class maps information [2-607](#)
 - displaying configuration information [2-593](#)
 - displaying configurations of policies [2-800](#)
 - displaying policy map information [2-796, 2-803](#)
 - displaying QoS information [2-823](#)
 - displaying QoS map information [2-828](#)
 - egress queue-sets
 - enabling the priority queue [2-113](#)
 - enabling global configuration mode [2-497](#)
 - enabling on control packets [2-506](#)
 - enabling per-VLAN QoS for a Layer 2 interface [2-523](#)
 - enabling QoS on an interface [2-498](#)
 - hierarchical policies
 - average-rate traffic shaping on a class [2-577](#)
 - bandwidth allocation for a class [2-50, 2-69](#)
 - creating a service policy [2-558](#)
 - marking [2-564](#)
 - strict priority queueing (LLQ) [2-485](#)
 - mapping DSCP values to transmit queues [2-516](#)
 - mapping egress DSCP-to-CoS [2-516](#)
 - mapping the DSCP-to-CoS value [2-516](#)
 - policy maps
 - creating [2-454](#)
 - marking [2-564](#)
 - traffic classifications
 - trust states [2-999](#)
 - setting the mapping of policed DSCP values [2-518](#)
 - setting the trust state [2-521](#)
 - specifying flow-based match criteria [2-402](#)

Supervisor Engine 6-E

- setting CoS [2-566](#)
- setting DSCP [2-569](#)
- setting precedence values [2-572](#)
- setting QoS group identifiers [2-575](#)

QoS CoS

- configuring for tunneled Layer 2 protocol packets [2-342](#)
- defining default CoS value [2-509](#)

qos dbl [2-510](#)

quality of service

See QoS

question command [1-1](#)

queueing information

- displaying [2-826](#)

queue limiting

- configuring packet limits [2-525](#)

R

Rapid PVST

- switching between PVST and MST [2-908](#)

re-authenticating 802.1X-enabled ports [2-191](#)

re-authentication

- periodic [2-192](#)
- set the time [2-194](#)

reauthentication, enabling [2-35](#)

reboots

- restoring bindings across [2-261](#)

redundancy

- accessing the main CPU [2-527](#)
- changing from active to standby supervisor engine [2-531](#)
- displaying information [2-830](#)
- displaying ISSU config-sync failure information [2-834](#)
- displaying redundancy facility information [2-830](#)
- displaying RF client list [2-830](#)
- displaying RF operational counters [2-830](#)

displaying RF states [2-830](#)enabling automatic synchronization [2-47](#)forcing switchover to standby supervisor engine [2-531](#)mismatched command listing [2-529](#)set the mode [2-409](#)synchronizing the route processor configurations [2-396](#)related documentation [1-xxi](#)remote-id, setting for an interface [2-480](#)remote-id, setting for an interface VLAN range [2-481](#)

remote SPAN

See RSPAN

renew commands

- ip dhcp snooping database [2-535](#)

rep admin vlan command [2-536](#)rep block port command [2-537](#)rep lsl-age-timer command [2-541](#)rep preempt delay command [2-543](#)rep preempt segment command [2-545](#)rep segment command [2-546](#)rep stcn command [2-549](#)

resetting PVLAN trunk

- setting switchport to trunk [2-956](#)

retry failed authentication, configuring [2-26](#)rj45 connector, selecting the connector [2-408](#)

ROM monitor mode

- summary [1-6](#)

Route Processor Redundancy

See redundancy

router, set to become ANCP client [2-18](#)

RPF

- disabling IPv4 exists-only checks [2-304](#)

- enabling IPv4 exists-only checks [2-304](#)

RPR

- set the redundancy mode [2-409](#)

RSPAN

- converting VLAN to RSPAN VLAN [2-534](#)

- displaying list [2-878](#)

S

- sampler (netflow-lite monitor submode) command [2-553](#)
- saving configuration changes [1-11](#)
- secure address, configuring [2-459](#)
- secure ports, limitations [2-962](#)
- server (AAA) alive actions, configuring [2-26](#)
- server (AAA) dead actions, configuring [2-26](#)
- service-policy command (policy-map class) [2-558](#)
- session classification, defining [2-30](#)
- set the redundancy mode [2-409](#)
- sfp connector, selecting the connector [2-408](#)
- shape command [2-577](#)
- shell trigger command [2-581, 2-840](#)
- show ancp multicast [2-586](#)
- show authentication interface command [2-588](#)
- show authentication registration command [2-588](#)
- show authentication sessions command [2-588](#)
- show commands
 - filtering parameters [1-7](#)
 - searching and filtering [1-6](#)
 - show platform commands [1-11](#)
- show energywise command [2-625](#)
- show ipv6 snooping counters command [2-727](#)
- show ip wccp command [2-713](#)
- show ip wccp detail command [2-713](#)
- show ip wccp view command [2-713](#)
- show mab command [2-753](#)
- show mac address-table learning command [2-211, 2-767](#)
- show netflow-lite exporter command [2-786](#)
- show netflow-lite monitor command [2-788](#)
- show netflow-lite sampler command [2-790](#)
- show nmsp command [2-791](#)
- show vlan group command [2-871](#)
- show vlan mapping command [2-873](#)
- Simple Network Management Protocol
 - See SNMP
- single-character patterns
 - special characters [1-7](#)
- single-host, setting [2-30](#)
- slaveslot0
 - displaying information on the standby supervisor [2-843](#)
- slot0
 - displaying information about the system [2-845](#)
- SNMP
 - debugging spanning tree activities [2-142](#)
 - ifIndex persistence
 - clearing SNMP ifIndex commands [2-885](#)
 - compress SNMP ifIndex table format [2-892](#)
 - disabling globally [2-891](#)
 - disabling on an interface [2-887](#)
 - enabling globally [2-891](#)
 - enabling on an interface [2-887](#)
 - informs
 - disabling [2-889](#)
 - enabling [2-889](#)
 - traps
 - configuring to send when storm occurs [2-934](#)
 - disabling [2-889](#)
 - enabling [2-889](#)
 - mac-notification
 - adding [2-893](#)
 - removing [2-893](#)
- source (netflow-lite exporter submode) command [2-894](#)
- SPAN commands
 - configuring a SPAN session to monitor [2-411](#)
 - displaying SPAN session information [2-858, 2-936](#)
- SPAN enhancements
 - displaying status [2-784](#)
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information [2-784](#)
 - filter ACLs [2-411](#)
 - specify encap type [2-411](#)
 - turn off host learning based on ingress packets [2-411](#)
- special characters

- anchoring, table [1-10](#)
- SSO [2-409](#)
- standard desktop
 - enabling Cisco-recommended features [2-370](#)
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features [2-372](#)
- sticky address, configuring [2-460](#)
- sticky-ARP
 - disabling on PVLANS [2-299](#)
 - enabling on PVLANS [2-299](#)
- sticky port
 - deleting [2-100](#)
 - enabling security [2-961](#)
- storm control
 - configuring for action when storm occurs [2-934](#)
 - disabling suppression mode [2-632](#)
 - displaying settings [2-855](#)
 - enabling [2-934](#)
 - enabling broadcast [2-934, 2-936](#)
 - enabling multicast [2-934, 2-936](#)
 - enabling suppression mode [2-632](#)
 - enabling timer to recover from error disable [2-217](#)
 - enabling unicast [2-934, 2-936](#)
 - multicast, enabling [2-936](#)
 - setting high and low levels [2-934](#)
 - setting suppression level [2-632](#)
- STP
 - configuring link type for a port [2-906](#)
 - configuring tunneling encapsulation rate [2-345](#)
 - debugging all activities [2-142](#)
 - debugging spanning tree activities [2-142](#)
 - debugging spanning tree BackboneFast events [2-144](#)
 - debugging spanning tree UplinkFast [2-147](#)
 - detecting misconfiguration [2-903](#)
 - displaying active interfaces only [2-847](#)
 - displaying BackboneFast status [2-847](#)
 - displaying bridge status and configuration [2-847](#)
 - displaying spanning tree debug messages [2-142](#)
 - displaying summary of interface information [2-847](#)
 - enabling BPDU filtering by default on all PortFast ports [2-922](#)
 - enabling BPDU filtering on an interface [2-899](#)
 - enabling BPDU guard by default on all PortFast ports [2-924](#)
 - enabling BPDU guard on an interface [2-901](#)
 - enabling extended system ID [2-904](#)
 - enabling loop guard as a default on all ports [2-907](#)
 - enabling PortFast by default on all access ports [2-925](#)
 - enabling PortFast mode [2-920](#)
 - enabling protocol tunneling for [2-340](#)
 - enabling root guard [2-905](#)
 - enabling spanning tree BackboneFast [2-898](#)
 - enabling spanning tree on a per VLAN basis [2-929](#)
 - enabling spanning tree UplinkFast [2-927](#)
 - setting an interface priority [2-926](#)
 - setting drop threshold for [2-343](#)
 - setting pathcost [2-902](#)
 - setting the default pathcost calculation method [2-919](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
 - creating a Layer 3 interface on a VLAN [2-242](#)
- switching characteristics
 - excluding from link-up calculation [2-953](#)
 - modifying [2-953](#)
 - returning to interfaces
 - capture function [2-953](#)
- switchport [2-977](#)
- switchport interfaces
 - displaying status of Layer 3 port [2-664](#)
 - displaying status of native VLAN tagging [2-664](#)
- switchport vlan mapping command [2-981](#)
- switch shim
 - debugging [2-145](#)
 - disabling debugging [2-145](#)
- switch to router connection
 - enabling Cisco-recommended features [2-374](#)
- switch to switch connection
 - enabling Cisco-recommended features [2-376](#)

switch virtual interface

See SVI

sw-vlan [2-148](#)

system prompts [1-5](#)

T

Tab key

command completion [1-1](#)

tables

characters with special meaning [1-7](#)

mac access-list extended subcommands [2-358](#)

multipliers [1-9](#)

relationship between duplex and speed
commands [2-932](#)

show cable-diagnostics tdr command output
fields [2-598](#)

show cdp neighbors detail field descriptions [2-606](#)

show cdp neighbors field descriptions [2-605](#)

show ip dhcp snooping command output [2-589, 2-753](#)

show ip interface field descriptions [2-699](#)

show policy-map control-plane field
descriptions [2-799](#)

show vlan command output fields [2-877](#)

show vtp command output fields [2-882](#)

special characters [1-9](#)

special characters used for anchoring [1-10](#)

speed command options [2-402, 2-932](#)

valid interface types [2-237](#)

TAC

displaying information useful to TAC [2-859](#)

TCAM

debugging spanning tree activities [2-142](#)

TDR

displaying cable diagnostic test results [2-597](#)

test condition of copper cables [2-987](#)

temperature readings

displaying information [2-629](#)

template data timeout (netflow-lite exporter submode)

command [2-985](#)

timer information [2-633](#)

traffic monitor

display status [2-753](#)

traffic shaping

enable on an interface [2-579](#)

transport udp (netflow-lite exporter submode)

command [2-995](#)

transport udp load-share (netflow-lite exporter submode)

command [2-997](#)

traps, enabling [2-889](#)

trunk encapsulation

setting format [2-977](#)

trunk interfaces

displaying trunk interfaces information [2-671](#)

trunk port, configuring VLAN mapping [2-981](#)

trunk ports, display VLAN mapping information [2-873](#)

trust configuration, setting on an interface [2-482, 2-483](#)

trust state

setting [2-250](#)

ttl (netflow-lite exporter submode) command [2-1001](#)

tunnel ports

displaying information about Layer 2 protocol [2-747](#)

TX queues

allocating bandwidth [2-1003](#)

returning to default values [2-1003](#)

setting priority to high [2-1003](#)

specifying burst size [2-1003](#)

specifying traffic rate [2-1003](#)

U

UDLD

displaying administrative and operational
status [2-861](#)

enabling by default on all fiber interfaces [2-1005](#)

enabling on an individual interface [2-1007](#)

preventing a fiber interface from being
enabled [2-1007](#)

resetting all shutdown ports [2-1009](#)

setting the message timer [2-1005](#)

Unidirectional Link Detection

See UDLD

unidirection port control, changing from bidirectional [2-23](#)

unknown multicast traffic, preventing [2-955](#)

unknown unicast traffic, preventing [2-955](#)

user EXEC mode, summary [1-5](#)

username

setting password and privilege level [2-1011](#)

V

VACLs

access-group mode [2-6](#)

applying VLAN access maps [2-1026](#)

displaying VLAN access map information [2-868](#)

specifying an action in a VLAN access map [2-13](#)

specifying the match clause for a VLAN access-map sequence [2-397](#)

using a VLAN filter [2-1026](#)

VLAN

applying an ARP ACL [2-244](#)

configuring [2-1015](#)

configuring service policies [2-1020](#)

converting to RSPAN VLAN [2-534](#)

displaying CEF information [2-678](#)

displaying CEF next-hop information [2-678](#)

displaying information on switch interfaces [2-689](#), [2-693](#)

displaying information on VLAN switch interfaces [2-696](#)

displaying information sorted by group IP address [2-689](#), [2-693](#)

displaying IP address and version information [2-689](#), [2-693](#)

displaying Layer 2 VLAN information [2-864](#)

displaying statistical information [2-782](#)

displaying VLAN information [2-866](#)

enabling dynamic ARP inspection [2-253](#)

enabling Explicit Host Tracking [2-284](#)

enabling guest per-port [2-180](#)

enabling guest VLAN supplicant [2-172](#), [2-181](#)

entering VLAN configuration mode [2-1020](#), [2-1022](#)

native frames

enabling tagging on all 802.1Q trunk ports [2-1024](#)

pruning the list for VTP [2-977](#)

setting the list of allowed [2-977](#)

VLAN, create or modify a group [2-1027](#)

VLAN Access Control Lists

See VACLs

VLAN access map

See VACLs

VLAN database

resetting [2-551](#)

VLAN debugging

limiting output [2-120](#)

vlan group command [2-1027](#)

VLAN groups, display VLANs mapped [2-871](#)

VLAN link-up calculation

excluding a switch port [2-953](#)

including a switch port [2-953](#)

VLAN manager

debugging [2-148](#)

disabling debugging [2-148](#)

IOS file system error tests

debugging [2-149](#)

disabling debugging [2-149](#)

VLAN mapping

configuring [2-981](#)

displaying [2-873](#)

VLAN mapping, configure on trunk port [2-981](#)

VLAN mapping on trunk ports, display information [2-873](#)

VLAN Query Protocol

See VQP

VLAN query protocol (VQPC)

debugging [2-155](#)

VLANs

clearing

counters [2-105](#)

- clearing hardware logic [2-78](#)
- configuring
 - internal allocation scheme [2-1029](#)
- displaying
 - internal VLAN allocation information [2-872](#)
 - RSPAN VLANs [2-878](#)
- entering VLAN configuration mode [2-1022](#)

VMPS

- configuring servers [2-1033](#)
- reconfirming dynamic VLAN assignments [2-155](#),
[2-1031](#)

voice VLANs

- enabling [2-949](#)

VoIP

- configuring auto-QoS [2-44](#)

VQP

- per-server retry count [2-1032](#)
- reconfirming dynamic VLAN assignments [2-155](#),
[2-1031](#)

vrf (netflow-lite exporter submode) command [2-1035](#)

VTP

- configuring the administrative domain name [2-1039](#)
- configuring the device in VTP client mode [2-1038](#)
- configuring the device in VTP server mode [2-1042](#)
- configuring the device in VTP transparent mode [2-1043](#)
- configuring tunnel encapsulation rate [2-345](#)
- creating a VTP domain password [2-1040](#)
- displaying domain information [2-881](#)
- displaying statistics information [2-881](#)
- enabling protocol tunneling for [2-340](#)
- enabling pruning in the VLAN database [2-1041](#)
- enabling VTP version 2 mode [2-1044](#)
- modifying the VTP configuration storage file name [2-1037](#)
- set drop threshold for [2-343](#)

VTP protocol code

- activating debug messages [2-152](#)
- deactivating debug messages [2-152](#)

W

- Webauth fallback, enabling [2-29](#)

