



Symbols

- \$ matches the end of a string **1-7**
- () in commands **1-10**
- * matches 0 or more sequences of a pattern **1-7**
- + matches 1 or more sequences of a pattern **1-7**
- . matches any single character **1-7**
- ? command **1-1**
- ? matches 0 or 1 occurrence of a pattern **1-7**
- ^ matches the beginning of a string **1-7**
- _ matches a comma (,), left brace ({), left parenthesis **1-7**
- " **1-10**

Numerics

- 802.1Q trunk ports and native VLANs **2-511**
- 802.1Q tunnel ports
 - configuring **2-470**
- 802.1S Multiple Spanning Tree
 - see MST
- 802.1X Port Based Authentication
 - allowing multiple hosts on a port **2-86**
 - debugging 802.1X Port Based Authentication **2-49**
 - displaying port based authentication **2-264**
 - enabling accounting for authentication sessions **2-3**
 - enabling authentication on the system **2-91**
 - enabling guest VLAN **2-82**
 - enabling manual control of auth state **2-87**
 - enabling periodic re-authentication of the client **2-90**
 - initializing re-authentication of dot1x ports **2-89**
 - initializing state machines **2-83**
 - receive session termination message upon reboot **2-4**
 - setting maximum number for EAP requests **2-85**

A

- abbreviating commands
- context-sensitive help **1-1**
- Access Gateway Module
 - connecting to a module **2-11**
 - connecting to a remote module **2-235**
 - connecting to a specific remote module **2-241**
- access-group
 - displaying mac interface **2-344**
 - show mode interface **2-245**
- access groups
 - IP **2-5**
- access lists
 - clearing an access template **2-26**
 - defining ARP **2-10**
 - displaying ARP information **2-246**
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter **2-512**
- ACLs
 - access-group mode **2-5**
 - determining ACL hardware programming **2-6**
 - displaying mac access-group interface **2-344**
 - using ACL naming conventions for MAC ACLs **2-165**
- action clause
 - specifying drop or forward action in a VACL **2-8**
- adjacency
 - debugging the adjacency table **2-43**
 - disabling the debug facility **2-43**
 - displaying IPC table entries **2-43**
- aggregate policer
 - displaying information **2-377**

- aging time
 displaying MAC address aging time [2-347](#)
 MAC address table [2-168](#)
- alarms
 displaying operational status [2-267](#)
- alternation
 description [1-9](#)
- anchoring
 description [1-10](#)
- ARP
 access list, displaying detailed information [2-246](#)
 defining access-lists [2-10](#)
- ARP inspection
 enforce certain types of checking [2-118](#)
- ARP packet
 deny based on DHCP bindings [2-79](#)
 permit based on DHCP bindings [2-195](#)
- authentication
 setting username [2-502](#)
 using an MD5-type encryption method [2-502](#)
 verifying MD5 signature [2-503](#)
 verifying the checksum for Flash memory [2-503](#)
- authorization state
 enabling manual control [2-87](#)
- authorization state of a controlled port [2-87](#)
- automatic installation
 displaying status [2-247](#)
- auto-negotiate interface speed
 example [2-461](#)
- auto-QoS
 configuring for VoIP [2-12](#)
 displaying configuration [2-248](#)
-
- B**
- baby giants
 displaying the system MTU setting [2-402](#)
 setting the maximum Layer 2 payload size [2-487](#)
- BackboneFast
- displaying debugging messages [2-68](#)
 displaying spanning tree status [2-393](#)
 enabling debugging [2-68](#)
- bindings
 store for DHCP snooping [2-126](#)
- BOOT environment variable
 displaying information [2-252](#)
- bootflash
 displaying information [2-250](#)
- BPDUs
 debugging spanning tree activities [2-67](#)
- bridge protocol data units
 See BPDUs
- broadcast suppression level
 configuring [2-462, 2-464](#)
 enabling [2-462, 2-464](#)
-
- C**
- Catalyst 4507R [2-205](#)
 power redundancy mode [2-207](#)
- CDP
 configuring tunneling encapsulation rate [2-161](#)
 enabling protocol tunneling for [2-157](#)
 set drop threshold for [2-159](#)
- CEF
 displaying next-hop information [2-308](#)
 displaying VLAN configuration information [2-308](#)
- cisco-desktop
 macro apply [2-174](#)
- Cisco Express Forwarding
 See CEF
- cisco-phone
 macro apply [2-176](#)
- cisco-router
 macro apply [2-178](#)
- cisco-switch
 macro apply [2-180](#)

- clear commands
- clearing Gigabit Ethernet interfaces **2-24**
 - clearing IGMP group cache entries **2-31**
 - clearing interface counters **2-21**
 - clearing IP access lists **2-26, 2-27**
 - clearing IP ARP inspection statistics VLAN **2-28**
 - clearing IP DHCP snooping database **2-29**
 - clearing IP DHCP snooping database statistics **2-30**
 - clearing MFIB counters and routes **2-34**
 - clearing MFIB fastdrop entries **2-35**
 - clearing PAgP channel information **2-38**
 - clearing QoS aggregate counters **2-40**
 - clearing VLAN interfaces **2-25**
- CLI string search
- anchoring **1-10**
 - expressions **1-7**
 - filtering **1-6**
 - multiple-character patterns **1-8**
 - multipliers **1-9**
 - parentheses for recall **1-10**
 - searching outputs **1-6**
 - single-character patterns **1-7**
 - using **1-6**
- command modes
- accessing privileged EXEC mode **1-4**
 - exiting **1-4**
 - understanding user EXEC and configuration modes **1-4**
- condition interface
- debugging interface-related activities **2-45**
- condition vlan
- debugging VLAN output **2-48**
- configuration, saving **1-11**
- configuring
- root as secondary **2-445**
- configuring a SPAN session to monitor
- limit SPAN source traffic **2-187**
- configuring forward delay **2-441**
- configuring root as primary **2-445**
- CoS
- assigning to Layer 2 protocol packets **2-158**
 - CoS QoS default
 - defining value on an interface **2-220**
 - Cost of Service
 - See QoS CoS
 - counters
 - clearing interface counters **2-21**
-
- D**
- DAI
- clear statistics **2-28**
- DBL
- displaying qos dbl **2-378**
 - enabling DBL globally on the switch **2-221**
- debug commands
- debugging backup events **2-44**
 - debugging DHCP snooping events **2-54**
 - debugging DHCP snooping messages **2-55**
 - debugging EtherChannel/PAGP/shim **2-50**
 - debugging IPC activity **2-53**
 - debugging IP DHCP snooping security messages **2-56**
 - debugging NVRAM activities **2-59**
 - debugging PAGP activities **2-60**
 - debugging port manager activities **2-63**
 - debugging software MAC filter updates **2-66**
 - debugging spanning tree activities **2-67**
 - debugging spanning tree backbonefast **2-68**
 - debugging spanning tree UplinkFast **2-71**
 - debugging supervisor redundancy **2-65**
 - debugging VLAN manager activities **2-72**
 - displaying monitor activity **2-58**
 - displaying the adjacency table **2-43**
 - enabling debug dot1x **2-49**
 - enabling debugging messages for ISL VLAN IDs **2-74**
 - enabling debugging messages for VTP **2-75**
 - enabling debugging of UDLD activity **2-76**
 - enabling switch shim debugging **2-69**

- enabling VLAN manager file system error tests **2-73**
- limiting debugging output for VLANs **2-48**
- limiting interface debugging output **2-45**
- limiting output for debugging standby state changes **2-46**
- shortcut to the debug condition interface **2-52**
- debugging
 - activity monitoring **2-58**
 - DHCP snooping events **2-54**
 - DHCP snooping packets **2-55**
 - IPC activities **2-53**
 - IP DHCP snooping security packets **2-56**
 - NVRAM activities **2-59**
 - PAgP activities **2-60**
 - PAgP shim **2-50**
 - PM activities **2-63**
 - SMF address insertions and deletions **2-66**
 - spanning tree BackboneFast events **2-68**
 - spanning tree switch shim **2-69**
 - spanning tree UplinkFast events **2-71**
 - VLAN manager activities **2-72**
 - VLAN manager IOS file system error tests **2-73**
 - VTP protocol debug messages **2-75**
 - debug spanning tree switch **2-69**
 - debug sw-vlan vtp **2-75**
 - default CoS value **2-220**
 - default form of a command, using **1-6**
 - defining egress DSCP-to-CoS mapping **2-225**
 - DHCP
 - clearing database statistics **2-30**
 - DHCP bindings
 - configuring bindings **2-125**
 - deny ARP packet based on matches **2-79**
 - permit ARP packet based on matches **2-195**
 - DHCP snooping
 - clearing database **2-29**
 - displaying **2-309**
 - displaying binding table **2-310**
 - displaying status of DHCP database **2-313**
 - displaying status of error detection **2-270**
 - enabling DHCP globally **2-124**
 - enabling IP source guard **2-155**
 - enabling on a VLAN **2-131**
 - enabling option 82 **2-128**
 - enabling rate limiting on an interface **2-129**
 - enabling trust on an interface **2-130**
 - establishing binding configuration **2-125**
 - renew binding database **2-237**
 - store generated bindings **2-126**
 - diagnostic test
 - displaying attributes **2-254**
 - display module-based results **2-256**
 - displaying error disable recovery **2-271**
 - displaying inline power status **2-372**
 - displaying monitoring activity **2-58**
 - displaying EEPROM information
 - GBIC **2-278**
 - displaying SPAN session information **2-401, 2-463**
 - document conventions **xvi**
 - document organization **xv**
 - DOS attack
 - protecting system's resources **2-113**
 - drop threshold, Layer 2 protocol tunneling **2-159**
 - DSCP rewrite for IP packets
 - enable **2-228**
 - dual-capable port
 - selecting a connector **2-184**
 - duplex mode
 - configuring autonegotiation on an interface **2-94**
 - configuring full duplex on an interface **2-94**
 - configuring half duplex on an interface **2-94**
 - dynamic ARP inspection
 - preventing **2-113**
 - Dynamic Buffer Limiting
 - See DBL
 - Dynamic Host Configuration Protocol
 - See DHCP

E

EAP

restarting authentication process **2-85**

enabling

debugging for UDLD **2-76**

voice VLANs **2-465**

environmental

alarms **2-267**

displaying information **2-267**

status **2-267**

temperature **2-267**

error disable detection

enabling error disable detection **2-96**

error-disabled state

displaying **2-294**

error disable recovery

configuring recovery mechanism variables **2-98**

displaying recovery timer information **2-271**

enabling ARP inspection timeout **2-98**

specifying recovery cause **2-98**

EtherChannel

assigning interfaces to EtherChannel groups **2-16**

debugging EtherChannel **2-50**

debugging PAgP shim **2-50**

debugging spanning tree activities **2-67**

displaying information for a channel **2-272**

removing interfaces from EtherChannel groups **2-16**

EtherChannel guard

detecting STP misconfiguration **2-432**

Explicit Host Tracking

clearing the database **2-33**

displaying host membership **2-321**

enabling per-VLAN **2-142**

expressions

matching multiple expression occurrences **1-9**

multiple-character patterns **1-8**

multiplying pattern occurrence **1-10**

single-character patterns **1-7**

Extensible Authentication Protocol

See EAP

F

field replaceable unit (FRU)

displaying status information **2-267**

Flash memory file system

displaying file system information **2-250**

verifying checksum **2-503**

flow control

configuring a gigabit interface for pause frames **2-101**

displaying per-interface statistics for flow control **2-276**

G

GBIC

displaying EEPROM information **2-278**

Gigabit Ethernet interface

clearing the hardware logic **2-24**

global configuration mode

using **1-5**

H

hardware module

resetting a module by toggling the power **2-104**

host membership on an interface

displaying information **2-321**

hot standby protocol

debugging **2-46**

disabling debugging **2-46**

limiting output **2-46**

IDPROMs

displaying EEPROM information

chassis **2-278**

clock module **2-278**

fan trays **2-278**

module **2-278**

mux buffer **2-278**

power supplies **2-278**

supervisor engine **2-278**

ifIndex persistence

clearing SNMP ifIndex commands **2-421**

compress SNMP ifIndex table format **2-426**

disabling globally **2-425**

disabling on an interface **2-422**

enabling globally **2-425**

enabling on an interface **2-422**

IGMP

applying filters for host joining on Layer 2 interfaces **2-133**

clearing IGMP group cache entries **2-31**

configuring frequency for IGMP host-query messages **2-136**

creating an IGMP profile **2-135**

displaying IGMP interface configuration information **2-315**

displaying profiles **2-316**

setting maximum group numbers **2-134**

IGMP profiles

displaying **2-316**

IGMP snooping

clearing the EHT database **2-33**

configuring a Layer 2 interface as a group member **2-146**

configuring a Layer 2 interface as a multicast router **2-144**

configuring a static VLAN interface **2-146**

displaying host membership **2-321**

displaying multicast information **2-323**

displaying VLAN information **2-317, 2-324**

enabling **2-137**

enabling immediate-leave processing **2-143**

enabling on a VLAN **2-141**

enabling per-VLAN Explicit Host Tracking **2-142**

informs

enabling **2-423**

inline power

displaying inline power status **2-372**

inspection log

clearing log buffer **2-27**

interface

displaying suppressed multicast bytes **2-288**

interface capabilities

displaying **2-285**

interface configuration mode

summary **1-5**

interface link

display cable disconnect time **2-291**

interfaces

configuring dot1q tunnel ports **2-470**

creating an interface-range macro **2-78**

debugging output of interface related activities **2-45**

displaying description **2-290**

displaying error-disabled state **2-294**

displaying information when tunneling is enabled **2-338**

displaying status **2-290**

displaying traffic for a specific interface **2-283**

executing a command on multiple ports in a range **2-108**

setting a CoS value for Layer 2 packets **2-158**

setting drop threshold for Layer 2 packets **2-159**

setting the interface type **2-470**

interface speed

configuring interface speed **2-459**

interface transceiver

displaying diagnostic data **2-297**

internal VLAN allocation

configuring **2-513**

default setting **2-513**

displaying allocation information [2-412](#)

Internet Group Management Protocol

See IGMP

IP ARP

applying ARP ACL to VLAN [2-111](#)

clearing inspection statistics [2-28](#)

clearing status of log buffer [2-27](#)

controlling packet logging [2-121](#)

enabling dynamic inspection [2-120](#)

limit rate of incoming requests [2-113](#)

set per-port config trust state [2-117](#)

showing status of dynamic ARP inspection [2-304](#)

showing status of log buffer [2-307](#)

IPC

debugging IPC activities [2-53](#)

IP DHCP Snooping

See DHCP snooping

IP header validation

disabling [2-154](#)

enabling [2-154](#)

IP multicast

displaying multicast routing table information [2-328](#)

IP packets

enable DSCP rewrite [2-228](#)

IP phone and standard desktop

enabling Cisco-recommended features [2-176](#)

IP source binding

adding or deleting [2-151](#)

displaying bindingstaging [2-333](#)

IP source guard

debugging messages [2-56](#)

displaying configuration and filters [2-334](#)

enabling on DHCP snooping [2-155](#)

J

Jumbo frames

enabling jumbo frames [2-191](#)

L

LACP

deselecting channeling protocol [2-18](#)

enabling LACP on an interface [2-18](#)

setting channeling protocol [2-18](#)

Layer 2

displaying ACL configuration [2-344](#)

Layer 2 interface type

specifying a nontrunking, nontagged single VLAN interface [2-470](#)

specifying a trunking VLAN interface [2-470](#)

Layer 2 protocol ports

displaying [2-338](#)

Layer 2 protocol tunneling error recovery [2-161](#)

Layer 2 switching

enabling voice VLANs [2-465](#)

modifying switching characteristics [2-465](#)

Layer 2 traceroute

IP addresses [2-491](#)

Layer 3 switching

displaying port status [2-295](#)

displaying status of native VLAN tagging [2-295](#)

log buffer

show status [2-307](#)

logging

controlling IP ARP packets [2-121](#)

M

MAC Access Control Lists

See MAC ACLs

MAC ACLs

defining extended MAC access list [2-165](#)

displaying MAC ACL information [2-409](#)

naming an ACL [2-165](#)

MAC address filtering

configuring [2-172](#)

disabling [2-172](#)

- enabling **2-172**
- MAC address table
 - adding static entries **2-182**
 - clearing dynamic entries **2-37**
 - configuring aging time **2-168**
 - displaying dynamic table entry information **2-349**
 - displaying entry count **2-348**
 - displaying information **2-345**
 - displaying interface-based information **2-351**
 - displaying multicast information **2-353**
 - displaying protocol-based information **2-355**
 - displaying static table entry information **2-357**
 - displaying the MAC address aging time **2-347**
 - displaying VLAN-based information **2-359**
 - learning in the protocol buckets **2-169**
 - removing static entries **2-182**
- MAC address tables
 - adding static entries **2-172**
 - deleting secure or specific addresses **2-39**
 - disabling IGMP snooping on static MAC addresses **2-172**
 - removing static entries **2-172**
- mac-address-table static **2-172**
- MAC address unicast filtering
 - dropping unicast traffic **2-172**
- macro keywords
 - help strings **2-2**
- mapping secondary VLANs to MST instance **2-212**
- mapping VLAN(s) to an MST instance **2-105**
- match subcommand
 - accessing **2-19**
- maximum transmission unit (MTU)
 - displaying the system MTU setting **2-402**
 - setting the maximum Layer 2 payload size **2-487**
- MD5
 - verifying MD5 signature **2-503**
- message digest 5
 - See MD5
- MFIB
 - clearing ip mfib counters **2-34**
 - clearing ip mfib fastdrop **2-35**
 - displaying all active MFIB routes **2-325**
 - displaying MFIB fastdrop table entries **2-327**
 - enabling IP MFIB fastdrops **2-148**
- modes
 - access-group **2-5**
 - show access-group interface **2-245**
 - switching between PVST+, MST, and Rapid PVST **2-437**
 - See also command modes
- module password clearing **2-23**
- module reset
 - resetting a module by toggling the power **2-104**
- More-- prompt
 - filter **1-6**
 - search **1-7**
- MST
 - designating the primary and secondary root **2-445**
 - displaying MST protocol information **2-398**
 - displaying region configuration information **2-398**
 - displaying spanning tree information **2-398**
 - entering MST configuration submode **2-439**
 - setting configuration revision number **2-239**
 - setting path cost and port priority for instances **2-438**
 - setting the forward delay timer for all instances **2-441**
 - setting the hello-time delay timer for all instances **2-442**
 - setting the max-age timer for all instances **2-443**
 - setting the MST region name **2-192**
 - specifying the maximum number of hops **2-444**
 - switching between PVST+ and Rapid PVST **2-437**
 - using the MST configuration submode revision command **2-239**
 - using the submode name command **2-192**
- MTU
 - displaying global MTU settings **2-402**
- multicast
 - enabling storm control **2-464**

multicast/unicast packets
 prevent forwarding **2-469**
Multicast Forwarding Information Base
 See MFIB
 multiple-character patterns **1-8**
 multiple hosts on authorized port **2-86**
Multiple Spanning Tree
 See MST

N

native VLAN
 controlling tagging of traffic **2-483**
 displaying ports eligible for native tagging **2-411**
 displaying ports eligible for tagging **2-411**
 enabling tagging on 802.1Q trunk ports **2-511**
 specifying the tagging of traffic **2-484**
NetFlow
 enabling NetFlow statistics **2-149**
 including infer fields in routing statistics **2-149**
next-hop
 displaying CEF VLAN information **2-308**
no form of a command, using **1-6**

NVRAM
 debugging NVRAM activities **2-59**

O
output
 pattern searches **1-7**

P
packet forwarding
 prevent unknown packets **2-469**
 packet memory failure
 direct switch action upon detection **2-81**

packet memory test
 bootup, displaying results **2-260**
 ongoing, displaying results **2-262**
PACL
 access-group mode **2-5**
 paging prompt
 see --More-- prompt
PAgP
 clearing port channel information **2-38**
 debugging PAgP activity **2-60**
 deselecting channeling protocol **2-18**
 displaying port channel information **2-365**
 hot standby mode
 returning to defaults **2-194**
 selecting ports **2-194**
 input interface of incoming packets
 learning **2-193**
 returning to defaults **2-193**
 setting channeling protocol **2-18**
 parentheses **1-10**
 password
 clearing on an intelligent line module **2-23**
 establishing enhanced password security **2-502**
 setting username **2-502**
PBR
 displaying route maps **xvi**
 redistributing route maps **xvi**
PM activities
 debugging **2-63**
 disabling debugging **2-63**
Policy Based Routing
 See PBR
port, dual-capable
 selecting the connector **2-184**
Port Aggregation Protocol
 See PAgP
port-based authentication
 displaying debug messages **2-49**
 displaying statistics and status **2-264**

- enabling 802.1X [2-87](#)
- manual control of authorization state [2-87](#)
- multiple hosts on authorized port [2-86](#)
- periodic re-authentication
 - enabling [2-90](#)
 - re-authenticating 802.1X-enabled ports [2-89](#)
 - switch-to-client frame-retransmission number [2-85](#)
- port channel
 - accessing [2-107](#)
 - creating [2-107](#)
 - displaying information [2-365](#)
 - load distribution method
 - resetting to defaults [2-199](#)
 - setting [2-199](#)
- port range
 - executing [2-108](#)
- port security
 - debugging ports security [2-64](#)
 - deleting secure or specific addresses [2-39](#)
 - enabling [2-472](#)
 - filter source IP and MAC addresses [2-155](#)
 - setting action upon security violation [2-472](#)
 - setting the rate limit for bad packets [2-472](#)
 - sticky port [2-472](#)
- Port Trust Device
 - displaying [2-379](#)
- power status
 - displaying inline power [2-372](#)
 - displaying power status [2-372](#)
- power supply
 - configuring combined and redundant power on the Catalyst 4507R [2-205](#)
 - configuring inline power [2-202](#)
 - configuring power consumption [2-204](#)
 - configuring power redundancy on the Catalyst 4507R [2-207](#)
 - displaying the EEPROM [2-278](#)
 - setting inline power state [2-201](#)
- Private VLAN
 - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
 - system [1-5](#)
- protocol tunneling
 - configuring encapsulation rate [2-161](#)
 - disabling [2-157](#)
 - displaying port information [2-338](#)
 - enabling [2-157](#)
 - setting a CoS value for Layer 2 packets [2-158](#)
 - setting a drop threshold for Layer 2 packets [2-159](#)
- PVLANS
 - configuring isolated, primary, and community PVLANS [2-208](#)
 - controlling tagging of native VLAN traffic [2-483](#)
 - disabling sticky-ARP [2-152](#)
 - displaying map information for VLAN SVIs [2-293](#)
 - displaying PVLAN information [2-414](#)
 - enabling interface configuration mode [2-470](#)
 - enabling sticky-ARP [2-152](#)
 - mapping VLANs to the same SVI [2-210](#)
 - specifying host ports [2-470](#)
 - specifying promiscuous ports [2-470](#)
- PVST+
 - switching between PVST and MST [2-437](#)

- Q**
- QoS
 - account Layer 2 encapsulation [2-215](#)
 - attaching a policy-map to an interface [2-240](#)
 - automatic configuration [2-12](#)
 - clearing aggregate counters [2-40](#)
 - configuring a QoS policy map [2-197](#)
 - configuring auto [2-12](#)
 - defining a named aggregate policer [2-217](#)
 - defining default CoS value [2-220](#)
 - defining ingress CoS-to-DSCP mapping [2-224](#)

- displaying aggregate policer information **2-377**
- displaying auto configuration **2-248**
- displaying class maps information **2-253**
- displaying configuration information **2-248**
- displaying configurations of policies **2-368**
- displaying policy map information **2-367**
- displaying QoS information **2-376**
- displaying QoS map information **2-380**
- enabling global configuration mode **2-213**
- enabling per-VLAN QoS for a Layer 2 interface **2-231**
- enabling QoS on an interface **2-214**
- mapping DSCP values to transmit queues **2-225**
- mapping egress DSCP-to-CoS **2-225**
- mapping the DSCP-to-CoS value **2-225**
- setting the mapping of policed DSCP values **2-227**
- setting the trust state **2-229**
- QoS CoS**
 - configuring for tunneled Layer 2 protocol packets **2-158**
 - defining default CoS value **2-220**
- qos dbl** **2-221**
- question command** **1-1**
- queueing information**
 - displaying **2-379**
- R**
 - Rapid PVST**
 - switching between PVST and MST **2-437**
 - re-authenticating 802.1X-enabled ports **2-89**
 - re-authentication
 - periodic **2-90**
 - reboots
 - restoring bindings across **2-125**
 - redundancy
 - accessing the main CPU **2-232**
 - changing from active to standby supervisor engine **2-233**
 - displaying information **2-382**
 - displaying redundancy facility information **2-382**
 - displaying RF client list **2-382**
 - displaying RF operational counters **2-382**
 - displaying RF states **2-382**
 - enabling automatic synchronization **2-15**
 - forcing switchover to standby supervisor engine **2-233**
 - set the mode **2-185**
 - synchronizing the route processor configurations **2-182**
 - related documentation **xv**
 - remote SPAN
 - See RSPAN
 - renew commands
 - ip dhcp snooping database **2-237**
 - resetting PVLAN trunk
 - setting switchport to trunk **2-470**
 - rj45 connector, selecting the connector **2-184**
 - ROM monitor mode
 - summary **1-6**
 - root guard
 - displaying root inconsistency status **2-393**
 - Route Processor Redundancy
 - See redundancy
 - RPR
 - set the redundancy mode **2-185**
 - RSPAN**
 - converting VLAN to RSPAN VLAN **2-236**
 - displaying list **2-416**
 - S**
 - saving configuration changes **1-11**
 - secure ports, limitations **2-473**
 - set the redundancy mode **2-185**
 - sfp connector, selecting the connector **2-184**
 - show commands
 - filtering parameters **1-7**
 - searching and filtering **1-6**
 - show platform commands **1-11**
 - Simple Network Management Protocol
 - See SNMP

- single-character patterns
 - special characters **1-7**
- slaveslot0
 - displaying information on the standby supervisor **2-389**
- slot0
 - displaying information about the system **2-391**
- SMF
 - debugging address insertions and deletions **2-66**
- SNMP
 - debugging spanning tree activities **2-67**
 - ifIndex persistence
 - clearing SNMP ifIndex commands **2-421**
 - compress SNMP ifIndex table format **2-426**
 - disabling globally **2-425**
 - disabling on an interface **2-422**
 - enabling globally **2-425**
 - enabling on an interface **2-422**
 - informs
 - disabling **2-423**
 - enabling **2-423**
 - traps
 - configuring to send when storm occurs **2-462**
 - disabling **2-423**
 - enabling **2-423**
- software MAC filter
 - See SMF
- SPAN commands
 - configuring a SPAN session to monitor **2-187**
 - displaying SPAN session information **2-401, 2-463**
- SPAN enhancements
 - displaying status **2-363**
- Spanning Tree Protocol
 - See STP
- SPAN session
 - displaying session information **2-363**
 - filter ACLs **2-187**
 - specify encapsulation type **2-187**
 - turn off host learning based on ingress packets **2-187**
- special characters
 - anchoring, table **1-10**
- SSO **2-185**
- standard desktop
 - enabling Cisco-recommended features **2-174**
- standard desktop and Cisco IP phone
 - enabling Cisco-recommended features **2-176**
- sticky-ARP
 - disabling on PVLANs **2-152**
 - enabling on PVLANs **2-152**
- sticky port
 - deleting **2-39**
 - enabling security **2-472**
- storm control
 - configuring for action when storm occurs **2-462**
 - disabling suppression mode **2-270**
 - displaying settings **2-400**
 - enabling **2-462**
 - enabling broadcast **2-462, 2-464**
 - enabling multicast **2-462, 2-464**
 - enabling suppression mode **2-270**
 - enabling timer to recover from error disable **2-98**
 - enabling unicast **2-462, 2-464**
 - multicast, enabling **2-464**
 - setting high and low levels **2-462**
 - setting suppression level **2-270**
- STP
 - configuring link type for a port **2-435**
 - configuring tunneling encapsulation rate **2-161**
 - debugging all activities **2-67**
 - debugging spanning tree activities **2-67**
 - debugging spanning tree BackboneFast events **2-68**
 - debugging spanning tree UplinkFast **2-71**
 - detecting misconfiguration **2-432**
 - displaying active interfaces only **2-393**
 - displaying BackboneFast status **2-393**
 - displaying bridge status and configuration **2-393**
 - displaying default path cost method **2-393**
 - displaying spanning tree debug messages **2-67**

displaying status information **2-393**
 displaying status per VLAN **2-393**
 displaying summary of interface information **2-393**
 displaying UplinkFast status **2-393**
 enabling BPDU filtering by default on all PortFast ports **2-450**
 enabling BPDU filtering on an interface **2-428**
 enabling BPDU guard by default on all PortFast ports **2-452**
 enabling BPDU guard on an interface **2-430**
 enabling extended system ID **2-433**
 enabling loop guard as a default on all ports **2-436**
 enabling PortFast by default on all access ports **2-453**
 enabling PortFast mode **2-448**
 enabling protocol tunneling for **2-157**
 enabling root guard **2-434**
 enabling spanning tree BackboneFast **2-427**
 enabling spanning tree on a per VLAN basis **2-457**
 enabling spanning tree UplinkFast **2-455**
 setting an interface priority **2-454**
 setting drop threshold for **2-159**
 setting pathcost **2-431**
 setting the default pathcost calculation method **2-447**
 subinterface configuration mode, summary **1-6**
SVI
 creating a Layer 3 interface on a VLAN **2-110**
switchport **2-484**
 switchport interfaces
 displaying status of Layer 3 port **2-295**
 displaying status of native VLAN tagging **2-295**
 switch shim
 debugging **2-69**
 disabling debugging **2-69**
 switch to router connection
 enabling Cisco-recommended features **2-178**
 switch to switch connection
 enabling Cisco-recommended features **2-180**
 switch virtual interface
 See **SVI**

sw-vlan **2-72**
 system prompts **1-5**

T

Tab key
 command completion **1-1**

tables
 characters with special meaning **1-7**
 mac access-list extended subcommands **2-165**
 match syntax description **2-20**
 multipliers **1-9**
 relationship between duplex and speed commands **2-460**
 show vlan command output fields **2-415**
 show vtp command output fields **2-419**
 special characters **1-9**
 special characters used for anchoring **1-10**
 speed command options **2-460**

TAC
 displaying information useful to TAC **2-403**

TCAM
 debugging spanning tree activities **2-67**

temperature readings
 displaying information **2-267**

timer information **2-271**

traffic shaping
 enable on an interface **2-242**
 traps, enabling **2-423**
 trunk encapsulation
 setting format **2-484**
 trunk interfaces
 displaying trunk interfaces information **2-302**

trust state
 setting **2-117**

tunnel ports
 displaying information about Layer 2 protocol **2-338**

TX queues
 allocating bandwidth **2-494**

returning to default values **2-494**
 setting priority to high **2-494**
 specifying burst size **2-494**
 specifying traffic rate **2-494**

U**UDLD**

enabling by default on all fiber interfaces **2-496**
 enabling on an individual interface **2-498**
 preventing a fiber interface from being enabled **2-498**
 resetting all shutdown ports **2-500**
 setting the message timer **2-496**

Unidirectional Link Detection

See UDLD

unknown multicast traffic, preventing **2-469**
 unknown unicast traffic, preventing **2-469**
 user EXEC mode, summary **1-5**
 username
 setting password and privilege level **2-502**

V**VACLs**

access-group mode **2-5**
 applying VLAN access maps **2-512**
 displaying VLAN access map information **2-409**
 specifying an action in a VLAN access map **2-8**
 specifying the match clause for a VLAN access-map sequence **2-183**
 using a VLAN filter **2-512**

VLAN

applying an ARP ACL **2-111**
 configuring **2-505**
 converting to RSPAN VLAN **2-236**
 displaying CEF information **2-308**
 displaying CEF next-hop information **2-308**
 displaying information on switch interfaces **2-317**

displaying information on VLAN switch interfaces **2-324**
 displaying information sorted by group IP address **2-317**
 displaying IP address and version information **2-317**
 displaying Layer 2 VLAN information **2-406**
 displaying statistical information **2-361**
 displaying VLAN information **2-408**
 enabling dynamic ARP inspection **2-120**
 enabling Explicit Host Tracking **2-142**
 enabling guest per-port **2-82**
 entering VLAN configuration mode **2-509**
 native frames
 enabling tagging on all 802.1Q trunk ports **2-511**

pruning the list for VTP **2-484**
 setting the list of allowed **2-484**

VLAN Access Control Lists

See VACLs
VLAN access map
 See VACLs

VLAN database

resetting **2-238**

VLAN debugging
 limiting output **2-48**

VLAN manager
 debugging **2-72**
 disabling debugging **2-72**
IOS file system error tests
 debugging **2-73**
 disabling debugging **2-73**

VLAN Query Protocol

See VQP
VLAN query protocol (VQPC)
 debugging **2-77**

VLANs
 clearing
 counters **2-41**
 clearing hardware logic **2-25**

configuring
 internal allocation scheme **2-513**

displaying
 internal VLAN allocation information **2-412**
 RSPAN VLANs **2-416**
 entering VLAN configuration mode **2-509**

VMPS
 configuring servers **2-517**
 reconfirming dynamic VLAN assignments **2-515**

voice VLANs
 enabling **2-465**

VoIP
 configuring auto-QoS **2-12**

VQP
 per-server retry count **2-516**
 reconfirming dynamic VLAN assignments **2-515**

VTP
 configuring the administrative domain name **2-521**
 configuring the device in VTP client mode **2-520**
 configuring the device in VTP server mode **2-524**
 configuring the device in VTP transparent mode **2-525**
 configuring tunnel encapsulation rate **2-161**
 creating a VTP domain password **2-522**
 displaying domain information **2-418**
 displaying statistics information **2-418**
 enabling protocol tunneling for **2-157**
 enabling pruning in the VLAN database **2-523**
 enabling VTP version 2 mode **2-526**
 modifying the VTP configuration storage file
 name **2-519**
 set drop threshold for **2-159**

VTP protocol code
 activating debug messages **2-75**
 deactivating debug messages **2-75**

