



## INDEX

---

### Symbols

- \$ matches the end of a string [1-7](#)
- () in commands [1-11](#)
- \* matches 0 or more sequences of a pattern [1-7](#)
- + matches 1 or more sequences of a pattern [1-7](#)
- . matches any single character [1-7](#)
- ? command [1-1](#)
- ? matches 0 or 1 occurrence of a pattern [1-7](#)
- ^ matches the beginning of a string [1-7](#)
- \_ matches a comma (,), left brace ({), left parenthesis [1-7](#)
- “ [1-10](#)

---

### Numerics

- 10-Gigabit Ethernet uplink
  - selecting [2-151](#)
  - showing the mode [2-439, 2-440](#)
- 802.1Q trunk ports and native VLANs [2-765](#)
- 802.1Q tunnel ports
  - configuring [2-707](#)
- 802.1S Multiple Spanning Tree
  - see MST
- 802.1X
  - configuring for multiple hosts [2-119](#)
  - configuring for single host [2-119](#)
  - configuring multiple domains [2-119](#)
  - disabling port control [2-112](#)
  - enabling port control [2-112](#)
- 802.1X Critical Authentication
  - disabling on a port [2-113](#)
  - disabling on a VLAN [2-116](#)
- EAPOL

- disabling send success packets [2-114](#)
- enabling send success packets [2-114](#)
- enabling on a port [2-113](#)
- enabling on a VLAN [2-116](#)
- returning delay time to default setting [2-115](#)
- setting delay time on a port [2-115](#)
- 802.1X Port Based Authentication
  - debugging 802.1X Port Based Authentication [2-74](#)
  - displaying port based authentication [2-423](#)
  - enabling accounting for authentication sessions [2-4](#)
  - enabling authentication on the system [2-130](#)
  - enabling guest VLAN [2-117](#)
  - enabling guest VLAN supplicant [2-110, 2-118](#)
  - enabling manual control of auth state [2-126](#)
  - enabling periodic re-authentication of the client [2-129](#)
  - initializing re-authentication of dot1x ports [2-128](#)
  - initializing state machines [2-121](#)
  - receive session termination message upon reboot [2-5](#)
  - setting maximum number for EAP requests [2-124](#)
  - setting the reauthentication timer [2-131](#)

---

### A

- abbreviating commands
  - context-sensitive help [1-1](#)
- Access Gateway Module
  - connecting to a module [2-17](#)
  - connecting to a remote module [2-363](#)
  - connecting to a specific remote module [2-375](#)
- access-group
  - displaying mac interface [2-544](#)
  - show mode interface [2-395](#)
- access groups

- IP [2-6](#)
  - access lists
    - clearing an access template [2-39](#)
    - defining ARP [2-16](#)
    - displaying ARP information [2-398](#)
    - See also ACLs, MAC ACLs, and VACLs
  - access maps
    - applying with VLAN filter [2-767](#)
  - ACLs
    - access-group mode [2-6](#)
    - balancing hardware regions [2-12](#)
    - capturing control packets [2-8](#)
    - determining ACL hardware programming [2-10](#)
    - disabling hardware statistics [2-146](#)
    - displaying mac access-group interface [2-544](#)
    - enabling hardware statistics [2-146](#)
    - using ACL naming conventions for MAC ACLs [2-249](#)
  - action clause
    - specifying drop or forward action in a VACL [2-13](#)
  - addresses, configuring a maximum [2-324](#)
  - adjacency
    - debugging the adjacency table [2-67](#)
    - disabling the debug facility [2-67](#)
    - displaying information about the adjacency table [2-396](#)
    - displaying IPC table entries [2-67](#)
  - aggregate policer
    - displaying information [2-596](#)
  - aging time
    - displaying MAC address aging time [2-547](#)
    - MAC address table [2-252](#)
  - alarms
    - displaying operational status [2-427](#)
  - alternation
    - description [1-10](#)
  - anchoring
    - description [1-10](#)
  - ARP
    - access list, displaying detailed information [2-398](#)
    - defining access-lists [2-16](#)
    - ARP inspection
      - enforce certain types of checking [2-168](#)
    - ARP packet
      - deny based on DHCP bindings [2-106](#)
      - permit based on DHCP bindings [2-297](#)
    - authentication
      - setting username [2-752](#)
      - using an MD5-type encryption method [2-752](#)
      - verifying MD5 signature [2-754](#)
      - verifying the checksum for Flash memory [2-754](#)
    - auth fail VLAN
      - enable on a port [2-111](#)
      - set max number of attempts [2-110](#)
    - authorization state
      - enabling manual control [2-126](#)
    - authorization state of a controlled port [2-126](#)
    - automatic installation
      - displaying status [2-399](#)
    - automatic medium-dependent interface crossover
      - See Auto-MDIX
    - Auto-MDIX
      - disabling [2-279](#)
      - enabling [2-279](#)
    - auto-negotiate interface speed
      - example [2-695](#)
    - auto-QoS
      - configuring for VoIP [2-18](#)
      - displaying configuration [2-400](#)
- 
- B**
  - baby giants
    - displaying the system MTU setting [2-628](#)
    - setting the maximum Layer 2 payload size [2-732](#)
  - BackboneFast
    - displaying debugging messages [2-93](#)
    - displaying spanning tree status [2-617](#)

- enabling debugging [2-93](#)
  - bandwidth command [2-22](#)
  - bindings
    - store for DHCP snooping [2-178](#)
  - BOOT environment variable
    - displaying information [2-403](#)
  - bootflash
    - displaying information [2-401](#)
  - BPDUs
    - debugging spanning tree activities [2-91](#)
  - bridge protocol data units
    - See BPDUs
  - broadcast
    - counters [2-64](#)
  - broadcast suppression level
    - configuring [2-696, 2-698](#)
    - enabling [2-696, 2-698](#)
- 
- C**
- cable diagnostics
    - TDR
      - displaying test results [2-404](#)
      - testing conditions of copper cables [2-734](#)
  - Catalyst 4507R [2-320](#)
  - CDP
    - configuring tunneling encapsulation rate [2-238](#)
    - displaying
      - neighbor information [2-406](#)
    - enabling protocol tunneling for [2-234](#)
    - set drop threshold for [2-236](#)
  - CEF
    - displaying next-hop information [2-476](#)
    - displaying VLAN configuration information [2-476](#)
  - cisco-desktop
    - macro apply [2-259](#)
  - Cisco Express Forwarding
    - See CEF
  - cisco-phone
    - macro apply [2-261](#)
  - cisco-router
    - macro apply [2-263](#)
  - cisco-switch
    - macro apply [2-265](#)
  - class maps
    - creating [2-32](#)
    - defining the match criteria [2-272](#)
  - clear commands
    - clearing Gigabit Ethernet interfaces [2-37](#)
    - clearing IGMP group cache entries [2-46](#)
    - clearing interface counters [2-34](#)
    - clearing IP access lists [2-39, 2-40](#)
    - clearing IP ARP inspection statistics VLAN [2-41](#)
    - clearing IP DHCP snooping database statistics [2-45](#)
    - clearing MFIB counters and routes [2-49](#)
    - clearing MFIB fastdrop entries [2-50](#)
    - clearing PAgP channel information [2-55](#)
    - clearing QoS aggregate counters [2-58](#)
    - clearing VLAN interfaces [2-38](#)
  - CLI string search
    - anchoring [1-10](#)
    - expressions [1-7](#)
    - filtering [1-6](#)
    - multiple-character patterns [1-8](#)
    - multipliers [1-9](#)
    - parentheses for recall [1-11](#)
    - searching outputs [1-6](#)
    - single-character patterns [1-7](#)
    - using [1-6](#)
  - command modes
    - accessing privileged EXEC mode [1-5](#)
    - exiting [1-5](#)
    - understanding user EXEC and configuration modes [1-5](#)
  - condition interface
    - debugging interface-related activities [2-69](#)
  - condition vlan
    - debugging VLAN output [2-72](#)

- configuration, saving [1-11](#)
  - configuring
    - root as secondary [2-679](#)
  - configuring a SPAN session to monitor
    - limit SPAN source traffic [2-284](#)
  - configuring forward delay [2-675](#)
  - configuring root as primary [2-679](#)
  - CoPP
    - attaching
      - policy map to control plane [2-373](#)
    - displaying
      - policy-map class information [2-573](#)
    - entering configuration mode [2-62](#)
    - removing
      - service policy from control plane [2-373](#)
  - CoS
    - assigning to Layer 2 protocol packets [2-235](#)
  - CoS QoS default
    - defining value on an interface [2-343](#)
  - Cost of Service
    - See QoS CoS
  - counters
    - clearing interface counters [2-34](#)
- 
- D**
- DAI
    - clear statistics [2-41](#)
  - DBL
    - displaying qos dbl [2-597](#)
    - enabling DBL globally on the switch [2-344](#)
  - debug commands
    - debugging backup events [2-68](#)
    - debugging DHCP snooping events [2-79](#)
    - debugging DHCP snooping messages [2-80](#)
    - debugging EtherChannel/PAgP/shim [2-75](#)
    - debugging IPC activity [2-78](#)
    - debugging IP DHCP snooping security messages [2-81](#)
    - debugging NVRAM activities [2-84](#)
    - debugging PAgP activities [2-85](#)
    - debugging port manager activities [2-88](#)
    - debugging spanning tree activities [2-91](#)
    - debugging spanning tree backbonefast [2-93](#)
    - debugging spanning tree UplinkFast [2-96](#)
    - debugging supervisor redundancy [2-90](#)
    - debugging VLAN manager activities [2-97](#)
    - displaying monitor activity [2-83](#)
    - displaying the adjacency table [2-67](#)
    - enabling debug dot1x [2-74](#)
    - enabling debugging messages for ISL VLAN IDs [2-100](#)
    - enabling debugging messages for VTP [2-101](#)
    - enabling debugging of UDLD activity [2-102](#)
    - enabling switch shim debugging [2-94](#)
    - enabling VLAN manager file system error tests [2-98](#)
    - limiting debugging output for VLANs [2-72](#)
    - limiting interface debugging output [2-69](#)
    - limiting output for debugging standby state changes [2-70](#)
    - shortcut to the debug condition interface [2-77](#)
  - debugging
    - activity monitoring [2-83](#)
    - DHCP snooping events [2-79](#)
    - DHCP snooping packets [2-80](#)
    - IPC activities [2-78](#)
    - IP DHCP snooping security packets [2-81](#)
    - NVRAM activities [2-84](#)
    - PAgP activities [2-85](#)
    - PAgP shim [2-75](#)
    - PM activities [2-88](#)
    - spanning tree BackboneFast events [2-93](#)
    - spanning tree switch shim [2-94](#)
    - spanning tree UplinkFast events [2-96](#)
    - VLAN manager activities [2-97](#)
    - VLAN manager IOS file system error tests [2-98](#)
    - VTP protocol debug messages [2-101](#)
  - debug spanning tree switch [2-94](#)

- debug sw-vlan vtp [2-101](#)
  - default CoS value [2-343](#)
  - default form of a command, using [1-6](#)
  - defining egress DSCP-to-CoS mapping [2-350](#)
  - DHCP
    - clearing database statistics [2-45](#)
  - DHCP bindings
    - configuring bindings [2-177](#)
    - deny ARP packet based on matches [2-106](#)
    - permit ARP packet based on matches [2-297](#)
  - DHCP snooping
    - clearing binding entries [2-42](#)
    - clearing database [2-44](#)
    - displaying binding table [2-479](#)
    - displaying configuration information [2-477](#)
    - displaying status of DHCP database [2-482](#)
    - displaying status of error detection [2-430](#)
    - enabling DHCP globally [2-176](#)
    - enabling IP source guard [2-211](#)
    - enabling on a VLAN [2-185](#)
    - enabling option 82 [2-180, 2-182](#)
    - enabling option-82 [2-187](#)
    - enabling rate limiting on an interface [2-183](#)
    - enabling trust on an interface [2-184](#)
    - establishing binding configuration [2-177](#)
    - renew binding database [2-365](#)
    - store generated bindings [2-178](#)
  - diagnostic test
    - bootup packet memory [2-417](#)
    - displaying attributes [2-411](#)
    - display module-based results [2-413](#)
    - running [2-109](#)
    - show results for TDR [2-404](#)
    - testing conditions of copper cables [2-734](#)
  - displaying error disable recovery [2-431](#)
  - displaying inline power status [2-588](#)
  - displaying monitoring activity [2-83](#)
  - displaying SEEPROM information
    - GBIC [2-441](#)
  - displaying SPAN session information [2-627, 2-697](#)
  - document conventions [1-xix](#)
  - document organization [1-xvii](#)
  - DoS
    - CoPP
      - attaching policy map to control plane [2-373](#)
      - displaying policy-map class information [2-573](#)
      - entering configuration mode [2-62](#)
      - removing service policy from control plane [2-373](#)
    - entering
      - CoPP configuration mode [2-62](#)
  - DOS attack
    - protecting system's resources [2-163](#)
  - drop threshold, Layer 2 protocol tunneling [2-236](#)
  - DSCP rewrite for IP packets
    - enable [2-353](#)
  - dual-capable port
    - selecting a connector [2-281](#)
  - duplex mode
    - configuring autonegotiation on an interface [2-133](#)
    - configuring full duplex on an interface [2-133](#)
    - configuring half duplex on an interface [2-133](#)
  - dynamic ARP inspection
    - preventing [2-163](#)
  - Dynamic Buffer Limiting
    - See DBL
  - Dynamic Host Configuration Protocol
    - See DHCP
- 
- ## E
- EAP
    - restarting authentication process [2-124](#)
  - EIGRP (Enhanced IGRP)
    - filters
      - routing updates, preventing [2-294](#)
  - enabling
    - debugging for UDLD [2-102](#)
    - voice VLANs [2-700](#)

## environmental

- alarms [2-427](#)
- displaying information [2-427](#)
- status [2-427](#)
- temperature [2-427](#)

erase a file [2-135](#)

## error disable detection

- enabling error disable detection [2-138](#)

## error-disabled state

- displaying [2-460](#)

## error disable recovery

- configuring recovery mechanism variables [2-140](#)
- displaying recovery timer information [2-431](#)
- enabling ARP inspection timeout [2-140](#)
- specifying recovery cause [2-140](#)

## EtherChannel

- assigning interfaces to EtherChannel groups [2-25](#)
- debugging EtherChannel [2-75](#)
- debugging PAgP shim [2-75](#)
- debugging spanning tree activities [2-91](#)
- displaying information for a channel [2-433](#)
- removing interfaces from EtherChannel groups [2-25](#)

## EtherChannel guard

- detecting STP misconfiguration [2-665](#)

## Explicit Host Tracking

- clearing the database [2-48](#)
- enabling per-VLAN [2-198](#)

## expressions

- matching multiple expression occurrences [1-9](#)
- multiple-character patterns [1-8](#)
- multiplying pattern occurrence [1-11](#)
- single-character patterns [1-7](#)

## Extensible Authentication Protocol

See EAP

---

**F**

## field replaceable unit (FRU)

- displaying status information [2-427](#)

## filters

## EIGRP

- routing updates, preventing [2-294](#)

## Flash memory file system

- displaying file system information [2-401](#)
- verifying checksum [2-754](#)

## flow control

- configuring a gigabit interface for pause frames [2-143](#)
- displaying per-interface statistics for flow control [2-437](#)

---

**G**

## GBIC

- displaying SEEPROM information [2-441](#)

## Gigabit Ethernet interface

- clearing the hardware logic [2-37](#)

## Gigabit Ethernet uplink

- selecting [2-151](#)
- showing the mode [2-439, 2-440](#)

## global configuration mode

- using [1-5](#)

---

**H**

## hardware module

- resetting a module by toggling the power [2-148](#)

## hardware statistics

- disabling [2-146](#)
- enabling [2-146](#)

## hardware uplink

- changing the mode [2-149](#)
- selecting the mode [2-151](#)
- showing the mode [2-439, 2-440](#)

helper addresses, IP [2-497](#)

## hot standby protocol

- debugging [2-70](#)
- disabling debugging [2-70](#)
- limiting output [2-70](#)

## IDPROMs

displaying SEEPROM information

chassis [2-441](#)

clock module [2-441](#)

fan trays [2-441](#)

module [2-441](#)

mux buffer [2-441](#)

power supplies [2-441](#)

supervisor engine [2-441](#)

## ifIndex persistence

clearing SNMP ifIndex commands [2-651](#)

compress SNMP ifIndex table format [2-658](#)

disabling globally [2-657](#)

disabling on an interface [2-653](#)

enabling globally [2-657](#)

enabling on an interface [2-653](#)

## IGMP

applying filters for host joining on Layer 2 interfaces [2-189](#)

clearing IGMP group cache entries [2-46](#)

configuring frequency for IGMP host-query messages [2-192](#)

creating an IGMP profile [2-191](#)

displaying IGMP interface configuration information [2-484](#)

displaying profiles [2-486](#)

setting maximum group numbers [2-190](#)

## IGMP profiles

displaying [2-486](#)

## IGMP snooping

clearing the EHT database [2-48](#)

configuring a Layer 2 interface as a group member [2-202](#)

configuring a Layer 2 interface as a multicast router [2-200](#)

configuring a static VLAN interface [2-202](#)

displaying multicast information [2-493](#)

displaying VLAN information [2-487, 2-491, 2-494](#)

enabling [2-193](#)

enabling immediate-leave processing [2-199](#)

enabling on a VLAN [2-197](#)

enabling per-VLAN Explicit Host Tracking [2-198](#)

## informs

enabling [2-655](#)

## inline power

displaying inline power status [2-588](#)

## In Service Software Upgrade

See ISSU

## inspection log

clearing log buffer [2-40](#)

## interface

displaying suppressed multicast bytes [2-454](#)

## interface capabilities

displaying [2-450](#)

## interface configuration mode

summary [1-5](#)

## interface link

display cable disconnect time [2-457](#)

## interfaces

configuring dot1q tunnel ports [2-707](#)

creating an interface-range macro [2-105](#)

debugging output of interface related activities [2-69](#)

displaying description [2-456](#)

displaying error-disabled state [2-460](#)

displaying information when tunneling is enabled [2-538](#)

displaying status [2-456](#)

displaying traffic for a specific interface [2-447](#)

entering interface configuration mode [2-155](#)

executing a command on multiple ports in a range [2-158](#)

selecting an interface to configure [2-155](#)

setting a CoS value for Layer 2 packets [2-235](#)

setting drop threshold for Layer 2 packets [2-236](#)

setting the interface type [2-707](#)

## interface speed

configuring interface speed [2-693](#)

- interface transceiver
  - displaying diagnostic data [2-464](#)
- internal VLAN allocation
  - configuring [2-768](#)
  - default setting [2-768](#)
  - displaying allocation information [2-640](#)
- Internet Group Management Protocol
  - See IGMP
- IP ARP
  - applying ARP ACL to VLAN [2-161](#)
  - clearing inspection statistics [2-41](#)
  - clearing status of log buffer [2-40](#)
  - controlling packet logging [2-171](#)
  - enabling dynamic inspection [2-170](#)
  - limit rate of incoming requests [2-163](#)
  - set per-port config trust state [2-167](#)
  - showing status of dynamic ARP inspection [2-471](#)
  - showing status of log buffer [2-474](#)
- IPC
  - debugging IPC activities [2-78](#)
- IP DHCP Snooping
  - See DHCP snooping
- IP header validation
  - disabling [2-210](#)
  - enabling [2-210](#)
- IP interfaces
  - displaying usability status [2-496](#)
- IP multicast
  - displaying multicast routing table information [2-502](#)
- IP packets
  - enable DSCP rewrite [2-353](#)
- IP phone and standard desktop
  - enabling Cisco-recommended features [2-261](#)
- IP Port Security
  - enabling [2-211](#)
- IP source binding
  - adding or deleting [2-207](#)
  - displaying bindingstaggering [2-507](#)
- IP source guard
  - debugging messages [2-81](#)
  - displaying configuration and filters [2-509](#)
  - enabling on DHCP snooping [2-211](#)
- IPv6 MLD
  - configuring queries [2-216, 2-218](#)
  - configuring snooping
    - last-listener-query-intervals [2-218](#)
  - configuring snooping
    - listener-message-suppression [2-220](#)
  - configuring snooping robustness-variables [2-221](#)
  - configuring tcn topology change notifications [2-223](#)
  - counting snooping last-listener-queries [2-216](#)
  - displaying information [2-514](#)
  - displaying ports for a switch or VLAN [2-516](#)
  - displaying querier information [2-517](#)
  - enabling snooping [2-214](#)
  - enabling snooping on a VLAN [2-224](#)
- ISSU
  - canceling process [2-226](#)
  - configuring rollback timer [2-233](#)
  - displaying capability [2-519](#)
  - displaying client information [2-521](#)
  - displaying compatibility matrix [2-523](#)
  - displaying endpoint information [2-528](#)
  - displaying entities [2-529](#)
  - displaying FSM session [2-530](#)
  - displaying messages [2-531](#)
  - displaying negotiated [2-533](#)
  - displaying rollback-timer [2-534](#)
  - displaying session information [2-535](#)
  - displaying software version [2-536](#)
  - displaying state [2-536](#)
  - forcing switchover to standby supervisor engine [2-232](#)
  - loading new image [2-229](#)
  - starting process [2-231](#)
  - stopping rollback timer [2-227](#)



**J**

## Jumbo frames

- enabling jumbo frames [2-290](#)

**L**

## LACP

- deselecting channeling protocol [2-27](#)
- enabling LACP on an interface [2-27](#)
- setting channeling protocol [2-27](#)
- setting system-priority [2-241](#)

## Layer 2

- displaying ACL configuration [2-544](#)

## Layer 2 interface type

- specifying a nontrunking, nontagged single VLAN interface [2-707](#)
- specifying a trunking VLAN interface [2-707](#)

## Layer 2 protocol ports

- displaying [2-538](#)

Layer 2 protocol tunneling error recovery [2-238](#)

## Layer 2 switching

- enabling voice VLANs [2-700](#)
- modifying switching characteristics [2-700](#)

## Layer 2 traceroute

- IP addresses [2-739](#)

## Layer 3 switching

- displaying information about an adjacency table [2-396](#)
- displaying port status [2-462](#)
- displaying status of native VLAN tagging [2-462](#)

## link-status event messages

## disabling

- globally [2-243, 2-246](#)
- on an interface [2-244, 2-247](#)

## enabling

- globally [2-243, 2-246](#)
- on an interface [2-244, 2-247](#)

lldp run command [2-242](#)

## log buffer

- show status [2-474](#)

## logging

- controlling IP ARP packets [2-171](#)

**M**

## MAC Access Control Lists

- See MAC ACLs

## MAC ACLs

- defining extended MAC access list [2-249](#)
- displaying MAC ACL information [2-637](#)
- naming an ACL [2-249](#)

## MAC address filtering

- configuring [2-258](#)
- disabling [2-258](#)
- enabling [2-258](#)

## MAC address table

- adding static entries [2-270](#)
- clearing dynamic entries [2-52, 2-54](#)
- configuring aging time [2-252](#)
- displaying dynamic table entry information [2-551](#)
- displaying entry count [2-549](#)
- displaying information [2-545](#)
- displaying interface-based information [2-553](#)
- displaying multicast information [2-555](#)
- displaying notification information [2-557](#)
- displaying protocol-based information [2-559](#)
- displaying static table entry information [2-561](#)
- displaying the MAC address aging time [2-547](#)
- displaying VLAN-based information [2-564](#)
- enabling authentication bypass [2-122](#)
- enabling notifications [2-256](#)
- learning in the protocol buckets [2-253](#)
- removing static entries [2-270](#)

## MAC address tables

- adding static entries [2-258](#)
- deleting secure or specific addresses [2-56](#)

- disabling IGMP snooping on static MAC addresses [2-258](#)
  - removing static entries [2-258](#)
- mac-address-table static [2-258](#)
- MAC address unicast filtering
  - dropping unicast traffic [2-258](#)
- macro
  - displaying descriptions [2-269](#)
- macro keywords
  - help strings [2-2](#)
- macros
  - adding a global description [2-269](#)
  - cisco global [2-267](#)
  - system-cpp [2-268](#)
- mapping secondary VLANs to MST instance [2-333](#)
- mapping VLAN(s) to an MST instance [2-153](#)
- match (class-map configuration) command [2-272](#)
- maximum transmission unit (MTU)
  - displaying the system MTU setting [2-628](#)
  - setting the maximum Layer 2 payload size [2-732](#)
- MD5
  - verifying MD5 signature [2-754](#)
- message digest 5
  - See MD5
- MFIB
  - clearing ip mfib counters [2-49](#)
  - clearing ip mfib fastdrop [2-50](#)
  - displaying all active MFIB routes [2-499](#)
  - displaying MFIB fastdrop table entries [2-501](#)
  - enabling IP MFIB fastdrops [2-204](#)
- MLD
  - configuring snooping
    - last-listener-query-intervals [2-218](#)
  - configuring snooping
    - listener-message-suppression [2-220](#)
  - configuring snooping robustness-variables [2-221](#)
  - configuring topology change notifications [2-223](#)
  - counting snooping last-listener-queries [2-216](#)
  - enabling snooping [2-214](#)
  - enabling snooping on a VLAN [2-224](#)
- MLD snooping
  - displaying [2-517](#)
- modes
  - access-group [2-6](#)
  - show access-group interface [2-395](#)
  - switching between PVST+, MST, and Rapid PVST [2-670](#)
  - See also command modes
- module password clearing [2-36](#)
- module reset
  - resetting a module by toggling the power [2-148](#)
- More-- prompt
  - filter [1-6](#)
  - search [1-7](#)
- MST
  - designating the primary and secondary root [2-679](#)
  - displaying MST protocol information [2-622](#)
  - displaying region configuration information [2-622](#)
  - displaying spanning tree information [2-622](#)
  - entering MST configuration submode [2-673](#)
  - setting configuration revision number [2-367](#)
  - setting path cost and port priority for instances [2-671](#)
  - setting the forward delay timer for all instances [2-675](#)
  - setting the hello-time delay timer for all instances [2-676](#)
  - setting the max-age timer for all instances [2-677](#)
  - setting the MST region name [2-291](#)
  - specifying the maximum number of hops [2-678](#)
  - switching between PVST+ and Rapid PVST [2-670](#)
  - using the MST configuration submode revision command [2-367](#)
  - using the submode name command [2-291](#)
- MTU
  - displaying global MTU settings [2-628](#)
- Multicast Listener Discovery
  - See MLD
- multicast
  - counters [2-64](#)
  - enabling storm control [2-698](#)
- multicast/unicast packets

prevent forwarding [2-706](#)

Multicast Forwarding Information Base

See MFIB

multiple-character patterns [1-8](#)

Multiple Spanning Tree

See MST

## N

native VLAN

controlling tagging of traffic [2-727](#)

displaying ports eligible for native tagging [2-639](#)

displaying ports eligible for tagging [2-639](#)

enabling tagging on 802.1Q trunk ports [2-765](#)

specifying the tagging of traffic [2-728](#)

NetFlow

enabling NetFlow statistics [2-205](#)

including infer fields in routing statistics [2-205](#)

next-hop

displaying CEF VLAN information [2-476](#)

no form of a command, using [1-6](#)

NVRAM

debugging NVRAM activities [2-84](#)

## O

output

pattern searches [1-7](#)

## P

packet forwarding

prevent unknown packets [2-706](#)

packet memory failure

direct switch action upon detection [2-108](#)

packet memory test

bootup, displaying results [2-417, 2-419](#)

ongoing, displaying results [2-421](#)

PACL

access-group mode [2-6](#)

paging prompt

see --More-- prompt

PAGP

clearing port channel information [2-55](#)

debugging PAGP activity [2-85](#)

deselecting channeling protocol [2-27](#)

displaying port channel information [2-570](#)

hot standby mode

returning to defaults [2-293](#)

selecting ports [2-293](#)

input interface of incoming packets

learning [2-292](#)

returning to defaults [2-292](#)

setting channeling protocol [2-27](#)

parentheses [1-11](#)

password

clearing on an intelligent line module [2-36](#)

establishing enhanced password security [2-752](#)

setting username [2-752](#)

PM activities

debugging [2-88](#)

disabling debugging [2-88](#)

police (percent) command [2-304](#)

police (two rates) command [2-306, 2-308](#)

police command [2-299](#)

policy maps

creating [2-312](#)

marking [2-377](#)

See also QoS, hierarchical policies

traffic classification

defining the class

defining trust states [2-742](#)

port, dual-capable

selecting the connector [2-281](#)

Port Aggregation Protocol

See PAGP

port-based authentication

- displaying debug messages [2-74](#)
- displaying statistics and status [2-423](#)
- enabling 802.1X [2-126](#)
- host modes [2-119](#)
- manual control of authorization state [2-126](#)
- periodic re-authentication
  - enabling [2-129](#)
- re-authenticating 802.1X-enabled ports [2-128](#)
- switch-to-client frame-retransmission number [2-124](#)

port channel

- accessing [2-157](#)
- creating [2-157](#)
- displaying information [2-570](#)
- load distribution method
  - resetting to defaults [2-314](#)
  - setting [2-314](#)

port range

- executing [2-158](#)

port security

- debugging ports security [2-89](#)
- deleting secure or specific addresses [2-56](#)
- displaying settings for an interface or switch [2-581](#)
- enabling [2-712](#)
- filter source IP and MAC addresses [2-211](#)
- setting action upon security violation [2-712](#)
- setting the rate limit for bad packets [2-712](#)
- sticky port [2-712](#)

Port Trust Device

- displaying [2-598](#)

power status

- displaying inline power [2-588](#)
- displaying power status [2-588](#)

power supply

- configuring combined and redundant power on the Catalyst 4507R [2-320](#)
- configuring inline power [2-317](#)
- configuring power consumption [2-319](#)
- displaying the SEEPROM [2-441](#)
- setting inline power state [2-316](#)

- priority command [2-325](#)
- priority-queue command [2-65](#)
- Private VLAN
  - See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
  - system [1-5](#)
- protocol tunneling
  - configuring encapsulation rate [2-238](#)
  - disabling [2-234](#)
  - displaying port information [2-538](#)
  - enabling [2-234](#)
  - setting a CoS value for Layer 2 packets [2-235](#)
  - setting a drop threshold for Layer 2 packets [2-236](#)
- PVLANS
  - configuring isolated, primary, and community PVLANS [2-327](#)
  - controlling tagging of native VLAN traffic [2-727](#)
  - disabling sticky-ARP [2-208](#)
  - displaying map information for VLAN SVIs [2-459](#)
  - displaying PVLAN information [2-642](#)
  - enabling interface configuration mode [2-707](#)
  - enabling sticky-ARP [2-208](#)
  - mapping VLANs to the same SVI [2-331](#)
  - specifying host ports [2-707](#)
  - specifying promiscuous ports [2-707](#)
- PVST+
  - switching between PVST and MST [2-670](#)

---

## Q

### QoS

- account Layer 2 encapsulation [2-336](#)
- attaching a policy-map to an interface [2-368](#)
- automatic configuration [2-18](#)
- class maps
  - creating [2-32](#)
  - defining the match criteria [2-272](#)
- clearing aggregate counters [2-58](#)

- configuring auto [2-18](#)
- defining a named aggregate policer [2-338](#)
- defining default CoS value [2-343](#)
- defining ingress CoS-to-DSCP mapping [2-348](#)
- displaying aggregate policer information [2-596](#)
- displaying auto configuration [2-400](#)
- displaying class maps information [2-409](#)
- displaying configuration information [2-400](#)
- displaying configurations of policies [2-576](#)
- displaying policy map information [2-572, 2-579](#)
- displaying QoS information [2-595](#)
- displaying QoS map information [2-600](#)
- egress queue-sets
  - enabling the priority queue [2-65](#)
- enabling global configuration mode [2-334](#)
- enabling on control packets [2-341](#)
- enabling per-VLAN QoS for a Layer 2 interface [2-356](#)
- enabling QoS on an interface [2-335](#)
- hierarchical policies
  - average-rate traffic shaping on a class [2-388](#)
  - bandwidth allocation for a class [2-22, 2-31](#)
  - creating a service policy [2-371](#)
  - marking [2-377](#)
  - strict priority queueing (LLQ) [2-325](#)
- mapping DSCP values to transmit queues [2-350](#)
- mapping egress DSCP-to-CoS [2-350](#)
- mapping the DSCP-to-CoS value [2-350](#)
- policy maps
  - creating [2-312](#)
  - marking [2-377](#)
  - traffic classifications
  - trust states [2-742](#)
- setting the mapping of policed DSCP values [2-352](#)
- setting the trust state [2-354](#)
- specifying flow-based match criteria [2-275](#)
- Supervisor Engine 6-E
  - setting CoS [2-379](#)
  - setting DSCP [2-381](#)

- setting precedence values [2-384](#)
  - setting QoS group identifiers [2-387](#)
- QoS CoS
  - configuring for tunneled Layer 2 protocol packets [2-235](#)
  - defining default CoS value [2-343](#)
- qos dbl [2-344](#)
- quality of service
  - See QoS
- question command [1-1](#)
- queueing information
  - displaying [2-598](#)

---

## R

- Rapid PVST
  - switching between PVST and MST [2-670](#)
- re-authenticating 802.1X-enabled ports [2-128](#)
- re-authentication
  - periodic [2-129](#)
  - set the time [2-131](#)
- reboots
  - restoring bindings across [2-177](#)
- redundancy
  - accessing the main CPU [2-358](#)
  - changing from active to standby supervisor engine [2-361](#)
  - displaying information [2-602](#)
  - displaying ISSU config-sync failure information [2-606](#)
  - displaying redundancy facility information [2-602](#)
  - displaying RF client list [2-602](#)
  - displaying RF operational counters [2-602](#)
  - displaying RF states [2-602](#)
  - enabling automatic synchronization [2-21](#)
  - forcing switchover to standby supervisor engine [2-361](#)
  - mismatched command listing [2-359](#)
  - set the mode [2-282](#)

synchronizing the route processor configurations [2-270](#)

related documentation [1-xvii](#)

remote SPAN

See RSPAN

renew commands

ip dhcp snooping database [2-365](#)

resetting PVLAN trunk

setting switchport to trunk [2-707](#)

rj45 connector, selecting the connector [2-281](#)

ROM monitor mode

summary [1-6](#)

Route Processor Redundancy

See redundancy

RPF

disabling IPv4 exists-only checks [2-213](#)

enabling IPv4 exists-only checks [2-213](#)

RPR

set the redundancy mode [2-282](#)

RSPAN

converting VLAN to RSPAN VLAN [2-364](#)

displaying list [2-644](#)

## S

saving configuration changes [1-11](#)

secure address, configuring [2-322](#)

secure ports, limitations [2-713](#)

service-policy command (policy-map class) [2-371](#)

set the redundancy mode [2-282](#)

sfp connector, selecting the connector [2-281](#)

shape command [2-388](#)

show commands

filtering parameters [1-7](#)

searching and filtering [1-6](#)

show platform commands [1-11](#)

Simple Network Management Protocol

See SNMP

single-character patterns

special characters [1-7](#)

slaveslot0

displaying information on the standby supervisor [2-613](#)

slot0

displaying information about the system [2-615](#)

SNMP

debugging spanning tree activities [2-91](#)

ifIndex persistence

clearing SNMP ifIndex commands [2-651](#)

compress SNMP ifIndex table format [2-658](#)

disabling globally [2-657](#)

disabling on an interface [2-653](#)

enabling globally [2-657](#)

enabling on an interface [2-653](#)

informs

disabling [2-655](#)

enabling [2-655](#)

traps

configuring to send when storm occurs [2-696](#)

disabling [2-655](#)

enabling [2-655](#)

mac-notification

adding [2-659](#)

removing [2-659](#)

SPAN commands

configuring a SPAN session to monitor [2-284](#)

displaying SPAN session information [2-627, 2-697](#)

SPAN enhancements

displaying status [2-568](#)

Spanning Tree Protocol

See STP

SPAN session

displaying session information [2-568](#)

filter ACLs [2-284](#)

specify encaps type [2-284](#)

turn off host learning based on ingress packets [2-284](#)

special characters

anchoring, table [1-10](#)

- SSO [2-282](#)
- standard desktop
  - enabling Cisco-recommended features [2-259](#)
- standard desktop and Cisco IP phone
  - enabling Cisco-recommended features [2-261](#)
- sticky address, configuring [2-323](#)
- sticky-ARP
  - disabling on PVLANS [2-208](#)
  - enabling on PVLANS [2-208](#)
- sticky port
  - deleting [2-56](#)
  - enabling security [2-712](#)
- storm control
  - configuring for action when storm occurs [2-696](#)
  - disabling suppression mode [2-430](#)
  - displaying settings [2-625](#)
  - enabling [2-696](#)
  - enabling broadcast [2-696, 2-698](#)
  - enabling multicast [2-696, 2-698](#)
  - enabling suppression mode [2-430](#)
  - enabling timer to recover from error disable [2-140](#)
  - enabling unicast [2-696, 2-698](#)
  - multicast, enabling [2-698](#)
  - setting high and low levels [2-696](#)
  - setting suppression level [2-430](#)
- STP
  - configuring link type for a port [2-668](#)
  - configuring tunneling encapsulation rate [2-238](#)
  - debugging all activities [2-91](#)
  - debugging spanning tree activities [2-91](#)
  - debugging spanning tree BackboneFast events [2-93](#)
  - debugging spanning tree UplinkFast [2-96](#)
  - detecting misconfiguration [2-665](#)
  - displaying active interfaces only [2-617](#)
  - displaying BackboneFast status [2-617](#)
  - displaying bridge status and configuration [2-617](#)
  - displaying spanning tree debug messages [2-91](#)
  - displaying summary of interface information [2-617](#)
  - enabling BPDU filtering by default on all PortFast ports [2-684](#)
  - enabling BPDU filtering on an interface [2-661](#)
  - enabling BPDU guard by default on all PortFast ports [2-686](#)
  - enabling BPDU guard on an interface [2-663](#)
  - enabling extended system ID [2-666](#)
  - enabling loop guard as a default on all ports [2-669](#)
  - enabling PortFast by default on all access ports [2-687](#)
  - enabling PortFast mode [2-682](#)
  - enabling protocol tunneling for [2-234](#)
  - enabling root guard [2-667](#)
  - enabling spanning tree BackboneFast [2-660](#)
  - enabling spanning tree on a per VLAN basis [2-691](#)
  - enabling spanning tree UplinkFast [2-689](#)
  - setting an interface priority [2-688](#)
  - setting drop threshold for [2-236](#)
  - setting pathcost [2-664](#)
  - setting the default pathcost calculation method [2-681](#)
- subinterface configuration mode, summary [1-6](#)
- SVI
  - creating a Layer 3 interface on a VLAN [2-160](#)
- switching characteristics
  - excluding from link-up calculation [2-704](#)
  - modifying [2-704](#)
  - returning to interfaces
    - capture function [2-704](#)
- switchport [2-728](#)
- switchport interfaces
  - displaying status of Layer 3 port [2-462](#)
  - displaying status of native VLAN tagging [2-462](#)
- switch shim
  - debugging [2-94](#)
  - disabling debugging [2-94](#)
- switch to router connection
  - enabling Cisco-recommended features [2-263](#)
- switch to switch connection
  - enabling Cisco-recommended features [2-265](#)
- switch virtual interface

See SVI

sw-vlan [2-97](#)

system prompts [1-5](#)

## T

Tab key

command completion [1-1](#)

tables

characters with special meaning [1-7](#)

mac access-list extended subcommands [2-249](#)

multipliers [1-9](#)

relationship between duplex and speed  
commands [2-694](#)

show cable-diagnostics tdr command output  
fields [2-405](#)

show cdp neighbors detail field descriptions [2-408](#)

show cdp neighbors field descriptions [2-407](#)

show ip interface field descriptions [2-497](#)

show policy-map control-plane field  
descriptions [2-575](#)

show vlan command output fields [2-643](#)

show vtp command output fields [2-648](#)

special characters [1-9](#)

special characters used for anchoring [1-10](#)

speed command options [2-275, 2-694](#)

valid interface types [2-155](#)

TAC

displaying information useful to TAC [2-629](#)

TCAM

debugging spanning tree activities [2-91](#)

TDR

displaying cable diagnostic test results [2-404](#)

test condition of copper cables [2-734](#)

temperature readings

displaying information [2-427](#)

Ten-Gigabit Ethernet uplink

blocking ports on redundant Supervisor Engine  
6-E [2-149](#)

timer information [2-431](#)

traffic shaping

enable on an interface [2-390](#)

traps, enabling [2-655](#)

trunk encapsulation

setting format [2-728](#)

trunk interfaces

displaying trunk interfaces information [2-469](#)

trust state

setting [2-167](#)

tunnel ports

displaying information about Layer 2 protocol [2-538](#)

TX queues

allocating bandwidth [2-744](#)

returning to default values [2-744](#)

setting priority to high [2-744](#)

specifying burst size [2-744](#)

specifying traffic rate [2-744](#)

## U

UDLD

displaying administrative and operational  
status [2-631](#)

enabling by default on all fiber interfaces [2-746](#)

enabling on an individual interface [2-748](#)

preventing a fiber interface from being enabled [2-748](#)

resetting all shutdown ports [2-750](#)

setting the message timer [2-746](#)

unicast

counters [2-64](#)

Unidirectional Link Detection

See UDLD

unknown multicast traffic, preventing [2-706](#)

unknown unicast traffic, preventing [2-706](#)

user EXEC mode, summary [1-5](#)

username

setting password and privilege level [2-752](#)



## V

### VACLs

- access-group mode [2-6](#)
- applying VLAN access maps [2-767](#)
- displaying VLAN access map information [2-637](#)
- specifying an action in a VLAN access map [2-13](#)
- specifying the match clause for a VLAN access-map sequence [2-271](#)
- using a VLAN filter [2-767](#)

### VLAN

- applying an ARP ACL [2-161](#)
- configuring [2-756](#)
- configuring service policies [2-761](#)
- converting to RSPAN VLAN [2-364](#)
- displaying CEF information [2-476](#)
- displaying CEF next-hop information [2-476](#)
- displaying information on switch interfaces [2-487, 2-491](#)
- displaying information on VLAN switch interfaces [2-494](#)
- displaying information sorted by group IP address [2-487, 2-491](#)
- displaying IP address and version information [2-487, 2-491](#)
- displaying Layer 2 VLAN information [2-633](#)
- displaying statistical information [2-566](#)
- displaying VLAN information [2-635](#)
- enabling dynamic ARP inspection [2-170](#)
- enabling Explicit Host Tracking [2-198](#)
- enabling guest per-port [2-117](#)
- enabling guest VLAN supplicant [2-110, 2-118](#)
- entering VLAN configuration mode [2-761, 2-763](#)
- native frames
  - enabling tagging on all 802.1Q trunk ports [2-765](#)
  - pruning the list for VTP [2-728](#)
  - setting the list of allowed [2-728](#)

### VLAN Access Control Lists

See VACLs

### VLAN access map

See VACLs

### VLAN database

resetting [2-366](#)

### VLAN debugging

limiting output [2-72](#)

### VLAN link-up calculation

excluding a switch port [2-704](#)

including a switch port [2-704](#)

### VLAN manager

debugging [2-97](#)

disabling debugging [2-97](#)

### IOS file system error tests

debugging [2-98](#)

disabling debugging [2-98](#)

### VLAN Query Protocol

See VQP

### VLAN query protocol (VQPC)

debugging [2-104](#)

### VLANs

clearing

counters [2-60](#)

clearing hardware logic [2-38](#)

configuring

internal allocation scheme [2-768](#)

displaying

internal VLAN allocation information [2-640](#)

RSPAN VLANs [2-644](#)

entering VLAN configuration mode [2-763](#)

### VMPS

configuring servers [2-772](#)

reconfirming dynamic VLAN assignments [2-104, 2-770](#)

### voice VLANs

enabling [2-700](#)

### VoIP

configuring auto-QoS [2-18](#)

### VQP

per-server retry count [2-771](#)

reconfirming dynamic VLAN assignments [2-104](#),  
[2-770](#)

## VTP

configuring the administrative domain name [2-776](#)

configuring the device in VTP client mode [2-775](#)

configuring the device in VTP server mode [2-779](#)

configuring the device in VTP transparent  
mode [2-780](#)

configuring tunnel encapsulation rate [2-238](#)

creating a VTP domain password [2-777](#)

displaying domain information [2-647](#)

displaying statistics information [2-647](#)

enabling protocol tunneling for [2-234](#)

enabling pruning in the VLAN database [2-778](#)

enabling VTP version 2 mode [2-781](#)

modifying the VTP configuration storage file  
name [2-774](#)

set drop threshold for [2-236](#)

## VTP protocol code

activating debug messages [2-101](#)

deactivating debug messages [2-101](#)