



INDEX

Symbols

\$ matches the end of a string **1-7**
() in commands **1-11**
* matches 0 or more sequences of a pattern **1-7**
+ matches 1 or more sequences of a pattern **1-7**
. matches any single character **1-7**
? command **1-1**
? matches 0 or 1 occurrence of a pattern **1-7**
^ matches the beginning of a string **1-7**
_ matches a comma (,), left brace ({), left parenthesis **1-7**
“ **1-10**

Numerics

10-Gigabit Ethernet uplink
 showing the mode **2-567**
802.1Q trunk ports and native VLANs **2-910**
802.1Q tunnel ports
 configuring **2-855**
802.1S Multiple Spanning Tree
 see MST
802.1X
 configuring for multiple hosts **2-184**
 configuring for single host **2-184**
 configuring multiple domains **2-184**
 disabling port control **2-177**
 enabling port control **2-177**
802.1X Critical Authentication
 disabling on a port **2-179**
 disabling on a VLAN **2-182**
EAPOL
 disabling send success packets **2-180**

enabling send success packets **2-180**
enabling on a port **2-179**
enabling on a VLAN **2-182**
returning delay time to default setting **2-181**
setting delay time on a port **2-181**
802.1X critical authentication
 configure parameters **2-22**
802.1X critical recovery delay, configuring **2-22**
802.1X Port Based Authentication
 debugging 802.1X Port Based Authentication **2-131**
 displaying port based authentication **2-552**
 enabling accounting for authentication sessions **2-4**
 enabling authentication on the system **2-195**
 enabling guest VLAN **2-183**
 enabling guest VLAN supplicant **2-176, 2-184**
 enabling manual control of auth state **2-191**
 enabling periodic re-authentication of the client **2-194**
 initializing re-authentication of dot1x ports **2-193**
 initializing state machines **2-187**
 receive session termination message upon reboot **2-5**
 setting maximum number for EAP requests **2-190**
 setting the reauthentication timer **2-196**

A

aaa authorization network command **2-178**
abbreviating commands
 context-sensitive help **1-1**
Access Gateway Module
 connecting to a module **2-19**
 connecting to a remote module **2-472**
 connecting to a specific remote module **2-495**
access-group

- displaying mac interface **2-671**
- show mode interface **2-440, 2-513, 2-741**
- access groups
 - IP **2-6, 2-172**
- access lists
 - clearing an access template **2-94**
 - defining ARP **2-18**
 - displaying ARP information **2-517**
 - See also ACLs, MAC ACLs, and VACLs
- access maps
 - applying with VLAN filter **2-911**
- access-node-identifier, setting for the switch **2-442**
- access-policies, applying using host-mode **2-26**
- ACLs
 - access-group mode **2-6**
 - balancing hardware regions **2-11**
 - capturing control packets **2-8**
 - determining ACL hardware programming **2-9**
 - disabling hardware statistics **2-212**
 - displaying mac access-group interface **2-671**
 - enabling hardware statistics **2-212**
 - using ACL naming conventions for MAC ACLs **2-327**
- action clause
 - specifying drop or forward action in a VACL **2-12**
- addresses, configuring a maximum **2-427**
- adjacency
 - debugging the adjacency table **2-124**
 - disabling the debug facility **2-124**
 - displaying information about the adjacency table **2-514**
 - displaying IPC table entries **2-124**
- aggregate policer
 - displaying information **2-742**
- aging time
 - displaying MAC address aging time **2-674**
- MAC address table **2-330**
- alarms
 - displaying operational status **2-556**
- alternation
 - description **1-10**
- anchoring
 - description **1-10**
- ancp, show multicast **2-516**
- ANCP client
 - port identifier **2-14**
 - remote server **2-15**
 - set router to become **2-16**
- ARP
 - access list, displaying detailed information **2-517**
 - defining access-lists **2-18**
- ARP inspection
 - enforce certain types of checking **2-233**
- ARP packet
 - deny based on DHCP bindings **2-166**
 - permit based on DHCP bindings **2-407**
- authentication **2-22, 2-28**
 - changing the control-direction **2-20**
 - configure actions for events
 - configuring the actions **2-23**
 - configuring port-control **2-31**
 - enabling reauthentication **2-30**
 - enabling Webauth fallback **2-25**
 - host-mode configuration **2-26**
 - setting priority of methods **2-33**
 - setting the timer **2-35**
 - setting username **2-899**
 - specifying the order of methods **2-29**
 - using an MD5-type encryption method **2-899**
 - verifying MD5 signature **2-900**
 - verifying the checksum for Flash memory **2-900**
- authentication control-direction command **2-20**
- authentication critical recovery delay command **2-22**
- authentication event command **2-23**
- authentication fallback command **2-25**
- authentication host-mode **2-26**
- authentication methods, setting priority **2-33**

authentication methods, specifying the order of attempts **2-29**

authentication open command **2-28**

authentication order command **2-29**

authentication periodic command **2-30**

authentication port-control command **2-31**

authentication priority command **2-33**

authentication timer, setting **2-35**

authentication timer command **2-35**

authentication violation command **2-37**

auth fail VLAN

enable on a port **2-176**

set max number of attempts **2-175**

Auth Manager

configuring

 authentication timer **2-35**

authorization state

 enabling manual control **2-191**

authorization state of a controlled port **2-191**

automatic installation

 displaying status **2-523**

automatic medium-dependent interface crossover

 See Auto-MDIX

Auto-MDIX

 disabling **2-374**

 enabling **2-374**

auto-negotiate interface speed

 example **2-834**

auto-QoS

 configuring for VoIP **2-59**

 displaying configuration **2-524**

auto qos srnd4 command **2-47**

B

baby giants

 displaying the system MTU setting **2-770**

 setting the maximum Layer 2 payload size **2-881**

BackboneFast

displaying debugging messages **2-153**

displaying spanning tree status **2-762**

enabling debugging **2-153**

bandwidth command **2-67**

bindings

 store for DHCP snooping **2-244**

BOOT environment variable

 displaying information **2-527**

bootflash

 displaying information **2-525**

BPDUUs

 debugging spanning tree activities **2-151**

bridge protocol data units

 See BPDUUs

broadcast suppression level

 configuring **2-835, 2-837**

 enabling **2-835, 2-837**

C

cable diagnostics

TDR

 displaying test results **2-528**

 testing conditions of copper cables **2-882**

call home

 displaying information **2-530**

 e-mailing output **2-75**

 entering configuration submode **2-70**

 executing **2-75**

 manually send test message **2-78**

 receiving information **2-73**

 sending alert group message **2-76**

 submitting information **2-73**

call home destination profiles

 displaying **2-532**

Catalyst 4507R **2-425**

CDP

 configuring tunneling encapsulation rate **2-315**

 displaying

- neighbor information **2-535**
- enabling protocol tunneling for **2-312**
- set drop threshold for **2-314**
- CEF**
 - displaying next-hop information **2-601**
 - displaying VLAN configuration information **2-601**
- chassis**
 - displaying
 - chassis MAC address ranges **2-669**
 - current and peak traffic meter readings **2-669**
 - percentage of backplane utilization **2-669**
 - switching clock failure recovery mode **2-669**
- circuit-id**
 - setting for an interface **2-444**
- circuit-id, setting for an interface VLAN range** **2-445**
- cisco-desktop**
 - macro apply **2-339**
- Cisco Express Forwarding**
 - See **CEF**
- cisco-phone**
 - macro apply **2-341**
- cisco-router**
 - macro apply **2-343**
- cisco-switch**
 - macro apply **2-345**
- CISP**
 - See Client Information Signalling Protocol
- cisp enable command** **2-83**
- class maps**
 - creating **2-87**
 - defining the match criteria **2-367**
- monitor capture** **2-380**
- clear commands**
 - clearing Gigabit Ethernet interfaces **2-92**
 - clearing IGMP group cache entries **2-101**
 - clearing interface counters **2-89**
 - clearing IP access lists **2-94, 2-95**
 - clearing IP ARP inspection statistics VLAN **2-96**
 - clearing IP DHCP snooping database statistics **2-100**
 - clearing MFIB counters and routes **2-104**
 - clearing MFIB fastdrop entries **2-105**
 - clearing PAgP channel information **2-112**
 - clearing QoS aggregate counters **2-116**
 - clearing VLAN interfaces **2-93**
- clear ip wccp command** **2-106**
- clear nmsp statistics command** **2-111**
- Client Information Signalling Protocol** **2-178**
- Client Information Signalling Protocol, enabling** **2-83**
- CLI string search**
 - anchoring **1-10**
 - expressions **1-7**
 - filtering **1-6**
 - multiple-character patterns **1-8**
 - multipliers **1-9**
 - parentheses for recall **1-11**
 - searching outputs **1-6**
 - single-character patterns **1-7**
 - using **1-6**
- command** **2-380**
- command modes**
 - accessing privileged EXEC mode **1-5**
 - exiting **1-5**
 - understanding user EXEC and configuration modes **1-5**
- condition interface**
 - debugging interface-related activities **2-126**
- condition vlan**
 - debugging VLAN output **2-129**
- configuration, saving** **1-11**
- configuring**
 - root as secondary **2-820**
- configuring a SPAN session to monitor**
 - limit SPAN source traffic **2-393**
- configuring critical recovery** **2-22**
- configuring forward delay** **2-816**
- configuring root as primary** **2-820**
- CoPP**
 - attaching

- policy map to control plane **2-493**
- displaying
 - policy-map class information **2-716**
- entering configuration mode **2-119**
- removing
 - service policy from control plane **2-493**
- CoS**
 - assigning to Layer 2 protocol packets **2-313**
- counter command** **2-121**
- counters**
 - clearing interface counters **2-89**
- critical authentication, configure 802.1X parameters **2-22**
- critical recovery, configuring 802.1X parameter **2-22**

- D**
- DAI**
 - clear statistics **2-96**
- DBL**
 - displaying qos dbl **2-743**
- debug commands**
 - debugging backup events **2-125**
 - debugging DHCP snooping events **2-136**
 - debugging DHCP snooping messages **2-137**
 - debugging EtherChannel/PAgP/shim **2-132**
 - debugging IPC activity **2-135**
 - debugging IP DHCP snooping security messages **2-138**
 - debugging NVRAM activities **2-142**
 - debugging PAgP activities **2-143**
 - debugging port manager activities **2-146**
 - debugging spanning tree activities **2-151**
 - debugging spanning tree backbonefast **2-153**
 - debugging spanning tree UplinkFast **2-156**
 - debugging supervisor redundancy **2-150**
 - debugging VLAN manager activities **2-157**
 - displaying monitor activity **2-140**
 - displaying the adjacency table **2-124**
 - enabling debug dot1x **2-131**
 - enabling debugging messages for ISL VLAN IDs **2-160**
 - enabling debugging messages for VTP **2-161**
 - enabling debugging of UDLD activity **2-162**
 - enabling switch shim debugging **2-154**
 - enabling VLAN manager file system error tests **2-158**
 - limiting debugging output for VLANs **2-129**
 - limiting interface debugging output **2-126**
 - limiting output for debugging standby state changes **2-127**
 - shortcut to the debug condition interface **2-134**
 - debugging**
 - activity monitoring **2-140**
 - DHCP snooping events **2-136**
 - DHCP snooping packets **2-137**
 - IPC activities **2-135**
 - IP DHCP snooping security packets **2-138**
 - NVRAM activities **2-142**
 - PAgP activities **2-143**
 - PAgP shim **2-132**
 - PM activities **2-146**
 - PPPoE Intermediate Agent **2-148**
 - spanning tree BackboneFast events **2-153**
 - spanning tree switch shim **2-154**
 - spanning tree UplinkFast events **2-156**
 - VLAN manager activities **2-157**
 - VLAN manager IOS file system error tests **2-158**
 - VTP protocol debug messages **2-161**
 - debug nmsp command **2-141**
 - debug spanning tree switch **2-154**
 - debug sw-vlan vtp **2-161**
 - default form of a command, using **1-6**
 - DHCP**
 - clearing database statistics **2-100**
 - DHCP bindings**
 - configuring bindings **2-243**
 - deny ARP packet based on matches **2-166**
 - permit ARP packet based on matches **2-407**
 - DHCP snooping**

- clearing binding entries **2-97**
 - clearing database **2-99**
 - displaying binding table **2-603**
 - displaying configuration information **2-602**
 - displaying status of DHCP database **2-606**
 - displaying status of error detection **2-559**
 - enabling DHCP globally **2-242**
 - enabling IP source guard **2-278**
 - enabling on a VLAN **2-251**
 - enabling option 82 **2-246, 2-248**
 - enabling option-82 **2-253**
 - enabling rate limiting on an interface **2-249**
 - enabling trust on an interface **2-250**
 - establishing binding configuration **2-243**
 - renew binding database **2-474**
 - store generated bindings **2-244**
 - diagnostic fpga soft-error recover command **2-172**
 - diagnostic test
 - bootup packet memory **2-546**
 - displaying attributes **2-540**
 - display module-based results **2-542**
 - running **2-174**
 - show results for TDR **2-528**
 - testing conditions of copper cables **2-882**
 - displaying error disable recovery **2-560**
 - displaying inline power status **2-730**
 - displaying monitoring activity **2-140**
 - displaying PoE policing and monitoring status **2-738**
 - displaying EEPROM information
 - GBIC **2-567**
 - displaying SPAN session information **2-770, 2-837**
 - document conventions **1-xxii**
 - document organization **1-xxi**
 - DoS
 - CoPP
 - attaching policy map to control plane **2-493**
 - displaying policy-map class information **2-716**
 - entering configuration mode **2-119**
 - removing service policy from control plane **2-493**
 - entering
 - CoPP configuration mode **2-119**
 - DOS attack
 - protecting system's resources **2-228**
 - dot1x credentials (global configuration) command **2-178**
 - drop threshold, Layer 2 protocol tunneling **2-314**
 - DSCP rewrite for IP packets
 - enable **2-463**
 - dual-capable port
 - selecting a connector **2-376**
 - duplex mode
 - configuring autonegotiation on an interface **2-198**
 - configuring full duplex on an interface **2-198**
 - configuring half duplex on an interface **2-198**
 - dynamic ARP inspection
 - preventing **2-228**
 - Dynamic Host Configuration Protocol
 - See DHCP
-
- ## E
- EAP
 - restarting authentication process **2-190**
 - EIGRP (Enhanced IGRP)
 - filters
 - routing updates, preventing **2-404**
 - enabling
 - debugging for UDLD **2-162**
 - voice VLANs **2-849**
 - enabling open access **2-28**
 - environmental
 - alarms **2-556**
 - displaying information **2-556**
 - status **2-556**
 - temperature **2-556**
 - epm access control command **2-200**
 - erase a file **2-201**
 - error disable detection
 - clearing error disable on an interface **2-90**

- enabling error disable detection **2-90, 2-204**
 enabling per-VLAN on BPDU guard **2-204**
- error-disabled state
 displaying **2-586**
- error disable recovery
 configuring recovery mechanism variables **2-206**
 displaying recovery timer information **2-560**
 enabling ARP inspection timeout **2-206**
 specifying recovery cause **2-206**
- EtherChannel
 assigning interfaces to EtherChannel groups **2-79**
 debugging EtherChannel **2-132**
 debugging PAgP shim **2-132**
 debugging spanning tree activities **2-151**
 displaying information for a channel **2-561**
 removing interfaces from EtherChannel groups **2-79**
- EtherChannel guard
 detecting STP misconfiguration **2-807**
- Explicit Host Tracking
 clearing the database **2-103**
 enabling per-VLAN **2-265**
- expressions
 matching multiple expression occurrences **1-9**
 multiple-character patterns **1-8**
 multiplying pattern occurrence **1-11**
 single-character patterns **1-7**
- Extensible Authentication Protocol
 See EAP
-
- F**
- fallback profile, specifying **2-25**
 field replaceable unit (FRU)
 displaying status information **2-556**
- filters
 EIGRP
 routing updates, preventing **2-404**
- Flash memory file system
 displaying file system information **2-525**
-
- verifying checksum **2-900**
 flow control
 configuring a gigabit interface for pause frames **2-209**
 displaying per-interface statistics for flow control **2-565**
-
- G**
- GBIC
 displaying EEPROM information **2-567**
 generic-error-message, setting for the switch **2-442**
- Gigabit Ethernet interface
 clearing the hardware logic **2-92**
 Gigabit Ethernet uplink
 showing the mode **2-567**
- global configuration mode
 using **1-5**
-
- H**
- hardware module
 resetting a module by toggling the power **2-214**
- hardware statistics
 disabling **2-212**
 enabling **2-212**
- hardware uplink
 showing the mode **2-567**
- helper addresses, IP **2-619**
- hot standby protocol
 debugging **2-127**
 disabling debugging **2-127**
 limiting output **2-127**
- hw-module beacon command **2-213**
-
- I**
- identifier-string, setting for the switch **2-442**
 ID mapping, creating an ANCP client **2-14**
 IDPROMs

- displaying SEEPROM information
 - chassis [2-567](#)
 - clock module [2-567](#)
 - fan trays [2-567](#)
 - module [2-567](#)
 - mux buffer [2-567](#)
 - power supplies [2-567](#)
 - supervisor engine [2-567](#)
- ifIndex persistence
 - clearing SNMP ifIndex commands [2-793](#)
 - compress SNMP ifIndex table format [2-798](#)
 - disabling globally [2-797](#)
 - disabling on an interface [2-794](#)
 - enabling globally [2-797](#)
 - enabling on an interface [2-794](#)
- IGMP
 - applying filters for host joining on Layer 2 interfaces [2-255](#)
 - clearing IGMP group cache entries [2-101](#)
 - configuring frequency for IGMP host-query messages [2-258](#)
 - creating an IGMP profile [2-257](#)
 - displaying IGMP interface configuration information [2-608](#)
 - displaying profiles [2-609](#)
 - setting maximum group numbers [2-256](#)
- IGMP profiles
 - displaying [2-609](#)
- IGMP snooping
 - clearing the EHT database [2-103](#)
 - configuring a Layer 2 interface as a group member [2-269](#)
 - configuring a Layer 2 interface as a multicast router [2-267](#)
 - configuring a static VLAN interface [2-269](#)
 - displaying multicast information [2-616](#)
 - displaying VLAN information [2-610, 2-614, 2-617](#)
 - enabling [2-260](#)
 - enabling immediate-leave processing [2-266](#)
 - enabling on a VLAN [2-264](#)
- enabling per-VLAN Explicit Host Tracking [2-265](#)
- informs
 - enabling [2-795](#)
- inline power
 - displaying inline power status [2-730](#)
- In Service Software Upgrade
 - See ISSU
- inspection log
 - clearing log buffer [2-95](#)
- interface
 - displaying suppressed multicast bytes [2-580](#)
- interface capabilities
 - displaying [2-576](#)
- interface configuration mode
 - summary [1-5](#)
- interface link
 - display cable disconnect time [2-583](#)
- interfaces
 - configuring dot1q tunnel ports [2-855](#)
 - creating an interface-range macro [2-165](#)
 - debugging output of interface related activities [2-126](#)
 - displaying description [2-582](#)
 - displaying error-disabled state [2-586](#)
 - displaying information when tunneling is enabled [2-664](#)
 - displaying status [2-582](#)
 - displaying traffic for a specific interface [2-573](#)
 - entering interface configuration mode [2-219](#)
 - executing a command on multiple ports in a range [2-222](#)
 - selecting an interface to configure [2-219](#)
 - setting a CoS value for Layer 2 packets [2-313](#)
 - setting drop threshold for Layer 2 packets [2-314](#)
 - setting the interface type [2-855](#)
- interface speed
 - configuring interface speed [2-832](#)
- interface transceiver
 - displaying diagnostic data [2-590](#)
- internal VLAN allocation

- configuring [2-913](#)
- default setting [2-913](#)
- displaying allocation information [2-783](#)
- Internet Group Management Protocol
 - See IGMP
- IP address of remote ANCP server, setting [2-15](#)
- IP ARP
 - applying ARP ACL to VLAN [2-226](#)
 - clearing inspection statistics [2-96](#)
 - clearing status of log buffer [2-95](#)
 - controlling packet logging [2-237](#)
 - enabling dynamic inspection [2-235](#)
 - limit rate of incoming requests [2-228](#)
 - set per-port config trust state [2-232](#)
 - showing status of dynamic ARP inspection [2-597](#)
 - showing status of log buffer [2-600](#)
- IPC
 - debugging IPC activities [2-135](#)
- IP DHCP Snooping
 - See DHCP snooping
- IP header validation
 - disabling [2-277](#)
 - enabling [2-277](#)
- IP interfaces
 - displaying usability status [2-618](#)
- IP multicast
 - displaying multicast routing table information [2-624](#)
- ip multicast multipath command [2-272](#)
- IP packets
 - enable DSCP rewrite [2-463](#)
- IP phone and standard desktop
 - enabling Cisco-recommended features [2-341](#)
- IP Port Security
 - enabling [2-278](#)
- IP source binding
 - adding or deleting [2-274](#)
 - displaying bindingstaging [2-629](#)
- IP source guard
 - debugging messages [2-138](#)
- displaying configuration and filters [2-630](#)
- enabling on DHCP snooping [2-278](#)
- IPv4 statistics, enabling collection [2-121](#)
- IPv6 MLD
 - configuring queries [2-293, 2-295](#)
 - configuring snooping last-listener-query-intervals [2-295](#)
 - configuring snooping listener-message-suppression [2-297](#)
 - configuring snooping robustness-variables [2-298](#)
 - configuring tcn topology change notifications [2-300](#)
 - counting snooping last-listener-queries [2-293](#)
 - displaying information [2-642](#)
 - displaying ports for a switch or VLAN [2-644](#)
 - displaying querier information [2-645](#)
 - enabling snooping [2-291](#)
 - enabling snooping on a VLAN [2-301](#)
- IPv6 statistics, enabling collection [2-121](#)
- ip wccp check services all command [2-284](#)
- ip wccp command [2-281](#)
- ip wccp group-address command [2-281](#)
- ip wccp group-list command [2-281](#)
- ip wccp group-listen command [2-286](#)
- ip wccp password command [2-281, 2-282](#)
- ip wccp redirect command [2-288](#)
- ip wccp redirect exclude in command [2-290](#)
- ip wccp redirect-list command [2-281](#)
- ISSU
 - canceling process [2-303](#)
 - configuring rollback timer [2-311](#)
 - displaying capability [2-647](#)
 - displaying client information [2-649](#)
 - displaying compatibility matrix [2-651](#)
 - displaying endpoint information [2-655](#)
 - displaying entities [2-656](#)
 - displaying FSM session [2-657](#)
 - displaying messages [2-658](#)
 - displaying negotiated [2-659](#)
 - displaying rollback-timer [2-660](#)

displaying session information [2-661](#)
 displaying software version [2-662](#)
 displaying state [2-662](#)
 forcing switchover to standby supervisor engine [2-310](#)
 loading new image [2-306](#)
 starting process [2-308](#)
 stopping rollback timer [2-304](#)

J

Jumbo frames
 enabling jumbo frames [2-398](#)

L

LACP
 deselecting channeling protocol [2-81](#)
 enabling LACP on an interface [2-81](#)
 setting channeling protocol [2-81](#)
 lacp port-priority command [2-317](#)
 lacp system-priority command [2-318](#)
 Layer 2
 displaying ACL configuration [2-671](#)
 Layer 2 interface type
 specifying a nontrunking, nontagged single VLAN interface [2-855](#)
 specifying a trunking VLAN interface [2-855](#)
 Layer 2 protocol ports
 displaying [2-664](#)
 Layer 2 protocol tunneling error recovery [2-315](#)
 Layer 2 switching
 enabling voice VLANs [2-849](#)
 modifying switching characteristics [2-849](#)
 Layer 2 traceroute
 IP addresses [2-887](#)
 Layer 3 interface, assign counters [2-121](#)
 Layer 3 switching

displaying information about an adjacency table [2-514](#)
 displaying port status [2-588](#)
 displaying status of native VLAN tagging [2-588](#)
 link-status event messages
 disabling
 globally [2-320, 2-323](#)
 on an interface [2-321, 2-324](#)
 enabling
 globally [2-320, 2-323](#)
 on an interface [2-321, 2-324](#)

LLDP

enabling power negotiation [2-319](#)
 lldp tlv-select power-management command [2-319](#)
 log buffer
 show status [2-600](#)
 logging
 controlling IP ARP packets [2-237](#)

M

MAB, display information [2-669](#)
 MAB, enable and configure [2-326](#)
 mab command [2-326](#)
 MAC Access Control Lists
 See MAC ACLs
 MAC ACLs
 defining extended MAC access list [2-327](#)
 displaying MAC ACL information [2-779](#)
 naming an ACL [2-327](#)
 MAC addresses
 disabling MAC address learning per VLAN [2-334](#)
 displaying
 notification settings [2-200, 2-641, 2-680](#)
 MAC address filtering
 configuring [2-338](#)
 disabling [2-338](#)
 enabling [2-338](#)
 MAC address learning on a VLAN, enabling [2-334](#)

MAC address table
 adding static entries **2-365**
 clearing dynamic entries **2-108, 2-110**
 configuring aging time **2-330**
 displaying dynamic table entry information **2-676**
 displaying entry count **2-675**
 displaying information **2-672**
 displaying interface-based information **2-678**
 displaying multicast information **2-681**
 displaying notification information **2-683**
 displaying protocol-based information **2-685**
 displaying static table entry information **2-687**
 displaying the MAC address aging time **2-674**
 displaying VLAN-based information **2-689**
 enabling authentication bypass **2-188**
 enabling notifications **2-336**
 learning in the protocol buckets **2-331**
 removing static entries **2-365**
 mac address-table learning vlan command **2-334**

MAC address tables
 adding static entries **2-338**
 deleting secure or specific addresses **2-113**
 disabling IGMP snooping on static MAC addresses **2-338**
 removing static entries **2-338**

mac-address-table static **2-338**

MAC address unicast filtering
 dropping unicast traffic **2-338**

MAC authentication bypass (MAB), display information **2-669**

MAC authorization bypass(MAB), enable and configure **2-326**

macro
 displaying descriptions **2-364**

macro auto global processing command **2-347, 2-349, 2-352, 2-353, 2-355, 2-357, 2-359, 2-361, 2-691**

macro auto monitor command **2-358**

macro keywords
 help strings **2-2**

macros

adding a global description **2-364**
 cisco global **2-362**
 system-cpp **2-363**
 mapping secondary VLANs to MST instance **2-457**
 mapping VLAN(s) to an MST instance **2-216**
 match (class-map configuration) command **2-13, 2-168, 2-169, 2-170, 2-171, 2-367, 2-838, 2-839, 2-841, 2-843, 2-847**
 maximum transmission unit (MTU)
 displaying the system MTU setting **2-770**
 setting the maximum Layer 2 payload size **2-881**

MD5
 verifying MD5 signature **2-900**

message digest 5
 See MD5

MFIB
 clearing ip mfib counters **2-104**
 clearing ip mfib fastdrop **2-105**
 displaying all active MFIB routes **2-621**
 displaying MFIB fastdrop table entries **2-623**
 enabling IP MFIB fastdrops **2-271**

MLD
 configuring snooping last-listener-query-intervals **2-295**
 configuring snooping listener-message-suppression **2-297**
 configuring snooping robustness-variables **2-298**
 configuring topology change notifications **2-300**
 counting snooping last-listener-queries **2-293**
 enabling snooping **2-291**
 enabling snooping on a VLAN **2-301**

MLD snooping
 displaying **2-645**

modes
 access-group **2-6**
 show access-group interface **2-440, 2-513, 2-741**
 switching between PVST+, MST, and Rapid PVST **2-812**
 See also command modes

module password clearing **2-91**

module reset

resetting a module by toggling the power **2-214**
 monitor capture {access-list | class-map} command **2-379**
 monitor capture mycap match command **2-386**
 monitor capture start command **2-388**
 --More-- prompt
 filter **1-6**
 search **1-7**
MST
 designating the primary and secondary root **2-820**
 displaying MST protocol information **2-766**
 displaying region configuration information **2-766**
 displaying spanning tree information **2-766**
 entering MST configuration submode **2-814**
 setting configuration revision number **2-487**
 setting path cost and port priority for instances **2-813**
 setting the forward delay timer for all instances **2-816**
 setting the hello-time delay timer for all instances **2-817**
 setting the max-age timer for all instances **2-818**
 setting the MST region name **2-399**
 specifying the maximum number of hops **2-819**
 switching between PVST+ and Rapid PVST **2-812**
 using the MST configuration submode revision command **2-487**
 using the submode name command **2-399**
MTU
 displaying global MTU settings **2-770**
multi-auth, setting **2-26**
Multicase Listener Discovery
 See MLD
multicast
 enabling storm control **2-837**
 show ancp **2-516**
multicast/unicast packets
 prevent forwarding **2-854**
Multicast Forwarding Information Base
 See MFIB
multi-domain, setting **2-26**
multiple-character patterns **1-8**

Multiple Spanning Tree
 See MST

N

native VLAN
 controlling tagging of traffic **2-875**
 displaying ports eligible for native tagging **2-781**
 displaying ports eligible for tagging **2-781**
 enabling tagging on 802.1Q trunk ports **2-910**
 specifying the tagging of traffic **2-876**
NetFlow
 enabling NetFlow statistics **2-274**
 including infer fields in routing statistics **2-274**
next-hop
 displaying CEF VLAN information **2-601**
nmsp attachment suppress command **2-401**
nmsp command **2-400**
no form of a command, using **1-6**
NVRAM
 debugging NVRAM activities **2-142**

O

open access on a port, enabling **2-28**
output
 pattern searches **1-7**

P

packet counters (statistics)
 clear for PPPoE Intermediate Agent **2-115**
 packet counters, display for PPPoE Intermediate Agent **2-739**
packet forwarding
 prevent unknown packets **2-854**
packet memory failure
 direct switch action upon detection **2-173**
packet memory test

- bootup, displaying results **2-546, 2-548**
- ongoing, displaying results **2-550**
- PACL
 - access-group mode **2-6**
- paging prompt
 - see --More-- prompt
- PAgP
 - clearing port channel information **2-112**
 - debugging PAgP activity **2-143**
 - deselecting channeling protocol **2-81**
 - displaying port channel information **2-713**
 - hot standby mode
 - returning to defaults **2-403**
 - selecting ports **2-403**
 - input interface of incoming packets
 - learning **2-402**
 - returning to defaults **2-402**
 - setting channeling protocol **2-81**
- parentheses **1-11**
- password
 - clearing on an intelligent line module **2-91**
 - establishing enhanced password security **2-899**
 - setting username **2-899**
- PBR
 - displaying route maps **1-xxii**
 - redistributing route maps **1-xxii**
- PM activities
 - debugging **2-146**
 - disabling debugging **2-146**
- PoE policing
 - configure on an interface **2-435**
- PoE policing and monitoring
 - displaying status **2-738**
- police (percent) command **2-413**
- police (two rates) command **2-415, 2-417**
- police command **2-409**
- policing, configure PoE **2-435**
- policing and monitoring status
 - displaying PoE **2-738**
- Policy Based Routing
 - See PBR
- policy maps
 - creating **2-421**
 - marking **2-497**
 - See also QoS, hierarchical policies
 - traffic classification
 - defining the class
 - defining trust states **2-889**
- port, dual-capable
 - selecting the connector **2-376**
- Port Aggregation Protocol
 - See PAgP
- port-based authentication
 - displaying debug messages **2-131**
 - displaying statistics and status **2-552**
 - enabling 802.1X **2-191**
 - host modes **2-184**
 - manual control of authorization state **2-191**
 - periodic re-authentication
 - enabling **2-194**
 - re-authenticating 802.1X-enabled ports **2-193**
 - switch-to-client frame-retransmission number **2-190**
- port channel
 - accessing **2-221**
 - creating **2-221**
 - displaying information **2-713**
 - load distribution method
 - resetting to defaults **2-423**
 - setting **2-423**
- port-channel standalone-disable command **2-424**
- port control, changing from unidirectional or bidirectional **2-20**
- port-control value, configuring **2-31**
- port range
 - executing **2-222**
- port security
 - debugging ports security **2-147**
 - deleting secure or specific addresses **2-113**

- displaying settings for an interface or switch [2-724](#)
 enabling [2-860](#)
 filter source IP and MAC addresses [2-278](#)
 setting action upon security violation [2-860](#)
 setting the rate limit for bad packets [2-860](#)
 sticky port [2-860](#)
- Port Trust Device
 displaying [2-744](#)
 power efficient-ethernet auto command [2-429](#)
 power inline four-pair forced command [2-433](#)
 power inline logging global command [2-434](#)
 power negotiation through LLDP, enabling [2-319](#)
 power status
 displaying inline power [2-730](#)
 displaying power status [2-730](#)
- power supply
 configuring combined and redundant power on the Catalyst 4507R [2-425](#)
 configuring inline power [2-430](#)
 configuring power consumption [2-425](#)
 displaying the EEPROM [2-567](#)
 setting inline power state [2-428](#)
- PPPoE Discovery
 enable vendor-tag stripping on packets
 enable vendor-tag stripping on Discovery packets [2-448](#)
- PPPoE Discovery packets, limit rate arriving on an interface [2-446](#)
- PPPoE Intermediate Agent
 clear statistics (packet counters) [2-115](#)
 debugging [2-148](#)
- pppoe intermediate-agent
 enable intermediate agent on a switch [2-439](#)
 enable on an interface VLAN range [2-441](#)
 enable PPPoE Intermediate Agent on an interface [2-440](#)
 enable vendor-tag stripping of Discovery packets [2-448](#)
 format-type (global) [2-442](#)
 limit rate of PPPoE Discovery packets [2-446](#)
- set circuit-id or remote-id for an interface [2-444](#)
 set circuit-id or remote-id for an interface VLAN range [2-445](#)
 set trust configuration on an interface [2-446, 2-447](#)
- PPPoE Intermediate Agent, display configuration and statistics (packet counters) [2-739](#)
- priority command [2-449](#)
 priority-queue command [2-123](#)
- Private VLAN
 See PVLANS
- privileged EXEC mode, summary [1-5](#)
- prompts
 system [1-5](#)
- protocol tunneling
 configuring encapsulation rate [2-315](#)
 disabling [2-312](#)
 displaying port information [2-664](#)
 enabling [2-312](#)
 setting a CoS value for Layer 2 packets [2-313](#)
 setting a drop threshold for Layer 2 packets [2-314](#)
- PVLANS
 configuring isolated, primary, and community PVLANS [2-451](#)
 controlling tagging of native VLAN traffic [2-875](#)
 disabling sticky-ARP [2-275](#)
 displaying map information for VLAN SVIs [2-585](#)
 displaying PVLAN information [2-786](#)
 enabling interface configuration mode [2-855](#)
 enabling sticky-ARP [2-275](#)
 mapping VLANs to the same SVI [2-455](#)
 specifying host ports [2-855](#)
 specifying promiscuous ports [2-855](#)
- PVST+
 switching between PVST and MST [2-812](#)
-
- Q**
- QoS
 account Layer 2 encapsulation [2-461](#)

attaching a policy-map to an interface **2-488**
 automatic configuration **2-39, 2-43, 2-47, 2-51, 2-55, 2-59, 2-61**
 class maps
 creating **2-87**
 defining the match criteria **2-367**
 clearing aggregate counters **2-116**
 configuring auto **2-59**
 defining a named aggregate policer **2-463**
 displaying aggregate policer information **2-742**
 displaying auto configuration **2-524**
 displaying class maps information **2-538**
 displaying configuration information **2-524**
 displaying configurations of policies **2-719**
 displaying policy map information **2-715, 2-722**
 displaying QoS information **2-741**
 displaying QoS map information **2-745**
 egress queue-sets
 enabling the priority queue **2-123**
 enabling global configuration mode **2-51, 2-460**
 enabling per-VLAN QoS for a Layer 2 interface **2-465**
 hierarchical policies
 average-rate traffic shaping on a class **2-508**
 bandwidth allocation for a class **2-67, 2-86**
 creating a service policy **2-491**
 marking **2-497**
 strict priority queueing (LLQ) **2-449**
 policy maps
 creating **2-421**
 marking **2-497**
 traffic classifications
 trust states **2-889**
 setting the trust state **2-463**
 specifying flow-based match criteria **2-370**
 Supervisor Engine 6-E
 setting CoS **2-499**
 setting DSCP **2-501**
 setting precedence values **2-504**
 setting QoS group identifiers **2-507**
 QoS CoS
 configuring for tunneled Layer 2 protocol packets **2-313**
 quality of service
 See QoS
 question command **1-1**
 queueing information
 displaying **2-744**
 queue limiting
 configuring packet limits **2-465**

R

Rapid PVST
 switching between PVST and MST **2-812**
 re-authenticating 802.1X-enabled ports **2-193**
 re-authentication
 periodic **2-194**
 set the time **2-196**
 reauthentication, enabling **2-30**
 reboots
 restoring bindings across **2-243**
 redundancy
 accessing the main CPU **2-467**
 changing from active to standby supervisor engine **2-470**
 displaying information **2-747**
 displaying ISSU config-sync failure information **2-750**
 displaying redundancy facility information **2-747**
 displaying RF client list **2-747**
 displaying RF operational counters **2-747**
 displaying RF states **2-747**
 enabling automatic synchronization **2-66**
 forcing switchover to standby supervisor engine **2-470**
 mismatched command listing **2-468**
 set the mode **2-377**

- synchronizing the route processor configurations [2-365](#)
- related documentation [1-xxii](#)
- remote-id, setting for an interface [2-444](#)
- remote-id, setting for an interface VLAN range [2-445](#)
- remote SPAN
See RSPAN
- renew commands
- ip dhcp snooping database [2-474](#)
 - rep admin vlan command [2-475](#)
 - rep block port command [2-476](#)
 - rep lsl-age-timer command [2-479](#)
 - rep preempt delay command [2-480](#)
 - rep preempt segment command [2-481](#)
 - rep segment command [2-482](#)
 - rep stcn command [2-485](#)
- resetting PVLAN trunk
- setting switchport to trunk [2-855](#)
- retry failed authentication, configuring [2-23](#)
- rj45 connector, selecting the connector [2-376](#)
- ROM monitor mode
- summary [1-6](#)
- Route Processor Redundancy
See redundancy
- router, set to become ANCP client [2-16](#)
- RPF
- disabling IPv4 exists-only checks [2-280](#)
 - enabling IPv4 exists-only checks [2-280](#)
- RPR
- set the redundancy mode [2-377](#)
- RSPAN
- converting VLAN to RSPAN VLAN [2-473](#)
 - displaying list [2-788](#)
-
- S**
- saving configuration changes [1-11](#)
- secure address, configuring [2-425](#)
- secure ports, limitations [2-861](#)
- server (AAA) alive actions, configuring [2-23](#)
- server (AAA) dead actions, configuring [2-23](#)
- service-policy command (policy-map class) [2-491](#)
- session classification, defining [2-26](#)
- set the redundancy mode [2-377](#)
- sfp connector, selecting the connector [2-376](#)
- shape command [2-508](#)
- shell trigger command [2-511, 2-755](#)
- show ancp multicast [2-516](#)
- show authentication interface command [2-518](#)
- show authentication registration command [2-518](#)
- show authentication sessions command [2-518](#)
- show capture command [2-702](#)
- show commands
- filtering parameters [1-7](#)
 - searching and filtering [1-6](#)
 - show platform commands [1-11](#)
- show ipv6 snooping counters command [2-641](#)
- show ip wccp command [2-632](#)
- show ip wccp detail command [2-632](#)
- show ip wccp view command [2-632](#)
- show mab command [2-669](#)
- show mac address-table learning command [2-200, 2-680](#)
- show macro auto monitor device command [2-694, 2-695, 2-697](#)
- show monitor capture command [2-704, 2-706](#)
- show monitor capture file command [2-706](#)
- show nmsp command [2-710](#)
- show vlan group command [2-782](#)
- show vlan mapping command [2-784](#)
- Simple Network Management Protocol
See SNMP
- single-character patterns
- special characters [1-7](#)
- single-host, setting [2-26](#)
- slaveslot0
- displaying information on the standby supervisor [2-758](#)
- slot0

- displaying information about the system **2-760**
- SNMP**
 - debugging spanning tree activities **2-151**
 - ifIndex persistence**
 - clearing SNMP ifIndex commands **2-793**
 - compress SNMP ifIndex table format **2-798**
 - disabling globally **2-797**
 - disabling on an interface **2-794**
 - enabling globally **2-797**
 - enabling on an interface **2-794**
 - informs**
 - disabling **2-795**
 - enabling **2-795**
 - traps**
 - configuring to send when storm occurs **2-835**
 - disabling **2-795**
 - enabling **2-795**
 - mac-notification
 - adding **2-799**
 - removing **2-799**
- SPAN commands**
 - configuring a SPAN session to monitor **2-393**
 - displaying SPAN session information **2-770, 2-837**
- SPAN enhancements**
 - displaying status **2-702**
- Spanning Tree Protocol**
 - See **STP**
- SPAN session**
 - displaying session information **2-702**
 - filter ACLs **2-393**
 - specify encapsulation type **2-393**
 - turn off host learning based on ingress packets **2-393**
- special characters**
 - anchoring, table **1-10**
- SSO** **2-377**
- standard desktop**
 - enabling Cisco-recommended features **2-339**
- standard desktop and Cisco IP phone**
 - enabling Cisco-recommended features **2-341**
- sticky address, configuring** **2-426**
- sticky-ARP**
 - disabling on PVLANs **2-275**
 - enabling on PVLANs **2-275**
- sticky port**
 - deleting **2-113**
 - enabling security **2-860**
- storm control**
 - configuring for action when storm occurs **2-835**
 - disabling suppression mode **2-559**
 - displaying settings **2-768**
 - enabling **2-835**
 - enabling broadcast **2-835, 2-837**
 - enabling multicast **2-835, 2-837**
 - enabling suppression mode **2-559**
 - enabling timer to recover from error disable **2-206**
 - enabling unicast **2-835, 2-837**
 - multicast, enabling **2-837**
 - setting high and low levels **2-835**
 - setting suppression level **2-559**
- STP**
 - configuring link type for a port **2-810**
 - configuring tunneling encapsulation rate **2-315**
 - debugging all activities **2-151**
 - debugging spanning tree activities **2-151**
 - debugging spanning tree BackboneFast events **2-153**
 - debugging spanning tree UplinkFast **2-156**
 - detecting misconfiguration **2-807**
 - displaying active interfaces only **2-762**
 - displaying BackboneFast status **2-762**
 - displaying bridge status and configuration **2-762**
 - displaying spanning tree debug messages **2-151**
 - displaying summary of interface information **2-762**
 - enabling BPDU filtering by default on all PortFast ports **2-824**
 - enabling BPDU filtering on an interface **2-803**
 - enabling BPDU guard by default on all PortFast ports **2-825**
 - enabling BPDU guard on an interface **2-805**

enabling extended system ID [2-808](#)
 enabling loop guard as a default on all ports [2-811](#)
 enabling PortFast by default on all access ports [2-826](#)
 enabling PortFast mode [2-822](#)
 enabling protocol tunneling for [2-312](#)
 enabling root guard [2-809](#)
 enabling spanning tree BackboneFast [2-802](#)
 enabling spanning tree on a per VLAN basis [2-830](#)
 enabling spanning tree UplinkFast [2-828](#)
 setting an interface priority [2-827](#)
 setting drop threshold for [2-314](#)
 setting pathcost [2-806](#)
 setting the default pathcost calculation method [2-821](#)
 subinterface configuration mode, summary [1-6](#)
SVI
 creating a Layer 3 interface on a VLAN [2-224](#)
 switching characteristics
 excluding from link-up calculation [2-853](#)
 modifying [2-853](#)
 returning to interfaces
 capture function [2-853](#)
switchport [2-876](#)
 switchport interfaces
 displaying status of Layer 3 port [2-588](#)
 displaying status of native VLAN tagging [2-588](#)
switchport vlan mapping command [2-879](#)
switch shim
 debugging [2-154](#)
 disabling debugging [2-154](#)
switch to router connection
 enabling Cisco-recommended features [2-343](#)
switch to switch connection
 enabling Cisco-recommended features [2-345](#)
switch virtual interface
 See **SVI**
sw-vlan [2-157](#)
system prompts [1-5](#)

T

Tab key
 command completion [1-1](#)
tables
 characters with special meaning [1-7](#)
 mac access-list extended subcommands [2-327](#)
 multipliers [1-9](#)
 relationship between duplex and speed commands [2-833](#)
 show cable-diagnostics tdr command output fields [2-529](#)
 show cdp neighbors detail field descriptions [2-537](#)
 show cdp neighbors field descriptions [2-536](#)
 show ip dhcp snooping command output [2-519, 2-669](#)
 show ip interface field descriptions [2-619](#)
 show policy-map control-plane field descriptions [2-717](#)
 show vlan command output fields [2-787](#)
 show vtp command output fields [2-791](#)
 special characters [1-9](#)
 special characters used for anchoring [1-10](#)
 speed command options [2-370, 2-832](#)
 valid interface types [2-219](#)
TAC
 displaying information useful to TAC [2-771](#)
TCAM
 debugging spanning tree activities [2-151](#)
TDR
 displaying cable diagnostic test results [2-528](#)
 test condition of copper cables [2-882](#)
temperature readings
 displaying information [2-556](#)
timer information [2-560](#)
traffic monitor
 display status [2-669](#)
traffic shaping
 enable on an interface [2-510](#)
traps, enabling [2-795](#)
trunk encapsulation

setting format **2-876**

trunk interfaces

- displaying trunk interfaces information **2-595**

trunk port, configuring VLAN mapping **2-879**

trunk ports, display VLAN mapping information **2-784**

trust configuration, setting on an interface **2-446, 2-447**

trust state

- setting **2-232**

tunnel ports

- displaying information about Layer 2 protocol **2-664**

TX queues

- allocating bandwidth **2-891**
- returning to default values **2-891**
- setting priority to high **2-891**
- specifying burst size **2-891**
- specifying traffic rate **2-891**

U

UDLD

- displaying administrative and operational status **2-773**
- enabling by default on all fiber interfaces **2-893**
- enabling on an individual interface **2-895**
- preventing a fiber interface from being enabled **2-895**
- resetting all shutdown ports **2-897**
- setting the message timer **2-893**

Unidirectional Link Detection

See UDLD

unidirection port control, changing from bidirectional **2-20**

unknown multicast traffic, preventing **2-854**

unknown unicast traffic, preventing **2-854**

user EXEC mode, summary **1-5**

username

- setting password and privilege level **2-899**

V

VACLs

- access-group mode **2-6**
- applying VLAN access maps **2-911**
- displaying VLAN access map information **2-779**
- specifying an action in a VLAN access map **2-12**
- specifying the match clause for a VLAN access-map sequence **2-366**
- using a VLAN filter **2-911**

VLAN

- applying an ARP ACL **2-226**
- configuring **2-902**
- configuring service policies **2-906**
- converting to RSPAN VLAN **2-473**
- displaying CEF information **2-601**
- displaying CEF next-hop information **2-601**
- displaying information on switch interfaces **2-610, 2-614**
- displaying information on VLAN switch interfaces **2-617**
- displaying information sorted by group IP address **2-610, 2-614**
- displaying IP address and version information **2-610, 2-614**
- displaying Layer 2 VLAN information **2-776**
- displaying statistical information **2-700**
- displaying VLAN information **2-777**
- enabling dynamic ARP inspection **2-235**
- enabling Explicit Host Tracking **2-265**
- enabling guest per-port **2-183**
- enabling guest VLAN supplicant **2-176, 2-184**
- entering VLAN configuration mode **2-906, 2-908**
- native frames

 - enabling tagging on all 802.1Q trunk ports **2-910**

- pruning the list for VTP **2-876**
- setting the list of allowed **2-876**

VLAN, create or modify a group **2-912**

VLAN Access Control Lists

See VACLs

- VLAN access map
 - See VACLs
- VLAN database
 - resetting **2-486**
- VLAN debugging
 - limiting output **2-129**
- vlan group command **2-912**
- VLAN groups, display VLANs mapped **2-782**
- VLAN link-up calculation
 - excluding a switch port **2-853**
 - including a switch port **2-853**
- VLAN manager
 - debugging **2-157**
 - disabling debugging **2-157**
- IOS file system error tests
 - debugging **2-158**
 - disabling debugging **2-158**
- VLAN mapping
 - configuring **2-879**
 - displaying **2-784**
- VLAN mapping, configure on trunk port **2-879**
- VLAN mapping on trunk ports, display information **2-784**
- VLAN Query Protocol
 - See VQP
- VLAN query protocol (VQPC)
 - debugging **2-164**
- VLANs
 - clearing
 - counters **2-117**
 - clearing hardware logic **2-93**
 - configuring
 - internal allocation scheme **2-913**
 - displaying
 - internal VLAN allocation information **2-783**
 - RSPAN VLANs **2-788**
 - entering VLAN configuration mode **2-908**
- VMPS
 - configuring servers **2-917**
- reconfirming dynamic VLAN assignments **2-164**, **2-915**
- voice VLANs
 - enabling **2-849**
- VoIP
 - configuring auto-QoS **2-59**
- VQP
 - per-server retry count **2-916**
 - reconfirming dynamic VLAN assignments **2-164**, **2-915**
- VTP
 - configuring the administrative domain name **2-921**
 - configuring the device in VTP client mode **2-920**
 - configuring the device in VTP server mode **2-924**
 - configuring the device in VTP transparent mode **2-925**
 - configuring tunnel encapsulation rate **2-315**
 - creating a VTP domain password **2-922**
 - displaying domain information **2-790**
 - displaying statistics information **2-790**
 - enabling protocol tunneling for **2-312**
 - enabling pruning in the VLAN database **2-923**
 - enabling VTP version 2 mode **2-926**
 - modifying the VTP configuration storage file name **2-919**
 - set drop threshold for **2-314**
- VTP protocol code
 - activating debug messages **2-161**
 - deactivating debug messages **2-161**

- W**
- Webauth fallback, enabling **2-25**