

AP Support Bundle

- Access Point Support Bundle, on page 1
- Exporting an AP Support Bundle (GUI), on page 1
- Exporting an AP Support Bundle (CLI), on page 2
- Monitoring the Status of Support Bundle Export, on page 2

Access Point Support Bundle

An access point (AP) support bundle contains core files, crash files, **show run-configuration**, configuration commands, msglogs, and traplogs.

This topic describes how you can retrieve the support bundle information of an AP and export it to the controller or to an external server. (Until Cisco IOS XE, Release 17.2.1, you had to log in to the AP console to retrieve the AP support-bundle information.)

The Access Point Support Bundle feature is supported only on Cisco Wave2 APs and Cisco Catalyst APs.

Exporting an AP Support Bundle (GUI)

Procedure

- **Step 1** Choose **Configuration** > **Wireless** > **Access Points**.
- Step 2 Click the corresponding AP name. The Edit AP window is displayed.
- **Step 3** Click the **Support Bundle** tab.
- **Step 4** From the **Destination** drop-down list, choose one of the following:
 - This Device: If you choose this, enter the values for the Server IP, Destination File Path, Username, and Password fields.
 - **Note** When you choose **This Device**, a bundle is sent through Secure Copy (SCP) to the controller (if you have configured the **ip scp server enable** command globally on the controller). You can easily retrieve the bundle later from your browser, using the controller file manager.
 - External Server: If you choose this, from the Transfer Mode drop-down list, choose either scp or tftp.

If you choose the **scp** transfer mode, enter the values for the **Server IP**, **Destination File Path**, **Username**, and **Password** fields.

If you choose the **tftp** transfer mode, enter the values for the **Server IP**, and **Destination File Path** fields.

Note Information about the Last Export Status, such as State, Transfer Mode, Server IP, File Path, and Time of Export, is displayed on the right-hand side of the window.

Step 5 Click Start Transfer.

Exporting an AP Support Bundle (CLI)

Procedure

	Command or Action	Purpose		
Step 1	enable Example:	Enables privileged EXEC mode. Enter your password, if prompted.		
Step 2	ap name Cisco-AP-name export	Exports the AP support bundle through the SCP or TFTP transfer modes. If you select the scp , you will be prompted to provide your username and password		
	<pre>support-bundle mode { scp tftp} target ip-address {A.B.C.D X:X:X:X:X} path file-path</pre>			
	<pre>Example: Device> ap name Cisco-AP-name export support-bundle mode scp target ip-address 10.1.1.1 path file-path</pre>	For tftp , username and password is not required.		

Monitoring the Status of Support Bundle Export

To monitor the status of a support bundle export, run the following command:

Device#	Sorver-TP		summary	Successful	Timo	Dath Filo-name	
	Server-ir	Status	Last	Successiui	TTILE		_
				/			

AP_28XXX 81.1.1.10 Copy Success 04/24/2020 07:27:38 UTC AP_28XXX support.17.4.0.2.2020.07XXXX.tgz