

Guía de migración de EzVPN-NEM a FlexVPN

Contenido

[Introducción](#)
[Prerequisites](#)
[Requirements](#)
[Componentes Utilizados](#)
[Convenciones](#)
[EzVPN frente a FlexVPN](#)
[Modelo EzVPN: lo que destaca](#)
[Negociación del túnel](#)
[Modelo de VPN de acceso remoto FlexVPN](#)
[Servidor FlexVPN](#)
[Métodos de Autenticación del Cliente IOS FlexVPN](#)
[Negociación del túnel](#)
[Configuración inicial](#)
[Topología](#)
[Configuración inicial](#)
[Enfoque de migración de EzVPN a FlexVPN](#)
[Topología migrada](#)
[Configuración](#)
[Verificación de la Operación FlexVPN](#)
[Servidor FlexVPN](#)
[Remoto FlexVPN](#)
[Información Relacionada](#)

[Introducción](#)

Este documento proporciona asistencia en el proceso de migración desde la configuración de EzVPN (Intercambio de claves de Internet v1 (IKEv1) a la configuración de FlexVPN (IKEv2) con el menor número de problemas posible. Dado que el acceso remoto IKEv2 difiere del acceso remoto IKEv1 de ciertas maneras que dificultan la migración, este documento le ayuda a elegir diferentes enfoques de diseño en la migración del modelo EzVPN al modelo de acceso remoto FlexVPN.

Este documento trata con el cliente IOS FlexVPN o el cliente de hardware, este documento no explica el cliente de software. Para obtener más información sobre el cliente de software, consulte:

- [FlexVPN: IKEv2 con autenticación de certificado y cliente de Windows integrada](#)
- [Ejemplo de Configuración de Cliente FlexVPN y Anyconnect IKEv2](#)
- [Implementación de FlexVPN: Acceso remoto AnyConnect IKEv2 con EAP-MD5](#)

Prerequisites

Requirements

Cisco recomienda que tenga conocimiento sobre estos temas:

- IKEv2
- Cisco FlexVPN
- Cisco AnyConnect Secure Mobility Client
- Cliente de Cisco VPN

Componentes Utilizados

Este documento no tiene restricciones específicas en cuanto a versiones de software y de hardware.

The information in this document was created from the devices in a specific lab environment. All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Convenciones


Consulte [Convenciones de Consejos TécnicosCisco](#) para obtener más información sobre las convenciones del documento.

EzVPN frente a FlexVPN

Modelo EzVPN: lo que destaca

Como sugiere el nombre, el objetivo de EzVPN es facilitar la configuración de VPN en los clientes remotos. Para lograr esto, el cliente se configura con los detalles mínimos necesarios para contactar con el servidor EzVPN correcto, también conocido como el perfil del cliente.

Negociación del túnel



Modelo de VPN de acceso remoto FlexVPN

Servidor FlexVPN

Una diferencia importante entre FlexVPN normal y una configuración de acceso remoto FlexVPN es que el servidor necesita autenticarse en los clientes FlexVPN únicamente mediante el uso del método de claves y certificados previamente compartidos (RSA-SIG). FlexVPN le permite decidir qué métodos de autenticación utiliza el iniciador y el respondedor, con independencia de los demás. En otras palabras, pueden ser iguales o pueden ser diferentes. Sin embargo, cuando se trata de FlexVPN Remote Access, el servidor no tiene opción.

Métodos de Autenticación del Cliente IOS FlexVPN

El cliente admite los siguientes métodos de autenticación:

- **RSA-SIG:** Autenticación de certificado digital.


- **Pre-Share:** autenticación de clave precompartida (PSK).
- **Protocolo de autenticación extensible (EAP)** - Autenticación EAP. EAP-Soporte para el cliente IOS FlexVPN se agregó en 15.2(3)T.Los métodos EAP admitidos por el cliente FlexVPN de IOS incluyen:Protocolo de autenticación extensible-Message Digest 5 (EAP-MD5),Protocolo de autenticación extensible: protocolo de autenticación por desafío mutuo de Microsoft versión 2 (EAP-MSCHAPv2), yProtocolo de autenticación extensible: tarjeta de testigo genérica (EAP-GTC).

Este documento sólo describe el uso de la autenticación RSA-SIG, por estas razones:

- **Escalable:** a cada cliente se le da un certificado y, en el servidor, una parte genérica de la identidad del cliente se autentica en su contra.
- **Seguro:** más seguro que un comodín PSK (en caso de autorización local). Aunque, en el caso de la autorización AAA (autenticación, autorización y contabilidad), es más fácil escribir PSK separados basándose en la identidad IKE manipulada.

La configuración del cliente FlexVPN que se muestra en este documento puede parecer poco exhaustiva en comparación con el cliente EasyVPN. Esto se debe a que la configuración incluye algunas partes de la configuración que el usuario no necesita configurar debido a los valores predeterminados inteligentes. Los valores predeterminados inteligentes son el término utilizado para referirse a la configuración preconfigurada o predeterminada para varias cosas como la propuesta, la política, el conjunto de transformación IPSec, etc. A diferencia de los valores predeterminados de IKEv1, los valores predeterminados inteligentes de IKEv2 son fuertes. Por ejemplo, utiliza el estándar de cifrado avanzado (AES-256), el algoritmo hash seguro (SHA-512) y el grupo 5 en las propuestas, y así sucesivamente.


[Negociación del túnel](#)



Para obtener más información sobre el intercambio de paquetes para un intercambio IKEv2, refiérase a [Intercambio de Paquetes IKEv2 y Debugging de Nivel de Protocolo](#).

Configuración inicial

Topología



Configuración inicial

Concentrador EzVPN - Basado en dVTI

```
!! AAA Config for EzVPN clients. We are using Local AAA Server.
aaa new-model
aaa authentication login default local
aaa authorization network default local

!! ISAKMP Policy
crypto isakmp policy 1
  encr 3des
  authentication pre-share
  group 2

!! ISAKMP On-Demand Keep-Alive
```

```

crypto isakmp keepalive 10 2

!! EzVPN Split ACL
access-list 101 permit ip 10.10.0.0 0.0.0.255 any

!! EzVPN Client Group Configuration. This is what holds all the config attributes
crypto isakmp client configuration group cisco
key cisco
dns 6.0.0.2
wins 7.0.0.1
domain cisco.com
acl 101
save-password

!! ISAKMP Profile. This ties Client IKE identity to AAA.
!! And since this is dVTI setup, ISAKMP Profile tells the IOS
!! from which Virtual-Template (VT1) to clone the Virtual Access interfaces
crypto isakmp profile vi
match identity group cisco
client authentication list default
isakmp authorization list default
virtual-template 1

!! IPSec Transform Set.
crypto ipsec transform-set set esp-3des esp-sha-hmac

!! IPSec Profile. This ties Transform set and ISAKMP Profile together.
crypto ipsec profile vi
set transform-set set
set isakmp-profile vi

!! The loopback interface. And virtual-template borrows the address from here.
interface Loopback0
ip address 10.10.10.1 255.255.255.252

!! dVTI interface.
interface Virtual-Template1 type tunnel
ip unnumbered Loopback0
tunnel mode ipsec ipv4
tunnel protection ipsec profile vi

```

Cliente EzVPN: clásico (sin VTI)

```

!! ISAKMP On-Demand Keep-Alive
crypto isakmp keepalive 10 2

!! EzVPN Client - Group Name and The key (as configured on the Server),
!! Peer address and XAUTH config go here.
crypto ipsec client ezvpn ez
connect auto
group cisco key cisco
local-address Ethernet0/0
mode network-extension
peer 10.0.0.1
username cisco password cisco
xauth userid mode local

!! EzVPn outside interface - i.e. WAN interface
interface Ethernet0/0
ip address 10.1.1.2 255.255.255.0

```

```

crypto ipsec client ezvpn ez

!! EzVPN inside interface
!! Traffic sourced from this LAN is sent over established Tunnel
interface Ethernet0/1
ip address 10.10.1.1 255.255.255.0
crypto ipsec client ezvpn ez inside

```

Cliente EzVPN: mejorado (basado en VTI)

```

!! VTI -
interface Virtual-Template1 type tunnel
no ip address
tunnel mode ipsec ipv4

!! ISAKMP On-Demand Keep-Alive
crypto isakmp keepalive 10 2

!! EzVPN Client - Group Name and The key (as configured on the Server),
!! Peer address and XAUTH config go here.
!! Also this config says which Virtual Template to use.
crypto ipsec client ezvpn ez
connect auto
group cisco key cisco
local-address Ethernet0/0
mode network-extension
peer 10.0.0.1
virtual-interface 1
username cisco password cisco
xauth userid mode local

!! EzVPn outside interface - WAN interface
interface Ethernet0/0
ip address 10.1.1.3 255.255.255.0
crypto ipsec client ezvpn ez

!! EzVPN inside interface -
!! Traffic sourced from this LAN is sent over established Tunnel
interface Ethernet0/1
ip address 10.10.2.1 255.255.255.0
crypto ipsec client ezvpn ez inside

```

Enfoque de migración de EzVPN a FlexVPN

El servidor que actúa como servidor EzVPN también puede actuar como servidor FlexVPN siempre que admita la configuración de acceso remoto IKEv2. Para obtener una compatibilidad de configuración IKEv2 completa, se recomienda cualquier valor superior a IOS v15.2(3)T. En estos ejemplos se ha utilizado 15.2(4)M1.

Hay dos enfoques posibles:


1. Configure el servidor EzVPN como servidor FlexVPN y, a continuación, migre los clientes EzVPN a la configuración Flex.
2. Configure un router diferente como servidor FlexVPN. Los clientes EzVPN y los clientes FlexVPN migrados continúan comunicándose mediante la creación de una conexión entre el servidor FlexVPN y el servidor EzVPN.

Este documento describe el segundo enfoque y utiliza un nuevo spoke (por ejemplo, Spoke3) como cliente FlexVPN. Este spoke se puede utilizar como referencia para migrar a otros clientes en el futuro.

Pasos de migración

Tenga en cuenta que cuando migre de un radio EzVPN a un radio FlexVPN, puede optar por cargar la **configuración FlexVPN** en el radio EzVPN. Sin embargo, a lo largo de todo el proceso de corte, es posible que necesite un acceso de administración fuera de banda (que no sea VPN) al dispositivo.

Topología migrada



Configuración

Concentrador FlexVPN

```

!! AAA Authorization done Locally
aaa new-model
aaa authorization network Flex local

!! PKI TrustPoint to Sign and Validate Certificates.
!! Contains Identity Certificate and CA Certificate
crypto pki trustpoint FlexServer
enrollment terminal
revocation-check none
rsakeypair FlexServer
subject-name CN=flexserver.cisco.com,OU=FlexVPN

!! Access-list used in Config-Reply in order to push routes
access-list 1 permit 10.10.0.0 0.0.0.255

!! IKEv2 Authorization done locally. Used in Config-Set.
crypto ikev2 authorization policy FlexClient-Author
def-domain cisco.com
route set interface
route set access-list 1

!! IKEv2 Proposal. Optional Config. Smart-Default takes care of this.
crypto ikev2 proposal FlexClient-Proposal
encryption aes-cbc-128 aes-cbc-192 3des
integrity sha256 sha512 sha1
group 5 2

!! If IKEv2 Proposal was left out default, then IKEv2 Policy can be left out too.
!! Ties Proposal to Peer address/fvrf
crypto ikev2 policy FlexClient-Policy
match fvrf any
proposal FlexClient-Proposal

!! IKEv2 Profile. This is the main Part
!! Clients are configured to send their FQDN. And we match the domain 'cisco.com'
!! We are sending 'flexserver.cisco.com' as the fqdn identity.
!! Local and Remote authentication is RSA-SIG
!! Authorization (config-reply) is done locally with the user-name
!! 'FlexClient-Author'
!! This whole profile is tied to Virtual-Template 1
crypto ikev2 profile FlexClient-Profile
match identity remote fqdn domain cisco.com
identity local fqdn flexserver.cisco.com
authentication remote rsa-sig
authentication local rsa-sig
pki trustpoint FlexServer
aaa authorization group cert list Flex FlexClient-Author
virtual-template 1

!! IPSec Transform set. Optional Config, since Smart Default takes care of this.
crypto ipsec transform-set ESP-AES-SHA1 esp-aes esp-sha-hmac

!! IPSec Profile ties default/Configured transform set with the IKEv2 Profile
crypto ipsec profile FlexClient-IPSec
set transform-set ESP-AES-SHA1
set ikev2-profile FlexClient-Profile

!! Loopback interface lends ip address to Virtual-template and
!! eventually to Virtual-Access interfaces spawned.
interface Loopback0
ip address 10.10.10.1 255.255.255.252

```

```

!! The IKEv2 enabled Virtual-Template
interface Virtual-Template1 type tunnel
ip unnumbered Loopback0
tunnel protection ipsec profile FlexClient-IPSec

!! WAN interface
interface Ethernet0/0
ip address 10.0.0.2 255.255.255.0

!! LAN interfaces
interface Ethernet0/1
ip address 10.10.0.1 255.255.255.0

```

Nota sobre certificados de servidor

Key Usage (KU) (Uso de claves) define el propósito o el uso esperado de la clave pública. Enhanced/Extended Key Usage (EKU) (Uso de clave mejorado/ampliado) (EKU)) limita el uso de la clave. FlexVPN requiere que el certificado del servidor tenga una EKU de **autenticación del servidor** (OID = 1.3.6.1.5.5.7.3.1) con los atributos KU de **firma digital y cifrado de clave** para que el certificado sea aceptado por el cliente.

```

FlexServer#show crypto pki certificates verbose
Certificate
  Status: Available
  Version: 3
  Certificate Serial Number (hex): 09
  Certificate Usage: General Purpose
  Issuer:
    l=lal-bagh
    c=IN
    o=Cisco
    ou=TAC
    cn=Praveen
  Subject:
    Name: flexserver.cisco.com
    ou=FlexVPN
    cn=flexserver.cisco.com
  CRL Distribution Points:
    http://10.48.67.33:80/Praveen/Praveen.crl
<snip>
  Signature Algorithm: MD5 with RSA Encryption
  Fingerprint MD5: F3646C9B 1CC26A81 C3CB2034 061302AA
  Fingerprint SHA1: 7E9E99D4 B66C70E3 CBA8C4DB DD94629C 023EEBE7
  X509v3 extensions:
    X509v3 Key Usage: E0000000
      Digital Signature
      Non Repudiation
      Key Encipherment
<snip>
  Authority Info Access:
  Extended Key Usage:
    Client Auth
    Server Auth
  Associated Trustpoints: FlexServer
  Storage: nvram:lal-bagh#9.cer
  Key Label: FlexServer
  Key storage device: private config

```

CA Certificate
<snip>

Configuración de cliente FlexVPN

```
!! AAA Authorization done Locally
aaa new-model
aaa authorization network Flex local

!! PKI TrustPoint to Sign and Validate Certificates.
!! Contains Identity Certificate and CA Certificate
crypto pki trustpoint Spoke3-Flex
enrollment terminal
revocation-check none
subject-name CN=spoke3.cisco.com,OU=FlexVPN
rsakeypair Spoke3-Flex

!! Access-list used in Config-Set in order to push routes
access-list 1 permit 10.10.3.0 0.0.0.255

!! IKEv2 Authorization done locally. Used in Config-Set.
crypto ikev2 authorization policy FlexClient-Author
route set interface
route set access-list 1

!! IKEv2 Proposal. Optional Config. Smart-Default takes care of this.
crypto ikev2 proposal FlexClient-Proposal
encryption aes-cbc-128 aes-cbc-192 3des
integrity sha256 sha512 sha1
group 5 2

!! If IKEv2 Proposal was left out default, then IKEv2 Policy can be left out too.
!! Ties Proposal to Peer address/fvrf
crypto ikev2 policy FlexClient-Policy
match fvrf any
proposal FlexClient-Proposal

!! IKEv2 Profile. This is the main Part
!! Server is configured to send its FQDN type IKE-ID,
!! and we match the domain 'cisco.com'
!! (If the IKE-ID type is DN (extracted from the certificate),
!! we will need a certificate map)
!! We are sending 'spoke3.cisco.com' as the IKE-identity of type fqdn.
!! Local and Remote authentication is RSA-SIG
!! Authorization (config-set) is done locally using the user-name filter
!! 'FlexClient-Author'
crypto ikev2 profile FlexClient-Profile
match identity remote fqdn flexserver.cisco.com
identity local fqdn spoke3.cisco.com
authentication remote rsa-sig
authentication local rsa-sig
pki trustpoint Spoke3-Flex
aaa authorization group cert list Flex FlexClient-Author

!! IPSec Transform set. Optional Config, since Smart Default takes care of this.
crypto ipsec transform-set ESP-AES-SHA1 esp-aes esp-sha-hmac

!! IPSec Profile ties the transform set with the IKEv2 Profile
crypto ipsec profile FlexClient-IPSec
```

```

set transform-set ESP-AES-SHA1
set ikev2-profile FlexClient-Profile

!! FlexVPN Client Tunnel interface.
!! If IP-Address of the tunnel is negotiated,
!!   FlexVPN server is capable of assigning an IP through Config-Set
interface Tunnel0
ip unnumbered Ethernet0/1
tunnel source Ethernet0/0
tunnel destination dynamic
tunnel protection ipsec profile FlexClient-IPSec

!! Final FlexVPN client Part.
!! Multiple backup Peer and/or Multiple Tunnel source interfaces can be configured
crypto ikev2 client flexvpn FlexClient
  peer 1 10.0.0.2
  client connect Tunnel0

!! WAN interface
interface Ethernet0/0
  ip address 10.1.1.4 255.255.255.248

!! LAN Interface
interface Ethernet0/1
  ip address 10.10.3.1 255.255.255.0

```

Nota sobre certificados de cliente

FlexVPN requiere que el certificado del cliente tenga una EKU de **autenticación del cliente** (OID = 1.3.6.1.5.5.7.3.2) con los atributos KU de **firma digital** y **cifrado de clave** para que el certificado sea aceptado por el servidor.

```

Spoke3#show crypto pki certificates verbose
Certificate
  Status: Available
  Version: 3
  Certificate Serial Number (hex): 08
  Certificate Usage: General Purpose
  Issuer:
    l=lal-bagh
    c=IN
    o=Cisco
    ou=TAC
    cn=Praveen
  Subject:
    Name: spoke3.cisco.com
    ou=FlexVPN
    cn=spoke3.cisco.com
<snip>
  Subject Key Info:
    Public Key Algorithm: rsaEncryption
    RSA Public Key: (1024 bit)
    Signature Algorithm: MD5 with RSA Encryption
    Fingerprint MD5: 2381D319 906177E1 F45019BC 61059BD5
    Fingerprint SHA1: D81FD705 653547F2 D0916710 E6B096A1 23F6C467
    X509v3 extensions:
      X509v3 Key Usage: E0000000
        Digital Signature
        Non Repudiation
        Key Encipherment
<snip>

```

```

Extended Key Usage:
  Client Auth
  Server Auth
Associated Trustpoints: Spoke3-Flex
Storage: nvram:lal-bagh#8.cer
Key Label: Spoke3-Flex
Key storage device: private config

```

CA Certificate
<snip>

Verificación de la Operación FlexVPN

Servidor FlexVPN

```

FlexServer#show crypto ikev2 session
IPv4 Crypto IKEv2 Session
Session-id:5, Status:UP-ACTIVE, IKE count:1, CHILD count:1

Tunnel-id Local           Remote           fvrf/ivrf       Status
1          10.0.0.2/500    10.1.1.4/500    none/none        READY
  Encr: AES-CBC, keysize: 192, Hash: SHA512, DH Grp:5, Auth sign: RSA, Auth verify:
  RSA
  Life/Active Time: 86400/7199 sec
Child sa: local selector 10.0.0.2/0 - 10.0.0.2/65535
          remote selector 10.1.1.4/0 - 10.1.1.4/65535
          ESP spi in/out: 0xA9571C00/0x822DDAAD

```

```
FlexServer#show crypto ikev2 session detailed
```

```

IPv4 Crypto IKEv2 Session

Session-id:5, Status:UP-ACTIVE, IKE count:1, CHILD count:1

Tunnel-id Local           Remote           fvrf/ivrf       Status
1          10.0.0.2/500    10.1.1.4/500    none/none        READY

  Encr: AES-CBC, keysize: 192, Hash: SHA512, DH Grp:5, Auth sign: RSA, Auth verify:
  RSA
  Life/Active Time: 86400/7244 sec
  CE id: 1016, Session-id: 5
  Status Description: Negotiation done
  Local spi: 648921093349609A      Remote spi: 1C2FFF727C8EA465
  Local id: flexserver.cisco.com
  Remote id: spoke3.cisco.com
  Local req msg id: 2            Remote req msg id: 5
  Local next msg id: 2           Remote next msg id: 5
  Local req queued: 2           Remote req queued: 5
  Local window: 5               Remote window: 5
  DPD configured for 0 seconds, retry 0
  NAT-T is not detected
  Cisco Trust Security SGT is disabled
  Initiator of SA : No
  Remote subnets:
```

```
10.10.3.0 255.255.255.0
```

```
Child sa: local selector 10.0.0.2/0 - 10.0.0.2/65535
      remote selector 10.1.1.4/0 - 10.1.1.4/65535
      ESP spi in/out: 0xA9571C00/0x822DDAAD
      AH spi in/out: 0x0/0x0
      CPI in/out: 0x0/0x0
      Encr: AES-CBC, keysize: 128, esp_hmac: SHA96
      ah_hmac: None, comp: IPCOMP_NONE, mode transport
```

```
FlexServer#show ip route static
  10.0.0.0/8 is variably subnetted, 9 subnets, 4 masks
S       10.10.3.0/30 is directly connected, Virtual-Access1
```

```
FlexServer#ping 10.10.3.1 repeat 100
```

```
Type escape sequence to abort.
Sending 100, 100-byte ICMP Echos to 10.10.3.1, timeout is 2 seconds:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Success rate is 100 percent (100/100), round-trip min/avg/max = 1/5/13 ms
```

```
FlexServer#show crypto ipsec sa | I ident|caps|spi
local  ident (addr/mask/prot/port): (10.0.0.2/255.255.255.255/47/0)
remote ident (addr/mask/prot/port): (10.1.1.4/255.255.255.255/47/0)
 #pkts encaps: 205, #pkts encrypt: 205, #pkts digest: 205
 #pkts decaps: 200, #pkts decrypt: 200, #pkts verify: 200
 current outbound spi: 0x822DDAAD(2184043181)
 spi: 0xA9571C00(2841058304)
 spi: 0x822DDAAD(2184043181)
```

[**Remoto FlexVPN**](#)

```
Spoke3#show crypto ikev2 session
IPv4 Crypto IKEv2 Session
Session-id:4, Status:UP-ACTIVE, IKE count:1, CHILD count:1

Tunnel-id Local                  Remote                  fvrif/ivrf          Status
1           10.1.1.4/500          10.0.0.2/500          none/none           READY
      Encr: AES-CBC, keysize: 192, Hash: SHA512, DH Grp:5, Auth sign: RSA, Auth verify:
      RSA
      Life/Active Time: 86400/7621 sec
Child sa: local selector 10.1.1.4/0 - 10.1.1.4/65535
      remote selector 10.0.0.2/0 - 10.0.0.2/65535
      ESP spi in/out: 0x822DDAAD/0xA9571C00
```

```
Spoke3#show crypto ikev2 session detailed
```

```
IPv4 Crypto IKEv2 Session
Session-id:4, Status:UP-ACTIVE, IKE count:1, CHILD count:1
```

Tunnel-id	Local	Remote	fvrif/ivrf	Status
-----------	-------	--------	------------	--------

1	10.1.1.4/500	10.0.0.2/500	none/none	READY
---	--------------	--------------	-----------	-------

```
Encr: AES-CBC, keysize: 192, Hash: SHA512, DH Grp:5, Auth sign: RSA, Auth verify: RSA
Life/Active Time: 86400/7612 sec
CE id: 1016, Session-id: 4
Status Description: Negotiation done
Local spi: 1C2FFF727C8EA465      Remote spi: 648921093349609A
Local id: spoke3.cisco.com
Remote id: flexserver.cisco.com
Local req msg id: 5            Remote req msg id: 2
Local next msg id: 5          Remote next msg id: 2
Local req queued: 5          Remote req queued: 2
Local window: 5              Remote window: 5
DPD configured for 0 seconds, retry 0
NAT-T is not detected
Cisco Trust Security SGT is disabled
Initiator of SA : Yes
Default Domain: cisco.com
Remote subnets:
10.10.10.1 255.255.255.255
10.10.0.0 255.255.255.0
```

```
Child sa: local selector 10.1.1.4/0 - 10.1.1.4/65535
          remote selector 10.0.0.2/0 - 10.0.0.2/65535
ESP spi in/out: 0x822DDAAD/0xA9571C00
AH spi in/out: 0x0/0x0
CPI in/out: 0x0/0x0
Encr: AES-CBC, keysize: 128, esp_hmac: SHA96
ah_hmac: None, comp: IPCOMP_NONE, mode transport
```

```
Spoke3#ping 10.10.0.1 repeat 100
```

```
Type escape sequence to abort.
Sending 100, 100-byte ICMP Echos to 10.10.0.1, timeout is 2 seconds:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!Success rate is 100 percent (100/100), round-trip min/avg/max = 1/5/12 ms
```

```
Spoke3#show crypto ipsec sa | i ident|caps|spi
local ident (addr/mask/prot/port): (10.1.1.4/255.255.255.255/47/0)
remote ident (addr/mask/prot/port): (10.0.0.2/255.255.255.255/47/0)
#pkts encaps: 300, #pkts encrypt: 300, #pkts digest: 300
#pkts decaps: 309, #pkts decrypt: 309, #pkts verify: 309
current outbound spi: 0xA9571C00(2841058304)
spi: 0x822DDAAD(2184043181)
spi: 0xA9571C00(2841058304)
```

Información Relacionada

- [FlexVPN: IKEv2 con cliente de Windows integrado y TechNote de autenticación de certificados](#)
- [Ejemplo de Configuración de Cliente FlexVPN y Anyconnect IKEv2 TechNote](#)
- [Implementación de FlexVPN: Acceso remoto AnyConnect IKEv2 con EAP-MD5 TechNote](#)
- [IKEv2 Packet Exchange y Protocol Level Debugging TechNote](#)

- [Cisco FlexVPN](#)
- [Negociación IPsec/Protocolos IKE](#)
- [Cisco AnyConnect Secure Mobility Client](#)
- [Cliente de Cisco VPN](#)
- [Soporte Técnico y Documentación - Cisco Systems](#)