

<#root>

N5K-A#

show feature | include fcoe

fcoe 1 enabled

fcoe-npv 1 disabled

show interface brief CLI

show interface brief

<#root>

N5K-A#

show interface brief

Interface	Vsan	Admin Mode	Admin Trunk Mode	Status	SFP	Oper Mode	Oper Speed (Gbps)	Port Channel
fc1/29	200	F	off	notConnected	sw1	--	200	
fc1/30	200	F	off	notConnected	sw1	--	200	
fc1/31	100	F	off	notConnected	sw1	--	100	
fc1/32	100	F	off	notConnected	sw1	--	100	

Ethernet Interface	VLAN	Type	Mode	Status	Reason	Speed	Port Ch #
Eth1/1	1	eth	trunk	down	SFP not inserted	10G(D)	--
Eth1/2	1	eth	access	down	SFP not inserted	10G(D)	--

<snip>

Port	VRF	Status	IP Address	Speed	MTU
mgmt0	--	up	192.168.1.2	100	1500

Interface	Vsan	Admin Mode	Admin Trunk Mode	Status	Bind Info	Oper Mode	Oper Speed (Gbps)
vfc100	100	F	on	trunking	00:10:94:00:00:02	TF	auto
vfc111	100	F	on	trunking	Eth1/1		
vfc200	200	F	on	trunking	00:20:94:00:00:02	TF	auto

show interface brief

ã,»ã,ãfYãfãfã,£ä³/4µ®³ã®ç—•è·j

ã€œ.†ã¼+æ€§ãœã~åœ¨ã™ã,è£½ã”ã€œã,»ã,ã,ãfSãJãSæ|,èª-ã•ã,œã|ã,ã,ã,ã,ã†ã

<#root>

N6K-A#

show interface eth1/2 counters brief

Interface	Input Rate (avg)		Output Rate (avg)		Rate averaging interval (seconds)
	Rate MB/s	Total Frames	Rate MB/s	Total Frames	
Eth1/2	1140	5482344	1140	5482507	30
	1140	5482321	1140	5482488	300

N6K-A#

show interface Ethernet 1/11 counters brief

Interface	Input Rate (avg)		Output Rate (avg)		Rate averaging interval (seconds)
	Rate MB/s	Total Frames	Rate MB/s	Total Frames	
Eth1/11	0	0	1140	5482508	30
	0	0	1140	5482496	300

N6K-A#

show interface Ethernet 1/16 counters brief

Interface	Input Rate (avg)		Output Rate (avg)		Rate averaging interval (seconds)
	Rate MB/s	Total Frames	Rate MB/s	Total Frames	
Eth1/16	0	0	1140	5482504	30
	0	0	1140	5482565	300

ãf†ãfã,ªã,¹ã®ã†°ãŠ>ã€œã¾ãYã-ã,Šè~ã®æf...ã±ã«é-Çã—ã|ä,æ~Žãª,¹ãœã TACã¾ãšãŠã,ã,ã,ã>ããããããã,ã€,

URL

<https://sec.cloudapps.cisco.com/security/center/content/CiscoSecurityAdvisory/cisco-sa-20190306-nexus-fbr-dos>

æ''¹è¨,å±¥æ´

ãfãf¼ã,ãfšãf³	èª-æ~Ž	ã,»ã,ã,ãfšãf³	ã,¹ãf†ãf¹¼ã,¿ã,¹	æ—¥ä»~
1.0	å^å>žå...-é-ãfªãfªãf¼ã,¹	-	Final	2019 å¹´ 3 æœˆ 6 æ—¥

å^©ç''è!ç´,,

æœ-ã,çãf%ãfã,ã,ã,¶ã,¶ãfªãç,,jã¿è¨¼ã¼ã@ã,,ãã@ãã¨ãã—ãã|ãã"æããã¼ãã—ãã|ããŠã,Šã€æœ-ã,çãf%ãfã,ã,ã,¶ã,¶ãfªãã@æf...å±ããŠã,^ãã³ãfªãfªã,ãã@ã¼¿ç''ãã«é-çãã™ã,«è²-ã»ãã@ã,€ãã¼ããÿã€ãã,ã,¹ã,³ããæœ-ãf%ãã,ãf¥ãf;ãf³ãf^ãã@ãt...ã@¹ã,'ã^ã'Sãããã—ãã«ã%ãæ'ãã—ããæœ-ã,çãf%ãfã,ã,ã,¶ã,¶ãfªãã@è¨~è:°ãt...ã@¹ãã«é-çãã—ãã|æf...å±é...ã¿jãã@ URLã,'çœçç¥ãã—ã€ããçç<-ãã@è»çè¼%ãã,,æ,,è¨³ã,'æ-½ãã—ããÿã'ãã^ã€ãã½"çã¼ãã€çç@ççãã"ãã@ãf%ãã,ãf¥ãf;ãf³ãf^ãã@æf...å±ããããã,ã,¹ã,³è£½ã"ãã@ã,,ãf³ãf%ããf'ãf¼ã,¶ã,'ã³¼è±jã

翻訳について

シスコは世界中のユーザにそれぞれの言語でサポート コンテンツを提供するために、機械と人による翻訳を組み合わせて、本ドキュメントを翻訳しています。ただし、最高度の機械翻訳であっても、専門家による翻訳のような正確性は確保されません。シスコは、これら翻訳の正確性について法的責任を負いません。原典である英語版（リンクからアクセス可能）もあわせて参照することを推奨します。