

CUAC Advanced サーバのロギング パスの設定

内容

[概要](#)

[前提条件](#)

[要件](#)

[使用するコンポーネント](#)

[ロギングロケーションの変更方法](#)

[SRVロギング\(ICD.log\)](#)

[Web管理ロギング](#)

[LDAPロギング\(ldaptrace/ldapwarning.log\)](#)

[CUPSロギング\(cupsplugin.log\)](#)

[CTIサーバ\(ctiserverlog\)](#)

[確認](#)

[トラブルシューティング](#)

[関連するシスコ サポート コミュニティ ディスカッション](#)

Cisco Unified Attendant Console Advanced(CUAC)C:\Program Files (x86)\Cisco\Logging


- CUAC
- Microsoft Windows 2008 Server

- CUAC 10.x
- Microsoft Windows 2008 Server

SRV(ICD.log)

1.

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Arc Solutions\Call Connect\Server\Runtime Logging




2. Logging File Name

Web

1.

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Arc Solutions\Call Connect\Web Admin\Runtime Logging




2. Logging File name

LDAP(ldaptrace/ldapwarning.log)

1.レジストリエディタで指定した場所に移動します。

Computer\HKEY_LOCAL_MACHINE\SOFTWARE\Wow6432Node\Arc Solutions\Call Connect\LDAP Synchronize Server\Runtime Logging




2. Logging File Name

CUPS(cupsplugin.log)

C:\Program Files (x86)\Cisco\CUPS

1. Cisco Presence Server Plug-in.exeXML




2. XML

CTI(ctiserverlog)

C:\Program Files (x86)\Cisco\CUPS

1. CTI Server.exeXML



The screenshot shows a Windows Explorer window titled "CTI Server" with the address bar set to "Computer > Local Disk (C:) > Program Files (x86) > Cisco > CTI Server". The file list includes folders like "DriverInstance" and "Repository", and files such as "acthmq-cpp.dll", "CodeLib.dll", "CTI Server", "CTI Server.exe", and "CTIAudioConversionLib.dll". The "CTI Server.exe" file is selected, and its properties are shown at the bottom: "CTI Server.exe", "XML Configuration File", "328'557 bytes".

Overlaid on the Explorer window is a Microsoft Visual Studio Tools for Applications 2.0 (Administrator) window titled "CTI Server.exe.config". The XML content is as follows:

```
<?xml version="1.0" encoding="utf-8"?>
<configuration>
  <appSettings>
    <add key="LoggingFilename" value="C:\Program Files (x86)\Cisco\Logging\CTIS\Log\cti-
    <add key="LoggingServer" value="0"/>
    <add key="LoggingMaxFiles" value="100"/>
    <add key="LoggingMaxFileLines" value="100000"/>
    <add key="ServerIP" value="CUACPUB10"/>
    <add key="ServerPort" value="1864"/>
    <add key="ServerMaxThreads" value="5"/>
    <add key="ServerMaxConnections" value="20"/>
    <add key="Encoding" value="Unicode"/>
  </appSettings>
</configuration>
```

2. XML