



イベント ログ メッセージ

イベント ログ メッセージは、次のモジュールで使用できます。

- 「CER_DATABASE」
- 「CER_SYSADMIN」
- 「CER_TELEPHONY」
- 「CER_AGGREGATOR」
- 「CER_GROUP」
- 「CER_CALLENGINE」
- 「CER_CLUSTER」
- 「CER_ONSITEALERT」

CER_DATABASE

表 H-1 CER_DATABASE のイベント ログ メッセージ

タイプ	メッセージ
INFO	Failed to get the fully qualified host name.DNS might not be enabled.Putting Ipaddress in Cluster database.
ERROR	CER Server Memory Usage is HIGH, above threshold value of 80%.Memory Figures: <MEMORY USAGE INFO>.
ERROR	Database replication broken.
ERROR	Number of <NUM> limit exceeded.Fetching only a maximum of *** <NUM> *** entries.

CER_SYSADMIN

表 H-2 CER_SYSADMIN のイベント ログ メッセージ

タイプ	メッセージ
ERROR	Failed to add this CER group to CER cluster
WARNING	<p>Cisco ER cluster functionality will not work till this problem is fixed.</p> <ol style="list-style-type: none"> 1. Check if "CERCluster password" is same as in Cisco ER ClusterDB. 2. Check if Cisco Tomcat and Database services are running on Cisco ER ClusterDB. 3. Check if Cisco ER ClusterDB Hostname is correct and accessible
ERROR	Failed to initialize LDAP.

CER_TELEPHONY

表 H-3 CER_TELEPHONY のイベント ログ メッセージ

タイプ	メッセージ
WARNING	<p>Emergency call from <CALLING ADDRESS> has been routed to default ERL because calling party modification failed.</p> <p>Please make sure that the checkbox "Enable Calling Party Number Modification" is checked on the Call Manager user page for the CER user.PSAP callbacks MAY NOT work correctly.The CER service will need to be restarted once the flag is checked on the Call Manager User page.</p>
WARNING	<p>Emergency call from <calling address> could not be routed using the following Routepatterns.</p> <p><LIST OF RP's></p> <p>Call Routed to <RP/NUMBER></p> <p>Please check the availability of the above routes.</p> <p>Also,Check for the following error conditions:</p> <ol style="list-style-type: none"> 1. If FAC and/or CMC are configured on the route patterns used for CER, please disable them. 2. If the "Calling Party Number Modification" flag on the CER user page in the call manager is not enabled, please enable it.
ERROR	Failed to load class <CLASS NAME>.
ERROR	CCMString is empty can't load telephony classes.
WARNING	Got OutOfService event from provider : <PROVIDER_NAME>.
INFO	Got InService event from provider : <PROVIDER_NAME>.
WARNING	Logged out of the duplicate provider - <CTI_Manager> from CER.Specify the CTI Ports (if any) of this provider, in a different CCM node.

表 H-3 CER_TELEPHONY のイベント ログ メッセージ (続き)

タイプ	メッセージ
ERROR	Cannot register media terminal for port: <PORT_NUMBER>.
WARNING	CTI Port :<PORT_NUMBER> is in OUTFSERVICE, trying after 10 seconds.
ERROR	Mediachannel creation failed: <ERROR>.
WARNING	Failed to create media channel for : <PORT_NUMBER>.
ERROR	Failed to initiate call to security : <NUMBER> <ERROR>. <ERROR> corresponds to: <ul style="list-style-type: none"> • PrivilegeViolationException • InvalidPartyException • MethodNotSupportedException • InvalidArgumentException • InvalidStateException • E911CallRouterException • <Other Exceptions (if any)>
ERROR	Failed to register route point : <ROUTE_PATTERN> with Provider : <PROVIDER_NAME> .
ERROR	RouteAddress : <ADDRESS> is in OUTFSERVICE.
WARNING	<ADDRESS> Route Point received IN_SERVICE event from Provider <NAME>.
WARNING	<ADDRESS> Route Point received OUT_OF_SERVICE event from Provider <NAME>.

表 H-3 CER_TELEPHONY のイベント ログメッセージ (続き)

タイプ	メッセージ
ERROR	<p>PSAP Callback failed for : <NUMBER></p> <p>"Address = "+callingAddress+" ; Terminal = "+callingTerminal; because, routeEndEvent returned : < EXCEPTION></p> <p>Exception can be:</p> <ul style="list-style-type: none"> • CAUSE_INVALID_DESTINATION • CAUSE_ROUTING_TIMER_EXPIRED • CAUSE_PARAMETER_NOT_SUPPORTED • CAUSE_STATE_INCOMPATIBLE • CAUSE_UNSPECIFIED_ERROR <p>ERROR_RESOURCE_BUSY.Please check availability of the Routes</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_FAC_NEEDED.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_CMC_NEEDED.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_FAC_CMC_NEEDED.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_FAC_INVALID.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_CMC_INVALID.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p>

表 H-3 CER_TELEPHONY のイベント ログ メッセージ (続き)

タイプ	メッセージ
ERROR	<p>Call failed to reach PSAP for : <NUMBER></p> <p>"Address = "+callingAddress+" ; Terminal = "+callingTerminal; because, routeEndEvent returned : <EXCEPTION></p> <p>Exception can be:</p> <ul style="list-style-type: none"> • CAUSE_INVALID_DESTINATION • CAUSE_ROUTING_TIMER_EXPIRED • CAUSE_PARAMETER_NOT_SUPPORTED • CAUSE_STATE_INCOMPATIBLE • CAUSE_UNSPECIFIED_ERROR <p>ERROR_RESOURCE_BUSY.Please check availability of the Routes</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_FAC_NEEDED.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_CMC_NEEDED.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_FAC_CMC_NEEDED.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_FAC_INVALID.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p> <p>CAUSE_CTIERR_FAC_CMC_REASON_CMC_INVALID.Please Uncheck the Requirement of FAC/CMC codes on the Route points used by the Cisco Emergency Responder.</p>
WARNING	<p>Call from <CALLER_ID> could not be routed to the Intrado ERL.Possible reasons: The TN Update to Intrado for the Intrado ERL may not yet happened or has met with errors.</p>
WARNING	<p>Call from <CALLER ID> could not be routed to the Offpremies ERL.Possible reasons: The phone-location association has not yet happened or has met with errors.</p>
WARNING	Failed to get the JTAPl Provider for : <NAME_STRING> trying infinitely.
WARNING	Not registering the provider : <PROVIDER_NAME> as is already registered/in the same CCM Cluster as that of :<element>.
WARNING	JTAPl logs are not enabled as the logs path is empty in E911Bootstrap properties.
ERROR	Failed to get the JTAPl Provider for : <IP Address/Host Name> after <NUMBER> attempts.
WARNING	Currently, no CTI Ports are available to place the call for <CallingAddress>.Phone notification will be retried in the next 60 seconds.

CER_AGGREGATOR

表 H-4 CER_AGGREGATOR のイベント ログ メッセージ

タイプ	メッセージ
WARNING	Device <IP Address> is SNMP unreachable. Please check SNMP settings in CER and also on this CCM. Please confirm proper access privilege (READ_ONLY) set on this box for SNMP service. Also, verify n/w connectivity.
WARNING	During discovery some devices are unreachable. List of Unreachable Switches <List>.
WARNING	WARNING During discovery some devices are unreachable. List of Unreachable CCMs <List>.
WARNING	CERServer could not communicate with CERPhoneTrackingEngine.
WARNING	CERServer could not communicate with CERPhoneTrackingEngine.
INFO	Device <IP Address> is SNMP unreachable. Please check SNMP settings in CER and also on this CCM. Please confirm proper access privilege (READ_ONLY) set on this box for SNMP service. Also, verify n/w connectivity.
INFO	Error in resolving HostName -> IPAddress through DNS, ignoring the seed from DE <IP Address>.
INFO	IP Address mismatch detected ,OLD_IP <IP Address> NEW_IP <IP Address> SEED <IP Address> for any changed configuration, deletion and re addition of seed device is recommended.
INFO	Device <IP Address> is not a valid switch.
INFO	Device <IP Address> is SNMP Un-reachable.
INFO	Device <IP Address> is not supported.
INFO	This Device <IP Address> is identified for a different device family than earlier discovered, ignored for this discovery cycle.
INFO	Failed to retrieve SysOid of a device <IP Address> Please check if device is SNMP reachable.
INFO	This device is not supported <seed>.
INFO	This Device <IP Address> is earlier discovered with different device family. Please note, for changed device config.(ipAddress, deviceFamily, dnsName), delete and re-add the device is must, also you need to re-enter SNMP community string if changed from earlier one.
INFO	The device <IP Address> is not a valid switch...please confirm.
INFO	This device not a valid CCM to discover <IP Address>.
INFO	Error in resolving HostName -> IPAddress , ignoring the seed for discovery <IP Address>.

表 H-4 CER_AGGREGATOR のイベント ログメッセージ (続き)

タイプ	メッセージ
INFO	IP Address mismatch detected ,OLD_IP <IP Address> NEW_IP <IP Address> SEED <IP Address> for any changed configuration, deletion and re addition of seed device is recommended.
INFO	Device <IP Address> is not a valid CCM.

CER_GROUP

表 H-5 CER_GROUP のイベント ログメッセージ

タイプ	メッセージ
INFO	Active Cisco Emergency Responder set to: <Server Details>.
INFO	Connection established with Cisco Emergency Responder: <PEER>.
WARNING	Disconnected from Cisco Emergency Responder : <PEER>.
ERROR	Cisco ER Couldn't open socket at port <NUMBER>, Exiting.
WARNING	Failed to open connection with Cisco Emergency Responder: <_remoteAddress> / <_remotePort>.

CER_CALLENGINE

表 H-6 CER_CALLENGINE のイベント ログメッセージ

タイプ	メッセージ
INFO	Cisco ER Exiting : <MSG> Graceful shutdown.
ERROR	Problem in initialising SERVER (Server Group).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising Database (E911ServerGroupParameters).Retried... <COUNT> times.
ERROR	Problem in initialising SERVER (Server).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising Database (Server).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising Database (CERServers).Retried... <COUNT> times.
ERROR	Problem in initialising SERVER (License).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising SERVER (Zone).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising SERVER (DiscoveryEngine).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising SERVER (CERIPSubnetManager).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising SERVER (CERVHMPhoneManager).Cannot continue ... <EXCEPTION>.

表 H-6 CER_CALLENGINE のイベント ログメッセージ (続き)

タイプ	メッセージ
ERROR	Problem in initialising SERVER (CCM Cluster - No Call Manager seeds configured).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising SERVER (Seed Switch).Cannot continue ... <EXCEPTION>.
ERROR	Problem in initialising SERVER (Discrepant entry).Cannot continue ... <EXCEPTION>C96.
ERROR	Problem in initialising SERVER (Security Contact).Cannot continue ... <EXCEPTION>.
ERROR	Problem in refreshing LDAP (Server Group).Cannot continue ...
ERROR	Problem in refreshing LDAP (Zone).Cannot continue ...
ERROR	Problem in refreshing LDAP (Server).Cannot continue ...
ERROR	Problem in refreshing LDAP (Seed Switch).Cannot continue ...
ERROR	Problem in refreshing LDAP (CCM Cluster).Cannot continue ...
ERROR	Problem in refreshing LDAP (Discrepant entry).Cannot continue ...
ERROR	Problem in refreshing LDAP (Security Contact).Cannot continue ...
ERROR	Problem in refreshing LDAP (Security Contact).Cannot continue ...
ERROR	Problem in refreshing zone port tree (Switchport to zone map).Cannot continue ...
ERROR	LicenseManager : End Of 60 Day Evaluation Period.CER Will not work.Please upload a valid License file".
ERROR	End Of 30 Day Grace Period.Please upload a valid license file for CER to function.Current License MAC : <License MAC value>
WARNING	Warning!!!You have exhausted all your user licenses.Please purchase additional user licenses. Number of phones being tracked/configured : <num> Total user license : <num>
INFO	License MAC change is detected in the system.System will now operate in 30 day grace period.Please upload a valid license before grace period expires.
INFO	user license count could not be read.
INFO	Reason :
WARNING	License manager Init: Error loading license, Possibly there is no license file.
WARNING	License checkout failed : <message>.

CER_CLUSTER

表 H-7 CER_CLUSTER のイベント ログメッセージ

タイプ	メッセージ
WARNING	IntraCluster Communication failed to ServerGroup with servers Master:<SERVER DETAILS> StandBy : <SERVER DETAILS>.

CER_ONSITEALERT

表 H-8 CER_ONSITEALERT のイベント ログ メッセージ

タイプ	メッセージ
WARNING	Backup Cisco ER <hostname> has taken control as Active Cisco ER. Transition time : <timestamp>.
WARNING	Master Cisco ER <hostname> has taken control as Active Cisco ER. Transition Time : <timestamp>.
WARNING	Emergency call Details Caller Extension: <num> Call Time : <time>
WARNING	Emergency call Details Caller Extension: <num> Zone/ERL : <zone> LOCATION : <location> Call Time : <time>

