

# 创建vSmart CLI模板以推送集中策略

## 目录

---

[简介](#)

[先决条件](#)

[要求](#)

[使用的组件](#)

[问题](#)

[解决方案](#)

[步骤1:确认vSmarts处于具有稳定控制连接的CLI模式](#)

[第二步：创建CLI模板](#)

[第三步：将新CLI模板推送到vSmart](#)

[相关信息](#)

---

## 简介

本文档介绍一种为vSmarts创建CLI模板的简单方法，因为需要它们来推送重叠的集中策略。

## 先决条件

### 要求

这些主题的基础知识：

- [SD-WAN通用解决方案概述](#)
- [vManage模板](#)
- [集中式](#)

### 使用的组件

本文档中的信息基于以下软件和硬件版本：

- vManage版本20.6.4
- vBond版本20.6.4
- vSmart版本20.6.4

本文档中的信息都是基于特定实验室环境中的设备编写的。本文档中使用的所有设备最初均采用原始（默认）配置。如果您的网络处于活动状态，请确保您了解所有命令的潜在影响。

## 问题

激活集中策略后，可以看到错误消息Failed to activate policy vSmarts x.x.x.x not in vManage

mode。

# Activate Policy



## Failed to activate policy

vSmarts [redacted] 3.1 are not in vManage mode

Cancel

## 解决方案


步骤1:确认vSmarts处于具有稳定控制连接的CLI模式

在此步骤中，您需要验证vManage和vSmart之间的控制连接是否正常且稳定。这是推入模板所必需的。

导航到vManage > Monitor > Network > vSmart。

 注意：从20.9版及更高版本导航到vManage > Monitor > Devices >vSmart。

请注意可接通性和Up Since。




The screenshot shows the Cisco vManage interface for monitoring network devices. The page title is "Monitor · Network". There are tabs for "WAN - Edge" and "Colocation Clusters". The "WAN - Edge" tab is active. The page displays a table of devices with columns for Hostname, System IP, Device Model, Chassis Number/ID, State, Reachability, Site ID, BFD, Control, Version, Up Since, and Device Groups. The table contains three rows of data.

Hostname	System IP	Device Model	Chassis Number/ID	State	Reachability	Site ID	BFD	Control	Version	Up Since	Device Groups
vmanage_20_6_4	[redacted].1	vManage	f1310071-c808-47aa-bd18-22...	●	reachable	10	--	6	20.6.4	23 Jan 2023 1:19:00 PM CST	No groups
vsmart1_20_6_4	[redacted].1	vSmart	13fafb25-b8c1-4083-835d-27...	●	reachable	10	--	6	20.6.4	22 Mar 2023 7:29:00 AM CST	No groups
vbond_20_6_4	[redacted].1	vEdge Cloud (vB...	5b063548-f955-425d-b94e-fc...	●	reachable	10	--	--	20.6.4	26 Dec 2022 2:29:00 AM CST	No groups

## 第二步：创建CLI模板

在此步骤中，您需要将运行配置从vSmart加载到CLI模板。vManage有一个选项，可将配置自动加载到模板中。

导航到vManage > Configuration > Templates > Create Template > CLI Template。



Cisco vManage Select Resource Group Configuration - Templates

Device Model: Select Device Model


Template Name:

Description:

CLI Configuration: Load Running config from reachable device: - Select - Search (x) Create Variable Encrypt Type6 Select a File

Config Preview: 1

填写所有必需的模板参数作为Template Name和Description。



Cisco vManage Select Resource Group Configuration - Templates

Device Model: vSmart


Template Name: vSmart\_East

Description: Template for vSmart East

CLI Configuration: Load Running config from reachable device: - Select - Search (x) Create Variable Encrypt Type6 Select a File

Config Preview

单击Next以从可访问设备加载运行配置，选择所需设备的配置。



Load Running config from reachable device: - Select -

3.1 - vsmart1\_20\_6\_4

vManage会自动将运行配置从设备加载到CLI模板。

Cisco vManage Configuration · Templates

Device Feature

Device Model: vSmart

Template Name: vSmart\_East

Description: Template for vSmart East

CLI Configuration: Load Running config from reachable device: 3.1 - vsmart1\_20\_6\_4

Config Preview

```

1 system
2 host-name vsmart1_20_6_4
3 system-ip 3.1
4 site-id 10
5 admin-tech-on-failure
6 no vrrp-adv-t-with-phy-mac
7 organization-name CISCORPLAB
8 clock timezone America/Detroit
9 vbond 192.168.18.189
10
11 ooo
12 auth-order local radius tacacs
13 usergroup basic
14 task system read
15 task interface read
16 !
17 usergroup netadmin
18 !
19 usergroup operator
20 task system read
21 task interface read
22 task policy read
23 task routing read
24 task security read
25 !
26 usergroup tenantadmin
27 !
28 user admin
29 password $6$75F48285de4ada305b/9R340279MjxutEyiHgKUL/CiA7wMM4dPN3R5y90eYMRX1E.F422QsJdLKZYKntaVklFmy5SPbpQz.98kNn/
30 !
31 ciscotacw-user true
32 ciscotacw-user true
33 !
34

```

Add Cancel

单击Add以创建模板。

### 第三步：将新CLI模板推送到vSmart

在此步骤中，您需要将刚刚创建的模板推送到正确的vSmart。

导航到vManage > Configuration > Templates > Template you just created > ... > 连接设备。

Cisco vManage Configuration · Templates

Device Feature

Search

Create Template

Template Type: Non-Default

Total Rows: 7

Name	Description	Type	Device Model	Device Role	Resource Group	Feature Templates	Draft Mode	Devices Attached	Updated By	Last Updated	Template Status
cedge1_base_config	cedge1_base_config	CLI	C8000v	global	global	0	Disabled	0	admin	06 Dec 2022 7:3...	In Sync
cedge2_base_config	cedge2_base_config	CLI	C8000v	global	global	0	Disabled	0	admin	06 Dec 2022 7:3...	In Sync
cedge3_base_config	cedge3_base_config	CLI	C8000v	global	global	0	Disabled	0	admin	06 Dec 2022 7:3...	In Sync
vSmart_FW	vSmart_FW	CLI	vSmart	global	global	0	Disabled	1	admin	15 Feb 2023 1:5...	In Sync
cedge2_template	cedge2_template	CLI	C8000v	global	global	0	Disabled	0	admin	23 Jan 2023 7:5...	In Sync
<b>vSmart_East</b>	<b>Template for vSmart East</b>	<b>CLI</b>	<b>vSmart</b>	<b>global</b>	<b>global</b>	<b>0</b>	<b>Disabled</b>	<b>0</b>	<b>admin</b>	<b>03 Apr 2023 3:4...</b>	<b>In Sync</b>
test_cedge	test cedge	Feature	C1101-4P	SOWAN Edge	global	10	Disabled	0	admin	16 Jan 2023 12:...	In Sync

## Attach Devices

Attach device from the list below

Available Devices  Select All

All

Name	Device IP
vsmart1_20_6_4	10.10.10.1

0 Items Selected

Selected Devices  Select All

All

Name	Device IP
------	-----------

Attach

Cancel

选择需要将模板推到的设备，然后将其推到右侧。然后，单击Attach。

## Attach Devices

Attach device from the list below

Available Devices  Select All

All

Name	Device IP
------	-----------

1 Items Selected

Selected Devices  Select All


All

Name	Device IP
vsmart1_20_6_4	10.10.10.1

Attach


Cancel

在左侧，单击vSmart Serial Number查看配置。



最后，单击Configure Devices推送模板。

要确认已推送模板，请导航到vManage > Configuration > Devices > Controllers > vSmart。



此时，您可以激活已配置的集中策略。

## 相关信息

[Cisco SD-WAN入门指南](#)

[Cisco SD-WAN策略配置指南，Cisco IOS XE版本17.x](#)

## 关于此翻译

思科采用人工翻译与机器翻译相结合的方式将此文档翻译成不同语言，希望全球的用户都能通过各自的语言得到支持性的内容。

请注意：即使是最好的机器翻译，其准确度也不及专业翻译人员的水平。

Cisco Systems, Inc. 对于翻译的准确性不承担任何责任，并建议您总是参考英文原始文档（已提供链接）。