

在IP電話7841上安裝電話區域設定

目錄

[簡介](#)

[必要條件](#)

[需求](#)

[採用元件](#)

[背景資訊](#)

[設定](#)

[組態](#)

[驗證](#)

[疑難排解](#)

簡介

本文檔介紹如何在Cisco 7841系列IP電話上安裝電話區域設定。

必要條件

需求

本文件沒有特定需求。

採用元件

本文中的資訊係根據以下軟體和硬體版本：

- 思科整合通訊管理員12.x
- Cisco IP電話7841

本文中的資訊是根據特定實驗室環境內的裝置所建立。文中使用到的所有裝置皆從已清除（預設）的組態來啟動。如果您的網路運作中，請確保您瞭解任何指令可能造成的影響。

背景資訊

Cisco Unified Communications Manager(CUCM)為12種語言（包括英語和16個國家/地區，包括美國）提供系統定義的本地化支援。網路區域設定指定特定於國家/地區的色調和節奏；使用者區域設定指定用於文本顯示的語言。

設定

組態

以下是執行電話硬式出廠重設的程式：

步驟1.從思科網站下載區域設定。

Downloads Home / Collaboration Endpoints / IP Phones / IP Phone 7800 Series / IP Phone 7841 / Unified Communications Manager Endpoints Locale Installer- 12.1(1.1000)

IP Phone 7841

Release 12.1(1.1000) Related Links and Documentation

Notifications - No related links or documentation -

File Information	Release Date	Size	
Cisco Unified Communications Locale Installer 12.1.1.1000 Arabic (United Arab Emirates) for Cisco Unified IP Phones FW 12.1(1) po-locale-ar_AE-k3-12.1.1.1000-1.cop.sgn	27-MAR-2018	2.89 MB	↓ 🛒 📄
Cisco Unified Communications Locale Installer 12.1.1.1000 Arabic (Bahrain) for Cisco Unified IP Phones FW 12.1(1) po-locale-ar_BH-k3-12.1.1.1000-1.cop.sgn	27-MAR-2018	2.88 MB	↓ 🛒 📄
Cisco Unified Communications Locale Installer 12.1.1.1000 Arabic (Algeria) for Cisco Unified IP Phones	27-MAR-2018	2.88 MB	↓ 🛒 📄

步驟2.導覽至OS Administration > Software Upgrades > Install/Upgrade。

Cisco Unified Operating System Administration

For Cisco Unified Communications Solutions

Show Settings Security **Software Upgrades** Services Help

Install/Upgrade

TFTP File Management

Install/Upgrade

Customized Logon Message

Branding

WARNING: It is recommended to perform a successful backup. Please verify backup configuration.

Cisco Unified Operating System Administration

System version: 12.0.0.99834-4

VMware Installation: 2 vCPU Intel(R) Xeon(R) CPU E5-2697A v4 @ 2.60GHz, disk 1: 110Gbytes, 8192Mbytes RAM, **ERROR: UNSUPPORTED: Partitions unaligned**
WARNING: DNS unreachable

User admin last logged in to this cluster on Friday, June 29, 2018 3:39:36 PM IST, to node 10.106.111.182, from 10.196.121.10 using HTTPS
User admin failed to log in 1 times!
Most recent failure Sunday, July 1, 2018 5:26:34 PM IST, to 10.106.111.182, from 10.65.43.63 using HTTPS

Copyright © 1999 - 2017 Cisco Systems, Inc.
All rights reserved.

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply that exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with applicable laws and regulations, you should not use this product.

A summary of U.S. laws governing Cisco cryptographic products may be found at our [Export Compliance Product Report](#) web site.

For information about Cisco Unified Communications Manager please visit our [Unified Communications System Documentation](#) web site.

For Cisco Technical Support please visit our [Technical Support](#) web site.

步驟3.如圖所示，輸入SFTP伺服器的憑證。



Cisco Unified Operating System Administration

For Cisco Unified Communications Solutions

Show ▾ Settings ▾ Security ▾ Software Upgrades ▾ Services ▾ Help ▾

Software Installation/Upgrade

Cancel Next

- Status -


Status: Ready

- Software Location -


Source*	<input type="text" value="Remote Filesystem"/>
Directory*	<input type="text" value="/"/>
Server*	<input type="text" value="192.168.0.5"/>
User Name*	<input type="text" value="cisco"/>
User Password*	<input type="password" value="*****"/>
Transfer Protocol*	<input type="text" value="SFTP"/>
SMTP Server	<input type="text"/>
Email Destination	<input type="text"/>

*- indicates required item.

步驟4.從Options/Upgrades下拉選單中選擇區域設定，然後按一下Next，如下圖所示。開始安裝區域設定。



5. 驗證Checksum Details後，按一下Next（如下圖所示）。



步驟6. 成功安裝區域設定

Cisco Unified Operating System Administration
For Cisco Unified Communications Solutions

Show ▾ Settings ▾ Security ▾ Software Upgrades ▾ Services ▾ Help ▾

Software Installation/Upgrade

Install Another

Installation Status

File po-locale-ca_ES-k3-12.1.1.1000-1.cop.sgn
 Start Time Mon Jul 02 13:19:26 IST 2018
 Status Complete

Installation Log

```

[18/07/02_13:19:57] locale_install.sh: Publisher: Starting installdb...
/bin/su -l informix -s /bin/sh -c
"source /usr/local/cm/db/dblenv.bash /usr/local/cm ;
source /usr/local/cm/db/informix/local/ids.env ;
nice /usr/local/cm/bin/installdb -x /usr/local/cm/db/xml/xml"
    
```

Install Another

i *- indicates required item.

步驟7. 導航到 **Servicability Page > Tools > Control Center Feature services** 時，在運行該服務的所有節點上重置Cisco TFTP服務。在此處選擇Cisco TFTP服務並按一下 **restart**，如下圖所示。

Cisco Unified Serviceability
For Cisco Unified Communications Solutions

Alarm ▾ Trace ▾ Tools ▾ Snmp ▾ CallHome ▾ Help ▾

Control Center - Feature Services

Start Stop Restart Refresh Page

Status:
Ready

Select Server
Server# 10.106.111.182--CUCM Voice/Video Go

Performance and Monitoring Services

Service Name	Status:
Cisco Serviceability Reporter	Started
Cisco CallManager SNMP Service	Started


Directory Services

Service Name	Status:
Cisco DirSync	Started


CM Services

Service Name	Status:
Cisco CallManager	Started
Cisco Unified Mobile Voice Access Service	Started
Cisco IP Voice Media Streaming App	Started
Cisco CTIManager	Started
Cisco Extension Mobility	Started
Cisco DHCP Monitor Service	Started
Cisco Intercluster Lookup Service	Started
Cisco Location Bandwidth Manager	Started
Cisco Directory Number Alias Sync	Started
Cisco Directory Number Alias Lookup	Started
Cisco Dialed Number Analyzer Server	Started
Cisco Dialed Number Analyzer	Started
Cisco Tftp	Started

步驟8. 導航至電話。




步驟9. 在使用者區域設定下，選擇您剛才下載的區域設定。



步驟10. 儲存、應用配置並重置電話。

驗證

如果區域設定安裝成功，您會看到以本地語言顯示的軟體，如下圖所示：



疑難排解

目前尚無適用於此組態的具體疑難排解資訊。