

在Cisco小型企業VoIP路由器上禁用SSID廣播

目錄

[簡介](#)

[如何在Linksys VOIP路由器上禁用SSID廣播？](#)

[相關資訊](#)

簡介

本文是系列文章中的一篇，旨在協助安裝、疑難排解和維護Cisco Small Business產品。

[問：如何在Cisco Small Business VoIP路由器上禁用SSID廣播？A.](#)

保護無線網路的一種方法是禁用SSID廣播。此過程可防止其他使用者在嘗試檢視您所在區域的可用無線網路時檢測您的SSID或您的無線網路名稱。要禁用SSID廣播，請完成以下步驟：


禁用SSID廣播

第1步：

訪問路由器的基於Web的設定頁。有關說明，請按一下[此處](#)。

第2步：

當路由器的基於Web的設定頁面出現時，按一下**Wireless**，查詢**Wireless SSID Broadcast**，然後選擇**Disable**。



The screenshot shows the Linksys web interface for 'Wireless Settings'. The 'Wireless' tab is selected in the top navigation bar. Below it, the 'Basic Wireless Settings' section is visible. The 'Wireless Network Mode' is set to 'Disabled'. The 'Wireless Network Name (SSID)' field is empty. The 'Wireless Channel' is set to '1'. The 'Wireless SSID Broadcast' option is set to 'Disable', with a yellow arrow pointing to the 'Disable' radio button and a yellow box containing the text 'Select Disable.'. At the bottom of the page, there are 'Save Settings' and 'Cancel Changes' buttons. The Cisco Systems logo is in the bottom right corner.

步驟3: 按一下 **Save Settings**。第4步：

通過在無線電腦的配置實用程式上建立配置檔案，重新連線到無線網路。 [相關資訊](#)

- [技術支援與文件 - Cisco Systems](#)