

# Cisco IOS ファイアウォールを使用した NAT を使用しない 3 インターフェイス ルータの設定

## 内容

[概要](#)

[前提条件](#)

[要件](#)

[使用するコンポーネント](#)

[表記法](#)

[設定](#)

[ネットワーク図](#)

[設定](#)

[確認](#)

[トラブルシュート](#)

[関連情報](#)

## 概要

この文書では、インターネットに接続して独自のサーバを実行する中小企業向けの典型的な設定の例を示します。インターネットへの接続はシリアル回線を経由します。イーサネット 0 は内部ネットワーク ( 単一の LAN ) に接続します。イーサネット 1 は「DMZ」ネットワークに接続します。このネットワークには、外部へのサービス提供に使用する単一のノードがあります。ISPはネットブロック192.168.27.0/24を会社に割り当てています。これは、サブネットマスクが255.255.255.128のDMZと内部LANの間で均等に分割されます。基本ポリシーは次のとおりです。

- 内部ネットワークのユーザがパブリック インターネット上のあらゆるサービスに接続できる。
- インターネット上のだれもが DMZ サーバ上の WWW、FTP、SMTP の各サービスに接続でき、DMZ サーバに DNS 問い合わせを実行できる。これにより、外部ユーザは会社の Web ページを閲覧したり、外部で利用してもらうために会社が掲載したファイルを選択したり、メールを会社へ送信したりできます。
- 内部ユーザが DMZ サーバ上の POP サービスに接続し ( 自分のメールを選択するため ) 、DMZ サーバに Telnet できる ( DMZ サーバを管理するため ) 。
- DMZ 上からプライベート ネットワークまたはインターネットへの接続をいっさい開始できない。
- ファイアウォールを経由するすべての接続をプライベート ネットワーク上の SYSLOG サーバで監査する。内部ネットワーク上のコンピュータは DMZ 上の DNS サーバを使用します。すべてのインターフェイス上で入力アクセスリストを使用し、スプーフィングを防ぎます。出力アクセスリストを使用し、どのトラフィックが特定のインターフェイスに送信されるのかを制御します。

Cisco IOS® ファイアウォールを使用して、NAT を使用しない 2 インターフェイス ルータを設定するには、『[Cisco IOS ファイアウォールを使用した、NAT を使用しない 2 インターフェイス ルータの設定](#)』を参照してください。

Cisco IOS ファイアウォールを使用して、NAT を使用する 2 インターフェイス ルータを設定するには、『[NAT CBAC 設定での 2 インターフェイス ルータ](#)』を参照してください。

## 前提条件

### 要件

このドキュメントに特有の要件はありません。

### 使用するコンポーネント

このドキュメントの情報は、次のソフトウェアとハードウェアのバージョンに基づくものです。

- Cisco IOS ソフトウェア リリース 12.2(15)T13 ( ファイアウォール機能セット付き )
- Cisco 7204 VXR ルータ

このドキュメントの情報は、特定のラボ環境にあるデバイスに基づいて作成されました。このドキュメントで使用するすべてのデバイスは、初期 ( デフォルト ) 設定の状態から起動しています。対象のネットワークが実稼働中である場合には、どのようなコマンドについても、その潜在的な影響について確実に理解しておく必要があります。

### 表記法

ドキュメント表記の詳細については、『[シスコ テクニカル ティップスの表記法](#)』を参照してください。


## 設定

このセクションでは、このドキュメントで説明する機能を設定するために必要な情報を提供しています。

注：このセクションで使用されているコマンドの詳細を調べるには、Command Lookup Tool ( 登録ユーザ専用 ) を参照してください。一部ツールについては、ゲスト登録のお客様にはアクセスできない場合がありますことをご了承ください。

### ネットワーク図

このドキュメントでは、次のネットワーク セットアップを使用します。



## 設定

このドキュメントでは次の設定を使用します。

### 7204VXR ルータ

```

version 12.2
service timestamps debug datetime msec
service timestamps log datetime msec
service password-encryption
!
hostname Router
!
logging queue-limit 100
enable secret 5 <something>
!
ip subnet-zero
ip cef
no ip domain lookup
!
ip inspect audit-trail
!
!--- Sets the length of time a TCP session !--- is
still managed after no activity. ! ip inspect tcp idle-
time 14400
!
!--- Sets the length of time a UDP session !--- is still
managed after no activity. ! ip inspect udp idle-time
1800
!
!--- Sets the length of time a DNS name lookup session
!--- is still managed after no activity. ! ip inspect
dns-timeout 7
!
!--- Sets up inspection list "standard" !--- to be used
for inspection of inbound Ethernet 0 !--- and inbound

```

```
serial (applied to both interfaces). ! ip inspect name
standard cuseeme
ip inspect name standard ftp
ip inspect name standard h323
ip inspect name standard http
ip inspect name standard rcmd
ip inspect name standard realaudio
ip inspect name standard smtp
ip inspect name standard sqlnet
ip inspect name standard streamworks
ip inspect name standard tcp
ip inspect name standard tftp
ip inspect name standard udp
ip inspect name standard vdolive
ip audit notify log
ip audit po max-events 100
!
no voice hpi capture buffer
no voice hpi capture destination
!
mta receive maximum-recipients 0
!

interface ethernet 3/0
ip address 192.168.27.129 255.255.255.128
!
!--- Apply the access list to allow all legitimate !---
traffic from the inside network and prevent spoofing. !
ip access-group 101 in
!
!--- Apply inspection list "standard" for inspection !--
- of inbound Ethernet traffic. This inspection opens !--
- temporary entries on access lists 111 and 121. ! ip
inspect standard in
duplex full

interface ethernet 3/1
ip address 192.168.27.1 255.255.255.128
!
!--- Apply the access list to permit DMZ traffic (except
spoofing) !--- on the DMZ interface inbound. The DMZ is
not permitted to initiate !--- any outbound traffic
except Internet Control Message Protocol (ICMP). ! ip
access-group 111 in
!
!--- Apply inspection list "standard" for inspection of
outbound !--- traffic from e1. This adds temporary
entries on access list 111 !--- to allow return traffic,
and protects servers in DMZ from !--- distributed denial
of service (DDoS) attacks. ip inspect standard out
duplex full
!
interface serial 2/0
ip address 10.89.129.194 255.255.255.252
!--- Apply the access list to allow legitimate traffic.
! ip access-group 121 in
serial restart_delay 0
!
ip classless
no ip http-server

!--- A syslog server is located at this address. logging
```

```
192.168.27.131 !--- This command enables the logging of
session !--- information (addresses and bytes). !---
Access list 20 is used to control which !--- network
management stations can access via SNMP. ! access-list
20 permit 192.168.27.5
!
!--- Use an access list to allow all legitimate traffic
from !--- the inside network and prevent spoofing. The
inside !--- network can only connect to the Telnet and
POP3 !--- service of 192.168.27.3 on DMZ, and can ping
(ICMP) to the DMZ. !--- Additional entries can be added
to permit SMTP, WWW, and !--- so forth, if necessary. In
addition, the inside network can !--- connect to any
service on the Internet. ! access-list 101 permit tcp
192.168.27.128 0.0.0.127 host 192.168.27.3 eq pop3
access-list 101 permit tcp 192.168.27.128 0.0.0.127 host
192.168.27.3 eq telnet
access-list 101 permit icmp 192.168.27.128 0.0.0.127
192.168.27.0 0.0.0.127
access-list 101 deny ip 192.168.27.128 0.0.0.127
192.168.27.0 0.0.0.127
access-list 101 permit ip 192.168.27.128 0.0.0.127 any
access-list 101 deny ip any any
!
!
!--- The access list permits ping (ICMP) from the DMZ
and denies all !--- traffic initiated from the DMZ.
Inspection opens !--- temporary entries to this list. !
access-list 111 permit icmp 192.168.27.0 0.0.0.127 any
access-list 111 deny ip any any
!
!
!
!--- Access list 121 allows anyone on the Internet to
connect to !--- WWW, FTP, DNS, and SMTP services on the
DMZ host. It also !--- allows some ICMP traffic. access-
list 121 permit udp any host 192.168.27.3 eq domain
access-list 121 permit tcp any host 192.168.27.3 eq
domain
access-list 121 permit tcp any host 192.168.27.3 eq www
access-list 121 permit tcp any host 192.168.27.3 eq ftp
access-list 121 permit tcp any host 192.168.27.3 eq smtp
access-list 121 permit icmp any 192.168.27.0 0.0.0.255
administratively-prohibited
access-list 121 permit icmp any 192.168.27.0 0.0.0.255
echo
access-list 121 permit icmp any 192.168.27.0 0.0.0.255
echo-reply
access-list 121 permit icmp any 192.168.27.0 0.0.0.255
packet-too-big
access-list 121 permit icmp any 192.169.27.0 0.0.0.255
time-exceeded
access-list 121 permit icmp any 192.168.27.0 0.0.0.255
traceroute
access-list 121 permit icmp any 192.168.27.0 0.0.0.255
unreachable
access-list 121 deny ip any any
!
!--- Apply access list 20 for SNMP process. ! snmp-
server community secret RO 20 snmp-server enable traps
tty ! call rsvp-sync ! mgcp profile default ! dial-peer
cor custom ! gatekeeper shutdown ! line con 0 exec-
timeout 5 0 password 7 14191D1815023F2036 login local
```

```
line vty 0 4 exec-timeout 5 0 password 7
14191D1815023F2036 login local length 35 end
```

## 確認

ここでは、設定が正常に機能しているかどうかを確認します。

[アウトプット インタープリタ ツール \( 登録ユーザ専用 \) \( OIT \)](#) は、特定の show コマンドをサポートします。OIT を使用して、show コマンドの出力の分析を表示します。

- **show access-list** : [上の例](#) で設定されたアクセス リストが正しく設定されていることを確認します。

```
Router#show access-list
Standard IP access list 20
  10 permit 192.168.27.5
Extended IP access list 101
  10 permit tcp 192.168.27.128 0.0.0.127 host 192.168.27.3 eq pop3
  20 permit tcp 192.168.27.128 0.0.0.127 host 192.168.27.3 eq telnet
  30 permit icmp 192.168.27.128 0.0.0.127 192.168.27.0 0.0.0.127
  40 deny ip 192.168.27.128 0.0.0.127 192.168.27.0 0.0.0.127
  50 permit ip 192.168.27.128 0.0.0.127 any
  60 deny ip any any
Extended IP access list 111
  10 permit icmp 192.168.27.0 0.0.0.127 any
  20 deny ip any any (9 matches)
Extended IP access list 121
  10 permit udp any host 192.168.27.3 eq domain
  20 permit tcp any host 192.168.27.3 eq domain
  30 permit tcp any host 192.168.27.3 eq www
  40 permit tcp any host 192.168.27.3 eq ftp
  50 permit tcp any host 192.168.27.3 eq smtp
  60 permit icmp any 192.168.27.0 0.0.0.255 administratively-prohibited
  70 permit icmp any 192.168.27.0 0.0.0.255 echo
  80 permit icmp any 192.168.27.0 0.0.0.255 echo-reply
  90 permit icmp any 192.168.27.0 0.0.0.255 packet-too-big
  100 permit icmp any 192.169.27.0 0.0.0.255 time-exceeded
  110 permit icmp any 192.168.27.0 0.0.0.255 traceroute
  120 permit icmp any 192.168.27.0 0.0.0.255 unreachable
  130 deny ip any any (4866 matches)
Router#
```

- **show ip audit all** : logging コマンドの設定を確認します。

```
Router#show ip audit all
Event notification through syslog is enabled
Event notification through Net Director is disabled
Default action(s) for info signatures is alarm
Default action(s) for attack signatures is alarm
Default threshold of recipients for spam signature is 250
PostOffice:HostID:0 OrgID:0 Msg dropped:0
      :Curr Event Buf Size:0 Configured:100
Post Office is not enabled - No connections are active
```

```
Router#
```

- **show ip inspect all** : Cisco IOS ファイアウォール検査ルールをインターフェイス別に確認します。

```
Router#show ip inspect all
  Session audit trail is enabled
  Session alert is enabled
  one-minute (sampling period) thresholds are [400:500] connections
  max-incomplete sessions thresholds are [400:500]
```

```
max-incomplete tcp connections per host is 50. Block-time 0 minute.  
tcp synwait-time is 30 sec -- tcp finwait-time is 5 sec  
tcp idle-time is 14400 sec -- udp idle-time is 1800 sec  
dns-timeout is 7 sec
```

#### Inspection Rule Configuration

```
Inspection name standard
```

```
cuseeme alert is on audit-trail is on timeout 14400  
ftp alert is on audit-trail is on timeout 14400  
h323 alert is on audit-trail is on timeout 14400  
http alert is on audit-trail is on timeout 14400  
rcmd alert is on audit-trail is on timeout 14400  
realaudio alert is on audit-trail is on timeout 14400  
smtp alert is on audit-trail is on timeout 14400  
sqlnet alert is on audit-trail is on timeout 14400  
streamworks alert is on audit-trail is on timeout 1800  
tcp alert is on audit-trail is on timeout 14400  
tftp alert is on audit-trail is on timeout 1800  
udp alert is on audit-trail is on timeout 1800  
vdolive alert is on audit-trail is on timeout 14400
```

#### Interface Configuration

```
Interface Ethernet3/0
```

```
Inbound inspection rule is standard
```

```
cuseeme alert is on audit-trail is on timeout 14400  
ftp alert is on audit-trail is on timeout 14400  
h323 alert is on audit-trail is on timeout 14400  
http alert is on audit-trail is on timeout 14400  
rcmd alert is on audit-trail is on timeout 14400  
realaudio alert is on audit-trail is on timeout 14400  
smtp alert is on audit-trail is on timeout 14400  
sqlnet alert is on audit-trail is on timeout 14400  
streamworks alert is on audit-trail is on timeout 1800  
tcp alert is on audit-trail is on timeout 14400  
tftp alert is on audit-trail is on timeout 1800  
udp alert is on audit-trail is on timeout 1800  
vdolive alert is on audit-trail is on timeout 14400
```

```
Outgoing inspection rule is not set
```

```
Inbound access list is 101
```

```
Outgoing access list is not set
```

```
Interface Ethernet3/1
```

```
Inbound inspection rule is not set
```

```
Outgoing inspection rule is standard
```

```
cuseeme alert is on audit-trail is on timeout 14400  
ftp alert is on audit-trail is on timeout 14400  
h323 alert is on audit-trail is on timeout 14400  
http alert is on audit-trail is on timeout 14400  
rcmd alert is on audit-trail is on timeout 14400  
realaudio alert is on audit-trail is on timeout 14400  
smtp alert is on audit-trail is on timeout 14400  
sqlnet alert is on audit-trail is on timeout 14400  
streamworks alert is on audit-trail is on timeout 1800  
tcp alert is on audit-trail is on timeout 14400  
tftp alert is on audit-trail is on timeout 1800  
udp alert is on audit-trail is on timeout 1800  
vdolive alert is on audit-trail is on timeout 14400
```

```
Inbound access list is 111
```

```
Outgoing access list is not set
```

```
Router#
```

## トラブルシューティング

IOS ファイアウォール ルータを設定した後、接続が機能しない場合は、インターフェイス上で `ip inspect (name defined) in or out` コマンドによる検査が有効にされていることを確認してください

。この設定では、`ip inspect standard in` がインターフェイス イーサネット 3/0 に適用され、`ip inspect standard out` がインターフェイス イーサネット 3/1 に適用されています。

トラブルシューティングの詳細については、『[CBAC 設定のトラブルシューティング](#)』を参照してください。

## **関連情報**

- [Cisco IOS ファイアウォールのサポート ページ](#)
- [テクニカル サポートとドキュメント – Cisco Systems](#)