

# Jabber Guest Issues Troubleshoot Guide



Document ID: 118592

Contributed by Alok Jaiswal, Cisco TAC Engineer.  
Nov 06, 2014

## Contents

### Introduction

### Prerequisites

- Requirements
- Components Used

### Topology

### Troubleshoot Guide

- Check Unified Communication Links
- Jabber Guest Link Redirects to the Expressway Web Page
- Accelerator Not Found
- Link Not Found
- Destination Not Reachable
- TURN Allocation Failed
- Unsupported Browser
- Password Reset
- Jabber Guest: Logging and Log Levels
  - Jabber Guest Web Plug-in Logs
  - Windows
  - Mac OS

### Related Information

## Introduction

This document describes how to troubleshoot some common issues with Cisco Jabber Guest.

## Prerequisites

## Requirements

Cisco recommends that you have knowledge of these topics:

- Cisco Expressway (Exp) C and E combination with Version x8.2 or later
- Traversal Using Relay NAT (TURN)/Interactive Connectivity Establishment (ICE) and Session Initiation Protocol (SIP)
- Video Communication Server (VCS)–C and VCS–E


## Components Used

The information in this document is based on these software and hardware versions:

- The only supported model is the (VCS)–C and VCS–E combination or Exp–C and Exp–E combination.
- Exp–E must have the TURN option key installed.

- Exp-C and Exp-E should have the necessary traversal zone set up correctly.
- The expressway box must have Version x8.2 or later.
- Cisco Jabber Guest Version *jg10.0\_10.0.2.75*.
- Internet client with Jabber Guest plug-in installed.

## Topology



## Troubleshoot Guide

This section describes common issues that are encountered.

### Check Unified Communication Links

Jabber Guest uses the Unified Communications link and a Secure Shell (SSH) tunnel for HTTPS message proxy between Expressway-E and Expressway-C.

- Unified Communication link status information can be checked from *Status > Unified Communications*.

**CISCO** Cisco Expressway-C

Status System Configuration Applications Users Maintenance

**Unified Communications** You are here: [Status](#) > Unified Communications

Unified Communications (last updated: 20:12:28 IST)

Unified Communications status	Enabled
Jabber Guest services	Enabled
Unified Communications services	Active

Domains

Name	Services	Associated zones
webrtc.com	Jabber Guest	JabberGuest_traversal_Zone

Zones

Name	SIP status
<a href="#">JabberGuest_traversal_Zone</a>	Active

- Unified Communication SSH tunnel status information can be checked from *Status > Unified Communication > Unified Communications SSH tunnels status*.

**CISCO** Cisco Expressway-C

Status System Configuration Applications Users Maintenance [Help](#) [Logout](#)

**Unified Communications SSH tunnels status** You are here: [Status](#) > [Unified Communications](#) > Unified Communications SSH tunnels status

SSH tunnels

Target	Domain	Status
JabberGuestExp-E.webrtc.com	webrtc.com	Active

## Jabber Guest Link Redirects to the Expressway Web Page

Sometimes when you try to access the Jabber Guest link, you are redirected to the Expressway web page.

**CISCO**

Welcome to uc telepresence ia

Access Login Page  
**WARNING!!!! UNAUTHORIZED ACCESS PROHIBITED**  
 You must have authorized permission to access this area.

Enter your username and password, e.g.  
 jdoe1

**Administrator login**

Username

Password

Login

If this happens, check these items:

- The Expressway-E is configured for Jabber Guest and that the Unified Communications Traversal Zone between the Expressway-E and Expressway-C is active.
- A firewall or web server translates requests from the public Internet to 443, to 9443, or from the public Internet to 80, to 9880.

**Note:** If the Expressway-E receives requests on port 9880, it redirects the request to 9443 automatically.

A good way to test this is to explicitly define port 9443 in the link and try to access the link from the browser.



If you still get redirected to the Expressway–E web page, then port 9443 is forwarded to 443 on the firewall. This configuration is incorrect; port 443 should forward to port 9443.

## Accelerator Not Found

Sometimes you load the Jabber Guest link and receive this error message:

### Not Found on Accelerator

---

**Description: Your request on host "10.106.93.165" was not found. Check the location and try again.**

---

If this happens, check these items:


- If the link you use does not contain a Domain Name and uses an IP address instead, change the link to use a Fully Qualified Domain Name (FQDN) instead. Navigate to *Settings > Links* and change the "Domain used for links" to FQDN.
- If the Jabber Guest link is in FQDN format, make sure the associated domain is configured for Jabber Guest services and a Jabber Guest server is associated.



- Verify that the SSH tunnels are active between Expressway–E and Expressway–C.
- Verify that the Unified Communication status is active on Expressway–E and Expressway–C.

## Link Not Found


Sometimes you load the Jabber Guest link and receive this error message:




If this happens, check these items:

- The requested URL link is not active (navigate to **Links > select the link**). Verify that it shows as active.
- Either URL contains the wrong calling URL or the configured URL has not activated (or expired).

**State**     Always Active  
             Active Between


**Start**     

**End**       

## Destination Not Reachable

Sometimes you load the Jabber Guest link and receive this error message:



The chip logs display this:

```

2014-10-03 16:03:55,756 INFO[0xa0f021a8] [webc] [Log(1236)] - Method call:
MediaPlugin.hangup

2014-10-03 16:03:55,756 INFO[0xa0f021a8] [chip] [AutoLog(7)] - Method entered:
chipAPI::hangupAsync

2014-10-03 16:03:55,756 INFO[0xa0f021a8] [chip] [AutoLog(7)] - Method entered:
CVideoAPI::HangupAsync

2014-10-03 16:03:55,756 INFO[0xa0f021a8] [chip] [AutoLog(11)] - Method exited:
CVideoAPI::HangupAsync

2014-10-03 16:03:55,756 INFO[0xa0f021a8] [chip] [AutoLog(11)] - Method exited:
chipAPI::hangupAsync

2014-10-03 16:03:55,756 INFO[0xb0629000] [chip] [Hangup(796)] - Method entered

2014-10-03 16:03:55,756 INFO[0xb0629000] [chip] [Hangup(808)] - Nothing
to hangup. no-op

2014-10-03 16:03:55,756 INFO[0xb0629000] [chip] [Hangup(796)] - Method exited

2014-10-03 16:03:55,757 INFO[0xb0629000] [chip] [AutoLog(7)] - Method entered:
chipAPI::Callback_Void

2014-10-03 16:03:55,757 INFO[0xb0629000] [chip] [FindJSObjectPtrValueGivenKey(97)] -
Failed To find key-Successcb or the value wasn't a JSObjectPtr

2014-10-03 16:03:55,757 INFO[0xb0629000] [chip] [AutoLog(11)] - Method exited:
chipAPI::Callback_Void

2014-10-03 16:04:15,975 INFO[0xa0f021a8] [webc] [Log(1236)] - Call event: [timeout]


```

If this happens, check these items:

- The neighbor zone to Cisco Unified Communications Manager (CUCM)/VCS–Control should be active.
- Proper Search rules should be configured on the Exp–C/VCS–C which is used for Jabber Guest deployment, so that it can route the calls over to CUCM or VCS–Control.
- The endpoint should be registered with the right URI/Extension on CUCM/VCS–Control, which matches to the one defined under destination on links on the Jabber Guest server.

## TURN Allocation Failed

Sometimes you load the Jabber Guest link and receive this error message:



If this happens, check these items:

- UDP port 3478 is not blocked. You must allow these ports inbound from the public Internet to the Expressway.

### Inbound from Public Internet to Cisco Expressway-E (DMZ)

Table 1 Inbound from Public Internet to Cisco Expressway-E (DMZ)

Purpose	Protocol	Internet Endpoint (Source)	Cisco Expressway-E (Listening)
HTTP	TCP	TCP source port	9980 <sup>1</sup>
HTTPS proxy	TLS	TCP source port	9443 <sup>2</sup>
TURN server control/media	UDP	UDP source port	3478–3483 (control and media sent to this port)

- UDP port 3478 is the default port on the Expressway–E. The port could be changed or could use a range of ports. In order to confirm which port should be used, check the Expressway–E TURN configuration.

CISCO Cisco Expressway-E

Status System **Configuration** Applications Users Maintenance

TURN You are here: Configuration > Traversal > TURN

Server

TURN services On ⓘ

TURN requests port \* 3478 ⓘ

Authentication realm \* TurnAdmin ⓘ [Configure TURN client credentials on local database](#)

Media port range start \* 24000 ⓘ

Media port range end \* 29999 ⓘ

- You must define the Authentication realm used during the TURN configuration under the local database or use the delegate credential check based on the deployment. Make sure the TURN Server configuration is proper and it shows as active on Exp-E/VCS-Exp server.

TURN server status

Status	Active
Listening address 1	10.106.93.165:3478
Number of active TURN clients	0
Number of active TURN relays (connected via TCP)	0
Number of active TURN relays (connected via UDP)	0

- The Expressway-E TURN Server (IP Address or DNS Name) field and TURN Port fields on the Jabber Guest server (*Settings > Call Control and Media*) are not configured properly.

If you have defined the wrong TURN server address in the Jabber Guest configuration, the web client machine sends the TURN allocation request to that server and eventually timeouts.

## Cisco Expressway-E

Expressway-E TURN server (IP address or DNS name):

10.106.93.169

TURN port:

3478



The chip logs display this:

```
2014-10-03 16:30:29,549 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> IN <-- AllocateReq (state Idle)

2014-10-03 16:30:29,549 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> 7d..16 OUT-->STUN: AllocateRequest sockh=10 Len=52 to
10.106.93.169:3478

2014-10-03 16:30:29,550 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> State (Idle -> WaitAllocRespNotAut)

2014-10-03 16:30:29,649 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> IN <-- TimerRetransmit (state WaitAllocRespNotAut)

2014-10-03 16:30:29,649 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> 7d..16 Retransmit initial allocateReq Retry: 1

2014-10-03 16:30:29,748 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> IN <-- TimerRetransmit (state WaitAllocRespNotAut)

2014-10-03 16:30:29,748 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> 7d..16

.

.

.

2014-10-03 16:30:37,506 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> IN <-- TimerRetransmit (state WaitAllocRespNotAut)

2014-10-03 16:30:37,506 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> 7d..16 Retransmit initial allocateReq Retry: 9

2014-10-03 16:30:39,099 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> IN <-- TimerRetransmit (state WaitAllocRespNotAut)

2014-10-03 16:30:39,100 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> Retransmit initial allocateReq failed after 9 retries

2014-10-03 16:30:39,100 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> State (WaitAllocRespNotAut -> Idle)

2014-10-03 16:30:39,100 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>(0)] -
<TURNCLIENT:00> StopAllTimers

2014-10-03 16:30:39,100 DEBUG [0xb06ab000] [pme] [.<ctxt:SIP,thread:-1335185408>(0)] -
F fsm_sendMsgWithPriority: Invalid destination address: Src: connhandler(0x00080000)-0
Dest: G2FSM(0x00050000)-0, Msg: G2FSM_Audit_Ind(327712)

2014-10-03 16:30:39,100 DEBUG [0xb06ab000] [pme] [.<ctxt:,thread:-1335185408>(0)] -
void connhandler_SerialAlloc_doNETTurnAllocateRej(PROC_DATA *, struct connhandler_PRIV *,
struct NET_TURN_ALLOCATE_REJ *): conn_id: 22314

2014-10-03 16:30:39,109 INFO[0xa0f021a8] [webc] [.<Log(1236)>] - InitializeIceMachineAsync
failed: ERROR_UNABLE_TO_CONTACT_TURN_SERVER
```

- The Domain name on the Jabber Guest server (*Settings > Call Control and Media*, under Cisco Expressway-C) is not a configured domain name on Cisco Expressway-C or is not configured for Cisco Jabber Guest services.

### Cisco Expressway-C

Expressway-C (IP address or DNS name)

Request short-term TURN credentials from  Expressway-C server that proxied the HTTP request from Jabber Guest client  
 Expressway-C server specified above

HTTPS port:

Domain:

Username:

Password:

The chip logs display this:

```

2014-10-03 16:44:17,187 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> ed..7f OUT-->STUN: AllocateRequest sockh=6 Len=208 to
10.106.93.165:3478

2014-10-03 16:44:17,187 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> State (WaitAllocRespNotAut -> WaitAllocResp)

2014-10-03 16:44:17,237 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> IN <-- TimerRetransmit (state WaitAllocResp)

2014-10-03 16:44:17,237 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> ed..7f Retransmit allocateReq Retry: 1

2014-10-03 16:44:17,285 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> ed..7f AllocateErrorResponse

2014-10-03 16:44:17,285 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> IN <-- AllocateRespError (state WaitAllocResp)

2014-10-03 16:44:17,285 DEBUG [0xb06ab000] [pme] [.<ctxt:ICE,thread:-1335185408>
(0)] - <TURNCLIENT:00> Authorisation failed code 401

2014-10-03 16:44:17,285 DEBUG [0xb06ab000] [pme] [.<ctxt:SIP,thread:-1335185408>
(0)] - F fsm_sendMsgWithPriority: Invalid destination address: Src: connhandler
(0x00080000)-0 Dest: G2FSM(0x00050000)-0, Msg: G2FSM_Audit_Ind(327712)

2014-10-03 16:44:17,290 INFO[0xa0f021a8] [webc] [.<Log(1236)>] - InitializeIceMachineAsync

```

failed: ERROR\_UNABLE\_TO\_CONTACT\_TURN\_SERVER

The Exp-E logs show this:

Message Header: (type=AllocateRequest(0x0003), length=188, id=15:99:aa:ab:00:01:00:00:76:f8:cc:ce, cookie=21:12:a4:42)

**Username: JC:edge.com:93e3f6cc-5854-4fb4-a6e9-88c322361c23**

MessageIntegrity: (offset=176, hash=e7:f4:f5:15:e7:8c:b2:89:ec:08:be:48:a3:51:cc:61:47:dc:c6:09)

SoftwareName: cpve


Nonce: 0aea2513a55a1c674efeb8a7bcc67ce8d48ae368245cb7090dd7c6b16aac

Realm: TurnAdmin

RequestedTransport: udp(17)

EvenPort: Reserve next=true

The turn allocation request comes with the domain *edge.com* configured on Jabber Guest. However, in this case, the domain configured on Exp-C is *webrtc.com*. So, Exp-E never authenticates the request.



## Unsupported Browser

Sometimes you load the Jabber Guest link and receive the error message: "Unsupported Browser"

*Description: We're sorry, the browser you are using is not supported.*

In order to access Jabber Guest, ensure that your system meets these requirements.

Support Microsoft Windows

- Microsoft Windows Vista or later

- Mozilla Firefox Version 10 or later
- Google Chrome Version 18 or later
- Microsoft Internet Explorer Version 8 or later (32-bit only)

#### Support Mac OS X

- Mac OS X Version 10.7 or later
- Apple Safari Version 5 or later
- Mozilla Firefox Version 10 or later
- Google Chrome Version 18 or later

## Password Reset

Sometimes you must reset the root password. Refer to [Reset the Root Password for Cisco Jabber Guest](#) for more information. The process is similar to how you reset the password for the Linux system with the use of single user mode.

In order to reset the admin password, complete these steps:

- Sign into the Jabber Guest server as root.
- Change the directory to */opt/cisco/webcommon/scripts*:

```
cd /opt/cisco/webcommon/scripts
```

- Enter this command:


```
python mongo_admin_reset.py
```

- The password is reset to its default value, *jabbercserver*.

## Jabber Guest: Logging and Log Levels

### Jabber Guest Web Plug-in Logs

In order to use Jabber Guest, a web plug-in must be installed on a PC or a Mac.



This web plug-in writes to a log file that can be configured for different logging levels and might be useful in troubleshooting.

## Windows

- The Jabber Guest plug-in writes to a *chip.log* file. For a Windows PC, you can find the *chip.log* here: `%HOMEPATH%\Appdata\LocalLow\Cisco\chip.log`.
- In order to alter the logging level, you can modify the log config file. This config file is located at: `C:\Users\<username>\AppData\Roaming\Cisco\chip\1.0.6.10\config\log4cxx.config`.
- If the plug-in crashed, a dump file called *chip.dmp* is created. This file is located at: `%HOMEPATH%\Appdata\LocalLow\Cisco\chip`.

*Note:* `%HOMEPATH%` is generally in the form of `C:\Users\username`.

## Mac OS

- For Mac OS, the *chip.log* is located at: `~/Library/"Internet Plug-Ins"/"Cisco Jabber Guest Plug-in.10.0.2.17.plugin"/Contents/Frameworks/Logs`.
- In order to alter the logging level, you can modify the log config file. This config file is located at: `~/Library/Internet Plug-Ins/Cisco Jabber Guest Plug-in.10.0.2.17.plugin/Contents/Frameworks/config/log4cxx.config`.

If the plug-in crashes, a dump file called *chip.dmp* is created. Currently, this file is created only for plug-in crashes on Microsoft Windows. If you are asked to send the *chip.dmp* file, follow this procedure.

Navigate to `%HOMEPATH%\Appdata\LocalLow\Cisco\chip`.

## Related Information

- *Jabber Guest Configuration*
- *Unified Communications Mobile and Remote Access via Cisco VCS*
- *Cisco TelePresence Video Communication Server Basic Configuration (Control with Expressway)*
- *Technical Support & Documentation – Cisco Systems*

---

Updated: Nov 06, 2014

Document ID: 118592

---