



Prerequisites: Insights

- [Requirements for Insights, on page 1](#)
- [Communication Ports for Insights, on page 2](#)
- [Fabric Requirements for Insights, on page 3](#)

Requirements for Insights



Note This section describes *additional* requirements and guidelines if you plan to enable the Insights service. Ensure that you have already satisfied the platform-level requirements described in the [Prerequisites and Guidelines](#) section.

- Starting with Nexus Dashboard release 3.1.1, Cisco DC App Center connectivity has been removed from Nexus Dashboard because downloading the services separately is no longer required.

To deploy Insights, download the unified installation image from the [Software Download](#) page; individual services' installation images are no longer available from the Cisco DC App Center.

- For Nexus Dashboard Insights service, the data network must provide IP reachability to the following:
 - The in-band network of each fabric and of the APIC.
 - The DNS server.
 - For Panduit PDU integration, to the Panduit PDU server.
 - For External Kafka integration, to the External Kafka server (consumer).
 - For SysLog integration, to the SysLog server.
 - For Network-Attached Storage integration, to the Network-Attached Storage server.
 - For vCenter integration, to vCenter.
 - For AppDynamics integration, to the AppDynamics controller.
- If you are using the Insights service with NDFC fabrics or have SFLOW/NetFlow enabled, the Data network interfaces must be Layer 2 adjacent.
- You must allocate the following number of persistent IP addresses depending on your use case.

For an overview of Persistent IP functionality, see [Prerequisites and Guidelines](#).

For ACI Fabrics:

- Nexus Dashboard Insights without Netflow or Panduit PDU integration: 0 IP needed in data network.
- Nexus Dashboard Insights with Panduit PDU integration: 1 IP (if using IPv4) and the integration is not supported with pure IPv6 stack.
- Nexus Dashboard Insights with Netflow and Panduit PDU integration : 8 IPs (if using IPv4) and 6 IPs (if using IPv6) in data network.
- Nexus Dashboard Insights with Netflow and without Panduit PDU integration : 8 IPs (if using IPv4) and 6 IPs (if using IPv6) in data network.

For NDFC fabrics:

- 8 IPs (if using IPv4) and 6 IPs (if using IPv6) in data network.

For Standalone NX-OS switches:

- 10 IPs (if using IPv4) and 8 IPs (if using IPv6) in data network.

Allocating persistent IP addresses is done after the cluster is deployed using the External Service Pools configuration in the UI, as described in the [Cisco Nexus Dashboard User Guide](#).

- Connectivity between the nodes is required on both networks with the following additional round trip time (RTT) requirements:

Table 1: Insights RTT Requirements

Connectivity	Maximum RTT
To switches	150 ms

Communication Ports for Insights

In addition to the ports required by the Nexus Dashboard cluster nodes (listed in a previous section), the following ports are required by the Insights service.



Note By default, Insights requires connectivity only between data interfaces of Nexus Dashboard cluster nodes and in-band IP of the switches. However, if a switch becomes unavailable, then Insights will attempt to connect to the OOB IP of the switches using the cluster nodes' management or data interface (depending on the route settings).

Table 2: Nexus Dashboard Insights Ports (Data Network)

Service	Port	Protocol	Direction In—towards the cluster Out—from the cluster towards the fabric or outside world	Connection
Show Techcollection	2022	TCP	In/Out	In-band of switches and APIC/NDFC
Flow Telemetry	5640-5671	UDP	In	In-band of switches
TAC Assist	8884	TCP	In/Out	Other cluster nodes
KMS	9989	TCP	In/Out	Other cluster nodes and ACI fabrics
Kafka	30001	TCP	In/Out	In-band IP of switches and APIC/NDFC
SW Telemetry	5695 30000 57500 30570	TCP	In/Out	Other cluster nodes

Fabric Requirements for Insights

Additional Prerequisites for ACI Fabrics

If you plan to use the Insights service with ACI fabrics, ensure that:

- You can on-board only 1 type of sites (ACI, NDFC, or Standalone NX-OS) within the same cluster.
Onboarding a mix of ACI and NDFC, ACI and NX-OS, or NDFC and NX-OS within the same cluster is not supported.
- You have configured NTP settings on Cisco APIC.
For more information, see [Configure NTP in ACI Fabric Solution](#).
- If you plan to use the flow telemetry functions in Nexus Dashboard Insights, Telemetry Priority must be selected in the ACI fabric node control policy.

In Cisco APIC, choose **Fabric > Fabric Policies > Policies > Monitoring > Fabric Node Controls > <policy-name> > Feature Selection** to select Telemetry Priority. Monitoring <policy-name> should be attached to **Fabric > Fabric Policies > Switches > Leaf/Spine Switches > Profiles > .**

- If you plan to use the flow telemetry functions in Nexus Dashboard Insights, Precision Time Protocol (PTP) must be enabled on Cisco APIC so that Nexus Dashboard Insights can correlate flows from multiple switches accordingly

In Cisco APIC, choose **System > System Settings > PTP and Latency Measurement > Admin State** to enable PTP.

The quality of the time synchronization via PTP depends on the accuracy of the PTP Grandmaster (GM) clock which is the source of the clock, and the accuracy and the number of PTP devices such as ACI switches and IPN devices in between.

Although a PTP GM device is generally equipped with a GNSS/GPS source to achieve the nanosecond accuracy which is the standard requirement of PTP, microsecond accuracy is sufficient for Nexus Dashboard Insights and its flow telemetry, hence a GNSS/GPS source is typically not required.

For a single-pod ACI fabric, you can connect your PTP GM via leaf switches. Otherwise, one of the spine switches will be elected as a GM. For a multi-pod ACI fabric, you can connect your PTP GM via leaf switches or via IPN devices. Your IPN devices should be PTP boundary clocks or PTP transparent clocks so that ACI switch nodes can synchronize their clock across pods. To maintain the same degree of accuracy across pods, it is recommended to connect your PTP GM via IPN devices.

See section "Precision Time Protocol" in Cisco APIC System Management Configuration Guide for details about PTP connectivity options.

- You have configured in-band management as described in [Cisco APIC and Static Management Access](#).
- If one or more DNS Domains are set under DNS Profiles, it is mandatory to set one DNS Domain as default.

In Cisco APIC, choose **Fabric > Fabric Policies > Policies > Global > DNS Profile > default > DNS Domains** and set one as default.

Failure to do so will result in the same switch appearing multiple times in the Nexus Dashboard Insights Flow map.

- Deploy ACI in-band network by configuring EPG using the following:
 - Tenant = `mgmt`
 - VRF = `inb`
 - BD = `inb`
 - Node Management EPG = `default/<any_epg_name>`
- Nexus Dashboard's data-network IP address and ACI fabric's in-band IP address must be in different subnets.

Additional Prerequisites for NDFC Fabrics or Standalone NX-OS Switches

If you plan to use the Insights service with NDFC fabrics or Standalone NX-OS switches, ensure that:

- You can on-board only 1 type of sites (ACI, NDFC, or Standalone NX-OS) within the same cluster.

Onboarding a mix of ACI and NDFC, ACI and NX-OS, or NDFC and NX-OS within the same cluster is not supported.
- The data network must have IP reachability to the fabrics' in-band IP addresses.

- To enable Flow Telemetry or Traffic Analytics, Precision Time Protocol (PTP) must be configured on all nodes you want to support with Nexus Dashboard Insights.

In both managed and monitor site mode, you must ensure PTP is correctly configured on all nodes in the site. You can enable PTP in NDFC easy site setup's **Advanced** tab by checking the **Enable Precision Time Protocol (PTP)** option.

The PTP Grandmaster Clock should be provided by a device that is external to the network site. Using Cisco Nexus 9000 series switches as PTP Grandmaster is not supported.



Note N9k-C93180YC-FX3 switch in the fabric can be used as a PTP GM.

The quality of the time synchronization via PTP depends on the accuracy of the PTP Grandmaster (GM) clock which is the source of the clock, and the accuracy and the number of PTP devices along the network path. Although a PTP GM device is generally equipped with a GNSS/GPS source to achieve the nanosecond accuracy which is the standard requirement of PTP, microsecond accuracy is sufficient for Nexus Dashboard Insights and its flow telemetry, hence a GNSS/GPS source is typically not required.

For details about configuring Precision Time Protocol on Nexus switches using NDFC, *Cisco NDFC LAN Fabric Configuration Guide*.

For details about manually configuring Precision Time Protocol on Nexus switches, see *Cisco Nexus 9000 Series NX-OS System Management Configuration Guide*.

