



CHAPTER

17

## Configuring Ethernet over MPLS

This chapter describes how to configure Ethernet over Multiprotocol Label Switching (EoMPLS) on the ML-Series card.

This chapter includes the following major sections:


- [Understanding EoMPLS, page 17-1](#)
- [Configuring EoMPLS, page 17-4](#)
- [EoMPLS Configuration Example, page 17-9](#)
- [Monitoring and Verifying EoMPLS, page 17-11](#)

## Understanding EoMPLS

EoMPLS provides a tunneling mechanism for Ethernet traffic through an MPLS-enabled Layer 3 core. It encapsulates Ethernet protocol data units (PDUs) inside MPLS packets and uses label stacking to forward them across the MPLS network. EoMPLS is an Internet Engineering Task Force (IETF) standard-track protocol based on the Martini draft, specifically the [draft-martini-l2circuit-encap-mpls-01](#) and [draft-martini-l2circuit-transport-mpls-05](#) sections.

EoMPLS allows service providers to offer customers a virtual Ethernet line service or VLAN service using the service provider's existing MPLS backbone. It also simplifies service provider provisioning, since the provider edge customer-leading edge (PE-CLE) equipment only needs to provide Layer 2 connectivity to the connected customer edge (CE) equipment.

[Figure 17-1](#) shows an example of EoMPLS implemented on a service provider network. In the example, the ML-Series card acts as PE-CLE equipment connecting to the Cisco GSR 12000 Series through an RPR access ring. Point-to-point service is provided to CE equipment in different sites that connect through ML-Series cards to the ML-Series card RPR access ring.

**Figure 17-1 EoMPLS Service Provider Network**

Implementing EoMPLS on a service provider network requires ML-Series card interfaces to play three major roles. The ML-Series card interface roles must be configured on both sides of the EoMPLS point-to-point service crossing the MPLS core.

- ML-Series card interfaces connect the provider's network directly to the customer edge equipment and are known as the PE-CLE interfaces. This PE-CLE interface on the ML-Series card is FastEthernet or GigabitEthernet and is configured to be an endpoint on the EoMPLS point-to-point session.
- An ML-Series card interface bridges the PE-CLE interface and the RPR network of ML-Series cards. This RPR/SPR interface contains POS ports and is configured for MPLS IP.
- An ML-Series card interface connects to a core MPLS interface. This interface is GigabitEthernet or FastEthernet and connects to the port of a Cisco GSR 12000 Series or similar device that is on the MPLS network. This MPLS cloud-facing interface bridges the SPR interface and the MPLS cloud.

Implementing EoMPLS across a service provider's network requires setting up directed Label Distribution Protocol (LDP) sessions (LSPs) between the ingress and egress PE-CLE routers to exchange information for a virtual circuit (VC). Each VC consists of two LSPs, one in each direction, since an LSP is a directed path to carry Layer 2 frames in one direction only.

EoMPLS uses a two-level label stack to transport Layer 2 frames, where the bottom/inner label is the VC label and the top/outer label is the tunnel label. The VC label is provided to the ingress PE-CLE by the egress PE-CLE of a particular LSP to direct traffic to a particular egress interface on the egress PE-CLE. A VC label is assigned by the egress PE-CLE during the VC setup and represents the binding between the egress interface and a unique and configurative VC ID. During a VC setup, the ingress and egress PE-CLE exchange VC label bindings for the specified VC ID.

An EoMPLS VC on the ML-Series card can transport an Ethernet port or an IEEE 802.1Q VLAN over MPLS. A VC type 5 tunnels an Ethernet port and a VC type 4 transports a VLAN over MPLS. In a VC type 5 session, the user can expect any traffic that is received on an ML-Series card PE-CLE port

with an **mpls l2transport route** command to be tunneled to the remote egress interface on the far-end ML-Series card PE-CLE port. With a VC type 4, a user can expect the tunnel to act as physical extension to that VLAN. The EoMPLS session commands are entered on a VLAN subinterface on the PE-CLE, and only VLAN-tagged traffic received on that port will be tunneled to the remote PE-CLE.

## EoMPLS Support

In Software Release 4.6, EoMPLS on the ML-Series card has the following characteristics:

- EoMPLS is only supported on FastEthernet and GigabitEthernet interfaces or subinterfaces.
- MPLS tag switching is only supported on SPR interfaces.
- Class of service (CoS) values are mapped to the experimental (EXP) bits in the MPLS label, either statically or by using the IEEE 802.1p bits (default).
- The ingress PE-CLE ML-Series card sets the time-to-live field to 2 and the tunnel label to a value of 255.
- Ingress PE-CLE ML-Series cards set the S bit of the VC label to 1 to indicate that the VC label is at the bottom of the stack.
- Since EoMPLS traffic is carried over the RPR, whatever load balancing is applicable for the traffic ingressing RPR is also applicable for the EoMPLS traffic.
- The Ethernet over MPLS feature is part of the Cisco Any Transport over MPLS (AToM) product set. The ML-Series card implementation of EoMPLS is based on Cisco IOS 12.1 E.
- The ML-Series card hosting the EoMPLS endpoint ports must be running the MPLS microcode image to support EoMPLS. For more information on multiple microcode images, see the “[Multiple Microcode Images](#)” section on page 3-11. Other ML-Series cards in the RPR are not restricted to the MPLS microcode image.

## EoMPLS Restrictions

In Software Release 4.6, EoMPLS on the ML-Series card has the following restrictions:

- Packet-based load balancing is not supported. Instead, circuit-ID based load balancing is used.
- Zero hop or hairpin VCs are not supported. A single ML-Series card cannot be both the source and destination for a VC.
- MPLS control word for sequencing of data transmission is not supported. Packets must be received and transmitted without control word.
- Sequence checking or resequencing of EoMPLS traffic is not supported. Both depend on the control word to function.
- Maximum transmission unit (MTU) fragmentation is not supported.
- Explicit-null label for back-to-back LDP sessions is not supported.



**Caution**

---

Since MTU fragmentation is not supported across the MPLS backbone, the network operator must make sure the MTU of all intermediate links between endpoints is sufficient to carry the largest Layer 2 PDU.

---

## EoMPLS Quality of Service

The EXP is a 3-bit field and part of the MPLS header. It was created by the IETF on an experimental basis, but later became part of the standard MPLS header. The EXP bits in the MPLS header carry the packet priority. Each label switch router along the path honors the packet priority by queuing the packet into the proper queue and servicing the packet accordingly.

By default, the ML-Series card does not map the IEEE 802.1P bits in the VLAN tag header to the MPLS EXP bits. The MPLS EXP bits are set to a value of 0.

There is no straight copy between Layer 2 CoS and MPLS EXP, but the user can use the **set mpls experimental** action to set the MPLS EXP bit values based on a match to 802.1p bits. This mapping occurs at the entry point, the ingress of the network.

Quality of service (QoS) for EoMPLS traffic on ML-Series cards uses strict priority and/or weighted round robin scheduling in the egress interface of both imposition and disposition router. This requires selection of the service class queue that determines the type of scheduling. In the imposition router, the priority bits EXP or RPR CoS that are marked based on policing are used to select the service class queue and in the disposition router, the dot1p CoS bits (which are copied from EXP bits of the labels) are used to do the same. In addition to scheduling in the egress interface, the output policy action can also include remarking of EXP and RPR CoS bits.

EoMPLS on the ML-Series card uses the Cisco Modular Quality of Service Command-Line Interface (MQC), just like the standard QoS on the ML-Series card. But the full range of MQC commands are not available. [Table 17-1](#) lists the applicable MQC statements and actions for the ML-Series card interfaces.

**Table 17-1 Applicable EoMPLS QoS Statements and Actions**

Interface	Applicable MQC Match Statements	Applicable MQC Actions
Imposition Ingress	<b>match cos</b> <b>match ip precedence</b> <b>match ip dscp</b> <b>match vlan</b>	<b>police cir cir-burst [pir-burst pir</b> <b>pir conform [set-mpls-exp  </b> <b>exceed [set-mpls-exp][violate</b> <b>set-mpls-exp]</b>
Imposition Egress	<b>match mpls exp</b>	<b>bandwidth/priority</b> and <b>set mpls exp</b>
Disposition Ingress	Not applicable	Not applicable
Disposition Egress	<b>match mpls exp</b>	<b>bandwidth/priority</b> and <b>set cos</b>

## Configuring EoMPLS

The ML-Series peer cards on both endpoints of the EoMPLS point-to-point service must be configured. Perform the following configuration tasks to enable EoMPLS:

- [VC Type 4 Configuration on PE-CLE Port, page 17-5](#) (Either VC type 4 or VC type 5 is required.)
- [VC Type 5 Configuration on PE-CLE Port, page 17-6](#) (Either VC type 4 or VC type 5 is required.)
- [EoMPLS Configuration on PE-CLE SPR Interface, page 17-7](#) (Required)

- Bridge Group Configuration on MPLS Cloud-facing Port, page 17-7 (Required)
- Setting the Priority of Packets with the EXP, page 17-8

## EoMPLS Configuration Guidelines

These are the guidelines for configuring EoMPLS:

- Loopback addresses are used to specify the peer ML-Series card's IP address.
- LDP configuration is required. The default Tag Distribution Protocol (TDP) will not work.
- EoMPLS uses LDP targeted session between the ML-Series cards to create the EoMPLS VCs.
- The MPLS backbone must use an Interior Gateway Protocol (IGP) routing protocol, for example, Intermediate System-to-Intermediate System (IS-IS) Protocol or Open Shortest Path First (OSPF).
- Tag switching of IP packets must be enabled on the SPR interface for the PE-CLE ML-Series card.

## VC Type 4 Configuration on PE-CLE Port

The customer-facing FastEthernet or GigabitEthernet port must be provisioned with EoMPLS and a VC type 4 or type 5. Interface GigE 0.1 on card A and card C plays the VC type 4 role in [Figure 17-2 on page 17-9](#). For more information on the role of a VC type 4, see the “[Understanding EoMPLS](#)” section on [page 17-1](#).

To provision a VC type 4, which transport IEEE 802.1Q VLAN packets between two PE-CLE ML-Series cards, perform the following procedure on the customer facing port, beginning in global configuration mode:

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	Router(config)# <b>mpls label protocol ldp</b>	Specifies LDP as the label distribution protocol. LDP must be specified. The ML-Series card does not operate EoMPLS with the default TDP as the label distribution protocol.
<b>Step 2</b>	Router(config)# <b>interface loopback0</b>	Enters loopback interface configuration mode.
<b>Step 3</b>	Router(config-if)# <b>ip address ip-address 255.255.255.255</b>	Assigns an IP address to the loopback interface. This loopback IP addresses is used to identify the peer in the EoMPLS point-to-point session. No subnet mask is needed.
<b>Step 4</b>	Router(config)# <b>interface {GigabitEthernet   FastEthernet} interface-number.sub-interface-number</b>	Specifies the Ethernet subinterface for the imposition interface. Make sure the subinterface on the adjoining CE equipment is on the same VLAN as this subinterface.
<b>Step 5</b>	Router(config-subif)# <b>no ip address</b>	Disables the IP address if an IP address is assigned.

## ■ VC Type 5 Configuration on PE-CLE Port

Command	Purpose
<b>Step 6</b> Router(config-subif)# <b>encapsulation dot1Q</b> <i>vlan-id</i>	Enables the subinterface to accept 802.1q VLAN packets. Make sure the VLAN ID is the same as the VLAN ID on the adjoining CE equipment.
<b>Step 7</b> Router(config-subif)# <b>mpls 12transport route</b> <i>destination vc-id</i>	<p>Specifies the VC to use to transport the VLAN packets. Initiates a remote LDP session with the peer point-to-point endpoint interface.</p> <p>The argument <i>destination</i> specifies the loopback address of the remote ML-Series at the other end of the VC (PE-CLE).</p> <p>The argument <i>vc-id</i> is a value you supply. It must be unique for each VC. The VC ID is used to connect the endpoints of the VC. Specify the same VC ID on both ends of the VC.</p>

## VC Type 5 Configuration on PE-CLE Port

The customer-facing FastEthernet or GigabitEthernet port must be provisioned with EoMPLS and a VC type 4 or type 5. Interface GigE 1 on card A and card C plays the VC type 5 role in [Figure 17-2 on page 17-9](#). For more information on the role of a VC type 5, see the “[Understanding EoMPLS](#)” section on [page 17-1](#).

To provision a VC type 5, which transports the configured port’s packets between two PE-CLE ML-Series cards, perform the following procedure on the customer facing port, beginning in global configuration mode:

Command	Purpose
<b>Step 1</b> Router(config)# <b>mpls label protocol ldp</b>	Specifies LDP as the label distribution protocol. LDP must be specified. The ML-Series card does not operate EoMPLS with the default TDP as the label distribution protocol.
<b>Step 2</b> Router(config)# <b>interface loopback0</b>	Enters loopback interface configuration mode.
<b>Step 3</b> Router(config-if)# <b>ip address</b> <i>ip-address</i> <b>255.255.255.255</b>	Assigns an IP address to the loopback interface. This loopback IP addresses is used to identify the peer in the EoMPLS point-to-point session. No subnet mask is needed.
<b>Step 4</b> Router(config)# <b>interface {GigabitEthernet  </b> <b>FastEthernet} <i>interface-number</i></b>	Specifies the Ethernet interface for the imposition interface.

Command	Purpose
<b>Step 5</b> Router(config-if)# <b>no ip address</b>	Disables the IP address if an IP address is assigned.
<b>Step 6</b> Router(config-if)# <b>mpls 12transport route destination vc-id</b>	<p>Specifies the VC to use to transport the VLAN packets. Initiates a remote LDP session with the peer point-to-point endpoint interface.</p> <p><i>destination</i> specifies the loopback address of the remote ML-Series card at the other end of the VC (PE-CLE).</p> <p><i>vc-id</i> is a common identifier used by the endpoints to identify the created EoMPLS VC. It must be unique for each VC and the same VC ID must be used on both ends of the VC.</p>

## EoMPLS Configuration on PE-CLE SPR Interface

To enable the RPR to act as an access ring for the MPLS cloud, you must provision the SPR interface on the same ML-Series card that hosts the EoMPLS PE-CLE FastEthernet or GigabitEthernet interfaces. Interface SPR 1 on card A and card C plays this role in [Figure 17-2 on page 17-9](#).

To provision the SPR interface for MPLS, perform the following procedure, beginning in global configuration mode:

	Command	Purpose
<b>Step 1</b>	Router(config)# <b>mpls label protocol ldp</b>	Specifies LDP as the label distribution protocol. LDP must be specified. The ML-Series card does not operate EoMPLS with the default TDP as the label distribution protocol.
<b>Step 2</b>	Router(config)# <b>interface spr 1</b>	Enters RPR interface configuration mode.
<b>Step 3</b>	Router(config-if)# <b>ip address ip-address mask</b>	Assigns an IP address to the RPR interface for MPLS.
<b>Step 4</b>	Router(config-if)# <b>mpls ip</b>	Implements tag switching on the SPR interface.
<b>Step 5</b>	Router(config-if)# <b>end</b>	Exits interface configuration mode.
<b>Step 6</b>	Router# <b>copy running-config startup-config</b>	Saves the running configuration file to the startup configuration file.

## Bridge Group Configuration on MPLS Cloud-facing Port

A FastEthernet or GigabitEthernet port from an ML-Series card in the RPR must connect to the interface of a router that is part of the MPLS cloud. A bridge group must be created that contains this FastEthernet or GigabitEthernet port and the SPR subinterface. Interface GigE 0 on card B and card D plays this role in [Figure 17-2 on page 17-9](#).

To provision the MPLS cloud-facing port for EoMPLS, perform the following procedure, beginning in global configuration mode:

## Setting the Priority of Packets with the EXP

	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	Router(config)# <b>bridge bridge-group-number</b> <b>protocol {rstp   ieee}</b>	(Optional) Assigns a bridge group number and defines the appropriate spanning-tree type: either IEEE 802.1D Spanning Tree Protocol or IEEE 802.1W Rapid Spanning Tree.
<b>Step 2</b>	Router(config)# <b>interface {GigabitEthernet</b>   <b>FastEthernet</b> } <b>interface-number</b>	Enters interface configuration mode to configure the MPLS cloud-facing FastEthernet or GigabitEthernet interface of the ML-Series card.
<b>Step 3</b>	Router(config-if)# <b>bridge-group</b> <b>bridge-group-number</b>	Assigns a network interface to a bridge group.
<b>Step 4</b>	Router(config-if)# <b>no shutdown</b>	Changes the shutdown state to up and enables the interface.
<b>Step 5</b>	Router(config)# <b>interface</b> <b>spr 1.subinterface-number</b>	Enters SPR subinterface configuration mode for the ML-Series card.
<b>Step 6</b>	Router(config-if)# <b>bridge-group</b> <b>bridge-group-number</b>	Assigns the network interface to a bridge group.
<b>Step 7</b>	Router(config-if)# <b>end</b>	Returns to privileged EXEC mode.
<b>Step 8</b>	Router# <b>copy running-config startup-config</b>	(Optional) Saves your entries in the configuration file.

## Setting the Priority of Packets with the EXP

Ethernet over MPLS provides QoS using the three EXP bits in a label to determine the priority of packets. To support QoS between ML-Series card point-to-point endpoints, set the experimental bits in both the VC and tunnel labels.

Perform the following steps to set the experimental bits:


	<b>Command</b>	<b>Purpose</b>
<b>Step 1</b>	Router(config)# <b>class-map</b> <b>class-name</b>	Specifies the user-defined name of the traffic class.
<b>Step 2</b>	Router(config-cmap)# <b>match</b> <b>any</b>	Specifies that all packets will be matched.
<b>Step 3</b>	Router(config-cmap)# <b>policy-map</b> <b>policy-name</b>	Specifies the name of the traffic policy to configure.
<b>Step 4</b>	Router(config-pmap)# <b>class</b> <b>class-name</b>	Specifies the name of a predefined traffic class, which was configured with the class-map command, used to classify traffic to the traffic policy.
<b>Step 5</b>	Router (config-pmap-c)# <b>set</b> <b>mpls experimental value</b>	Designates the value to which the MPLS bits are set if the packets match the specified policy map.

	<b>Command</b>	<b>Purpose</b>
<b>Step 6</b>	Router(config)# <b>interface</b> <b>GigabitEthernet</b> <i>interface-number</i>  or  <b>interface FastEthernet</b> <i>interface-number</i>	Enters interface configuration mode.
<b>Step 7</b>	Router(config-if)# <b>service-policy input</b> <i>policy-name</i>	Attaches a traffic policy to an interface.

## EoMPLS Configuration Example

Figure 17-2 illustrates the sample network that the configuration commands reference. Examples 17-1, 17-2, 17-3, and 17-4 list relevant portions of the configuration files for enabling EoMPLS on ML-Series cards in a sample network.

**Figure 17-2 EoMPLS Configuration Example**



96982

### Example 17-1 ML-Series Card A Configuration

```

microcode mpls
ip subnet-zero
no ip domain-lookup
!
mpls label protocol ldp
!
interface Loopback0
    ip address 10.10.10.10 255.255.255.255
!
```

**EoMPLS Configuration Example**

```

interface SPR1
  ip address 100.100.100.100 255.255.255.0
  no keepalive
  spr station-id 1
  mpls ip
  hold-queue 150 in
!
interface GigabitEthernet0
  no ip address
!
interface GigabitEthernet0.1
  encapsulation dot1Q 10
  mpls 12transport route 3.3.3.3 1
!
interface GigabitEthernet1
  no ip address
  mpls 12transport route 4.4.4.4 2
!
interface POS0
  no ip address
  spr-intf-id 1
  crc 32
!
interface POS1
  no ip address
  spr-intf-id 1
  crc 32
  router ospf 1
    log-adjacency-changes
    network 1.1.1.0 0.0.0.255 area 0
    network 10.10.10.0 0.0.0.255 area 0
!
  ip classless
  no ip http server

```

***Example 17-2 ML-Series Card B Configuration***

```

bridge 10 protocol ieee
!
!
interface SPR1
  no ip address
  no keepalive
  bridge-group 10
  hold-queue 150 in
!
interface GigabitEthernet0
  no ip address
  bridge-group 10

```

***Example 17-3 ML-Series Card C Configuration***

```

microcode mpls
ip subnet-zero
no ip domain-lookup
!
mpls label protocol ldp
!
interface Loopback0
  ip address 20.20.20.20 255.255.255.255
!
```

```

interface SPR1
  ip address 100.100.100.100 255.255.255.0
  no keepalive
  spr station-id 4
  mpls ip
  hold-queue 150 in
!
interface GigabitEthernet0
  no ip address
!
interface GigabitEthernet0.1
  encapsulation dot1Q 10
  mpls 12transport route 1.1.1.1 1
!
interface GigabitEthernet1
  no ip address
  mpls 12transport route 2.2.2.2 2
!
interface POS0
  no ip address
  spr-intf-id 1
  crc 32
!
interface POS1
  no ip address
  spr-intf-id 1
  crc 32
!
router ospf 1
  log-adjacency-changes
  network 1.1.1.0 0.0.0.255 area 0
  network 10.10.10.0 0.0.0.255 area 0
!
ip classless
no ip http server

```

**Example 17-4 ML-Series Card D Configuration**

```

bridge 20 protocol ieee
!
!
interface SPR1
no ip address
no keepalive
  bridge-group 20
  hold-queue 150 in
!
interface GigabitEthernet0
no ip address
bridge-group 20

```

## Monitoring and Verifying EoMPLS

Table 17-2 shows the privileged EXEC commands for monitoring and verifying EoMPLS.

**Table 17-2 Commands for Monitoring and Maintaining Tunneling**

<b>Command</b>	<b>Purpose</b>
<code>show mpls l2transport vc</code>	Provides information about all EoMPLS tunnels.
<code>show mpls l2transport vc detailed</code>	Provides detailed information about the EoMPLS tunnel.
<code>show mpls l2transport vc summary</code>	Provides summary information about the EoMPLS tunnel.
<code>show mpls l2transport vc vc-id</code>	Provides information about a specific EoMPLS tunnel.