

Introduction to the Cisco ASA

The Cisco ASA provides advanced stateful firewall and VPN concentrator functionality in one device as well as integrated services with add-on modules. The ASA includes many advanced features, such as multiple security contexts (similar to virtualized firewalls), clustering (combining multiple firewalls into a single firewall), transparent (Layer 2) firewall or routed (Layer 3) firewall operation, advanced inspection engines, IPsec VPN, SSL VPN, and clientless SSL VPN support, and many more features.



Note

ASDM supports many ASA versions. The ASDM documentation and online help includes all of the latest features supported by the ASA. If you are running an older version of ASA software, the documentation might include features that are not supported in your version. Please refer to the feature history table for each chapter to determine when features were added. For the minimum supported version of ASDM for each ASA version, see Cisco ASA Compatibility. See also Special, Deprecated, and Legacy Services, on page 22.

- ASDM Requirements, on page 1
- Hardware and Software Compatibility, on page 4
- VPN Compatibility, on page 5
- New Features, on page 5
- Firewall Functional Overview, on page 17
- VPN Functional Overview, on page 21
- Security Context Overview, on page 21
- ASA Clustering Overview, on page 22
- Special, Deprecated, and Legacy Services, on page 22

ASDM Requirements

ASDM Java Requirements

You can install ASDM using Oracle JRE 8.0. OpenJRE is not supported.



Note

ASDM is not tested on Linux.

Table 1: ASA and ASA FirePOWER: ASDM Operating System and Browser Requirements

Operating System	Browser			Oracle JRE	
	Internet Explorer	Firefox	Safari	Chrome	
Microsoft Windows (English and Japanese):	Yes	Yes	No support	Yes	8.0
7					
Server 2012 R2					
Server 2012					
Server 2008					
Apple OS X 10.4 and later	No support	Yes	Yes	Yes (64-bit version only)	8.0

ASDM Compatibility Notes

The following table lists compatibility caveats for ASDM.

Conditions	Notes	
Windows 10	"This app can't run on your PC" error message.	
	When you install the ASDM Launcher, Windows 10 might replace the ASDM shortcut target with the Windows Scripting Host path, which causes this error. To fix the shortcut target:	
	1. Choose Start > Cisco ASDM-IDM Launcher, and right-click the Cisco ASDM-IDM Launcher application.	
	2. Choose More > Open file location.	
	Windows opens the directory with the shortcut icon.	
	3. Right click the shortcut icon, and choose Properties .	
	4. Change the Target to:	
	C:\Windows\System32\wscript.exe invisible.vbs run.bat	
	5. Click OK.	
OS X	On OS X, you may be prompted to install Java the first time you run ASDM; follow the prompts as necessary. ASDM will launch after the installation completes.	

Conditions Notes OS X 10.8 and later You need to allow ASDM to run because it is not signed with an Apple Developer ID. If you do not change your security preferences, you see an error screen. "Cisco ASDM-IDM" can't be opened because it is from an unidentified developer. Your security preferences allow installation of only apps from the Mac App Store and identified developers. "Cisco ASDM-IDM" is on the disk image "dm launcher-3.dmg*. Safari downloaded this disk image today at 3:47 PM from 172.23.195.57. ? 1. To allow ASDM to run, right-click (or Ctrl-Click) the Cisco ASDM-IDM Launcher icon, and choose **Open**. Chess.app Mar 21, 2013 2:14 PM K Cisco ASDM-IDM.app Open Cisco Jabber.app Show Package Contents Contacts.app Move to Trash 1 of 62 select Get Info Compress "Cisco ASDM-IDM.app" Burn "Cisco ASDM-IDM.app" to Disc ... Duplicate Make Alias Quick Look "Cisco ASDM-IDM.app" Share Copy "Cisco ASDM-IDM.app" **Show View Options** Label: x 2. You see a similar error screen; however, you can open ASDM from this screen. Click Open. The ASDM-IDM Launcher opens. "Cisco ASDM-IDM.app" is from an unidentified developer. Are you sure you want to open it? Opening "Cisco ASDM-IDM.app" will always allow it to run on this Mac. Google Chrome.app downloaded this file on December 4, 2013 from 10.86.118.3.

(?)

Cancel

Condition	ons	Notes	
Requires Strong Encryption license (3DES/AES) on ASA		ASDM requires an SSL connection to the ASA. You can request a 3DES license from Cisco:	
	Smart licensing models allow	1. Go to www.cisco.com/go/license.	
	initial access with ASDM without the Strong Encryption	2. Click Continue to Product License Registration.	
	license.	3. In the Licensing Portal, click Get Other Licenses next to the text field.	
		4. Choose IPS , Crypto , Other from the drop-down list.	
		5. Type ASA in to the Search by Keyword field.	
		6. Select Cisco ASA 3DES/AES License in the Product list, and click Next.	
	7. Enter the serial number of the ASA, and follow the prompts to request a 3DES/AES license for the ASA.		
cer • IPv	If-signed certificate or an untrusted rtificate v6 refox and Safari	When the ASA uses a self-signed certificate or an untrusted certificate, Firefox and Safari are unable to add security exceptions when browsing using HTTPS over IPv6. See https://bugzilla.mozilla.org/show_bug.cgi?id=633001 . This caveat affects all SSL connections originating from Firefox or Safari to the ASA (including ASDM connections). To avoid this caveat, configure a proper certificate for the ASA that is issued by a trusted certificate authority.	
inc RC in	L encryption on the ASA must clude both RC4-MD5 and C4-SHA1 or disable SSL false start Chrome.	If you change the SSL encryption on the ASA to exclude both RC4-MD5 and RC4-SHA1 algorithms (these algorithms are enabled by default), then Chrome cannot launch ASDM due to the Chrome "SSL false start" feature. We suggest re-enabling one of these algorithms (see the Configuration > Device Management > Advanced > SSL Settings pane); or you can disable SSL false start in Chrome using thedisable-ssl-false-start flag according to Run Chromium with flags.	
IE9 for	servers	For Internet Explorer 9.0 for servers, the " Do not save encrypted pages to disk " option is enabled by default (See Tools > Internet Options > Advanced). This option causes the initial ASDM download to fail. Be sure to disable this option to allow ASDM to download.	

Hardware and Software Compatibility

For a complete list of supported hardware and software, see Cisco ASA Compatibility.

VPN Compatibility

See Supported VPN Platforms, Cisco ASA Series.

New Features

This section lists new features for each release.



Note

New, changed, and deprecated syslog messages are listed in the syslog message guide.

New Features in ASA 9.6(4)/ASDM 7.9(1)

Released: December 13, 2017

There are no new features in this release.

New Features in ASA 9.6(3.1)/ASDM 7.7(1)

Released: April 3, 2017



Note

Version 9.6(3) was removed from Cisco.com due to bug CSCvd78303.

Feature	Description
AAA Features	
Separate authentication for users with SSH public key authentication and users with passwords	In releases prior to 9.6(2), you could enable SSH public key authentication (ssh authentication) without also explicitly enabling AAA SSH authentication with the Local user database (aaa authentication ssh console LOCAL). In 9.6(2), the ASA required you to explicitly enable AAA SSH authentication. In this release, you no longer have to explicitly enable AAA SSH authentication; when you configure the ssh authentication command for a user, local authentication is enabled by default for users with this type of authentication. Moreover, when you explicitly configure AAA SSH authentication, this configuration only applies for for usernames with passwords, and you can use any AAA server type (aaa authentication ssh console radius_1, for example). For example, some users can use public key authentication using the local database, and other users can use passwords with RADIUS. We did not modify any screens.

New Features in ASDM 7.6(2.150)

Released: October 12, 2016

There are no new features in this release.

New Features in ASA 9.6(2)/ASDM 7.6(2)

Released: August 24, 2016

Feature	Description
Platform Features	
ASA for the Firepower 4150	We introduced the ASA for the Firepower 4150.
	Requires FXOS 2.0.1.
	We did not add or modify any screens.
Hot Plug Interfaces on the ASAv	You can add and remove Virtio virtual interfaces on the ASAv while the system is active. When you add a new interface to the ASAv, the virtual machine detects and provisions the interface. When you remove an existing interface, the virtual machine releases any resource associated with the interface. Hot plug interfaces are limited to Virtio virtual interfaces on the Kernel-based Virtual Machine (KVM) hypervisor.
Microsoft Azure support on the ASAv10	Microsoft Azure is a public cloud environment that uses a private Microsoft Hyper V Hypervisor. The ASAv runs as a guest in the Microsoft Azure environment of the Hyper V Hypervisor. The ASAv on Microsoft Azure supports one instance type, the Standard D3, which supports four vCPUs, 14 GB, and four interfaces. Also in 9.5(2.200).
Through traffic support on the Management 0/0 interface for the ASAv	You can now allow through traffic on the Management 0/0 interface on the ASAv. Previously, only the ASAv on Microsoft Azure supported through traffic; now all ASAvs support through traffic. You can optionally configure this interface to be management-only, but it is not configured by default.

Feature	Description
Common Criteria Certification	The ASA was updated to comply with the Common Criteria requirements. See the rows in this table for the following features that were added for this certification:
	ASA SSL Server mode matching for ASDM
	SSL client RFC 6125 support:
	Reference Identities for Secure Syslog Server connections and Smart Licensing connections
	ASA client checks Extended Key Usage in server certificates
	Mutual authentication when ASA acts as a TLS client for TLS1.1 and 1.2
	PKI debug messages
	Crypto Key Zeroization verification
	IPsec/ESP Transport Mode Support for IKEv2
	New syslog messages
Firewall Features	
DNS over TCP inspection	You can now inspect DNS over TCP traffic (TCP/53).
	We modified the following page: Configuration > Firewall > Objects > Inspection Maps > DNS Add/Edit dialog box
MTP3 User Adaptation (M3UA) inspection	You can now inspect M3UA traffic and also apply actions based on point code, service indicator, and message class and type.
	We added or modified the following pages: Configuration > Firewall > Objects > Inspection Maps > M3UA; the Rule Action > Protocol Inspection tab for service policy rules
Session Traversal Utilities for NAT (STUN) inspection	You can now inspect STUN traffic for WebRTC applications including Cisco Spark. Inspection opens pinholes required for return traffic.
	We added an option to the Rule Actions > Protocol Inspection tab of the Add/Edit Service Policy dialog box
Application layer health checking for Cisco Cloud Web Security	You can now configure Cisco Cloud Web Security to check the health of the Cloud Web Security application when determining if the server is healthy. By checking application health, the system can fail over to the backup server when the primary server responds to the TCP three-way handshake but cannot process requests. This ensures a more reliable system.
	We modified the following screen: Configuration > Device Management > Cloud Web Security

Feature	Description
Connection holddown timeout for route convergence.	You can now configure how long the system should maintain a connection when the route used by the connection no longer exists or is inactive. If the route does not become active within this holddown period, the connection is freed. You can reduce the holddown timer to make route convergence happen more quickly. However, the 15 second default is appropriate for most networks to prevent route flapping.
	We modified the following screen: Configuration > Firewall > Advanced > Global Timeouts
	Also in 9.4(3).
Changes in TCP option handling	You can now specify actions for the TCP MSS and MD5 options in a packet's TCP header when configuring a TCP map. In addition, the default handling of the MSS, timestamp, window-size, and selective-ack options has changed. Previously, these options were allowed, even if there were more than one option of a given type in the header. Now, packets are dropped by default if they contain more than one option of a given type. For example, previously a packet with 2 timestamp options would be allowed, now it will be dropped.
	You can configure a TCP map to allow multiple options of the same type for MD5, MSS, selective-ack, timestamp, and window-size. For the MD5 option, the previous default was to clear the option, whereas the default now is to allow it. You can also drop packets that contain the MD5 option. For the MSS option, you can set the maximum segment size in the TCP map (per traffic class). The default for all other TCP options remains the same: they are cleared.
	We modified the following screen: Configuration > Firewall > Objects > TCP Maps Add/Edit dialog box
Transparent mode maximum interfaces per bridge group increased to 64	The maximum interfaces per bridge group was increased from 4 to 64. We did not modify any screens.
Flow offload support for multicast connections in transparent mode.	You can now offload multicast connections to be switched directly in the NIC on transparent mode Firepower 4100 and 9300 series devices. Multicast offload is available for bridge groups that contain two and only two interfaces.
	There are no new commands or ASDM screens for this feature.
Customizable ARP rate limiting	You can set the maximum number of ARP packets allowed per second. The default value depends on your ASA model. You can customize this value to prevent an ARP storm attack.
	We modified the following screen: Configuration > Device Management > Advanced > ARP > ARP Static Table
Ethertype rule support for the IEEE 802.2 Logical Link Control packet's Destination Service Access Point	You can now write Ethertype access control rules for the IEEE 802.2 Logical Link Control packet's Destination Service Access Point address. Because of this addition, the bpdu keyword no longer matches the intended traffic. Rewrite bpdu rules for dsap 0x42 .
address.	We modified the following screen: Configuration > Firewall > EtherType Rules .
Remote Access Features	1
Pre-fill/Username-from-cert feature for multiple context mode	AnyConnect SSL support is extended, allowing pre-fill/username-from-certificate feature CLIs, previously available only in single mode, to be enabled in multiple context mode as well.
	We did not modify any screens.

Feature	Description
Flash Virtualization for Remote Access VPN	Remote access VPN in multiple context mode now supports flash virtualization. Each context can have a private storage space and a shared storage place based on the total flash that is available:
	• Private storage—Store files associated only with that user and specific to the content that you want for that user.
	Shared storage—Upload files to this space and have it accessible to any user context for read/write access once you enable it.
	We modified the following screens: Configuration > Context Management > Resource Class > Add Resource Class
	Configuration > Context Management > Security Contexts
AnyConnect client profiles supported in multiple context mode	AnyConnect client profiles are supported in multiple context mode. To add a new profile using ASDM, you must have the AnyConnect Secure Mobility Client release 4.2.00748 or 4.3.03013 and later.
Stateful failover for AnyConnect	Stateful failover is now supported for AnyConnect connections in multiple context mode.
connections in multiple context mode	We did not modify any screens.
Remote Access VPN Dynamic	You can now configure DAP per context in multiple context mode.
Access Policy (DAP) is supported in multiple context mode	We did not modify any screens.
Remote Access VPN CoA (Change	You can now configure CoA per context in multiple context mode.
of Authorization) is supported in multiple context mode	We did not modify any screens.
Remote Access VPN localization is supported in multiple context mode	Localization is supported globally. There is only one set of localization files that are shared across different contexts.
	We did not modify any screens.
Umbrella Roaming Security module support	You can choose to configure the AnyConnect Secure Mobility Client's Umbrella Roaming Security module for additional DNS-layer security when no VPN is active.
	We modified the following screen: Configuration > Remote Access VPN > Network (Client) Access > AnyConnect Client Profile.
IPsec/ESP Transport Mode Support for IKEv2	Transport mode is now supported for ASA IKEv2 negotiation. It can be used in place of tunnel (default) mode. Tunnel mode encapsulates the entire IP packet. Transport mode encapsulates only the upper-layer protocols of an IP packet. Transport mode requires that both the source and destination hosts support IPSec, and can only be used when the destination peer of the tunnel is the final destination of the IP packet.
	We modified the following screen: Configuration > Remote Access VPN > Network (Client) Access > Advanced > IPsec > IPsec Proposals (Transform Sets) > IKEv2 proposals > Add/Edit

Feature	Description
Per-packet routing lookups for IPsec inner packets	By default, per-packet adjacency lookups are done for outer ESP packets; lookups are not done for packets sent through the IPsec tunnel. In some network topologies, when a routing update has altered the inner packet's path, but the local IPsec tunnel is still up, packets through the tunnel may not be routed correctly and fail to reach their destination. To prevent this, use the new option to enable per-packet routing lookups for the IPsec inner packets.
	We modified the following screen: Configuration > Remote Access VPN > Network (Client) Access > Advanced > IPsec > Crypto Maps adding the Enable IPsec Inner Routing Lookup checkbox.
Certificate and Secure Connection	Features
ASA client checks Extended Key Usage in server certificates	Syslog and Smart licensing Server Certificates must contain "ServerAuth" in the Extended Key Usage field. If not, the connection fails.
Mutual authentication when ASA acts as a TLS client for TLS1.1 and 1.2	If the server requests a client certificate from the ASA for authentication, the ASA will send the client identity certificate configured for that interface. The certificate is configured by the ssl trust-point command.
PKI debug messages	The ASA PKI module makes connections to CA servers such as SCEP enrollment, revocation checking using HTTP, etc. All of these ASA PKI exchanges will be logged as debug traces under debug crypto ca message 5.
ASA SSL Server mode matching for ASDM	For an ASDM user who authenticates with a certificate, you can now require the certificate to match a certificate map.
	We modified the following screen: Configuration > Device Management > Management Access > ASDM/HTTPS/Telnet/SSH
Reference Identities for Secure Syslog Server connections and Smart Licensing connections	TLS client processing now supports rules for verification of a server identity defined in RFC 6125, Section 6. Identity verification will be done during PKI validation for TLS connections to the Syslog Server and the Smart Licensing server only. If the presented identity cannot be matched against the configured reference identity, the connection is not established.
	We modifed the following screens:
	Configuration > Remote Access VPN > Advanced
	Configuration > Device Management > Logging > Syslog Servers > Add/Edit
	Configuration > Device Management > Smart Call Home
Crypto Key Zeroization verification	The ASA crypto system has been updated to comply with new key zeroization requirements. Keys must be overwritten with all zeros and then the data must be read to verify that the write was successful.

Feature	Description
SSH public key authentication improvements	In earlier releases, you could enable SSH public key authentication without also enabling AAA SSH authentication with the Local user database. The configuration is now fixed so that you must explicitly enable AAA SSH authentication. To disallow users from using a password instead of the private key, you can now create a username without any password defined.
	We modifed the following screens:
	Configuration > Device Management > Management Access > ASDM/HTTPS/Telnet/SSH
	Configuration > Device Management > Users/AAA > User Accounts > Add/Edit User Account
Interface Features	
Increased MTU size for the ASA on the Firepower 4100/9300 chassis	You can set the maximum MTU to 9188 bytes on the Firepower 4100 and 9300; formerly, the maximum was 9000 bytes. This MTU is supported with FXOS 2.0.1.68 and later.
	We modified the following screen: Configuration > Device Setup > Interface Settings > Interfaces > Advanced
Routing Features	
Bidirectional Forwarding Detection (BFD) Support	The ASA now supports the BFD routing protocol. Support was added for configuring BFD templates, interfaces, and maps. Support for BGP routing protocol to use BFD was also added.
	We added or modified the following screens:
	Configuration > Device Setup > Routing > BFD > Template
	Configuration > Device Setup > Routing > BFD > Interface
	Configuration > Device Setup > Routing > BFD > Map
	Configuration > Device Setup > Routing > BGP > IPv6 Family > Neighbors

Feature	Description
IPv6 DHCP	The ASA now supports the following features for IPv6 addressing:
	 DHCPv6 Address client—The ASA obtains an IPv6 global address and optional default route from the DHCPv6 server.
	DHCPv6 Prefix Delegation client—The ASA obtains delegated prefix(es) from a DHCPv6 server. The ASA can then use these prefixes to configure other ASA interface addresses so that StateLess Address Auto Configuration (SLAAC) clients can autoconfigure IPv6 addresses on the same network.
	BGP router advertisement for delegated prefixes
	DHCPv6 stateless server—The ASA provides other information such as the domain name to SLAAC clients when they send Information Request (IR) packets to the ASA. The ASA only accepts IR packets, and does not assign addresses to the clients.
	We added or modified the following screens:
	Configuration > Device Setup > Interface Settings > Interface > Add Interface > IPv6
	Configuration > Device Management > DHCP > DHCP Pool
	Configuration > Device Setup > Routing > BGP > IPv6 Family > Networks
	Monitoring > interfaces > DHCP
High Availability and Scalability F	Features
Improved sync time for dynamic ACLs from AnyConnect when using Active/Standby failover	When you use AnyConnect on a failover pair, then the sync time for the associated dynamic ACLs (dACLs) to the standby unit is now improved. Previously, with large dACLs, the sync time could take hours during which time the standby unit is busy syncing instead of providing high availability backup.
	We did not modify any screens.
Licensing Features	
Permanent License Reservation for the ASAv	For highly secure environments where communication with the Cisco Smart Software Manager is not allowed, you can request a permanent license for the ASAv. In 9.6(2), we also added support for this feature for the ASAv on Amazon Web Services. This feature is not supported for Microsoft Azure.
	Note Not all accounts are approved for permanent license reservation. Make sure you have approval from Cisco for this feature before you attempt to configure it.
	We introduced the following commands: license smart reservation, license smart reservation cancel, license smart reservation install, license smart reservation request universal, license smart reservation return
	No ASDM support.
	Also in 9.5(2.200).

Feature	Description
Satellite Server support for the ASAv	If your devices cannot access the internet for security reasons, you can optionally install a local Smart Software Manager satellite server as a virtual machine (VM).
	We did not modify any screens.
Permanent License Reservation for the ASAv Short String enhancement	Due to an update to the Smart Agent (to 1.6.4), the request and authorization codes now use shorter strings.
	We did not modify any screens.
Permanent License Reservation for the ASA on the Firepower 4100/9300 chassis	For highly secure environments where communication with the Cisco Smart Software Manager is not allowed, you can request a permanent license for the ASA on the Firepower 9300 and Firepower 4100. All available license entitlements are included in the permanent license, including the Standard Tier, Strong Encryption (if qualified), Security Contexts, and Carrier licenses. Requires FXOS 2.0.1.
	All configuration is performed on the Firepower 4100/9300 chassis; no configuration is required on the ASA.
Smart Agent Upgrade for ASAv to v1.6	The smart agent was upgraded from Version 1.1 to Version 1.6. This upgrade supports permanent license reservation and also supports setting the Strong Encryption (3DES/AES) license entitlement according to the permission set in your license account.
	Note If you downgrade from Version 9.5(2.200), the ASAv does not retain the licensing registration state. You need to re-register with the Configuration > Device Management > Licensing > Smart Licensing page with the Force registration option; obtain the ID token from the Smart Software Manager.
	We did not change any screens.
	Also in 9.5(2.200).
Monitoring Features	
Packet capture of type asp-drop supports ACL and match filtering	When you create a packet capture of type asp-drop, you can now also specify an ACL or match option to limit the scope of the capture.
	We did not modify any screens.
Forensic Analysis enhancements	You can create a core dump of any process running on the ASA. The ASA also extracts the text section of the main ASA process that you can copy from the ASA for examination.
	We did not modify any screens.
Tracking Packet Count on a Per-Connection Basis through NetFlow	Two counters were added that allow Netflow users to see the number of Layer 4 packets being sent in both directions on a connection. You can use these counters to determine average packet rates and sizes and to better predict traffic types, anomalies, and events.
	We did not modify any screens.

Feature	Description
SNMP engineID sync for Failover	In a failover pair, the SNMP engineIDs of the paired ASAs are synced on both units. Three sets of engineIDs are maintained per ASA—synced engineID, native engineID and remote engineID.
	An SNMPv3 user can also specify the engineID of the ASA when creating a profile to preserve localized snmp-server user authentication and privacy options. If a user does not specify the native engineID, the show running config output will show two engineIDs per user.
	We modified the following command: snmp-server user
	No ASDM support.
	Also in 9.4(3).

New Features in ASA 9.6(1)/ASDM 7.6(1)

Released: March 21, 2016



Note

The ASAv 9.5.2(200) features, including Microsoft Azure support, are not available in 9.6(1). They are available in 9.6(2).

Feature	Description
Platform Features	
ASA for the Firepower 4100 series	We introduced the ASA for the Firepower 4110, 4120, and 4140.
	Requires FXOS 1.1.4.
	We did not add or modify any screens.
SD card support for the ISA 3000	You can now use an SD card for external storage on the ISA 3000. The card appears as disk3 in the ASA file system. Note that plug and play support requires hardware version 2.1 and later. Use the show module command to check your hardware version.
	We did not add or modify any screens.
Dual power supply support for the ISA 3000	For dual power supplies in the ISA 3000, you can establish dual power supplies as the expected configuration in the ASA OS. If one power supply fails, the ASA issues an alarm. By default, the ASA expects a single power supply and won't issue an alarm as long as it includes one working power supply.
	No ASDM support.
Firewall Features	1

Feature	Description
Diameter inspection improvements	You can now inspect Diameter over TCP/TLS traffic, apply strict protocol conformance checking, and inspect Diameter over SCTP in cluster mode.
	We added or modified the following screens:
	Configuration > Firewall > Objects > Inspect Maps > Diameter
	Configuration > Firewall > Service Policy add/edit wizard's Rule Actions > Protocol Inspection tab
SCTP stateful inspection in cluster mode	SCTP stateful inspection now works in cluster mode. You can also configure SCTP stateful inspection bypass in cluster mode.
	We did not add or modify any screens.
H.323 inspection support for the H.255 FACILITY message coming before the H.225 SETUP message for H.460.18 compatibility.	You can now configure an H.323 inspection policy map to allow for H.225 FACILITY messages to come before the H.225 SETUP message, which can happen when endpoints comply with H.460.18.
	We added an option to the Call Attributes tab in the H.323 inspection policy map.
Cisco Trustsec support for Security Exchange Protocol (SXP) version 3.	Cisco Trustsec on ASA now implements SXPv3, which enables SGT-to-subnet bindings, which are more efficient than host bindings.
	We modified the following screens: Configuration > Firewall > Identity By TrustSec and the SGT Map Setup dialog boxes.
Flow off-load support for the Firepower 4100 series.	You can identify flows that should be off-loaded from the ASA and switched directly in the NIC for the Firepower 4100 series.
	Requires FXOS 1.1.4.
	We did not add or modify any screens.
Remote Access Features	
IKEv2 Fragmentation, RFC-7383 support	The ASA now supports this standard fragmentation of IKEv2 packets. This allows interoperability with other IKEv2 implementations such as Apple, Strongswan etc. ASA continues to support the current, proprietary IKEv2 fragmentation to maintain backward compatibility with Cisco products that do not support RFC-7383, such as the AnyConnect client.
VPN Throughput Performance Enhancements on Firepower 9300 and Firepower 4100 series	The crypto engine accelerator-bias command is now supported on the ASA security module on the Firepower 9300 and Firepower 4100 series. This command lets you "bias" more crypto cores toward either IPSec or SSL.
	We did not add or modify any screens.

Feature	Description
Configurable SSH encryption and HMAC algorithm.	Users can select cipher modes when doing SSH encryption management and can configure HMAC and encryption for varying key exchange algorithms. You might want to change the ciphers to be more or less strict, depending on your application. Note that the performance of secure copy depends partly on the encryption cipher used. By default, the ASA negotiates one of the following algorithms in order: 3des-cbc aes128-cbc aes192-cbc aes256-cbc aes128-ctr aes192-ctr aes256-ctr. If the first algorithm proposed (3des-cbc) is chosen, then the performance is much slower than a more efficient algorithm such as aes128-cbc. To change the proposed ciphers, use ssh cipher encryption custom aes128-cbc , for example.
	We introduced the following screen: Configuration > Device Management > Advanced > SSH Ciphers
	Also available in 9.1(7), 9.4(3), and 9.5(3).
HTTP redirect support for IPv6	When you enable HTTP redirect to HTTPS for ASDM access or clientless SSL VPN, you can now redirect traffic sent an to IPv6 address.
	We added functionality to the following screen: Configuration > Device Management > HTTP Redirect
	Also available in 9.1(7) and 9.4(3).
Routing Features	
IS-IS routing	The ASA now supports the Intermediate System to Intermediate System (IS-IS) routing protocol. Support was added for routing data, performing authentication, and redistributing and monitoring routing information using the IS-IS routing protocol.
	We introduced the following screens:
	Configuration > Device Setup > Routing > ISIS
	Monitoring > Routing > ISIS
High Availability and Scalability F	Ceatures Ceatures
Support for site-specific IP addresses in Routed, Spanned EtherChannel mode	For inter-site clustering in routed mode with Spanned EtherChannels, you can now configure site-specific IP addresses in addition to site-specific MAC addresses. The addition of site IP addresses allows you to use ARP inspection on the Overlay Transport Virtualization (OTV) devices to prevent ARP responses from the global MAC address from traveling over the Data Center Interconnect (DCI), which can cause routing problems. ARP inspection is required for some switches that cannot use VACLs to filter MAC addresses.
	We modified the following screen: Configuration > Device Setup > Interface Settings > Interfaces > Add/Edit EtherChannel Interface > Advanced

Feature	Description
Longer password support for local username and enable passwords (up to 127 characters)	You can now create local username and enable passwords up to 127 characters (the former limit was 32). When you create a password longer than 32 characters, it is stored in the configuration using a PBKDF2 (Password-Based Key Derivation Function 2) hash. Shorter passwords continue to use the MD5-based hashing method.
	We modified the following screens:
	Configuration > Device Setup > Device Name/Password > Enable Password
	Configuration > Device Management > Users/AAA > User Accounts > Add/Edit User Account > Identity
Support for the cempMemPoolTable in the CISCO-ENHANCED-MEMPOOL-MIB	The cempMemPoolTable of the CISCO-ENHANCED-MEMPOOL-MIB is now supported. This is a table of memory pool monitoring entries for all physical entities on a managed system. Note The CISCO-ENHANCED-MEMPOOL-MIB uses 64-bit counters and supports reporting of memory on platforms with more than 4GB of RAM. We did not add or modify any screens.
	Also available in 9.1(7) and 9.4(3).
REST API Version 1.3.1	We added support for the REST API Version 1.3.1.

Firewall Functional Overview

Firewalls protect inside networks from unauthorized access by users on an outside network. A firewall can also protect inside networks from each other, for example, by keeping a human resources network separate from a user network. If you have network resources that need to be available to an outside user, such as a web or FTP server, you can place these resources on a separate network behind the firewall, called a *demilitarized zone* (DMZ). The firewall allows limited access to the DMZ, but because the DMZ only includes the public servers, an attack there only affects the servers and does not affect the other inside networks. You can also control when inside users access outside networks (for example, access to the Internet), by allowing only certain addresses out, by requiring authentication or authorization, or by coordinating with an external URL filtering server.

When discussing networks connected to a firewall, the *outside* network is in front of the firewall, the *inside* network is protected and behind the firewall, and a *DMZ*, while behind the firewall, allows limited access to outside users. Because the ASA lets you configure many interfaces with varied security policies, including many inside interfaces, many DMZs, and even many outside interfaces if desired, these terms are used in a general sense only.

Security Policy Overview

A security policy determines which traffic is allowed to pass through the firewall to access another network. By default, the ASA allows traffic to flow freely from an inside network (higher security level) to an outside network (lower security level). You can apply actions to traffic to customize the security policy.

Permitting or Denying Traffic with Access Rules

You can apply access rules to limit traffic from inside to outside, or allow traffic from outside to inside. For bridge group interfaces, you can also apply an EtherType access rule to allow non-IP traffic.

Applying NAT

Some of the benefits of NAT include the following:

- You can use private addresses on your inside networks. Private addresses are not routable on the Internet.
- NAT hides the local addresses from other networks, so attackers cannot learn the real address of a host.
- NAT can resolve IP routing problems by supporting overlapping IP addresses.

Protecting from IP Fragments

The ASA provides IP fragment protection. This feature performs full reassembly of all ICMP error messages and virtual reassembly of the remaining IP fragments that are routed through the ASA. Fragments that fail the security check are dropped and logged. Virtual reassembly cannot be disabled.

Applying HTTP, HTTPS, or FTP Filtering

Although you can use access lists to prevent outbound access to specific websites or FTP servers, configuring and managing web usage this way is not practical because of the size and dynamic nature of the Internet.

You can configure Cloud Web Security on the ASA, or install an ASA module that provides URL and other filtering services, such as ASA CX or ASA FirePOWER. You can also use the ASA in conjunction with an external product such as the Cisco Web Security Appliance (WSA).

Applying Application Inspection

Inspection engines are required for services that embed IP addressing information in the user data packet or that open secondary channels on dynamically assigned ports. These protocols require the ASA to do a deep packet inspection.

Sending Traffic to Supported Hardware or Software Modules

Some ASA models allow you to configure software modules, or to insert hardware modules into the chassis, to provide advanced services. These modules provide additional traffic inspection and can block traffic based on your configured policies. You can send traffic to these modules to take advantage of these advanced services.

Applying QoS Policies

Some network traffic, such as voice and streaming video, cannot tolerate long latency times. QoS is a network feature that lets you give priority to these types of traffic. QoS refers to the capability of a network to provide better service to selected network traffic.

Applying Connection Limits and TCP Normalization

You can limit TCP and UDP connections and embryonic connections. Limiting the number of connections and embryonic connections protects you from a DoS attack. The ASA uses the embryonic limit to trigger TCP Intercept, which protects inside systems from a DoS attack perpetrated by flooding an interface with

TCP SYN packets. An embryonic connection is a connection request that has not finished the necessary handshake between source and destination.

TCP normalization is a feature consisting of advanced TCP connection settings designed to drop packets that do not appear normal.

Enabling Threat Detection

You can configure scanning threat detection and basic threat detection, and also how to use statistics to analyze threats.

Basic threat detection detects activity that might be related to an attack, such as a DoS attack, and automatically sends a system log message.

A typical scanning attack consists of a host that tests the accessibility of every IP address in a subnet (by scanning through many hosts in the subnet or sweeping through many ports in a host or subnet). The scanning threat detection feature determines when a host is performing a scan. Unlike IPS scan detection that is based on traffic signatures, the ASA scanning threat detection feature maintains an extensive database that contains host statistics that can be analyzed for scanning activity.

The host database tracks suspicious activity such as connections with no return activity, access of closed service ports, vulnerable TCP behaviors such as non-random IPID, and many more behaviors.

You can configure the ASA to send system log messages about an attacker or you can automatically shun the host.

Firewall Mode Overview

The ASA runs in two different firewall modes:

- Routed
- Transparent

In routed mode, the ASA is considered to be a router hop in the network.

In transparent mode, the ASA acts like a "bump in the wire," or a "stealth firewall," and is not considered a router hop. The ASA connects to the same network on its inside and outside interfaces in a "bridge group".

You might use a transparent firewall to simplify your network configuration. Transparent mode is also useful if you want the firewall to be invisible to attackers. You can also use a transparent firewall for traffic that would otherwise be blocked in routed mode. For example, a transparent firewall can allow multicast streams using an EtherType access list.

Stateful Inspection Overview

All traffic that goes through the ASA is inspected using the Adaptive Security Algorithm and either allowed through or dropped. A simple packet filter can check for the correct source address, destination address, and ports, but it does not check that the packet sequence or flags are correct. A filter also checks *every* packet against the filter, which can be a slow process.



Note

The TCP state bypass feature allows you to customize the packet flow.

A stateful firewall like the ASA, however, takes into consideration the state of a packet:

• Is this a new connection?

If it is a new connection, the ASA has to check the packet against access lists and perform other tasks to determine if the packet is allowed or denied. To perform this check, the first packet of the session goes through the "session management path," and depending on the type of traffic, it might also pass through the "control plane path."

The session management path is responsible for the following tasks:

- Performing the access list checks
- Performing route lookups
- Allocating NAT translations (xlates)
- Establishing sessions in the "fast path"

The ASA creates forward and reverse flows in the fast path for TCP traffic; the ASA also creates connection state information for connectionless protocols like UDP, ICMP (when you enable ICMP inspection), so that they can also use the fast path.



Note

For other IP protocols, like SCTP, the ASA does not create reverse path flows. As a result, ICMP error packets that refer to these connections are dropped.

Some packets that require Layer 7 inspection (the packet payload must be inspected or altered) are passed on to the control plane path. Layer 7 inspection engines are required for protocols that have two or more channels: a data channel, which uses well-known port numbers, and a control channel, which uses different port numbers for each session. These protocols include FTP, H.323, and SNMP.

Is this an established connection?

If the connection is already established, the ASA does not need to re-check packets; most matching packets can go through the "fast" path in both directions. The fast path is responsible for the following tasks:

- IP checksum verification
- Session lookup
- TCP sequence number check
- NAT translations based on existing sessions
- Layer 3 and Layer 4 header adjustments

Data packets for protocols that require Layer 7 inspection can also go through the fast path.

Some established session packets must continue to go through the session management path or the control plane path. Packets that go through the session management path include HTTP packets that require inspection or content filtering. Packets that go through the control plane path include the control packets for protocols that require Layer 7 inspection.

VPN Functional Overview

A VPN is a secure connection across a TCP/IP network (such as the Internet) that appears as a private connection. This secure connection is called a tunnel. The ASA uses tunneling protocols to negotiate security parameters, create and manage tunnels, encapsulate packets, transmit or receive them through the tunnel, and unencapsulate them. The ASA functions as a bidirectional tunnel endpoint: it can receive plain packets, encapsulate them, and send them to the other end of the tunnel where they are unencapsulated and sent to their final destination. It can also receive encapsulated packets, unencapsulate them, and send them to their final destination. The ASA invokes various standard protocols to accomplish these functions.

The ASA performs the following functions:

- Establishes tunnels
- Negotiates tunnel parameters
- · Authenticates users
- Assigns user addresses
- Encrypts and decrypts data
- · Manages security keys
- · Manages data transfer across the tunnel
- Manages data transfer inbound and outbound as a tunnel endpoint or router

The ASA invokes various standard protocols to accomplish these functions.

Security Context Overview

You can partition a single ASA into multiple virtual devices, known as security contexts. Each context is an independent device, with its own security policy, interfaces, and administrators. Multiple contexts are similar to having multiple standalone devices. Many features are supported in multiple context mode, including routing tables, firewall features, IPS, and management; however, some features are not supported. See the feature chapters for more information.

In multiple context mode, the ASA includes a configuration for each context that identifies the security policy, interfaces, and almost all the options you can configure on a standalone device. The system administrator adds and manages contexts by configuring them in the system configuration, which, like a single mode configuration, is the startup configuration. The system configuration identifies basic settings for the ASA. The system configuration does not include any network interfaces or network settings for itself; rather, when the system needs to access network resources (such as downloading the contexts from the server), it uses one of the contexts that is designated as the admin context.

The admin context is just like any other context, except that when a user logs into the admin context, then that user has system administrator rights and can access the system and all other contexts.

ASA Clustering Overview

ASA Clustering lets you group multiple ASAs together as a single logical device. A cluster provides all the convenience of a single device (management, integration into a network) while achieving the increased throughput and redundancy of multiple devices.

You perform all configuration (aside from the bootstrap configuration) on the control unit only; the configuration is then replicated to the member units.

Special, Deprecated, and Legacy Services

For some services, documentation is located outside of the main configuration guides and online help.

Special Services Guides

Special services allow the ASA to interoperate with other Cisco products; for example, by providing a security proxy for phone services (Unified Communications), or by providing Botnet traffic filtering in conjunction with the dynamic database from the Cisco update server, or by providing WCCP services for the Cisco Web Security Appliance. Some of these special services are covered in separate guides:

- · Cisco ASA Botnet Traffic Filter Guide
- Cisco ASA NetFlow Implementation Guide
- Cisco ASA Unified Communications Guide
- Cisco ASA WCCP Traffic Redirection Guide
- SNMP Version 3 Tools Implementation Guide

Deprecated Services

For deprecated features, see the configuration guide for your ASA version. Similarly, for redesigned features such as NAT between Version 8.2 and 8.3 or transparent mode interfaces between Version 8.3 and 8.4, refer to the configuration guide for your version. Although ASDM is backwards compatible with previous ASA releases, the configuration guide and online help only cover the latest release.

Legacy Services Guide

Legacy services are still supported on the ASA, however there may be better alternative services that you can use instead. Legacy services are covered in a separate guide:

Cisco ASA Legacy Feature Guide

This guide includes the following chapters:

- Configuring RIP
- AAA Rules for Network Access
- Using Protection Tools, which includes Preventing IP Spoofing (**ip verify reverse-path**), Configuring the Fragment Size (**fragment**), Blocking Unwanted Connections (**shun**), Configuring TCP Options (for ASDM), and Configuring IP Audit for Basic IPS Support (**ip audit**).
- Configuring Filtering Services