



Contacts

Contacts are similar to users without mailboxes; however, they have a phone extension, but no voicemail or administrative rights on Cisco Unity Connection and frequently communicates with the users.

If a Voice Profile for Internet Mail (VPIM) user is configured as a contact, Unity Connection can record and forward voicemail to the contact via Simple Mail Transfer Protocol (SMTP).

See the following sections:

- [Types of Contacts, page 5-1](#)
- [Contact Templates, page 5-2](#)
- [Configuring Contacts, page 5-2](#)
- [Contact Settings, page 5-3](#)

Types of Contacts

Unity Connection supports the following types of contacts:

- **Administrator defined contacts:** Administrator defined contacts are the contacts are available to all users. These contacts can be configured for agents, staff vendors, or contractors that have an external phone number and need to be reachable from the voice messaging system.

Administrator-defined contacts can be configured for VPIM messaging. These contacts represent users on other VPIM-compatible voice messaging systems. When contacts have been set up to represent the VPIM users, Unity Connection users can send and receive messages to and from the VPIM users on the other voice messaging systems. For more information on VPIM network, see the “Creating VPIM Contacts” section of the “VPIM Networking in Cisco Unity Connection 10.x” chapter of the *Networking Guide for Cisco Unity Connection Release 10.x* at http://www.cisco.com/c/en/us/td/docs/voice_ip_comm/connection/10x/networking/guide/10xcucnet/10xcucnet035.html#pgfId-1073988.

- **User defined contacts:** User defined contacts are created by the individual users and are only accessible to the users who create them. You can create such contacts through Cisco Personal Communications Assistant. You can also add such contacts to their personal call routing rules, caller groups, and can also use voice commands to call other contacts.

For more information on how a user can maintain contacts, see the “Managing Your Contacts” chapter *User Guide for the Cisco Unity Connection Messaging Assistant Web Tool Release 10.x* at http://www.cisco.com/c/en/us/td/docs/voice_ip_comm/connection/10x/user/guide/assistant/b_10xcucugasst/b_10xcucugasst_chapter_01001.html.

Contact Templates

Contacts are based on contact templates. Contact Template settings apply to all newly created contacts and any change in the template thereafter is not reflected in any existing contact.

Unity Connection includes one predefined contact template that you can edit. You can also create new templates based on your requirements. If Unity Connection has more than one partition defined or is configured for VPIM networking, you may want to create a contact template for each partition or for each VPIM location.

Configuring Contact Templates

To Configure Contact Templates in Unity Connection

- Step 1** In Cisco Unity Connection Administration, expand **Templates** and select **Contact Templates**. The Search Contact Templates page appears displaying the currently configured contact templates.
- Step 2** Configure contact templates (For more information on each field, see **Help > This Page**):
- To add a contact template:
 - a. On the Search Contact Templates page, select **Add New**.
 - b. On the New Contact Template page, enter the values of the required fields and select **Save**.
 - c. On the Edit Contact Template Basics page, enter the values of the required fields and select **Save**.
 - To edit an existing contact template:
 - a. On the Search Contact Templates page, select the contact template that you want to edit.
 - b. On the Edit Contact Template Basics page, enter the values of the required fields and select **Save**.
 - To delete one or more contact templates:
 - a. On the Search Contact Templates page, check the check boxes to select the contact templates that you want to delete.
 - b. Select **Delete Selected** and **OK** to confirm deletion.
-

Configuring Contacts

You can configure contacts using either of the following methods:

- **Configuring Contacts Manually:** Allows to manually configure each contact through Search Contacts page. For information, see the [Configuring Contacts Manually, page 5-3](#).
- **Configuring Contacts through Bulk Administration Tool (BAT):** Allows you to configure multiple contacts using BAT at the same time. For information, see the [Configuring Contacts through Bulk Administration Tool \(BAT\), page 5-3](#).

Configuring Contacts Manually

To Configure Contacts Manually

- Step 1** In Cisco Unity Connection Administration, expand **Contacts** and select **Contacts**.
The Search Contacts page appears displaying the currently configured contacts.
- Step 2** Configure contacts in Unity Connection (For more information on each field, see **Help > This Page**):
- **To add a contact:**
 - a. On the Search Contacts page, select **Add New**.
 - b. On the New Contact page, enter the values of the required fields and select **Save**.
 - c. On the Edit Contact Basics page, enter the values of the required fields and select **Save**.
 - **To edit a contact:**
 - a. On the Search Contacts page, select the contact that you want to edit.
 - b. On the Edit Contacts Basics page, select **Edit** to edit the contact settings and select **Save**.
 - **To edit multiple contacts:**
 - a. On the Search Contacts page, check the check boxes for the contacts you want to edit and then select **Bulk Edit**.
 - b. On the Edit Contact Basics page, enter the values of the required fields and select **Submit**.

**Note**

You cannot edit the Alternate Names of multiple contacts using **Bulk Edit**.

- **To delete one or more contacts:**
 - a. On the Search Contacts page, select the contacts that you want to delete.
 - b. Select **Delete Selected** and **OK** to confirm deletion.

Configuring Contacts through Bulk Administration Tool (BAT)

BAT allows you to create Cisco Unity Connection contacts from a CSV file. For information on configuring contacts and constructing CSV file, see the [Bulk Administration Tool, page 19-2](#) section.

Contact Settings

Contact settings includes configuring the contacts with alternate names and providing SMTP proxy addresses. Using Alternate names, contacts can be recognized using voice recognition functionality and setting up SMTP proxy address enables the IMAP client users to communicate with Unity Connection contacts or VPIM contacts.

Alternate Names

Alternate names are different versions of a name than what is listed in the corporate directory. For example, if a caller asks Unity Connection to dial “Mary Jameson,” which was the maiden name of Mary Brown, Unity Connection can reference this information and connect the caller to the correct user.

Alternate names can be created for VPIM contacts, administrator defined contacts, and user defined contacts. You could also use alternate names to add phonetic spellings of hard to pronounce names. For example, you can add “Goolay” as an alternate name for the last name “Goulet.”

SMTP Proxy Addresses

Unity Connection uses SMTP proxy addresses to map the recipients of an incoming SMTP message sent from an IMAP client to the appropriate Unity Connection user or VPIM contact. If users use IMAP clients to send, reply to, or forward messages to VPIM contacts you should configure each VPIM contact with an SMTP address.



Note Unity Connection handles SMTP messages sent to the contacts that are not associated with a VPIM location according to the option selected for the **System Settings > General Configuration > When a Recipient Cannot Be Found** setting.

For example, when Robin Smith, whose email client is configured to access Unity Connection with the email address robin.smith@example.com, records a voice message in ViewMail for Outlook and sends it to chris.jones@example.com, Unity Connection searches the list of SMTP proxy addresses for robin.smith@example.com and chris.jones@example.com. If these addresses are defined as SMTP proxy addresses for the Unity Connection users Robin Smith and Chris Jones respectively, Unity Connection delivers the message as a voice message from Robin Smith to Chris Jones.



Note For more information on configuring Unity Connection so that users can use IMAP clients to send, forward, or reply to messages through the Unity Connection server, see the [Integrated Messaging, page 11-14](#) section.

To Configure SMTP Proxy Address for Contacts in Unity Connection

- Step 1** In Cisco Unity Connection Administration, expand **Contacts** and select **Contacts**.
The Search Contacts page appears displaying the currently configured contacts.
- Step 2** Configure SMTP proxy addresses for contacts (For more information on each field, see **Help > This Page**):
- To add SMTP proxy address for a contact:
 - a. On the Search Contact page, select the contact that you want to edit.
 - b. On the Edit Contact Basics page, select **Edit > SMTP Proxy Address**.
 - c. On the SMTP Proxy Addresses page, select **Add New**.
 - d. Enter the SMTP proxy address and select **Save**.
 - To add SMTP proxy addresses for multiple contacts:
 - a. On the Search Contact page, select the contacts that you want to edit and then select **Bulk Edit**.

- b. On the Edit Contact Basics page, select **Edit> SMTP Proxy Address**.
 - c. Enter the SMTP proxy addresses and select **Submit**.
-

