

Catalyst XL交換機和Catalyst第2層固定配置交換機之間的EtherChannel和802.1Q中繼配置示例

目錄

[簡介](#)
[開始之前](#)
[慣例](#)
[必要條件](#)
[採用元件](#)
[背景理論](#)
[設定](#)
[動態中繼通訊協定](#)
[連線埠彙總通訊協定](#)
[連結彙總控制通訊協定\(LACP\)](#)
[網路圖表](#)
[組態](#)
[驗證](#)
[Catalyst 2900XL/3500XL](#)
[Catalyst 2950/2955](#)
[疑難排解](#)
[相關資訊](#)

[簡介](#)

本檔案將提供在Catalyst 3524XL和Catalyst 2950交換器之間的IEEE 802.1Q中繼和EtherChannel上的組態範例。每個命令的結果在執行時顯示。任何Catalyst第2層固定組態交換器（包括2900XL/3500XL、2940、2950/2955和2970）都可以在本檔案所介紹的案例中使用，以取得相同的結果。

[開始之前](#)

[慣例](#)

如需文件慣例的詳細資訊，請參閱[思科技術提示慣例](#)。

[必要條件](#)

在本文檔中，每台交換機的四個快速乙太網埠已設定為802.1Q中繼並捆綁到快速EtherChannel(FEC)中。

採用元件

若要建立本檔案中的範例，我們已在實驗室環境中使用下列已清除組態交換器：

- 執行Cisco IOS®軟體版本12.0(5.2)XU的Catalyst 3524XL交換器
- 執行Cisco IOS軟體版本12.1(6)EA2a的Catalyst 2950交換器

背景理論

無需在這些交換機上使用連續埠來形成FEC。

使用執行Cisco IOS軟體版本11.2(8)SA1或11.2(8)SA2的Catalyst 2900XL，每台交換器允許四個FEC（連續埠群組），且每個群組的連續埠數不受限制。通道中鏈路間的負載均衡始終基於目標MAC地址。屬於同一portchannel的所有埠都必須以相同方式配置。它們需要承載相同的VLAN集，並且所有交換機都必須具有中繼或非中繼作為運行中繼狀態。不支援交換式連續埠分析器(SPAN)和連續埠安全功能。

在執行Cisco IOS軟體版本11.2(8)SA3或更新版本的Catalyst 2900XL、執行Cisco IOS軟體版本11.2(8)SA6或更新版本的Catalyst 3500XL和Catalyst 2950/2955上，通道中連結間的負載均衡可設定為基於來源或目的地MAC位址，且來源為預設值。基於源的轉發允許一個FEC（埠組）中最多八個埠。基於目標的轉發允許每個埠組有無限的埠。每台交換機最多可以配置12個FEC埠組，並且可以混合使用基於源/目標的組。屬於同一portchannel的所有埠都必須以相同方式配置。它們需要承載相同的VLAN集，並且所有交換機都必須具有中繼或非中繼作為運行中繼狀態。不支援SPAN和埠安全。

Catalyst 2940和2950/2955交換器僅支援802.1Q中繼，不支援交換器間連結通訊協定(ISL)中繼。Catalyst 2970支援802.1Q和ISL中繼協定。

設定

動態中繼通訊協定

有建立中繼的方法。如果埠可以成為中繼，它還可以自動中繼，在某些情況下，甚至可以協商要在埠上使用的中繼型別。這種與另一裝置協商中繼方法的能力稱為動態中繼協定(DTP)。

註：Catalyst 2900XL/3500XL交換機不支援DTP。Catalyst 2950/2955交換器使用Cisco IOS軟體版本12.1(6)EA2或更新版本支援動態中繼的DTP。Catalyst 2940和2970在所有Cisco IOS軟體版本中支援DTP。

連續埠彙總通訊協定

埠聚合協定(PAgP)有助於自動建立FECL鏈路。在支援FECL的埠之間傳送PAgP資料包以協商通道的形成。PAgP中特意引入了一些限制。限制如下：

- PAgP不會在針對動態VLAN配置的埠上形成捆綁包。PAgP要求通道中的所有埠屬於同一個VLAN或配置為中繼埠。如果套件組合已存在，且修改了連續埠的VLAN，則套件組合中的所有連續埠都會修改為與該VLAN相符。
- PAgP不對以不同速度或埠雙工運行的埠進行分組。如果存在捆綁包時更改了速度和雙工，PAgP將更改捆綁包中所有埠的速度和雙工。

- PAgP模式為off、auto、desirable和on。只有auto-desirable、desirable-desirable和on-on組合才允許形成通道。PAgP模式解釋如下。
· PAgP將不會運行。頻道被迫上。off: PAgP將不會運行。
· 通道被迫保持。PAgP被動運行。需要形成通道；但是，它不會啟動。desirable: PAgP正在積極運行。希望並啟動通道的形成。只有auto-desirable、desirable-desirable和on-on的組合才能形成通道。如果通道一端的裝置（例如路由器）不支援PAgP，則另一端的裝置必須將PAgP設定為on。

註：Catalyst 2900XL/3500XL交換機不支援PAgP。Catalyst 2950/2955交換器支援PagP，以便與Cisco IOS軟體版本12.1(6)EA2或更新版本進行通道交涉；Cisco IOS軟體版本12.0僅支援靜態配置。Catalyst 2940和2970在所有Cisco IOS軟體版本中支援PAgP。

連結集總控制通訊協定(LACP)

鏈路聚合控制協定(LACP)中繼支援四種操作模式：


- 強制形成鏈路聚合而不進行任何LACP協商。換句話說，交換機既不傳送LACP資料包，也不處理任何入站LACP資料包。這類似於PAgP的on狀態。
- Off: 未形成鏈路聚合。我們不傳送或理解LACP資料包。這類似於PAgP的off狀態。
- 被動: 交換器不會啟動通道，但會瞭解傳入LACP封包。對等體（處於活動狀態）發起協商（當它發出一個LACP資料包時），我們接收並應答該資料包，最終與對等體形成聚合通道。這類似於PAgP中的自動模式。
- 活動：我們可以形成聚合鏈路並啟動協商。如果另一端以LACP主動或被動模式運行，則會形成鏈路聚合。這類似於PAgP的desirable模式。

注意：預設情況下，配置LACP通道時，LACP通道模式為被動模式。

註：Catalyst 2900XL/3500XL交換機不支援LACP。Catalyst 2950/2955交換器支援LACP，以便與Cisco IOS軟體版本12.1(6)EA2或更新版本進行通道交涉。Cisco IOS軟體版本12.0僅支援靜態配置。在所有Cisco IOS軟體版本中，Catalyst 2940和2970都支援LACP。

網路圖表

本文檔使用下圖所示的網路設定。



組態

本文檔使用如下所示的配置。

Catalyst 3524 XL

```
Comments between the outputs are added in blue italics  
for explanation. Flush#show run  
Building configuration...  
Current configuration:  
!  
version 12.0  
no service pad  
service timestamps debug uptime  
service timestamps log uptime  
no service password-encryption  
!  
hostname Flush  
!  
!  
ip subnet-zero  
!  
!--- Since the 2900XL/3500XL switches do not support !---  
- dynamic channel negotiation, verify the !---  
configuration before enabling secondary links. !--- You  
may see a loop before the configuration is finished if  
!--- both ports are connected while doing changes. !---  
Shut down the ports involved in the channel first. When  
the !--- configuration is complete, enable them back. !-  
-- An example of a brief loop is shown below. !---  
flush# !--- 6d12h: %LINK-4-ERROR: FastEthernet0/1 is  
experiencing errors. !--- 6d12h: %RTD-1-ADDR_FLAP:  
FastEthernet0/3 relearning five addresses per minute. !-  
-- 6d12h: %LINK-4-ERROR: FastEthernet0/1 is experiencing  
errors. !--- 6d12h: %RTD-1-ADDR_FLAP: FastEthernet0/24  
relearning eight addresses per minute. !--- 6d12h:  
%LINK-4-ERROR: FastEthernet0/1 is experiencing errors. !  
! interface FastEthernet0/1 port group 1 !--- Assigned  
port to port channel 1. switchport trunk encapsulation  
dot1q !--- Configured the port to use the trunking  
encapsulation dot1Q. switchport mode trunk !---  
Configured port to be in trunking mode. ! interface  
FastEthernet0/2 port group 1 !--- Assigned port to port  
channel 1. switchport trunk encapsulation dot1q  
switchport mode trunk ! interface FastEthernet0/3 port  
group 1 !--- Assigned port to port channel 1. switchport  
trunk encapsulation dot1q switchport mode trunk !  
interface FastEthernet0/4 port group 1 !--- Assigned  
port to port channel 1. switchport trunk encapsulation  
dot1q switchport mode trunk .....(output Suppressed) !  
interface VLAN1 ip address 1.1.1.2 255.255.255.0 no ip  
directed-broadcast no ip route-cache ! line con 0  
transport input none stopbits 1 line vty 0 4 login line  
vty 5 15 login
```

Catalyst 2950

```
Comments between the outputs are added in blue italics  
for explanation. Hanka>en Hanka#show run  
Building configuration...  
Current configuration : 1298 bytes  
!  
version 12.1  
no service pad  
service timestamps debug uptime  
service timestamps log uptime  
no service password-encryption
```

```

!
hostname Hanka
!
!
ip subnet-zero
!
interface Port-channel1
flowcontrol send off
switchport mode trunk
!--- Since the 2900XL/3500XL series switches do not !---
support dynamic channel negotiation, !--- verify the
configuration before !--- enabling secondary links. !---
You may see a loop before the configuration is !---
finished if both ports are connected while doing
changes. !--- We suggest shutting down the ports
involved in the channel !--- first, and when the
configuration is complete, !--- enabling them back. !---
An example of a brief loop is shown below. !--- flush#
!--- 6d12h: %LINK-4-ERROR: FastEthernet0/1 is
experiencing errors. !--- 6d12h: %RTD-1-ADDR_FLAP:
FastEthernet0/3 relearning five addresses per minute. !-
-- 6d12h: %LINK-4-ERROR: FastEthernet0/1 is experiencing
errors. !--- 6d12h: %RTD-1-ADDR_FLAP: FastEthernet0/24
relearning eight addresses per minute. !--- 6d12h:
%LINK-4-ERROR: FastEthernet0/1 is experiencing errors. !
interface FastEthernet0/1 switchport mode trunk !---
Configured port to be in trunking mode. channel-group 1
mode on !--- Assigned port to port channel 1. !---
Catalyst 2950/2955 switches only support 802.1Q
encapsulation, !--- which is configured automatically !-
-- when trunking is enabled on the interface by !---
issuing the switchport mode trunk command. !--- Note:
The channel-group command is introduced in !--- Cisco
IOS Software Release 12.1. Cisco IOS Software Release
12.0 has !--- the port group command to configure
channeling.

```

```

!
interface FastEthernet0/2
switchport mode trunk
channel-group 1 mode on
!--- Assigned port to port channel 1. ! interface
FastEthernet0/3 switchport mode trunk channel-group 1
mode on !--- Assigned port to port channel 1. !
interface FastEthernet0/4 switchport mode trunk channel-
group 1 mode on !--- Assigned port to port channel 1.
.....(output Suppressed) interface Vlan1 ip address
1.1.1.1 255.255.255.0 no ip route-cache ! ip http server
! line con 0 transport input none line vty 0 4 login
line vty 5 15 login ! end

```

驗證

本節提供的資訊可用於確認您的組態是否正常運作。

Catalyst 2900XL/3500XL

```
show CDP neighbor
```

```
Flush#show cdp neighbor
```

```
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge  
S - Switch, H - Host, I - IGMP, r - Repeater
```

Device ID	Local Intrfce	Holdtme	Capability	Platform	Port ID
Hanka	Fas 0/4	173	S I	WS-C2950T-Fas	0/4
Hanka	Fas 0/3	173	S I	WS-C2950T-Fas	0/3
Hanka	Fas 0/2	173	S I	WS-C2950T-Fas	0/2
Hanka	Fas 0/1	173	S I	WS-C2950T-Fas	0/1

```
Flush#
```

```
show port group
```

```
Flush>en
```

```
Flush#show port group
```

Group	Interface	Transmit Distribution
1	FastEthernet0/1	source address
1	FastEthernet0/2	source address
1	FastEthernet0/3	source address
1	FastEthernet0/4	source address

```
show spanning-tree
```

```
Flush#show spanning-tree
```

```
Spanning tree 1 is executing the IEEE compatible Spanning Tree protocol  
Bridge Identifier has priority 32768, address 0001.4264.82c0  
Configured hello time 2, max age 20, forward delay 15  
We are the root of the spanning tree  
Topology change flag not set, detected flag not set, changes 2  
Times: hold 1, topology change 35, notification 2  
hello 2, max age 20, forward delay 15  
Timers: hello 0, topology change 0, notification 0
```

```
Interface Fa0/1 (port 1) in Spanning tree 1 is FORWARDING
```

```
Port path cost 8, Port priority 128  
Designated root has priority 32768, address 0001.4264.82c0  
Designated bridge has priority 32768, address 0001.4264.82c0  
Designated port is 1, path cost 0  
Timers: message age 0, forward delay 0, hold 0  
BPDU: sent 41527, received 231
```

```
Interface Fa0/5 (port 17) in Spanning tree 1 is down
```

```
Port path cost 100, Port priority 128
```

註：介面Fa0/2 — 輸出中不顯示介面Fa0/4，因為它們與埠通道中的Fa0/1捆綁在一起。

```
show interface x/x switchport
```

```
Flush#show interface fast 0/1 switchport
```

```
Name: Fa0/1  
Switchport: Enabled  
Administrative mode: trunk  
Operational Mode: trunk  
Administrative Trunking Encapsulation: dot1q  
Operational Trunking Encapsulation: dot1q
```

```

Negotiation of Trunking: Disabled
Access Mode VLAN: 0 ((Inactive))
Trunking Native Mode VLAN: 1 (default)
Trunking VLANs Enabled: ALL
Trunking VLANs Active: 1,2
Pruning VLANs Enabled: 2-1001

Priority for untagged frames: 0
Override vlan tag priority: FALSE
Voice VLAN: none
Appliance trust: none

Flush#show interface fast 0/2 switchport
Name: Fa0/2
Switchport: Enabled
Administrative mode: trunk
Operational Mode: trunk
Administrative Trunking Encapsulation: dot1q
Operational Trunking Encapsulation: dot1q
Negotiation of Trunking: Disabled
Access Mode VLAN: 0 ((Inactive))
Trunking Native Mode VLAN: 1 (default)
Trunking VLANs Enabled: ALL
Trunking VLANs Active: 1,2
Pruning VLANs Enabled: 2-1001

Priority for untagged frames: 0
Override vlan tag priority: FALSE
Voice VLAN: none
Appliance trust: none
Flush#

```

[Catalyst 2950/2955](#)

show CDP neighbor

```

Hanka#show cdp neighbor
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

```

Device ID	Local Intrfce	Holdtme	Capability	Platform	Port ID
Flush	Fas 0/4	127	T S	WS-C3524-XFas	0/4
Flush	Fas 0/3	127	T S	WS-C3524-XFas	0/3
Flush	Fas 0/2	127	T S	WS-C3524-XFas	0/2
Flush	Fas 0/1	127	T S	WS-C3524-XFas	0/1

Hanka#

show etherchannel

注意：此命令最初是在Cisco IOS軟體版本12.1(6)EA2中引入的。它取代了show port group命令。

```

Hanka#show etherchannel port-channel
      Channel-group listing:
      -----
Group: 1
-----
      Port-channels in the group:

```

```
-----  
Port-channel: Po1  
-----  
Age of the Port-channel = 00d:23h:06m:07s  
Logical slot/port = 1/0 Number of ports = 4  
GC = 0x00010001 HotStandBy port = null  
Port state = Port-channel Ag-Inuse
```

```
Ports in the Port-channel:  
Index Load Port EC state  
-----+-----+-----  
0 00 Fa0/1 on  
0 00 Fa0/2 on  
0 00 Fa0/3 on  
0 00 Fa0/4 on
```

```
Time since last port bundled: 00d:23h:05m:46s Fa0/4
```

```
show spanning-tree
```

```
Hanka#show spanning-tree  
Port 65 (Port-channel1) of VLAN1 is forwarding  
Port path cost 8, Port priority 128, Port Identifier 128.65.  
Designated root has priority 32768, address 0001.4264.82c0  
Designated bridge has priority 32768, address 0001.4264.82c0  
Designated port id is 128.1, designated path cost 0  
Timers: message age 2, forward delay 0, hold 0  
Number of transitions to forwarding state: 1  
BPDU: sent 5, received 41627
```

```
show interfaces trunk
```

註：此命令最初是在Cisco IOS軟體版本12.1(6)EA2中引入的。

```
Hanka#show interfaces trunk  
  
Port Mode Encapsulation Status Native vlan  
Po1 on 802.1Q trunking 1  
  
Port Vlans allowed on trunk  
Po1 1-1005  
  
Port Vlans allowed and active in management domain  
Po1 1-2,999  
  
Port Vlans in spanning tree forwarding state and not pruned  
Po1 1-2,999  
Hanka#
```

疑難排解

目前尚無適用於此組態的具體疑難排解資訊。

相關資訊

- [在Catalyst 2950/2955交換器上設定交換器介面](#)

- [在2940交換機上配置交換機介面](#)
- [在2970交換機上配置交換機介面](#)
- [配置EtherChannel](#)
- [在Catalyst 2900XL和3500XL交換機上配置VTP、VLAN和VLAN中繼](#)
- [建立EtherChannel埠組](#)
- [技術支援 - Cisco Systems](#)