



## **IP Addresses and Services Command Reference for Cisco 8000 Series Routers**

**First Published:** 2020-03-01

**Last Modified:** 2024-09-04

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at [www.cisco.com/go/offices](http://www.cisco.com/go/offices).

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: <https://www.cisco.com/c/en/us/about/legal/trademarks.html>. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2020–2023 Cisco Systems, Inc. All rights reserved.



## CONTENTS

---

### PREFACE

#### **Preface** xiii

Changes to This Document xiii

Communications, Services, and Additional Information xiii

---

### CHAPTER 1

#### **Access List Commands** 1

clear access-list ipv4 3

clear access-list ipv6 5

copy access-list ipv4 7

copy access-list ipv6 9

deny (IPv4) 11

deny (IPv6) 19

dont-fragment 24

first-fragment 26

fragment-offset 27

fragment-type 28

hw-module profile stats acl-permit 30

ipv4 access-group 32

ipv4 access-list 34

ipv4 access-list log-update rate 35

ipv4 access-list log-update threshold 36

ipv6 access-group 37

ipv6 access-list 39

ipv6 access-list log-update rate 42

ipv6 access-list log-update threshold 43

is-fragment 44

last-fragment 45

object-group network	46
object-group port	47
packet-length	48
permit (IPv4)	50
permit (IPv6)	63
show access-lists ipv4	71
show access-lists ipv6	74
show tech-support access-lists	78
tcam format access-list (ipv4 and ipv6)	80

---

**CHAPTER 2****ARP Commands 83**

arp	84
arp cache-limit	86
arp dagr	87
arp gratuitous ignore	88
arp learning	89
arp police-interval	90
arp purge-delay	91
arp timeout	92
clear arp-cache	93
local-proxy-arp	95
peer (DAGR)	96
priority-timeout	97
proxy-arp	98
route distance	99
route metric	100
show arp	101
show arp idb	105
show arp dagr	107
show arp traffic	108
timers (DAGR)	111

---

**CHAPTER 3****DHCP Commands 113**

clear dhcp ipv6 relay binding	114
-------------------------------	-----

client-mac-mismatch	116
dhcp ipv4	117
dhcp ipv6	118
giaddr policy	119
helper-address	121
helper-address (ipv6)	123
hop-count-seed	125
iana-route-add	126
profile (DHCP)	127
relay information	129
show dhcp ipv4 relay	131
show dhcp ipv6 relay binding	133
show dhcp ipv6 relay statistics	135
vrf (relay profile)	137

---

**CHAPTER 4**
**Cisco Express Forwarding Commands 139**

cef adjacency route override rib	141
cef load-balancing	143
clear adjacency statistics	146
clear cef ipv4 drops	148
clear cef ipv4 exceptions	150
clear cef ipv6 drops	152
clear cef ipv6 exceptions	154
hw-module profile cef	156
hw-module profile route scale	157
show adjacency	159
show cef bgp-attribute	162
show cef	164
show cef exact-route (user-data)	167
show cef ext-client	169
show cef ipv4 adjacency	172
show cef ipv4 adjacency hardware	175
show cef ipv4	178
show cef ipv4 drops	180

show cef ipv4 exact-route	182
show cef ipv4 exceptions	185
show cef ipv4 hardware	187
show cef ipv4 interface	193
show cef ipv4 non-recursive	195
show cef ipv4 resource	198
show cef ipv4 summary	200
show cef ipv4 unresolved	202
show cef ipv6 adjacency	204
show cef ipv6 adjacency hardware	206
show cef ipv6	212
show cef ipv6 drops	215
show cef ipv6 exact-route	217
show cef ipv6 exceptions	220
show cef ipv6 hardware	221
show cef ipv6 interface	223
show cef ipv6 non-recursive	225
show cef ipv6 resource	227
show cef ipv6 summary	228
show cef ipv6 unresolved	230
show cef mpls adjacency	232
show cef mpls adjacency hardware	234
show cef mpls drops	236
show cef mpls interface	237
show cef mpls unresolved	239
show cef recursive-nextthop	240
show cef summary	241
show cef vrf	243
show hw-module profile cef	245

---

**CHAPTER 5****Host Services and Applications Commands 247**

cinetd rate-limit	249
clear host	250
domain ipv4 host	251

domain ipv6 host	252
domain list	253
domain lookup disable	254
domain name (IPAddr)	255
domain name-server	256
ftp client anonymous-password	257
ftp client passive	258
ftp client password	259
ftp client source-interface	260
ftp client username	261
http client connection	262
http client response	263
http client secure-verify-host	264
http client secure-verify-peer	265
http client source-interface	266
http client ssl	267
http client tcp-window-scale	268
http client version	269
http client vrf	270
logging source-interface vrf	271
ping bulk (network)	272
ping (network)	274
scp	277
show cinetd services	279
show hosts	281
telnet	283
telnet client source-interface	286
telnet dscp	287
telnet server	289
telnet transparent	291
tftp server	292
tftp client source-interface	293
traceroute	294

---

**CHAPTER 6****LPTS Commands 297**

- clear lpts ifib statistics 298
- clear lpts pifib statistics 299
- flow (LPTS) 300
- lpts pifib hardware dynamic-flows 303
- lpts pifib hardware police 305
- show lpts bindings 307
- show lpts clients 311
- show lpts flows 313
- show lpts ifib 316
- show lpts ifib slices 319
- show lpts ifib statistics 322
- show lpts ifib times 324
- show lpts pifib 326
- show lpts pifib hardware entry 331
- show lpts pifib hardware object-group entry 334
- show lpts pifib hardware police 339
- show lpts pifib statistics 343
- show lpts port-arbitrator statistics 344
- show lpts vrf 345

---

**CHAPTER 7****Network Stack Commands 347**

- clear ipv6 neighbors 349
- clear ipv6 path-mtu 351
- hw-module profile route scale ipv6-unicast connected-prefix high 352
- hw-module local-station-mac 353
- icmp ipv4 rate-limit unreachable 354
- ipv4 address (network) 355
- ipv4 assembler max-packets 357
- ipv4 assembler timeout 358
- ipv4 conflict-policy 359
- ipv4 directed-broadcast 360
- ipv4 helper-address 361



ipv4 mask-reply	363
ipv4 mtu	364
ipv4 redirects	366
ipv4 source-route	367
ipv4 tcp-mss-adjust	368
ipv4 unnumbered (point-to-point)	370
ipv4 unreachable disable	372
ipv4 virtual address	373
ipv6 address	375
ipv6 address link-local	377
ipv6 assembler	379
ipv6 conflict-policy	380
ipv6 enable	381
ipv6 hop-limit	382
ipv6 icmp error-interval	383
ipv6 mtu	385
ipv6 nd dad attempts	387
ipv6 nd managed-config-flag	390
ipv6 nd ns-interval	392
ipv6 nd other-config-flag	394
ipv6 nd prefix	396
ipv6 nd ra dns server	398
ipv6 nd ra dns search list	400
ipv6 nd ra-interval	402
ipv6 nd ra-lifetime	404
ipv6 nd ra specific route	405
ipv6 nd reachable-time	407
ipv6 nd redirects	409
ipv6 nd router-preference	410
ipv6 nd scavenge-timeout	412
ipv6 nd suppress-ra	413
ipv6 neighbor	414
ipv6 path-mtu enable	416
ipv6 path-mtu timeout	417

ipv6 source-route	418
ipv6 tcp-mss-adjust	419
ipv6 unreachable disable	420
ipv6 virtual address	421
local pool	423
show arm conflicts	426
show arm registrations producers	428
show arm database	430
show arm router-ids	433
show arm summary	434
show arm vrf-summary	436
show clns statistics	437
show hw-module local-station-mac	439
show ipv4 interface	440
show ipv4 traffic	443
show ipv6 interface	445
show ipv6 neighbors	450
show ipv6 neighbors summary	454
show ipv6 path-mtu	455
show ipv6 traffic	456
show linux networking interfaces address-only	459
show local pool	460
show mpa client	462
show mpa groups	463
show mpa ipv4	465
show mpa ipv6	467
show hw-module profile route-scale	469

**CHAPTER 8****Transport Stack Commands 471**

clear nsr ncd client	473
clear nsr ncd queue	475
clear nsr npl	477
clear raw statistics pcb	481
clear tcp nsr client	483

clear tcp nsr pcb	484
clear tcp nsr session-set	486
clear tcp nsr statistics client	487
clear tcp nsr statistics pcb	489
clear tcp nsr statistics session-set	491
clear tcp nsr statistics summary	493
clear tcp pcb	495
clear tcp statistics	498
clear udp statistics	500
forward-protocol udp	502
nsr process-failures switchover	504
service tcp-small-servers	505
service udp-small-servers	506
show nsr ncd client	507
show nsr ncd queue	509
show raw brief	511
show raw detail pcb	513
show raw extended-filters	515
show raw statistics	517
show tcp brief	519
show tcp detail	521
show tcp dump-file	522
show tcp extended-filters	523
show tcp nsr brief	525
show tcp nsr client brief	527
show tcp nsr detail client	528
show tcp nsr detail endpoint	530
show tcp nsr detail pcb	531
show tcp nsr detail session-set	534
show tcp nsr session-set brief	536
show tcp nsr statistics client	538
show tcp nsr statistics npl	540
show tcp nsr statistics pcb	542
show tcp nsr statistics session-set	544

show tcp nsr statistics summary	546
show tcp packet-trace	549
show tcp pak-rate	551
show tcp statistics	553
show udp brief	555
show udp detail pcb	557
show udp extended-filters	559
show udp statistics	560
tcp dump-file convert	562
tcp mss	564
tcp path-mtu-discovery	565
tcp selective-ack	566
tcp synwait-time	567
tcp timestamp	568
tcp window-size	569

---

**CHAPTER 9**

<b>VRRP Commands</b>	<b>571</b>
clear vrrp statistics	572
show vrrp	573
show vrrp statistics	579
unicast-peer	581



## Preface

This preface contains these sections:

- [Changes to This Document, on page xiii](#)
- [Communications, Services, and Additional Information, on page xiii](#)

## Changes to This Document

This table lists the technical changes made to this document since it was first released.

**Table 1: Changes to This Document**

Date	Summary
September 2024	Republished for Cisco IOS XR Release 24.3.1.
March 2024	Republished for Cisco IOS XR Release 24.1.1.
August 2023	Republished for Cisco IOS XR Release 7.10.1.
May 2021	Republished for Cisco IOS XR Release 7.3.15.
February 2021	Republished for Cisco IOS XR Release 7.3.1.
October 2020	Republished for Cisco IOS XR Release 7.2.12.
March 2020	Initial release of this document.

## Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at [Cisco Profile Manager](#).
- To get the business impact you're looking for with the technologies that matter, visit [Cisco Services](#).
- To submit a service request, visit [Cisco Support](#).
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit [Cisco DevNet](#).

- To obtain general networking, training, and certification titles, visit [Cisco Press](#).
- To find warranty information for a specific product or product family, access [Cisco Warranty Finder](#).

### **Cisco Bug Search Tool**

[Cisco Bug Search Tool](#) (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.



## Access List Commands

---

This module describes the Cisco IOS XR software commands used to configure IP Version 4 (IPv4) and IP Version 6 (IPv6) access lists.

For detailed information about ACL concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [clear access-list ipv4](#), on page 3
- [clear access-list ipv6](#), on page 5
- [copy access-list ipv4](#) , on page 7
- [copy access-list ipv6](#), on page 9
- [deny \(IPv4\)](#) , on page 11
- [deny \(IPv6\)](#) , on page 19
- [dont-fragment](#), on page 24
- [first-fragment](#), on page 26
- [fragment-offset](#), on page 27
- [fragment-type](#), on page 28
- [hw-module profile stats acl-permit](#), on page 30
- [ipv4 access-group](#), on page 32
- [ipv4 access-list](#), on page 34
- [ipv4 access-list log-update rate](#) , on page 35
- [ipv4 access-list log-update threshold](#) , on page 36
- [ipv6 access-group](#), on page 37
- [ipv6 access-list](#), on page 39
- [ipv6 access-list log-update rate](#), on page 42
- [ipv6 access-list log-update threshold](#) , on page 43
- [is-fragment](#), on page 44
- [last-fragment](#), on page 45
- [object-group network](#), on page 46
- [object-group port](#), on page 47
- [packet-length](#), on page 48
- [permit \(IPv4\)](#) , on page 50
- [permit \(IPv6\)](#) , on page 63
- [show access-lists ipv4](#) , on page 71
- [show access-lists ipv6](#), on page 74
- [show tech-support access-lists](#), on page 78

- [tcam format access-list \(ipv4 and ipv6\)](#), on page 80



## clear access-list ipv4

To clear IPv4 access list counters, use the **clear access-list ipv4** command in XR EXEC mode.

```
clear access-list ipv4 access-list-name hardware {clear access-list ipv4 access-list-name hardware
{ingress | egress } [ interface interface-path-id ] [ sequence sequence-number ] [ location
node-id ] }
```

### Syntax Description

<i>access-list-name</i>	Name of a particular IPv4 access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<i>sequence-number</i>	(Optional) Specific sequence number with which counters are cleared for an access list. Range is 1 to 2147483644.
<b>ingress</b>	Specifies an inbound direction.
<b>egress</b>	Specifies an outbound direction.
<i>interface-path-id</i>	Physical interface or virtual interface.
<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
	For more information about the syntax for the router, use the question mark (?) online help function.
<b>location</b> <i>node-id</i>	(Optional) Clears hardware resource counters from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

### Command Default

The default clears the specified IPv4 access list.

### Command Modes

XR EXEC mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

Use the **clear access-list ipv4** command to clear counters for a specified configured access list. Use a sequence number to clear counters for an access list with a specific sequence number.

Use an asterisk (\*) in place of the *access-list-name* argument to clear all access lists.

### Task ID

Task ID	Operations
basic-services	read, write
acl	read, write
bgp	read, write, execute

---

**Examples**

In the following example, counters for an access list named *marketing* are cleared:

```
Router# show access-lists ipv4 marketing hardware ingress location 0/RP0/CPU0
ipv4 access-list marketing
10 permit ipv4 192.168.34.0 0.0.0.255 any
20 permit ipv4 172.16.0.0 0.0.255.255 any
30 deny tcp host 172.16.0.0 eq 2330 host 192.168.202.203 (23345 matches)

Router# clear access-list ipv4 marketing hardware ingress location 0/RP0/CPU0
```

# clear access-list ipv6

To clear IPv6 access list counters, use the **clear access-list ipv6** command in .

```
clear access-list ipv4 access-list-name hardware {ingress | egress } [ interface interface-path-id ] [ sequence sequence-number ] [ location node-id]
```

## Syntax Description

<i>access-list-name</i>	Name of a particular IPv6 access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<i>sequence-number</i>	(Optional) Specific sequence number for a particular access control entry (ACE) with which counters are cleared for an access list. Range is 1 to 2147483644.
<b>ingress</b>	(Optional) Specifies an inbound direction.
<b>egress</b>	(Optional) Specifies an outbound direction.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>location</b> <i>node-id</i>	(Optional) Clears counters for an access list enabled on a card interface. The <i>node-id</i> argument is entered in the rack/slot/module notation.

## Command Default

The default clears the specified IPv6 access list.

## Command Modes

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

The **clear access-list ipv6** command is similar to the **clear access-list ipv4** command, except that it is IPv6-specific.

Use the **clear access-list ipv6** command to clear counters for a specified configured access list. Use a sequence number to clear counters for an access list with a specific sequence number

Use an asterisk (\*) in place of the *access-list-name* argument to clear all access lists.

## Task ID

Task ID	Operations
basic-services	read, write
acl	read, write

Task ID	Operations
network	read, write

## Examples

In the following example, counters for an access list named *marketing* are cleared:

```
Router# show access-lists ipv6 marketing hardware ingress location 0/RP0/CPU0
ipv6 access-list marketing
 10 permit ipv6 3333:1:2:3::/64 any
 20 permit ipv6 4444:1:2:3::/64 any
 30 permit ipv6 5555:1:2:3::/64 any
Router# clear access-list ipv6 marketing hardware ingress location 0/RP0/CPU0
```

# copy access-list ipv4

To create a copy of an existing IPv4 access list, use the **copy access-list ipv4** command in XR EXEC mode.

```
copy access-list ipv4 source-acl destination-acl
```

<b>Syntax Description</b>	<i>source-acl</i> Name of the access list to be copied.
	<i>destination-acl</i> Name of the destination access list where the contents of the <i>source-acl</i> argument is copied.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b> <b>Modification</b>
	Release 7.0.12      This command was introduced.

**Usage Guidelines** Use the **copy access-list ipv4** command to copy a configured access list. Use the *source-acl* argument to specify the access list to be copied and the *destination-acl* argument to specify where to copy the contents of the source access list. The *destination-acl* argument must be a unique name; if the *destination-acl* argument name exists for an access list or prefix list, the access list is not copied. The **copy access-list ipv4** command checks that the source access list exists then checks the existing list names to prevent overwriting existing access lists or prefix lists.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read, write
	filesystem	execute

## Examples

In the following example, a copy of access list list-1 is created:

```
Router# show access-lists ipv4 list-1

ipv4 access-list list-1
 10 permit tcp any any log
 20 permit ip any any
Router# copy access-list ipv4 list-1 list-2
Router# show access-lists ipv4 list-2
ipv4 access-list list-2
 10 permit tcp any any log
 20 permit ip any any
```

In the following example, copying the access list list-1 to list-3 is denied because a list-3 access list already exists:

```
Router# copy access-list ipv4 list-1 list-3
```

```
list-3 exists in access-list
```

```
Router# show access-lists ipv4 list-3
```

```
ipv4 access-list list-3  
 10 permit ip any any  
 20 deny tcp any any log
```

# copy access-list ipv6

To create a copy of an existing IPv6 access list, use the **copy access-list ipv6** command in .

```
copy access-list ipv6 source-acl destination-acl
```

<b>Syntax Description</b>	<i>source-acl</i>	Name of the access list to be copied.
	<i>destination-acl</i>	Destination access list where the contents of the <i>source-acl</i> argument is copied.

**Command Default** No default behavior or value

## Command Modes

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

## Usage Guidelines

Use the **copy access-list ipv6** command to copy a configured access list. Use the *source-acl* argument to specify the access list to be copied and the *destination-acl* argument to specify where to copy the contents of the source access list. The *destination-acl* argument must be a unique name; if the *destination-acl* argument name exists for an access list or prefix list, the access list is not copied. The **copy access-list ipv6** command checks that the source access list exists then checks the existing list names to prevent overwriting existing access lists or prefix lists.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read, write
	filesystem	execute

## Examples

In this example, a copy of access list list-1 is created:

```
Router# show access-lists ipv6 list-1

ipv6 access-list list-1
 10 permit tcp any any log
 20 permit ipv6 any any

Router# copy access-list ipv6 list-1 list-2

Router# show access-lists ipv6 list-2

ipv6 access-list list-2
 10 permit tcp any any log
 20 permit ipv6 any any
```

In this example, copying access list list-1 to list-3 is denied because a list-3 access list already exists:

```
Router# copy access-list ipv6 list-1 list-3
```

```
list-3 exists in access-list
```

```
Router# show access-lists ipv6 list-3
```

```
ipv6 access-list list-3
 10 permit ipv6 any any
 20 deny tcp any any log
```



## deny (IPv4)

To set conditions for an IPv4 access list, use the **deny** command in access list configuration mode. There are two versions of the **deny** command: **deny** (source), **deny** (destination), and **deny** (protocol). To remove a condition from an access list, use the **no** form of this command.

```
[ sequence-number ] deny source [ source-wildcard ] [ log | log-input ]
[ sequence-number ] deny protocol source source-wildcard destination destination-wildcard [ precedence
precedence ] [ dscp dscp [ bitmask value ] ] [ fragments ] [ packet-length operator packet-length
value ] [ log | log-input ]
no sequence-number
```

### Internet Control Message Protocol (ICMP)

```
[ sequence-number ] deny icmp source source-wildcard destination destination-wildcard [ icmp-type ]
[ icmp-code ] [ precedence precedence ] [ dscp dscp ] [ fragments ] [ log ][ icmp-off ]
```

### Transmission Control Protocol (TCP)

```
[ sequence-number ] permit tcp { source-ipv4-prefix/ prefix-length | any | host source-ipv4-address
ipv4-wildcard-mask/prefix-length } [ operator { port | protocol-port } ] { destination-ipv4-prefix/
prefix-length | any | host destination-ipv4-address ipv4-wildcard-mask/prefix-length } [ operator { port |
protocol/port } ] [ dscp value ] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments
] [ established ] { match-any | match-all | + | - } [ flag-name ] [ log ]
```

### Internet Group Management Protocol (IGMP)

```
[ sequence-number ] deny igmp source source-wildcard destination destination-wildcard [ igmp-type ]
[ precedence precedence ] [ dscp value ] [ fragments ] [ log ]
```

### User Datagram Protocol (UDP)

```
[ sequence-number ] deny udp source source-wildcard [ operator { portprotocol-port } ] destination
destination-wildcard [ operator { portprotocol-port } ] [ precedence precedence ] [ dscp dscp ] [ fragments ]
[ log ]
```

### Syntax Description

<i>sequence-number</i>	(Optional) Number of the <b>deny</b> statement in the access list. This number determines the order of the statements in the access list. The number can be from 1 to 2147483644. (By default, the first statement is number 10, and the subsequent statements are incremented by 10.)
<i>source</i>	Number of the network or host from which the packet is being sent. There are three alternative ways to specify the source: <ul style="list-style-type: none"> <li>Use a 32-bit quantity in four-part dotted-decimal format.</li> <li>Use the <b>any</b> keyword as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of 0.0.0.0 255.255.255.255.</li> <li>Use the <b>host source</b> combination as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of <i>source</i> 0.0.0.0.</li> </ul>

<i>source-wildcard</i>	<p>Wildcard bits to be applied to the source. There are three alternative ways to specify the source wildcard:</p> <ul style="list-style-type: none"> <li>• Use a 32-bit quantity in four-part dotted-decimal format. Place ones in the bit positions you want to ignore.</li> <li>• Use the <b>any</b> keyword as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of 0.0.0.0 255.255.255.255.</li> <li>• Use the <b>host source</b> combination as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of <i>source</i> 0.0.0.0.</li> </ul>
<i>protocol</i>	<p>Name or number of an IP protocol. It can be one of the keywords <b>ahp</b>, <b>esp</b>, <b>gre</b>, <b>icmp</b>, <b>igmp</b>, <b>igrp</b>, <b>ip</b>, <b>ipinip</b>, <b>nos</b>, <b>ospf</b>, <b>pim</b>, <b>pcp</b>, <b>tcp</b>, or <b>udp</b>, or an integer from 0 to 255 representing an IP protocol number. To match any Internet protocol (including ICMP, TCP, and UDP), use the <b>ip</b> keyword. ICMP, and TCP allow further qualifiers, which are described later in this table.</p> <p><b>Note</b> Filtering on AHP protocol is not supported.</p>
<i>destination</i>	<p>Number of the network or host to which the packet is being sent. There are three alternative ways to specify the destination:</p> <ul style="list-style-type: none"> <li>• Use a 32-bit quantity in four-part dotted-decimal format.</li> <li>• Use the <b>any</b> keyword as an abbreviation for the <i>destination</i> and <i>destination-wildcard</i> of 0.0.0.0 255.255.255.255.</li> <li>• Use the <b>host destination</b> combination as an abbreviation for a <i>destination</i> and <i>destination-wildcard</i> of <i>destination</i> 0.0.0.0.</li> </ul>
<i>destination-wildcard</i>	<p>Wildcard bits to be applied to the destination. There are three alternative ways to specify the destination wildcard:</p> <ul style="list-style-type: none"> <li>• Use a 32-bit quantity in four-part dotted-decimal format. Place ones in the bit positions you want to ignore.</li> <li>• Use the <b>any</b> keyword as an abbreviation for a <i>destination</i> and <i>destination-wildcard</i> of 0.0.0.0 255.255.255.255.</li> <li>• Use the <b>host destination</b> combination as an abbreviation for a <i>destination</i> and <i>destination-wildcard</i> of <i>destination</i> 0.0.0.0.</li> </ul>
<b>precedence</b> <i>precedence</i>	<p>(Optional) Packets can be filtered by precedence level (as specified by a number from 0 to 7) or by the following names:</p> <ul style="list-style-type: none"> <li>• <b>routine</b> —Match packets with routine precedence (0)</li> <li>• <b>priority</b> —Match packets with priority precedence (1)</li> <li>• <b>immediate</b> —Match packets with immediate precedence (2)</li> <li>• <b>flash</b> —Match packets with flash precedence (3)</li> <li>• <b>flash-override</b> —Match packets with flash override precedence (4)</li> <li>• <b>critical</b> —Match packets with critical precedence (5)</li> <li>• <b>internet</b> —Match packets with internetwork control precedence (6)</li> <li>• <b>network</b> —Match packets with network control precedence (7)</li> </ul>

<b>dscp</b> <i>dscp</i>	<p>(Optional) Differentiated services code point (DSCP) provides quality of service control. The values for <i>dscp</i> are as follows:</p> <ul style="list-style-type: none"> <li>• <b>0–63</b>—Differentiated services codepoint value</li> <li>• <b>af11</b>—Match packets with AF11 dscp (001010)</li> <li>• <b>af12</b>—Match packets with AF12 dscp (001100)</li> <li>• <b>af13</b>—Match packets with AF13 dscp (001110)</li> <li>• <b>af21</b>—Match packets with AF21 dscp (010010)</li> <li>• <b>af22</b>—Match packets with AF22 dscp (010100)</li> <li>• <b>af23</b>—Match packets with AF23 dscp (010110)</li> <li>• <b>af31</b>—Match packets with AF31 dscp (011010)</li> <li>• <b>af32</b>—Match packets with AF32 dscp (011100)</li> <li>• <b>af33</b>—Match packets with AF33 dscp (011110)</li> <li>• <b>af41</b>—Match packets with AF41 dscp (100010)</li> <li>• <b>af42</b>—Match packets with AF42 dscp (100100)</li> <li>• <b>af43</b>—Match packets with AF43 dscp (100110)</li> <li>• <b>cs1</b>—Match packets with CS1 (precedence 1) dscp (001000)</li> <li>• <b>cs2</b>—Match packets with CS2 (precedence 2) dscp (010000)</li> <li>• <b>cs3</b>—Match packets with CS3 (precedence 3) dscp (011000)</li> <li>• <b>cs4</b>—Match packets with CS4 (precedence 4) dscp (100000)</li> <li>• <b>cs5</b>—Match packets with CS5 (precedence 5) dscp (101000)</li> <li>• <b>cs6</b>—Match packets with CS6 (precedence 6) dscp (110000)</li> <li>• <b>cs7</b>—Match packets with CS7 (precedence 7) dscp (111000)</li> <li>• <b>default</b>—Default DSCP (000000)</li> <li>• <b>ef</b>—Match packets with EF dscp (101110)</li> </ul>
<b>fragments</b>	<p>(Optional) Causes the software to examine fragments of IPv4 packets when applying this access list entry. When this keyword is specified, fragments are subject to the access list entry.</p>
<b>log</b>	<p>(Optional) Causes an informational logging message about the packet that matches the entry to be sent to the console. (The level of messages logged to the console is controlled by the <b>logging console</b> command.)</p> <p><b>Note</b> ACL logging is supported only in ingress direction for both IPv4 and IPv6.</p> <p>The message includes the access list number, whether the packet was permitted or denied; the protocol, whether it was TCP, UDP, ICMP, or a number; and, if appropriate, the source and destination addresses and source and destination port numbers. The message is generated for the first packet that matches a flow, and then at 5-minute intervals, including the number of packets permitted or denied in the prior 5-minute interval.</p>
<b>log-input</b>	<p>(Optional) Provides the same function as the <b>log</b> keyword, except that the log-message also includes the input interface.</p>
<b>icmp-off</b>	<p>(Optional) Turns off ICMP generation for denied packets.</p>
<i>icmp-type</i>	<p>(Optional) ICMP message type for filtering ICMP packets. Range is from 0 to 255.</p>

<i>icmp-code</i>	(Optional) ICMP message code for filtering ICMP packets. Range is from 0 to 255.
<i>igmp-type</i>	(Optional) IGMP message type (0 to 15) or message name for filtering IGMP packets, as follows: <ul style="list-style-type: none"> <li>• dvmrp</li> <li>• host-query</li> <li>• host-report</li> <li>• mtrace</li> <li>• mtrace-response</li> <li>• pim</li> <li>• precedence</li> <li>• trace</li> <li>• v2-leave</li> <li>• v2-report</li> <li>• v3-report</li> </ul>
<i>operator</i>	(Optional) Operator is used to compare source or destination ports. Possible operands are <b>lt</b> (less than), <b>gt</b> (greater than), <b>eq</b> (equal), <b>neq</b> (not equal), and <b>range</b> (inclusive range). <p>If the operator is positioned after the <i>source</i> and <i>source-wildcard</i> values, it must match the source port.</p> <p>If the operator is positioned after the <i>destination</i> and <i>destination-wildcard</i> values, it must match the destination port.</p> <p>The <b>range</b> operator requires two port numbers. All other operators require one port number.</p>
<i>port</i>	Decimal number of a TCP or UDP port. A port number is a number from 0 to 65535. <p>TCP ports can be used only when filtering TCP. UDP ports can be used only when filtering UDP.</p>
<i>protocol-port</i>	Name of a TCP or UDP port. TCP and UDP port names are listed in the “Usage Guidelines” section. <p>TCP port names can be used only when filtering TCP. UDP port names can be used only when filtering UDP.</p>
<b>established</b>	(Optional) For the TCP protocol only: Indicates an established connection.
<b>match-any</b>	(Optional) For the TCP protocol only: Filters on any combination of TCP flags.
<b>match-all</b>	(Optional) For the TCP protocol only: Filters on all TCP flags.
+   -	(Required) For the TCP protocol <b>match-any</b> , <b>match-all</b> : Prefix <i>flag-name</i> with + or - . Use the + <i>flag-name</i> argument to match packets with the TCP flag set. Use the - <i>flag-name</i> argument to match packets when the TCP flag is not set.
<i>flag-name</i>	(Optional) For the TCP protocol <b>match-any</b> , <b>match-all</b> . Flag names are: <b>ack</b> , <b>fin</b> , <b>psh</b> , <b>rst</b> , <b>syn</b> , <b>urg</b> .

**Command Default** ICMP message generation is enabled by default.

**Command Modes** IPv4 access list configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.8.1	<b>log-input</b> keyword was introduced.
	Release 7.5.4	<b>bitmask</b> keyword was introduced.

**Usage Guidelines** Use the **deny** command following the **ipv4 access-list** command to specify conditions under which a packet cannot pass the access list.

By default, the first statement in an access list is number 10, and the subsequent statements are incremented by 10.

You can add **permit**, **deny**, or **remark** statements to an existing access list without retyping the entire list. To add a new statement anywhere other than at the end of the list, create a new statement with an appropriate entry number that falls between two existing entry numbers to indicate where it belongs.

The following is a list of precedence names:

- critical
- flash
- flash-override
- immediate
- internet
- network
- priority
- routine

The following is a list of ICMP message type names:

- administratively-prohibited
- alternate-address
- conversion-error
- dod-host-prohibited
- dod-net-prohibited
- echo
- echo-reply
- general-parameter-problem
- host-isolated
- host-precedence-unreachable
- host-redirect
- host-tos-redirect
- host-tos-unreachable
- host-unknown
- host-unreachable

- information-reply
- information-request
- mask-reply
- mask-request
- mobile-redirect
- net-redirect
- net-tos-redirect
- net-tos-unreachable
- net-unreachable
- network-unknown
- no-room-for-option
- option-missing
- packet-too-big
- parameter-problem
- port-unreachable
- precedence-unreachable
- protocol-unreachable
- reassembly-timeout
- redirect
- router-advertisement
- router-solicitation
- source-quench
- source-route-failed
- time-exceeded
- timestamp-reply
- timestamp-request
- traceroute
- unreachable

The following is a list of TCP port names that can be used instead of port numbers. Refer to the current *Assigned Numbers* RFC to find a reference to these protocols. You can find port numbers corresponding to these protocols by typing a ? in the place of a port number.

- bgp
- chargen
- cmd
- daytime
- discard
- domain
- echo
- exec
- finger
- ftp
- ftp-data
- gopher
- hostname
- ident

- irc
- klogin
- kshell
- login
- lpd
- nntp
- pim-auto-rp
- pop2
- pop3
- smtp
- sunrpc
- tacacs
- talk
- telnet
- time
- uucp
- whois
- www

The following UDP port names can be used instead of port numbers. Refer to the current *Assigned Numbers* RFC to find a reference to these protocols. You can find port numbers corresponding to these protocols by typing a ? in the place of a port number.

- biff
- bootpc
- bootps
- discard
- dnsix
- domain
- echo
- isakmp
- mobile-ip
- nameserver
- netbios-dgm
- netbios-ns
- netbios-ss
- ntp
- pim-auto-rp
- rip
- snmp
- snmptrap
- sunrpc
- syslog
- tacacs
- talk
- tftp
- time

- who
- xdmcp

Use the following flags in conjunction with the **match-any** and **match-all** keywords and the + and - signs to select the flags to display:

- ack
- fin
- psh
- rst
- syn

For example, **match-all** + *ack* + *syn* displays TCP packets with both the *ack* and *syn* flags set, or **match-any** + *ack* - *syn* displays the TCP packets with the *ack* set or the *syn* not set.



**Note** If any ACE in an ACL contains ABF clause, this ACL cannot be applied at any non-zero compression level.

Task ID	Task ID	Operations
	ipv4	read, write
	acl	read, write

## Examples

This example shows how to set a deny condition for an access list named Internet filter:

```
Router(config)# ipv4 access-list Internetfilter
Router(config-ipv4-acl)# 10 deny 192.168.34.0 0.0.0.255
Router(config-ipv4-acl)# 20 deny 172.16.0.0 0.0.255.255
Router(config-ipv4-acl)# 25 deny tcp host 172.16.0.0 gt bgp host 192.168.202.203 range 1300
1400
Router(config-ipv4-acl)# permit 10.0.0.0 0.255.255.255
```

This example shows how you can configure DSCP bitmask on ingress ERSPAN.

```
Router# config
Router(config)# ipv4 access-list acl1
Router(config-ipv4-acl)# 10 permit ipv4 host 192.0.2.1 any dscp af22 bitmask 0x3f
Router(config-ipv4-acl)# commit
Router(config-ipv4-acl)# exit
Router(config)# interface HundredGigE0/0/0/6
Router(config-if)# ipv4 address 192.0.2.51 255.255.255.0
Router(config-if)# monitor-session TEST ethernet direction rx-only port-level acl ipv4 acl1
Router(config-if)# commit
```



## deny (IPv6)

To set deny conditions for an IPv6 access list, use the **deny** command in IPv6 access list configuration mode. To remove the deny conditions, use the **no** form of this command.

```
[sequence-number] deny protocol { source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/ prefix-length } [ operator { port | protocol-port } ] [ dscp value [ bitmask value
] ] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments ] [ packet-length operator
packet-length value ] [ log | log-input ] [ ttl ttl value [ value1 . . . value2 ] ] icmp-off ]
no sequence-number
```

### Internet Control Message Protocol (ICMP)

```
[ sequence-number] deny icmp { source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/ prefix-length } { destination-ipv6-prefix/ prefix-length | any | host
destination-ipv6-address ipv6-wildcard-mask/ prefix-length } [ icmp-type ] [ icmp-code ] [ dscp value
] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments ] [ log ] [ icmp-off
]
```

### Transmission Control Protocol (TCP)

```
[sequence-number] deny tcp {source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/ prefix-length} [operator {port | protocol-port}] {destination-ipv6-prefix/ prefix-length
/ any | host destination-ipv6-address ipv6-wildcard-mask/ prefix-length} [operator {port | protocol | port}]
[ dscpvalue ] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments ] [ established ] {match-any
| match-all | + | -} [ flag-name ] [ log ] [ icmp-off ]
```

### User Datagram Protocol (UDP)

```
[sequence-number] deny tcp {source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/ prefix-length} [operator {port | protocol-port}] {destination-ipv6-prefix/ prefix-length
/ any | host destination-ipv6-address ipv6-wildcard-mask/ prefix-length} [operator {port | protocol | port}]
[ dscpvalue ] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments ] [ established ] [ flag-name ]
[ log ] [ icmp-off ]
```

### Syntax Description

<i>sequence-number</i>	(Optional) Number of the <b>deny</b> statement in the access list. This number determines the order of the statements in the access list. Range is 1 to 2147483644. (By default, the first statement is number 10, and the subsequent statements are incremented by 10.)
<i>protocol</i>	Name or number of an Internet protocol. It can be one of the keywords <b>ahp</b> , <b>esp</b> , <b>gre</b> , <b>icmp</b> , <b>igmp</b> , <b>igrp</b> , <b>ipinip</b> , <b>ipv6</b> , <b>nos</b> , <b>ospf</b> , <b>pcp</b> , <b>tcp</b> , or <b>udp</b> , or an integer in the range from 0 to 255 representing an IPv6 protocol number.
<i>source-ipv6-prefix</i> / <i>prefix-length</i>	The source IPv6 network or class of networks about which to set deny conditions.  This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
<i>any</i>	An abbreviation for the IPv6 prefix <code>::/0</code> .
<b>host</b> <i>source-ipv6-address</i>	Source IPv6 host address about which to set deny conditions.  This <i>source-ipv6-address</i> argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.

<i>ipv6wildcardmask</i>	IPv6 wildcard mask. The IPv6 wildcard mask can take any IPv6 address value which is used instead of prefix length.
<i>operator</i> { <i>port / protocol-port</i> }	<p>(Optional) Operand that compares the source or destination ports of the specified protocol. Operands are <b>lt</b> (less than), <b>gt</b> (greater than), <b>eq</b> (equal), <b>neq</b> (not equal), and <b>range</b> (inclusive range).</p> <p>If the operator is positioned after the <i>source-ipv6-prefix / prefix-length</i> argument, it must match the source port.</p> <p>If the operator is positioned after the <i>destination-ipv6-prefix / prefix-length</i> argument, it must match the destination port.</p> <p>The <b>range</b> operator requires two port numbers. All other operators require one port number.</p> <p>The <i>port</i> argument is the decimal number of a TCP or UDP port. Range is 0 to 65535. The <i>protocol-port</i> argument is the name of a TCP or UDP port. TCP port names can be used only when filtering TCP. UDP port names can be used only when filtering UDP.</p>
<i>destination-ipv6-prefix / prefix-length</i>	<p>Destination IPv6 network or class of networks about which to set deny conditions.</p> <p>This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.</p>
<b>host</b> <i>destination-ipv6-address</i>	<p>Destination IPv6 host address about which to set deny conditions.</p> <p>This <i>destination-ipv6-address</i> argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.</p>
<b>dscp value</b>	(Optional) Matches a differentiated services code point DSCP value against the traffic class value in the Traffic Class field of each IPv6 packet header. Range is 0 to 63.
routing	(Optional) Matches source-routed packets against the routing extension header within each IPv6 packet header.
hop-by-hop	(Optional) Supports Jumbo-grams. With the Router Alert option, it is an integral part in the operation of Multicast Listener Discovery (MLD). Router Alert [3] is an integral part in the operations of IPv6 Multicast through MLD and RSVP for IPv6.
authen	(Optional) Matches if the IPv6 egress authentication header is present.
destopts	(Optional) Matches if the IPv6 egress destination options header is present.
fragments	(Optional) Matches noninitial fragmented packets where the fragment extension header contains a nonzero fragment offset. The <b>fragments</b> keyword is an option only if the <i>operator</i> [ <i>port-number</i> ] arguments are not specified.

<b>log</b>	(Optional) Causes an informational logging message about the packet that matches the entry to be sent to the console. (The level of messages logged to the console is controlled by the <b>logging console</b> command.)  <b>Note</b> ACL logging is supported only in ingress direction for both IPv4 and IPv6.  The message includes the access list name and sequence number, whether the packet was denied; the protocol, whether it was TCP, UDP, ICMP, or a number; and, if appropriate, the source and destination addresses and source and destination port numbers. The message is generated for the first packet that matches, and then at 5-minute intervals, including the number of packets denied in the prior 5-minute interval.
<b>log-input</b>	(Optional) Provides the same function as the <b>log</b> keyword, except that the log-message also includes the input interface.
<b>ttl</b>	(Optional) Turns on matching against time-to-life (TTL) value. For IPv6 packets, <b>ttl</b> is also referred to as hop limit.
<i>ttl value</i> [ <i>value1 ... value2</i> ]	(Optional) TTL value used for filtering. Range is 1 to 255. If only <i>value</i> is specified, the match is against this value. If both <i>value1</i> and <i>value2</i> are specified, the packet TTL is matched against the range of TTLs between <i>value1</i> and <i>value2</i> .
<b>operator</b>	(Optional) Operand that compares the source or destination ports of the specified protocol. Operands are <b>lt</b> (less than), <b>gt</b> (greater than), <b>eq</b> (equal), <b>neq</b> (not equal), and <b>range</b> (inclusive range).
<b>icmp-off</b>	(Optional) Turns off ICMP generation for denied packets.
<b>icmp-type</b>	(Optional) ICMP message type for filtering ICMP packets. ICMP packets can be filtered by ICMP message type. Range is 0 to 255.
<b>icmp-code</b>	(Optional) ICMP message code for filtering ICMP packets. ICMP packets that are filtered by ICMP message type can also be filtered by the ICMP message code. Range is 0 to 255.
<b>established</b>	(Optional) For the TCP protocol only: Indicates an established connection.
<b>match-any</b>	(Optional) For the TCP protocol only: Filters on any combination of TCP flags.
<b>match-all</b>	(Optional) For the TCP protocol only: Filters on all TCP flags.
<b>+   -</b>	(Required) For the TCP protocol <b>match-any</b> , <b>match-all</b> : Prefix <i>flag-name</i> with + or - . Use the + <i>flag-name</i> argument to match packets with the TCP flag set. Use the - <i>flag-name</i> argument to match packets when the TCP flag is not set.
<b>flag-name</b>	(Optional) For the TCP protocol <b>match-any</b> , <b>match-all</b> . Flag names are: <b>ack</b> , <b>fin</b> , <b>psh</b> , <b>rst</b> , <b>syn</b> , <b>urg</b> .

**Command Default**

ICMP message generation is enabled by default.

**Command Modes**

IPv6 access list configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.2.1	Ingress IPv6 TCP flags are supported.
	Release 7.3.15	Egress IPv6 TCP flags are supported.
	Release 7.8.1	<b>log-input</b> keyword was introduced.
	Release 7.8.1	<b>tfl</b> keyword was introduced.
	Release 7.5.4	<b>bitmask</b> keyword was introduced.
	Release 7.10.1	IPv6 AHP and ESP headers are supported.

**Usage Guidelines**

The **deny** (IPv6) command is similar to the **deny** (IPv4) command, except that it is IPv6-specific.

Use the **deny** (IPv6) command following the **ipv6 access-list** command to define the conditions under which a packet passes the access list.



**Note** If any ACE in an ACL contains ABF clause, this ACL cannot be applied at any non-zero compression level.

Specifying **ipv6** for the *protocol* argument matches against the IPv6 header of the packet.

By default, the first statement in an access list is number 10, and the subsequent statements are numbered in increments of 10.

You can add permit, deny, or remark statements to an existing access list without retyping the entire list. To add a new statement anywhere other than at the end of the list, create a new statement with an appropriate entry number that falls between two existing entry numbers to indicate where it belongs.

Both the *source-ipv6-prefix/prefix-length* and *destination-ipv6-prefix/prefix-length* arguments are used for traffic filtering (the source prefix filters traffic based upon the traffic source; the destination prefix filters traffic based upon the traffic destination).



**Note** IPv6 prefix lists, not access lists, should be used for filtering routing protocol prefixes.

The **fragments** keyword is an option only if the *operator* [*port* | *protocol-port* ] arguments are not specified.

**Task ID**

Task ID	Operations
acl	read, write

## Examples

The following example shows how to configure the IPv6 access list named toCISCO and apply the access list to the traffic entering the HundredGigE interface 0/2/0/2. Specifically, the deny entry in the list keeps all packets that have a destination TCP port number greater than 5000 from entering the HundredGigE interface 0/2/0/2. The permit entry in the list permits all ICMP packets to enter the HundredGigE interface 0/2/0/2.

```
Router(config)# ipv6 access-list toCISCO
Router(config-ipv6-acl)# deny tcp any any gt 5000
Router(config-ipv6-acl)# permit icmp any any
Router(config)# interface HundredGigE 0/2/0/2
Router(config-if)# ipv6 access-group toCISCO ingress
```

The following example shows how to configure the IPv6 access list named toCISCO and apply the access list to the traffic entering theHundredGigE interface 0/2/0/2. Specifically, the deny entry in the list keeps all packets that have a hop-by-hop optional field from entering the HundredGigE interface 0/2/0/2.

```
Router(config)# ipv6 access-list toCISCO
Router(config-ipv6-acl)# deny ipv6 any any hop-by-hop
Router(config)# interface HundredGigE 0/2/0/2
Router(config-if)# ipv6 access-group toCISCO ingress
```

The following example shows how you can configure DSCP bitmask on ingress ERSPAN.

```
Router# config
Router(config)# ipv6 access-list acl1
Router(config-ipv6-acl)# 10 permit ipv6 host 2001:DB8::2/32 any dscp 33 bitmask 0x3f
Router(config-ipv6-acl)# commit
Router(config-ipv6-acl)# exit
Router(config)# interface HundredGigE 0/0/10/3
Router(config-if)# ipv6 address 2001:DB8::1/32
Router(config-if)# monitor-session TEST ethernet direction rx-only port-level acl ipv6 acl1
Router(config-if)# commit
```

The following example shows how you can configure AHP and ESP headers on an ACLs.

```
Router(config)# #ipv6 access-list ipv6_umpp_access_list
Router(config-ipv6-acl)# 12 deny ahp any any
Router(config-ipv6-acl)# ipv6 access-list ipv6_umpp_access_list
Router(config-ipv6-acl)# 14 deny esp any any
Router(config-ipv6-acl)# commit
Router(config-ipv6-acl)# exit
```

# dont-fragment

To configure an access list to match on the **dont-fragment** flag.

```
fragment-type dont-fragment {capture | counter | first-fragment | is-fragment | last-fragment | log |
log-input | set | udf | nexthop1 }
```

## Syntax Description

<b>capture</b>	ACL matches on the <b>dont-fragment</b> flag, and captures the matched packet.
<b>counter</b>	ACL matches on the <b>dont-fragment</b> flag, and displays the counter for the matches.
<b>first-fragment</b>	ACL matches on the <b>dont-fragment</b> flag, and then matches on the <b>first-fragment</b> flag.
<b>is-fragment</b>	ACL matches on the <b>dont-fragment</b> flag, and then matches on the <b>is-fragment</b> flag.
<b>last-fragment</b>	ACL matches on the <b>dont-fragment</b> flag, and then matches on the <b>last-fragment</b> flag.
<b>log</b>	ACL matches on the <b>dont-fragment</b> flag and logs the matches.
<b>log-input</b>	ACL matches on the <b>dont-fragment</b> flag and logs the matches, including on the input interface.
<b>set</b>	ACL matches on the <b>dont-fragment</b> flag and sets a particular action on the matches.
<b>udf</b>	ACL matches on the <b>dont-fragment</b> flag, and sets the user-defined fields for the matches.
<b>nexthop1</b>	ACL matches on the <b>dont-fragment</b> flag, and then matches on the <b>nexthop1</b> flag.

## Command Default

None

## Command Modes

ACL configuration mode

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

This command is supported only for IPv4 ACLs.

## Example

Use the following sample configuration to match on the **dont-fragment** flag.

```
/* Enter the global configuraton mode and configure an IPv4 access list */
Router# config
Router(config)# ipv4 access-list TEST
Router(config-ipv4-acl)# 10 permit tcp any any

/* Configure an ACE to match on the dont-fragment flag (indicates a non-fragmented packet)
and forward the packet to the default (pre-configured) next hop */
Router(config-ipv4-acl)# 20 permit tcp any any fragment-type dont-fragment nexthop1 ipv4
```

```
192.0.2.1  
Router(config-ipv4-acl)# commit
```

# first-fragment

To configure an ACL to match on the **first-fragment** flag.

**fragment-type first-fragment** {**capture** | **counter** | **log** | **log-input** | **set** | **udf** | **<none>**}

## Syntax Description

<b>capture</b>	ACL matches on the <b>first-fragment</b> flag, and captures the matched packet.
<b>counter</b>	ACL matches on the <b>first-fragment</b> flag, and displays the counter for the matches.
<b>log</b>	ACL matches on the <b>first-fragment</b> flag and logs the matches.
<b>log-input</b>	ACL matches on the <b>first-fragment</b> flag and logs the matches, including on the input interface.
<b>set</b>	ACL matches on the <b>first-fragment</b> flag and sets a particular action on the matches.
<b>udf</b>	ACL matches on the <b>first-fragment</b> flag, and sets the user-defined fields for the matches.
<b>nexthop1</b>	ACL matches on the <b>first-fragment</b> flag, and then matches on the <b>nexthop1</b> flag.

## Command Default

None

## Command Modes

ACL configuration mode.

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

This command is supported only for IPv4 ACLs.

## Example

Use the following sample configuration to match on the **first-fragment** flag.

```
/* Enter the global configuraton mode and configure an IPv4 access list */
Router# config
Router(config)# ipv4 access-list TEST
Router(config-ipv4-acl)# 10 permit tcp any any

/* Configure an ACE to match on the first-fragment flag (indicates the first fragment of a
fragmented packet)
and forward the packet to a next hop of 20.20.20.1 */
Router(config-ipv4-acl)# 40 permit ospf any any fragment-type first-fragment nexthop1 ipv4
192.0.2.1
Router(config-ipv4-acl)# commit
```



# fragment-offset

To enable packet filtering at an ingress or egress interface by specifying fragment-offset as a match condition in an IPv4 or IPv6 ACL, use the **fragment-offset** option in **permit** or **deny** command in IPv4 or IPv6 access-list configuration mode. To disable this feature, use the **no** form of this command.

**fragment-offset** {**eq** *value* | **gt** *value* | **lt** *value* | **neq** *value* | **range** *lower-limit upper-limit*}

Syntax Description	fragment-offset eq <i>value</i>	Filters packets that have a fragment offset equal to the specified limit.
	fragment-offset gt <i>value</i>	Filters packets that have a fragment offset greater than the specified limit.
	fragment-offset lt <i>value</i>	Filters packets that have a fragment offset less than the specified limit.
	fragment-offset neq <i>value</i>	Filters packets that have a fragment offset that does not match the specified limit.
	fragment-offset range <i>lower-limit upper-limit</i>	Filters packets that have a fragment offset within the specified range.

**Command Default** None

**Command Modes** IPv4 or IPv6 Access List Configuration mode

Release	Modification
Release 7.3.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

## Example

This example shows how to configure an IPv4 access list to filter packets by the fragment-offset condition:

```
Router# config
Router(config)# ipv4 access-list fragment-offset-acl
Router(config-ipv4-acl)# 10 permit ipv4 any any fragment-offset range 300 400
```

# fragment-type

To configure an access list to match on the type of fragment.

**fragment-type** {**dont-fragment** | **first-fragment** | **is-fragment** | **last-fragment**}

Syntax Description	
<b>dont-fragment</b>	ACL matches on the <b>dont-fragment</b> flag
<b>first-fragment</b>	ACL matches on the <b>first-fragment</b> flag
<b>is-fragment</b>	ACL matches on the <b>is-fragment</b> flag
<b>last-fragment</b>	ACL matches on the <b>last-fragment</b> flag

**Command Default** None

**Command Modes** ACL configuration mode

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** This command is supported only for IPv4 access lists.

## Example

Use the following sample configuration to configure an ACL to match on the type of fragment..

```
/* Enter the global configuraton mode and configure an IPv4 access list */
Router# config
Router(config)# ipv4 access-list TEST
Router(config-ipv4-acl)# 10 permit tcp any any

/* Configure an ACE to match on the dont-fragment flag (indicates a non-fragmented packet)
and forward the packet to the default (pre-configured) next hop */
Router(config-ipv4-acl)# 20 permit tcp any any fragment-type dont-fragment default

/* Configure an ACE to match on the is-fragment flag (indicates a fragmented packet)
and forward the packet to a next hop of 10.10.10.1 */
Router(config-ipv4-acl)# 30 permit udp any any fragment-type is-fragment nexthop1 ipv4
10.10.10.1

/* Configure an ACE to match on the first-fragment flag (indicates the first fragment of a
fragmented packet)
and forward the packet to a next hop of 20.20.20.1 */
Router(config-ipv4-acl)# 40 permit ospf any any fragment-type first-fragment nexthop1 ipv4
20.20.20.1

/* Configure an ACE to match on the last-fragment flag (indicates the last fragment of a
fragmented packet)
and forward the packet to a next hop of 30.30.30.1 */
```

```
Router(config-ipv4-acl)# 50 permit icmp any any fragment-type last-fragment nexthop1 ipv4  
30.30.30.1  
Router(config-ipv4-acl)# commit
```

## hw-module profile stats acl-permit

To obtain statistics of the packet count of the routing traffic that an ACL permits, use the **hw-module profile stats acl-permit** command in XR Config mode. To disable the tracking of permitted packet count, use the **no** form of this command.

```
hw-module profile stats acl-permit
no hw-module profile stats acl-permit
```

### Syntax Description

This command has no keywords or arguments.

### Command Default

If you do not configure the **hw-module profile stats acl-permit** command, you cannot enable the statistics for the routing traffic that an ACL permits.

### Command Mode

XR Config

### Command History

Release	Modification
Release 7.3.2	Supports logging of permit statistics for ACL-based forwarding (ABF).
Release 7.2.12	This command was introduced.

### Usage Guidelines

- The permit statistics of the routing traffic that an ACL allows are available only after you execute the **hw-module profile stats acl-permit** command and based on the requirement, reboot the line cards or the router.

Task ID	Operations
config-services	read, write
root-lr	read, write

### Examples

The following example shows you how to configure the **acl-permit** command:

```
Router# configure
Router(config)# hw-module profile stats acl-permit
Fri Aug 7 05:52:58.052 UTC
In order to activate/deactivate this stats profile, you must manually reload the chassis/all
line cards
Router(config)# commit
Fri Aug 7 05:55:50.103 UTC
```

```
LC/0/4/CPU0:Aug 7 05:55:50.218 UTC: fia_driver[245]:  
%FABRIC-FIA_DRV-4-STATS_HW_PROFILE_MISMATCH : Mismatch found, reload LC to activate the  
new stats profile  
Router(config)#
```

## ipv4 access-group

To control access to an interface, use the **ipv4 access-group** command in interface configuration mode. To remove the specified access group, use the **no** form of this command.

**ipv4 access-group** *access-list-name* { **ingress** | **egress** } [ **compress level** *compression-level* ]

Syntax Description		
<i>access-list-name</i>		Name of an IPv4 access list as specified by an <b>ipv6 access-list</b> command.
<b>ingress</b>		Filters on inbound packets.
<b>egress</b>		Filters on outbound packets.
<b>compress level</b> <i>compression-level</i>		Configures compression level for interface ACLs. Compression level values range from zero and five.

**Command Default** The interface does not have an IPv4 access list applied to it.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.3.1	Compression level can be configured

**Usage Guidelines** Use the **ipv4 access-group** command to control access to an interface. To remove the specified access group, use the **no** form of the command. Use the *access-list-name* argument to specify a particular IPv4 access list.

Filtering of MPLS packets through interface ACL is not supported.

If the access list permits the addresses, the software continues to process the packet. If the access list denies the address, the software discards the packet and returns an Internet Control Message Protocol (ICMP) host unreachable message.

If the specified access list does not exist, all packets are passed.

By default, the unique or per-interface ACL statistics are disabled.

Task ID	Task ID	Operations
	acl	read, write
	network	read, write

**Examples** The following example shows how to apply filters on packets from HundredGigE interface 0/2/0/2:

```
Router(config)# interface HundredGigE 0/2/0/2  
Router(config-if)# ipv4 access-group p-ingress-filter ingress
```

The following example shows how to apply compress level 2 on ingress traffic:

```
Router(config)# interface HundredGigE 0/2/0/0  
Router(config-if)# ipv4 access-group p-ingress-filter ingress compress level 2
```

This example shows how to apply compression level 2 on egress traffic for an IPv4 Hybrid ACL, where you've already created a network object group and attached an ACL(network-object-acl) to it:

```
Router# configure  
Router(config)# interface HundredGigE 0/0/10/3  
Router(config-if)# ipv4 address 1.1.1.1/24  
Router(config-if)# no shut  
Router(config-if)# ipv4 access-group network-object-acl egress compress level 2  
Router(config-if)# commit  
Router(config-if)# exit
```

## ipv4 access-list

To define an IPv4 access list by name, use the **ipv4 access-list** command in XR Config mode. To remove all entries in an IPv4 access list, use the **no** form of this command.

```
ipv4 access-list name
no ipv4 access-list name
```

### Syntax Description

*name* Name of the access list. Names cannot contain a space or quotation marks.

### Command Default

No IPv4 access list is defined.

### Command Modes

XR Config mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

Use the **ipv4 access-list** command to configure an IPv4 access list. This command places the router in access list configuration mode, in which the denied or permitted access conditions must be defined with the **deny** or **permit** command.

Use the **ipv4 access-group** command to apply the access list to an interface.

### Task ID

Task ID	Operations
acl	read, write

### Examples

This example shows how to define a standard access list named Internetfilter:

```
Router(config)# ipv4 access-list Internetfilter
Router(config-ipv4-acl)# 10 permit 192.168.34.0 0.0.0.255
Router(config-ipv4-acl)# 20 permit 172.16.0.0 0.0.255.255
Router(config-ipv4-acl)# 30 permit 10.0.0.0 0.255.255.255
Router(config-ipv4-acl)# 39 remark Block BGP traffic from 172.16 net.
Router(config-ipv4-acl)# 40 deny tcp host 172.16.0.0 eq bgp host 192.168.202.203 range 1300
1400
```



## ipv4 access-list log-update rate

To specify the rate at which IPv4 access lists are logged, use the **ipv4 access-list log-update rate** command in XR Config mode. To return the update rate to the default setting, use the **no** form of this command.

```
ipv4 access-list log-update rate rate-number
no ipv4 access-list log-update rate rate-number
```

<b>Syntax Description</b>	<i>rate-number</i> Rate at which IPv4 access hit logs are generated per second on the router. Range is 1 to 1000.	
<b>Command Default</b>	Default is 1.	
<b>Command Modes</b>	XR Config mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	The <i>rate-number</i> argument applies to all the IPv4 access-lists configured on the interfaces. That is, at any given time there can be between 1 and 1000 log entries for the system.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv4	read, write
	acl	read, write

### Examples

The following example shows how to configure a IPv4 access hit logging rate for the system:

```
Router(config)# ipv4 access-list log-update rate 10
```

## ipv4 access-list log-update threshold

To specify the number of updates that are logged for IPv4 access lists, use the **ipv4 access-list log-update threshold** command in XR Config mode. To return the number of logged updates to the default setting, use the **no** form of this command.

```
ipv4 access-list log-update threshold update-number
no ipv4 access-list log-update threshold update-number
```

<b>Syntax Description</b>	<i>update-number</i> Number of updates that are logged for every IPv4 access list configured on the router. Range is 0 to 2147483647.
---------------------------	---

<b>Command Default</b>	For IPv4 access lists, 2147483647 updates are logged.
------------------------	---

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	IPv4 access list updates are logged at 5-minute intervals, following the first logged update. Configuring a lower number of updates (a number lower than the default) is useful when more frequent update logging is desired.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read, write
	acl	read, write

<b>Examples</b>	This example shows how to configure a log threshold of ten updates for every IPv4 access list configured on the router:
-----------------	---

```
Router(config)# ipv4 access-list log-update threshold 10
```

## ipv6 access-group

To control access to an interface, use the **ipv6 access-group** command in interface configuration mode. To remove the specified access group, use the **no** form of this command.

```
ipv6 access-group access-list-name { ingress | egress } [ compress level compression-level ]
```

Syntax Description		
<i>access-list-name</i>	Name of an IPv6 access list as specified by an <b>ipv6 access-list</b> command.	
<b>ingress</b>	Filters on inbound packets.	
<b>compress level</b> <i>compression-level</i>	Configures compression level for interface ACLs. Compression level values range from zero and five.	

**Command Default** The interface does not have an IPv6 access list applied to it.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.3.1	Compression level can be configured

**Usage Guidelines** Use compression level two to create Hybrid ACLs with an ACE that uses IPv6 extension headers to filter ingress and egress IPv6 packets.

Task ID	Task ID	Operations
	acl	read, write
	ipv6	read, write

### Examples

This example shows how to apply filters on packets from HundredGigE interface 0/2/0/2:

```
Router(config)# interface HundredGigE 0/2/0/2
Router(config-if)# ipv6 access-group p-in-filter ingress
```

This example shows how to create an ingress IPv6 Hybrid ACL with compression level 2 based on extensions headers:

```
Router# configure
Router(config)# ipv6 access-list ACL-EXT-HEADER
Router(config-ipv6-acl)# 10 deny ipv6 any any routing
Router(config-ipv6-acl)# commit
```

```
Router(config-ipv6-acl)# exit
Router(config)# interface hundredGigE 0/4/0/36
Router(config-if)# ipv6 access-group ACL-EXT-HEADER ingress compress level 2
Router(config-if)# commit
```

This example shows how to create an egress IPv6 Hybrid ACL with compression level 2 based on extensions headers:

```
Router# configure
Router(config)# ipv6 access-list ACL-EGRESS
Router(config-ipv6-acl)# 10 deny ipv6 any any routing
Router(config-ipv6-acl)# commit
Router(config-ipv6-acl)# exit
Router(config)# interface hundredGigE 0/4/0/13
Router(config-if)# ipv6 access-group ACL-EGRESS egress compress level 2
Router(config-if)# commit
```

# ipv6 access-list

To define an IPv6 access list and to place the router in IPv6 access list configuration mode, use the **ipv6 access-list** command in interface configuration mode. To remove the access list, use the **no** form of this command.

**ipv6 access-list** *name*  
**no ipv6 access-list** *name*

<b>Syntax Description</b>	<i>name</i> Name of the IPv6 access list. Names cannot contain a space or quotation mark, or begin with a numeric.				
<b>Command Default</b>	No IPv6 access list is defined.				
<b>Command Modes</b>	Interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

**Usage Guidelines** The **ipv6 access-list** command is similar to the **ipv4 access-list** command, except that it is IPv6-specific. The IPv6 access lists are used for traffic filtering based on source and destination addresses, IPv6 option headers, and optional, upper-layer protocol type information for finer granularity of control. IPv6 access lists are defined by using the **ipv6 access-list** command in XR Config mode mode and their permit and deny conditions are set by using the **deny** and **permit** commands in IPv6 access list configuration mode. Configuring the **ipv6 access-list** command places the router in IPv6 access list configuration mode—the router prompt changes to router (config-ipv6-acl)#. From IPv6 access list configuration mode, permit and deny conditions can be set for the defined IPv6 access list.

See the “Examples” section for an example of a translated IPv6 access control list (ACL) configuration.



**Note** No more than one IPv6 access list can be applied to an interface per direction.



**Note** Every IPv6 access list has an implicit **deny ipv6 any any** statement as its last match condition. An IPv6 access list must contain at least one entry for the implicit **deny ipv6 any any** statement to take effect.



**Note** IPv6 prefix lists, not access lists, should be used for filtering routing protocol prefixes.

Use the **ipv6 access-group** interface configuration command with the *access-list-name* argument to apply an IPv6 access list to an IPv6 interface.



**Note** An IPv6 access list applied to an interface with the **ipv6 access-group** command filters traffic that is forwarded, not originated, by the router.



**Note** Every IPv6 ACL has implicit **permit icmp any any nd-na**, **permit icmp any any nd-ns**, and **deny ipv6 any any** statements as its last match conditions. (The former two match conditions allow for ICMPv6 neighbor discovery.) An IPv6 ACL must contain at least one entry for the implicit **deny ipv6 any any** statement to take effect. **permit icmp any any nd-na permit icmp any any nd-ns deny ipv6 any any deny ipv6 any any**.

The IPv6 neighbor discovery process makes use of the IPv6 network layer service; therefore, by default, IPv6 ACLs implicitly allow IPv6 neighbor discovery packets to be sent and received on an interface. In IPv4, the Address Resolution Protocol (ARP), which is equivalent to the IPv6 neighbor discovery process, makes use of a separate data link layer protocol; therefore, by default, IPv4 ACLs implicitly allow ARP packets to be sent and received on an interface.

Task ID	Task ID	Operations
	acl	read, write
	ipv6	read, write

## Examples

This example shows how to configure the IPv6 access list named list2 and applies the ACL to traffic on interface HundredGigE 0/2/0/2. Specifically, the first ACL entry keeps all packets from the network fec0:0:0:2::/64 (packets that have the site-local prefix fec0:0:0:2 as the first 64 bits of their source IPv6 address) from exiting out of interface HundredGigE 0/2/0/2. The second entry in the ACL permits all other traffic to exit out of interface HundredGigE 0/2/0/2. The second entry is necessary because an implicit deny all condition is at the end of each IPv6 ACL.

```
Router(config)# ipv6 access-list list2
Router(config-ipv6-acl)# 10 deny fec0:0:0:2::/64 any
Router(config-ipv6-acl)# 20 permit any any

Router# show ipv6 access-lists list2

ipv6 access-list list2
 10 deny ipv6 fec0:0:0:2::/64 any
 20 permit ipv6 any any

Router(config)# interface HundredGigE 0/2/0/2
```



**Note** IPv6 is automatically configured as the protocol type in **permit any any** and **deny any any** statements that are translated from XR Config mode mode to IPv6 access list configuration mode.



---

**Note** An IPv6 router does not forward to another network an IPv6 packet that has a link-local address as either its source or destination address (and the source interface for the packet is different from the destination interface for the packet).

---

## ipv6 access-list log-update rate

To specify the rate at which IPv6 access lists are logged, use the **ipv6 access-list log-update rate** command in XR Config mode. To return the update rate to the default setting, use the **no** form of this command.

```
ipv6 access-list log-update rate rate-number
no ipv6 access-list log-update rate rate-number
```

<b>Syntax Description</b>	<i>rate-number</i> Rate at which IPv6 access hit logs are generated per second on the router. Range is 1 to 1000.	
<b>Command Default</b>	Default is 1.	
<b>Command Modes</b>	XR Config mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	The <i>rate-number</i> argument applies to all the IPv6 access-lists configured on the interfaces. That is, at any given time there can be between 1 and 1000 log entries for the system.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read, write
	acl	read, write
<b>Examples</b>	This example shows how to configure a IPv6 access hit logging rate for the system:	
	Router(config)# <b>ipv6 access-list log-update rate 10</b>	



# ipv6 access-list log-update threshold

To specify the number of updates that are logged for IPv6 access lists (ACLs), use the **ipv6 access-list log-update threshold** command in XR Config mode. To return the number of logged updates to the default setting, use the **no** form of this command.

```
ipv6 access-list log-update threshold update-number
no ipv6 access-list log-update threshold update-number
```

<b>Syntax Description</b>	<code>update-number</code> Number of updates that are logged for every IPv6 access list configured on the router. Range is 0 to 2147483647.
---------------------------	---

<b>Command Default</b>	For IPv6 access lists, 350000 updates are logged.
------------------------	---

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The <b>ipv6 access-list log-update threshold</b> command is similar to the <b>ipv4 access-list log-update threshold</b> command, except that it is IPv6-specific.
-------------------------	---

IPv6 access list updates are logged at 5-minute intervals, following the first logged update. Configuring a lower number of updates (a number lower than the default) is useful when more frequent update logging is desired.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read, write
	ipv6	read, write

## Examples

This example shows how to configure a log threshold of ten updates for every IPv6 access list configured on the router:

```
Router(config)# ipv6 access-list log-update threshold 10
```

# is-fragment

To configure an ACL to match on the **is-fragment** flag.

**fragment-type is-fragment** { **capture** | **counter** | **log** | **log-input** | **set** | **udf** | **nexthop1** }

## Syntax Description

<b>capture</b>	ACL matches on the <b>is-fragment</b> flag, and captures the matched packet.
<b>counter</b>	ACL matches on the <b>is-fragment</b> flag, and displays the counter for the matches.
<b>log</b>	ACL matches on the <b>is-fragment</b> flag and logs the matches.
<b>log-input</b>	ACL matches on the <b>is-fragment</b> flag and logs the matches, including on the input interface.
<b>set</b>	ACL matches on the <b>is-fragment</b> flag and sets a particular action on the matches.
<b>udf</b>	ACL matches on the <b>is-fragment</b> flag, and sets the user-defined fields for the matches.
<b>nexthop1</b>	ACL matches on the <b>is-fragment</b> flag, and then matches on the <b>nexthop1</b> flag.

## Command Default

None

## Command Modes

ACL configuration mode.

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

This command is supported only for IPv4 ACLs.

## Example

Use the following sample configuration to match on the **is-fragment** flag.

```
/* Enter the global configuraton mode and configure an IPv4 access list */
Router# config
Router(config)# ipv4 access-list TEST
Router(config-ipv4-acl)# 10 permit tcp any any

/* Configure an ACE to match on the is-fragment flag (indicates a fragmented packet)
and forward the packet to a next hop of 10.10.10.1 */
Router(config-ipv4-acl)# 30 permit udp any any fragment-type is-fragment nexthop1 ipv4
192.0.2.1
Router(config-ipv4-acl)# commit
```

# last-fragment

To configure an access list to match on the **last-fragment** flag.

**fragment-type last-fragment** {**capture** | **counter** | **log** | **log-input** | **set** | **udf** | **nexthop1** }

## Syntax Description

<b>capture</b>	ACL matches on the <b>last-fragment</b> flag, and captures the matched packet.
<b>counter</b>	ACL matches on the <b>last-fragment</b> flag, and displays the counter for the matches.
<b>log</b>	ACL matches on the <b>last-fragment</b> flag and logs the matches.
<b>log-input</b>	ACL matches on the <b>last-fragment</b> flag and logs the matches, including on the input interface.
<b>set</b>	ACL matches on the <b>last-fragment</b> flag and sets a particular action on the matches.
<b>udf</b>	ACL matches on the <b>last-fragment</b> flag, and sets the user-defined fields for the matches.
<b>nexthop1</b>	ACL matches on the <b>last-fragment</b> flag, and then matches on the <b>nexthop1</b> flag.

## Command Default

None

## Command Modes

ACL configuration mode.

## Command History

Release	Modification
Release 7.3.1	This command was introduced.

## Usage Guidelines

This command is supported only for IPv4 ACLs.

## Example

Use the following sample configuration to match on the **last-fragment** flag.

```
/* Enter the global configuraton mode and configure an IPv4 access list */
Router# config
Router(config)# ipv4 access-list TEST
Router(config-ipv4-acl)# 10 permit tcp any any

/* Configure an ACE to match on the last-fragment flag (indicates the last fragment of a
fragmented packet)
and forward the packet to a next hop of 30.30.30.1 */
Router(config-ipv4-acl)# 50 permit icmp any any fragment-type last-fragment nexthop1 ipv4
192.0.2.1
Router(config-ipv4-acl)# commit
```

## object-group network

To configure a network object group, and to enter the network object group configuration mode, use the **object-group network** command in the global configuration mode. To de-configure the network object group, use the **no** form of this command.

**object-group network** { **ipv4** | **ipv6** } *object-group-name*  
**no object-group network** { **ipv4** | **ipv6** } *object-group-name*

Syntax Description		
	<b>ipv4</b>	Configures the operation state of an IPV4 network object group.
	<b>ipv6</b>	Configures the operation state of an IPV6 network object group.
	<i>object-group-name</i>	Name of the object-group.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** Inherited object-groups up to four levels are supported in this release.

If an ACL is applied on an interface with non-zero compression level (implying it contains no ABF ACEs), a user cannot add an ACE with object-group.

Task ID	Task ID	Operation
	system read, write	

### Example

This example shows how to configure a network object-group, and to enter the network object-group configuration mode:

```
Router# configure
Router(config)# object-group network ipv4 ipv4_type5_obj1
Router(config-object-group-ipv4)#
```

# object-group port

To configure a port object group, and to enter the port object group configuration mode, use the **object-group port** command in the global configuration mode. To de-configure the port object group, use the **no** form of this command.

**object-group port** *object-group-name*  
**no object-group port** *object-group-name*

<b>Syntax Description</b>	<i>object-group-name</i> Name of the object-group.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Global configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.3.1</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.3.1	This command was introduced.
Release	Modification				
Release 7.3.1	This command was introduced.				
<b>Usage Guidelines</b>	Inherited object-groups upto four levels are supported.				



**Note** If any ACE in an ACL contains ABF clause, this ACL cannot be applied at any non-zero compression level.

Task ID	Task ID	Operation
	system	read, write

## Example

This example show how to configure a port object-group, and to enter the port object-group configuration mode:

```
Router# configure
Router(config)# object-group port ipv4_type5_obj1
Router(config-object-group-port)#
```

# packet-length

Enables filtering of packets at an ingress/egress interface by specifying the packet length as a match condition in a IPv4/IPv6 ACL.

By using the **packet-length** condition in an ACL, IPv4 and IPv6 packets are either processed (permit statement) or dropped (deny statement).

To remove this configuration, use the **no** prefix for the command.

**packet-length** { **eq** *value* | **gt** *value* | **lt** *value* | **neq** *value* | **range** *lower-limit upper-limit* }

Syntax Description		
<b>packet-length eq</b> <i>value</i>		Filters packets that have a packet length equal to the specified limit.
<b>packet-length gt</b> <i>value</i>		Filters packets that have a packet length greater than the specified limit.
<b>packet-length lt</b> <i>value</i>		Filters packets that have a packet length less than the specified limit.
<b>packet-length neq</b> <i>value</i>		Filters packets that have a packet length that does not match the specified limit.
<b>packet-length range</b> <i>lower-limit upper-limit</i>		Filters packets that have a packet length within the specified range. The IPv4/IPv6 packet length ranges from 0 to 65535.

**Command Default** None

**Command Modes** Access List Configuration mode

Release	Modification
Release 7.3.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

## Example

The following example shows how you can configure an IPv4 access list with the **packet-length** condition.

```
Router# config
Router(config)# ipv4 access-list pktlen-v4
Router(config-ipv4-acl)# 10 permit tcp any any packet-length eq 1482
Router(config-ipv4-acl)# 20 permit udp any any packet-length range 1400 1500
Router(config-ipv4-acl)# 30 deny ipv4 any any
```

The following example shows how you can configure an IPv6 access list with the **packet-length** condition.

```
Router# config
Router(config)# ipv6 access-list pktlen-v6
Router(config-ipv6-acl)# 10 permit tcp any any packet-length eq 1500
```

```
Router(config-ipv6-acl)# 20 permit udp any any packet-length range 1500 1600
Router(config-ipv6-acl)# 30 deny ipv6 any any
```

## permit (IPv4)

To set conditions for an IPv4 access list, use the **permit** command in access list configuration mode. There are two versions of the **permit** command: **permit** (source), **permit** (destination), and **permit** (protocol). To remove a condition from an access list, use the **no** form of this command.

```
[ sequence-number ] permit source [ source-wildcard ] [ log | log-input ]
[ sequence-number ] permit protocol source source-wildcard destination destination-wildcard
[ precedence precedence ] [ nexthop [ ipv4-address1 ] [ ipv4-address2 ] [ ipv4-address3 ] ] [
dscp dscp [ bitmask value ] ] [ fragments ] [ log | log-input ] [ nexthop [ track track-name ]
[ ipv4-address1 ] [ ipv4-address2 ] [ ipv4-address3 ] [ ttl ttl value [ value1 . . . value2 ]
]
no sequence-number
```

### Internet Control Message Protocol (ICMP)

```
[sequence-number] permit icmp source source-wildcard destination destination-wildcard [icmp-type]
[icmp-code] [precedence precedence] [dscp dscp] [fragments]
```

### Transmission Control Protocol (TCP)

```
[sequence-number] permit tcp { source-ipv4-prefix/ prefix-length | any | host source-ipv4-address
ipv4-wildcard-mask/prefix-length } [ operator { port | protocol-port } ] { destination-ipv4-prefix/
prefix-length | any | host destination-ipv4-address ipv4-wildcard-mask/prefix-length } [ operator { port |
protocol/port } ] [ dscp value ] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments
] [ established ] { match-any | match-all | + | - } [ flag-name ] [ log ]
```

### Internet Group Management Protocol (IGMP)

```
[sequence-number] permit igmp source source-wildcard destination destination-wildcard [igmp-type]
[precedence precedence] [dscp value] [fragments]
```

### User Datagram Protocol (UDP)

```
[sequence-number] permit udp source source-wildcard [operator {portprotocol-port}] destination
destination-wildcard [operator {portprotocol-port}] [precedence precedence] [dscp dscp] [fragments]
```

---

#### Syntax Description

*sequence-number*

(Optional) Number of the **permit** statement in the access list. This number determines the order of the statements in the access list. Range is 1 to 2147483644. (By default, the first statement is number 10, and the subsequent statements are incremented by 10.)

---



<i>source</i>	<p>Number of the network or host from which the packet is being sent. There are three alternative ways to specify the source:</p> <ul style="list-style-type: none"> <li>• Use a 32-bit quantity in four-part dotted-decimal format.</li> <li>• Use the <b>any</b> keyword as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of 0.0.0.0 255.255.255.255.</li> <li>• Use the <b>host source</b> combination as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of <i>source</i> 0.0.0.0.</li> </ul>
<i>source-wildcard</i>	<p>Wildcard bits to be applied to the source. There are three alternative ways to specify the source wildcard:</p> <ul style="list-style-type: none"> <li>• Use a 32-bit quantity in four-part dotted-decimal format. Place ones in the bit positions you want to ignore.</li> <li>• Use the <b>any</b> keyword as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of 0.0.0.0 255.255.255.255.</li> <li>• Use the <b>host source</b> combination as an abbreviation for a <i>source</i> and <i>source-wildcard</i> of <i>source</i> 0.0.0.0.</li> </ul>
<i>protocol</i>	<p>Name or number of an IP protocol. It can be one of the keywords <b>ahp</b>, <b>esp</b>, <b>gre</b>, <b>icmp</b>, <b>igmp</b>, <b>igrp</b>, <b>ip</b>, <b>ipinip</b>, <b>nos</b>, <b>ospf</b>, <b>pim</b>, <b>pcp</b>, <b>tcp</b>, or <b>udp</b>, or an integer from 0 to 255 representing an IP protocol number. To match any Internet protocol (including ICMP, TCP, and UDP), use the <b>ip</b> keyword. ICMP, and TCP allow further qualifiers, which are described later in this table.</p> <p><b>Note</b> Filtering on AHP protocol is not supported.</p>

---

*destination*

Number of the network or host to which the packet is being sent. There are three alternative ways to specify the destination:

- Use a 32-bit quantity in four-part dotted-decimal format.
- Use the **any** keyword as an abbreviation for the *destination* and *destination-wildcard* of 0.0.0.0 255.255.255.255.
- Use the **host destination** combination as an abbreviation for a *destination* and *destination-wildcard* of *destination* 0.0.0.0.

---

*destination-wildcard*

Wildcard bits to be applied to the destination. There are three alternative ways to specify the destination wildcard:

- Use a 32-bit quantity in four-part dotted-decimal format. Place ones in the bit positions you want to ignore.
- Use the **any** keyword as an abbreviation for a *destination* and *destination-wildcard* of 0.0.0.0 255.255.255.255.
- Use the **host destination** combination as an abbreviation for a *destination* and *destination-wildcard* of *destination* 0.0.0.0.

---

**nexthop1, nexthop2, nexthop3**

Specifies the next hop for this entry.

**Note** You must specify the VRF for all nexthops unless the nexthop is in the default VRF.

---

---

**precedence** *precedence*

(Optional) Packets can be filtered by precedence level (as specified by a number from 0 to 7) or by the following names:

- **Routine** —Match packets with routine precedence (0)
  - **priority** —Match packets with priority precedence (1)
  - **immediate** —Match packets with immediate precedence (2)
  - **flash** —Match packets with flash precedence (3)
  - **flash-override** —Match packets with flash override precedence (4)
  - **critical** —Match packets with critical precedence (5)
  - **internet** —Match packets with internetwork control precedence (6)
  - **network** —Match packets with network control precedence (7)
-

---

**dscp** *dscp*

(Optional) Differentiated services code point (DSCP) provides quality of service control. The values for *dscp* are as follows:

- 0–63—Differentiated services codepoint value
  - af11—Match packets with AF11 dscp (001010)
  - af12—Match packets with AF12 dscp (001100)
  - af13—Match packets with AF13 dscp (001110)
  - af21—Match packets with AF21 dscp (010010)
  - af22—Match packets with AF22 dscp (010100)
  - af23—Match packets with AF23 dscp (010110)
  - af31—Match packets with AF31 dscp (011010)
  - af32—Match packets with AF32 dscp (011100)
  - af33—Match packets with AF33 dscp (011110)
  - af41—Match packets with AF41 dscp (100010)
  - af42—Match packets with AF42 dscp (100100)
  - af43—Match packets with AF43 dscp (100110)
  - cs1—Match packets with CS1 (precedence 1) dscp (001000)
  - cs2—Match packets with CS2 (precedence 2) dscp (010000)
  - cs3—Match packets with CS3 (precedence 3) dscp (011000)
  - cs4—Match packets with CS4 (precedence 4) dscp (100000)
  - cs5—Match packets with CS5 (precedence 5) dscp (101000)
  - cs6—Match packets with CS6 (precedence 6) dscp (110000)
  - cs7—Match packets with CS7 (precedence 7) dscp (111000)
  - default—Default DSCP (000000)
  - ef—Match packets with EF dscp (101110)
-

---

**dscp range** *dscp dscp*

(Optional) Differentiated services code point (DSCP) provides quality of service control. The values for *dscp* are as follows:

- 0–63—Differentiated services codepoint value
  - af11—Match packets with AF11 dscp (001010)
  - af12—Match packets with AF12 dscp (001100)
  - af13—Match packets with AF13 dscp (001110)
  - af21—Match packets with AF21 dscp (010010)
  - af22—Match packets with AF22 dscp (010100)
  - af23—Match packets with AF23 dscp (010110)
  - af31—Match packets with AF31 dscp (011010)
  - af32—Match packets with AF32 dscp (011100)
  - af33—Match packets with AF33 dscp (011110)
  - af41—Match packets with AF41 dscp (100010)
  - af42—Match packets with AF42 dscp (100100)
  - af43—Match packets with AF43 dscp (100110)
  - cs1—Match packets with CS1 (precedence 1) dscp (001000)
  - cs2—Match packets with CS2 (precedence 2) dscp (010000)
  - cs3—Match packets with CS3 (precedence 3) dscp (011000)
  - cs4—Match packets with CS4 (precedence 4) dscp (100000)
  - cs5—Match packets with CS5 (precedence 5) dscp (101000)
  - cs6—Match packets with CS6 (precedence 6) dscp (110000)
  - cs7—Match packets with CS7 (precedence 7) dscp (111000)
  - default—Default DSCP (000000)
  - ef—Match packets with EF dscp (101110)
-

<b>fragments</b>	(Optional) Causes the software to examine noninitial fragments of IPv4 packets when applying this access list entry. When this keyword is specified, fragments are subject to the access list entry.
<b>log</b>	(Optional) Causes an informational logging message about the packet that matches the entry to be sent to the console. (The level of messages logged to the console is controlled by the <b>logging console</b> command.)
	<b>Note</b> ACL logging is supported only in ingress direction for both IPv4 and IPv6.
	The message includes the access list number, whether the packet was permitted or denied; the protocol, whether it was TCP, UDP, ICMP, or a number; and, if appropriate, the source and destination addresses and source and destination port numbers. The message is generated for the first packet that matches a flow, and then at 5-minute intervals, including the number of packets permitted or denied in the prior 5-minute interval.
<b>log-input</b>	(Optional) Provides the same function as the <b>log</b> keyword, except that the log-message also includes the input interface.
<b>ttl</b>	(Optional) Turns on matching against time-to-life (TTL) value.
<i>ttl value [value1 ... value2]</i>	(Optional) TTL value used for filtering. Range is 1 to 255.  If only <i>value</i> is specified, the match is against this value.  If both <i>value1</i> and <i>value2</i> are specified, the packet TTL is matched against the range of TTLs between <i>value1</i> and <i>value2</i> .
<i>icmp-type</i>	(Optional) ICMP message type for filtering ICMP packets. Range is from 0 to 255.

<i>icmp-code</i>	(Optional) ICMP message code for filtering ICMP packets. Range is from 0 to 255.
<i>igmp-type</i>	<p>(Optional) IGMP message type (0 to 15) or message name for filtering IGMP packets, as follows:</p> <ul style="list-style-type: none"> <li>• dvmrp</li> <li>• host-query</li> <li>• host-report</li> <li>• mtrace</li> <li>• mtrace-response</li> <li>• pim</li> <li>• precedence</li> <li>• trace</li> <li>• v2-leave</li> <li>• v2-report</li> <li>• v3-report</li> </ul>
<i>operator</i>	<p>(Optional) Operator is used to compare source or destination ports. Possible operands are <b>lt</b> (less than), <b>gt</b> (greater than), <b>eq</b> (equal), <b>neq</b> (not equal), and <b>range</b> (inclusive range).</p> <p>If the operator is positioned after the <i>source</i> and <i>source-wildcard</i> values, it must match the source port.</p> <p>If the operator is positioned after the <i>destination</i> and <i>destination-wildcard</i> values, it must match the destination port.</p> <p>If the operator is positioned after the <b>ttl</b> keyword, it matches the TTL value.</p> <p>The <b>range</b> operator requires two port numbers. All other operators require one port number.</p>
<i>port</i>	<p>Decimal number a TCP or UDP port. Range is 0 to 65535.</p> <p>TCP ports can be used only when filtering TCP. UDP ports can be used only when filtering UDP.</p>

<i>protocol-port</i>	Name of a TCP or UDP port. TCP and UDP port names are listed in the “Usage Guidelines” section.  TCP port names can be used only when filtering TCP. UDP port names can be used only when filtering UDP.
<b>established</b>	(Optional) For the TCP protocol only: Indicates an established connection.
<b>match-any</b>	(Optional) For the TCP protocol only: Filters on any combination of TCP flags.
<b>match-all</b>	(Optional) For the TCP protocol only: Filters on all TCP flags.
+   -	(Required) For the TCP protocol <b>match-any</b> , <b>match-all</b> : Prefix <i>flag-name</i> with + or - . Use the + <i>flag-name</i> argument to match packets with the TCP flag set. Use the - <i>flag-name</i> argument to match packets when the TCP flag is not set.
<i>flag-name</i>	(Optional) For the TCP protocol <b>match-any</b> , <b>match-all</b> . Flag names are: <b>ack</b> , <b>fin</b> , <b>psh</b> , <b>rst</b> , <b>syn</b> , <b>urg</b> .

**Command Default** ICMP message generation is enabled by default.

**Command Modes** IPv4 access list configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
	Release 7.8.1	<b>log-input</b> keyword was introduced.
	Release 7.5.4	<b>bitmask</b> keyword was introduced.

**Usage Guidelines** Use the **permit** command following the **ipv4 access-list** command to specify conditions under which a packet can pass the access list.

By default, the first statement in an access list is number 10, and the subsequent statements are incremented by 10.



You can add **permit**, **deny**, or **remark** statements to an existing access list without retyping the entire list. To add a new statement anywhere other than at the end of the list, create a new statement with an appropriate entry number that falls between two existing entry numbers to indicate where it belongs.



---

**Note** If any ACE in an ACL contains ABF clause, this ACL cannot be applied at any non-zero compression level.

---

The following is a list of precedence names:

- critical
- flash
- flash-override
- immediate
- internet
- network
- priority
- routine

The following is a list of ICMP message type names:

- administratively-prohibited
- alternate-address
- conversion-error
- dod-host-prohibited
- dod-net-prohibited
- echo
- echo-reply
- general-parameter-problem
- host-isolated
- host-precedence-unreachable
- host-redirect
- host-tos-redirect
- host-tos-unreachable
- host-unknown
- host-unreachable
- information-reply
- information-request
- mask-reply
- mask-request
- mobile-redirect
- net-redirect
- net-tos-redirect
- net-tos-unreachable
- net-unreachable
- network-unknown
- no-room-for-option
- option-missing
- packet-too-big

- parameter-problem
- port-unreachable
- precedence-unreachable
- protocol-unreachable
- reassembly-timeout
- redirect
- router-advertisement
- router-solicitation
- source-quench
- source-route-failed
- time-exceeded
- timestamp-reply
- timestamp-request
- traceroute
- ttl-exceeded
- unreachable

The following is a list of TCP port names that can be used instead of port numbers. Refer to the current *Assigned Numbers* RFC to find a reference to these protocols. You can find port numbers corresponding to these protocols by typing a ? in the place of a port number.

- bgp
- chargen
- cmd
- daytime
- discard
- domain
- echo
- exec
- finger
- ftp
- ftp-data
- gopher
- hostname
- ident
- irc
- klogin
- kshell
- login
- lpd
- nntp
- pim-auto-rp
- pop2
- pop3
- smtp
- sunrpc
- tacacs

- talk
- telnet
- time
- uucp
- whois
- www

The following UDP port names can be used instead of port numbers. Refer to the current *Assigned Numbers* RFC to find a reference to these protocols. You can find port numbers corresponding to these protocols by typing a ? in the place of a port number.

- biff
- bootpc
- bootps
- discard
- dnsix
- domain
- echo
- isakmp
- mobile-ip
- nameserver
- netbios-dgm
- netbios-ns
- netbios-ss
- ntp
- pim-auto-rp
- rip
- snmp
- snmptrap
- sunrpc
- syslog
- tacaacs
- talk
- tftp
- time
- who
- xdmcp

Use the following flags in conjunction with the **match-any** and **match-all** keywords and the + and - signs to select the flags to display:

- ack
- fin
- psh
- rst
- syn

For example, **match-all** +ack +syn displays TCP packets with both the ack *and* syn flags set, or **match-any** +ack - - syn displays the TCP packets with the ack set *or* the syn not set.

Task ID	Task ID	Operations
	ipv4	read, write
	acl	read, write

## Examples

The following example shows how to set a permit condition for an access list named Internetfilter:

```
Router(config)# ipv4 access-list Internetfilter
Router(config-ipv4-acl)# 10 permit 192.168.34.0 0.0.0.255
Router(config-ipv4-acl)# 20 permit 172.16.0.0 0.0.255.255
Router(config-ipv4-acl)# 25 permit tcp host 172.16.0.0 eq bgp host 192.168.202.203 range
1300 1400
Router(config-ipv4-acl)# deny 10.0.0.0 0.255.255.255
```

This example shows how you can configure DSCP bitmask on ingress ERSPAN.

```
Router# config
Router(config)# ipv4 access-list acl1
Router(config-ipv4-acl)# 10 permit ipv4 host 192.0.2.1 any dscp af22 bitmask 0x3f
Router(config-ipv4-acl)# commit
Router(config-ipv4-acl)# exit
Router(config)# interface HundredGigE0/0/0/6
Router(config-if)# ipv4 address 192.0.2.51 255.255.255.0
Router(config-if)# monitor-session TEST ethernet direction rx-only port-level acl ipv4 acl1
Router(config-if)# commit
```

## permit (IPv6)

To set permit conditions for an IPv6 access list, use the **permit** command in IPv6 access list configuration mode. To remove the permit conditions, use the **no** form of this command.

```
[sequence-number] permit source { source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/prefix-length } [ operator { port | protocol-port } ] [ dscp value [ bitmask value
] ] [ routing ] [ hop-by-hop ] [ authen ] [ destopts ] [ fragments ] [ packet-length operator
packet-length value ] [ log | log-input ]
[sequence-number] permit protocol { source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/prefix-length } { source-ipv6-prefix/ prefix-length | any | host source-ipv6-address } [
operator { port | protocol-port } ] [ dscp value [ bitmask value ] ] [ routing ] [ hop-by-hop ]
[ authen ] [ destopts ] [ fragments ] [ packet-length operator packet-length value ] [ log |
log-input ]
[ttl ttl value [ value1 . . . value2 ] ]
no sequence-number
```

### Internet Control Message Protocol (ICMP)

```
[ sequence-number] permit icmp {source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/prefix-length} {source-ipv6-prefix/ prefix-length | any | host source-ipv6-address }
{destination-ipv6-prefix/ prefix-length | any | host destination-ipv6-address
ipv6-wildcard-mask/prefix-length} [icmp-type] [ icmp-code] [dscp value] [ routing] [hop-by-hop]
[authen] [destopts] [ fragments] [ log]
```

### Transmission Control Protocol (TCP)

```
[sequence-number] permit tcp {source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/prefix-length} [operator {port | protocol-port}] {destination-ipv6-prefix/ prefix-length
/ any | host destination-ipv6-address ipv6-wildcard-mask/prefix-length} [operator {port | protocol | port}]
[dscp value] [routing] [hop-by-hop] [authen] [destopts] [fragments] [established] {match-any
| match-all | + | -} [flag-name] [log]
```

### User Datagram Protocol (UDP)

```
[sequence-number] permit tcp {source-ipv6-prefix/ prefix-length | any | host source-ipv6-address
ipv6-wildcard-mask/prefix-length} [operator {port | protocol-port}] {destination-ipv6-prefix/ prefix-length
/ any | host destination-ipv6-address ipv6-wildcard-mask/prefix-length} [operator {port | protocol | port}]
[dscp value] [routing] [hop-by-hop] [authen] [destopts] [fragments] [established] [flag-name]
[log]
```

#### Syntax Description

sequence-number	(Optional) Number of the <b>permit</b> statement in the access list. This number determines the order of the statements in the access list. Range is from 1 to 2147483644. (By default, the first statement is number 10, and the subsequent statements are incremented by 10.)
-----------------	---

protocol	Name or number of an Internet protocol. It can be one of the keywords <b>ahp</b> , <b>esp</b> , <b>gre</b> , <b>icmp</b> , <b>igmp</b> , <b>igrp</b> , <b>isinip</b> , <b>ipv6</b> , <b>nos</b> , <b>ospf</b> , <b>pcp</b> , <b>sctp</b> , <b>tcp</b> , or <b>udp</b> , or an integer that ranges from 0 to 255, representing an IPv6 protocol number.
<i>source-ipv6-prefix / prefix-length</i>	Source IPv6 network or class of networks about which permit conditions are to be set.  This argument must be in the form documented in RFC 2373, where the address is specified in hexadecimal using 16-bit values between colons.
any	An abbreviation for the IPv6 prefix <code>::/0</code> .
<b>host</b> <i>source-ipv6-address</i>	Source IPv6 host address about which to set permit conditions.  This <i>source-ipv6-address</i> argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
<i>ipv6-wildcard-mask</i>	IPv6 wildcard mask. The IPv6 wildcard mask can take any IPv6 address value which is used instead of prefix length.

<i>operator</i> { <i>port</i>   <i>protocol-port</i> }	<p>(Optional) Operand that compares the source or destination ports of the specified protocol. Operands are <b>lt</b> (less than), <b>gt</b> (greater than), <b>eq</b> (equal), <b>neq</b> (not equal), and <b>range</b> (inclusive range).</p> <p>If the operator is positioned after the <i>source-ipv6-prefix</i> / <i>prefix-length</i> argument, it must match the source port.</p> <p>If the operator is positioned after the <i>destination-ipv6-prefix</i> / <i>prefix-length</i> argument, it must match the destination port.</p> <p>The <b>range</b> operator requires two port numbers. All other operators require one port number.</p> <p>The <i>port</i> argument is the decimal number of a TCP or UDP port. A port number is a number whose range is from 0 to 65535. The <i>protocol-port</i> argument is the name of a TCP or UDP port. TCP port names can be used only when filtering TCP. UDP port names can be used only when filtering UDP.</p>
<i>destination-ipv6-prefix</i> / <i>prefix-length</i>	<p>Destination IPv6 network or class of networks about which permit conditions are to be set.</p> <p>This argument must be in the form documented in RFC 2373, where the address is specified in hexadecimal using 16-bit values between colons.</p>
<b>host</b> <i>destination-ipv6-address</i>	<p>Specifies the destination IPv6 host address about which permit conditions are to be set.</p> <p>This <i>destination-ipv6-address</i> argument must be in the form documented in RFC 2373, where the address is specified in hexadecimal using 16-bit values between colons.</p>

<b>dscp</b> <i>value</i>	(Optional) Matches a differentiated services code point (DSCP) value against the traffic class value in the Traffic Class field of each IPv6 packet header. Range is from 0 to 63.
routing	(Optional) Matches source-routed packets against the routing extension header within each IPv6 packet header.
hop-by-hop	(Optional) Supports Jumbo-grams. With the Router Alert option, it is an integral part in the operation of Multicast Listener Discovery (MLD). Router Alert [3] is an integral part in the operations of IPv6 Multicast through MLD and RSVP for IPv6.
authen	(Optional) Matches if the IPv6 authentication header is present.
destopts	(Optional) Matches if the IPv6 destination options header is present.
fragments	(Optional) Matches noninitial fragmented packets where the fragment extension header contains a nonzero fragment offset. The <b>fragments</b> keyword is an option available only if the <i>operator</i> [ <i>port-number</i> ] arguments are not specified.



<b>log</b>	<p>(Optional) Causes an informational logging message about the packet that matches the entry to be sent to the console. (The level of messages logged to the console is controlled by the <b>logging console</b> command.)</p> <p><b>Note</b> ACL logging is supported only in ingress direction for both IPv4 and IPv6.</p> <p>The message includes the access list name and sequence number, and whether the packet is permitted; the protocol, and whether it is TCP, UDP, ICMP, or a number; and, if appropriate, the source and destination addresses and source and destination port numbers. The message is generated for the first matching packet, and then at 5-minute intervals, including the number of packets permitted in the prior 5-minute interval.</p>
<b>log-input</b>	<p>(Optional) Provides the same function as the <b>log</b> keyword, except that the log-message also includes the input interface.</p>
<b>ttl</b>	<p>(Optional) Turns on matching against time-to-life (TTL) value. For IPv6 packets, <b>tll</b> is also referred to as hop limit.</p>
<i>ttl value [value1 ... value2]</i>	<p>(Optional) TTL value used for filtering. Range is 1 to 255.</p> <p>If only <i>value</i> is specified, the match is against this value.</p> <p>If both <i>value1</i> and <i>value2</i> are specified, the packet TTL is matched against the range of TTLs between <i>value1</i> and <i>value2</i> .</p>
operator	<p>(Optional) Operand that compares the source or destination ports of the specified protocol. Operands are <b>lt</b> (less than), <b>gt</b> (greater than), <b>eq</b> (equal), <b>neq</b> (not equal), and <b>range</b> (inclusive range).</p>

icmp-type	(Optional) ICMP message type for filtering ICMP packets. Range is from 0 to 255.
icmp-code	(Optional) ICMP message code for filtering ICMP packets. Range is from 0 to 255.
established	(Optional) For the TCP protocol only: Indicates an established connection.
match-any	(Optional) For the TCP protocol only: Filters on any combination of TCP flags.
match-all	(Optional) For the TCP protocol only: Filters on all TCP flags.
+   -	(Required) For the TCP protocol <b>match-any</b> , <b>match-all</b> : Prefix <i>flag-name</i> with + or - . Use the + <i>flag-name</i> argument to match packets with the TCP flag set. Use the - <i>flag-name</i> argument to match packets when the TCP flag is not set.
flag-name	(Required) For the TCP protocol <b>match-any</b> , <b>match-all</b> . Flag names are: <b>ack</b> , <b>fin</b> , <b>psh</b> , <b>rst</b> , <b>syn</b> , <b>urg</b> .

**Command Default** ICMP message generation is enabled by default.

**Command Modes** IPv6 access list configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.
	Release 7.2.1	Ingress IPv6 TCP flags are supported.
	Release 7.3.15	Egress IPv6 TCP flags are supported.
	Release 7.8.1	<b>log-input</b> keyword was introduced.
	Release 7.8.1	<b>tll</b> keyword was introduced.
	Release 7.5.4	<b>bitmask</b> keyword was introduced.

Release	Modification
Release 7.10.1	IPv6 AHP and ESP headers are supported.

### Usage Guidelines

The **permit** (IPv6) command is similar to the **permit** (IPv4) command, except that it is IPv6-specific.

Use the **permit** (IPv6) command following the **ipv6 access-list** command to define the conditions under which a packet passes the access list.

Specifying **ipv6** for the *protocol* argument matches against the IPv6 header of the packet.

By default, the first statement in an access list is number 10, and the subsequent statements are numbered in increments of 10.

You can add **permit**, **deny**, or **remark** statements to an existing access list without retyping the entire list. To add a new statement anywhere other than the end of the list, create a new statement with an appropriate entry number that falls between two existing entry numbers to indicate where it belongs.

Both the *source-ipv6-prefix/prefix-length* and *destination-ipv6-prefix/prefix-length* arguments are used for traffic filtering (the source prefix filters traffic based upon the traffic source; the destination prefix filters traffic based upon the traffic destination).



**Note** IPv6 prefix lists, and not access lists, should be used for filtering routing protocol prefixes.

The **fragments** keyword is an option available only if the *operator* [*port* | *protocol-port*] arguments are not specified.

### Task ID

Task ID	Operations
acl	read, write

### Examples

This example shows how to configure the IPv6 access list named v6-abf-acl and apply the access list to inbound traffic on HundredGigE interface 0/0/2/0.

```
Router(config)# ipv6 access-list v6-abf-acl
Router(config-ipv6-acl)# 10 permit ipv6 any any
Router(config-ipv6-acl)# 20 permit ipv4 any any
Router(config)# interface HundredGigE 0/0/2/0
Router(config-if)# ipv6 access-group v6-abf-acl ingress
```

The following example shows how to configure the IPv6 access list named toCISCO and apply the access list to the traffic entering the HundredGigE interface 0/2/0/2. Specifically, the permit entry in the list allows all packets that have a hop-by-hop optional field from entering the HundredGigE interface 0/2/0/2.

```
Router(config)# ipv6 access-list toCISCO
Router(config-ipv6-acl)# permit ipv6 any any hop-by-hop
Router(config)# interface HundredGigE 0/2/0/2
Router(config-if)# ipv6 access-group toCISCO ingress
```

The following example shows how you can configure DSCP bitmask on ingress ERSPAN.

```
Router# config
Router(config)# ipv6 access-list acl1
Router(config-ipv6-acl)# 10 permit ipv6 host 2001:DB8::2/32 any dscp 33 bitmask 0x3f
Router(config-ipv6-acl)# commit
Router(config-ipv6-acl)# exit
Router(config)# interface HundredGigE 0/0/10/3
Router(config-if)# ipv6 address 2001:DB8::1/32
Router(config-if)# monitor-session TEST ethernet direction rx-only port-level acl ipv6 acl1
Router(config-if)# commit
```

The following example shows how you can configure AHP and ESP headers on an ACLs.

```
Router(config)# #ipv6 access-list ipv6_umpp_access_list
Router(config-ipv6-acl)# 12 permit ahp any any
Router(config-ipv6-acl)# ipv6 access-list ipv6_umpp_access_list
Router(config-ipv6-acl)# 14 permit esp any any
Router(config-ipv6-acl)# commit
Router(config-ipv6-acl)# exit
```

## show access-lists ipv4

To display the contents of current IPv4 access lists, use the **show access-lists ipv4** command in XR EXEC mode.

```
show access-lists ipv4 [access-list-name hardware {ingress|egress} [interface type interface-path-id]
{sequence number | location node-id | [usage pfilter { location node-id } ]}]
```

Syntax	Description
<i>access-list-name</i>	(Optional) Name of a particular IPv4 access list. The name cannot contain spaces or quotation marks, but can include numbers.
<b>hardware</b>	(Optional) Identifies the access list as an access list for an interface.
<b>ingress</b>	(Optional) Specifies an inbound interface.
<b>interface</b>	(Optional) Displays interface statistics.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>sequence</b> <i>number</i>	(Optional) Sequence number of a particular IPv4 access list. Range is 1 to 2147483644.
<b>location</b> <i>node-id</i>	(Optional) Location of a particular IPv4 access list. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>summary</b>	(Optional) Displays a summary of all current IPv4 access lists.

<i>sequence-number</i>	(Optional) Sequence number of a particular IPv4 access list. Range is 1 to 2147483644.
<b>usage</b>	(Optional) Displays the usage of the access list on a given line card.
<b>pfilter</b>	(Optional) Displays the packet filtering usage for the specified line card.

**Command Default** The default displays all IPv4 access lists.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show access-lists ipv4** command to display the contents of all IPv4 access lists. To display the contents of a specific IPv4 access list, use the *name* argument. Use the *sequence-number* argument to specify the sequence number of the access list.

Use the **hardware**, **ingress** and **location** keywords to display the access list hardware contents and counters for all interfaces that use the specified access list in a given direction. To display the contents of a specific access list entry, use the **sequence number** keyword and argument. The access group for an interface must be configured using the **ipv4 access-group** command for access list hardware counters to be enabled.

Use the **show access-lists ipv4 summary** command to display a summary of all current IPv4 access lists. To display a summary of a specific IPv4 access list, use the *name* argument.

Use the **show access-list ipv4 usage** command to display a summary of all interfaces and access lists programmed on the specified line card.

Task ID	Task ID	Operations
	acl	read

### Examples

In the following example, the contents of all IPv4 access lists are displayed:

```
Router# show access-lists ipv4

ipv4 access-list test_ipv4
 10 permit ipv4 any any
 20 deny tcp any eq 2000 any eq 2000
 30 permit tcp any eq 3000 any eq 3000
```

This table describes the significant fields shown in the display.

**Table 2: show access-lists ipv4 hardware Field Descriptions**

Field	Description
hw matches	Number of hardware matches.
ACL name	Name of the ACL programmed in hardware.
Sequence Number	Each ACE sequence number is programmed into hardware with all the fields that are corresponding to the values set in ACE.
Grant	Depending on the ACE rule, the grant is set to deny, permit, or both.
Logging	Logging is set to on if ACE uses a log option to enable logs.
Per ace icmp	If Per ace icmp is set to on in the hardware, ICMP is unreachable, is rate-limited, and is generated. The default is set to on.
Hits	Hardware counter for that ACE.

In the following example, a summary of all IPv4 access lists are displayed:

```
Router# show access-lists ipv4 summary
```

```
ACL Summary:
  Total ACLs configured: 3
  Total ACEs configured: 11
```

This table describes the significant fields shown in the display.

**Table 3: show access-lists ipv4 summary Field Descriptions**

Field	Description
Total ACLs configured	Number of configured IPv4 ACLs.
Total ACEs configured	Number of configured IPV4 ACEs.

This example displays the packet filtering usage for the specified line card:

```
Router# show access-lists ipv4 usage pfilter location 0/RP0/CPU0

Interface : HundredGigE0/0/0/10/0
Input ACL : Common-ACL : N/A ACL : test_ipv4
Output ACL : N/A
```



**Note** To display the packet filtering usage for bundle interfaces, use the **show access-lists ipv4 usage pfilter location all** command.

## show access-lists ipv6

To display the contents of current IPv6 access lists, use the **show access-lists ipv6** command in XR Config mode.

```
show access-lists ipv6 [access-list-name hardware {ingress|egress} [interface type interface-path-id]
{sequence number | location node-id | [usage pfilter { location node-id }]]]
```

### Syntax Description

<i>access-list-name</i>	(Optional) Name of a particular IPv6 access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<b>hardware</b>	(Optional) Identifies the access list as an access list for an interface.
<b>ingress</b>	(Optional) Specifies an inbound interface.
<b>interface</b>	(Optional) Displays interface statistics.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	(Optional) Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0) and the module is CPU0. Example: interface MgmtEth0/RSP0/CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>sequence</b> <i>number</i>	(Optional) Sequence number of a particular IPv6 access list. Range is 1 to 2147483644.
<b>location</b> <i>node-id</i>	(Optional) Location of a particular IPv6 access list. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>summary</b>	(Optional) Displays a summary of all current IPv6 access lists.
<i>sequence-number</i>	(Optional) Sequence number of a particular IPv6 access list. Range is 1 to 2147483644.
<b>usage</b>	(Optional) Displays the usage of the access list on a given line card.



<b>pfilter</b>	(Optional) Displays the packet filtering usage for the specified line card.
<b>all</b>	(Optional) Displays the location of all the line cards.

**Command Default** Displays all IPv6 access lists.

**Command Modes** XR Config mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **show access-lists ipv6** command is similar to the **show access-lists ipv4** command, except that it is IPv6 specific.

Use the **show access-lists ipv6** command to display the contents of all IPv6 access lists. To display the contents of a specific IPv6 access list, use the *name* argument. Use the *sequence-number* argument to specify the sequence number of the access list.

Use the **hardware**, **ingress** and **location** keywords to display the access list hardware contents and counters for all interfaces that use the specified access list in a given direction. To display the contents of a specific access list entry, use the **sequence number** keyword and argument. The access group for an interface must be configured using the **ipv6 access-group** command for access list hardware counters to be enabled.

Use the **show access-lists ipv6 summary** command to display a summary of all current IPv6 access lists. To display a summary of a specific IPv6 access list, use the *name* argument.

Use the **show access-list ipv6 usage** command to display a summary of all interfaces and access lists programmed on the specified line card.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read

## Examples

In the following example, the IPv6 ACL is configured with the source IPv6 wildcard mask FF:0:FFFF:AA:20 and the destination wildcard mask 0:FFFF:2233::FFFF, the show command displays these wildcard mask:

```
Router# config
Router(config)# ipv6 access-list acl1
Router(config-ipv6-acl)# permit 1:2::3 FF:0:FFFF:AA:20:: 4:5::6 0:FFFF:2233::FFFF
Router(config-ipv6-acl)# commit
Router# show run ipv6 access-list
ipv6 access-list ACL1
  10 permit ipv6 1:2::3 ff:0:ffff:aa:20:: 4:5::6 0:ffff:2233::ffff
```

In the following example, the contents of all IPv6 access lists are displayed:

```
Router# show access-lists ipv6

ipv6 access-list test_ipv6
```

```

10 permit ipv6 any any
20 permit tcp any eq 3000 any eq 3000

```

In the following example, the contents of an access list named Internetfilter is displayed:

```

Router# show access-lists ipv6 Internetfilter

ipv6 access-list Internetfilter
 3 remark Block BGP traffic from a given host
 4 deny tcp host 6666:1:2:3::10 eq bgp host 7777:1:2:3::20 range 1300 1404 deny tcp host
171.69.2.88 255.255.0.0 any eq telnet
 20 permit ipv6 3333:1:2:3::/64 any
 25 permit ipv6 4444:1:2:3::/64 any
 30 permit ipv6 5555:1:2:3::/64 any

```

This table describes the significant fields shown in the display.

**Table 4: show access-lists ipv6 hardware Command Field Descriptions**

Field	Description
hw matches	Number of hardware matches.

In the following example, a summary of all IPv6 access lists is displayed:

```

Router# show access-lists ipv6 summary

ACL Summary:
  Total ACLs configured: 3
  Total ACEs configured: 11

```

This table describes the significant fields shown in the display.

**Table 5: show access-lists ipv6 summary Command Field Descriptions**

Field	Description
Total ACLs configured	Number of configured IPv6 ACLs.
Total ACEs configured	Number of configured IPv6 ACEs.

In the following example, the OOR details of the IPv6 access lists are displayed:

```

Router# show access-lists ipv6 maximum detail

Default max configurable acls :1000
Default max configurable aces :50000
Current configured acls      :1
Current configured aces      :2
Current max configurable acls :1000
Current max configurable aces :50000
Max configurable acls        :2000
Max configurable aces        :100000

```

This example displays the packet filtering usage for the specified line card:

```
Router# show access-lists ipv6 usage pfilter location 0/0/CPU0
```

```
Interface : HundredGigE0/0/0/10/0  
Input ACL : Common-ACL : N/A ACL : test_ipv6  
Output ACL : N/A
```

This example displays the ABF ACL match counter statistics when the **show access-lists ipv6** command is used with the **hardware** option.

```
Router# show access-lists ipv6 abf_1_v6 hardware ingress location 0/RP0/CPU0
```

```
Fri Sep 27 17:18:19.288 PDT  
ipv6 access-list abf_1_v6  
 5 permit ipv6 any 2001:150:25:207::/64 (1883512876 matches) (next-hop:  
addr=2620:149:bb:3210::90, vrf name=default)  
10 permit ipv6 any any (153796235 matches)
```

# show tech-support access-lists

To automatically collect information about Ethernet Services, IPV4, IPV6, and Platform dependent ACL related information, use the **show tech-support access-lists** command in configuration mode.

**show tech-support access-lists** { **ethernet-services** | **ipv4** | **ipv6** | **platform** }

Syntax Description		
	<b>ethernet-services</b>	Collects information regarding the ethernet-services access lists in the router.
	<b>ipv4</b>	Collects information regarding the ipv4 access lists in the router.
	<b>ipv6</b>	Collects information regarding the ipv6 access lists in the router.
	<b>platform</b>	Collects information regarding the platform specific access lists in the router.

**Command Default** None

**Command Modes** Configuration mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

## Usage Guidelines

- To use commands, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.
- This command generates tech-support information that is useful for Cisco Technical Support representatives when troubleshooting a router. By default, the output of this command is saved on the router's hard disk in a file with *.tgz* extension. You can share this file with Cisco Technical Support. To share, use the **copy** command to copy the *.tgz* file to a server or local machine. For example, **copy harddisk:/showtech/ name.tgz tftp:// server\_path** .
- This command is not required during normal use of the router.

Task ID	Task ID	Operations
	acl	read

## Examples

The following example shows the output of the **show tech-support access-lists** command:

```
Router# show tech-support access-lists ipv4
Thu Oct 20 10:38:18.041 PDT
++ Show tech start time: 2022-Oct-20.103818.PDT ++
Thu Oct 20 10:38:18 PDT 2022 Waiting for gathering to complete
.....
Thu Oct 20 10:38:33 PDT 2022 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-M8102TOR1-ipv4-acl-2022-Oct-20.103818.PDT.tgz
++ Show tech end time: 2022-Oct-20.103833.PDT ++
```

## tcam format access-list (ipv4 and ipv6)

To configure the object group ACLs for IPv4 and IPv6 using the user-defined TCAM keys (UDK), use the **hw-module profile tcam format access-list ipv4** command and **hw-module profile tcam format access-list ipv6** in XR Config mode.

Syntax for IPv4:

```
hw-module profile tcam format access-list ipv4
```

Syntax Description		
	<b>dst-addr</b>	Specifies destination address. This is a 32-bit qualifier for IPv4 ACLs.
	<b>dst-object-group</b>	Specifies the destination object group.
	<b>dst-port</b>	Destination port for TCP/UDP. This is a 16-bit qualifier.
	<b>frag-bit</b>	Fragmentation bit for IPv4 ACLs. This is a 1-bit qualifier.
	<b>fragment-offset</b>	Specifies the fragment offset for IPv4 ACLs.
	<b>packet-len</b>	Specifies packet length for IPv4 ACLs. This is a 10-bit qualifier.
	<b>precedence</b>	Specifies DSCP precedence in IPv4 header. This is a 10-bit qualifier.
	<b>proto</b>	Specifies protocol type in IPv4 header. This is an 8-bit qualifier.
	<b>src-addr</b>	Specifies source address. This is a 32-bit qualifier for IPv4 ACLs.
	<b>src-object-group</b>	Specifies the source object group.
	<b>src-port</b>	Specifies source port for TCP/UDP. This is a 16-bit qualifier.
	<b>tcp-flags</b>	Specifies TCP Flags. This is a 6-bit qualifier for IPv4 ACLs.

Syntax for IPv6:

```
hw-module profile tcam format access-list ipv6
```

Syntax Description		
	<b>dst-addr</b>	Specifies destination address. This is a 128-bit qualifier for IPv6 ACLs.
	<b>dst-object-group</b>	Specifies the destination object group.
	<b>dst-port</b>	Destination port for TCP/UDP. This is a 16-bit qualifier.
	<b>frag-bit</b>	Fragmentation bit for IPv6 ACLs. This is a 1-bit qualifier.
	<b>next-hdr</b>	(Mandatory) Specifies the next header field in IPv6 header. This is an 8-bit qualifier.
	<b>packet-len</b>	Specifies packet length for IPv6 ACLs. This is a 10-bit qualifier.
	<b>src-addr</b>	Specifies source address. This is a 128-bit qualifier for IPv6 ACLs.
	<b>src-object-group</b>	Specifies the source object group.

<b>src-port</b>	(Mandatory) Specifies source port for TCP/UDP. This is a 16-bit qualifier.
<b>tcp-flags</b>	Specifies TCP Flags. This is an 8-bit qualifier for IPv6 ACLs.
<b>traffic-class</b>	Specifies traffic class in IPv6 header. This is an 8-bit qualifier for IPv6 ACLs.

**Command Default**

None

**Command Modes**

XR Config mode

**Command History**

Release	Modification
Release 24.2.1	These commands were introduced.

**Usage Guidelines**

- Remove all ACL attachments to interfaces before the IPv4/IPv6 UDK configuration.
- Make sure that you reload the line card for this configuration to take effect.

**Task ID**

Task ID	Operations
acl	read, write
ipv4	read, write
ipv6	read, write

**Examples**

**Example 1:** In UDK, if only the **dst-object-group** is specified and the **src-object-group** is not specified, you compress only the destination address (compress level 4) as shown in this example.

```
Router(config)# hw-module profile tcam format access-list ipv4 src-addr src-port dst-port
proto tcp-flags frag-bit dst-object-group
Router(config)# hw-module profile tcam format access-list ipv6 src-addr src-port dst-port
next-hdr frag-bit tcp-flags dst-object-group

interface FH0/0/0/1
RP/0/RP0/CPU0:ios(config-if)#ipv6 access-group v6-test ingress compress level 4
```

**Example 2:** In UDK, if only the **src-object-group** is specified and the **dst-object-group** is not specified, you compress only the source address (compress level 1) as shown in this example.

```
Router(config)# hw-module profile tcam format access-list ipv4 src-object-group src-port
dst-port proto tcp-flags frag-bit dst-addr
Router(config)# hw-module profile tcam format access-list ipv6 src-object-group src-port
dst-port next-hdr frag-bit tcp-flags dst-addr

interface FH0/0/0/1
RP/0/RP0/CPU0:ios(config-if)#ipv4 access-group v4-test ingress compress level 1
```



---

**Note** By default, compression level 2 is supported for both the **src-object-group** and **dst-object-group** without the UDK configuration.

---





## ARP Commands

---

This chapter describes the commands used to configure and monitor the Address Resolution Protocol (ARP) on Cisco 8000 Series Routers.

For detailed information about ARP concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [arp](#), on page 84
- [arp cache-limit](#), on page 86
- [arp dagr](#), on page 87
- [arp gratuitous ignore](#), on page 88
- [arp learning](#), on page 89
- [arp police-interval](#), on page 90
- [arp purge-delay](#), on page 91
- [arp timeout](#), on page 92
- [clear arp-cache](#), on page 93
- [local-proxy-arp](#), on page 95
- [peer \(DAGR\)](#), on page 96
- [priority-timeout](#), on page 97
- [proxy-arp](#), on page 98
- [route distance](#), on page 99
- [route metric](#), on page 100
- [show arp](#), on page 101
- [show arp idb](#), on page 105
- [show arp dagr](#), on page 107
- [show arp traffic](#), on page 108
- [timers \(DAGR\)](#), on page 111

## arp

To add a permanent entry in the Address Resolution Protocol (ARP) cache, use the **arp** command in XR Config mode. To remove an entry from the ARP cache, enter the **no** form of this command.

```
arp [vrf vrf-name] ip-address hardware-address encapsulation-type [alias]
no arp [vrf vrf-name] ip-address hardware-address encapsulation-type [alias]
```

### Syntax Description

vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
vrf-name	(Optional) VRF instance that identifies a VPN.
ip-address	IPv4 (network layer) address for which a permanent entry is added to the ARP cache. Enter the IPv4 address in a four-part dotted-decimal format that corresponds to the local data-link address (a 32-bit address).
hardware-address	Hardware (data link layer) address that the IPv4 address is linked to. Enter the local data-link address (a 48-bit address), such as 0800.0900.1834.
encapsulation-type	Encapsulation type. The encapsulation types are: <ul style="list-style-type: none"> <li>• arpa</li> <li>• srp</li> <li>• srpa</li> <li>• srpb</li> </ul> <p>For Ethernet interfaces, this is typically the arpa keyword.</p>
alias	(Optional) Causes the software to respond to ARP requests as if it were the owner of both the specified IP address and hardware address, whether proxy ARP is enabled or not.

### Command Default

No entries are permanently installed in the ARP cache.

### Command Modes

XR Config mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

The software uses ARP cache entries to translate 32-bit IP addresses into 48-bit hardware addresses.

Because most hosts support dynamic resolution, you generally need not specify static ARP cache entries.

Static entries are permanent entries that map a network layer address (IPv4 address) to a data-link layer address (MAC address). If the **alias** keyword is specified when creating the entry, the interface to which the entry is attached will act as if it is the owner of the specified addresses, that is, it will respond to ARP request packets for this network layer address with the data link layer address in the entry.

The software does not respond to any ARP requests received for the specified IP address unless proxy ARP is enabled on the interface on which the request is received. When proxy ARP is enabled, the software responds to ARP requests with its own local interface hardware address.

To remove all nonstatic entries from the ARP cache, enter the `clear arp-cache` in XR EXEC mode.

Task ID	Task ID	Operations
	cef	read, write

### Examples

The following is an example of a static ARP entry for a typical Ethernet host:

```
Router# configure
Router(config)# arp 192.168.7.19 0800.0900.1834 arpa
```

# arp cache-limit

To configure a limit on ARP cache entries on the router, use the **arp cache-limit** command in interface configuration mode.

**arp cache-limit** *limit*

## Syntax Description

*limit* Specify the value for the cache entries. The supported range in the router is 0–127999.

**Note** The arp cache resources vary depending on the hardware resources available in a router. Ensure the cache-limit configured such that the available resources in the router are able to accommodate the entries.

## Command Default

By default, the ARP cache limit per interface in the router is 127999.

## Command Modes

Interface configuration

## Command History

Release	Modification
Release 7.9.1	This command was introduced.
Release 7.5.4	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Examples

The following example shows how to set the ARP cache limit for an interface:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/0
Router(config-if)#arp cache-limit 3900
Router(config-if)#commit
```

# arp dagr

To configure Direct Attached Gateway Redundancy (DAGR), use the **arp dagr** command in interface configuration mode.

## arp dagr

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	Disabled
------------------------	----------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	This command has no keywords or arguments.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	write

## Examples

The following example enables DAGR configuration:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/0
Router(config-if)# arp dagr
Router(config-if-dagr)#
```

## arp gratuitous ignore

To ignore receipt of gratuitous Address Resolution Protocol (ARP) packets, use the **arp gratuitous ignore** command in interface configuration mode. To receipt gratuitous ARP packets, use the no form of this command.

**arp gratuitous ignore**  
**no arp gratuitous ignore**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Disabled

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	write

**Examples** This example shows how to configure **arp gratuitous ignore** command:

```
Router# configure
Router(config)# interface HundredGigE 0/1/0/0
Router(config-if)# arp gratuitous ignore
```

# arp learning

To enable the dynamic learning of ARP entries for a local subnet or all subnets, use the **arp learning** command.

To disable this command, use the **no** prefix or the **disable** option for this command.

```
arp learning local
no arp learning local
arp learning disable
no arp learning disable
```

## Syntax Description

<b>local</b>	Enables the dynamic learning of ARP entries for local subnets.  When arp learning local is configured on an interface or sub-interface, it learns only the ARP entries from ARP packets on the same subnet.
<b>disable</b>	Disables the dynamic learning of all ARP entries.

## Command Default

This command has no keywords or arguments.

## Command Modes

Sub-interface configuration mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Task ID

Task ID	Operations
cef	write

The following example shows how to configure **arp learning local** command that enables the learning of ARP entries for only the local subnet:

```
Router(config)#interface HundredGigE 0/0/0/1
Router(config-if)# ipv4 address 192.0.2.1 255.255.255.0
Router(config-if)# arp learning local
Router(config-if)# no shut
Router(config-if)# commit
```

The following example shows how to configure **arp learning disable** command that disables the learning of all ARP entries.

```
Router(config)# interface HundredGigE 0/0/0/1
Router(config-if)# ipv4 address 192.0.2.1 255.255.255.0
Router(config-if)# arp learning disable
Router(config-if)# commit
```

# arp police-interval

To permit policing of duplicate ARP packets from the same sender protocol address (IP) or same source MAC address within the specified interval, use the **arp police-interval** command in the global configuration mode.

Behavior of the policer:

- When the **arp police-interval** command is configured, ARP requests coming from the same IP address or MAC address within the configured interval are dropped.
- If there was an ARP response existing for the ARP request from the same IP address within the configured interval, the new request will be dropped.
- If the ARP response was not existing already for the ARP request from the same IP address, then the MAC policer will be checked.

**arp police-interval** *interval*

---

**Syntax Description**     *interval* Specify the police interval value. The supported range is 1–60 seconds.

---



---

**Command Default**     Disabled

---

**Command Modes**     Global configuration mode

---

Command History	Release	Modification
	Release 7.8.1	This command was introduced.

---



---

**Usage Guidelines**     No specific guidelines impact the use of this command.

---

**Examples**     This example shows how to set the ARP police interval.

```
Router# configure
Router(config)#arp police-interval 34
Router(config)#commit
```



## arp purge-delay

To delay purging Address Resolution Protocol (ARP) entries when an interface goes down, use the **arp purge-delay** command in interface configuration mode. To turn off the purge delay feature, use the **no** form of this command.

```
arp purge-delay value
no arp purge-delay value
```

<b>Syntax Description</b>	<i>value</i> Sets the purge delay time in seconds. Range is 1 to 65535.
---------------------------	---

<b>Command Default</b>	Default value is off.
------------------------	-----------------------

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>arp purge-delay</b> command to delay purging ARP entries when an interface goes down. If the interface comes up within the delay time, then the ARP entries are restored to prevent packet loss with Equal Cost Multipath (ECMP) configured.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read, write

### Examples

The following is an example of setting the purge delay to 50 seconds:

```
Router# configure
Router(config)# interface HundredGigE 0/0/0/0
Router(config-if)# arp purge-delay 50
```

# arp timeout

To specify the duration of dynamic entries learned on an interface remain in the Address Resolution Protocol (ARP) cache, enter the **arp timeout** command in interface configuration mode. To remove the **arp timeout** command from the configuration file and restore the system to its default condition with respect to this command, enter the **no** form of this command.

**arp timeout** *seconds*

**no arp timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Indicates the time, in seconds, for which an entry remains in the ARP cache. Range is 30 to 4294967295.
---------------------------	--

<b>Command Default</b>	Entries remain in the ARP cache for 14,400 seconds (4 hours).
------------------------	---

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was supported.

<b>Usage Guidelines</b>	This command is ignored when issued on interfaces that do not use ARP. Also, ARP entries that correspond to the local interface or that are statically configured by the user never time out.
-------------------------	---

The **arp timeout** command applies only to the interface that is entered. When the timeout is changed for an interface the change applies only to that interface.

The **show interfaces** command displays the ARP timeout value in hours:minutes:seconds, as follows:

```
ARP type: ARPA, ARP Timeout 04:00:00
```

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read, write

## Examples

The following example shows how to set the ARP timeout to 3600 seconds to allow entries to time out more quickly than the default:

```
RP/0/RP0/CPU0:router#configure
RP/0/RP0/CPU0:router(config)#
RP/0/RP0/CPU0:router(config-if)# arp timeout 3600
```

# clear arp-cache

To delete all dynamic entries from the Address Resolution Protocol (ARP) cache, clear the fast-switching cache, and clear the IP route cache, use the **clear arp-cache** command in XR EXEC mode.

**clear arp-cache** {**traffic** *type interface-path-id* | **location** *node-id*}

## Syntax Description

<b>traffic</b>	Deletes traffic statistics on the specified interface.
<i>t type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface- path-id</i>	<p>Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>• Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li>• <i>rack</i>: Chassis number of the rack.</li> <li>• <i>slot</i>: Physical slot number of the modular services card or line card.</li> <li>• <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li>• <i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>• Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>location</b> <i>node-id</i>	Clears the ARP entries for a specified location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

No default behavior or values

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

When issued without keywords or arguments, the **clear arp-cache** command clears all entries in the ARP cache.

## Task ID

Task ID	Operations
cef	execute

---

**Examples**

The following example shows how to remove traffic statistic entries from the ARP cache that match the specified interface:

```
Router# clear arp-cache traffic HundredGige 0/1/0/0 location 0/1/CPU0
```

The following example shows how to remove entries from the ARP cache that match the specified location:

```
Router# clear arp-cache location 0/1/CPU0
```

# local-proxy-arp

To enable local proxy Address Resolution Protocol (ARP) on an interface, enter the **local-proxy-arp** command in interface configuration mode. To disable local proxy ARP on the interface, enter the **no** form of this command.

**local-proxy-arp**  
**no local-proxy-arp**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	Local proxy ARP is disabled on all interfaces.
------------------------	--

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	When local proxy ARP is enabled, the networking device responds to ARP requests that meet all the following conditions:
-------------------------	---

- The target IP address in the ARP request, the IP address of the ARP source, and the IP address of the interface on which the ARP request is received are on the same Layer 3 network.
- The next hop for the target IP address is through the same interface as the request is received.

Typically, local proxy ARP is used to resolve MAC addresses to IP addresses in the same Layer 3 network such as, private VLANs that are Layer 2-separated. Local proxy ARP supports all types of interfaces supported by ARP and unnumbered interfaces.

Using the **no** form of the command removes the specified command from the configuration file and restores the system to its default condition with respect to the command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read, write

## peer (DAGR)

To create a Direct Attached Gateway Redundancy (DAGR) group for a virtual IP address, use the **peer** command in DAGR interface configuration mode.

**peer ipv4** *IP-address*

<b>Syntax Description</b>	<i>IP-address</i> Virtual IPv4 address for the DAGR group.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	DAGR interface configuration
----------------------	------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	write

**Examples** The following example configures a DAGR group peer:

```
Router(config-if-dagr)# peer ipv4 192.168.7.19
Router(config-if-dagr-peer)#
```

# priority-timeout

To configure the timer to time out a high-priority Direct Attached Gateway Redundancy (DAGR) route and reverting to normal priority, use the **priority-timeout** command in DAGR peer interface configuration mode.

**priority-timeout** *time*

<b>Syntax Description</b>	<b>time</b> Time in seconds after which a high-priority route reverts to a normal priority route. The range of values is 1 to 10000.
---------------------------	--

<b>Command Default</b>	Default for <i>time</i> is 20 seconds.
------------------------	--

<b>Command Modes</b>	DAGR peer interface configuration
----------------------	-----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
-------------------------	--

When this function is applied, the DAGR group configuration is updated in the database.

The new timer values take effect the next time the timer is set. No immediate timer restarts are triggered on the basis of this event.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	write

## Examples

The following example configures a priority timeout of 25 seconds:

```
Router(config-if-dagr-peer) # priority-timeout 25
Router(config-if-dagr-peer) #
```

## proxy-arp

To enable proxy Address Resolution Protocol (ARP) on an interface, enter the **proxy-arp** command in interface configuration mode. To disable proxy ARP on the interface, enter the **no** form of this command.

**proxy-arp**  
**no proxy-arp**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	Proxy ARP is disabled on all interfaces.
------------------------	--

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	When proxy ARP is disabled, the networking device responds to ARP requests received on an interface only if one of the following conditions is met:
-------------------------	---

- The target IP address in the ARP request is the same as the interface IP address on which the request is received.
- The target IP address in the ARP request has a statically configured ARP alias.

When proxy ARP is enabled, the networking device also responds to ARP requests that meet all of the following conditions:

- The target IP address is not on the same physical network (LAN) on which the request is received.
- The networking device has one or more routes to the target IP address.
- All of the routes to the target IP address go through interfaces other than the one on which the request is received.

Using the **no** form of the command removes the specified command from the configuration file and restores the system to its default condition with respect to the command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read, write

### Examples

The following example shows how to enable proxy ARP on HundredGigE interface 0/0/0/0:

```
Router#(config)# interface HundredGigE 0/0/0/0
Router#(config-if)# proxy-arp
```



## route distance

To configure route distance for a given Direct Attached Gateway Redundancy (DAGR) group, use the **route distance** command in DAGR peer interface configuration mode.

**route distance normal** *normal-distance* **priority** *priority-distance*

<b>Syntax Description</b>	<b>normal</b> <i>normal-distance</i>	Sets normal route (administrative) distance. Range is 0 to 256.
---------------------------	--------------------------------------	---

	<b>priority</b> <i>priority-distance</i>	Sets priority route (administrative) distance. Range is 0 to 256.
--	--	---

<b>Command Default</b>	Default for <i>normal-distance</i> default is 150 and the default for <i>priority-distance</i> is 5.
------------------------	--

<b>Command Modes</b>	DAGR peer interface configuration
----------------------	-----------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The default setting for a priority distance takes precedence over that of a typical Internet Gateway Protocol (IGP). The normal distance setting does not.
-------------------------	--

When this setting is applied, the DAGR group is updated in the database.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	write

<b>Examples</b>	The following example configures a DAGR group peer with a normal route distance of 48 and priority route distance of 5:
-----------------	---

```
Router(config-if-dagr-peer) # route distance normal 48 priority 5
Router(config-if-dagr-peer) #
```

## route metric

To configure normal and priority route metrics for a given Direct Attached Gateway Redundancy (DAGR) group, use the **route metric** command in DAGR peer interface configuration mode.

**route metric normal** *normal-metric* **priority** *priority-metric*

<b>Syntax Description</b>	<b>normal</b> <i>normal-metric</i>	Sets a normal value for routes installed in the Routing Information Base (RIB). The range of values is 0 to 256.
	<b>priority</b> <i>priority-metric</i>	Sets a priority value for routes installed in the RIB. The range of values is 0 to 256.

**Command Default** The default for *normal-metric* is 100, and the default for *priority-metric* is 90.

**Command Modes** DAGR peer interface configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The route metric values are of less significance than the **route distance** command values. Setting a route metric allows the configuration of values for routers installed in the RIB. When this setting is applied, the DAGR group is updated in the database.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	write

**Examples** The following example configures a DAGR group peer with a normal metric of 48 and a priority metric of 5:

```
Router(config-if-dagr-peer)# route metric normal 48 priority 5
Router(config-if-dagr-peer)#
```

# show arp

To display the Address Resolution Protocol (ARP), enter the **show arp** command in XR EXEC mode.

```
show arp vrf vrf-name [ip-address hardware-address interface-path-id] location node-id
```

## Syntax Description

vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
vrf-name	(Optional) VRF instance that identifies a VPN.
ip-address	(Optional) The ARP entries you want to display.
hardware-address	(Optional) The ARP entries that match the 48-bit MAC address are displayed.
interface-path-id	(Optional) Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul>

For more information about the syntax for the router, use the question mark (?) online help function.

<b>location</b> node-id	(Optional) Displays the ARP entry for a specific location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
-------------------------	--

## Command Default

The active RSP is the default location.

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

ARP establishes correspondences between network addresses (an IP address, for example) and Ethernet hardware addresses. A record of each correspondence is kept in a cache for a predetermined amount of time and then discarded.

For **show arp** *interface-type interface-instance* form, the **location** *node-id* keyword and argument is mandatory for Bundle and VLAN-on-Bundle interfaces to indicate which location the cache entries for the bundle should be displayed. For physical interfaces, specifying the **location** *node-id* keyword and argument is optional since the interface can only exist on one node.

Task ID	Task ID	Operations
	cef	read

### Examples

The following is sample output from the **show arp** command with no location specified:

```
Router# show arp

0/7/CPU0
-----
Address          Age           Hardware Addr  State   Type   Interface
192.1.1.1.2      -            e4c7.2284.f863 Interface ARPA   HundredGigE0/7/0/3
192.1.1.2        -            e4c7.2284.f863 Interface ARPA   HundredGigE0/7/0/3.1
192.79.1.1       -            e4c7.2284.f887 Interface ARPA   HundresGigE0/7/0/39

0/RP0/CPU0
-----
Address          Age           Hardware Addr  State   Type   Interface
203.1.24.208    00:00:03     0016.9cf2.3800 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.0.1       00:53:00     0000.0c07.ac07 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.0.2       00:00:01     0026.0bdd.0000 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.0.3       00:00:05     0026.0bdc.ffc0 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.13.2      02:41:25     0015.17d6.684b Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.36.19     00:33:28     0014.a841.0ffc Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.44.1      00:54:57     6c20.5618.96aa Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.44.2      01:46:47     6c20.5618.982e Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.44.3      02:46:28     4c4e.35b6.57e8 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.44.100    02:45:10     4c4e.35b6.57e8 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.44.101    02:45:05     6c20.5618.96aa Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.49.41     00:03:16     6400.f142.134c Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.49.43     01:10:36     6400.f142.134c Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.49.121    02:54:42     0020.b007.6700 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.49.122    01:51:05     0020.b007.6700 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.49.123    00:31:59     0033.b515.68ff Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.49.254    00:24:09     0003.310a.a039 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.54.10     -            e050.07fa.ef05 Interface ARPA   MgmtEth0/RP0/CPU0/0
203.7.54.11     -            e050.07fa.ef05 Interface ARPA   MgmtEth0/RP0/CPU0/0
203.7.54.12     01:24:34     4c4e.35b6.4af8 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.1      00:06:21     10f3.11b6.c634 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.2      00:05:58     6400.f142.1500 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.8      01:59:01     0024.c4d8.c2cc Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.9      00:54:16     6400.f142.0bbe Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.10     01:25:07     6400.f142.115a Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.11     00:59:03     0022.56d8.36a0 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
203.7.57.13     00:22:16     000a.b8b7.fff8 Dynamic  ARPA   MgmtEth0/RP0/CPU0/0
```

The following is sample output from the **show arp** command with the *interface-type interface-instance* argument:

```
Router# show arp HundredGigE 0/0/0/1

0/RP0/CPU0
-----
Address          Age           Hardware Addr  State   Type   Interface
20.30.1.1        -            c472.95a6.2a86 Interface ARPA   HundredGigE0/0/0/1
20.30.1.2        00:04:58     6c9c.ed2c.a060 Dynamic  ARPA   HundredGigE0/0/0/1
```

```
Router# show arp mgmtEth 0/RP1/CPU0/0
```

```
Address      Age           Hardware Addr  State   Type   Interface
192.4.9.2    00:35:55     0030.7131.abfc Dynamic  ARPA   MgmtEth0/RP1/CPU0/0
192.4.9.1    00:35:55     0000.0c07.ac24 Dynamic  ARPA   MgmtEth0/RP1/CPU0/0
192.4.9.99   00:49:12     0007.ebea.44d0 Dynamic  ARPA   MgmtEth0/RP1/CPU0/0
192.4.9.199  -            0001.c9eb.dffe Interface ARPA   MgmtEth0/RP1/CPU0/0
```

The following is sample output from the **show arp** command with the *hardware-address* designation:

```
Router# show arp 0005.5f1d.8100
```

```
Address Age Hardware Addr State Type Interface
192.16.7.2 - 0005.5f1d.8100 Interface ARPA HundredGigE0/0/0/2
```

The following is sample output from the **show arp** command with the **location** keyword and *node-id* argument:

```
Router# show arp location 0/2/CPU0
```

```
Address Age Hardware Addr State Type Interface
192.168.15.1 - 00dd.00ee.00ff Alias ARPA
192.168.13.1 - 00aa.00bb.00cc Static ARPA
203.16.7.1 00:35:49 0002.fc0e.9600 Dynamic ARPA HundredGigE0/1/0/2
203.16.7.2 - 0005.5f1d.8100 Interface ARPA HundredGigE0/1/0/2
```

This table describes the significant fields shown in the display.

**Table 6: show arp Command Field Descriptions**

Field	Description
Address	Displays the network address that corresponds to the hardware address.
Age	Displays the age in hours:minutes:seconds of the cache entry. A hyphen (-) means the address is local.
Hardware Addr	Displays the LAN hardware address of a MAC address that corresponds to the network address.
State	Displays the current state of the cache entry. Values are: <ul style="list-style-type: none"> <li>• Dynamic</li> <li>• Interface</li> <li>• Alias</li> <li>• Static</li> <li>• “-” (indicates global static and alias entries)</li> </ul>
Type	Displays the encapsulation type the Cisco IOS XR software is using for the network address in this entry. Value is ARPA.
Interface	Displays the interface associated with this network address.

Field	Description
ARP statistics	Displays ARP packet and error statistics.
ARP cache	Displays general information about the IP address and MAC address association entries in the ARP cache.
IP Packet drop count for node */*/*	Displays the number of IP packets dropped because the buffer ran out of space before an ARP response was received. <b>Note</b> */*/* represents the node ID in the format <i>rack/slot/module</i> .

## show arp idb

To display the ARP database statistics for an interface, use the **show arp idb** command in EXEC mode.

```
show arp idb interface-name location node-id
```

### Syntax Description

*interface-name* Name of the interface

*node-id* Location of the interface. LC node for physical interfaces, RP or LC node for virtual interfaces

### Command Default

There is no default location, location needs to be provided in the CLI.

### Command History

Release	Modification
Release 3.3.0	This command was introduced.

### Usage Guidelines

The **show arp idb** command is useful to verify the IP addresses, Mac address, ARP configuration(s) applied on the interface and the entry statistics.

For **show arp idb** *interface-type interface-instance* form, the **location** *node-id* keyword and argument is mandatory for Bundle and VLAN-on-Bundle interfaces to indicate which location the cache entries for the bundle should be displayed.

### Task ID

Task ID	Operations
cef	read

### Examples

The following is sample output from the **show arp idb** command:

```
RP/0/0/CPU0:ios#show arp idb GigabitEthernet 0/0/0/0 location 0/0/CPU0
Mon Jan 30 10:32:15.387 IST
GigabitEthernet0/0/0/0 (0x00000060):
IDB Client: default
IPv4 address 1.1.1.1, Vrf ID 0x60000000
VRF Name default
Dynamic learning: Enable
Dynamic entry timeout: 14400 secs
Drop adjacency timeout: Disable
Purge delay: off
Cache limit: 128000
Incomplete glean count: 1
```

```
Complete glean count: 0
Complete protocol count: 0
Dropped glean count: 0
Dropped protocol count: 0
IPv4 caps added (state up)
MPLS caps not added
Interface not virtual, not client fwd ref,
Proxy arp not configured, not enabled
Local Proxy arp not configured
Packet IO layer is NetIO
Srg Role : DEFAULT
Idb Flag : 49292
IDB is Complete
IDB Flag Description:
[CAPS | COMPLETE | IPV4_CAPS_CREATED | SPIO_ATTACHED |
SPIO_SUPPORTED]
Idb Flag Ext : 0x0
Idb Oper Progress : NONE
Client Resync Time : Jan 30 10:07:10.736787
Total entries : 9
| Event Name | Time Stamp | S, M
| idb-create | Jan 30 10:07:10.784 | 1, 0
| idb-state-up | Jan 30 10:07:10.784 | 0, 0
| caps-state-update | Jan 30 10:07:10.784 | 0, 1
| address-update | Jan 30 10:07:10.784 | 0, 0
| idb-complete | Jan 30 10:07:10.784 | 0, 0
| idb-entry-create | Jan 30 10:07:10.784 | 0, 0
| idb-caps-add | Jan 30 10:07:10.784 | 0, 0
| idb-caps-add-cb | Jan 30 10:07:10.784 | 0, 0
| idb-last-garp-sent | Jan 30 10:07:11.808 | 0, 0
```



# show arp dagr

To display the operational state of all Direct Attached Gateway Redundancy (DAGR) groups, use the **show arp dagr** command in XR EXEC mode

```
show arp dagr [interface [IP-address]]
```

<b>Syntax Description</b>	<i>interface [IP-address]</i> (Optional) Restricts the output to a specific interface and virtual IP address.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	This command has no keywords or arguments.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read, write

## Examples

The following example shows the current operational state of the DAGR groups:

```
Router# show arp dagr
```

```
-----  
0/1/CPU0  
-----
```

Interface	Virtual IP	State	Query-pd	Dist	Metr
HundredGigE0/1/0/2	192.0.2.1	Active	None	150	100
HundredGigE0/1/0/2	192.24.0.45	Query	1	None	None
HundredGigE0/1/0/3	192.66.0.45	Init	None	None	None

# show arp traffic

To display Address Resolution Protocol (ARP) traffic statistics, enter the **show arp traffic** command in XR EXEC mode.

```
show arp traffic [vrf vrf-name] [interface-path-id] [location node-id]
```

## Syntax Description

<b>vrf</b>	(Optional) Specifies VPN routing and forwarding (VRF) instance.
<b>vrf-name</b>	(Optional) VRF instance that identifies a VPN.
<b>interface- path-id</b>	(Optional) Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>• Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li>• <i>rack</i>: Chassis number of the rack.</li> <li>• <i>slot</i>: Physical slot number of the modular services card or line card.</li> <li>• <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li>• <i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>• Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>location node-id</b>	(Optional) Displays the ARP entry for a specific location. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

The active RSP is the default location.

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

ARP establishes correspondences between network addresses (an IP address, for example) and Ethernet hardware addresses. A record of each correspondence is kept in a cache for a predetermined amount of time and then discarded.

For **show arp traffic**, *interface-instance*, the **location***node-id* keyword and argument is mandatory for Bundle and VLAN-on-Bundle interfaces to indicate which location the cache entries for the bundle should be displayed. For physical interfaces, specifying the **location** *node-id* keyword and argument is optional since the interface can only exist on one node.

Task ID	Task ID	Operations
	cef	read

### Examples

The following is sample output from the **show arp traffic** command:

```
Router# show arp traffic

show arp traffic
Thu Dec 10 09:51:38.761 UTC

-----
0/6/CPU0
-----

ARP statistics:
  Recv: 163 requests, 79 replies
  Sent: 14138 requests, 177 replies (0 proxy, 0 local proxy, 14 gratuitous)
  Resolve requests rcvd: 7204
  Resolve requests dropped: 295
  Errors: 0 out of memory, 0 no buffers, 0 out of sunbet

ARP cache:
  Total ARP entries in cache: 22
  Dynamic: 11, Interface: 11, Standby: 0
  Alias: 0,   Static: 0,   DHCP: 0

  IP Packet drop count for node 0/6/CPU0: 6909

  Total ARP-IDB:19

-----
0/2/CPU0
-----

ARP statistics:
  Recv: 162532 requests, 243 replies
  Sent: 15879 requests, 162561 replies (0 proxy, 0 local proxy, 29 gratuitous)
  Resolve requests rcvd: 47593
  Resolve requests dropped: 0
  Errors: 0 out of memory, 0 no buffers, 0 out of sunbet

ARP cache:
  Total ARP entries in cache: 125
  Dynamic: 112, Interface: 13, Standby: 0
  Alias: 0,   Static: 0,   DHCP: 0

  IP Packet drop count for node 0/2/CPU0: 44804

  Total ARP-IDB:13
```

The following is sample output from the **show arp traffic** command with the **location** keyword and **node-id** argument:

```
Router# show arp traffic location 0/4/CPU0

Thu Dec 10 09:51:56.209 UTC
```

```
ARP statistics:
  Recv: 364474 requests, 96 replies
  Sent: 14131 requests, 364499 replies (0 proxy, 0 local proxy, 25 gratuitous)
  Resolve requests rcvd: 5699
  Resolve requests dropped: 94
  Errors: 0 out of memory, 0 no buffers, 0 out of sunbet

ARP cache:
  Total ARP entries in cache: 18
  Dynamic: 9, Interface: 9, Standby: 0
  Alias: 0,   Static: 0,   DHCP: 0

IP Packet drop count for node 0/4/CPU0: 5603

Total ARP-IDB:18
```

## timers (DAGR)

To configure the Direct Attached Gateway Redundancy (DAGR) timers for sending ARP requests, use the **timers** command in DAGR peer interface configuration mode.

**timers** **query** *query-time* **standby** *standby-time*

Syntax Description	query <i>query-time</i>	The value is a time (in seconds) between successive ARP requests being sent out to the virtual IP address, when the group is in the query state. The range of values is 1 to 10000.
	<b>standby</b> <i>standby-time</i>	The value is a time (in seconds) between successive ARP requests being sent out to the virtual IP address, when the group is in the standby state. The range of values is 1 to 10000.

**Command Default** The default for *query-time* is 1 second, and the default for *standby-time* is 20 seconds.

**Command Modes** DAGR peer interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** When this function is applied, the DAGR group configuration is updated in the database. The new timer values take effect the next time the timer is set. No immediate timer restarts are triggered on the basis of this event.

Task ID	Task ID	Operations
	cef	write

**Examples** The following example configures a DAGR group peer with a query time of 2 and a standby time of 40:

```
Router(config-if-dagr-peer) # timers query 2 standby 40
Router(config-if-dagr-peer) #
```





## DHCP Commands

---

This chapter describes the commands used to configure and monitor Dynamic Host Configuration Protocol (DHCP) features.

For detailed information about DHCP concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [clear dhcp ipv6 relay binding, on page 114](#)
- [client-mac-mismatch, on page 116](#)
- [dhcp ipv4 , on page 117](#)
- [dhcp ipv6, on page 118](#)
- [giaddr policy, on page 119](#)
- [helper-address, on page 121](#)
- [helper-address \(ipv6\), on page 123](#)
- [hop-count-seed, on page 125](#)
- [iana-route-add, on page 126](#)
- [profile \(DHCP\), on page 127](#)
- [relay information, on page 129](#)
- [show dhcp ipv4 relay, on page 131](#)
- [show dhcp ipv6 relay binding, on page 133](#)
- [show dhcp ipv6 relay statistics, on page 135](#)
- [vrf \(relay profile\), on page 137](#)

## clear dhcp ipv6 relay binding

To clear DHCPv6 relay binding, use the **clear dhcp ipv6 relay binding** command in XR EXEC mode.

```
clear dhcp ipv6 relay binding [client-duid client-duid-number ] [interface type interface-path-id]
[vrf vrf-name] [location node-id]
```

Syntax Description		
<b>client-duid</b> <i>client-duid-number</i>	(Optional) Clears DHCPv6 relay client binding information.	The argument <i>client-duid-number</i> is the client's DHCP Unique Identifier (DUID) number.
	<b>Note</b> Use the <b>show dhcp ipv6 relay binding</b> command to see the client DUID number.	
<b>interface</b> <i>type interface-path-id</i>	(Optional) Clears DHCPv6 relay client binding information for an interface.	Specifies a physical interface or a virtual interface.
	<b>Note</b> Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.	
<b>vrf</b> <i>vrf-name</i>	(Optional) Clears DHCPv6 relay client binding information for a VPN routing and forwarding (VRF) instance.	
<b>location</b> <i>node-id</i>	(Optional) Clears DHCPv6 relay client binding information for a specified node.	The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>Command Default</b>	None.	
<b>Command Modes</b>	XR EXEC mode	



Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	ip-services	execute
	root-system	read, write

This example shows how to clear DHCPv6 relay binding:

```
Router# clear dhcp ipv6 relay binding
```

# client-mac-mismatch

To enable DHCP MAC address verification.

## client-mac-mismatch action drop

### Syntax Description

**action** Specifies an action for the router when the DHCP MAC address is a not a match.

**drop** Drops the packet with the mismatched DHCP MAC address.

### Command Default

None

### Command Modes

DHCP Relay Profile Configuration Mode

### Command History

Release	Modification
Release 7.2.12	This command was introduced.

### Usage Guidelines

Enables MAC address verification. If MAC address in the DHCPv4 protocol header does not match the L2 header source MAC address in the DHCPv4 relay profile, the frame is dropped.

### Example

Use the following example to configure DHCP MAC address verification.

```
Router# configure

Router(config)# dhcp ipv4
/* Configures DHCP for IPv4 and enters the DHCPv4 configuration submode. */

Router(config-dhcpv4)# profile client relay
/* Enables DHCP relay profile */

Router(config-dhcpv4)# client-mac-mismatch action drop
/* Enables MAC address verification. If MAC address in the DHCPv4 protocol header does not
match the L2 header source MAC address in the DHCPv4 relay profile,
the frame is dropped */

Router(config-dhcpv4-relay-profile)# commit

Router(config-dhcpv4-relay-profile)# exit
```

# dhcp ipv4

To enable Dynamic Host Configuration Protocol (DHCP) for IPv4 and to enter DHCP IPv4 configuration mode, use the **dhcp ipv4** command in Global Configuration mode. To disable DHCP for IPv4 and exit the DHCP IPv4 configuration mode, use the **no** form of this command.

**dhcp ipv4**  
**no dhcp ipv4**

---

**Command Modes** None

---

**Command Modes** Global Configuration mode

---

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

---



---

**Usage Guidelines** Use the **dhcp ipv4** command to enter DHCP IPv4 configuration mode.

---

Task ID	Task ID	Operations
	ip-services	read, write

---



---

**Examples** This example shows how to enable DHCP for IPv4:

```
Router# configure
Router(config)# dhcp ipv4
Router# (config-dhcpv4)#
```

# dhcp ipv6

To enable Dynamic Host Configuration Protocol (DHCP) for IPv6 and to enter DHCP IPv6 configuration mode, use the **dhcp ipv6** command in XR Config mode. To disable the DHCP for IPv6, use the **no** form of this command.

## dhcp ipv6

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Modes</b>	XR Config mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.
<b>Usage Guidelines</b>	Use the <b>dhcp ipv6</b> command to enter DHCP IPv6 configuration mode.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write
<b>Examples</b>	This example shows how to enable DHCP for IPv6:	
	<pre>Router(config)# <b>dhcp ipv6</b> Router(config-dhcpv6)#</pre>	

## giaddr policy

To configure how Dynamic Host Configuration Protocol (DHCP) IPv4 Relay processes BOOTREQUEST packets that already contain a nonzero giaddr attribute, use the **giaddr policy** command in DHCP IPv4 profile relay configuration submenu. To restore the default giaddr policy, use the **no** form of this command.

```
giaddr policy {replace | drop}
no giaddr policy {replace | drop}
```

### Syntax Description

**replace** Replaces the existing giaddr value with a value that it generates.

**drop** Drops the packet that has an existing nonzero giaddr value.

### Command Default

DHCP IPv4 relay retains the existing nonzero giaddr value in the DHCP IPv4 packet received from a client value.

### Command Modes

DHCP IPv4 profile relay configuration

### Command History

Release	Modification
Release 7.2.12	This command was introduced.

### Usage Guidelines

The **giaddr policy** command affects only the packets that are received from a DHCP IPv4 client that have a nonzero giaddr attribute.

### Task ID

Task ID	Operations
ip-services	read, write

### Examples

The following example shows how to use the **giaddr policy** command:

```
Router# config
Router(config)# dhcp ipv4
Router(config-dhcpv4)# profile client relay
Router(config-dhcpv4-relay-profile)# giaddr policy drop
```

### Related Commands

Command	Description
<a href="#">dhcp ipv4</a> , on page 117	Enables DHCP for IPv4 and enters DHCP IPv4 configuration mode.
<a href="#">helper-address</a> , on page 121	Configures the DHCP relay agent to relay packets to a specific DHCP Server.
<a href="#">profile (DHCP)</a> , on page 127	Configures a relay profile for the DHCP IPv4 component.

Command	Description
<a href="#">relay information, on page 129</a>	Configures a Dynamic Host Configuration Protocol (DHCP) IPv4 relay information options in forwarded BOOTREPLY messages.

# helper-address

To configure the Dynamic Host Configuration Protocol (DHCP) IPv4 relay agent to relay DHCP packets to a specific DHCP server, use the **helper-address** command in an DHCP IPv4 relay profile configuration mode. Use the **no** form of this command to clear the address.

```
helper-address { vrf vrf-name | address } giaddr [ gateway-address ]
no helper-address { vrf vrf-name | address } giaddr [ gateway-address ]
```

Syntax Description	
<i>vrf-name</i>	(Optional) Specifies the name of a particular VRF.
<i>address</i>	IPv4 in four part, dotted decimal format.
<b>giaddr</b> <i>gateway-address</i>	(Optional) Specifies the gateway address to use in packets relayed to server. This keyword is applicable for IPv4 helper address.

**Command Default** Helper address is not configured.

**Command Modes** DHCP IPv4 relay profile configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** A maximum of upto eight helper addresses can be configured.

Task ID	Task ID	Operations
	ip-services	read, write

**Examples** This example shows how to set the helper-address for a VRF using the **helper address** command in DHCP IPv4 relay profile class configuration mode:

```
RP/0/CPU0:router(config)# dhcp ipv4
RP/0/CPU0:router(config-dhcpv4)# profile profile1 relay
RP/0/CPU0:router(config-dhcpv4-relay-profile)# helper-address vrf my-server-vrf 192.0.2.1
```

Related Commands	Command	Description
	dhcp ipv4	Enables Dynamic Host Configuration Protocol (DHCP) for IPv4 and enters DHCP IPv4 configuration mode.
	relay information check	Configures a DHCP server to validate the relay agent information option in forwarded BOOTREPLY messages.

Command	Description
relay information option	Enables the system to insert a DHCP relay agent information option in forwarded BOOTREQUEST messages to a DHCP server.
relay information option allow-untrusted	Configures the DHCP component to not drop BOOTREQUEST messages that have the relay information option set and the giaddr set to zero.



## helper-address (ipv6)

To configure the Dynamic Host Configuration Protocol (DHCP) IPv6 relay agent for prefix delegation to relay DHCP packets to a specific DHCP server, use the **helper-address** command in the DHCP IPv6 profile configuration submenu. Use the **no** form of this command to clear the address.

```
helper-address ipv6-address | vrf vrf-address [ interface type interface-path-id ]
no helper-address ipv6-address | vrf vrf-address [ interface type interface-path-id ]
```

Syntax Description	
<i>ipv6-address</i>	<p>The IPv6 address assigned to the interface.</p> <p>This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal format using 16-bit values between colons.</p>
<b>interface</b> <i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	<p>(Optional) Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between value s is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0) and the module is CPU0. Example: interface MgmtEth0/RSP0/CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>Command Default</b>	No default behavior or values
<b>Command Modes</b>	DHCP IPv6 profile configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	ip-services	read, write

### Example

This is a sample output that shows how to set the helper-address using the **helper-address** command

```
Router# config
Router(config)# dhcp ipv6
Router(config-dhcpv6)# profile p1 relay
Router(config-dhcpv6-profile)# helper-address 2001:DB8::1 HundredGigE 0/2/0/0
```

### Related Commands

Command	Description
<a href="#">dhcp ipv6, on page 118</a>	Enables Dynamic Host Configuration Protocol (DHCP) for IPv6.

# hop-count-seed

To configure the hop-count in relay-forward message for a DHCP relay agent as zero, use the `hop-count-seed` command in the DHCP IPv6 configuration mode. By default, hop-count in relay-forward message for DHCP relay agents is set to one.

**hop-count-seed**  
**no hop-count-seed**

## Syntax Description

This command has no keywords or arguments.

## Command Default

If this command is not configured, by default, hop-count in relay-forward message for DHCP relay agents is set to one.

## Command Modes

DHCP IPv6 configuration

## Command History

Release	Modification
Release 7.2.12	This command was introduced.

## Usage Guidelines

Use this command only on routers that are configured as DHCP relay agents. You can only configure this command in the DHCP IPv6 mode and not on DHCP IPv4 mode.

## Task ID

Task ID	Operations
ip-services	read, write

The following is an example of the **hop-seed-count** command:

```
Router# config
Router(config)# dhcp ipv6
Router(dhcp-ipv6)# hop-count-seed
```

# iana-route-add

To enable route addition for identity association for non-temporary address (IANA), use the **iana-route-add** command in DHCPv6 relay profile configuration submode. To disable route addition to IANA, use the **no** form of this command.

**iana-route-add**  
**no iana-route-add**

**Syntax Description** This command has no keywords or arguments.

**Command Default** Disabled.

**Command Modes** DHCP IPv6 relay profile configuration submode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** The DHCPv6 relay is capable of installing routes for multiple identity association for prefix delegation (IAPD) options within a DHCPv6 message. The route addition for IAPD is enabled by default. The DHCPv6 relay is capable of installing routes for IANA as well, but this feature is disabled by default. Users can enable the route addition to IANA feature by using **iana-route-add** command in DHCPv6 relay profile configuration submode.

Task ID	Task ID	Operation
	ip-services	read, write

## Example

This example shows how to enable route addition to IANA:

```
Router# config
Router(config)# dhcp ipv6
Router(config-dhcpv6)# profile client relay
Router(config-dhcpv6-relay-profile)# iana-route-add
```

## profile (DHCP)

To configure a DHCP relay profile, use the **profile** command in DHCP IPv4 or DHCP IPv6 configuration mode. To disable this feature and exit the profile mode, use the **no** form of this command.

**profile** *name* **relay**  
**no profile** *name* **relay**

Syntax Description		
	<i>name</i>	Name that uniquely identifies the relay or snoop profile.
	<b>relay</b>	<p>Configures a DHCP relay profile. A DHCP relay agent is a host that forwards DHCP packets between clients and servers. When the clients and servers are not on the same physical subnet, the relay agents are used to forward requests and replies between them.</p> <p>A DHCP relay agent is any host that forwards DHCP packets between clients and servers. Relay agents are used to forward requests and replies between clients and servers when they are not on the same physical subnet. Relay agent forwarding is distinct from the normal forwarding of an IP router, where IP datagrams are switched between networks rather transparently. By contrast, relay agents receive DHCP messages and then generate a new DHCP message to send out on another interface. The relay agent sets the gateway IP address (giaddr field of the DHCP packet) and, if configured, adds the relay agent information option (option82) in the packet and forwards it to the DHCP server. The reply from the server is forwarded back to the client after removing option 82.</p>
<b>Command Default</b>	None	
<b>Command Modes</b>	DHCP IPv4 configuration DHCP IPv6 configuration	

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	ip-services	read, write

### Examples

This example shows how to use the **profile** command to configure DHCP IPv6 relay profile:

```
Router(config)# dhcp ipv6
Router(config-dhcpv6)# profile TEST relay
Router(config-dhcpv6-relay-profile)#
```

This example shows how to use the **profile** command to configure DHCP IPv4 relay profile:

```
Router(config)# dhcp ipv4
Router(config-dhcpv4)# profile TEST relay
Router(config-dhcpv4-relay-profile)#
```

## relay information

To configure Dynamic Host Configuration Protocol (DHCP) IPv4 relay information options, use the relay information command in DHCP IPv4 relay profile configuration submenu. To restore the default relay information policy, use the no form of this command.

```

relay information { check | option [ allow-untrusted | remote-id format-type { ascii
ascii-value | hex hex-value } | subscriber-id subscriber-value | vpn | vpn-mode {
cisco | rfc } ] | policy { drop | encapsulate | keep } }
no relay information { check | option [ allow-untrusted | remote-id format-type
{ ascii ascii-value | hex hex-value } | subscriber-id subscriber-value | vpn | vpn-mode
{ cisco | rfc } ] | policy { drop | encapsulate | keep } }

```

Syntax Description	check	Validates the relay agent information option in forwarded BOOTREPLY messages.
	<b>option</b>	Configures relay agent information options in forwarded BOOTREQUEST messages.
	<b>allow-untrusted</b>	Forwards untrusted packets.
	<b>remote-id format-type</b>	Configures the value of the remote-id in either ascii or hex format.
	<b>subscriber-id</b> <i>subscriber-value</i>	Configures the value of the subscriber-id
	<b>vpn</b>	Configures VPN suboptions in forwarded BOOTREQUEST messages.
	<b>vpn-mode</b>	Configures VPN suboptions mode either in CISCO proprietary or RFC compliance.
	<b>policy</b>	Configures relay agent information option policy
	<b>drop</b>	Directs the DHCP IPv4 Relay to discard BOOTREQUEST packets with the existing relay information option
	<b>keep</b>	Directs the DHCP IPv4 Relay not to discard a BOOTREQUEST packet that is received with an existing relay information option and to keep the existing relay information option value.
	<b>encapsulate</b>	Encapsulates the DHCP relay agent information option received from a prior relay agent in forwarded BOOTREQUEST messages.

**Command Default** The DHCP IPv4 Relay does not discard a BOOTREQUEST packet that has an existing relay information option. The option and the existing relay information option value is replaced.

**Command Modes** DHCP IPv4 relay profile configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** The encapsulate keyword allows the second relay agent to encapsulate option 82 information in a message received from the first relay agent, if it is also configured to add its own option 82 information. This configuration allows the DHCP server to use option 82 information from both relay agents.

Task ID	Task ID	Operation
	ip-services	read, write
	basic-services	read, write

This is sample output from executing the relay information policy command:

```
Router# config
Router(config)# dhcp ipv4
Router(config-dhcpv4)# profile TEST relay
Router(config-dhcpv4-relay-profile)# relay information policy keep
```

This example shows how to encapsulate the DHCP relay agent information option:

```
Router# config
Router(config)# dhcp ipv4
Router(config-dhcpv4)# profile TEST relay
Router(config-dhcpv4-relay-profile)# relay information policy encapsulate
```

#### Related Commands

Command	Description
dhcp ipv4	Enables DHCP for IPv4 and enters DHCP IPv4 configuration mode.
helper-address	Configures the DHCP relay agent to relay packets to a specific DHCP Server.
relay information check	Configures a DHCP server to validate the relay agent information option in forwarded BOOTREPLY messages.
relay information option	Enables the system to insert a DHCP relay agent information option in forwarded BOOTREQUEST messages to a DHCP server.
relay information option allow-untrusted	Configures the DHCP component to not drop BOOTREQUEST messages that have the relay information option set and the giaddr set to zero.



# show dhcp ipv4 relay

To display the Dynamic Host Configuration Protocol (DHCP) IPv4 relay agent packet information, use the **show dhcp ipv4 relay** command in the XR EXEC mode.

```
show dhcp ipv4 relay { profile [ name profile-name ] | statistics [ detail ] } [ location node-id ]
```

## Syntax Description

<b>profile name</b> <i>profile-name</i>	(Optional) Displays the profile name.
<b>statistics</b>	(Optional) Displays the profile statistics.
<b>location</b> <i>node-id</i>	(Optional) Displays the information for the specified node.

## Command Default

No default behavior or values

## Command History

Release	Modification
Release 7.2.12	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Task ID

Task ID	Operations
ip-services	read

## Examples

The following is sample output from the **show dhcp ipv4 relay statistics** command when none of the optional keywords or arguments are used command:

```
Router# show dhcp ipv4 relay statistics
-----
                Bridge                |      RX      |      TX      |      DR      |
-----|-----|-----|-----|
default                |              0 |              0 |              0 |
```

The following is sample output from the **show dhcp ipv4 relay profile** command:

```
Router# show dhcp ipv4 relay profile
DHCP IPv4 Relay Profiles
-----
r1
r2
```

The following is sample output from the **show dhcp ipv4 relay profile name profile-name** command:

```
Router# show dhcp ipv4 relay profile name R1
DHCP IPv4 Relay Profile R1:

Helper Addresses:
10.10.10.1, vrf default
Information Option: Disabled
Information Option Allow Untrusted: Disabled
```

```
Information Option Policy: Replace  
Information Option Check: Disabled  
Giaddr Policy: Keep  
Broadcast-flag Policy: Ignore
```

```
VRF References:  
default  
Interface References:  
FINT0_RP0_CPU0  
MgmtEth0_RP0_CPU0_0
```

## show dhcp ipv6 relay binding

To display DHCPv6 client bindings for relay, use the **show dhcp ipv6 relay binding** command in XR EXEC mode.

```
show dhcp ipv6 relay binding [ client-duid client-duid-number ] [ [detail] ] | [ [ interface type interface-path-id ] ] | [ [location node-id ] ] | [ [summary] ] | [ vrf vrf-name ]
```

Syntax Description		
<b>client-duid</b> <i>client-duid-number</i>	(Optional) Displays DHCPv6 relay client binding information.	The argument <i>client-duid-number</i> is the client's DHCP Unique Identifier (DUID) number.  <b>Note</b> Use the <b>show dhcp ipv6 relay binding</b> command to see the client DUID number.
<b>detail</b>	(Optional) Displays detailed DHCPv6 relay client binding information for all clients.	
<b>interface</b> <i>type interface-path-id</i>	(Optional) Displays DHCPv6 relay client binding by interface.	Specifies a physical interface or a virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed DHCPv6 relay client binding information for a specified node.	The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>summary</b>	(Optional) Displays the summary of DHCPv6 relay client binding.	
<b>vrf</b> <i>vrf-name</i>	(Optional) Displays DHCPv6 relay client binding information for a VPN routing and forwarding (VRF) instance.	

<b>Command Default</b>	None.	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.2.12	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	ip-services	read

This is the sample output for show dhcp ipv6 relay binding command:

```
Router# show dhcp ipv6 relay binding
Summary:
Total number of clients: 1

IPv6 Address: fc00:35:0:ef5c:a932:239f:1b0e:e4ed/128 (BVI3500)
  Client DUID: 000100011b626e6f0000cae2da26
  IAID: 0x0
  VRF: default
  Lifetime: 172800 secs (2d00h)
  Expiration: 172766 secs (1d23h)
```

# show dhcp ipv6 relay statistics

To display DHCPv6 relay statistics, use the **show dhcp ipv6 relay statistics** command in XR EXEC mode.

```
show dhcp ipv6 relay statistics [ vrf vrf-name ] | [ detail ] [ location node-id ]
```

Syntax Description	detail	(Optional) Displays DHCPv6 relay statistics information in details.
	<b>location</b> <i>node-id</i>	(Optional) Displays DHCPv6 relay debug statistics information for for a specified node.  The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>vrf</b> <i>vrf-name</i>	(Optional) Displays DHCPv6 relay statistics information for a VPN routing and forwarding (VRF) instance.
	<b>location</b> <i>node-id</i>	(Optional) Displays detailed DHCPv6 relay statistics information for a specified node.  The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** None.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	ip-services	read

This is the sample output for **show dhcp ipv6 relay statistics** command:

```
Router# show dhcp ipv6 relay statistics
VRF | RX | TX | DR
-----|-----|-----|-----
default | 241 | 5 | 236 |
```

## show dhcp ipv6 relay statistics

**nVSatellite		0		0		0	
red4		0		0		0	
red6		0		0		0	
**eint		0		0		0	

## vrf (relay profile)

To configure a relay profile on a VPN routing and forwarding (VRF) instance, use the **vrf (relay profile)** command in Dynamic Host Configuration Protocol (DHCP) IPv4 configuration mode. To disable this feature, use the **no** form of this command.

```
vrf { vrf-name | default | all } relay [ profile profile-name ]
no vrf { vrf-name | default | all } relay [ profile profile-name ]
```

Syntax Description		
	<i>vrf-name</i>	User-defined name for the VRF.
	<b>default</b>	Specifies a profile for the default VRF.
	<b>all</b>	Specifies a profile for all VRFs.
	<b>relay</b>	Specifies a relay profile.
	<b>profile</b> <i>profile-name</i>	Specifies a name for the profile.

**Command Default** If **default** is selected, then the configuration defaults to VRF.

**Command Modes** DHCP IPv4 configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	ip-services	read, write

**Examples** The following example shows how to set the relay profile for all VRFs:

```
Router# config
Router(config)# dhcp ipv4
Router(config-dhcpv4)# vrf all
```

Related Commands	Command	Description
	<a href="#">dhcp ipv4 , on page 117</a>	Enables DHCP for IPv4 and enters DHCP IPv4 configuration mode.
	<a href="#">giaddr policy, on page 119</a>	Configures how a relay agent processes BOOTREQUEST messages that already contain a nonzero giaddr attribute.

Command	Description
<a href="#">helper-address, on page 121</a>	Configures the DHCP relay agent to relay packets to a specific DHCP Server.
<a href="#">relay information, on page 129</a>	Configures a Dynamic Host Configuration Protocol (DHCP) IPv4 relay information options in forwarded BOOTREPLY messages.





## Cisco Express Forwarding Commands

This chapter describes the commands used to configure and monitor Cisco Express Forwarding (CEF) on a Cisco 8000 Series Router.

For detailed information about ACL concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Command Reference for Cisco 8000 Series Routers*

- [cef adjacency route override rib, on page 141](#)
- [cef load-balancing, on page 143](#)
- [clear adjacency statistics, on page 146](#)
- [clear cef ipv4 drops, on page 148](#)
- [clear cef ipv4 exceptions, on page 150](#)
- [clear cef ipv6 drops, on page 152](#)
- [clear cef ipv6 exceptions, on page 154](#)
- [hw-module profile cef, on page 156](#)
- [hw-module profile route scale, on page 157](#)
- [show adjacency, on page 159](#)
- [show cef bgp-attribute, on page 162](#)
- [show cef, on page 164](#)
- [show cef exact-route \(user-data\), on page 167](#)
- [show cef ext-client, on page 169](#)
- [show cef ipv4 adjacency, on page 172](#)
- [show cef ipv4 adjacency hardware, on page 175](#)
- [show cef ipv4, on page 178](#)
- [show cef ipv4 drops, on page 180](#)
- [show cef ipv4 exact-route, on page 182](#)
- [show cef ipv4 exceptions, on page 185](#)
- [show cef ipv4 hardware, on page 187](#)
- [show cef ipv4 interface, on page 193](#)
- [show cef ipv4 non-recursive, on page 195](#)
- [show cef ipv4 resource, on page 198](#)
- [show cef ipv4 summary, on page 200](#)
- [show cef ipv4 unresolved, on page 202](#)
- [show cef ipv6 adjacency, on page 204](#)
- [show cef ipv6 adjacency hardware, on page 206](#)
- [show cef ipv6 , on page 212](#)

- [show cef ipv6 drops](#), on page 215
- [show cef ipv6 exact-route](#), on page 217
- [show cef ipv6 exceptions](#), on page 220
- [show cef ipv6 hardware](#), on page 221
- [show cef ipv6 interface](#), on page 223
- [show cef ipv6 non-recursive](#), on page 225
- [show cef ipv6 resource](#), on page 227
- [show cef ipv6 summary](#), on page 228
- [show cef ipv6 unresolved](#), on page 230
- [show cef mpls adjacency](#), on page 232
- [show cef mpls adjacency hardware](#), on page 234
- [show cef mpls drops](#), on page 236
- [show cef mpls interface](#), on page 237
- [show cef mpls unresolved](#), on page 239
- [show cef recursive-nextthop](#), on page 240
- [show cef summary](#), on page 241
- [show cef vrf](#), on page 243
- [show hw-module profile cef](#), on page 245

# cef adjacency route override rib

To enable the CEF prefer Routing Information Base (RIB) prefixes over Adjacency Information Base (AIB) prefixes in the Global configuration mode. To enable the CEF prefer AIB prefixes over RIB prefixes, use the **no** form of this command.

**cef adjacency route override rib**

**no cef adjacency route override rib**

## Syntax Description

<b>route</b>	Enables adjacency route configuration
<b>override</b>	Sets override options for the adjacency routes.
<b>rib</b>	Sets options for adjacency routes to override the RIB routes.

## Command Default

By default, CEF prefers RIB prefixes over AIB prefixes.

## Command Modes

Global configuration

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

CEF may prefer the L2 adjacency for forwarding over the RIB (routing) entry under the following conditions:

- When there is no local ARP entry (yet).  
ARP learning may result in the router creating a forwarding entry.
- A forwarding entry of /32 (or /128 for IPv6) RIB routes are overridden when there is a covering connected or attached route.  
If an interface has a larger subnet, and you want to redirect a /32 out of that subnet of a different interface via a static route.

To deviate from the behavior of preferring a L2 adjacency for forwarding over a route entry, use the **cef adjacency route override rib** command.

## Task ID

Task ID	Operation
cef	read, write

## Example

The following example shows how to override the CEF adjacency route:

```
Router# configure
Router# cef adjacency route override rib
```

## cef load-balancing

To configure load-balancing parameters, use the **cef load-balancing** command in Global configuration mode. To enable the default CEF load-balancing behavior, use the **no** form of this command.

```
cef load-balancing { mode hierarchical { ucmp group-size | ecmp min-path } <range> |
recursive oor mode dampening-and-dlb [ dampening resource-threshold <percentage> | dlb
resource-threshold <percentage> | max-duration <secs> ] }
```

Syntax Description	Parameter	Description
	<b>mode</b>	Specifies the mode as hierarchical.
	<b>hierarchical</b>	Specifies the configuration for multi-level load balancing in CEF.
	<b>ucmp</b>	Specifies the <b>ucmp</b> parameters for CEF load-balancing configuration.
	<b>group-size</b>	Enables <b>ucmp</b> group size for hierarchical load balancing (HLB).
	<b>ecmp</b>	Specifies the <b>ecmp</b> parameters for CEF load-balancing configuration.
	<b>min-path</b>	Specifies the minimum number of paths required for hierarchical <b>ecmp</b> load balancing.
	<i>range</i>	Specifies the range of values for configuring the group size for <b>ucmp</b> and minimum paths for <b>ecmp</b> in hierarchical load balancing. The routers supports the values ranging from 1 to 128.
	<b>recursive</b>	Enables recursive route configuration.
	<b>oor</b>	Enables oor configuration.
	<b>dlb</b>	Specifies the dynamic load balancing (DLB) parameter in CEF load balancing.
	<b>dampening-and-dlb</b>	Enables dampening and dlb mode for oor handling.
	<b>dampening</b>	Configure dampening mode parameters.
	<b>resource-threshold</b>	Specifies the resource threshold percentage to enable dynamic load-balancing mode.
	<i>percentage</i>	Specifies the threshold percentage for enabling FIB dampening and DLB features.
	<b>max-duration</b>	Specifies the maximum duration time configuration for dampening and dynamic load balancing in CEF load balancing.
	<i>secs</i>	Specifies the maximum duration time, in seconds, for configuring dampening and dynamic load balancing in CEF load balancing. You can configure the time range from 1 to 600 seconds.

**Command Default** None

**Command Modes** Global configuration

Command History	Release	Modification
	Release 24.2.1	This command was introduced.

### Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **cef load-balancing mode hierarchical ecmp min-paths** command is a replacement for the **cef hierarchical-load-balancing ecmp min-paths** command.

If the number of paths exceeds 128, HLB is automatically applied.

The **cef load-balancing mode hierarchical ucmp group-size** command is a replacement for the **cef hierarchical-load-balancing ucmp group-size** command.

Task ID	Task ID	Operation
	cef	read, write

### Example

The following example shows how to enable FIB dampening and DLB features with default values of dampening threshold percentage and max switchover duration and dlb threshold percentage as (70%, 300 sec, 90%)

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# cef load-balancing recursive oor mode dampening-and-dlb
```

The following example shows how to enable FIB dampening and DLB features with default values of dampening threshold percentage and max switchover duration and dlb threshold percentage as (70%, 90%).

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# cef load-balancing recursive oor mode dampening-and-dlb max-duration
600
```

The following example shows how to configure dampening and dynamic load balancing with specified resource-threshold for dampening and dlb each and maximum duration for switchover time.



**Note** The dampening threshold value should be lower than the DLB threshold.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# cef load-balancing recursive oor mode dampening-and-dlb dampening
resource-threshold 99 max-duration 600 dlb resource-threshold 99
```

The following example shows how to configure the group size for ucmp in hierarchical load balancing

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# cef load-balancing mode hierarchical ucmp group-size 128
```

The following example shows how to configure the minimum paths for hierarchical ecmp load balancing.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router# cef load-balancing mode hierarchical ecmp min-path 128
```

## clear adjacency statistics

To clear adjacency packet and byte counter statistics, use the **clear adjacency statistics** command in XR EXEC mode.

**clear adjacency statistics** [**ipv4** [**nexthop** *ipv4-address*] | **mpls** | **ipv6**] [*interface-type interface-instance* | **location** *node-id*]

Syntax Description	
<b>ipv4</b>	(Optional) Clears only IPv4 adjacency packet and byte counter statistics.
<b>nexthop</b> <i>ipv4-address</i>	(Optional) Clears adjacency statistics that are destined to the specified IPv4 nexthop.
<b>mpls</b>	(Optional) Clears only MPLS adjacency statistics.
<b>ipv6</b>	(Optional) Clears only IPv6 adjacency statistics.
<b>interface-type</b>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<b>interface-instance</b>	(Optional) Either a physical interface instance or a virtual interface instance: <ul style="list-style-type: none"> <li>• Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation.               <ul style="list-style-type: none"> <li>• <i>rack</i>: Chassis number of the rack.</li> <li>• <i>slot</i>: Physical slot number of the line card.</li> <li>• <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li>• <i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric ( <i>RP0</i> ) and the module is <i>CPU0</i>. Example: interface <i>MgmtEth0/ RP0</i></p> <ul style="list-style-type: none"> <li>• Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>location</b> <i>node-id</i>	(Optional) Clears detailed adjacency statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>Command Default</b>	No default behavior or values
<b>Command Modes</b>	XR EXEC mode



Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **clear adjacency statistics** command is useful for troubleshooting network connection and forwarding problems.

If you do not specify any of the optional keywords, all adjacency statistics are cleared for the node on which the command is issued.

Task ID	Task ID	Operations
	basic-services	read, write
	cef	read, write

Related Commands	Command	Description
	<a href="#">show adjacency, on page 159</a>	Displays the IPv4 CEF adjacency table.

# clear cef ipv4 drops

To clear Cisco Express Forwarding (CEF) IPv4 packet drop counters, use the **clear cef ipv4 drops** command in XR EXEC mode.

**clear cef ipv4 drops location *node-id***

<b>Syntax Description</b>	<b>location <i>node-id</i></b> Clears IPv4 packet drop counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, this command will clear IPv4 CEF drop counters only for the node on which the command is issued.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read, write
	cef	read, write

## Examples

The following example displays sample output for the IPv4 Cisco Express Forwarding (CEF) table packet drop counters, and clears IPv4 CEF drop counters for location 0/RP0/CPU0:

```
Router# show cef ipv4 drops

CEF Drop Statistics
Node: 0/RP0/CPU0
  Unresolved drops   packets : 0
  Unsupported drops  packets : 0
  Null0 drops        packets : 0
  No route drops     packets : 0
  No Adjacency drops packets : 0
  Checksum error drops packets : 0
  RPF drops          packets : 0
  RPF suppressed drops packets : 0
  RP destined drops  packets : 0
  Discard drops      packets : 0
  GRE lookup drops   packets : 0
  GRE processing drops packets : 0
  LISP punt drops    packets : 0
  LISP encap err drops packets : 0
```

```
LISP decap err drops packets :           0
Node: 0/RP1/CPU0
  Unresolved drops      packets :         0
  Unsupported drops     packets :         0
  Null0 drops           packets :         0
  No route drops        packets :         0
  No Adjacency drops    packets :         0
  Checksum error drops  packets :         0
  RPF drops             packets :         0
  RPF suppressed drops  packets :         0
  RP destined drops     packets :         0
  Discard drops         packets :         0
  GRE lookup drops      packets :         0
  GRE processing drops  packets :         0
  LISP punt drops       packets :         0
  LISP encap err drops  packets :         0
  LISP decap err drops  packets :         0
```

```
Router# clear cef ipv4 drops location 0/RP0/CPU0
```

```
Node: 0/RP0/CPU0
Clearing CEF Drop Statistics
```

# clear cef ipv4 exceptions

To clear IPv4 Cisco Express Forwarding (CEF) exception packet counters, use the **clear cef ipv4 exceptions** command in XR EXEC mode.

**clear cef ipv4 exceptions location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Clears IPv4 CEF exception packet counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, this command will clear IPv4 CEF exception packet counters for all nodes.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read, write
	cef	read, write

**Examples**

The following example displays sample output for the IPv4 Cisco Express Forwarding (CEF) exception packet counters, and clear s IPv4 CEF exception packets node 0/RP0/CPU0:

```
Router# show cef ipv4 exceptions

CEF Exception Statistics
Node: 0/RP0/CPU0
  Slow encap packets :          0
  Unsupported packets :          0
  Redirect packets   :          0
  Receive packets   :          0
  Broadcast packets  :          0
  IP options packets :          0
  TTL expired packets :          0
  Fragmented packets :          0
Node: 0/RP1/CPU0
  Slow encap packets :          3
  Unsupported packets :          0
  Redirect packets   :          0
  Receive packets   :        12787
  Broadcast packets  :        74814
```

```
IP options packets :           0
TTL expired packets :           0
Fragmented packets :           0
```

```
Router# clear cef ipv4 exceptions location 0/RP0/CPU0
```

```
Node: 0/RP0/CPU0
```

```
Clearing CEF Exception Statistics
```

# clear cef ipv6 drops

To clear Cisco Express Forwarding (CEF) IPv6 packet drop counters, use the **clear cef ipv6 drop** command in XR EXEC mode.

**clear cef ipv6 drops location *node-id***

<b>Syntax Description</b>	<b>location <i>node-id</i></b> Clears IPv6 packet drop counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, this command clears IPv6 CEF drop counters for all nodes.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read, write
	cef	read, write

**Examples**

The following example displays sample output for the IPv6 Cisco Express Forwarding (CEF) table packet drop counters, and clears IPv6 CEF drop counters for location 0/RP0/CPU0:

```
Router# show cef ipv6 drops

CEF Drop Statistics
Node: 0/RP0/CPU0
  Unresolved drops   packets :      0
  Unsupported drops  packets :      0
  Null0 drops        packets :      0
  No route drops     packets :      1
  No Adjacency drops packets :      0
  Checksum error drops packets :      0
  RPF drops          packets :      0
  RPF suppressed drops packets :      0
  RP destined drops  packets :      0
  Discard drops      packets :      0
  GRE lookup drops   packets :      0
  GRE processing drops packets :      0
  LISP punt drops    packets :      0
  LISP encap err drops packets :      0
```

```
LISP decap err drops packets :           0
Node: 0/RP1/CPU0
  Unresolved drops      packets :         0
  Unsupported drops     packets :         0
  Null0 drops           packets :         0
  No route drops        packets :         1
  No Adjacency drops    packets :         0
  Checksum error drops  packets :         0
  RPF drops             packets :         0
  RPF suppressed drops  packets :         0
  RP destined drops     packets :         0
  Discard drops         packets :         0
  GRE lookup drops      packets :         0
  GRE processing drops  packets :         0
  LISP punt drops       packets :         0
  LISP encap err drops  packets :         0
  LISP decap err drops  packets :         0
```

```
Router# clear cef ipv6 drop
```

```
Node: 0/RP0/CPU0
Clearing CEF Drop Statistics
```

# clear cef ipv6 exceptions

To clear IPv6 Cisco Express Forwarding (CEF) exception packet counters, use the **clear cef ipv6 exceptions** command in XR EXEC mode .

**clear cef ipv6 exceptions location** *node-id*

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Clears IPv6 CEF exception packet counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, this command clears IPv6 CEF exception packet counters for all nodes.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	basic-services	read, write
	cef	read, write

<b>Examples</b>	The following example displays sample output for the IPv6 Cisco Express Forwarding (CEF) exception packet counters, and clears the IPv6 CEF exception packets for location:
-----------------	---

```
Router# show cef ipv6 exceptions

CEF Exception Statistics
Node: 0/RP0/CPU0
  Slow encap packets :          0
  Unsupported packets :          0
  Redirect packets   :          0
  Receive packets   :           1
  Broadcast packets :           0
  IP options packets :           0
  TTL expired packets :          0
  Fragmented packets :          0

Node: 0/RP1/CPU0
  Slow encap packets :          0
  Unsupported packets :          0
  Redirect packets   :          0
  Receive packets   :           7
```



```
Broadcast packets :          0
IP options packets :         0
TTL expired packets :        0
Fragmented packets :         0
```

```
Router# clear cef ipv6 exceptions location 0/RP0/CPU0
```

```
Node: 0/RP0/CPU0
```

```
Clearing CEF Exception Statistics
```

# hw-module profile cef

To configure cef profile on a Global Configuration level, use the `hw-module profile cef` command in the XR Config mode.



**Note** Use the **lpts acl** option in the `hw-module profile cef` command in the Global Configuration mode. To disable the LPTS ACL mode, use the **no** form of this command.

```
hw-module profile cef { [ bgplu enable ] | [ dark-bw enable ] | [ lpts acl ] |
[ source-rtbh enable ] }
```

Syntax Description	Parameter	Description
	<b>bgplu</b>	Configures the bgplu feature.
	<b>dark-bw</b>	Configures the dark bandwidth.
	<b>lpts acl</b>	Configures the lpts acl mode
	<b>source-rtbh enable</b>	Configures source-based Remote Triggered Black Hole filtering (RTBH).

**Command Default** No default behavior or values

**Command Modes** XR Config

Command History	Release	Modification
	Release 7.5.2	The <b>lpts acl</b> option was introduced.
	Release 7.0.12	This command was introduced.
	Release 24.2.1	This command was modified. The <b>source-rtbh enable</b> keyword-pair was introduced.

Task ID	Task ID	Operations
	basic-services	read, write
	cef	read, write

**Usage Guidelines** You must reload the router after executing the **hw-module profile cef** command.

For more information about configuring Dark Bandwidth (dark-bw), see chapter *Implementing MPLS Traffic Engineering* in the *MPLS Configuration Guide for Cisco 8000 Series Routers*.

# hw-module profile route scale

To increase the route scale for IPv4 or IPv6 traffic types, use the **hw-module profile stats route-scale** command in XR Config mode.

**hw-module profile route scale lpm tcam-banks wide-entries shortened**

## Syntax Description

<b>lpm tcam-banks</b>	Increases the IPv4 route scale from 2 million to 3 million entries and IPv6 route scale from 0.5 million to 1 million entries.
<b>lpm wide-entries shortened</b>	Shortens the wide routing prefixes for IPv6 addresses.

## Command Default

By default, the route scale for IPv4 traffic is 2 million entries and IPv6 traffic is 0.5 million entries.

## Command Mode

XR Config

## Command History

Release	Modification
Release 24.1.1	The <b>lpm wide-entries shortened</b> keyword was introduced.
Release 7.9.1	This command was introduced.

## Usage Guidelines

- You must reload the router after executing the **hw-module profile route scale** command.
- When you increase the route scale, it will result in restricted resources for packet classification features such as Security ACL, QoS ACL, BGP Flowspec, and LPTS.
- The **hw-module profile route scale lpm wide-entries shortened** command isn't enabled by default, and we recommend using it judiciously to accommodate higher number of wide-entry IPv6 prefixes.

Task ID	Operations
config-services	read, write
root-lr	read, write

## Examples

The following example shows you how to configure the **hw-module profile route scale** command:

```
Router# config
Router(config)# hw-module profile route scale lpm tcam-banks
Router(config)# commit
Router# reload location all
```

The following example shows you how to configure the **hw-module profile route scale lpm wide-entries shortened** command:

```
Router# config
Router(config)# hw-module profile route scale lpm wide-entries shortened
Router(config)# commit
Router# reload location all
```

# show adjacency

To display Cisco Express Forwarding (CEF) adjacency table information, use the **show adjacency** command in XR EXEC mode.

```
show adjacency [ipv4 [nexthop ipv4-address] | mpls | ipv6] [interface type interface-instance]
[remote] [detail] [location node-id]
```

Syntax	Description
<b>ipv4</b>	(Optional) Displays only IPv4 adjacencies.
<b>nexthop</b> <i>ipv4-address</i>	(Optional) Displays adjacencies that are destined to the specified IPv4 nexthop.
<b>mpls</b>	(Optional) Displays only MPLS adjacencies.
<b>ipv6</b>	(Optional) Displays only IPv6 adjacencies.
<i>interface-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-instance</i>	<p>Either a physical interface instance or a virtual interface instance:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>remote</b>	(Optional) Displays only remote adjacencies. A remote adjacency is an internal adjacency used to forward packets between line cards.
<b>detail</b>	(Optional) Displays detailed adjacency information, including Layer 2 information.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines**

This command is used to verify that an adjacency exists for a connected device, that the adjacency is valid, and that the MAC header rewrite string is correct.

If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the CEF adjacency table for the node on which the command is issued.

**Task ID**

Task ID	Operations
cef	read

**Examples**

The following is sample output from **show adjacency** command with the **location** keyword specified:

```
Router# show adjacency location 0/RP1/CPU0
```

Interface	Address	Version	Refcount	Protocol
FH0/0/0/21	(interface)	5	1 ( 0)	
FH0/0/0/17	(interface)	9	1 ( 0)	
Mg0/RP0/CPU0/0	(interface)	1	1 ( 0)	
FH0/0/0/13	(interface)	13	1 ( 0)	
Hu0/0/0/34	(interface)	27	1 ( 0)	
FH0/0/0/3	(interface)	23	1 ( 0)	
Hu0/0/0/30	(interface)	31	1 ( 0)	
FH0/0/0/7	(interface)	19	1 ( 0)	
Hu0/0/0/26	(interface)	35	1 ( 0)	
FH0/0/0/11	(interface)	15	1 ( 0)	
FH0/0/0/20	(interface)	6	1 ( 0)	
FH0/0/0/16	(interface)	10	1 ( 0)	
FH0/0/0/12	(interface)	14	1 ( 0)	
Hu0/0/0/33	(interface)	28	1 ( 0)	
FH0/0/0/4	(interface)	22	1 ( 0)	
Hu0/0/0/29	(interface)	32	1 ( 0)	
FH0/0/0/8	(interface)	18	1 ( 0)	
Hu0/0/0/25	(interface)	36	1 ( 0)	
Hu0/0/0/24	(interface)	37	1 ( 0)	
FH0/0/0/23	(interface)	3	1 ( 0)	
FH0/0/0/19	(interface)	7	1 ( 0)	
Hu0/0/0/32	(interface)	29	1 ( 0)	
FH0/0/0/15	(interface)	11	1 ( 0)	
Hu0/0/0/28	(interface)	33	1 ( 0)	
FH0/0/0/1	(interface)	25	1 ( 0)	
FH0/0/0/5	(interface)	21	1 ( 0)	
FH0/0/0/9	(interface)	17	1 ( 0)	
FH0/0/0/0	(interface)	2	1 ( 0)	
FH0/0/0/22	(interface)	4	1 ( 0)	
FH0/0/0/18	(interface)	8	1 ( 0)	
FH0/0/0/14	(interface)	12	1 ( 0)	
Hu0/0/0/35	(interface)	26	1 ( 0)	
FH0/0/0/2	(interface)	24	1 ( 0)	
Hu0/0/0/31	(interface)	30	1 ( 0)	
FH0/0/0/6	(interface)	20	1 ( 0)	
Hu0/0/0/27	(interface)	34	1 ( 0)	
FH0/0/0/10	(interface)	16	1 ( 0)	

This table describes the significant fields shown in the display.

**Table 7: show adjacency Command Field Descriptions**

Field	Description
Interface	Outgoing interface associated with the adjacency.
Address	Address can represent one of these addresses: <ul style="list-style-type: none"> <li>• Next hop IPv4 or IPv6 address</li> <li>• Point-to-Point address</li> </ul> Information in parentheses indicates different types of adjacency.
Version	Version number of the adjacency. Updated whenever the adjacency is updated.
RefCount	Number of references to this adjacency.
Protocol	Protocol for which the adjacency is associated.
0f000800 and 000c86f33d330800453a21c10800	Layer 2 encapsulation string.
mtu	Value of the maximum transmission unit (MTU).
flags	Internal field.
packets	Number of packets going through the adjacency.
bytes	Number of bytes going through the adjacency.

# show cef bgp-attribute

To display Border Gateway Protocol (BGP) attributes for Cisco Express Forwarding (CEF), use the **show cef bgp-attribute** command in XR EXEC mode.

**show cef bgp-attribute** [**attribute-id index-id**] [**local-attribute-id index-id**] [**location node-id**]

Syntax Description	
<b>attribute-id index-id</b>	(Optional) Displays FIB attribute index.
<b>local-attribute-id index-id</b>	(Optional) Displays FIB local attribute index.
<b>location node-id</b>	(Optional) Displays BGP information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** The default location is active RP.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This command has no keywords or arguments.

Task ID	Task ID	Operations
	cef	read

**Examples** The following example shows how to use the **show cef bgp-attribute** command:

```
Router# show cef bgp-attribute

Total number of entries: 75742
BGP Attribute ID: 0x2058a, Local Attribute ID: 0x1
  Origin AS: 195, Next Hop AS: 195
BGP Attribute ID: 0x20583, Local Attribute ID: 0x2
  Origin AS: 22, Next Hop AS: 22
BGP Attribute ID: 0x20582, Local Attribute ID: 0x3
  Origin AS: 21, Next Hop AS: 21
BGP Attribute ID: 0x20585, Local Attribute ID: 0x4
  Origin AS: 28, Next Hop AS: 28
BGP Attribute ID: 0x20584, Local Attribute ID: 0x5
  Origin AS: 27, Next Hop AS: 27
BGP Attribute ID: 0x2057f, Local Attribute ID: 0x6
  Origin AS: 86, Next Hop AS: 86
BGP Attribute ID: 0x2058b, Local Attribute ID: 0x7
  Origin AS: 196, Next Hop AS: 196
BGP Attribute ID: 0x20589, Local Attribute ID: 0x8
  Origin AS: 194, Next Hop AS: 194
```



This table describes the significant fields shown in the display.

**Table 8: show cef bgp-attribute Command Field Descriptions**

<b>Field</b>	<b>Description</b>
BGP Attribute ID	Displays the id assigned by BGP.
Local Attribute ID	Displays the id assigned by FIB.
Origin AS	Displays the origin AS of the prefix that carries this attribute id.
Next Hop AS	Displays the AS that contains the BGP nexthop for this prefix.

# show cef

To display information about packets forwarded by Cisco Express Forwarding (CEF), use the **show cef** command in XR EXEC mode.

```
show cef tables [prefix [mask]] [ hardware { egress } | detail ] [ location { node-id | all } ]
```

## Syntax Description

<b>prefix</b>	(Optional) Longest matching CEF entry for the specified IPv4 destination prefix.
<b>mask</b>	(Optional) Exact CEF entry for the specified IPv4 prefix and mask.
<b>hardware</b>	(Optional) Displays detailed information about hardware.
<b>egress</b>	Displays information from the egress packets.
<b>detail</b>	(Optional) Displays full details.
<b>location node-id</b>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>all</b>	(Optional) Displays all locations.
<b>tables</b>	Displays the list of tables known to Forwarding Information Base (FIB).

## Command Default

When the prefix is not explicitly specified, this command displays all the IPv4 prefixes that are present in CEF. When not specified, the location defaults to the active Route Processor (RP) node.

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 24.4.1	This command was modified to include the <b>tables</b> keyword.
Release 7.0.12	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Task ID

Task ID	Operations
cef	read

## Examples

The following sample output shows the load information flag from the **show cef** command for both **hardware** and **ingress** keywords:

```

Router# show cef 192.0.2.1/16 hardware ingress location 0/RP0/CPU0

Tue Apr 28 04:17:05.105 UTC
192.0.2.1/32, version 25, internal 0x1000001 0x0 (ptr 0x8e7cf528) [1], 0x0 (0x8e9a7a68),
0x0 (0x0)
Updated Apr 28 04:06:38.879
local adjacency 9.1.58.5
Prefix Len 32, traffic index 0, precedence n/a, priority 1
gateway array (0x8e80fe90) reference count 2, flags 0x0, source rib (7), 0 backups
[3 type 3 flags 0x8401 (0x8e8c1cd8) ext 0x0 (0x0)]
LW-LDI[type=3, refc=1, ptr=0x8e9a7a68, sh-ldi=0x8e8c1cd8]
gateway array update type-time 1 Apr 28 04:06:38.879
LDI Update time Apr 28 04:06:38.899
LW-LDI-TS Apr 28 04:06:38.899
via 192.0.10.1/32, Bundle-Ether4, 7 dependencies, weight 0, class 0 [flags 0x0]
path-idx 0 NHID 0x0 [0x8fa2a260 0x0]
next hop 9.1.58.5/32
local adjacency
via 192.0.20.1/32, Bundle-Ether28, 7 dependencies, weight 0, class 0 [flags 0x0]
path-idx 1 NHID 0x0 [0x8fa2a140 0x0]
next hop 9.9.28.2/32
local adjacency
via 10.28.1.2/32, Bundle-Ether2801, 7 dependencies, weight 0, class 0 [flags 0x0]
path-idx 2 NHID 0x0 [0x8fa2a1d0 0x0]
next hop 192.0.30.1/32
local adjacency

Load distribution: 0 1 2 (refcount 3)

Hash OK Interface Address
0 Y Bundle-Ether4 192.0.10.1
1 Y Bundle-Ether28 192.0.20.1
2 Y Bundle-Ether2801 192.0.30.1

```

The following sample output shows the Cisco Express Forwarding (CEF) tables from the **show cef** command for **tables** keyword:

```

Router# show cef tables detail

Codes: L - SVD Local Routes, R - SVD Remote Routes
T - Total Routes
C - Table Converged, D - Table Deleted
M - Table Marked, S - Table Subscribed
F - Fallback VRF, FM - Fallback VRF Marked

Table Table ID L R T C D M S F FM
cofo-v4 0x2b 0 0 0 N N N N N N

---Origin Protocol Routes---
DIRECTLY_CONNECTED 0
LOCAL 0
STATIC 0
BGP 0
ISIS 0
OSPF 0
GRIBI 0

vrf1 0xe0000201 0 0 5 N N N Y N N

---Origin Protocol Routes---
DIRECTLY_CONNECTED 0
LOCAL 0
STATIC 0

```

show cef

```

      BGP                0
      ISIS               0
      OSPF               0
      GRIBI              0

default      0xe0000000    22      0      46 N N N Y N N

---Origin Protocol      Routes---
  DIRECTLY_CONNECTED    0
  LOCAL                 0
  STATIC                0
  BGP                   0
  ISIS                  0
  OSPF                  0
  GRIBI                 0

iid          0xe0000801    0      0      5 N N N Y N N

---Origin Protocol      Routes---
  DIRECTLY_CONNECTED    0
  LOCAL                 0
  STATIC                0
  BGP                   0
  ISIS                  0
  OSPF                  0
  GRIBI                 0

decap_te    0xe0000101    0      0      5 N N N Y N N

---Origin Protocol      Routes---
  DIRECTLY_CONNECTED    0
  LOCAL                 0
  STATIC                0
  BGP                   0
  ISIS                  0
  OSPF                  0
  GRIBI                 0

```

## show cef exact-route (user-data)

To display the route taken from a source IP to a destination IP, use the **show cef exact-route** command in XR EXEC mode.

```
show cef [exact-route ipv4-source-address ipv4-destination-address protocol protocol source-port
source-port destination-port destination-port { ingress-interface ingress-interface | user-data user-data
ingress-interface ingress-interface [ brief | detail | hardware | internal | location | policy-class |
protocol ] } ]
```

Syntax	Description				
<b>exact-route</b>	(Optional) Displays the egress interface where traffic corresponding to the other specified parameters will be sent.				
<i>ipv4-source-address</i>	Specifies IPv4 source address in x.x.x.x format.				
<i>ipv4-destination-address</i>	Specifies IPv4 destination address in x.x.x.x format.				
<b>protocol</b> <i>protocol</i>	Specifies protocol number or name for this route. For more information, use the question mark (?) online help function.				
<b>source-port</b> <i>source-port</i>	Specifies the source port number. The range is from 0 to 65535.				
<b>destination-port</b> <i>destination-port</i>	Specifies the destination port number. The range is from 0 to 65535.				
<b>ingress-interface</b>	(Optional) Specifies the ingress interface information.				
<b>user-data</b> <i>user-data</i>	(Optional) Specifies the additional user chosen data bytes used in multi-path computation. In <i>user-data</i> , you can enter 1-4 bytes in hexadecimal.				
<b>ingress-interface</b> <i>ingress-interface</i>	Specifies the ingress interface information.				
<b>brief</b>	(Optional) Displays brief information of CEF table.				
<b>detail</b>	(Optional) Displays full information of CEF table.				
<b>hardware</b>	(Optional) Displays information from hardware.				
<b>location</b>	(Optional) Provides the forwarding information for the designated node. The node-id argument is entered in the <i>rack/slot/module</i> notation.				
<b>policy-class</b>	(Optional) Class for policy-based tunnel selection.				
<b>Command Default</b>	None				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.5.5</td> <td>The keyword <b>user-data</b> was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.5.5	The keyword <b>user-data</b> was introduced.
Release	Modification				
Release 7.5.5	The keyword <b>user-data</b> was introduced.				

**show cef exact-route (user-data)**

Release	Modification
Release 24.2.11	The keyword <b>user-data</b> was introduced.
Release 7.0.12	This command was introduced.

**Usage Guidelines**

If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the CEF table on the node in which the command is issued. Otherwise, the command is effective on the node specified by the **location** *node-id* keyword and argument.

**Task ID**

Task ID	Task	Operations
	cef	read

**Examples**

The following is a sample output of the **show cef exact-route** command:

```
Router# show cef exact-route 100.0.0.10 60.1.0.1 protocol 253 source-port 0 destination-port
 0 user-data 0x4 ingress-interface HundredGigE0/0/0/2 location 0/0/cpu0

Mon Aug 14 07:56:18.145 UTC

Unsupported protocol value 253
48.0.0.0/4, version 1377, internal 0x1000001 0x20 (ptr 0x8b470510) [1], 0x400 (0x8e0d45e8),
0x0 (0x0)
Updated Aug 14 07:50:20.022
local adjacency to HundredGigE0/0/0/26.29

Prefix Len 4, traffic index 0, precedence n/a, priority 2
via HundredGigE0/0/0/26.29
via 34.0.9.2/32, HundredGigE0/0/0/26.29, 5 dependencies, weight 0, class 0 [flags 0x0]
path-idx 1 NHID 0x0 [0x8c60c480 0x0]
next hop 34.0.9.2/32
local adjacency
```

# show cef ext-client

To display Cisco Express Forwarding (CEF) external client dependency information, use the **show cef ext-client** command in XR EXEC mode.

**show cef ext-client** [ **detail** | **hardware** | **internal** | **location** | **summary** ]

Syntax	Description
<b>detail</b>	(Optional) Displays all information of all external clients in details.
<b>hardware</b>	(Optional) Displays hardware information of external clients.
<b>internal</b>	(Optional) Displays internal information of external clients.
<b>location</b> <i>node-id</i>	(Optional) Displays external client dependency information for the specified node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>prefix</b>	(Optional) Displays external client information for a specific prefix.
<b>resolved</b>	(Optional) Displays external client information for resolved ECD prefixes.
<b>summary</b>	(Optional) Displays summary of external client information.
<b>unresolved</b>	(Optional) Displays external client information for unresolved specific prefixes.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

The following sample output is from the show cef external command:

```
Router#show cef ext-client summary
Thu Apr  9 15:33:32.259 UTC
Client Name: mfwd6 (comp-id: 0x89a)
-----
Protocol           : ipv4
# of Registrations : 0
# of Pending notif: 0
Client last pulsed : Never
```

```
ECD version: 1
# of ECD Pathlist: 0

Client Name: l2fib_mgr (comp-id: 0x7e6d)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0

Client Name: ipv4_IPV4_MRIB (comp-id: 0x305)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0

Client Name: XTC_AGENT (comp-id: 0x19fc)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0

Client Name: object_tracking (comp-id: 0xc99)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0

Client Name: mfwd (comp-id: 0x348)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0

Client Name: PBR_EA (comp-id: 0x1277)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0

Client Name: bfd_agent (comp-id: 0x859)
-----
Protocol          : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
```



```
# of ECD Pathlist: 0

Client Name: IPV4_ABF (comp-id: 0x1e01)
-----
Protocol      : ipv4
# of Registrations : 0
# of Pending notifs: 0
Client last pulsed : Never
ECD version: 1
# of ECD Pathlist: 0
```

**Related Commands**

Command	Description
<a href="#">show cef, on page 164</a>	Displays information about packets forwarded by Cisco Express Forwarding (CEF).

## show cef ipv4 adjacency

To display Cisco Express Forwarding (CEF) IPv4 adjacency status and configuration information, use the **show cef ipv4 adjacency** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv4 adjacency [interface-type interface-path-id] [location node-id] [detail]
[discard] [glean] [null] [punt] [remote] [protected]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>interface-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface- path-id</i>	(Optional) Either a physical interface instance or a virtual interface instance: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> For more information about the syntax for the router, use the question mark (?) online help function.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>detail</b>	(Optional) Displays the detailed adjacency information.
<b>discard</b>	(Optional) Filters out and displays only the discarded adjacency information.
<b>glean</b>	(Optional) Filters out and displays only the glean adjacency information.
<b>null</b>	(Optional) Filters out and displays only the adjacency information.
<b>punt</b>	(Optional) Filters out and displays only the punt adjacency information.
<b>remote</b>	(Optional) Filters out and displays only the remote adjacency information.
<b>protected</b>	(Optional) Filters out and displays only the IP-Fast Reroute (FRR) protected adjacency information.
<b>Command Default</b>	No default behavior or values

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the **show cef ipv4 adjacency** command displays the CEF adjacency table for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

### Examples

The following sample output is from **show cef ipv4 adjacency** command :

```
Router# show cef ipv4 adjacency

Display protocol is ipv4
Interface      Address                                     Type      Refcount
-----
Hu0/6/0/16
    Interface: Hu0/6/0/16 Type: glean
    Interface Type: 0x0, Base Flags: 0x220 (0x8ceb3f98)
    Nhinfo PT: 0x8ceb3f98, Idb PT: 0x8cb35a20,
    If Handle: 0x30001e0 no dependent adj
    Ancestor If Handle: 0x0
Update time Dec  7 11:20:35.145

Hu0/6/0/16 Prefix: 10.0.22.2/32                local    9
Adjacency: PT:0x8d5752b8 10.0.22.2/32
Interface: Hu0/6/0/16
NHID: 0x0
MAC: e6.07.2b.8d.33.f0.e6.48.5c.10.b3.a0.08.00
Interface Type: 0x0, Base Flags: 0x1 (0x8d001fa0)
Nhinfo PT: 0x8d001fa0, Idb PT: 0x8cb35a20,
If Handle: 0x30001e0 no dependent adj
Ancestor If Handle: 0x0
Update time Dec  7 11:20:45.022

Hu0/6/0/18
    Interface: Hu0/6/0/18 Type: glean
    Interface Type: 0x0, Base Flags: 0x220 (0x8ceb44c0)
    Nhinfo PT: 0x8ceb44c0, Idb PT: 0x8cb35920,
    If Handle: 0x30001f0 no dependent adj
    Ancestor If Handle: 0x0
Update time Dec  7 11:20:33.449

Hu0/6/0/18 Prefix: 10.0.62.2/32                local    10
Adjacency: PT:0x8d5794a0 10.0.62.2/32
Interface: Hu0/6/0/18
NHID: 0x0
MAC: e6.07.2b.8d.34.48.e6.48.5c.10.b3.a8.08.00
Interface Type: 0x0, Base Flags: 0x1 (0x8d002aa0)
Nhinfo PT: 0x8d002aa0, Idb PT: 0x8cb35920
If Handle: 0x30001f0 no dependent adj
```

```
        Ancestor If Handle: 0x0  
Update time Dec  7 11:20:45.019
```

This table describes the significant fields shown in the display.

**Table 9: show cef ipv4 adjacency Command Field Descriptions**

Field	Description
Interface	Interface associated with the prefix.
Address	Prefix address information.
Type	Type of adjacency, can be either local or remote.
Refcount	Number of times the adjacency is referenced by other routers.

# show cef ipv4 adjacency hardware

To display Cisco Express Forwarding (CEF) IPv4 adjacency hardware status and configuration information, use the **show cef ipv4 adjacency hardware** command in XR EXEC mode.

**show cef**[vrf *vrf-name*] **ipv4 adjacency hardware** {egress} [**detail** | **discard** | **drop** | **glean** | **location** *node-id* | **null** | **punt** | **protected** | **remote**]

Syntax Description	Parameter	Description
	<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	<b>egress</b>	Displays information from the egress packets.
	<b>detail</b>	(Optional) Displays full details.
	<b>discard</b>	(Optional) Displays the discard adjacency information.
	<b>drop</b>	(Optional) Displays the drop adjacency information.
	<b>glean</b>	(Optional) Displays the glean adjacency information.
	<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>null</b>	(Optional) Displays the null adjacency information.
	<b>punt</b>	(Optional) Displays the punt adjacency information.
	<b>protected</b>	(Optional) Filters out and displays only the IP-Fast Reroute (FRR) protected adjacency information.
	<b>remote</b>	(Optional) Displays the remote adjacency information.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output shows the load information flag from the **show cef ipv4 adjacency hardware** command for the **egress** keyword:

```
Router# show cef ipv4 adjacency hardware egress detail location 0/RP0/CPU0
Tue Apr 28 04:15:15.408 UTC
Display protocol is ipv4
Interface      Address                                          Type      Refcount

BE3
  Interface: BE3 Type: glean
  Interface Type: 0x1c, Base Flags: 0x10001100 (0x8deeece0)
  Nhinfo PT: 0x8deeece0, Idb PT: 0x8db2a1c0, If Handle: 0xf00001c
no dependent adj
  Ancestor If Handle: 0x0
  Update time Apr 28 03:49:04.881

BE3      Prefix: 9.1.48.4/32                          local    5
  Adjacency: PT:0x8e68dlb8 9.1.48.4/32
  Interface: BE3
  NHID: 0x0
  MAC: 78.70.32.67.6d.03.b0.65.62.36.20.03.08.00
  Interface Type: 0x1c, Base Flags: 0x10000001 (0x8fa2a0b0)
  Nhinfo PT: 0x8fa2a0b0, Idb PT: 0x8db2a1c0, If Handle: 0xf00001c
no dependent adj
  Ancestor If Handle: 0x0
  Update time Apr 28 03:49:05.238

BE4
  Interface: BE4 Type: glean
  Interface Type: 0x1c, Base Flags: 0x10001100 (0x8deeed68)
  Nhinfo PT: 0x8deeed68, Idb PT: 0x8db2a250, If Handle: 0xf000024
no dependent adj
  Ancestor If Handle: 0x0
  Update time Apr 28 03:49:04.884

BE4      Prefix: 9.1.58.5/32                          local    7
  Adjacency: PT:0x8e68d548 9.1.58.5/32
  Interface: BE4
  NHID: 0x0
  MAC: 78.46.8e.f2.f9.03.b0.65.62.36.20.02.08.00
  Interface Type: 0x1c, Base Flags: 0x10000001 (0x8fa2a260)
  Nhinfo PT: 0x8fa2a260, Idb PT: 0x8db2a250, If Handle: 0xf000024
no dependent adj
  Ancestor If Handle: 0x0
  Update time Apr 28 04:05:26.678

BE28
  Interface: BE28 Type: glean
  Interface Type: 0x1c, Base Flags: 0x10001100 (0x8deeedf0)
  Nhinfo PT: 0x8deeedf0, Idb PT: 0x8db2a2e0, If Handle: 0xf00002c
no dependent adj
  Ancestor If Handle: 0x0
  Update time Apr 28 03:49:04.884

BE28      Prefix: 9.9.28.2/32                          local    7
  Adjacency: PT:0x8e68d2e8 9.9.28.2/32
  Interface: BE28
```

```
NHID: 0x0
MAC: 78.70.d8.38.0d.03.b0.65.62.36.20.01.08.00
Interface Type: 0x1c, Base Flags: 0x10000001 (0x8fa2a140)
Nhinfo PT: 0x8fa2a140, Idb PT: 0x8db2a2e0, If Handle: 0xf00002c
no dependent adj
Ancestor If Handle: 0x0
Update time Apr 28 04:04:30.218

BE2801                                     special 2
Interface: BE2801 Type: glean
Interface Type: 0x1c, Base Flags: 0x10001100 (0x8deeee78)
Nhinfo PT: 0x8deeee78, Idb PT: 0x8db2a370, If Handle: 0xf000034
no dependent adj
Ancestor If Handle: 0x0
Update time Apr 28 03:49:04.884

BE2801      Prefix: 10.28.1.2/32           local  7
Adjacency: PT:0x8e68d418 10.28.1.2/32
Interface: BE2801
NHID: 0x0
MAC: 78.70.d8.38.0d.02.b0.65.62.36.20.00.08.00
Interface Type: 0x1c, Base Flags: 0x10000001 (0x8fa2a1d0)
Nhinfo PT: 0x8fa2a1d0, Idb PT: 0x8db2a370, If Handle: 0xf000034
no dependent adj
Ancestor If Handle: 0x0
Update time Apr 28 04:04:30.218
```

## show cef ipv4

To display the IPv4 Cisco Express Forwarding (CEF) table, use the **show cef ipv4** command in XR EXEC mode.

**show cef** [**vrf** *vrf-name*] **ipv4** [*prefix* [*mask*] | *interface-type interface-instance*] [**detail**] [**location** *node-id*]

Syntax	Description
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>prefix</i>	(Optional) Longest matching CEF entry for the specified IPv4 destination prefix.
<i>mask</i>	(Optional) Exact CEF entry for the specified IPv4 prefix and mask.
<i>interface-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-instance</i>	<p>Either a physical interface instance or a virtual interface instance:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0) and the module is CPU0. Example: interface MgmtEth0/RP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>detail</b>	(Optional) Displays full CEF entry information.
<b>location</b> <i>node-id</i>	(Optional) Displays the IPv4 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>Command Default</b>	If the location is not specified, the command defaults to the active RP node.
<b>Command Modes</b>	XR EXEC mode



Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the CEF table on the node in which the command is issued. Otherwise, the command is effective on the node specified by the **location** *node-id* keyword and argument.

Task ID	Task ID	Operations
	cef	read

### Examples

The following sample output is from the **show cef ipv4** command:

```
Router# show cef ipv4
Prefix          Next Hop          Interface
-----
0.0.0.0/0      drop              default handler
0.0.0.0/32     broadcast
1.75.55.1/32   1.76.0.1/32     <recursive>
1.76.0.0/16    attached         MgmtEth0/RP0/CPU0/0
1.76.0.0/32    broadcast        MgmtEth0/RP0/CPU0/0
1.76.0.1/32    1.76.0.1/32     MgmtEth0/RP0/CPU0/0
1.76.0.2/32    1.76.0.2/32     MgmtEth0/RP0/CPU0/0
1.76.0.3/32    1.76.0.3/32     MgmtEth0/RP0/CPU0/0
1.76.11.2/32   1.76.11.2/32    MgmtEth0/RP0/CPU0/0
```

```
Router# show cef ipv4
Prefix          Next Hop          Interface
-----
0.0.0.0/0      drop              default handler
0.0.0.0/32     broadcast
1.75.55.1/32   1.76.0.1/32     <recursive>
1.76.0.0/16    attached         MgmtEth0/RP0/CPU0/0
1.76.0.0/32    broadcast        MgmtEth0/RP0/CPU0/0
1.76.0.1/32    1.76.0.1/32     MgmtEth0/RP0/CPU0/0
1.76.0.2/32    1.76.0.2/32     MgmtEth0/RP0/CPU0/0
1.76.0.3/32    1.76.0.3/32     MgmtEth0/RP0/CPU0/0
1.76.11.2/32   1.76.11.2/32    MgmtEth0/RP0/CPU0/0
```

This table describes the significant fields shown in the display.

**Table 10: show cef ipv4 Command Field Descriptions**

Field	Description
Prefix	Prefix in the IPv4 CEF table.
Next Hop	Next hop of the prefix.
Interface	Interface associated with the prefix.

## show cef ipv4 drops

To display IPv4 Cisco Express Forwarding (CEF) table packet drop counters, use the **show cef ipv4 drops** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv4 drops [location node-id]
```

<b>Syntax Description</b>	<b>vrf</b> (Optional) Displays VPN routing and forwarding (VRF) instance information.				
	<i>vrf-name</i> (Optional) Name of a VRF.				
	<b>location</b> <i>node-id</i> (Optional) Displays IPv4 CEF table packet drop counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	<p>A packet might be dropped from the IPv4 CEF table because of unresolved CEF entries, unsupported features, absence of route information, absence of adjacency information, or an IP checksum error.</p> <p>If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, this command displays IPv4 CEF packet drop counters for all nodes.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>cef</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	cef	read
Task ID	Operations				
cef	read				

### Examples

The following is sample output from the **show cef ipv4 drops** for location command:

```
Router# show cef ipv4 drops

CEF Drop Statistics
Node: 0/RP0/CPU0
  Unresolved drops   packets :           0
  Unsupported drops  packets :           0
  Null0 drops        packets :           0
  No route drops     packets :           0
  No Adjacency drops packets :           0
  Checksum error drops packets :           0
  RPF drops          packets :           0
  RPF suppressed drops packets :           0
  RP destined drops  packets :           0
  Discard drops      packets :           0
  GRE lookup drops   packets :           0
  GRE processing drops packets :           0
  LISP punt drops    packets :           0
```

```

LISP encap err drops packets :           0
LISP decap err drops packets :           0

Node: 0/RP1/CPU0
  Unresolved drops      packets :           0
  Unsupported drops    packets :           0
  Null0 drops          packets :           0
  No route drops       packets :           0
  No Adjacency drops   packets :           0
  Checksum error drops packets :           0
  RPF drops            packets :           0
  RPF suppressed drops packets :           0
  RP destined drops    packets :           0
  Discard drops        packets :           0
  GRE lookup drops     packets :           0
  GRE processing drops packets :           0
  LISP punt drops      packets :           0
  LISP encap err drops packets :           0
  LISP decap err drops packets :           0

```

**Table 11: show cef ipv4 drop Command Field Descriptions**

Field	Description
Unresolved drops	Drops due to unresolved routes.
Unsupported drops	Drops due to an unsupported feature.
Null0 drops	Drops to the Null0 interface.
No route drops	Number of packets dropped because there were no routes to the destination.
No Adjacency drops	Number of packets dropped because there were no adjacencies established.
Checksum error drops	Drops due to IPv4 checksum error.
RPF drops	Drops due to IPv4 unicast RPF <sup>1</sup> .
RPF suppressed drops	Drops suppressed due to IPv4 unicast RPF.
RP destined drops	Drops destined for the router.
Discard drops	Drops those were discarded.
GRE lookup drops	GRE packets dropped during GRE Lookup.
GRE processing drops	GRE packets dropped during GRE Processing.
LISP punt drops	LISP packets dropped during software processing of the packets.
LISP encap err drops	LISP encap packets dropped due to errors.
LISP decap err drops	LISP Decap packets dropped due to errors.

<sup>1</sup> RPF = Reverse Path Forwarding

## show cef ipv4 exact-route

To display an IPv4 Cisco Express Forwarding (CEF) exact route, use the **show cef ipv4 exact-route** command in XR EXEC mode.

```
show cef [vrf vrf-name]ipv4 exact-route {source-address destination-address} [protocol protocol-name]
[source-port source-port] [destination-port destination-port] [type
interface-path-id] [policy-class-value] [detail | location node-id] { ingress-interface ingress-interface |
user-data user-data ingress-interface ingress-interface [ brief | detail | hardware | internal | location
| policy-class | protocol ] }
```

### Syntax Description

<b>vrf</b>	(Optional) Sets VPN routing and forwarding (VRF) instance information.
<b>vrf-name</b>	(Optional) Name of a VRF.
<b>source-address</b>	The IPv4 source address in x.x.x.x format.
<b>destination-address</b>	The IPv4 destination address in x.x.x.x format.
<b>protocol protocol name</b>	(Optional) Sets the specified protocol for the route.
<b>source-port source-port</b>	(Optional) Sets the TCP and UDP source port. The range is from 0 to 65535.
<b>destination-port destination-port</b>	(Optional) Sets the TCP and UDP destination port. The range is from 0 to 65535.
<b>type</b>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<b>interface-path-id</b>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>detail</b>	(Optional) Provides full CEF entry information.
<b>location node-id</b>	(Optional) Provides the IPv4 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>ingress-interface</b>	(Optional) Specifies the ingress interface information.
<b>user-data user-data</b>	(Optional) Specifies the additional user chosen data bytes used in multi-path computation. In <i>user-data</i> , you can enter 1-4 bytes in hexadecimal.
<b>ingress-interface ingress-interface</b>	Specifies the ingress interface information.
<b>brief</b>	(Optional) Displays brief information of CEF table.

<b>detail</b>	(Optional) Displays full information of CEF table.
<b>hardware</b>	(Optional) Displays information from hardware.
<b>location</b>	(Optional) Provides the forwarding information for the designated node. The node-id argument is entered in the <i>rack/slot/module</i> notation.
<b>policy-class</b>	(Optional) Class for policy-based tunnel selection.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.5.5	The keyword <b>user-data</b> was introduced.
	Release 24.2.11	The keyword <b>user-data</b> was introduced.
	Release 7.0.12	This command was introduced.

**Usage Guidelines** For TCP and UDP protocols, configure the source-port and destination-port mandatorily. For other protocols, configure the source-port and destination-port as zero. Otherwise, the output of the **show cef ipv4 exact-route** command is not correct.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read

## Examples

The following sample output is from the **show cef ipv4 exact-route** command:

```
Router# show cef ipv4 exact-route 192.0.2.1 198.51.100.1 protocol TCP source-port 25000
destination-port 30000 ingress-interface HundredGigE 0/0/0/24
Wed Apr 15 02:15:16.102 UTC
5.5.5.5/32, version 18, labeled SR, internal 0x1000001 0x8110 (ptr 0x94730608) [1], 0x0
(0x94710b18), 0xa28 (0x9849c0a8)
Updated Apr 14 19:08:57.655 local adjacency 30.0.0.2
Prefix Len 32, traffic index 0, precedence n/a, priority 1, encap-id 0x1000800000001
via Bundle-Ether3
via 30.0.0.2/32, Bundle-Ether3, 7 dependencies, weight 0, class 0 [flags 0x0]
path-idx 1 NHID 0x0 [0x97b2d338 0x0]
next hop 30.0.0.2/32
local adjacency
local label 21555 labels imposed {21555}
```

The following is a sample output of the **show cef ipv4 exact-route** command with **user-data** keyword:

```
Router# show cef ipv4 exact-route 100.0.0.10 60.1.0.1 protocol 253 source-port 0
destination-port 0 user-data 0x4 ingress-interface HundredGigE0/0/0/2 location 0/0/cpu0
Mon Aug 14 07:56:18.145 UTC
```

## show cef ipv4 exact-route

```

Unsupported protocol value 253
48.0.0.0/4, version 1377, internal 0x1000001 0x20 (ptr 0x8b470510) [1], 0x400 (0x8e0d45e8),
0x0 (0x0)
Updated Aug 14 07:50:20.022
local adjacency to HundredGigE0/0/0/26.29

Prefix Len 4, traffic index 0, precedence n/a, priority 2
via HundredGigE0/0/0/26.29
via 34.0.9.2/32, HundredGigE0/0/0/26.29, 5 dependencies, weight 0, class 0 [flags 0x0]
  path-idx 1 NHID 0x0 [0x8c60c480 0x0]
  next hop 34.0.9.2/32
  local adjacency

```

This table describes the significant fields shown in the display.

**Table 12: show cef ipv4 exact-route Command Field Descriptions**

Field	Description
Prefix	Prefix in the IPv4 CEF table .
Next Hop	Next hop of the prefix
Interface	Interface associated with the prefix

# show cef ipv4 exceptions

To display IPv4 Cisco Express Forwarding (CEF) exception packet counters, use the **show cef ipv4 exceptions** command in .

```
show cef [vrf vrf-name] ipv4 exceptions [location node-id]
```

Syntax Description	Parameter	Description
	<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	<b>location</b> <i>node-id</i>	(Optional) Displays CEF exception packet counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

## Command Modes

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** CEF exception packets are those packets that have been sent from the hardware to the software because they require additional handling. The types of IPv4 CEF exception packets are displayed in the command's output and are defined.

If you do not specify a node with the **location** keyword and *node-id* argument, this command displays IPv4 CEF exception packet counters on all nodes.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv4 exceptions** command:

```
Router# show cef ipv4 exceptions

CEF Exception Statistics
Node: 0/RP0/CPU0
  Slow encap packets :           0
  Unsupported packets :           0
  Redirect packets :             0
  Receive packets :             0
  Broadcast packets :           0
  IP options packets :           0
  TTL expired packets :           0
  Fragmented packets :           0
Node: 0/RP1/CPU0
  Slow encap packets :           3
  Unsupported packets :           0
  Redirect packets :             0
```

```

Receive      packets :          12787
Broadcast   packets :          74814
IP options  packets :              0
TTL expired packets :              0
Fragmented  packets :              0

```

This table describes the significant fields shown in the display.

**Table 13: show cef ipv4 exceptions Command Field Descriptions**

Field	Description
Slow encap	Number of packets requiring special processing during encapsulation.
Redirect	Number of ICMP <sup>2</sup> redirect messages sent.
Receive	Number of packets destined to the router.
Broadcast	Number of broadcasts received.
IP options	Number of IP option packets.
TTL expired	Number of packets with expired TTLs <sup>3</sup> .
Fragmented	Number of packets that have been fragmented.

<sup>2</sup> ICMP = internet control message protocol

<sup>3</sup> TTL = time to live



# show cef ipv4 hardware

To display Cisco Express Forwarding (CEF) IPv4 hardware status and configuration information, use the **show cef ipv4 hardware** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv4 hardware {egress | [detail | location node-id]}
```

Syntax Description	
vrf	(Optional) Displays VPN routing and forwarding (VRF) instance information.
vrf-name	(Optional) Name of a VRF.
egress	Displays information from the egress packets.
detail	(Optional) Displays full details.
<b>location</b> node-id	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output is from the **show cef ipv4 hardware** command:

```
Router# show cef ipv4 hardware egress detail location 0/RP0/CPU0

Wed Apr 22 09:06:45.028 UTC
0.0.0.0/0, version 0, proxy default, default route handler, drop adjacency, internal 0x1001011
0x0 (ptr 0x919f10b8) [1], 0x0 (0x919bf0a8), 0x0 (0x0)
Updated Apr 22 09:03:29.837
Prefix Len 0, traffic index 0, precedence n/a, priority 15
gateway array (0x918320a8) reference count 1, flags 0x200, source default (12), 0 backups

[2 type 3 flags 0xa401 (0x918e50a8) ext 0x0 (0x0)]
LW-LDI[type=3, refc=1, ptr=0x919bf0a8, sh-ldi=0x918e50a8]
gateway array update type-time 1 Apr 22 09:03:29.838
LDI Update time Apr 22 09:03:29.881
LW-LDI-TS Apr 22 09:03:29.881
```

## show cef ipv4 hardware

```

via 0.0.0.0/32, 3 dependencies, weight 0, class 0 [flags 0x0]
  path-idx 0 NHID 0x0 [0x90e9d810 0x0]
  next hop 0.0.0.0/32
  drop adjacency

```

Show-data Print at RPLC

```

LEAF - HAL pd context :
sub-type : IPV4, ecd_marked:0, has_collapsed_ldi:0
collapse_bwalk_required:0, ecdv2_marked:0,
HW Walk:
LEAF:
  trans_id: 29
  PI_ctx: 0x30919f10b8
  eng_ctx: 0x30919f1158
  revision: 29
  hal_leaf_type: IPV4
  created_in_ofa: 1
  NHGROUP_key: {ID: 24-14-00-10-01-00-00-00}
  leaf npd data:

```

```

FIB_HAL_OBJECT_NRLWLDI:
  hal_proto: 12
  trans_id: 0
  prev_trans_id: 28
  engctx: 0x30919bf0e8

```

```

FIB_HAL_OBJECT_SHLDI:
  hal_proto: 12
  trans_id: 0
  prev_trans_id: 27
  engctx: 0x30918e5178
  nhgroup
    key: 24140010 01000000
    num paths: 1
    oor_state: 0
    is_protected[0]: 0
    next_obj[0] type: 6
    next_obj[0] exceptionnh key: type,4, intf,0, proto,0
  nhgroup npd data:

```

```

c_nextobj_ip6llnhtnh=NS,0:rdesc_nextobj_nhgrouptnh=NS

```

```

HW Walk:
LEAF:
  trans_id: 29
  PI_ctx: 0x30919f10b8
  eng_ctx: 0x30919f1158
  revision: 29
  hal_leaf_type: IPV4
  created_in_ofa: 1
  NHGROUP_key: {ID: 24-14-00-10-01-00-00-00}
  leaf npd data:

```



## show cef ipv4 hardware

```

path-idx 0 NHID 0x0 [0x90e9e468 0x0]
next hop 0.0.0.0/32
external adjacency

```

Show-data Print at RPLC

```

LEAF - HAL pd context :
sub-type : IPV4, ecd_marked:0, has_collapsed_ldi:0
collapse_bwalk_required:0, ecdv2_marked:0,
HW Walk:
LEAF:

```

```

trans_id: 41
PI_ctx: 0x30919f1478
eng_ctx: 0x30919f1518
revision: 41
hal_leaf_type: IPV4
created_in_ofa: 1
NHGROUP_key: {ID: 24-14-00-10-02-00-00-00}
leaf npd data:

```

```

FIB_HAL_OBJECT_NRLWLDI:
hal_proto: 12
trans_id: 0
prev_trans_id: 40
engctx: 0x30919c1788

```

```

FIB_HAL_OBJECT_SHLDI:
hal_proto: 12
trans_id: 0
prev_trans_id: 39
engctx: 0x30918e7a78
nhgroup
key: 24140010 02000000
num paths: 1
oor_state: 0
is_protected[0]: 0
next_obj[0] type: 6
next_obj[0] exceptionnh key: type,1, intf,0, proto,0
nhgroup npd data:

```

```

nextobj_ip6llnhtnh=NS,0:rdesc_nextobj_nhgroupntnh=NS

```

HW Walk:

```

LEAF:
trans_id: 41
PI_ctx: 0x30919f1478
eng_ctx: 0x30919f1518
revision: 41
hal_leaf_type: IPV4
created_in_ofa: 1
NHGROUP_key: {ID: 24-14-00-10-02-00-00-00}
leaf npd data:

```



## show cef ipv4 hardware

```

leaf npd data:

Load distribution: 0 (refcount 2)

Hash OK Interface Address
0 Y recursive receive
255.255.255.255/32, version 0, broadcast
Updated Apr 22 09:03:29.905
Prefix Len 32

Show-data Print at RPLC

LEAF - HAL pd context :
sub-type : IPV4, ecd_marked:0, has_collapsed_ldi:0
collapse_bwalk_required:0, ecdv2_marked:0,
HW Walk:
LEAF:
trans_id: 32
PI_ctx: 0x30919f11a8
eng_ctx: 0x30919f1248
revision: 32
hal_leaf_type: IPV4
created_in_ofa: 1
ExceptionNH_key: {type: 2, proto: 0, l3addr: 0.0.0.0}
leaf npd data:

FIB_HAL_OBJECT_NRLWLDI:
hal_proto: 12
trans_id: 0
prev_trans_id: 31
engctx: 0x30919bfa90

FIB_HAL_OBJECT_SHLDI:
hal_proto: 12
trans_id: 0
prev_trans_id: 30
engctx: 0x30918e5bb8

HW Walk:
LEAF:
trans_id: 32
PI_ctx: 0x30919f11a8
eng_ctx: 0x30919f1248
revision: 32
hal_leaf_type: IPV4
created_in_ofa: 1
ExceptionNH_key: {type: 2, proto: 0, l3addr: 0.0.0.0}
leaf npd data:

```

# show cef ipv4 interface

To display IPv4 Cisco Express Forwarding (CEF)-related information for an interface, use the **show cef ipv4 interface** command in XR EXEC mode.

```
show cef[vrf vrf-name] ipv4 interface type interface-path-id [detail] [location node-id]
```

Syntax	Description
vrf	(Optional) Displays VPN routing and forwarding (VRF) instance information.
vrf-name	(Optional) Name of a VRF.
type	Interface type. For more information, use the question mark (?) online help function.
in interface-path-id	<p>Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0) and the module is CPU0. Example: interface HundredGigE 0/RP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
detail	(Optional) Displays detailed CEF information for all the interfaces on the node in which the command is issued.
location node-id	(Optional) Displays IPv4 CEF-related information for an interface. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the **show cef ipv4 interface rpf-statistics** command displays the CEF-related information for the interface on the route processor.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv4 interface** command:

```
Router# show cef ipv4 interface HundredGigE 0/0/0/24
HundredGigE0/0/0/0 is up if_handle 0x0f000138 if_type IFT_HUNDREDGE(0x49)
    idb info 0x9093e730 flags 0x8001 ext 0x942c8da8 flags 0x50
    Vrf Local Info (0x95106328)
    Interface last modified Jan 13, 2020 06:08:29, create
    Reference count 1      Next-Hop Count 2
    Forwarding is enabled
    ICMP redirects are never sent
    ICMP unreachable are enabled
    Protocol MTU 1500, TableId 0xe0000000(0x90d43400)
    Protocol Reference count 2
    Primary IPV4 local address 100.0.0.6/32
```

This table describes the significant fields shown in the display.

**Table 14: show cef ipv4 interface Command Field Descriptions**

Field	Description
HundredGigE0/0/0/24 is down	Status of the interface.
if_handle	Internal interface handle.
Forwarding is enabled	Indicates that Cisco Express Forwarding (CEF) is enabled.
ICMP redirects are always sent or never sent	Indicates whether ICMP <sup>4</sup> redirect messages should be sent. By default, ICMP redirect messages are always sent.
IP MTU	Value of the IPv4 MTU <sup>5</sup> size set on the interface.
Reference count	Internal reference counter.

<sup>4</sup> ICMP = internet control message protocol

<sup>5</sup> MTU = maximum transmission unit



## show cef ipv4 non-recursive

To display the IPv4 nonrecursive prefix entries in the IPv4 Cisco Express Forwarding (CEF) table, use the **show cef ipv4 non-recursive** command in XR EXEC mode.

**show cef** [**vrf** *vrf-name*] **ipv4 non-recursive** [**detail**] [**hardware** {**egress** | **ingress**}] [*interface-type interface-instance*] [**location** *node-id*]

Syntax	Description
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<b>vrf-name</b>	(Optional) Name of a VRF.
<b>detail</b>	(Optional) Displays detailed information about nonrecursive prefix entries in the IPv4 CEF table.
<b>hardware</b>	(Optional) Displays detailed information about hardware.
<b>egress</b>	(Optional) Displays egress NPU.
<b>ingress</b>	(Optional) Displays ingress NPU.
<b>interface-type</b>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<b>interface-instance</b>	<p>(Optional) Either a physical interface instance or a virtual interface instance:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0) and the module is CPU0. Example: interface MgmtEth0/RP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>location</b> <i>node-id</i>	(Optional) Displays the IPv4 nonrecursive prefix entries in the IPv4 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

## show cef ipv4 non-recursive

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the output displays the IPv4 CEF nonrecursive routes for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv4 non-recursive** command:

```
Router# show cef ipv4 non-recursive

Prefix                Next Hop                Interface
0.0.0.0/0             1012.8.0.1
0.0.0.0/32            broadcast
10.8.0.0/16           attached                MgmtEth0/0/CPU0/0
10.8.0.0/32           broadcast                MgmtEth0/0/CPU0/0
10.8.0.1/32           12.8.0.1                MgmtEth0/0/CPU0/0
10.8.0.2/32           12.8.0.2                MgmtEth0/0/CPU0/0
10.8.0.3/32           12.8.0.3                MgmtEth0/0/CPU0/0
10.8.16.10/32         12.8.16.10              MgmtEth0/0/CPU0/0
10.8.16.30/32         12.8.16.30              MgmtEth0/0/CPU0/0
10.8.16.40/32         12.8.16.40              MgmtEth0/0/CPU0/0
10.8.28.8/32          12.8.28.8               MgmtEth0/0/CPU0/0
10.8.28.101/32        12.8.28.101             MgmtEth0/0/CPU0/0
10.8.28.103/32        12.8.28.103             MgmtEth0/0/CPU0/0
10.8.28.104/32        12.8.28.104             MgmtEth0/0/CPU0/0
10.8.28.106/32        receive                  MgmtEth0/0/CPU0/0
10.8.29.113/32        12.8.29.113             MgmtEth0/0/CPU0/0
10.8.29.118/32        12.8.29.118             MgmtEth0/0/CPU0/0
10.8.29.140/32        12.8.29.140             MgmtEth0/0/CPU0/0
10.8.33.101/32        12.8.33.101             MgmtEth0/0/CPU0/0
10.8.33.103/32        12.8.33.103             MgmtEth0/0/CPU0/0
10.8.33.105/32        12.8.33.105             MgmtEth0/0/CPU0/0
10.8.33.110/32        12.8.33.110             MgmtEth0/0/CPU0/0
10.8.57.1/32          12.8.57.1               MgmtEth0/0/CPU0/0
10.8.255.255/32       broadcast                MgmtEth0/0/CPU0/0
10.29.31.2/32         12.29.31.2              MgmtEth0/0/CPU0/0
10.255.0.0/16         attached                 MgmtEth0/0/CPU0/0
10.255.254.254/32    10223.255.254.254      MgmtEth0/0/CPU0/0
10.0.0.0/4            0.0.0.0
10.0.0.0/24           receive
255.255.255.255/32   broadcast
```

This table describes the significant fields shown in the display.

**Table 15: show cef ipv4 non-recursive Command Field Descriptions**

Field	Description
Prefix	Nonrecursive prefixes detected on the node.

Field	Description
Next Hop	Routing next hop.
Interface	Interface associated with the nonrecursive prefix.

# show cef ipv4 resource

To display the IPv4 nonrecursive prefix entries in the IPv4 Cisco Express Forwarding (CEF) table, use the **show cef ipv4 resource** command in XR EXEC mode.

```
show cef ipv4 resource [detail] [ hardware { egress | ingress } ] [location node-id]
```

Syntax Description	detail	(Optional) Displays detailed information resources listed in the IPv4 CEF table.
	location node-id	(Optional) Displays the IPv4 resource entries in the IPv4 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the output displays the IPv4 CEF nonrecursive routes for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv4 resource** command:

```
Router# show cef ipv4 resource detail

CEF resource availability summary state: GREEN
CEF will work normally
  ipv4 shared memory resource:
    CurrMode GREEN, CurrAvail 7167668222 bytes, MaxAvail 7242276863 bytes
  ipv6 shared memory resource:
    CurrMode GREEN, CurrAvail 7167668222 bytes, MaxAvail 7242276863 bytes
  mpls shared memory resource:
    CurrMode GREEN, CurrAvail 7167668222 bytes, MaxAvail 7242276863 bytes
  common shared memory resource:
    CurrMode GREEN, CurrAvail 7167668222 bytes, MaxAvail 7242276863 bytes
  DATA_TYPE_TABLE_SET hardware resource: GREEN
  DATA_TYPE_TABLE hardware resource: GREEN
  DATA_TYPE_IDB hardware resource: GREEN
  DATA_TYPE_IDB_EXT hardware resource: GREEN
  DATA_TYPE_LEAF hardware resource: GREEN
  DATA_TYPE_LOADINFO hardware resource: GREEN
  DATA_TYPE_PATH_LIST hardware resource: GREEN
  DATA_TYPE_NHINFO hardware resource: GREEN
```

```
DATA_TYPE_LABEL_INFO hardware resource: GREEN
DATA_TYPE_FRR_NHINFO hardware resource: GREEN
DATA_TYPE_ECD hardware resource: GREEN
DATA_TYPE_RECURSIVE_NH hardware resource: GREEN
DATA_TYPE_TUNNEL_ENDPOINT hardware resource: GREEN
DATA_TYPE_LOCAL_TUNNEL_INTF hardware resource: GREEN
DATA_TYPE_ECD_TRACKER hardware resource: GREEN
DATA_TYPE_ATTRIBUTE hardware resource: GREEN
DATA_TYPE_LSPA hardware resource: GREEN
DATA_TYPE_LDI_LW hardware resource: GREEN
DATA_TYPE_LDSH_ARRAY hardware resource: GREEN
DATA_TYPE_TE_TUN_INFO hardware resource: GREEN
DATA_TYPE_DUMMY hardware resource: GREEN
DATA_TYPE_IDB_VRF_LCL_CEF hardware resource: GREEN
DATA_TYPE_PROTO_GBL hardware resource: GREEN
DATA_TYPE_MOL hardware resource: GREEN
DATA_TYPE_MPI hardware resource: GREEN
DATA_TYPE_SUBS_INFO hardware resource: GREEN
DATA_TYPE_LISP_IPENCAP hardware resource: GREEN
DATA_TYPE_LSM_ID hardware resource: GREEN
DATA_TYPE_INTF_LIST hardware resource: GREEN
DATA_TYPE_TUNNEL_ENCAP_STR hardware resource: GREEN
DATA_TYPE_LABEL_RPF hardware resource: GREEN
DATA_TYPE_L2_SUBS_INFO hardware resource: GREEN
DATA_TYPE_LISP_IID_MAPPING hardware resource: GREEN
DATA_TYPE_LISP_RLOC_TBL hardware resource: GREEN
DATA_TYPE_NHID hardware resource: GREEN
DATA_TYPE_LOOKUP hardware resource: GREEN
DATA_TYPE_PREFIX_FILTER hardware resource: GREEN
DATA_TYPE_PREFIX_FILTER_TBL hardware resource: GREEN
DATA_TYPE_LLC_TBL hardware resource: GREEN
DATA_TYPE_LLC hardware resource: GREEN
DATA_TYPE_TI_PL_TBL hardware resource: GREEN
DATA_TYPE_RETRY_TBL hardware resource: GREEN
DATA_TYPE_RETRY hardware resource: GREEN
DATA_TYPE_OBJECT_QUEUE_HEAD hardware resource: GREEN
DATA_TYPE_OBJECT_MARKER hardware resource: GREEN
DATA_TYPE_PL_TRKR_ENTRY hardware resource: GREEN
DATA_TYPE_PL_TRKR_SHARE_NH hardware resource: GREEN
DATA_TYPE_NH_TRKR_SHARE_NH hardware resource: GREEN
DATA_TYPE_LEAF_TRKR_SHARE_NH hardware resource: GREEN
DATA_TYPE_FRR_NH_TRKR_SHARE_NH hardware resource: GREEN
DATA_TYPE_NH_REPL hardware resource: GREEN
DATA_TYPE_LEAF_EXT hardware resource: GREEN
DATA_TYPE_QUEUE_EXT hardware resource: GREEN
DATA_TYPE_COFO_TBL hardware resource: GREEN
DATA_TYPE_COFO_TBL_ENTRY hardware resource: GREEN
DATA_TYPE_COFO_IDB_TBL hardware resource: GREEN
DATA_TYPE_COFO_IDB_ENTRY hardware resource: GREEN
DATA_TYPE_DELETED_OBJECT_TBL hardware resource: GREEN
DATA_TYPE_DELETED_OBJECT hardware resource: GREEN
DATA_TYPE_SR6_GBL hardware resource: GREEN
DATA_TYPE_SR6A hardware resource: GREEN
DATA_TYPE_SR6I hardware resource: GREEN
DATA_TYPE_TEP hardware resource: GREEN
DATA_TYPE_LTEP hardware resource: GREEN
DATA_TYPE_TES hardware resource: GREEN
DATA_TYPE_ENCAP hardware resource: GREEN
DATA_TYPE_ENCAP_ARRAY hardware resource: GREEN
DATA_TYPE_ENCAP_IDA hardware resource: GREEN
DATA_TYPE_ENCAP_ID_TBL hardware resource: GREEN
DATA_TYPE_ENCAP_ID hardware resource: GREEN
```

# show cef ipv4 summary

To display a summary of the IPv4 Cisco Express Forwarding (CEF) table, use the **show cef ipv4 summary** command in XR EXEC mode.

**show cef** [**vrf** *vrf-name*] **ipv4 summary** [**location** *node-id*]

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<b>location</b> <i>node-id</i>	(Optional) Displays a summary of the IPv4 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays a summary of the IPv4 CEF table for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output is from the **show cef ipv4 summary** command:

```
Router# show cef ipv4 summary
Router ID is
10
0
.0.0.0

IP CEF with switching (Table Version 0)

Load balancing: L3
Tableid 0xe0000000, Vrfid 0x60000000, Vrid 0x20000000, Flags 0x301
Vrfname default, Refcount 367
193 routes, 0 reresolve, 0 unresolved (0 old, 0 new), 13896 bytes
204 load sharing elements, 51904 bytes, 154 references
17 shared load sharing elements, 5536 bytes
187 exclusive load sharing elements, 46368 bytes
0 CEF route update drops, 175 revisions of existing leaves
Resolution Timer: 15s
0 prefixes modified in place
```

```

0 deleted stale prefixes
16 prefixes with label imposition, 51 prefixes with label information
Adjacency Table has 44 adjacencies
1 incomplete adjacency

```

This table describes the significant fields shown in the display.

**Table 16: show cef ipv4 summary Command Field Descriptions**

Field	Description
Load balancing	Current load-balancing mode. The default value is L3.
Table Version	Version of the CEF table.
tableid	Table identification number.
vrfid	VPN routing and forwarding (VRF) identification (vrfid) number.
vrfname	VRF name.
vrid	Virtual router identification (vrid) number.
flags	Option value for the table
routes	Total number of routes.
resolve	Total number of routes being resolved.
unresolved ( <i>x</i> old, <i>x</i> new)	Number of routes not yet resolved.
load sharing elements	Total number of internal load-sharing data structures.
bytes	Total memory used by internal load sharing data structures.
references	Total reference count of all internal load sharing data structures.
CEF resets	Number of CEF table resets.
revisions of existing leaves	Number of updates to existing prefixes.
Exponential (currently <i>xs</i> , peak <i>xs</i> )	Currently not used.
prefixes modified in place	Prefixes modified in place.
Adjacency Table has <i>x</i> adjacencies	Total number of adjacencies.
<i>x</i> incomplete adjacency	Total number of incomplete adjacencies.

# show cef ipv4 unresolved

To display unresolved routes in the IPv4 Cisco Express Forwarding (CEF) table, use the **show cef ipv4 unresolved** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv4 unresolved [detail] [hardware {egress}] [location node-id]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<b>detail</b>	(Optional) Displays detailed information unresolved routes listed in the IPv4 CEF table.
<b>hardware</b>	(Optional) Displays detailed information about hardware.
<b>egress</b>	(Optional) Displays egress packets.
<b>location</b> <i>node-id</i>	(Optional) Displays the unresolved routes in the IPv4 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the output displays the unresolved routes for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv4 unresolved** command when an unresolved route is detected:

```
Router# show cef ipv4 unresolved

Prefix          Next Hop          Interface
10.3.3.3        102.2.2.2        ?
```



This table describes the significant fields shown in the display.

**Table 17: show cef ipv4 unresolved Command Field Descriptions**

<b>Field</b>	<b>Description</b>
Prefix	Prefix of the unresolved CEF.
Next Hop	Next hop of the unresolved CEF.
Interface	Next hop interface. A question mark (?) indicates that the interface has not been resolved.

## show cef ipv6 adjacency

To display Cisco Express Forwarding (CEF) IPv6 adjacency status and configuration information, use the **show cef ipv6 adjacency** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv6 adjacency [interface-type interface-path-id] [location node-id] [detail]
[discard] [glean] [null] [punt] [remote]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>interface-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface- path-id</i>	(Optional) Either a physical interface instance or a virtual interface instance: <ul style="list-style-type: none"> <li>• Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation.               <ul style="list-style-type: none"> <li>• <i>rack</i>: Chassis number of the rack.</li> <li>• <i>slot</i>: Physical slot number of the line card.</li> <li>• <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li>• <i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0) and the module is CPU0. Example: interface MgmtEth0/RP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>• Virtual interface instance. Number range varies depending on interface type.</li> </ul> For more information about the syntax for the router, use the question mark (?) online help function.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>detail</b>	(Optional) Displays the detailed adjacency information.
<b>discard</b>	(Optional) Filters out and displays only the discarded adjacency information.
<b>glean</b>	(Optional) Filters out and displays only the glean adjacency information.
<b>null</b>	(Optional) Filters out and displays only the null adjacency information.
<b>punt</b>	(Optional) Filters out and displays only the punt adjacency information.
<b>remote</b>	(Optional) Filters out and displays only the remote adjacency information.

---

**Command Default** No default behavior or values

---

**Command Modes** XR EXEC mode

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

---



---

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the CEF adjacency table for the node on which the command is issued.

---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read

---

# show cef ipv6 adjacency hardware

To display Cisco Express Forwarding (CEF) IPv6 adjacency hardware status and configuration information, use the **show cef ipv6 adjacency hardware** command in XR EXEC mode.

**show cef** [**vrf** *vrf-name*] **ipv6 adjacency hardware** {**egress**} [**detail** | **discard** | **drop** | **glean** | **location** *node-id* | **null** | **punt** | **remote**]

Syntax Description		
<b>vrf</b>	(Optional)	Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional)	Name of a VRF.
<b>egress</b>		Displays information from the egress packets.
<b>detail</b>	(Optional)	Displays full details.
<b>discard</b>	(Optional)	Displays the discard adjacency information.
<b>drop</b>	(Optional)	Displays the drop adjacency information.
<b>glean</b>	(Optional)	Displays the glean adjacency information.
<b>location</b> <i>node-id</i>	(Optional)	Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>null</b>	(Optional)	Displays the null adjacency information.
<b>punt</b>	(Optional)	Displays the punt adjacency information.
<b>remote</b>	(Optional)	Displays the remote adjacency information.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

**Examples** The following sample output is from the **show cef ipv6 adjacency hardware** command:

```

Router# sh cef ipv6 adjacency hardware egress location 0/6/CPU

Display protocol is ipv6
Interface      Address                                          Type      Refcount

BE31
    Interface: BE31 Type: glean
    Interface Type: 0x1c, Base Flags: 0x8001100
    Nhinfo PT: 0x9420ebb0, Idb PT: 0x93793f00, If Handle: 0xf00001c
no dependent adj
    Ancestor If Handle: 0x0
Update time May  4 22:49:44.108

Show-data Print at RPLC

BE31          Prefix: 45:31::5/128                          local    3
Adjacency: PT:0x91369078 45:31::5/128
Interface: BE31
NHID: 0x0
MAC: 78.d3.62.4d.c5.03.78.4a.33.fd.49.03.86.dd
Interface Type: 0x1c, Base Flags: 0x8000001
Nhinfo PT: 0x987610b0, Idb PT: 0x93793f00, If Handle: 0xf00001c
no dependent adj
    Ancestor If Handle: 0x0
Update time May  5 17:37:20.035

Show-data Print at RPLC

FIB_HAL_OBJECT_NHINFO_TX:
    hal_proto: 19
    trans_id: 0
    prev_trans_id: 693
    engctx: 0x3098761140

BE31          Prefix: fe80::7ad3:62ff:fe4d:c503/128          local    3
Adjacency: PT:0x913692d8 fe80::7ad3:62ff:fe4d:c503/128
Interface: BE31
NHID: 0x0
MAC: 78.d3.62.4d.c5.03.78.4a.33.fd.49.03.86.dd
Interface Type: 0x1c, Base Flags: 0x8000001
Nhinfo PT: 0x98761340, Idb PT: 0x93793f00, If Handle: 0xf00001c
no dependent adj
    Ancestor If Handle: 0x0
Update time May  5 17:37:20.063

Show-data Print at RPLC

FIB_HAL_OBJECT_NHINFO_TX:
    hal_proto: 19
    trans_id: 0
    prev_trans_id: 697
    engctx: 0x30987613d0

BE31.1
    special 2

```

## show cef ipv6 adjacency hardware

```

Interface: BE31.1 Type: glean
Interface Type: 0x19, Base Flags: 0x8001100
Nhinfo PT: 0x9420ee38, Idb PT: 0x93794290, If Handle: 0xf000024
no dependent adj
Ancestor If Handle: 0x0
Update time May 4 22:49:44.132

```

Show-data Print at RPLC

```

BE31.1          Prefix: 45:31:1::5/128                local  3
Adjacency: PT:0x91369408 45:31:1::5/128
Interface: BE31.1
NHID: 0x0
MAC: 78.d3.62.4d.c5.03.78.4a.33.fd.49.03.81.00.00.01.86.dd
Interface Type: 0x19, Base Flags: 0x8000001
Nhinfo PT: 0x987615d0, Idb PT: 0x93794290, If Handle: 0xf000024
no dependent adj
Ancestor If Handle: 0x0
Update time May 5 17:37:33.401

```

Show-data Print at RPLC

```

FIB_HAL_OBJECT_NHINFO_TX:
hal_proto: 19
trans_id: 0
prev_trans_id: 700
engctx: 0x3098761660

```

```

BE31.1          Prefix: fe80::7ad3:62ff:fe4d:c503/128        local  3
Adjacency: PT:0x91369668 fe80::7ad3:62ff:fe4d:c503/128
Interface: BE31.1
NHID: 0x0
MAC: 78.d3.62.4d.c5.03.78.4a.33.fd.49.03.81.00.00.01.86.dd
Interface Type: 0x19, Base Flags: 0x8000001
Nhinfo PT: 0x98761af0, Idb PT: 0x93794290, If Handle: 0xf000024
no dependent adj
Ancestor If Handle: 0x0
Update time May 5 17:37:33.414

```

Show-data Print at RPLC

```

FIB_HAL_OBJECT_NHINFO_TX:
hal_proto: 19
trans_id: 0
prev_trans_id: 705
engctx: 0x3098761b80

```

```

FH0/0/0/6          Interface: FH0/0/0/6 Type: glean                special 2
Interface Type: 0xcb, Base Flags: 0x8001100
Nhinfo PT: 0x9420e6a0, Idb PT: 0x93793320, If Handle: 0xf0001c8
no dependent adj
Ancestor If Handle: 0x0
Update time May 4 22:49:42.113

```

Show-data Print at RPLC

```
FH0/0/0/6      Prefix: 20::2/128                      local  3
Adjacency: PT:0x913698c8 20::2/128
Interface: FH0/0/0/6
NHID: 0x0
MAC: 78.1a.ee.b6.f0.00.78.4a.33.fd.48.30.86.dd
Interface Type: 0xcb, Base Flags: 0x8000001
Nhinfo PT: 0x98762010, Idb PT: 0x93793320, If Handle: 0xf0001c8
no dependent adj
Ancestor If Handle: 0x0
Update time May  5 17:39:48.833
```

Show-data Print at RPLC

```
FIB_HAL_OBJECT_NHINFO_TX:
hal_proto: 19
trans_id: 0
prev_trans_id: 709
engctx: 0x30987620a0
```

```
FH0/0/0/6      Prefix: fe80::7a1a:eeff:feb6:f000/128      local  3
Adjacency: PT:0x91369b28 fe80::7a1a:eeff:feb6:f000/128
Interface: FH0/0/0/6
NHID: 0x0
MAC: 78.1a.ee.b6.f0.00.78.4a.33.fd.48.30.86.dd
Interface Type: 0xcb, Base Flags: 0x8000001
Nhinfo PT: 0x98762530, Idb PT: 0x93793320, If Handle: 0xf0001c8
no dependent adj
Ancestor If Handle: 0x0
Update time May  5 17:39:53.830
```

Show-data Print at RPLC

```
FIB_HAL_OBJECT_NHINFO_TX:
hal_proto: 19
trans_id: 0
prev_trans_id: 714
engctx: 0x30987625c0
```

```
Hu0/0/0/32                                          special 2
Interface: Hu0/0/0/32 Type: glean
Interface Type: 0x49, Base Flags: 0x8001100
Nhinfo PT: 0x9420dc80, Idb PT: 0x93793878, If Handle: 0xf000218
no dependent adj
Ancestor If Handle: 0x0
Update time May  4 22:49:42.097
```

Show-data Print at RPLC

```
Hu0/0/0/31                                          special 2
Interface: Hu0/0/0/31 Type: glean
```

## show cef ipv6 adjacency hardware

```

                Interface Type: 0x49, Base Flags: 0x8001100
                Nhinfo PT: 0x9420d9f8, Idb PT: 0x93793910, If Handle: 0xf000220
no dependent adj
                Ancestor If Handle: 0x0
                Update time May  4 22:49:42.097

```

Show-data Print at RPLC

```

Hu0/0/0/30                                           special 2
                Interface: Hu0/0/0/30 Type: glean
                Interface Type: 0x49, Base Flags: 0x8001100
                Nhinfo PT: 0x9420d770, Idb PT: 0x937939a8, If Handle: 0xf000228
no dependent adj
                Ancestor If Handle: 0x0
                Update time May  4 22:49:42.090

```

Show-data Print at RPLC

```

Hu0/0/0/30.1                                       special 2
                Interface: Hu0/0/0/30.1 Type: glean
                Interface Type: 0x19, Base Flags: 0x8001100
                Nhinfo PT: 0x9420df08, Idb PT: 0x93793f98, If Handle: 0xf000258
no dependent adj
                Ancestor If Handle: 0x0
                Update time May  4 22:49:42.100

```

Show-data Print at RPLC

```

Hu0/0/0/31.1                                       special 2
                Interface: Hu0/0/0/31.1 Type: glean
                Interface Type: 0x19, Base Flags: 0x8001100
                Nhinfo PT: 0x9420e190, Idb PT: 0x93794030, If Handle: 0xf000260
no dependent adj
                Ancestor If Handle: 0x0
                Update time May  4 22:49:42.104

```

Show-data Print at RPLC

```

Hu0/0/0/32.1                                       special 2
                Interface: Hu0/0/0/32.1 Type: glean
                Interface Type: 0x19, Base Flags: 0x8001100
                Nhinfo PT: 0x9420e418, Idb PT: 0x937940c8, If Handle: 0xf000268
no dependent adj
                Ancestor If Handle: 0x0
                Update time May  4 22:49:42.107

```

Show-data Print at RPLC

```

FH0/0/0/6.1                                           special 2

```



```

Interface: FH0/0/0/6.1 Type: glean
Interface Type: 0x19, Base Flags: 0x8001100
Nhinfo PT: 0x9420e928, Idb PT: 0x93794160, If Handle: 0xf000270
no dependent adj
Ancestor If Handle: 0x0
Update time May 4 22:49:42.114

```

Show-data Print at RPLC

```

FH0/0/0/6.1 Prefix: 20:0:1::2/128 local 3
Adjacency: PT:0x91369d88 20:0:1::2/128
Interface: FH0/0/0/6.1
NHID: 0x0
MAC: 78.1a.ee.b6.f0.00.78.4a.33.fd.48.30.81.00.00.01.86.dd
Interface Type: 0x19, Base Flags: 0x8000001
Nhinfo PT: 0x98762a50, Idb PT: 0x93794160, If Handle: 0xf000270
no dependent adj
Ancestor If Handle: 0x0
Update time May 5 17:39:57.518

```

Show-data Print at RPLC

```

FIB_HAL_OBJECT_NHINFO_TX:
hal_proto: 19
trans_id: 0
prev_trans_id: 718
engctx: 0x3098762ae0

```

```

FH0/0/0/6.1 Prefix: fe80::7a1a:eeff:feb6:f000/128 local 3
Adjacency: PT:0x91369fe8 fe80::7a1a:eeff:feb6:f000/128
Interface: FH0/0/0/6.1
NHID: 0x0
MAC: 78.1a.ee.b6.f0.00.78.4a.33.fd.48.30.81.00.00.01.86.dd
Interface Type: 0x19, Base Flags: 0x8000001
Nhinfo PT: 0x98762f70, Idb PT: 0x93794160, If Handle: 0xf000270
no dependent adj
Ancestor If Handle: 0x0
Update time May 5 17:40:02.514

```

Show-data Print at RPLC

```

FIB_HAL_OBJECT_NHINFO_TX:
hal_proto: 19
trans_id: 0
prev_trans_id: 723
engctx: 0x3098763000

```

# show cef ipv6

To display the IPv6 Cisco Express Forwarding (CEF) table, use the **show cef ipv6** command in XR EXEC mode.

**show cef** [**vrf** *vrf-name*]] **ipv6** [*interface-type interface-number* / *ipv6-prefix/prefix-length*] [**detail**] [**location***node-id*]

Syntax	Description
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>interface-type interface-number</i>	(Optional) IPv6 prefixes going through the specified next hop interface.
<i>ipv6-prefix/prefix-length</i>	(Optional) Longest prefix entry in the CEF table matching the specified IPv6 prefix and prefix length.
<b>detail</b>	(Optional) Displays detailed IPv6 CEF table information.
<b>location</b> <i>node-id</i>	(Optional) Displays the IPv6 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the IPv6 CEF table for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output is from the **show cef ipv6** command:

```
Router# show cef ipv6

::/0
drop default handler
fe80::/10
receive
ff02::/16
```

```

receive
ff02::2/128
receive
ff02::1:ff00:0/104
receive
ff05::/16
receive
ff12::/16
receive

```

This table describes the significant fields shown in the display.

**Table 18: show cef ipv6 Command Field Descriptions**

Field	Description
drop	Indicates that packets sent to the destination prefix are dropped.
loopback	Indicates that the prefix points to a loopback address. Packets sent to loopback addresses are dropped.
receive	Indicates that the prefix is configured on one of the router interfaces. Packets sent to those prefixes are received by the router.
connected	Indicates that the prefix points to a directly connected next-hop interface.
recursive	Indicates that the prefix is not directly connected but is reachable through the next-hop prefix displayed.

The following sample output is from the **show cef ipv6** with the **detail** keyword:

```

Router# show cef ipv6 detail

::/0, version 0, proxy default, default route handler, drop adjacency, internal 0x1001011
0x0 (ptr 0x8d7d52dc) [1], 0x0 (0x8db46098), 0x0 (0x0)
Updated Nov 22 22:57:58.580
Prefix Len 0, traffic index 0, precedence n/a, priority 15
via ::/128, 3 dependencies, weight 0, class 0 [flags 0x0]
path-idx 0 NHID 0x0 [0x8cf1c218 0x0]
next hop ::/128
drop adjacency
::ffff:90.0.0.1/128, version 14, attached, receive
Updated Nov 25 15:28:03.320
Prefix Len 128
internal 0x1004141 (ptr 0x8d7d48b4) [1], 0x0 (0x8db462c8), 0x0 (0x0)
fe80::/10, version 0, receive
Updated Nov 22 22:57:58.611
Prefix Len 10
internal 0x1004001 (ptr 0x8d7d4cc4) [1], 0x0 (0x8db461e8), 0x0 (0x0)
ff02::/16, version 0, receive
Updated Nov 22 22:57:58.611
Prefix Len 16
internal 0x1004001 (ptr 0x8d7d4f14) [1], 0x0 (0x8db46140), 0x0 (0x0)
ff02::2/128, version 0, receive
Updated Nov 22 22:57:58.611
Prefix Len 128
internal 0x1004001 (ptr 0x8d7d4fe4) [1], 0x0 (0x8db46108), 0x0 (0x0)
ff02::1:ff00:0/104, version 0, receive
Updated Nov 22 22:57:58.601

```

```

Prefix Len 104
internal 0x1004001 (ptr 0x8d7d520c) [1], 0x0 (0x8db460d0), 0x0 (0x0)
ff05::/16, version 0, receive
Updated Nov 22 22:57:58.607
Prefix Len 16
internal 0x1004001 (ptr 0x8d7d513c) [1], 0x0 (0x8db461b0), 0x0 (0x0)
ff12::/16, version 0, receive
Updated Nov 22 22:57:58.607
Prefix Len 16
internal 0x1004001 (ptr 0x8d7d4d94) [1], 0x0 (0x8db46178), 0x0 (0x0)

```

This table describes the significant output fields shown in the display.

**Table 19: show cef ipv6 detail Command Field Descriptions**

Field	Description
flags:	Properties of the indicated prefix.
Loadinfo owner:	Owner of the Loadinfo used by the prefix for forwarding. The Loadinfo owner is the prefix that owns the array of pointers to adjacencies.
fast adj:	Cached adjacency used for forwarding.
path 1:	The following three items are displayed below path 1: <ul style="list-style-type: none"> <li>• flags—Properties of the path.</li> <li>• next hop—Next-hop prefix if the packet is being forwarded.</li> <li>• interface—Next-hop interface if the packet is being forwarded.</li> </ul>

# show cef ipv6 drops

To display IPv6 Cisco Express Forwarding (CEF) table packet drop counters, use the **show cef ipv6 drops** command in XR EXEC mode.

```
show cef [vrf vrf-name]ipv6 drops [location node-id]
```

Syntax Description	Parameter	Description
	<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	<b>location</b> <i>node-id</i>	(Optional) Displays IPv6 CEF table packet drop counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** A packet might be dropped by the IPv6 CEF table because of unresolved CEF entries, unsupported features, absence of route information, absence of adjacency information, or an IP checksum error.

If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the packet drops for all nodes.



**Note** Because no hardware forwarding occurs on the route processor (RP), no packet drop information is displayed for that node.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv6 drops** command:

```
Router# show cef ipv6 drops location 0/RP0/CPU0

CEF Drop Statistics
Node: 0/RP0/CPU0
  Unresolved drops    packets :          0
  Unsupported drops   packets :          0
  Null0 drops         packets :          0
  No route drops      packets :          1
```

## show cef ipv6 drops

```

No Adjacency drops packets : 0
Checksum error drops packets : 0
RPF drops packets : 0
RPF suppressed drops packets : 0
RP destined drops packets : 0
Discard drops packets : 0
GRE lookup drops packets : 0
GRE processing drops packets : 0
LISP punt drops packets : 0
LISP encap err drops packets : 0
LISP decap err drops packets : 0

```

Table 20: show cef ipv6 drops Command Field Descriptions

Field	Description
Unresolved drops	Drops due to unresolved routes.
Unsupported drops	Drops due to an unsupported feature.
Null0 drops	Drops to the Null0 interface.
No route drops	Number of packets dropped because there were no routes to the destination.
No Adjacency drops	Number of packets dropped because there were no adjacencies established.
Checksum error drops	Drops due to IPv6 checksum error.
RPF drops	Drops due to IPv6 unicast RPF <sup>6</sup> .
RPF suppressed drops	Drops suppressed due to IPv6 unicast RPF.
RP destined drops	Drops destined for the router.
Discard drops	Drops those were discarded
GRE lookup drops	GRE packets dropped during GRE Lookup.
GRE processing drops	GRE packets dropped during GRE Processing.
LISP punt drops	LISP packets dropped during software processing of the packets.
LISP encap err drops	LISP encap packets dropped due to errors.
LISP decap err drops	LISP Decap packets dropped due to errors.

<sup>6</sup> RPF = Reverse Path Forwarding

## show cef ipv6 exact-route

To display the path an IPv6 flow comprising a source and destination address would take, use the **show cef ipv6 exact-route** command in XR EXEC mode.

```
show cef [ vrf vrf-name ] ipv6 exact-route { source-address destination-address } [ flow-label
flow-label-value ] [ protocol { protocol-number | protocol-value } ] [ source-port
source-port-number ] [ destination-port destination-port-number ] [ ingress-interface interface-type
interface-id ] [ hardware { ingress | egress } ] [ policy-class value ] [ detail | location
node-id ] { ingress-interface ingress-interface | user-data user-data ingress-interface ingress-interface
[ brief | detail | flow-label | hardware | internal | location | policy-class | protocol ] }
```

Syntax Description		
<b>vrf</b>		(Optional) Sets VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>		(Optional) Name of a VRF.
<i>source-address</i>		The IPv6 source address in x:x::x format.
<i>destination-address</i>		The IPv6 destination address in x:x::x format.
<b>protocol</b> <i>protocol-number</i>   <i>protocol-name</i>		Sets the specified protocol for the route.
<b>source-port</b> <i>source-port-number</i>		(Optional) Sets the source port. The range is from 0 to 65535.
<b>destination-port</b> <i>destination-port-number</i>		(Optional) Sets the destination port. The range is from 0 to 65535.
<b>ingress-interface</b> <b>interface-type</b> <i>interface-id</i>		Sets the ingress interface type and ID.
<b>hardware</b> { <b>protocol-value</b>   <b>protocol-name</b> }		(Optional) Reads from the ingress or egress packet.
<b>flow-label</b> <i>flow-label-value</i>		Sets the IPv6 flow-label and flow-label-value.
<b>policy-class</b> <i>value</i>		(Optional) Sets the class for the policy-based tunnel selection. The range for the tunnel policy class value is from 1 to 7.
detail		(Optional) Provides full CEF entry information.

<b>location</b> <i>node-id</i>	(Optional) Provides the IPv6 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>ingress-interface</b>	(Optional) Specifies the ingress interface information.
<b>user-data</b> <i>user-data</i>	(Optional) Specifies the additional user chosen data bytes used in multi-path computation. In <i>user-data</i> , you can enter 1-4 bytes in hexadecimal.
<b>ingress-interface</b> <i>ingress-interface</i>	Specifies the ingress interface information.
<b>brief</b>	(Optional) Displays brief information of CEF table.
<b>detail</b>	(Optional) Displays full information of CEF table.
<b>flow-label</b>	(Optional) Specifies the IPv6 flow-label.
<b>hardware</b>	(Optional) Displays information from hardware.
<b>location</b>	(Optional) Provides the forwarding information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>policy-class</b>	(Optional) Class for policy-based tunnel selection.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.5.5	The keyword <b>user-data</b> was introduced.
	Release 24.2.11	The keyword <b>user-data</b> was introduced.
	Release 7.0.12	This command was introduced.



**Usage Guidelines**

For TCP and UDP protocols, providing the source-port and destination-port is mandatory. For other protocols, provide the source-port and destination-port as zero. Providing flow-label is also mandatory. Otherwise, the output of the **show cef ipv6 exact-route** command is not correct.

Task ID	Task ID	Operations
	cef	read

**Examples**

The following sample output is from the **show cef ipv6 exact-route** command:

```
Router# show cef ipv6 exact-route 2001:DB8::1 2001:DB8:0:ABCD::1 flow-label 15000 protocol
  UDP source-port 34000 destination-port 45000 ingress-interface HundredGigE 0/0/0/24
Wed Apr 15 02:36:17.632 UTC
2001:DB8:0:ABCD::1/128, version 27, labeled SR, internal 0x1000001 0x8010 (ptr 0x96a0571c)
 [1], 0x0 (0x969e5160), 0xa28 (0x9849c120)
Updated Apr 14 21:29:19.925
local adjacency fe80::7ace:ecff:febf:d103
Prefix Len 128, traffic index 0, precedence n/a, priority 1, encap-id 0x1001500000001
via Bundle-Ether2
via fe80::7ace:ecff:febf:d103/128, Bundle-Ether2, 7 dependencies, weight 0, class 0
[flags 0x0]
  path-idx 0 NHID 0x0 [0x981225d0 0x0]
  next hop fe80::7ace:ecff:febf:d103/128
  local adjacency
  local label 21556 labels imposed {21556}
```

The following sample output is from the **show cef ipv6 exact-route** command with **user-data** keyword:

```
Router# show cef ipv6 exact-route 100::10 60::1 flow-label 0 protocol 59 source-port 0
destination-port 0 user-data 0x2 ingress-interface HundredGigE0/0/0/2 location 0/0/cpu0

Unsupported protocol value 59
60::/16, version 1293, internal 0x1000001 0x20 (ptr 0x8b78ef00) [1], 0x400 (0x8e9cfc48),
0x0 (0x0)
Updated Aug 14 07:50:20.022
local adjacency to Bundle-Ether3.30

Prefix Len 16, traffic index 0, precedence n/a, priority 2
via Bundle-Ether3.30
via fe80::72b3:17ff:feae:d703/128, Bundle-Ether3.30, 7 dependencies, weight 0, class 0
[flags 0x0]
  path-idx 7 NHID 0x0 [0x8db8bed8 0x0]
  next hop fe80::72b3:17ff:feae:d703/128
  local adjacency
```

# show cef ipv6 exceptions

To display IPv6 Cisco Express Forwarding (CEF) exception packet counters, use the **show cef ipv6 exceptions** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv6 exceptions [location node-id]
```

Syntax Description	Parameter	Description
	<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	<b>location node-id</b>	(Optional) Displays IPv6 CEF exception packet counters for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** CEF exception packets are those packets that have been sent from the hardware to the software because they require additional handling. The types of IPv6 CEF exception packets are displayed in the output of **show cef ipv6 exceptions**.

If you do not specify a node with **location** keyword and *node-id* argument, this command displays IPv6 CEF exception packet counters for all nodes.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv6 exceptions** command:

```
Router# show cef ipv6 exceptions location 0/RP0/CPU0

CEF Exception Statistics
Node: 0/RP0/CPU0
  Slow encap packets :          0
  Unsupported packets :          0
  Redirect packets   :          0
  Receive packets   :           1
  Broadcast packets  :           0
  IP options packets :           0
  TTL expired packets :          0
  Fragmented packets :           0
```

# show cef ipv6 hardware

To display Cisco Express Forwarding (CEF) IPv6 hardware status and configuration information, use the **show cef ipv6 hardware** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv6 hardware {egress | [detail | location node-id]}
```

Syntax Description	Parameter	Description
	<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	<b>egress</b>	Displays information from the egress packets.
	<b>detail</b>	(Optional) Displays full details.
	<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output displays the full details from the **show cef ipv6 hardware** command:

```
Router# show cef ipv6 hardware egress detail

::/0, version 0, proxy default, default route handler, drop adjacency, internal 0x1001011
0x0 (ptr 0x8d7d52dc) [1], 0x0 (0x8db46098), 0x0 (0x0)
Updated Nov 22 22:57:58.578
Prefix Len 0, traffic index 0, precedence n/a, priority 15
gateway array (0x8d87a098) reference count 1, flags 0x200, source default (12), 0 backups
[2 type 3 flags 0xa401 (0x8d9cf098) ext 0x0 (0x0)]
LW-LDI[type=3, refc=1, ptr=0x8db46098, sh-ldi=0x8d9cf098]
gateway array update type-time 1 Nov 22 22:57:58.578
LDI Update time Nov 22 22:57:58.595
LW-LDI-TS Nov 22 22:57:58.595
via ::/128, 3 dependencies, weight 0, class 0 [flags 0x0]
path-idx 0 NHID 0x0 [0x8cf1c218 0x0]
```

```
next hop ::/128
drop adjacency
```

```
Load distribution: 0 (refcount 2)
```

```
Hash OK Interface Address
```

```
0 Y Unknown drop
```

```
::ffff:90.0.0.1/128, version 14, attached, receive
```

```
Updated Nov 25 15:28:03.318
```

```
Prefix Len 128
```

```
internal 0x1004141 (ptr 0x8d7d48b4) [1], 0x0 (0x8db462c8), 0x0 (0x0)
```

```
fe80::/10, version 0, receive
```

```
Updated Nov 22 22:57:58.608
```

```
Prefix Len 10
```

```
internal 0x1004001 (ptr 0x8d7d4cc4) [1], 0x0 (0x8db461e8), 0x0 (0x0)
```

```
ff02::/16, version 0, receive
```

```
Updated Nov 22 22:57:58.609
```

```
Prefix Len 16
```

```
internal 0x1004001 (ptr 0x8d7d4f14) [1], 0x0 (0x8db46140), 0x0 (0x0)
```

# show cef ipv6 interface

To display IPv6 Cisco Express Forwarding (CEF)-related information for an interface, use the **show cef ipv6 interface** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv6 interface type interface-path-id [detail] [location node-id]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>detail</b>	(Optional) Displays detailed CEF information for all the interfaces on the node in which the command is issued.
<b>location</b> <i>node-id</i>	(Optional) Displays IPv4 CEF-related information for an interface. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the **show cef ipv6 interface** command displays the CEF-related information for the interface on the route processor.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output is from the **show cef ipv6 interface HundredGigE 0/0/0/0** command:

```
Router# show cef ipv6 interface HundredGigE 0/0/0/0

HundredGigE0/0/0/0 is up if_handle 0x0f000138 if_type IFT_HUNDREDGE(0x49)
      idb info 0x9093e730 flags 0x8001 ext 0x9557d0a8 flags 0x50
```

**show cef ipv6 interface**

```
Vrf Local Info (0x95b7a0a8)
Interface last modified Jan 13, 2020 06:08:29, create
Reference count 1      Next-Hop Count 1
Forwarding is enabled
ICMP redirects are never sent
ICMP unreachable are enabled
Protocol MTU 1500, TableId 0xe0800000(0x91382758)
Protocol Reference count 2
Primary IPV6 local address 100::6/128
```

# show cef ipv6 non-recursive

To display the IPv6 nonrecursive prefix entries in the IPv6 Cisco Express Forwarding (CEF) table, use the **show cef ipv6 non-recursive** command in XR EXEC mode.

**show cef** [*vrf vrf-name*] **ipv6 non-recursive** [**hardware** {**egress** | **ingress**}] [**detail**] [**location** *node-id*]

Syntax Description	
vrf	(Optional) Displays VPN routing and forwarding (VRF) instance information.
vrf-name	(Optional) Name of a VRF.
hardware	(Optional) Displays Cisco Express Forwarding (CEF) IPv6 hardware status and configuration information.
egress	(Optional) Displays information from the egress packets.
ingress	(Optional) Displays information from the ingress packets.
detail	(Optional) Displays full details.
<b>location</b> <i>node-id</i>	(Optional) Displays the nonrecursive prefix entries in the IPv6 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the nonrecursive routes for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv6 non-recursive** command:

```
Router# show cef ipv6 non-recursive

20::/64
connected FourHundredGigE0/0/0/6
20::2/128
20::2/128 FourHundredGigE0/0/0/6
20::3/128
```

```

receive FourHundredGigE0/0/0/6
20:0:1::/64
connected FourHundredGigE0/0/0/6.1
20:0:1::2/128
20:0:1::2/128 FourHundredGigE0/0/0/6.1
20:0:1::3/128
receive FourHundredGigE0/0/0/6.1
30:30::/64
connected HundredGigE0/0/0/30
30:30::3/128
receive HundredGigE0/0/0/30
30:30:1::/64
connected HundredGigE0/0/0/30.1
30:30:1::3/128
receive HundredGigE0/0/0/30.1
30:31::/64
connected HundredGigE0/0/0/31
30:31::3/128
receive HundredGigE0/0/0/31
30:31:1::/64
connected HundredGigE0/0/0/31.1
30:31:1::3/128
receive HundredGigE0/0/0/31.1
30:32::/64
connected HundredGigE0/0/0/32
30:32::3/128
receive HundredGigE0/0/0/32
30:32:1::/64
connected HundredGigE0/0/0/32.1
30:32:1::3/128
receive HundredGigE0/0/0/32.1
45:31::/64
connected Bundle-Ether31
45:31::3/128
receive Bundle-Ether31
45:31::5/128
45:31::5/128 Bundle-Ether31
45:31:1::/64
connected Bundle-Ether31.1
45:31:1::3/128
receive Bundle-Ether31.1
45:31:1::5/128
45:31:1::5/128 Bundle-Ether31.1
210:210:1::3/128
receive Loopback0

```

This table describes the significant fields shown in the display.

**Table 21: show cef ipv6 non-recursive Command Field Descriptions**

Field	Description
drop	Indicates that packets sent to the destination prefix are dropped.
loopback	Indicates that the prefix points to a loopback address. Packets sent to loopback addresses are dropped.
receive	Indicates that the prefix is configured on one of the router interfaces. Packets sent to those prefixes are received by the router.
connected	Indicates that the prefix points to a directly connected next-hop interface.



# show cef ipv6 resource

To display the IPv6 nonrecursive prefix entries in the IPv6 Cisco Express Forwarding (CEF) table, use the **show cef ipv6 resource** command in XR EXEC mode.

```
show cef ipv6 resource [detail] [location node-id]
```

<b>Syntax Description</b>	<b>detail</b>	(Optional) Displays detailed information resources listed in the IPv6 CEF table.
	<b>location node-id</b>	(Optional) Displays the IPv6 resource entries in the IPv6 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, the output displays the IPv6 CEF nonrecursive routes for the node on which the command is issued.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read

## Examples

The following is sample output from the **show cef ipv6 resource** command:

```
Router# show cef ipv6 resource

CEF resource availability summary state: GREEN
  ipv4 shared memory resource: GREEN
  ipv6 shared memory resource: GREEN
  mpls shared memory resource: GREEN
  common shared memory resource: GREEN
  TABLE hardware resource: GREEN
  LEAF hardware resource: GREEN
  LOADINFO hardware resource: GREEN
  NHINFO hardware resource: GREEN
  LABEL_INFO hardware resource: GREEN
  IDB hardware resource: GREEN
  FRR_NHINFO hardware resource: GREEN
  LDSH_ARRAY hardware resource: GREEN
  RSRC_MON hardware resource: GREEN
```

# show cef ipv6 summary

To display a summary of the IPv6 Cisco Express Forwarding (CEF) table, use the **show cef ipv6 summary** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv6 summary [location node-id]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<b>location</b> <i>node-id</i>	(Optional) Displays a summary of the IPv6 CEF table for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays a summary of the IPv6 CEF table for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from the **show cef ipv6 summary** command:

```
Router# show cef ipv6 summary

IP CEF with switching (Table Version 0)

Load balancing: L3
Tableid 0xe0800000, Vrfid 0x60000000, Vrid 0x20000000, Flags 0x301
Vrfname default, Refcount 12
4 routes, 0 reresolve, 0 unresolved (0 old, 0 new), 288 bytes
0 load sharing elements, 0 bytes, 0 references
0 shared load sharing elements, 0 bytes
0 exclusive load sharing elements, 0 bytes
0 CEF route update drops, 0 revisions of existing leaves
Resolution Timer: 15s
0 prefixes modified in place
0 deleted stale prefixes
0 prefixes with label imposition, 0 prefixes with label information
Adjacency Table has 44 adjacencies
1 incomplete adjacency
```

This table describes the significant fields shown in the display.

**Table 22: show cef ipv6 summary Command Field Descriptions**

Field	Description
Load balancing	Current load-balancing mode. The default value is L3.
Table Version	Version of the CEF table.
routes	Total number of routes.
unresolved ( <i>x</i> old, <i>x</i> new)	Number of routes not yet resolved.
load sharing elements	Total number of internal load-sharing data structures.
bytes	Total memory used by internal load sharing data structures.
references	Total reference count of all internal load sharing data structures.
CEF resets	Number of CEF table resets.
revisions of existing leaves	Number of updates to existing prefixes.
Exponential (currently <i>xs</i> , peak <i>xs</i> )	Currently not used.
prefixes modified in place	Prefixes modified in place.
Router ID	Router identification.
Adjacency Table has <i>x</i> adjacencies	Total number of adjacencies.
<i>x</i> incomplete adjacency	Total number of incomplete adjacencies.

# show cef ipv6 unresolved

To display the unresolved routes in the IPv6 Cisco Express Forwarding (CEF) table, use the **show cef ipv6 unresolved** command in XR EXEC mode.

```
show cef [vrf vrf-name] ipv6 unresolved [detail] [hardware {egress}] [location node-id]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<b>detail</b>	(Optional) Displays full details.
<b>hardware</b>	(Optional) Displays Cisco Express Forwarding (CEF) IPv6 hardware status and configuration information.
<b>egress</b>	Displays information from the egress packets.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, this command displays the unresolved routes for the node on which the command is issued.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from **show cef ipv6 unresolved** command when an unresolved route is detected:

```
Router# show cef ipv6 unresolved

9999::/64
  unresolved
```

This table describes the significant fields shown in the display.

**Table 23: show cef ipv6 unresolved Command Field Descriptions**

<b>Field</b>	<b>Description</b>
<code>xxxx::/xx</code>	Detected unresolved route.

# show cef mpls adjacency

To display the Multiprotocol Label Switching (MPLS) adjacency table, use the **show cef mpls adjacency** command in XR EXEC mode.

**show cef mpls adjacency** [*interface-type interface-path-id*] [**detail** | **discard** | **drop** | **glean** | **null** | **punt** | **remote**] [**location** *node-id*]

## Syntax Description

<i>interface-type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface- path-id</i>	(Optional) Either a physical interface instance or a virtual interface instance: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash mark between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0) and the module is CPU0. Example: interface MgmtEth0/RP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>detail</b>	(Optional) Displays full details.
<b>discard</b>	(Optional) Displays the discard adjacency information.
<b>drop</b>	(Optional) Displays the drop adjacency information.
<b>glean</b>	(Optional) Displays the glean adjacency information.
<b>null</b>	(Optional) Displays the null adjacency information.
<b>punt</b>	(Optional) Displays the punt adjacency information.
<b>remote</b>	(Optional) Displays the remote adjacency information.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If you do not specify a node with the **location** keyword and *node-id* argument, the **show cef mpls adjacency** command displays the MPLS adjacency table for the node in which the command is issued.

Task ID	Task ID	Operations
	cef	read

### Examples

The following is sample output from **show cef mpls adjacency** command:

```
Router# sh cef mpls adjacency inter

Display protocol is mpls
Interface      Address                                         Type      Refcount
-----
BE1906        Prefix: 10.0.86.1/32                          local      7
Adjacency: PT:0x8cba28d0 10.0.86.1/32
Interface: BE1906
NHID: 0x0
MAC: e6.48.5c.10.b4.8e.e6.07.2b.8d.34.88.88.47
Interface Type: 0x1c, Base Flags: 0x1 (0x8d10f620)
Nhinfo PT: 0x8d10f620, Idb PT: 0x8ca57320, If Handle:
0x8000174
no dependent adj
Ancestor If Handle: 0x0
Update time Dec 21 03:56:49.977

BE1904        Prefix: 10.0.85.1/32                          local      7
Adjacency: PT:0x8cba3c78 10.0.85.1/32
Interface: BE1904
NHID: 0x0
MAC: e6.48.5c.10.b4.86.e6.07.2b.8d.34.89.88.47
Interface Type: 0x1c, Base Flags: 0x1 (0x8d10f1a0)
Nhinfo PT: 0x8d10f1a0, Idb PT: 0x8ca572a0, If Handle:
0x800016c
no dependent adj
Ancestor If Handle: 0x0
Update time Dec 21 03:57:25.360
```

# show cef mpls adjacency hardware

To display the Multiprotocol Label Switching (MPLS) adjacency hardware status and configuration information, use the **show cef mpls adjacency hardware** command in XR EXEC mode.

```
show cef mpls adjacency hardware {egress} [detail | discard | drop | glean | location node-id | null | punt | remote]
```

Syntax	Description
<b>egress</b>	Displays information from the egress packets.
<b>detail</b>	(Optional) Displays full details.
<b>discard</b>	(Optional) Displays the discard adjacency information.
<b>drop</b>	(Optional) Displays the drop adjacency information.
<b>glean</b>	(Optional) Displays the glean adjacency information.
<b>location</b> <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>null</b>	(Optional) Displays the null adjacency information.
<b>punt</b>	(Optional) Displays the punt adjacency information.
<b>remote</b>	(Optional) Displays the remote adjacency information.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

## Examples

The following is sample output from **show cef mpls adjacency hardware** command:

```
Router# sh cef mpls adjacency inter

Display protocol is mpls
Interface      Address                               Type      Refcount
```



```
BE1906      Prefix: 10.0.86.1/32                local  7
Adjacency: PT:0x8cba28d0 10.0.86.1/32
Interface: BE1906
NHID: 0x0
MAC: e6.48.5c.10.b4.8e.e6.07.2b.8d.34.88.88.47
Interface Type: 0x1c, Base Flags: 0x1 (0x8d10f620)
Nhinfo PT: 0x8d10f620, Idb PT: 0x8ca57320, If Handle:
0x8000174
no dependent adj
Ancestor If Handle: 0x0
Update time Dec 21 03:56:49.977

BE1904      Prefix: 10.0.85.1/32                local  7
Adjacency: PT:0x8cba3c78 10.0.85.1/32
Interface: BE1904
NHID: 0x0
MAC: e6.48.5c.10.b4.86.e6.07.2b.8d.34.89.88.47
Interface Type: 0x1c, Base Flags: 0x1 (0x8d10f1a0)
Nhinfo PT: 0x8d10f1a0, Idb PT: 0x8ca572a0, If Handle:
0x800016c
no dependent adj
Ancestor If Handle: 0x0
Update time Dec 21 03:57:25.360
```

# show cef mpls drops

To display Multiprotocol Label Switching (MPLS) drop counters for packets that belong to a segment routing (SR) network, use the **show cef mpls drops** command in XR EXEC mode.

**show cef mpls drops** [**location** {*node-id* | **all**}]

## Syntax Description

**location** *node-id* (Optional) Displays detailed Cisco Express Forwarding (CEF) information for the designated node. The *node-id* argument is entered in the *rack/slot/module* notation.

**all** (Optional) Displays all locations.

## Command Default

No default behavior or values

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

Use this command to display the SR MPLS drop counters.

The incoming top MPLS label is inspected. If the label belongs to the Segment Routing Local Block (SRLB) or the Segment Routing Global Block (SRGB), an MPLS SR drop counter is incremented for unknown label value or for MPLS time to live (TTL) expiry.



**Note** The drop counters will increment for manually allocated adjacency SIDs and prefix SIDs only. They will not increment for dynamically allocated adjacency SIDs.

## Task ID

Task ID	Operation
cef	read

## Example

The following is sample output from **show cef mpls drops** command:

```
Router# show cef mpls drops location 0/0/CPU0
Sat Jun  9 03:49:27.100 IST
CEF Drop Statistics
Node: 0/0/CPU0
  SR MPLS unreachable packets :           100
  SR MPLS TTL expired packets :           400
```

# show cef mpls interface

To display the Multiprotocol Label Switching (MPLS) Cisco Express Forwarding (CEF)-related information for an interface, use the **show cef mpls interface** command in XR EXEC mode.

**show cef mpls interface** *type interface-path-id* [**detail**] [**location** *node-id*]

<b>Syntax Description</b>	<p><i>type</i> Interface type. For more information, use the question mark (?) online help function.</p> <hr/> <p><i>in interface-path-id</i> Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>• Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li>• <i>rack</i>: Chassis number of the rack.</li> <li>• <i>slot</i>: Physical slot number of the modular services card or line card.</li> <li>• <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li>• <i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric ( RP0 ) and the module is CPU0. Example: interface MgmtEth0/ RP0</p> <ul style="list-style-type: none"> <li>• Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p> <hr/> <p><b>detail</b> (Optional) Displays detailed CEF information for all the interfaces on the node in which the command is issued.</p> <hr/> <p><b>location</b> <i>node-id</i> (Optional) Displays IPv4 CEF-related information for an interface. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.</p> <hr/>				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	If you do not specify a node with the <b>location</b> keyword and <i>node-id</i> argument, the <b>show cef mpls interface</b> command displays the CEF-related information for the interface on the route processor.				

## show cef mpls interface

Task ID	Task ID	Operations
	cef	read

### Examples

The following sample output is from the **show cef mpls interface** command:

```
Router# sh cef mpls interface hundredGigE 0/0/0/24
Wed Apr 22 16:56:48.376 UTC
HundredGigE0/0/0/24 is down if_handle 0x0f0001f8 if_type IFT_HUNDREDGE(0x49)
  idb info 0x912e6ae0 flags 0x8001 ext 0x0
  Vrf Local Info (0x0)
  Interface last modified Apr 22, 2020 14:28:51, create
  Reference count 1      Next-Hop Count 0
  Protocol Reference count 0
  Protocol mpls not configured or enabled on this card
```

# show cef mpls unresolved

To display the Multiprotocol Label Switching (MPLS) unresolved routes, use the **show cef mpls unresolved** command in XR EXEC mode.

```
show cef mpls unresolved [detail] [location node-id]
```

Syntax Description	detail	(Optional) Displays detailed adjacency information, including Layer 2 information.
	location <i>node-id</i>	(Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	cef	read

## Examples

The following sample output is from the **show cef mpls unresolved** command:

```
Router# show cef mpls unresolved

Label/EOS          Next Hop          Interface
20001/0
20001/1
```

This table describes the significant fields shown in the display.

**Table 24: show cef mpls unresolved Command Field Descriptions**

Field	Description
Label/EOS	MPLS forwarding label/End of Stack (EOS) bit.
Next Hop	Next hop of the prefix.
Interface	Interface associated with the prefix.

# show cef recursive-nexthop

To display Cisco Express Forwarding (CEF) recursive next-hop information, use the **show cef recursive-nexthop** command in XR EXEC mode.

**show cef recursive-nexthop** [**hardware**] [**location node-id**]

<b>Syntax Description</b>	<b>hardware</b> (Optional) Displays hardware information related to the recursive next hop.
	<b>location node-id</b> (Optional) Displays recursive next-hop information for the specified node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show cef, on page 164</a>	Displays information about packets forwarded by Cisco Express Forwarding (CEF).

# show cef summary

To display summary information for the Cisco Express Forwarding (CEF) table, use the **show cef summary** command in XR EXEC mode.

```
show cef summary [location {node-id | all}]
```

Syntax Description	
	<b>location</b> <i>node-id</i> (Optional) Displays detailed CEF information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>all</b> (Optional) Displays all locations.

**Command Default** The **show cef summary** command assumes the IPv4 CEF table and the active RP node as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task	Operations
	cef	read

## Examples

The following sample output is from the **show cef summary** command.

```
Router# show cef summary location 0/RP0/CPU0

Router ID is 10.1.1.1

IP CEF with switching (Table Version 0) for node0_1_CPU0

  Load balancing: L3
  Tableid 0xe0000000, Vrfid 0x60000000, Vrid 0x20000000, Flags 0x301
  Vrfname default, Refcount 318
  170 routes, 0 reresolve, 0 unresolved (0 old, 0 new), 12240 bytes
  183 load sharing elements, 57292 bytes, 184 references
  19 shared load sharing elements, 7036 bytes
  164 exclusive load sharing elements, 50256 bytes
  0 CEF route update drops, 10 revisions of existing leaves
  Resolution Timer: 15s
  0 prefixes modified in place
  0 deleted stale prefixes
  21 prefixes with label imposition, 60 prefixes with label information
Adjacency Table has 49 adjacencies
  25 incomplete adjacencies
```

This table describes the significant fields shown in the display.

**Table 25: show cef summary Command Field Descriptions**

Field	Description
Load balancing	Current load-balancing mode. The default value is L3.
Table Version	Version of the CEF table.
tableid	Table identification number.
vrfname	VRF name.
flags	Option value for the table
routes	Total number of routes.
rerresolve	Total number of routes being reresolved.
unresolved ( <i>x</i> old, <i>x</i> new)	Number of routes not yet resolved.
load sharing elements	Total number of internal load-sharing data structures.
bytes	Total memory used by internal load sharing data structures.
references	Total reference count of all internal load sharing data structures.
CEF resets	Number of CEF table resets.
revisions of existing leaves	Number of updates to existing prefixes.
Exponential (currently <i>xs</i> , peak <i>xs</i> )	Currently not used.
prefixes modified in place	Prefixes modified in place.
Adjacency Table has <i>x</i> adjacencies	Total number of adjacencies.
<i>x</i> incomplete adjacency	Total number of incomplete adjacencies.



# show cef vrf

To display the contents of the VPN routing and forwarding (VRF) instance, use the **show cef vrf** command in XR EXEC mode.

```
show cef vrf [vrf-name]
```

<b>Syntax Description</b>	vrf-name Name of the VRF instance.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	To display unresolved routes, you must use the <b>unresolved</b> keyword explicitly.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>cef</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	cef	read
Task ID	Operations				
cef	read				

## Examples

The following is sample output from **show cef vrf** command when an unresolved route is detected:

```
Router# show cef vrf test1
Tue Apr 28 04:21:48.588 UTC

Prefix          Next Hop          Interface
-----
0.0.0.0/0       drop              default handler
0.0.0.0/32      broadcast
26.0.0.0/24     attached         HundredGigE0/0/0/26
26.0.0.0/32     broadcast         HundredGigE0/0/0/26
26.0.0.1/32     26.0.0.1/32      HundredGigE0/0/0/26
26.0.0.2/32     receive          HundredGigE0/0/0/26
26.0.0.255/32   broadcast         HundredGigE0/0/0/26
27.0.0.0/24     attached         HundredGigE0/0/0/27
27.0.0.0/32     broadcast         HundredGigE0/0/0/27
27.0.0.2/32     receive          HundredGigE0/0/0/27
27.0.0.3/32     27.0.0.3/32      HundredGigE0/0/0/27
27.0.0.255/32   broadcast         HundredGigE0/0/0/27
224.0.0.0/4     0.0.0.0/32
224.0.0.0/24    receive
```

This table describes the significant fields shown in the display.

*Table 26: show cef vrf Command Field Descriptions*

<b>Field</b>	<b>Description</b>
Prefix	Prefix in the IPv4 CEF table.
Next Hop	Next hop of the prefix.
Interface	Interface associated with the prefix.

# show hw-module profile cef

To display information about the configuration status of CEF hardware-modules, use the **show hw-module profile cef** command in XR EXEC mode.

```
show hw-module profile cef
```

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.1	This command was introduced.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	cef	read

## Examples

This sample output is from the **show hw-module profile cef** command:

```
Router# show hw-module profile cef
Tue Oct 6 00:34:47.735 UTC
```

Knob	Status	Applied	Action
BGPLU	Configured	No	Reload
Dark Bandwidth	Unconfigured	Yes	None
MPLS Per Path Stats	Unconfigured	Yes	None
Tunnel TTL Decrement	Configured	Yes	None
High-Scale No-LDP-Over-TE	Unconfigured	Yes	None

show hw-module profile cef



## Host Services and Applications Commands

This chapter describes the commands used to configure and monitor the Host Services and Applications on Cisco 8000 Series Routers.

For detailed information about Host Services and Applications concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [cinetd rate-limit](#), on page 249
- [clear host](#), on page 250
- [domain ipv4 host](#), on page 251
- [domain ipv6 host](#), on page 252
- [domain list](#), on page 253
- [domain lookup disable](#), on page 254
- [domain name \(IPAddr\)](#), on page 255
- [domain name-server](#), on page 256
- [ftp client anonymous-password](#), on page 257
- [ftp client passive](#), on page 258
- [ftp client password](#), on page 259
- [ftp client source-interface](#), on page 260
- [ftp client username](#), on page 261
- [http client connection](#), on page 262
- [http client response](#), on page 263
- [http client secure-verify-host](#), on page 264
- [http client secure-verify-peer](#), on page 265
- [http client source-interface](#), on page 266
- [http client ssl](#), on page 267
- [http client tcp-window-scale](#), on page 268
- [http client version](#), on page 269
- [http client vrf](#), on page 270
- [logging source-interface vrf](#), on page 271
- [ping bulk \(network\)](#), on page 272
- [ping \(network\)](#), on page 274
- [scp](#), on page 277
- [show cinetd services](#), on page 279
- [show hosts](#), on page 281
- [telnet](#), on page 283

- [telnet client source-interface](#), on page 286
- [telnet dscp](#), on page 287
- [telnet server](#), on page 289
- [telnet transparent](#), on page 291
- [tftp server](#), on page 292
- [tftp client source-interface](#), on page 293
- [traceroute](#), on page 294

## cinetd rate-limit

To configure the rate limit at which service requests are accepted by Cisco inetd (Cinetd), use the **cinetd rate-limit** command in XR Config mode. To restore the default, use the **no** form of this command.

**cinetd rate-limit** *value*  
**no cinetd rate-limit** *value*

<b>Syntax Description</b>	<i>value</i> Number of service requests that are accepted per second. Range is 1 to 100. Default is 1.				
<b>Command Default</b>	One service request per second is accepted.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	Any service request that exceeds the rate limit is rejected. The rate limit is applied to individual applications.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read, write
Task ID	Operations				
ip-services	read, write				
<b>Examples</b>	<p>The following example shows the <b>cinetd rate-limit</b> being set to 10:</p> <pre>Router# <b>config</b> Router(config)# <b>cinetd rate-limit 10</b></pre>				

# clear host

To delete temporary entries from the hostname-to-address cache, use the **clear host** command in XR EXEC mode.

```
clear host {host-name | *}
```

## Syntax Description

**host-name** Name of host to be deleted.

**\*** Specifies that all entries in the local cache be deleted.

## Command Default

No default behavior or values

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

The dynamic host entries in the cache are cleared.

The temporary entries in the cache are cleared; the permanent entries that were entered with the `domain ipv4 host` or the `domain ipv6 host` command are not cleared.

By default, no static mapping is configured.

## Task ID

Task ID	Operations
ip-services	execute

## Examples

The following example shows how to clear all temporary entries from the hostname-and-address cache:

```
Router# clear host *
```



## domain ipv4 host

To define a static hostname-to-address mapping in the host cache using IPv4, use the **domain ipv4 host** command in XR Config mode. To remove the **domain ipv4 host** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
domain ipv4 host host-name v4address2.....v4address8
no domain ipv4 host host-name v4address1
```

Syntax Description		
	host-name	Name of the host. The first character can be either a letter or a number.
	v4address1	Associated IP address.
	v4address2...v4address8	(Optional) Additional associated IP address. You can bind up to eight addresses to a hostname.

**Command Default** No static mapping is configured.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The first character can be either a letter or a number. If you use a number, the operations you can perform (such as **ping**) are limited.

Task ID	Task ID	Operations
	ip-services	read, write
	basic-services	read, write

### Examples

The following example shows how to define two IPv4 static mappings:

```
Router(config)# domain ipv4 host host1 192.168.7.18
Router(config)# domain ipv4 host bost2 10.2.0.2 192.168.7.33
```

# domain ipv6 host

To define a static hostname-to-address mapping in the host cache using IPv6, use the **domain ipv6 host** command in XR Config mode. To remove the **domain ipv6 host** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
domain ipv6 host host-name v6address1 [v6address2 .....v6address4]
no domain ipv6 host host-name v6address1
```

Syntax Description		
host-name	Name of the host. The first character can be either a letter or a number.	
v6address1	Associated IP address.	
v6address2...v6address4	(Optional) Additional associated IP address. You can bind up to four addresses to a hostname.	

**Command Default** No static mapping is configured. IPv6 address prefixes are not enabled.

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The first character can be either a letter or a number. If you use a number, the operations you can perform (such as **ping**) are limited.

Task ID	Task ID	Operations
	ip	read,
	services	write

## Examples

The following example shows how to define two IPv6 static mappings:

```
Router(config)# domain ipv6 host host1 ff02::2
Router(config)# domain ipv6 host host2 ff02::1
```

# domain list

To define a list of default domain names to complete unqualified hostnames, use the **domain list** command in XR Config mode. To delete a name from a list, use the **no** form of this command.

**domain list** *domain-name*  
**no domain list** *domain-name*

<b>Syntax Description</b>	<i>domain-name</i> Domain name. Do not include the initial period that separates an unqualified name from the domain name.
---------------------------	--

<b>Command Default</b>	No domain names are defined.
------------------------	------------------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	If there is no domain list, the domain name that you specified with the <code>domain name (IPAddr)</code> command is used to complete unqualified hostnames. If there is a domain list, the default domain name is not used. The <b>domain list</b> command is similar to the <code>domain name (IPAddr)</code> command, except that you can use the <b>domain list</b> command to define a list of domains, each to be tried in turn.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-service	read, write

<b>Examples</b>	The following example shows how to add several domain names to a list:
-----------------	--

```
Router(config)# domain list domain1.com
Router(config)# domain list domain2.edu
```

The following example shows how to add a name to and then delete a name from the list:

```
Router(config)# domain list domain3.edu
Router(config)# no domain list domain2.edu
```

# domain lookup disable

To disable the IP Domain Name System (DNS)-based hostname-to-address translation, use the **domain lookup disable** command in XR Config mode. To remove the specified command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**domain lookup disable**  
**no domain lookup disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** The IP DNS-based host-to-address translation is enabled.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Using the **no** command removes the specified command from the configuration file and restores the system to its default condition. The **no** form of this command is not stored in the configuration file.

Task ID	Task ID	Operations
	ip-services	read, write

**Examples** The following example shows how to enable the IP DNS-based hostname-to-address translation:

```
Router(config)# domain lookup disable
```

## domain name (IPAddr)

To define a default domain name that the software uses to complete unqualified hostnames, use the **domain name** command in the appropriate mode. To remove the name, use the **no** form of this command.

**domain name** *domain-name*  
**no domain name** *domain-name*

<b>Syntax Description</b>	domain-name Default domain name used to complete unqualified hostnames. Do not include the initial period that separates an unqualified name from the domain name.				
<b>Command Default</b>	There is no default domain name.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	<p>If a hostname does not contain a domain name, then a dot and the domain name configured by the <b>domain name</b> command are appended to the hostname before it is added to the host table.</p> <p>If no domain name is configured by the <b>domain name</b> command and the user provides only the hostname, then the request is not looked up.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read, write
Task ID	Operations				
ip-services	read, write				

# domain name-server

To specify the address of one or more name servers to use for name and address resolution, use the **domain name-server** command in XR Config mode. To remove the address specified, use the **no** form of this command.

**domain name-server** *server-address*  
**no domain name-server** *server-address*

## Syntax Description

*server-address* IP address of a name server.

## Command Default

If no name server address is specified, the default name server is 255.255.255.255. IPv4 and IPv6 address prefixes are not enabled.

## Command Modes

XR Config mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

You can enter up to six addresses, but only one for each command.

If no name server address is specified, the default name server is 255.255.255.255 so that the DNS lookup can be broadcast to the local network segment. If a DNS server is in the local network, it replies. If not, there might be a server that knows how to forward the DNS request to the correct DNS server.

## Task ID

Task ID	Operations
ip-services	read, write

## Examples

The following example shows how to specify host 192.168.1.111 as the primary name server and host 192.168.1.2 as the secondary server:

```
Router(config)# domain name-server 192.168.1.111
Router(config)# domain name-server 192.168.1.2
```

# ftp client anonymous-password

To assign a password for anonymous users, use the **ftp client anonymous-password** command in XR Config mode. To remove the **ftp client anonymous-password** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
ftp client anonymous-password password
no ftp client anonymous-password
```

<b>Syntax Description</b>	password Password for the anonymous user.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	The <b>ftp client anonymous-password</b> command is File Transfer Protocol (FTP) server dependent.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read, write
Task ID	Operations				
ip-services	read, write				
<b>Examples</b>	<p>The following example shows how to set the anonymous password to <code>xxxx</code>:</p> <pre>Router(config)# ftp client anonymous-password xxxx</pre>				

# ftp client passive

To configure the software to use only passive File Transfer Protocol (FTP) connections, use the **ftp client passive** command in XR Config mode. To remove the **ftp client passive** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**ftp client passive**  
**no ftp client passive**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	FTP data connections are active.
------------------------	----------------------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	Using the <b>ftp client passive</b> command allows you to make only passive-mode FTP connections. To specify the source IP address for FTP connections, use the <b>ftp client source-interface</b> command.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write

## Examples

The following example shows how to configure the networking device to use only passive FTP connections:

```
Router(config)# ftp client passive

1d:3h:54:47: ftp_fs[16437]: FTP: verifying tuple passive (SET).
1d:3h:54:47: ftp_fs[16437]: FTP: applying tuple passive (SET).
1d:3h:54:47: ftp_fs[16437]: FTP: passive mode has been enabled.
```



# ftp client password

To specify the password for the File Transfer Protocol (FTP) connections, use the **ftp client password** command in XR Config mode. To disable this feature, use the **no** form of this command.

**ftp client password** {*clear-text-password* | **clear** *clear-text password* | **encrypted** *encrypted-text password*}

**no ftp client password** {*clear-text-password* | **clear** *clear-text password* | **encrypted** *encrypted-text password*}

Syntax Description		
	clear-text-password	Specifies an unencrypted (cleartext) user password
	<b>clear</b> <i>clear-text password</i>	Specifies an unencrypted (cleartext) shared password.
	<b>encrypted</b> <i>encrypted-text password</i>	Specifies an encrypted shared password.

**Command Default** No default behavior or values

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	ip-services	read, write

**Examples** The following example shows how to specify the password for the File Transfer Protocol (FTP) connections:

```
Router(config)# ftp client password lab
```

# ftp client source-interface

To specify the source IP address for File Transfer Protocol (FTP) connections, use the **ftp client source-interface** command in XR Config mode. To remove the **ftp client source-interface** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
ftp client source-interface type interface-path-id
no ftp client source-interface type interface-path-id
```

<b>Syntax Description</b>	<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	Physical interface or virtual interface.
	<b>Note</b>	Use the show interfaces command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** The FTP source address is the IP address of the interface used by the FTP packets to leave the networking device.

**Command Modes** XR Config mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use this command to set the same source address for all FTP connections. To configure the software to use only passive FTP connections, use the **ftp client passive** command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ip-services	read, write

## Examples

The following example shows how to configure the IP address associated with HundredGigEinterface 0/1/2/1 as the source address on all FTP packets, regardless of which interface is actually used to send the packet:

```
Router(config)# ftp client source-interface HundredGigE0/1/2/1
```

# ftp client username

To specify the username for File Transfer Protocol (FTP) connections, use the **ftp client username** command in XR Config mode. To disable this feature, use the **no** form of this command.

```
ftp client username username
no ftp client username username
```

## Syntax Description

**username** Name for FTP user.

## Command Modes

XR Config mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Task ID

Task ID	Operations
ip-services	read, write

## Examples

The following example shows how to specify the username for FTP connections:

```
Router(config)# ftp client username brownfox
```

# http client connection

To configure the connection for http client, use the **http client connection** command in XR Config mode. To restore the default value, use the **no** form of this command.

```
http client connection { retry count | timeout seconds }
```

Syntax Description	retry <i>count</i>	timeout <i>seconds</i>
	Specifies how many times HTTP Client resends a connection request. Range is from 1 to 5. The default value is 0.	The time interval (in seconds) that HTTP client waits for a server connection to establish before giving up. Range is from 1 to 60 seconds. The default value is 10 seconds.

**Command Default** The connection retry is not configured by default. The default connection timeout is set to 10 seconds.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use this command to set the connection timeout or connection retry count.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to configure the connection request retry to two times:

```
RP/0/RP0/CPU0:router (config) #http client connection retry 2
```

The following example shows how to configure the connection request timeout to 20 seconds:

```
RP/0/RP0/CPU0:router (config) #http client connection timeout 20
```

# http client response

To configure the time interval (in seconds) for HTTP Client to wait for a response from the server before giving up, use the **http client response** command in XR Config mode. To restore the default value, use the **no** form of this command.

```
http client response { timeout seconds }
```

<b>Syntax Description</b>	<b>timeout</b> <i>seconds</i>	The time interval (in seconds) that HTTP client waits for a response from the server before giving up. Range is from 1 to 300 seconds. The default value is 30 seconds.
<b>Command Default</b>	The response timeout is 30 seconds by default.	
<b>Command Modes</b>	XR Config mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	Use this command to configure the response timeout.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to configure the response timeout to 40 seconds:

```
RP/0/RP0/CPU0:router(config)#http client response timeout 40
```

# http client secure-verify-host

To enable verifying host in peer's certificate, use the **http client secure-verify-host** command in XR Config mode. To restore the default value, use the **no** form of this command.

## http client secure-verify-host

<b>Syntax Description</b>	<b>secure-verify-host</b> Verifies the host in peer's certificate. This is enabled by default. To disable, use the command <b>http client secure-verify-host <i>disable</i></b>				
<b>Command Default</b>	Host verification is enabled by default.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	Use the <b>http client secure-verify-host</b> command to disable the host verification.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				

The following example shows how to disable host verification :

```
RP/0/RP0/CPU0:router (config) #http client secure-verify-host disable
```

# http client secure-verify-peer

To enable verifying authenticity of the peer certificate, use the **http client secure-verify-peer** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client secure-verify-peer**

<b>Syntax Description</b>	<b>secure-verify-peer</b> Verifies authenticity of the peer certificate. This is enabled by default. To disable, use the command <b>http client secure-verify-peer disable</b>				
<b>Command Default</b>	Peer verification is enabled by default.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	Use the <b>http client secure-verify-peer</b> command to disable the peer verification.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				

The following example shows how to disable peer verification :

```
RP/0/RP0/CPU0:router(config)#http client secure-verify-peer disable
```

## http client source-interface

To specify the interface for source address for Hypertext Transfer Protocol (HTTP) connections, use the **http client source-interface** command in XR Config mode. To remove the **http client source-interface** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**http client source-interface** { **ipv4** | **ipv6** }

### Syntax Description

**ipv4** Enter ipv4 address from interface.  
*ip-address*

**ipv6** Enter ipv6 address from interface.  
*ip-address*

### Command Default

No default behavior or values.

### Command History

Release	Modification
Release 7.10.1	This command was modified to configure both ipv4 and ipv6 source interfaces.
Release 7.0.12	This command was introduced.

### Usage Guidelines

Use the **http client source-interface** command to configure ipv4 and ipv6 source interfaces. If both the source interfaces are configured, then the source interface is selected depending on the host DNS resolution.

### Task ID

Task ID	Operations
config-services	read, write

The following example shows how to configure ipv4 source interface for HTTP connection:

```
RP/0/RP0/CPU0:router(config)#http client source-interface ipv4 gigabitEthernet 0/0/0/0
```

The following example shows how to configure ipv6 source interface for HTTP connection:

```
RP/0/RP0/CPU0:router(config)#http client source-interface ipv6 gigabitEthernet 0/0/0/0
```



# http client ssl

To configure Secure Socket Layer (SSL) version to be used for HTTPS requests, use the **http client ssl** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client ssl** *version*

<b>Syntax Description</b>	<p><b>ssl version</b> Specify the SSL version to be used for HTTPS requests. Select one of the following versions:</p> <ul style="list-style-type: none"> <li>• <b>tls1.0</b> - Forces TLSv1.0 to be used for HTTPS requests.</li> <li>• <b>tls1.1</b> - Forces TLSv1.1 to be used for HTTPS requests.</li> <li>• <b>tls1.2</b> - Forces TLSv1.2 to be used for HTTPS requests.</li> <li>• <b>tls1.3</b> - Forces TLSv1.3 to be used for HTTPS requests.</li> </ul>
---------------------------	---

By default libcurl does not force the TLS version.

<b>Command Default</b>	By default, the SSL version is not configured.
------------------------	--

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> <tr> <td>Release 24.3.1</td> <td>The support for SSL version TLS 1.3 was added.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.	Release 24.3.1	The support for SSL version TLS 1.3 was added.
Release	Modification						
Release 7.0.12	This command was introduced.						
Release 24.3.1	The support for SSL version TLS 1.3 was added.						

<b>Usage Guidelines</b>	Use this command to configure the ssl version to be used in HTTPS requests.
-------------------------	---

<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-servicess</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-servicess	read, write
Task ID	Operations				
config-servicess	read, write				

The following example shows how to configure the SSL version to `tls1.1`:

```
RP/0/RP0/CPU0:router(config)#http client ssl tls1.1
```

# http client tcp-window-scale

To configure the TCP window scale factor for high latency links, use the **http client tcp-window-scale** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client tcp-window-scale** *scale*

<b>Syntax Description</b>	<i>scale</i> Specify the TCP window scale for HTTP requests. Range is 1 to 14.
---------------------------	--

<b>Command Default</b>	By default, TCP window scale is disabled.
------------------------	---

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.3.6	This command was introduced.

<b>Usage Guidelines</b>	Use this command to configure the TCP window scale for HTTP requests.
-------------------------	---



<b>Note</b>	Currently, this is enabled for copying of files using HTTP.
-------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to set the TCP window scale to 10:

```
RP/0/RP0/CPU0:router (config) #http client tcp-window-scale 10
```

# http client version

To configure the HTTP version to be used for HTTP requests, use the **http client version** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client version** *version*

<b>Syntax Description</b>	<p><b>version</b><i>version</i> Specify the HTTP version to be used for HTTP requests. Select one of the following versions:</p> <ul style="list-style-type: none"> <li>• <b>1.0</b> - Forces HTTP1.0 to be used for all HTTP requests.</li> <li>• <b>1.1</b> - Forces HTTP1.1 to be used for all HTTP requests.</li> <li>• <b>default</b> - libcurl picks up HTTP version automatically.</li> </ul>
---------------------------	--

<b>Command Default</b>	By default, libcurl does not force the HTTP version.
------------------------	--



<b>Note</b>	HTTP Client uses libcurl version 7.30
-------------	---------------------------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

<b>Usage Guidelines</b>	Use this command to configure the HTTP version to be used in HTTP requests.
-------------------------	---

<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				

The following example shows how to configure the HTTP version to 1.1:

```
Router(config)#http client version 1.1
```

## http client vrf

To configure a new VRF to be used by the HTTP client, use the **http client vrf** command. To remove the specified vrf, use the **no** form of this command.

```
http client vrf vrf-name
```

<b>Syntax Description</b>	<i>vrf-name</i> Specifies the name of the VRF to be used by the HTTP client.				
<b>Command Default</b>	If not configured, the default VRF "default-vrf" will be used.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	A HTTP client can have only one VRF. If a specific VRF is not configured for the HTTP client, the default VRF is assumed.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				

The following example shows the HTTP client being configured to start with the specified VRF:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# http client vrf green
```

## logging source-interface vrf

To configure the logging source interface in order to identify the syslog traffic that originates in a VRF from a particular router, as coming from a single device, use the **logging source-interface vrf** command in XR Config mode. To remove the source-interface logging configuration for the given VRF, use the **no** form of this command.

```
logging source-interface interface vrf vrf-name
no logging source-interface interface vrf vrf-name
```

### Syntax Description

*interface* Interface number of the source

*vrf-name* Name that identifies the VRF

### Command Default

If *vrf-name* is not specified, the source interface is configured for the default VRF.

### Command Modes

XR Config mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

Normally, a syslog message contains the IPv4 or IPv6 address of the interface used to exit the router. The **logging source-interface** command configures the syslog packets to contain the IPv4 or IPv6 address of a particular interface for a VRF, regardless of which interface the packet uses to exit the router.

### Task ID

Task ID	Operation
logging	read, write

### Example

This example shows how to configure interface loopback 0 to be the logging source interface for VRF vrf1.

```
Router#logging source-interface loopback 0 vrf vrf1
Router#logging source-interface loopback 1 vrf default
```

This sample output shows a logging source interface that is correctly configured for the VRF.

```
Router#show running-config logging
Wed Mar 4 07:37:48.974 UTC
logging console disable
logging source-interface Loopback0 vrf vrf1
```

# ping bulk (network)

To check reachability and network connectivity to multiple hosts on IP networks, use the **ping bulk** command in XR EXEC mode.

```
ping bulk ipv4 [input cli [batch | inline]]
[vrf vrf-name] [ip-address | domain-name]
```

Syntax Description	Parameter	Description
	<b>ipv4</b>	Specifies IPv4 address prefixes.
	<b>input</b>	Specifies input mode.
	<b>cli</b>	Specifies input via CLI.
	<b>batch</b>	Pings after all destinations are input.
	<b>inline</b>	Pings after each destination is input.
	<b>vrf</b> <i>vrf-name</i> <i>ip-address</i> <i>domain-name</i>	(Optional) Specifies a particular VRF. IP address of the system to ping. (Optional) Domain name of the system to ping.
	<b>Note</b>	You must hit the Enter button and then specify one destination address per line.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** You must hit the Enter button and then specify one destination address per line.  
Maximum number of destinations you can specify in the cli or batch mode is 2000.

Task ID	Task ID	Operation
	basic-services	read, write, execute

## Example

The following example shows how to ping many hosts by the input via CLI method:

```
Router# ping bulk ipv4 input cli batch
```

```
Please enter input via CLI with one destination per line and when done Ctrl-D/(exit)
to initiate pings:
1: vrf myvrf1 10.2.1.16
2:
Starting pings...
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 10.2.1.16, vrf is myvrf1, timeout is 2
seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 5/7/9 ms
```

```
Router# ping bulk ipv4 input cli
```

```
Please enter input via CLI with one destination per line:
vrf myvrf1 1.1.1.1
vrf myvrf2 2.2.2.2
vrf myvrf1 myvrf1.cisco.com
vrf myvrf2 myvrf2.cisco.com

Starting pings...
Type escape sequence to abort.
Sending 1, 100-byte ICMP Echos to 1.1.1.1, vrf is myvrf1:
!
Success rate is 100 percent (1/1), round-trip min/avg/max = 1/1/1 ms
Sending 2, 100-byte ICMP Echos to 2.2.2.2, vrf is myvrf2:
!!
Success rate is 100 percent (2/2), round-trip min/avg/max = 1/1/1 ms
Sending 1, 100-byte ICMP Echos to 1.1.1.1, vrf is myvrf1:
!
Success rate is 100 percent (1/1), round-trip min/avg/max = 1/4/1 ms
Sending 2, 100-byte ICMP Echos to 2.2.2.2, vrf is myvrf2:
!!
Success rate is 100 percent (2/2), round-trip min/avg/max = 1/3/1 ms
```

## ping (network)

To check host reachability and network connectivity on IP networks, use the **ping** command in XR EXEC mode.

**ping** [**ipv4** | **ipv6**] [*host-name*|*ip-address*] [**count** *number*] [**size** *number*] [**source** {*ip-address*|*interface-name* | **type** *number*}] [**timeout** *seconds*] [**pattern** *number*] [**type** *number*] [**priority** *number*][**verbose**] [**donnotfrag**] [**validate**] [**sweep**]

Syntax	Description
<b>ipv4</b>	(Optional) Specifies IPv4 address prefixes.
<b>A.B.C.D</b>	Target end address of the pseudowire.
<i>host-name</i>	(Optional) Hostname of the system to ping.
<i>ip-address</i>	(Optional) IP address of the system to ping.
<b>count</b> <i>number</i>	(Optional) Sets the repeat count. Range is 0 to 2147483647.
<b>size</b> <i>number</i>	(Optional) Sets the datagram size. Range is 36 to 18024
<i>source</i>	(Optional) Identifies the source address or source interface.
<b>type</b> <i>number</i>	(Optional) Sets the type of service. Range is 0 to 255. Available when the <b>ipv4</b> keyword is specified.
<b>timeout</b> <i>seconds</i>	(Optional) Sets the timeout in seconds. Range is 0 to 3600.
<b>priority</b> <i>number</i>	(Optional) Sets the packet priority. Range is 0 to 15. Available when the <b>ipv6</b> keyword is specified.
<b>pattern</b> <i>number</i>	(Optional) Sets the data pattern. Range is 0 to 65535.
<i>verbose</i>	(Optional) Sets verbose output.
<b>donnotfrag</b>	(Optional) Sets the Don't Fragment (DF) bit in the IP header.
<b>validate</b>	(Optional) Validates the return packet.
<b>sweep</b>	(Optional) Sets the sweep ping.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The default value for the **ping** command refers only to the target IP address. No default value is available for the target IP address.



The ping program sends an echo request packet to an address and then waits for a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.



**Note** The **ping** (EXEC) command is supported only on IP networks.

If you enter the command without specifying either a hostname or an IP address, the system prompts you to specify the target IP address and several other command parameters. After specifying the target IP address, you can specify alternate values for the remaining parameters or accept the displayed default for each parameter.

If the system cannot map an address for a hostname, it returns an “%Unrecognized host or address, or protocol not running” error message.

To abnormally terminate a ping session, enter the escape sequence, which is, by default, Ctrl-C. Simultaneously press and release the Ctrl and C keys.

This table describes the test characters sent by the ping facility.

**Table 27: ping Test Characters**

Character	Description
!	Each exclamation point indicates receipt of a reply.
.	Each period indicates that the network server timed out while waiting for a reply.
?	Unknown packet type.
U	A “destination unreachable” error protocol data unit (PDU) was received.
C	A “congestion experienced” packet was received.
M	Fragmentation is needed, but the “don’t fragment” bit in the IP header is set. When this bit is set, the IP layer does not fragment the packet and returns an Internet Control Message Protocol (ICMP) error message to the source if the packet size is larger than the maximum transmission size. When this bit is not set, the IP layer fragments the packet to forward it to the next hop.
Q	A source quench packet was received.

Task ID	Task ID	Operations
	basic-services	read, write, execute

### Examples

Although the precise dialog varies somewhat between IPv4 and IPv6, all are similar to the ping session, using default values shown in the following output:

```
Router# ping

Protocol [ipv4]:
Target IP address: 10.0.0.1
Repeat count [5]:
Datagram size [100]:
Timeout in seconds [2]:
```

```
Extended commands? [no]: yes
Source address or interface: 10.0.0.2
Type of service [0]:
Set DF bit in IP header? [no]:
Validate reply data? [no]: yes
Data pattern [0xABCD]:
Loose, Strict, Record, Timestamp, Verbose[none]:
Sweep range of sizes? [no]:
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 10.25.58.21, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 2/11/49 ms
```

If you enter a hostname or an address on the same line as the **ping** command, the command performs the default actions appropriate for the protocol type of that hostname or address, as shown in the following output:

```
Router# ping server01

Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.168.7.27, timeout is 2 seconds:
!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/9 ms
```

# scp

To securely transfer a file from a local directory to a remote directory or from a remote directory to a local directory, use the **scp** command in XR EXEC mode.

```
scp {local-directory username@location/directory} /filename {username@location/directory local-directory} /filename
```

Syntax Description		
	<i>local-directory</i>	Specifies the local directory on the device.
	<i>username@location/directory</i>	Specifies the remote directory where <i>location</i> is the IP address of the remote device.
	<i>filename</i>	Specifies the file name to be transferred.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Secure Copy Protocol (SCP) is a file transfer protocol which provides a secure and authenticated method for transferring files. SCP relies on SSHv2 to transfer files from a remote location to a local location or from local location to a remote location.

Use the **scp** command to copy a file from the local device to a destination device or from a destination device to the local device.

Using SCP, you can only transfer individual files. You cannot transfer a file from a remote device to another remote device.

SSH server process must be running on the remote device.

Task ID	Task ID	Operations
	ip-services	read, write

## Examples

The following example shows how to copy a file using the **scp** command from a local directory to a remote directory:

```
Router# scp /usr/file1.txt root@209.165.200.1:/root/file3.txt
```

```
Connecting to 209.165.200.1...
```

```
Password:
```

```
Transferred 553065 Bytes
```

```
553065 bytes copied in 0 sec (7576232)bytes/sec
```

The following example shows how to copy a file using the **scp** command from a remote directory to a local directory:

```
Router# scp root@209.165.200.1:/root/file4.txt /usr/file.txt
```

```
Connecting to 209.165.200.1...
```

```
Password:
```

```
Transferred 553065 Bytes
```

```
553065 bytes copied in 0 sec (7576232)bytes/sec
```

# show cinetd services

To display the services whose processes are spawned by Cinetd when a request is received, use the **show cinetd services** command in XR Exec mode.

```
show cinetd services
```

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

**Command History**

Release	Modification
Release 7.5.4	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

**Task ID**

Task ID	Operations
ip-services	read

## Examples

The following is sample is output from the **show cinetd services** command:

```
RP/0/RP0/CPU0:router# show cinetd services

Vrf Name          Family Service Proto Port ACL max_cnt curr_cnt wait Program Client Option
context-management v4      tftp  udp   69   unlimited    0   wait tftpd sysdb disk0:
default           v4      telnet tcp   23    100          2   nowait telnetd sysdb disk0
```

This table describes the significant fields shown in the display.

**Table 28: show cinetd services Command Field Descriptions**

Field	Description
Family	Version of the network layer (IPv4 or IPv6).
Service	Network service (for example, FTP, Telnet, and so on).
Proto	Transport protocol used by the service (tcp or udp).
Port	Port number used by the service.
ACL	Access list used to limit the service from some hosts.
max_cnt	Maximum number of concurrent servers allowed for a service.

Field	Description
curr_cnt	Current number of concurrent servers for a service.
wait	Status of whether Cinetd has to wait for a service to finish before serving the next request.
Program	Name of the program for a service.
Option	Service-specific options.

# show hosts

To display the default domain name, the style of name lookup service, a list of name server hosts, and the cached list of hostnames and addresses, use the **show hosts** command in XR EXEC mode.

```
show hosts [host-name]
```

<b>Syntax Description</b>	host-name (Optional) Name of the host about which to display information. If omitted, all entries in the local cache are displayed.				
<b>Command Default</b>	Unicast address prefixes are the default when IPv4 address prefixes are configured.				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read
Task ID	Operations				
ip-services	read				

## Examples

The following is sample output from the **show hosts** command:

```
Router# show hosts

Default domain is cisco.com
Name/address lookup uses domain service
Name servers are 255.255.255.255
Host          Flags          Age (hr)   Type          Address(es)
host1.cisco.com (temp, OK)    1          IP            192.168.4.10
abc           (perm, OK)    0          IP            10.0.0.0 10.0.0.2 10.0.0.3
```

This table describes the significant fields shown in the display.

**Table 29: show hosts Command Field Descriptions**

Field	Description
Default domain	Default domain used to complete the unqualified hostnames.
Name/address lookup	Lookup is disabled or uses domain services.
Name servers	List of configured name servers.
Host	Hostname.

Field	Description
Flags	Indicates the status of an entry. <ul style="list-style-type: none"><li>• temp—Temporary entry entered by a name server; the software removes the entry after 72 hours of inactivity.</li><li>• perm—Permanent entry entered by a configuration command; does not time out.</li><li>• OK—Entry is believed to be valid.</li><li>• ??—Entry is considered suspect and subject to revalidation.</li><li>• EX—Entry has expired.</li></ul>
Age(hr)	Number of hours since the software most recently referred to the cache entry.
Type	Type of address (IPv4 or IPv6).
Address(es)	Address of the host. One host may have up to eight addresses.



# telnet

To log in to a host that supports Telnet, use the **telnet** command in XR EXEC mode.

```
telnet [vrf {vrf-name | default}] {ip-address | host-name} [options]
```

Syntax Description		
vrf		(Optional) Specifies a VPN routing and forwarding (VRF) instance
vrf-name		VRF name of the system to ping.
default		Specifies the default VRF instance.
ip-address		IP address of a specific host on a network. <ul style="list-style-type: none"> <li>• IPv4 address format—Must be entered in the (x.x.x.x) format.</li> <li>• IPv6 address format— Must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.</li> </ul>
host-name		Name of a specific host on a network.
options		(Optional) Telnet connection options. See <b>Telnet Connection Options</b> for a list of supported options.

**Command Default** Telnet client is in Telnet connection options nostream mode.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If the Telnet server is enabled, you should be able to start a Telnet session as long as you have a valid username and password.

This table lists the supported Telnet connection options.

**Table 30: Telnet Connection Options**

Option	Description
/stream	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and can be appropriate for connections to ports running UNIX-to-UNIX copy program (UUCP) and other non-Telnet protocols.
/nostream	Turns off stream processing.
port number	Port number. Range is 0 to 65535.
/source-interface	Specifies source interface.

To display a list of the available hosts, use the **show hosts** command. To display the status of all TCP connections, use the **show tcp** command.

The software assigns a logical name to each connection, and several commands use these names to identify connections. The logical name is the same as the hostname, unless that name is already in use or you change the connection name with the **name-connection EXEC** command. If the name is already in use, the software assigns a null name to the connection.

The Telnet software supports special Telnet commands in the form of Telnet sequences that map generic terminal control functions to operating system-specific functions. To issue a special Telnet command, enter the escape sequence and then a command character. The default escape sequence is Ctrl-^ (press and hold the Control and Shift keys and the 6 key). You can enter the command character as you hold down Ctrl or with Ctrl released; you can use either uppercase or lowercase letters. **Special Telnet Escape Sequences** lists the special Telnet escape sequences.

**Table 31: Special Telnet Escape Sequences**

Escape Sequence <sup>7</sup>	Purpose
Ctrl-^ c	Interrupt Process (IP).
Ctrl-^ o	Terminates Output (AO).
Ctrl-^ u	Erase Line (EL).

<sup>7</sup> The caret (^) symbol refers to Shift-6 on your keyboard.

At any time during an active Telnet session, you can list the Telnet commands by pressing the escape sequence keys followed by a question mark at the system prompt:

**ctrl-^?**

A sample of this list follows. In this sample output, the first caret (^) symbol represents the Control key, and the second caret represents Shift-6 on your keyboard:

```
Router# ^^?
```

```
[Special telnet escape help]
^^B  sends telnet BREAK
^^C  sends telnet IP
^^H  sends telnet EC
^^O  sends telnet AO
^^T  sends telnet AYT
^^U  sends telnet EL
```

You can have several concurrent Telnet sessions open and switch among them. To open a subsequent session, first suspend the current connection by pressing the escape sequence (Ctrl-Shift-6 and then x [Ctrl^x] by default) to return to the system command prompt. Then open a new connection with the **telnet** command.

To terminate an active Telnet session, issue any of the following commands at the prompt of the device to which you are connecting:

- close
- disconnect
- exit
- logout
- quit

Task ID	Task ID	Operations
	basic-services	read, write, execute

### Examples

The following example shows how to establish a Telnet session to a remote host named host1:

```
Router# telnet host1
```

## telnet client source-interface

To specify the source IP address for a Telnet connection, use the **telnet client source-interface** command in XR Config mode. To remove the **telnet client source-interface** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
telnet {ipv4|ipv6} client source-interface type interface-path-id
no telnet client source-interface type interface-path-id
```

Syntax Description		
<b>ipv4</b>	Specifies IPv4 address prefixes.	
<b>ipv6</b>	Specifies IPv6 address prefixes.	
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.	
<i>interface-path-id</i>	Physical interface or virtual interface.	
	<b>Note</b> Use the show interfaces command to see a list of all interfaces currently configured on the router.	
	For more information about the syntax for the router, use the question mark (?) online help function.	

**Command Default** The IP address of the best route to the destination is used as the source IP address.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **telnet client source-interface** command to set the IP address of an interface as the source for all Telnet connections.

Task ID	Task ID	Operations
	ipv4	read, write
	ip-services	read, write

### Examples

The following example shows how to set the IP address for HundredGigE interface 1/0/2/1 as the source address for Telnet connections:

```
Router(config)# telnet ipv4 client source-interface hundredgige1/0/2/1
```

# telnet dscp

To define the differentiated services code point (DSCP) value and IPv4 precedence to specifically set the quality-of-service (QoS) marking for Telnet traffic on a networking device, use the **telnet dscp** command in XR Config mode. To disable DSCP, use the **no** form of this command.

```
telnet [vrf {vrf-name | default}] ipv4 dscp dscp-value
no telnet [vrf {vrf-name | default}] ipv4 dscp dscp-value
```

Syntax Description		
	<b>vrf</b>	(Optional) Specifies a VPN routing and forwarding (VRF) instance.
	<b>vrf-name</b>	(Optional) VRF name of the system to ping.
	<b>default</b>	(Optional) Specifies the default VRF instance.
	ipv4	Specifies IPv4 address prefixes.
	dscp-value	Value for DSCP. The range is from 0 to 63. The default value is 0.

**Command Default** If DSCP is disabled or not configured, the following default values are listed:

- The default value for the server is 16.
- The default value for the client is 0.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** IPv4 is the supported protocol for defining a DSCP value for locally originated Telnet traffic. DSCP can impact both server and client behavior of the specific VRF.

Task ID	Task ID	Operations
	ipv4	read, write
	ip-services	read, write

**Examples** The following example shows how to define the DSCP value and IPv4 precedence:

```
Router(config)# telnet vrf default ipv4 dscp 40  
Router(config)# telnet vrf default ipv4 dscp 10
```

# telnet server

To enable Telnet services on a networking device, use the **telnet server** command in XR Config mode. To disable Telnet services, use the **no** form of this command.

```
telnet [vrf {vrf-name | default}] {ipv4 | ipv6} server max-servers {no-limit|limit} [access-list list-name]
no telnet [vrf {vrf-name | default}] {ipv4 | ipv6} server max-servers {no-limit|limit} [access-list list-name]
```

Syntax Description	
vrf	(Optional) Specifies VPN routing and forwarding (VRF) instance.
vrf-name	(Optional) VRF name of the system to ping.
default	(Optional) Specifies the default VRF instance.
ipv4	Specifies IPv4 address prefixes.
ipv6	Specifies IPv6 address prefixes.
max-servers	Sets the number of allowable Telnet servers.
no-limit	Specifies that there is no maximum number of allowable Telnet servers.
limit	Specifies the maximum number of allowable Telnet servers. Range is 1 to 200.
access-list	(Optional) Specifies an access list.
list-name	(Optional) Access list name.

**Command Default** Telnet services are disabled.

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Disable Telnet services to prevent inbound Telnet connections from being accepted into a networking device using the **telnet** command. After Telnet services are disabled, no new inbound connections are accepted, and the Cisco Internet services daemon (Cinetd) stops listening on the Telnet port.

Enable Telnet services by setting the **max-servers** keyword to a value of one or greater. This allows inbound Telnet connections into a networking device.

This command affects only inbound Telnet connections to a networking device. Outgoing Telnet connections can be made regardless of whether Telnet services are enabled.

Using the **no** form of the command disables the Telnet connection and restores the system to its default condition.




---

**Note** Before establishing communications with the router through a Telnet session, configure the telnet server and vty-pool functions (see *System Management Command Reference for Cisco 8000 Series Routers*, *System Management Configuration Guide for Cisco 8000 Series Routers*, and *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*).

---

Task ID	Task ID	Operations
	ipv4	read, write
	ip-services	read, write

### Examples

The following example shows how to enable Telnet services for one server:

```
Router(config)# telnet ipv4 server max-servers 1
```



# telnet transparent

To send a Carriage Return (CR) as a CR-NULL rather than a Carriage Return-Line Feed (CR-LF) for virtual terminal sessions, use the **telnet transparent** command in line template submode. To remove the **telnet transparent** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**telnet transparent**  
**no telnet transparent**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** Line console

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **telnet transparent** command is useful for coping with different interpretations of end-of-line handling in the Telnet protocol specification.

Task ID	Task ID	Operations
	tty-access	read, write

## Examples

The following example shows how to configure the vty line to operate in Telnet transparent mode so that when the carriage return key is pressed the system sends the signal as a CR-NULL key combination rather than a CR-LF key combination:

```
Router(config)# line console
Router(config-line)# telnet transparent
```

# tftp server

To enable or disable the TFTP server or a feature running on the TFTP server, use the **tftp server** command in XR Config mode.

```
tftp { ipv4 | ipv6 } server homedir tftp-home-directory [ max-servers [ number | no-limit ] | access-list name ]
```

## Syntax Description

<b>ipv4</b>	Specifies IPv4 address prefixes.
<b>ipv6</b>	Specifies IPv6 address prefixes.
<b>homedir</b> <i>tftp-home-directory</i>	Specifies the home directory.
<b>max-servers</b> <i>number</i>	(Optional) Sets the maximum number of concurrent TFTP servers. The range is from 1 to 2147483647.
<b>max-servers no-limit</b>	(Optional) Sets no limit to process a number of allowable TFTP server.
<b>access-list</b> <i>name</i>	(Optional) Specifies the name of the access list associated with the TFTP server.

## Command Default

The TFTP server is disabled by default. When not specified, the default value for the **max-servers** keyword is unlimited.

## Command Modes

XR Config mode

## Command History

Release	Modification
Release 7.5.4	This command was introduced.

## Usage Guidelines

Using the **no** form of the **tftp server** command removes the specified command from the configuration file and restores the system to its default condition. The **no** form of the command is not stored in the configuration file.

## Task ID

Task ID	Operations
ipv4	read, write
ip-services	read, write

## Examples

The following example shows that the TFTP server is enabled for the access list named test:

```
RP/0/RP0/CPU0:router(config)# tftp ipv4 server homedir disk0 access-list test
```

## tftp client source-interface

To specify the source IP address for a TFTP connection, use the **tftp client source-interface** command in XR Config mode. To remove the **tftp client source-interface** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

```
tftp client source-interface type interface-path-id
no tftp client source-interface type interface-path-id
```

<b>Syntax Description</b>	<p><i>type</i> Interface type. For more information, use the question mark (?) online help function.</p> <hr/> <p><i>interface-path-id</i> Physical interface or virtual interface.</p> <p><b>Note</b> Use the show interfaces command to see a list of all interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>				
<b>Command Default</b>	The IP address of the best route to the destination is used as the source IP address.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th data-bbox="386 1031 537 1062">Release</th> <th data-bbox="553 1031 704 1062">Modification</th> </tr> </thead> <tbody> <tr> <td data-bbox="386 1083 537 1115">Release 7.0.12</td> <td data-bbox="553 1083 704 1115">This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	Use the <b>tftp client source-interface</b> command to set the IP address of an interface as the source for all TFTP connections.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th data-bbox="386 1276 488 1308">Task ID</th> <th data-bbox="505 1276 623 1308">Operations</th> </tr> </thead> <tbody> <tr> <td data-bbox="386 1329 488 1360">ip-services</td> <td data-bbox="505 1329 623 1392">read, write</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read, write
Task ID	Operations				
ip-services	read, write				
<b>Examples</b>	<p>The following example shows how to set the IP address for HundredGigE interface 1/0/2/1 as the source address for TFTP connections:</p> <pre>Router(config)# <b>tftp client source-interface</b> hundredgige1/0/2/1</pre>				

# tracert

To discover the routes that packets actually take when traveling to their destination across an IP network, use the **tracert** command in XR EXEC mode.

**tracert** [**ipv4** | **ipv6**] [*host-name* | *ip-address*] [ {*source* | *ip-address* | *interface-name* } ] [**numeric**] [*timeout seconds*] [*probe count*] [*minttl seconds*] [*maxttl seconds*] [*port number*] [*priority number*] [**verbose**]

Syntax Description	
<b>ipv4</b>	(Optional) Specifies IPv4 address prefixes.
<b>ipv6</b>	(Optional) Specifies IPv6 address prefixes.
<b>host-name</b>	(Optional) Hostname of system to use as the destination of the trace attempt.
<b>ip-address</b>	(Optional) Address of system to use as the destination of the trace attempt.
<b>source</b>	(Optional) Source address.
<i>ip-address-name</i>	(Optional) IP address A.B.C.D or hostname.
<b>numeric</b>	(Optional) Numeric display only.
<b>timeout seconds</b>	(Optional) Timeout value. Range is 0 to 3600.
<b>probe count</b>	(Optional) Probe count. Range is 0 to 65535.
<b>minttl seconds</b>	(Optional) Minimum time to live. Range is 0 to 255.
<b>maxttl seconds</b>	(Optional) Maximum time to live. Range is 0 to 255.
<b>port number</b>	(Optional) Port number. Range is 0 to 65535.
<b>priority number</b>	(Optional) Packet priority. Range is 0 to 15. Available when the <b>ipv6</b> keyword is specified.
<b>verbose</b>	(Optional) Verbose output.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The default value for the **tracert** command refers only to the destination. No default value is available for the destination address.

The **tracert** command works by taking advantage of the error messages generated by networking devices when a datagram exceeds its time-to-live (TTL) value.

The **traceroute** command starts by sending probe datagrams with a TTL value of 1, which causes the first networking device to discard the probe datagram and send back an error message. The **traceroute** command sends several probes at each TTL level and displays the round-trip time for each.

The **traceroute** command sends out one probe at a time. Each outgoing packet may result in one or two error messages. A “time-exceeded” error message indicates that an intermediate networking device has seen and discarded the probe. A “destination-unreachable” error message indicates that the destination node has received the probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, the **traceroute** command prints an asterisk (\*).

The **traceroute** command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace with the escape sequence, which is, by default, Ctrl-C. Simultaneously press and release the Ctrl and C keys.

To use nondefault parameters and invoke an extended **traceroute** test, enter the command without a *host-name* or *ip-address* argument. You are stepped through a dialog to select the desired parameter values for the **traceroute** test.

Because of how IP is implemented on various networking devices, the IP **traceroute** command may behave in unexpected ways.

Not all destinations respond correctly to a probe message by sending back an “ICMP port unreachable” message. A long sequence of TTL levels with only asterisks, terminating only when the maximum TTL has been reached, may indicate this problem.

There is a known problem with the way some hosts handle an “ICMP TTL exceeded” message. Some hosts generate an “ICMP” message, but they reuse the TTL of the incoming packet. Because this value is zero, the ICMP packets do not succeed in returning. When you trace the path to such a host, you may see a set of TTL values with asterisks (\*). Eventually the TTL is raised high enough that the “ICMP” message can get back. For example, if the host is six hops away, the **traceroute** command times out on responses 6 through 11.

Task ID	Task ID	Operations
	basic-services	read, write, execute

## Examples

The following output shows a sample **traceroute** session when a destination hostname has been specified:

```
Router# traceroute host8-sun

Type escape sequence to abort.
Tracing the route to 192.168.0.73
 0 192.168.1.6 (192.168.1.6) 10 msec 0 msec 10 msec
 1 gateway01-gw.gateway.cisco.com (192.168.16.2) 0 msec 10 msec 0 msec
 2 host8-sun.cisco.com (192.168.0.73) 10 msec * 0 msec
```

The following display shows a sample extended **traceroute** session when a destination hostname is not specified:

```
traceroute# traceroute

Protocol [ipv4]:
Target IP address: ena-view3
Source address: 10.0.58.29
Numeric display? [no]:
Timeout in seconds [3]:
```

```

Probe count [3]:
Minimum Time to Live [1]:
Maximum Time to Live [30]:
Port Number [33434]:
Loose, Strict, Record, Timestamp, Verbose[none]:

```

Type escape sequence to abort.

Tracing the route to 171.71.164.199

```

 1  sjc-jpxlnock-vpn.cisco.com (10.25.0.1) 30 msec  4 msec  4 msec
 2  151lab-vlan725-gw1.cisco.com (173.19.72.2) 7 msec  5 msec  5 msec
 3  stc15-001lab-gw1.cisco.com (173.24.114.33) 5 msec  6 msec  6 msec
 4  stc5-lab4-gw1.cisco.com (173.24.114.89) 5 msec  5 msec  5 msec
 5  stc5-sbb4-gw1.cisco.com (172.71.241.162) 5 msec  6 msec  6 msec
 6  stc5-dc5-gw1.cisco.com (172.71.241.10) 6 msec  6 msec  5 msec
 7  stc5-dc1-gw1.cisco.com (172.71.243.2) 7 msec  8 msec  8 msec
 8  ena-view3.cisco.com (172.71.164.199) 6 msec  *  8 msec

```

This table describes the characters that can appear in traceroute output.

**Table 32: traceroute Text Characters**

Character	Description
xx msec	For each node, the round-trip time in milliseconds for the specified number of probes.
*	Probe time out.
?	Unknown packet type.
A	Administratively unreachable. This output usually indicates that an access list is blocking traffic.
H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
U	Port unreachable.



## LPTS Commands

---

This chapter describes the Cisco IOS XR software commands used to monitor Local Packet Transport Services.

For detailed information about LPTS concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [clear lpts ifib statistics, on page 298](#)
- [clear lpts pifib statistics , on page 299](#)
- [flow \(LPTS\), on page 300](#)
- [lpts pifib hardware dynamic-flows, on page 303](#)
- [lpts pifib hardware police, on page 305](#)
- [show lpts bindings, on page 307](#)
- [show lpts clients, on page 311](#)
- [show lpts flows, on page 313](#)
- [show lpts ifib , on page 316](#)
- [show lpts ifib slices, on page 319](#)
- [show lpts ifib statistics, on page 322](#)
- [show lpts ifib times, on page 324](#)
- [show lpts pifib, on page 326](#)
- [show lpts pifib hardware entry, on page 331](#)
- [show lpts pifib hardware object-group entry, on page 334](#)
- [show lpts pifib hardware police, on page 339](#)
- [show lpts pifib statistics, on page 343](#)
- [show lpts port-arbitrator statistics, on page 344](#)
- [show lpts vrf, on page 345](#)

# clear lpts ifib statistics

To clear the Internal Forwarding Information Base (IFIB) statistics, use the **clear lpts ifib statistics** command in XR EXEC mode.

**clear lpts ifib statistics** [**location** *node-id*]

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> Clears the IFIB statistics for the designated node. The <i>node-id</i> argument is entered in standard <i>rack/slot/module</i> notation.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	lpts	execute

**Examples** The following example shows how to clear the IFIB statistics for the RP:

```
RP/0/RP0/CPU0:router# clear lpts ifib statistics
```



# clear lpts pifib statistics

To clear the Pre-Internal Forwarding Information Base (Pre-IFIB) statistics, use the **clear lpts pifib statistics** command in XR EXEC mode.

```
clear lpts pifib statistics [location node-id]
```

<b>Syntax Description</b>	<b>location node-id</b> Clears the Pre-IFIB statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>lpts</td> <td>execute</td> </tr> </tbody> </table>	Task ID	Operations	lpts	execute
Task ID	Operations				
lpts	execute				
<b>Examples</b>	<p>The following example shows how to clear the Pre-IFIB statistics for the RP:</p> <pre>RP/0/RP0/CPU0:router# clear lpts pifib statistics location 0/RP0/CPU0</pre>				

## flow (LPTS)

To configure the policer for the Local Packet Transport Services (LPTS) flow type, use the **flow** command in pifib policer global configuration mode or pifib policer per-node configuration mode. To disable this feature, use the **no flow** form of this command.

```
flow flow-type rate rate
no flow flow-type rate rate
```

### Syntax Description

**flow-type** List of supported flow types.

**rate rate** Specifies the rate in packets per seconds (PPS). The range is from 0 to 50000.

### Command Default

The default behavior is to load the policer values from the static configuration file that is platform dependant.

### Command Modes

Pifib policer global configuration

Pifib policer per-node configuration

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

The table lists the supported flow types and the parameters that are used to define a policer.

*Table 33: List of Supported Flow Types*

Flow Type	Description	Default Packet Rate (Recommended)
BGP-default	SRC port 179 and Dest Port 179 with protocol as TCP.	4000
fragment	IPv4/v6 fragmented packets.	1000
ICMP-default	All ICMP type packets.	2500
ISIS default	All ISIS protocol packets.	3500

Flow Type	Description	Default Packet Rate (Recommended)
LDP-UDP	UDP with Destination Port 646.	2000
OSPF-MC-default	OSPFv2 (24052406)OSPF3 ( FF02::5 and FF02::6).	3500
OSPF-UC-default	OSPFv2 and OSPFv3 Unicast DBD packets.	3000
RAW-default	RAW default entry in LPTS.	500
RSVP-default	All RSVP protocol packets ( RSVP signalling, refresh etc...).	14500
TCP-default	All TCP protocol packets (TCP-known, cfg-peer, listen).	25500
Third party applications	All third party application packets.	10000
UDP-default	All UDP protocol packets (UDP-known, CFG-peer, listen).	25500

**Task ID****Task ID****Operations**

config-services read,  
write

---

**Examples**

The following example shows how to configure the LPTS policer for the bgp-default flow type for all line cards:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lpts pifib hardware police
RP/0/RP0/CPU0:router(config-pifib-policer-global)# flow bgp-default rate 4000
```

The following example shows how to configure LPTS policer for the Intermediate System-to-Intermediate System (IS-IS)-default flow type for a specific line card:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:routerconfig)# lpts pifib hardware police location 0/2/CPU0
RP/0/RP0/CPU0:router(config-pifib-policer-per-node)# flow isis-default rate 22222
```

# Ipts pifib hardware dynamic-flows

To configure LPTS flow types and define the maximum LPTS entries for each flow type in the TCAM use the **lpts pifib hardware dynamic-flows** in configuration mode.

**lpts pifib hardware dynamic-flows location** *node-id* **flow** *flow-type* **max** *maximum-flow-entries*

Syntax Description	location	<i>node-id</i>	Configures Dynamic LPTS per node. The <i>node-id</i> argument is entered in the rack/slot/module notation. For more information, use the question mark (?) online help function
	flow	<i>flow-type</i>	Configures specified flow type.
	max	<i>maximum-flow-entries</i>	Configures maximum flow entries per node. <b>Note</b> The maximum flow entry value of zero denotes that a flow type is not configured. For more information, use the question mark (?) online help function

**Command Default** Dynamic LPTS is disabled

**Command Modes** Configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The sum of maximum LPTS entries configured for all flow types must not exceed 16000 entries. User can configure only configurable LPTS flow types listed in below table.

**Table 34: Configurable Flow Types and Default Maximum Flow Entries**

Flow Type	Default Maximum Flow Entries
BGP-known	900
BGP-cfg-peer	900
IP-SLA	50
LDP-TCP-known	300
LDP-TCP-cfg-peer	300
SSH-known	150
Telnet Known	150

Flow Type	Default Maximum Flow Entries
NTP known	150
LDP-UDP	300
OSPF-uc-known	300
OSPF-mc-known	600
RSVP known	300
ISIS known	300
TPA	5
PIM-mcast-known	300
IGMP	1200
SNMP	300
VRRP	150
DNS	40
All-routers	300



**Note** You can increase or decrease the flow entries of any flow type in such a way that the total of flow entries add up to 8000.

Task ID	Task ID	Operation
	lpts	read, write
	config-services	read, write

In this example you will configure the BGP-known and ISIS-known LPTS flow type in the TCAM and define the maximum flow entries as 1800 and 500 for node location 0/1/CPU0.

```
Router#configure
Router(config)#lpts pifib hardware dynamic-flows location 0/1/CPU0
Router(config-pifib-flows-per-node)#flow bgp-known max 1800
Router(config-pifib-flows-per-node)#flow ISIS-known max 500
```

# lpts pifib hardware police

To configure the ingress policers and to enter pifib policer global configuration mode or pifib policer per-node configuration mode, use the **lpts pifib hardware police** command in XR Config mode. To set the policer to the default value, use the **no** form of this command.

```
lpts pifib hardware police [ location node-id ] [ flow flow-type { default } [ rate rate ]
no lpts pifib hardware police [ location node-id ] [ flow flow-type { default } [ rate rate ]
```

Syntax Description		
<b>location</b> <i>node-id</i>		(Optional) Designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>flow</b> <i>flow-type</i> <b>rate</b> <i>rate</i>		LPTS flow type and the policer rate in packets per second (PPS).
<b>default</b>		Indicates generic flows which are policed with default-rate. For example, BGP (*, 179), any packet with port: 179 policed with default rate.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

## Usage Guidelines

- Provided that the application and the IP-SLA processing rates support it, you can specify the flow rate for IP-SLA flow entries to up to 1500.
- When configuring the HSRP IPv6 networks on Physical interfaces, Physical sub-interfaces, Bundle interfaces, and Bundle sub-interfaces on the Cisco Silicon One P100 and Cisco Silicon One Q200 ASIC-based systems, for a scale higher than the supported scale of IPv6 HSRP groups, set the [default UDP entry policy rate](#) to 3000 or higher to avoid any LPTS drops. For information about the supported scale, see [HSRP over Physical Interfaces and Bundle Interfaces](#).
- When configuring the HSRP/VRRP IPv4 or IPv6 networks on Physical interfaces, Physical sub-interfaces, Bundle interfaces, and Bundle sub-interfaces on the Cisco Silicon One P100 and Cisco Silicon One Q200 ASIC-based systems, for HSRP/VRRP IPv4 or IPv6 groups with a scale higher than the supported scale or groups with aggressive timer values less than 1 second, increase the [LPTS policer rate](#) to 3000 or higher to avoid any LPTS drops. For information about the supported scale, see:
  - [HSRP over Physical Interfaces and Bundle Interfaces](#)
  - [VRRP over Physical Interfaces and Bundle Interfaces](#)

Task ID	Task ID	Operations
	lpts	read, write
	config-services	read, write

## Examples

This example shows how to configure the **lpts pifib hardware police** command for all line cards:

```
RP/0/RP0/CPU0:router(config)# lpts pifib hardware police
RP/0/RP0/CPU0:router(config-pifib-policer-global)#
```

This example shows how to configure the **lpts pifib hardware police** command for a specific line card:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# lpts pifib hardware police location 0/2/CPU0
```

This example shows how to set the default UDP entry policer rate in the **lpts pifib hardware police** command for a specific line card:

```
RP/0/RP0/CPU0:ios(config)#lpts pifib hardware police location 0/0/CPU0 flow udp default
rate 1000
RP/0/RP0/CPU0:ios(config)#commit
Mon Apr 22 22:42:15.322 UTC
RP/0/RP0/CPU0:ios(config)#
```

This example sets the default UDP entry policer rate to 3000 so that there will not be any LPTS drops for HSRP flows for a higher scale.

```
RP/0/RP0/CPU0:ios(config)#lpts pifib hardware police location 0/0/CPU0 flow udp default
rate 3000
RP/0/RP0/CPU0:ios(config)#commit
```

These examples set the LPTS policer rate to 3000 for HSRP and VRRP so that there will not be any LPTS drops for HSRP/VRRP flows for a higher scale.

```
RP/0/RP0/CPU0:ios#configure
Tue Apr 23 05:06:31.016 UTC
RP/0/RP0/CPU0:ios(config)#lpts pifib hardware police
RP/0/RP0/CPU0:ios(config-lpts-policer-global)#flow hsrp rate 3000
RP/0/RP0/CPU0:ios(config-lpts-policer-global)#commit
Tue Apr 23 05:07:13.440 UTC
```

```
RP/0/RP0/CPU0:ios#configure
Tue Apr 23 05:06:31.016 UTC
RP/0/RP0/CPU0:ios(config)#lpts pifib hardware police
RP/0/RP0/CPU0:ios(config-lpts-policer-global)#flow vrrp rate 3000
RP/0/RP0/CPU0:ios(config-lpts-policer-global)#commit
Tue Apr 23 05:07:13.440 UTC
```



## show lpts bindings

To display the binding information in the Port Arbitrator, use the **show lpts bindings** command in XR EXEC mode.

```
show lpts bindings [location node-id] [client-id {clnl | ipsec | ipv4-io | ipv6-io | mpa | tcp | test | udp
| raw}] [brief] [vrf vrf-name]
```

### Syntax Description

<b>location</b> <i>node-id</i>	(Optional) Displays information for the specified node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>client-id</b>	(Optional) Type of client. It can be one of the following values: <ul style="list-style-type: none"> <li>• <b>clnl</b> —ISO connectionless protocol (used by IS-IS)</li> <li>• <b>ipsec</b> —Secure IP</li> <li>• <b>ipv4-io</b> —Traffic processed by the IPv4 stack</li> <li>• <b>ipv6-io</b> —Traffic processed by the IPv6 stack</li> <li>• <b>mpa</b> —Multicast Port Arbitrator (multicast group joins)</li> <li>• <b>tcp</b> —Transmission Control Protocol</li> <li>• <b>test</b> —Test applications</li> <li>• <b>udp</b> —User Datagram Protocol</li> <li>• <b>raw</b> —Raw IP</li> </ul>
<b>brief</b>	(Optional) Displays summary output.
<b>vrf</b> <i>vrf-name</i>	(Optional) Name of assigned VRF.

### Command Default

No default behavior or values

### Command Modes

XR EXEC mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

The **show lpts bindings** command displays the Local Packet Transport Services (LPTS) bindings (requests to receive traffic of a particular type). Bindings are aggregated into flows by the LPTS Port Arbitrator; flows are then programmed into the Internal Forwarding Information Base (IFIB) and Pre-IFIB to direct packets to applications.

If you specify the optional **client-id** keyword and type of client, only bindings from that client are shown. If you specify the optional **location** keyword and *node-id* argument, only bindings from clients on that node are displayed.

Task ID	Task ID	Operations
	lpts	read

### Examples

The following sample output is from the **show lpts bindings** command, displaying bindings for all client ID types:

```
RP/0/RP0/CPU0:router# show lpts bindings

@ - Indirect binding; Sc - Scope

-----
Location      :0/1/CPU0
Client ID     :IPV4_IO
Cookie        :0x00000001
Clnt Flags    :
Layer 3       :IPV4
Layer 4       :ICMP
Local Addr    :any
Remote Addr   :any
Local Port    :any
Remote Port   :any
Filters       :Type / Intf or Pkt Type / Source Addr / Location
INCLUDE_TYPE / type 8
INCLUDE_TYPE / type 13
INCLUDE_TYPE / type 17
-----

Location      :0/2/CPU0
Client ID     :IPV4_IO
Cookie        :0x00000001
Clnt Flags    :
Layer 3       :IPV4
Layer 4       :ICMP
Local Addr    :any
Remote Addr   :any
Local Port    :any
Remote Port   :any
Filters       :Type / Intf or Pkt Type / Source Addr / Location
INCLUDE_TYPE / type 8
INCLUDE_TYPE / type 13
INCLUDE_TYPE / type 17
-----

Location      :0/RP1/CPU0
Client ID     :TCP
Cookie        :0x4826f1f8
Clnt Flags    :REUSEPORT
Layer 3       :IPV4
Layer 4       :TCP
Local Addr    :any
Remote Addr   :any
Local Port    :7
Remote Port   :any
-----

Location      :0/RP1/CPU0
Client ID     :TCP
Cookie        :0x4826fa0c
Clnt Flags    :REUSEPORT
Layer 3       :IPV4
Layer 4       :TCP
```

```

Local Addr :any
Remote Addr:any
Local Port :9
Remote Port:any
-----
Location   :0/RP1/CPU0
Client ID  :TCP
Cookie     :0x482700d0
Clnt Flags :REUSEPORT
Layer 3    :IPV4
Layer 4    :TCP
Local Addr :any
Remote Addr:any
Local Port :19
Remote Port:any
-----
Location   :0/RP1/CPU0
Client ID  :IPV4_IO
Cookie     :0x00000001
Clnt Flags :
Layer 3    :IPV4
Layer 4    :ICMP
Local Addr :any
Remote Addr:any
Local Port :any
Remote Port:any
Filters    :Type / Intf or Pkt Type / Source Addr / Location
INCLUDE_TYPE / type 8
INCLUDE_TYPE / type 13
INCLUDE_TYPE / type 17

```

This table describes the significant fields shown in the display.

**Table 35: show lpts bindings Command Field Descriptions**

Field	Description
Location	Node location, in the format of <i>rack/slot/module</i> .
Client ID	LPTS client type.
Cookie	Client's unique tag for the binding.
Clnt Flags	REUSEPORT -- client has set the SO_REUSEPORT or SO_REUSEADDR socket option.
Layer 3	Layer 3 protocol (IPv4, IPv6, CLNL).
Layer 4	Layer 4 protocol (TCP, UDP).
Local Addr	Local (destination) address.
Remote Addr	Remote (source) address.
Local Port	Local (destination) TCP or UDP port, or ICMP/IGMP packet type, or IPsec SPI.
Remote Port	Remote (source) TCP or UDP port.

The following sample output is from the **show lpts bindings brief** command:

```
RP/0/RP0/CPU0:router# show lpts bindings brief
```

```
@ - Indirect binding; Sc - Scope
```

```

Location   Clnt Sc L3   L4   VRF-ID   Local,Remote Address.Port   Interface
-----
0/1/CPU0   IPV4 LO IPV4 ICMP *       any.ECHO any                       any
0/1/CPU0   IPV4 LO IPV4 ICMP *       any.TSTAMP any                    any
0/1/CPU0   IPV4 LO IPV4 ICMP *       any.MASKREQ any                   any
0/1/CPU0   IPV6 LO IPV6 ICMP6 *      any.ECHOREQ any                   any
0/3/CPU0   IPV4 LO IPV4 ICMP *       any.ECHO any                       any
0/3/CPU0   IPV4 LO IPV4 ICMP *       any.TSTAMP any                    any

```

This table describes the significant fields shown in the display.

**Table 36: show lpts bindings brief Command Field Descriptions**

Field	Description
Location	Node location, in the format of <i>rack/slot/module</i> .
Clnt ID	LPTS client type.
Sc	Scope (LR = Logical-Router, LO = Local).
Layer 3	Layer 3 protocol.
Layer 4	Layer 4 protocol.
VRF-ID	VPN routing and forwarding (VRF) identification (vrfid) number.
Local,Remote Address.Port	Local (destination) and Remote (source) addresses and ports or packet types.
Interface	Inbound interface.

# show lpts clients

To display the client information for the Port Arbitrator, use the **show lpts clients** command in XR EXEC mode.

```
show lpts clients [times]
```

<b>Syntax Description</b>	times (Optional) Displays information about binding request rates and service times.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The <b>show lpts clients</b> command displays the clients connected to the local packet transport services (LPTS) port arbitrator (PA).
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	lpts	read

## Examples

The following sample output is from the **show lpts clients** command:

```
RP/0/RP0/CPU0:router# show lpts clients

o_flg - open flags ; clid - client id
clid      loc      flags  o_flg
RAW(3)    0/RP1/CPU0    0x1    0x2
TCP(1)    0/RP1/CPU0    0x1    0x2
IPV4_IO(5) 0/1/CPU0      0x3    0x2
IPV4_IO(5) 0/2/CPU0      0x3    0x2
IPV4_IO(5) 0/RP1/CPU0    0x3    0x2
MPA(7)    0/RP1/CPU0    0x3    0x0
```

This table describes the significant fields shown in the display.

**Table 37: show lpts clients Command Field Descriptions**

Field	Description
Clid	LPTS client ID.
Loc	Node location, in the format <i>rack/slot/module</i> .

Field	Description
Flags	Client flags. <b>Note</b> The client flags are used only for debugging purposes.
o_flags	Open flags. <b>Note</b> The open flags are used only for debugging purposes.

The following sample output is from the **show lpts clients times** command. The output shows samples for the last 30 seconds, 1 minute, 5 minutes, 10 minutes, and a total (if nonzero). The number of transactions, number of updates, and the minimum/average/maximum time in milliseconds to process each transaction is shown.

```
RP/0/RP0/CPU0:router# show lpts clients times
```

```
o_flg - open flags ; clid - client id
clid      loc      flags  o_flg
RAW(3)    0/RP1/CPU0    0x1    0x2
  30s:2 tx 2 upd 2/2/3ms/tx
  1m:2 tx 2 upd 2/2/3ms/tx
  5m:2 tx 2 upd 2/2/3ms/tx
 10m:2 tx 2 upd 2/2/3ms/tx
 total:2 tx 2 upd 2/-/3ms/tx
TCP(1)    0/RP1/CPU0    0x1    0x2
 total:3 tx 3 upd 1/-/1ms/tx
IPV4_IO(5) 0/1/CPU0      0x3    0x2
 total:1 tx 1 upd 0/-/0ms/tx
IPV4_IO(5) 0/2/CPU0      0x3    0x2
 total:1 tx 1 upd 1/-/1ms/tx
IPV4_IO(5) 0/RP1/CPU0    0x3    0x2
 total:1 tx 1 upd 3/-/3ms/tx
MPA(7)    0/RP1/CPU0    0x3    0x0
```

# show lpts flows

To display information about Local Packet Transport Services (LPTS) flows, use the **show lpts flows** command in XR EXEC mode.

```
show lpts flows [brief]
```

<b>Syntax Description</b>	<b>brief</b> (Optional) Displays summary output.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The <b>show lpts flows</b> command is used to display LPTS flows, which are aggregations of identical binding requests from multiple clients and are used to program the LPTS Internal Forwarding Information Base (IFIB) and Pre-IFIB.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	lpts	read

## Examples

The following sample output is from the **show lpts flows** command:

```
RP/0/RP0/CPU0:router# show lpts flows
```

```
-----
L3-proto      : IPV4 (2)
L4-proto      : ICMP (1)
VRF-ID        : * (000000000)
Local-IP      : any
Remote-IP     : any
Pkt-Type      : 8
Remote-Port   : any
Interface     : any (0x0)
Flow-type     : ICMP-local
Min-TTL       : 0
Slice         : RAWIP4_FM
Flags         : 0x20 (in Pre-IFIB)
Location      : (drop)
Element References
location / count / scope
* / 3 / LOCAL
```

This table describes the significant fields shown in the display.

**Table 38: show lpts flows Command Field Descriptions**

Field	Description
L3-PROTO	Layer 3 protocol (IPv4, IPv6, CLNL).
L4-PROTO	Layer 4 protocol (TCP, UDP, and so on).
VRF-ID	VPN routing and forwarding (VRF) identification (vrfid) number.
Local-IP	Local (destination) IP address.
Remote-IP	Remote (source) IP address.
Pkt-Type	ICMP or IGMP packet type.
Remote-Port	Remote (source) TCP or UDP port.
Interface	Ingress interface.
Flow-type	Flow classification for hardware packet policing.
Min-TTL	Minimum time-to-live value expected from in the incoming packet. Any packet received with a lower TTL value will be dropped.
Slice	IFIB slice.
Flags	<ul style="list-style-type: none"> <li>• Has FGID: Delivered to multiple destinations.</li> <li>• No IFIB entry: IFIB entry suppressed.</li> <li>• Retrying FGID allocation.</li> <li>• In Pre-IFIB: Entry is in Pre-IFIB as well.</li> <li>• Deliver to one: If multiple bindings, will deliver to only one.</li> </ul>
Location	<i>rack/slot/module</i> to deliver to.
Element References	<ul style="list-style-type: none"> <li>• location: <i>rack/slot/module</i> of client.</li> <li>• count: number of clients at that location.</li> <li>• scope: binding scope (LR:Logical Router, LOCAL:Local).</li> </ul>

The following sample output is from the **show lpts flows brief** command:

```
RP/0/RP0/CPU0:router# show lpts flows brief

+ - Additional delivery destination; L - Local interest; P - In Pre-IFIB

L3   L4   VRF-ID   Local, Remote Address.Port   Interface   Location   LPT
-----
IPV4 ICMP *       any.ECHO any                         any         (drop)    LP
IPV4 ICMP *       any.TSTAMP any                         any         (drop)    LP
IPV4 ICMP *       any.MASKREQ any                         any         (drop)    LP
IPV6 ICMP6 *      any.ECHOREQ any                         any         (drop)    LP
IPV4 any  default  224.0.0.2 any                         Gi0/1/0/1   0/5/CPU0  P
```



This table describes the significant fields shown in the display.

**Table 39: show lpts flows brief Command Field Descriptions**

Field	Description
L3	Layer 3 protocol (IPv4, IPv6, CLNL).
L4	Layer 4 protocol.
VRF-ID	VPN routing and forwarding (VRF) identification (vrfid) number.
Local, Remote Address.Port	Local (destination) and remote (source) IP addresses and TCP or UDP ports, or ICMP/IGMP packet types, or IPsec Security Parameters Indices.
Interface	Ingress interface.
Location	Delivery location: <ul style="list-style-type: none"> <li>• <i>rack/slot/module</i>—Individual location.</li> <li>• [0xNNNNN]—Multiple locations (platform-dependent value).</li> <li>• (drop)—Do not deliver to any application.</li> </ul>
LP	Local interest (to be processed by IPv4 or IPv6 stack directly) or entry is resident in Pre-IFIB.

## show lpts ifib

To display the entries in the Internal Forwarding Information Base (IFIB), use the **show lpts ifib** command in XR EXEC mode.

```
show lpts ifib [entry] [type {bgp4 | bgp6 | isis | mcast4 | mcast6 | ospf-mc4 | ospf-mc6 | ospf4 | ospf6
| raw4 | raw6 | tcp4 | tcp6 | udp4 | udp6} | all] [brief [statistics]] [slices] [times] [location node-id]
```

### Syntax Description

<b>entry</b>	(Optional) Displays the IFIB entries.
<b>type</b>	(Optional) Displays the following protocol types. <ul style="list-style-type: none"> <li>• <b>bgp4</b> —IPv4 Border Gateway Protocol (BGP) slice</li> <li>• <b>bgp6</b> —IPv6 BGP slice</li> <li>• <b>isis</b> —Intermediate System-to-Intermediate System (IS-IS) slice</li> <li>• <b>mcast4</b> —IPv4 multicast slice</li> <li>• <b>mcast6</b> —IPv6 multicast slice</li> <li>• <b>ospf-mc4</b> —IPv4 Open Shortest Path First (OSPF) multicast slice</li> <li>• <b>ospf-mc6</b> —IPv6 OSPF multicast slice</li> <li>• <b>ospf4</b> —IPv4 OSPF slice</li> <li>• <b>ospf6</b> —IPv6 OSPF slice</li> <li>• <b>raw4</b> —IPv4 raw IP</li> <li>• <b>raw6</b> —IPv6 raw IP</li> <li>• <b>tcp4</b> —IPv4 Transmission Control Protocol (TCP) slice</li> <li>• <b>tcp6</b> —IPv6 TCP slice</li> <li>• <b>udp4</b> —IPv4 UDP slice</li> <li>• <b>udp6</b> —IPv6 UDP slice</li> </ul>
<b>all</b>	Displays all IFIB types.
<b>brief</b>	(Optional) Displays the IFIB entries in brief format.
<b>statistics</b>	(Optional) Displays the IFIB table with statistics information.
<b>slices</b>	(Optional) Displays IFIB slices.
<b>times</b>	(Optional) Displays the IFIB update transaction times.
<b>location</b> <i>node-id</i>	(Optional) Specifies the location of the Flow Manager. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

### Command Default

No default behavior or values

### Command Modes

XR EXEC mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

**Usage Guidelines**

Use this command to display detailed information about the entries in an IFIB slice. This command is useful for debugging problems with delivering packets to applications.

When the **statistics** keyword is used, detailed statistics are displayed for packet count, number of entries in each slice, and a total entries count.

**Task ID**

Task ID	Task	Operations
	lpts	read

**Examples**

The following sample output is from the **show lpts ifib** command:

```
RP/0/RP0/CPU0:router# show lpts ifib

O - Opcode; A - Accept Counter; D - Drop Counter; F - Flow Type; L - Listener Tag;
I - Local Flag; Y - SYN; T - Min TTL; DV - Deliver; DP - Drop; RE - Reassemble; na - Not
Applicable
-----
VRF-ID          : default (0x60000000)
Port/Type       : any
Source Port     : any
Dest IP         : any
Source IP       : any
Layer 4         : 88 (88)
Interface       : any (0x0)
O/A/D/F/L/I/Y/T : DELIVER/0/0/IPv4_STACK/0/0/0
Deliver List    : 0/5/CPU0
-----
```

This table describes the significant fields shown in the display.

**Table 40: show lpts ifib entries Command Field Descriptions**

Field	Description
VRF-ID	VPN routing and forwarding (VRF) identification (vrfid) number.
Port/Type	Destination (local) TCP or UDP port number, or ICMP/IGMP packet type, or IPSec Security Parameters Index.t2222
Source Port	Source (remote) TCP or UDP port.
Dest IP	Destination (local) IP address.
Source IP	Source (remote) IP address.
Layer 4	Layer 4 protocol number (6 = TCP). <b>Note</b> Only the common Layer 4 protocol names are displayed.
Interface	Ingress interface name.

Field	Description
O/S/P/R/L/I/Y	<ul style="list-style-type: none"> <li>• O: Opcode (DELIVER, DROP, or REASSEMBLE)</li> <li>• S: Stats counter</li> <li>• P: Packet forwarding priority (LO, MED, or HIGH)</li> <li>• R: Rate limit (LO, MED, or HIGH)</li> <li>• L: Listener tag (IPv4_STACK, IPv6_STACK, or CLNL_STACK)</li> <li>• I: Local-interest flag (0 or 1)</li> <li>• Y: TCP SYN flag (0 or 1)</li> </ul>
Deliver List	<ul style="list-style-type: none"> <li>• (drop)—Drop packet</li> <li>• rack/slot/module—Deliver to single destination</li> <li>• [0xNNNN]—Deliver to multiple destinations (platform-dependent format)</li> </ul>

The following sample output is from the **show lpts ifib brief** command:

```
RP/0/RP0/CPU0:router# show lpts ifib brief

Slice      Local, Remote Address.Port          L4   Interface   Dlvr
-----
TCP4       any.7 any                            TCP  any         0/RP1/CPU0
TCP4       any.9 any                            TCP  any         0/RP1/CPU0
```

The following sample output is from the **show lpts ifib brief statistics** command:

```
RP/0/RP0/CPU0:router# show lpts ifib brief statistics

Slice      Local, Remote Address.Port          L4   Interface   Accept/Drop
-----
TCP4       any.7 any                            TCP  any         0/0
TCP4       any.9 any                            TCP  any         0/0
TCP4       any.19 any                           TCP  any         0/0

Slice      Num. Entries Accepts/Drops
-----
TCP4       3          0/0
Total     3          0/0
```

## show lpts ifib slices

To display Internal Forwarding Information Base (IFIB) slice information, use the **show lpts ifib slices** command in XR EXEC mode.

```
show lpts ifib slices [type {bgp4 | bgp6 | isis | mcast4 | mcast6 | ospf-mc4 | ospf-mc6 | ospf4 | ospf6 |
raw4 | raw6 | tcp4 | tcp6 | udp4 | udp6}] [all] [statistics] [times]
```

Syntax Description	
<b>type</b>	(Optional) Enter protocol types. <ul style="list-style-type: none"> <li>• <b>bgp4</b> —IPv4 Border Gateway Protocol (BGP) slice</li> <li>• <b>bgp6</b> —IPv6 BGP slice</li> <li>• <b>isis</b> —Intermediate System-to-Intermediate System (IS-IS) slice</li> <li>• <b>mcast4</b> —IPv4 multicast slice</li> <li>• <b>mcast6</b> —IPv6 multicast slice</li> <li>• <b>ospf-mc4</b> —IPv4 Open Shortest Path First (OSPF) multicast slice</li> <li>• <b>ospf-mc6</b> —IPv6 OSPF multicast slice</li> <li>• <b>ospf4</b> —IPv4 OSPF slice</li> <li>• <b>ospf6</b> —IPv6 OSPF slice</li> <li>• <b>raw4</b> —IPv4 raw IP</li> <li>• <b>raw6</b> —IPv6 raw IP</li> <li>• <b>tcp4</b> —IPv4 Transmission Control Protocol (TCP) slice</li> <li>• <b>tcp6</b> —IPv6 TCP slice</li> <li>• <b>udp4</b> —IPv4 UDP slice</li> <li>• <b>udp6</b> —IPv6 UDP slice</li> </ul>
<b>all</b>	(Optional) Displays all entries.
<b>statistics</b>	(Optional) Displays the statistics for slice lookups.
<b>times</b>	(Optional) Displays the IFIB update transaction times.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show lpts ifib slices** command when troubleshooting IFIB entries and slice assignments. This command is especially useful when troubleshooting problems with delivering packets to applications.

## show lpts ifib slices

Task ID	Task ID	Operations
	lpts	read

## Examples

The following sample output is from the **show lpts ifib slices** command:

```
RP/0/RP0/CPU0:router# show lpts ifib slices
```

Slice	L3	L4	Port	Location
RAWIP4	IPV4	any	any	0/RP0/CPU0
RAWIP6	IPV6	any	any	0/RP0/CPU0
OSPF4	IPV4	OSPF	any	0/RP0/CPU0
OSPF6	IPV6	OSPF	any	0/RP0/CPU0
OSPF_MC4	IPV4	any	any	0/RP0/CPU0
OSPF_MC6	IPV6	any	any	0/RP0/CPU0
BGP4	IPV4	TCP	179	0/RP0/CPU0
BGP6	IPV6	TCP	179	0/RP0/CPU0
UDP4	IPV4	UDP	any	0/RP0/CPU0
UDP6	IPV6	UDP	any	0/RP0/CPU0
TCP4	IPV4	TCP	any	0/RP0/CPU0
TCP6	IPV6	TCP	any	0/RP0/CPU0
ISIS	CLNS	-	any	0/RP0/CPU0
MCAST4	IPV4	any	any	0/RP0/CPU0
MCAST6	IPV6	any	any	0/RP0/CPU0

The following sample output is from the **show lpts ifib slices times** command:

```
RP/0/RP0/CPU0:router# show lpts ifib slices times
```

Slice	L3	L4	Port	Location
RAWIP4	IPV4	any	any	0/RP0/CPU0
RAWIP6	IPV6	any	any	0/RP0/CPU0
OSPF4	IPV4	OSPF	any	0/RP0/CPU0
OSPF6	IPV6	OSPF	any	0/RP0/CPU0
OSPF_MC4	IPV4	any	any	0/RP0/CPU0
OSPF_MC6	IPV6	any	any	0/RP0/CPU0
BGP4	IPV4	TCP	179	0/RP0/CPU0
BGP6	IPV6	TCP	179	0/RP0/CPU0
UDP4	IPV4	UDP	any	0/RP0/CPU0
UDP6	IPV6	UDP	any	0/RP0/CPU0
TCP4	IPV4	TCP	any	0/RP0/CPU0
TCP6	IPV6	TCP	any	0/RP0/CPU0
ISIS	CLNS	-	any	0/RP0/CPU0
MCAST4	IPV4	any	any	0/RP0/CPU0
MCAST6	IPV6	any	any	0/RP0/CPU0

```
Flow Manager 0/RP0/CPU0:
total:5 tx 13 upd 1/-/lms/tx
```

The following sample output is from the **show lpts ifib slices statistics** command:

```
RP/0/RP0/CPU0:router# show lpts ifib slices all statistics
```

Slice	L3	L4	Port	Location	Lookups	RmtDlvr	Rejects	RLDrops	NoEntry
-------	----	----	------	----------	---------	---------	---------	---------	---------

```

-----
RAWIP4  IPV4  any   any   0/0/CPU0  5      0      0      0      0
RAWIP6  IPV6  any   any   0/0/CPU0  0      0      0      0      0
OSPF4   IPV4  OSPF  any   0/0/CPU0  0      0      0      0      0
OSPF6   IPV6  OSPF  any   0/0/CPU0  0      0      0      0      0
OSPF_MC4 IPV4  any   any   0/0/CPU0  0      0      0      0      0
OSPF_MC6 IPV6  any   any   0/0/CPU0  0      0      0      0      0
BGP4    IPV4  TCP   179   0/0/CPU0  0      0      0      0      0
BGP6    IPV6  TCP   179   0/0/CPU0  0      0      0      0      0

UDP4    IPV4  UDP   any   0/0/CPU0  3704   0      979    0      0
UDP6    IPV6  UDP   any   0/0/CPU0  0      0      0      0      0
TCP4    IPV4  TCP   any   0/0/CPU0  0      0      0      0      0
TCP6    IPV6  TCP   any   0/0/CPU0  0      0      0      0      0
ISIS    CLNS  -     any   0/0/CPU0  0      0      0      0      0
MCAST4  IPV4  any   any   0/0/CPU0  0      0      0      0      0
MCAST6  IPV6  any   any   0/0/CPU0  0      0      0      0      0
Flow Manager 0/0/CPU0:
Packets in: 3792
Packets delivered locally without lookups: 83
Slice lookups: 3709
Rejects: 979

```

This table describes the significant fields shown in the display.

**Table 41: show lpts ifib slices statistics Command Field Descriptions**

Field	Description
Slice	Slice number.
L3-proto	Layer 3 protocol (IPv4, IPv6, CLNL).
L4-proto	Layer 4 protocol (TCP, UDP, and others).
Port	Local (destination) TCP or UDP port.
Location	Node location, in the format <i>rack/slot/module</i> .

## show lpts ifib statistics

To display Internal Forwarding Information Base (IFIB) statistics, use the **show lpts ifib statistics** command in .

```
show lpts ifib statistics [location node-id]
```

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) Displays IFIB statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	---

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

### Command Modes

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task	Operations
	lpts	read

### Examples

The following sample output is from the **show lpts ifib statistics** command:

```
RP/0/# show lpts ifib statistics

Flow Manager 0/RP0/CPU0:
  Packets in:254
  Packets delivered locally without lookups:0
  Slice lookups:254
    Post-lookup error drops:
      Failed ipv4_netio_input:1
    Rejects:254
  Packets delivered locally:0
  Packets delivered remotely:0
```

This table describes the significant fields shown in the display.

**Table 42: show lpts ifib statistics Command Field Descriptions**

Field	Description
Packets in	Packets presented to the LPTS decaps node in netio.
Packets delivered locally without lookups	Packets previously resolved on a LC delivered directly to L3.
Slice lookups	Packets requiring slice lookups.



Field	Description
Post-lookup error drops	Packets dropped after a slice lookup.
Rejects	Packets that caused a TCP RST or ICMP Port/Protocol Unreachable.
Packets delivered locally	Packets delivered to local applications after slice lookups.
Packets delivered remotely	Packets delivered to applications on remote RPs.



---

**Note** The sample output is an example only and displays only those fields showing a value. No display exists for nonzero values. This command may show other values depending on your router configuration.

---

# show lpts ifib times

To display Internal Forwarding Information Base (IFIB) update transaction times, use the **show lpts ifib times** command in XR EXEC mode.

**show lpts ifib times** [**location** *node-id*]

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) Displays IFIB update transaction times for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	---

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	lpts	read

**Examples** The following sample output is from the **show lpts ifib times** command:

```
RP/0/RP0/CPU0:router# show lpts ifib times

Slice    L3    L4    Port  Location
-----  -
RAWIP4   IPV4  any   any   0/RP1/CPU0
RAWIP6   IPV6  any   any   0/RP1/CPU0
OSPF4    IPV4  OSPF  any   0/RP1/CPU0
OSPF6    IPV6  OSPF  any   0/RP1/CPU0
OSPF_MC4 IPV4  any   any   0/RP1/CPU0
OSPF_MC6 IPV6  any   any   0/RP1/CPU0
BGP4     IPV4  TCP   179   0/RP1/CPU0
BGP6     IPV6  TCP   179   0/RP1/CPU0
UDP4     IPV4  UDP   any   0/RP1/CPU0
UDP6     IPV6  UDP   any   0/RP1/CPU0
TCP4     IPV4  TCP   any   0/RP1/CPU0
TCP6     IPV6  TCP   any   0/RP1/CPU0
ISIS     CLNS  -     any   0/RP1/CPU0
MCAST4   IPV4  any   any   0/RP1/CPU0
MCAST6   IPV6  any   any   0/RP1/CPU0
Flow Manager 0/RP0/CPU0:
total:5 tx 13 upd 1/-/lms/tx
```

This table describes the significant fields shown in the display.

**Table 43: show lpts ifib times Command Field Descriptions**

<b>Field</b>	<b>Description</b>
Slice	Slice number.
L3 Protocol	Layer 3 protocol (IPv4, IPV6, CLNL).
L4 Protocol	Layer 4 protocol (TCP, UDP, and so on).
Port	Local (destination) TCP or UDP port.
Location	Node location, in the format <i>rack/slot/module</i> .

# show lpts pifib

To display Pre-Internal Forwarding Information Base (Pre-IFIB) entries, use the **show lpts pifib** command in XR EXEC mode.

```
show lpts pifib [entry] [hardware {entry | police} [brief] [location node-id]
```

Syntax Description	entry	(Optional) Pre-IFIB entry.
	<b>hardware</b>	(Optional) Displays hardware for Pre-IFIB.
	<b>entry</b>	(Optional) Displays the entries for Pre-IFIB.
	<b>police</b>	(Optional) Displays the policer values that are being use.
	<b>brief</b>	(Optional) Pre-IFIB entries in brief format.
	<b>location</b> <i>node-id</i>	(Optional) The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation (for example, 0/7/CPU0).

**Command Default** By default, all entries are displayed.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show lpts pifib** command with the **brief** keyword to perform the following functions:

- Display entries of all or part of a Pre-IFIB.
- Display a short description of each entry in the LPTS Pre-IFIB, optionally displaying packet counts for each entry.



**Note** These statistics are used only for packets that are processed by a line card, route processor, or distributed route processor.

Pre-IFIB statistics for packets processed by line card hardware are counted separately.

By default, all the defaults including the statistics for **hardware** are displayed.

Task ID	Task ID	Operations
	lpts	read

## Examples

The following is sample output for the **show lpts pifib** command:

```
RP/0/RP0/CPU0:router# show lpts pifib entry brief location 0/3/CPU0

* - Any VRF; I - Local Interest;
X - Drop; R - Reassemble;

Type          VRF-ID  L4      Interface  Deliver  Local-Address,Port Remote-Address,Port
-----
ISIS          *       -       any        0/RP0/CPU0  - -
IPv4_frag    *       any     any        R          any any
IPv4_echo    *       ICMP   any        I          any,ECHO any
IPv4         *       ICMP   any        0/RP0/CPU0  any,ECHOREPLY any
IPv4         *       ICMP   any        I          any,TSTAMP any
IPv4         *       ICMP   any        I          any,MASKREQ any
IPv4         *       TCP    any        0/RP0/CPU0  any any,179
IPv4         *       TCP    any        0/RP0/CPU0  any,179 any
IPv4         *       TCP    any        0/RP0/CPU0  any any
IPv4         *       UDP    any        0/RP0/CPU0  any,1701 any
IPv4         *       UDP    any        0/RP0/CPU0  any any
IPv4         *       OSPF   any        0/RP0/CPU0  192.0.0.5 any
IPv4         *       OSPF   any        0/RP0/CPU0  192.0.0.6 any
IPv4         *       OSPF   any        0/RP0/CPU0  any any
IPv4         *       any    any        0/RP0/CPU0  any any
IPv6_frag    *       any    any        R          any any
IPv6_echo    *       ICMP6  any        I          any,ECHOREQ any
```

The following is sample output for the **show lpts pifib type** command using the **ipv4** and **tcp** keywords.

```
RP/0/RP0/CPU0:router# show lpts pifib type ipv4 tcp

O - Opcode; F - Flow Type; L - Listener Tag; I - Local Flag; T - Min TTL;
na - Not Applicable

-----
L3 Protocol      : IPV4
L4 Protocol      : TCP
VRF-ID           : default (0x60000000)
Destination IP   : any
Source IP        : any
Port/Type        : Port:23
Source Port      : any
Is Fragment      : 0
Is SYN           : 0
Interface        : any (0x0)
O/F/L/I/T       : DELIVER/TELNET-default/IPv4_LISTENER/0/0
Deliver List     : 0/RP0

/CPU0
Accepts/Drops    : 0/0
Is Stale         : 0
-----
```

The following is sample output from the **show lpts pifib** command with the **entry** and **brief** keywords added command:

```
RP/0/RP0/CPU0:router# show lpts pifib entry brief
```

## show lpts pifib

\* - Critical Flow; I - Local Interest;  
X - Drop; R - Reassemble;

Type	VRF-ID	Local, Remote Address.Port	L4	Interface	Deliver
ISIS	*	- -	-	any	0/0/CPU0
IPv4_frag	*	any any	any	any	R
IPv4_IXMP	*	any.ECHO any	ICMP	any	XI
IPv4_IXMP	*	any.TSTAMP any	ICMP	any	XI
IPv4_IXMP	*	any.MASKREQ any	ICMP	any	XI
IPv4_IXMP	*	any any	ICMP	any	0/0/CPU0
IPv4_IXMP	*	any any	IGMP	any	0/0/CPU0
IPv4_mcast	*	192.0.0.5 any	any	any	0/0/CPU0
IPv4_mcast	*	192.0.0.6 any	any	any	0/0/CPU0
IPv4_mcast	*	192.0.0.0/4 any	any	any	0/0/CPU0
IPv4_TCP	*	any.179 any	TCP	any	0/0/CPU0
IPv4_TCP	*	any any.179	TCP	any	0/0/CPU0
IPv4_TCP	*	any any	TCP	any	0/0/CPU0
IPv4_UDP	*	any any	UDP	any	0/0/CPU0
IPv4_IPsec	*	any any	ESP	any	0/0/CPU0
IPv4_IPsec	*	any any	AH	any	0/0/CPU0
IPv4_rawIP	*	any any	OSPF	any	0/0/CPU0
IPv4_rawIP	*	any any	any	any	0/0/CPU0
IPv6_frag	*	any any	any	any	R
IPv6_ICMP	*	any.na any	ICMP6	any	XI
IPv6_ICMP	*	any any	ICMP6	any	0/0/CPU0
IPv6_mcast	*	ff02::5 any	any	any	0/0/CPU0
IPv6_mcast	*	ff02::6 any	any	any	0/0/CPU0
IPv6_mcast	*	ff00::/8 any	any	any	0/0/CPU0
IPv6_TCP	*	any.179 any	TCP	any	0/0/CPU0
IPv6_TCP	*	any any.179	TCP	any	0/0/CPU0
IPv6_TCP	*	any any	TCP	any	0/0/CPU0
IPv6_UDP	*	any any	UDP	any	0/0/CPU0
IPv6_IPsec	*	any any	ESP	any	0/0/CPU0
IPv6_IPsec	*	any any	AH	any	0/0/CPU0
IPv6_rawIP	*	any any	OSPF	any	0/0/CPU0
IPv6_rawIP	*	any any	any	any	0/0/CPU0

The following sample output is from the **show lpts pifib** command with the **entry**, **brief**, and **entry brief statistics** keywords added:

RP/0/RP0/CPU0:router# **show lpts pifib entry brief statistics**

\* - Critical Flow; I - Local Interest;  
X - Drop; R - Reassemble;

Type	VRF-ID	Local, Remote Address.Port	L4	Interface	Accepts/Drops
ISIS	*	- -	-	any	0/0
IPv4_frag	*	any any	any	any	0/0
IPv4_IXMP	*	any.ECHO any	ICMP	any	0/0
IPv4_IXMP	*	any.TSTAMP any	ICMP	any	0/0
IPv4_IXMP	*	any.MASKREQ any	ICMP	any	0/0
IPv4_IXMP	*	any any	ICMP	any	5/0
IPv4_IXMP	*	any any	IGMP	any	0/0
IPv4_mcast	*	224.0.0.5 any	any	any	0/0
IPv4_mcast	*	224.0.0.6 any	any	any	0/0

```

IPv4_mcast *      224.0.0.0/4 any          any any          0/0
IPv4_TCP *        any.179 any          TCP any          0/0
IPv4_TCP *        any any.179          TCP any          0/0
IPv4_TCP *        any any              TCP any          0/0
IPv4_UDP *        any any              UDP any          4152/0
IPv4_IPsec *      any any              ESP any          0/0
IPv4_IPsec *      any any              AH  any          0/0
IPv4_rawIP *      any any              OSPF any          0/0

```

-----

statistics:

Type	Num. Entries	Accepts/Drops
-----	-----	-----
ISIS	1	0/0
IPv4_frag	1	0/0
IPv4_IXMP	5	5/0
IPv4_mcast	3	0/0
IPv4_TCP	3	0/0
IPv4_UDP	1	4175/0
IPv4_IPsec	2	0/0
IPv4_rawIP	2	0/0
IPv6_frag	1	0/0
IPv6_ICMP	2	0/0
IPv6_mcast	3	0/0
IPv6_TCP	3	0/0
IPv6_UDP	1	0/0
IPv6_IPsec	2	0/0
IPv6_rawIP	2	0/0
Total	32	

Packets into Pre-IFIB: 4263

Lookups: 4263

Packets delivered locally: 4263

Packets delivered remotely: 0

This table describes the significant fields shown in the display for the **show lpts pifib** command with the **brief** and **statistics** keywords .

**Table 44: show lpts pifib Command Field Descriptions**

Field	Description
Type	Hardware entry type.
VRF ID	VPN routing and forwarding (VRF) identification (vrfid) number.
Local, Remote Address. Port	Indicates local address (in the form of local port and type) and remote address (remote port).
L4	Layer 4 protocol of the entry.
Interface	Interface for this entry.
Accepts/Drops	Number of packets sent to DestAddr/Number of packets dropped due to policing.

Field	Description
Num. Entries	Number of pre-ifib entries of the listed type.
Packets into Pre-IFIB	Packets presented for pre-IFIB lookups.
Lookups	Packets looked up.
Packets delivered locally	Packets delivered to local applications or the local stack ( <i>n</i> duplicated) packets duplicated for delivery to applications and the local stack.
Packets delivered remotely	Packets delivered to applications or for lookup on other RPs.



## show lpts pifib hardware entry

To display entries in the Local Packet Transport Services (LPTS) pre-IFIB hardware table, use the **show lpts pifib hardware entry** command in XR EXEC mode.

```
show lpts pifib hardware entry [brief] [location {allnode_id}]
```

Syntax Description	Parameter	Description
	<b>brief</b>	(Optional) Displays summary hardware entry information.
	<b>location all</b>	(Optional) Specifies all locations.
	<b>location node-id</b>	(Optional) Displays pre-Internal Forwarding Information Base (IFIB) information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** Displays hardware entry information in brief.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	lpts	read

### Examples

The following sample output is from the **show lpts pifib hardware entry** command with the **location** keyword:

```
RP/0/RP0/CPU0:router# show lpts pifib hardware entry brief location 0/3/CPU0
```

```
* - Read on clear stats
```

```
-----
DestIP          L4Proto  port/Type      remotePort  npu  ListenerTag
Flowtype        DestNode  Accepted*  Dropped*
-----
0.0.0.0         0        any           0           0    0          IPv4_REASS
Fragment       Local LC   0           0           0
0.0.0.0         1        ICMP_Dflt    0           0    0          RAWIP4_FM
ICMP-default   Local LC   0           0           0
192.0.0.5      89       any           0           0    0          IPv4_STACK
OSPF-mc-default Deliver RP 72          0           0
192.0.0.6      89       any           0           0    0          IPv4_STACK
OSPF-mc-default Deliver RP 0           0           0
0.0.0.0        89       any           0           0    0          OSPF4_FM
-----
```

## show lpts pifib hardware entry

```

OSPF-uc-default      Deliver RP      30      0
0.0.0.0              6      Port:179      0      0      0      BGP4_FM
BGP-default          Local LC        0      0      0      BGP4_FM
0.0.0.0              6      Port:any      179      0      0      BGP4_FM
BGP-default          Local LC        25      0      0      TCP4_FM
0.0.0.0              6      Port:any      0      0      0      TCP4_FM
TCP-default          Local LC        0      0      0      UDP4_FM
0.0.0.0              17     Port:any      0      0      0      UDP4_FM
UDP-default          Local LC        67      0      0      RAWIP4_FM
0.0.0.0              46     any           0      0      0      RAWIP4_FM
RSVP-default         Local LC        0      0      0      RAWIP4_FM
0.0.0.0              0      any           0      0      0      RAWIP4_FM
Raw-default          Local LC        0      0      0      IPv6_REASS
::                  0      any           0      0      0      IPv6_REASS
Fragment            Local LC        0      0      0      RAWIP6_FM
::                  58     ICMP6_LL      0      0      0      RAWIP6_FM
ICMP-default         Local LC        10     0      0      RAWIP6_FM
::                  58     ICMP6_MD      0      0      0      RAWIP6_FM
ICMP-default         Local LC        3      0      0      RAWIP6_FM
::                  58     ICMP6_Dflt    0      0      0      RAWIP6_FM
ICMP-default         Local LC        4      0      0      IPv6_STACK
2001:DB8::1         89     any           0      0      0      IPv6_STACK
OSPF-mc-default      Deliver RP      76     0      0      IPv6_STACK
2001:DB8::2         89     any           0      0      0      IPv6_STACK
OSPF-mc-default      Deliver RP      0      0      0      OSPF6_FM
::                  89     any           0      0      0      OSPF6_FM
OSPF-uc-default      Deliver RP      44     0      0      BGP6_FM
::                  6      Port:179     0      0      0      BGP6_FM
BGP-default          Local LC        16     0      0      BGP6_FM
::                  6      Port:any     179     0      0      BGP6_FM
BGP-default          Local LC        16     0      0      TCP6_FM
::                  6      Port:any     0      0      0      TCP6_FM
TCP-default          Local LC        0      0      0      UDP6_FM
::                  17     Port:any     0      0      0      UDP6_FM
UDP-default          Local LC        0      0      0      RAWIP6_FM
::                  0      any           0      0      0      RAWIP6_FM
Raw-default          Local LC        0      0      0      CLNS_STACK
any                  0      ISIS_Dflt    0      0      0      CLNS_STACK
ISIS-default         Deliver RP      56     0      0      CLNS_STACK
any                  0      ISIS_Jumbo   0      0      0      CLNS_STACK
ISIS-default         Deliver RP      0      0      0

```

This table describes the significant fields shown in the display.

**Table 45: show lpts pifib hardware entry Command Field Descriptions**

Field	Description
DestIP	IP address of the destination node.
L4 Protocol	Layer 4 protocol of the entry.
Port/Type	Port or type for this entry.
remotePort	Remote port for this entry.
npu	Network Processor Unit.
ListenerTag	Name of the listener node.
Flowtype	Type of the LPTS flow.

Field	Description
DestNode	Destination node to which to send the packet.
Accepted/Dropped	Number of packets sent to DestAddr/Number of packets dropped due to policing.

## show lpts pifib hardware object-group entry

To display OGLPTS (Object-Group LPTS) entries that accommodate higher number of BGP sessions for BGP peering, use the **show lpts pifib hardware object-group entry** command in XR EXEC mode.

```
show lpts pifib hardware object-group entry [ brief ] [ location { all node_id } ]
```

Syntax Description	
<b>object-group entry</b>	Displays the OGLPTS entries for BGP sessions.
<b>brief</b>	(Optional) Displays summary of hardware entry information.
<b>location all</b>	(Optional) Specifies all locations.
<b>location node-id</b>	(Optional) Displays pre-Internal Forwarding Information Base (IFIB) information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** Displays hardware entry information in brief.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.3.1	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	lpts	read

**Examples** This sample output is from the **show lpts pifib hardware object-group entry brief location all** command that shows summary of all the OGLPTS entries in brief:

```
Router# show lpts pifib hardware object-group entry brief location all
Wed Jan  6 19:54:44.012 UTC

-----
Type  DestIP                DestOgid  SrcIP                SrcOgid  Interface  vrf
   L4  LPort/Type             RPort  npu  Flowtype                DestNode  PuntPrio  Accept
Drop
-----
-----
-----
IPv4  123.123.123.2          1025     123.123.123.1        1         any        1
     6  Port:179             42319  0    BGP-known              DlvR  RPO    CRITICAL    0
0
IPv4  123.123.123.2          1025     123.123.123.1        1         any        1
```

```

    6   Port:179   0   0   BGP-cfg-peer   DlvR RP0   MEDIUM   0
0
IPv4 any
    6   Port:any   179   0   BGP-default   DlvR RP0   LOW   0   0
0
IPv4 any
    6   Port:179   0   0   BGP-default   DlvR RP0   LOW   0   0
0
IPv6 123::2
    6   Port:179   39330   0   BGP-known   DlvR RP0   CRITICAL   0   1
0
IPv6 123::2
    6   Port:179   0   0   BGP-cfg-peer   DlvR RP0   MEDIUM   0   1
0
IPv6 any
    6   Port:any   179   0   BGP-default   DlvR RP0   LOW   0   0
0
IPv6 any
    6   Port:179   0   0   BGP-default   DlvR RP0   LOW   0   0
0

```

This table describes the significant fields shown in the display.

**Table 46: show lpts pifib hardware object-group entry brief location all Command Output Field Descriptions**

Field	Description
DestIP	IP address of the destination node.
DestOgid	ID of the object-group entry for the destination node.
SrcIP	IP address of the source node.
SrcOgId	ID of the object-group entry for the source node.
Interface	Interface of the BGP session
vrf	VRF ID
L4	Layer 4 protocol of the object-group entry.
LPort/Type	Port or type for this object-group entry.
RPort	Remote port for this object-group entry.
npu	Network Processor Unit.
Flowtype	Type of the LPTS flow.
ListenerTag	Name of the listener node.
DestNode	Destination node to which to send the packet.

Field	Description
PuntPrio	Punt priority of the LPTS packet. The values of PuntPrio can be Critical, High, Medium, or Low.
Accepted/Dropped	Number of packets sent to DestAddr/Number of packets dropped due to policing.

This sample output is from the **show lpts pifib hardware object-group entry location all** command that shows all the OGLPTS entries in details:

```
Router# show lpts pifib hardware object-group entry location all
Wed Jan 6 19:55:08.871 UTC
```

```
-----
L4 Protocol      : 6
L4 remote port   : 42319
npu id           : 0
Destination IP   : 123.123.123.2
Source IP        : 123.123.123.1
DestOgid         : 1025
SrcOgid          : 1
Port/Type        : Port:179
Is Fragment      : 0
vrf              : 1
Listener Tag     : IPv4_STACK
Flow Type        : BGP-known
DestNode         : Deliver RPO
Type             : Dlvr
Punt Queue Prio  : CRITICAL
Interface        : any
Accepted/Dropped : 0/0
```

```
-----
L4 Protocol      : 6
L4 remote port   : 0
npu id           : 0
Destination IP   : 123.123.123.2
Source IP        : 123.123.123.1
DestOgid         : 1025
SrcOgid          : 1
Port/Type        : Port:179
Is Fragment      : 0
vrf              : 1
Listener Tag     : IPv4_LISTENER
Flow Type        : BGP-cfg-peer
DestNode         : Deliver RPO
Type             : Dlvr
Punt Queue Prio  : MEDIUM
Interface        : any
Accepted/Dropped : 0/0
```

```
-----
L4 Protocol      : 6
L4 remote port   : 179
npu id           : 0
Destination IP   : any
Source IP        : any
```

```

DestOgid      : any
SrcOgid       : any
Port/Type     : Port:any
Is Fragment   : 0
vrf           : 0
Listener Tag  : BGP4_FM
Flow Type     : BGP-default
DestNode      : Deliver RP0
Type          : Dlvr
Punt Queue Prio : LOW
Interface     : any
Accepted/Dropped : 0/0

```

```

-----
L4 Protocol   : 6
L4 remote port : 0
npu id       : 0
Destination IP : any
Source IP    : any
DestOgid     : any
SrcOgid      : any
Port/Type    : Port:179
Is Fragment  : 0
vrf          : 0
Listener Tag  : BGP4_FM
Flow Type    : BGP-default
DestNode     : Deliver RP0
Type         : Dlvr
Punt Queue Prio : LOW
Interface    : any
Accepted/Dropped : 0/0

```

```

-----
L4 Protocol   : 6
L4 remote port : 39330
npu id       : 0
Destination IP : 123::2
Source IP    : 123::1
DestOgid     : 1025
SrcOgid      : 1
Port/Type    : Port:179
Is Fragment  : 0
vrf          : 1
Listener Tag  : IPv6_STACK
Flow Type    : BGP-known
DestNode     : Deliver RP0
Type         : Dlvr
Punt Queue Prio : CRITICAL
Interface    : any
Accepted/Dropped : 0/0

```

```

-----
L4 Protocol   : 6
L4 remote port : 0
npu id       : 0
Destination IP : 123::2
Source IP    : 123::1
DestOgid     : 1025
SrcOgid      : 1
Port/Type    : Port:179
Is Fragment  : 0
vrf          : 1
Listener Tag  : IPv6_LISTENER
Flow Type    : BGP-cfg-peer

```

## show lpts pifib hardware object-group entry

```

DestNode      : Deliver RP0
Type          : Dlvr
Punt Queue Prio : MEDIUM
Interface     : any
Accepted/Dropped : 0/0

```

```

-----
L4 Protocol   : 6
L4 remote port : 179
npu id       : 0
Destination IP : any
Source IP    : any
DestOgid    : any
SrcOgid     : any
Port/Type    : Port:any
Is Fragment  : 0
vrf         : 0
Listener Tag : BGP6_FM
Flow Type   : BGP-default
DestNode    : Deliver RP0
Type       : Dlvr
Punt Queue Prio : LOW
Interface  : any
Accepted/Dropped : 0/0

```

```

-----
L4 Protocol   : 6
L4 remote port : 0
npu id       : 0
Destination IP : any
Source IP    : any
DestOgid    : any
SrcOgid     : any
Port/Type    : Port:179
Is Fragment  : 0
vrf         : 0
Listener Tag : BGP6_FM
Flow Type   : BGP-default
DestNode    : Deliver RP0
Type       : Dlvr
Punt Queue Prio : LOW
Interface  : any
Accepted/Dropped : 0/0

```



## show lpts pifib hardware police

To display the policer configuration value set, use the **show lpts pifib hardware police** command in XR EXEC mode.

```
show lpts pifib hardware police [location {allnode-id}]
```

Syntax Description	location <i>node-id</i>	(Optional) Displays pre-Internal Forwarding Information Base (IFIB) information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	all	Specifies all locations.

**Command Default** If no policer is configured, the default value is the configured rate.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.



**Note** Cisco IOS XR Release 7.3.2 introduces support to monitor LPTS host path drops via `Cisco-IOS-XR-lpts-pre-ifib-oper` YANG data model.

Task ID	Task ID	Operations
	lpts	read

### Examples

This sample output is from the **show lpts pifib hardware police** command with the **location** keyword for 0/0/CPU0:

```
Router#show lpts pifib hardware police location 0/0/CPU0
```

```
-----
Node 0/0/CPU0:
-----
FlowType                Policer Type    Cur. Rate Burst    Accepted    Dropped    npu
-----
Fragment                2              np              542         1000        0           0           0
Fragment                2              np              542         1000        0           0           1
OSPF-mc-known           3              np              1627        1000        0           0           0
```

## show lpts pifib hardware police

OSPF-mc-known	3	np	1627	1000	0	0	1
OSPF-mc-default	4	np	1084	1000	0	0	0
OSPF-mc-default	4	np	1084	1000	0	0	1
OSPF-uc-known	5	np	542	1000	0	0	0
OSPF-uc-known	5	np	542	1000	0	0	1
OSPF-uc-default	6	np	542	1000	0	0	0
OSPF-uc-default	6	np	542	1000	0	0	1
BFD-default	10	np	8136	1000	0	0	0
BFD-default	10	np	8136	1000	0	0	1
BFD-MP-known	11	np	8136	1000	0	0	0
BFD-MP-known	11	np	8136	1000	0	0	1
BGP-known	16	np	9763	1000	0	0	0
BGP-known	16	np	9763	1000	0	0	1
BGP-cfg-peer	17	np	1084	1000	0	0	0
BGP-cfg-peer	17	np	1084	1000	0	0	1
BGP-default	18	np	542	1000	0	0	0
BGP-default	18	np	542	1000	0	0	1
PIM-mcast-default	19	np	542	1000	0	0	0
PIM-mcast-default	19	np	542	1000	0	0	1
PIM-mcast-known	20	np	1627	1000	0	0	0
PIM-mcast-known	20	np	1627	1000	0	0	1
PIM-ucast	21	np	542	1000	0	0	0
PIM-ucast	21	np	542	1000	0	0	1
IGMP	22	np	1627	1000	0	0	0
IGMP	22	np	1627	1000	0	0	1
ICMP-local	23	np	542	1000	0	0	0
ICMP-local	23	np	542	1000	0	0	1
ICMP-control	25	np	2169	1000	0	0	0
ICMP-control	25	np	2169	1000	0	0	1
LDP-TCP-known	28	np	2169	1000	0	0	0
LDP-TCP-known	28	np	2169	1000	0	0	1
LDP-TCP-cfg-peer	29	np	1084	1000	0	0	0

LDP-TCP-cfg-peer	29	np	1084	1000	0	0	1
LDP-TCP-default	30	np	542	1000	0	0	0
LDP-TCP-default	30	np	542	1000	0	0	1
LDP-UDP	31	np	542	1000	0	0	0
LDP-UDP	31	np	542	1000	0	0	1
All-routers	32	np	542	1000	0	0	0
All-routers	32	np	542	1000	0	0	1
RSVP-default	38	np	542	1000	0	0	0
RSVP-default	38	np	542	1000	0	0	1
RSVP-known	39	np	1627	1000	0	0	0
RSVP-known	39	np	1627	1000	0	0	1
SNMP	47	np	542	1000	0	0	0
SNMP	47	np	542	1000	0	0	1
SSH-known	48	np	542	1000	0	0	0
SSH-known	48	np	542	1000	0	0	1
SSH-default	49	np	542	1000	0	0	0
SSH-default	49	np	542	1000	0	0	1
HTTP-known	50	np	542	1000	0	0	0
HTTP-known	50	np	542	1000	0	0	1
SHTTP-known	52	np	542	1000	0	0	0
SHTTP-known	52	np	542	1000	0	0	1
TELNET-known	54	np	542	1000	0	0	0
TELNET-known	54	np	542	1000	0	0	1
TELNET-default	55	np	542	1000	0	0	0
TELNET-default	55	np	542	1000	0	0	1
UDP-known	60	np	24950	1000	0	0	0
UDP-known	60	np	24950	1000	0	0	1
UDP-default	63	np	542	1000	0	0	0
UDP-default	63	np	542	1000	0	0	1
TCP-default	67	np	542	1000	0	0	0
TCP-default	67	np	542	1000	0	0	1
Raw-default	71	np	542	1000	0	0	0

Raw-default	71	np	542	1000	0	0	1
GRE	77	np	542	1000	0	0	0
GRE	77	np	542	1000	0	0	1
VRRP	78	np	542	1000	0	0	0
VRRP	78	np	542	1000	0	0	1
DNS	83	np	542	1000	0	0	0
DNS	83	np	542	1000	0	0	1
NTP-known	87	np	542	1000	0	0	0
NTP-known	87	np	542	1000	0	0	1
DHCPv4	93	np	3796	1000	0	0	0
DHCPv4	93	np	3796	1000	0	0	1
DHCPv6	94	np	3796	1000	0	0	0
DHCPv6	94	np	3796	1000	0	0	1
TPA	96	np	1627	1000	0	0	0
TPA	96	np	1627	1000	0	0	1
PM-TWAMP	99	np	1627	1000	0	0	0
PM-TWAMP	99	np	1627	1000	0	0	1

This table describes the significant fields shown in the display.

**Table 47: show lpts pifib hardware police Command Field Descriptions**

Field	Description
FlowType	Type of flow that is binding between a tuple and a destination.
Policer	Policer Values in PPS.
Type	Type of LPTS entry.
Cur. Rate	Packet rate effective in hardware for the entry.
Burst	Acceptable burst size for the policer.
npu	Network Processor Unit.

# show lpts pifib statistics

To display Pre-Internal Forwarding Information Base (Pre-IFIB) statistics, use the **show lpts pifib statistics** command in XR EXEC mode.

```
show lpts pifib statistics [location node-id]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays Pre-IFIB statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	lpts	read

## Examples

The following sample output is from the **show lpts pifib statistics** command:

```
RP/0/RP0/CPU0:router# show lpts pifib statistics

Packets into Pre-IFIB:80
Lookups:80
Packets delivered locally:80
Packets delivered remotely:0
```

This table describes the significant fields shown in the display.

**Table 48: show lpts pifib statistics Command Field Descriptions**

Field	Description
Packets into Pre-IFIB	Packets presented for pre-IFIB lookups.
Lookups	Packets looked up.
Packets delivered locally	Packets delivered to local applications or the local stack ( <i>n</i> duplicated) packets duplicated for delivery to applications and the local stack.
Packets delivered remotely	Packets delivered to applications or for lookup on other RPs.

# show lpts port-arbitrator statistics

To display local packet transport services (LPTS) port arbitrator statistics, use the **show lpts port-arbitrator statistics** command in XR EXEC mode.

**show lpts port-arbitrator statistics**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	lpts	read

## Examples

The following sample output is from the **show lpts port-arbitrator statistics** command:

```
RP/0/RP0/CPU0:router# show lpts port-arbitrator statistics
```

```
LPTS Port Arbitrator statistics:
PA FGID-DB library statistics:
 0 FGIDs in use, 512 cached, 0 pending retries
 0 free allocation slots, 0 internal errors, 0 retry attempts
 1 FGID-DB notify callback, 0 FGID-DB errors returned
FGID-DB permit mask: 0x7 (alloc mark rack0)
PA API calls:
   1 init                1 realloc_done
   8 alloc                8 free
  16 join                16 leave
   8 detach
FGID-DB API calls:
   1 register            1 clear_old
   1 alloc                0 free
  16 join                16 leave
   0 mark                1 mark_done
```

# show lpts vrf

To display the Local Packet Transport Services (LPTS) VPN routing and forwarding (VRF) instance identification numbers and names, use the **show lpts vrf** command in XR EXEC mode.

**show lpts vrf**

**Syntax Description** This command has no keywords or arguments.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	<b>lpts</b>	read

## Examples

The following sample output is from the **show lpts vrf** command:

```
RP/0/RP0/CPU0:router# show lpts vrf
```

```
VRF-ID      VRF-NAME
0x00000000  *
0x60000000  default
```

This table describes the significant fields shown in the display.

**Table 49: show lpts vrf Command Field Descriptions**

Field	Description
VRF-ID	VPN routing and forwarding (VRF) identification (vrfid) number.
VRF-NAME	Name given to the VRF.

show lpts vrf





## Network Stack Commands

---

This chapter describes the Cisco IOS XR software to configure and monitor features related to IP Version 4 (IPv4) and IP Version 6 (IPv6).

For detailed information about network stack concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [clear ipv6 neighbors, on page 349](#)
- [clear ipv6 path-mtu, on page 351](#)
- [hw-module profile route scale ipv6-unicast connected-prefix high, on page 352](#)
- [hw-module local-station-mac, on page 353](#)
- [icmp ipv4 rate-limit unreachable, on page 354](#)
- [ipv4 address \(network\), on page 355](#)
- [ipv4 assembler max-packets, on page 357](#)
- [ipv4 assembler timeout, on page 358](#)
- [ipv4 conflict-policy, on page 359](#)
- [ipv4 directed-broadcast, on page 360](#)
- [ipv4 helper-address, on page 361](#)
- [ipv4 mask-reply, on page 363](#)
- [ipv4 mtu, on page 364](#)
- [ipv4 redirects, on page 366](#)
- [ipv4 source-route, on page 367](#)
- [ipv4 tcp-mss-adjust, on page 368](#)
- [ipv4 unnumbered \(point-to-point\), on page 370](#)
- [ipv4 unreachable disable, on page 372](#)
- [ipv4 virtual address, on page 373](#)
- [ipv6 address, on page 375](#)
- [ipv6 address link-local, on page 377](#)
- [ipv6 assembler, on page 379](#)
- [ipv6 conflict-policy, on page 380](#)
- [ipv6 enable , on page 381](#)
- [ipv6 hop-limit, on page 382](#)
- [ipv6 icmp error-interval, on page 383](#)
- [ipv6 mtu, on page 385](#)
- [ipv6 nd dad attempts , on page 387](#)
- [ipv6 nd managed-config-flag, on page 390](#)

- [ipv6 nd ns-interval](#), on page 392
- [ipv6 nd other-config-flag](#) , on page 394
- [ipv6 nd prefix](#), on page 396
- [ipv6 nd ra dns server](#), on page 398
- [ipv6 nd ra dns search list](#), on page 400
- [ipv6 nd ra-interval](#), on page 402
- [ipv6 nd ra-lifetime](#), on page 404
- [ipv6 nd ra specific route](#), on page 405
- [ipv6 nd reachable-time](#), on page 407
- [ipv6 nd redirects](#), on page 409
- [ipv6 nd router-preference](#), on page 410
- [ipv6 nd scavenge-timeout](#), on page 412
- [ipv6 nd suppress-ra](#), on page 413
- [ipv6 neighbor](#), on page 414
- [ipv6 path-mtu enable](#), on page 416
- [ipv6 path-mtu timeout](#), on page 417
- [ipv6 source-route](#), on page 418
- [ipv6 tcp-mss-adjust](#), on page 419
- [ipv6 unreachable disable](#), on page 420
- [ipv6 virtual address](#), on page 421
- [local pool](#), on page 423
- [show arm conflicts](#), on page 426
- [show arm registrations producers](#), on page 428
- [show arm database](#), on page 430
- [show arm router-ids](#), on page 433
- [show arm summary](#), on page 434
- [show arm vrf-summary](#), on page 436
- [show clns statistics](#), on page 437
- [show hw-module local-station-mac](#), on page 439
- [show ipv4 interface](#), on page 440
- [show ipv4 traffic](#), on page 443
- [show ipv6 interface](#) , on page 445
- [show ipv6 neighbors](#), on page 450
- [show ipv6 neighbors summary](#) , on page 454
- [show ipv6 path-mtu](#), on page 455
- [show ipv6 traffic](#), on page 456
- [show linux networking interfaces address-only](#), on page 459
- [show local pool](#), on page 460
- [show mpa client](#), on page 462
- [show mpa groups](#), on page 463
- [show mpa ipv4](#), on page 465
- [show mpa ipv6](#), on page 467
- [show hw-module profile route-scale](#), on page 469

# clear ipv6 neighbors

To delete all entries in the IPv6 neighbor discovery cache, except static entries, use the **clear ipv6 neighbors** command in XR EXEC mode.

```
clear ipv6 neighbors [location node-id]
```

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) The designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR EXEC mode						
<b>Command History</b>	<p><b>Release</b></p> <p>Release 7.0.12 This command was introduced.</p>						
<b>Usage Guidelines</b>	If the location option is specified, only the neighbor entries specified in the <b>location</b> <i>node-id</i> keyword and argument are cleared.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>network</td> <td>read, write</td> </tr> <tr> <td>IPv6</td> <td>execute</td> </tr> </tbody> </table>	Task ID	Operations	network	read, write	IPv6	execute
Task ID	Operations						
network	read, write						
IPv6	execute						

## Examples

In the following example, only the highlighted entry is deleted:

```
RP/0/RP0/CPU0:router# clear ipv6 neighbors ?
location specify a node name

RP/0/RP0/CPU0:router# show ipv6 neighbor

IPv6 Address Age Link-layer Addr State Interface
8888::3 - 1234.2345.9877 REACH HundredGigE0/0/0/0
8888::8 - 1234.2345.9877 REACH HundredGigE0/0/0/0
fe80::205:1ff:fe9f:6400 1335 0005.019f.6400 STALE HundredGigE0/0/0/0
fe80::206:d6ff:fece:3808 1482 0006.d6ce.3808 STALE HundredGigE0/0/0/0
fe80::200:11ff:fe11:1112 1533 0000.1111.1112 STALE HundredGigE0/0/0/2

RP/0/RP0/CPU0:router# clear ipv6 neighbors location 0/2/0
RP/0/RP0/CPU0:router# show ipv6 neighbor

IPv6 Address Age Link-layer Addr State Interface
8888::3 - 1234.2345.9877 REACH HundredGigE0/0/0/0
8888::8 - 1234.2345.9877 REACH HundredGigE0/0/0/0
fe80::205:1ff:fe9f:6400 1387 0005.019f.6400 STALE HundredGigE0/0/0/0
```

**clear ipv6 neighbors**

```
fe80::206:d6ff:fece:3808 1534 0006.d6ce.3808 STALE HundredGigE0/0/0/0
```

## clear ipv6 path-mtu

To clear the learnt path maximum transmission unit (MTU) values of IPv6 packets, use the **clear ipv6 path-mtu** command in the XR EXEC mode.

```
clear ipv6 path-mtu [vrf {vrf-name | all}] [location node-id ] ] [ address { ipv6-address } [ location node-id ] ]
```

### Syntax Description

**location node-id** (Optional) The designated node. The node-id argument is entered in the *rack/slot/module* notation.

*ipv6-address* (Optional) Specific IPv6 address.

### Command Default

None.

### Command Modes

XR EXEC mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

If the location option is specified, only the entries of the node specified in the **location node-id** keyword and argument are cleared. Path MTU discovery for IPv6 packets is supported only for applications using TCP and Ping protocol.

### Task ID

Task ID	Operations
ipv6	read, write
network	read, write
config-services	read, write

### Examples

This example shows how to clear learnt values of path MTU values of IPv6 packets:

```
Router# clear ipv6 path-mtu vrf all location all
```

# hw-module profile route scale ipv6-unicast connected-prefix high

To enable the IPv6 prefix scale expansion for inserting /126 and /127 IPv6 prefixes in the CEM memory instead of the LPM memory, and increase the scalability of these prefixes, use the **hw-module profile route scale ipv6-unicast connected-prefix high** command in System Admin Config mode.

Use the **no** form of the command to disable the feature.

**hw-module profile route scale ipv6-unicast connected-prefix high**

**Syntax Description** This command has no keywords or arguments.

**Command Default** This command is disabled by default.

**Command Modes** System Admin Config mode

Command History	Release	Modification
	Release 7.5.3	This command was introduced.

**Usage Guidelines** The chassis must be reloaded for the **hw-module** command to be functional.

Task ID	Task ID	Operations
	ipv6	read, write

```
Router# configure
Router(config)# hw-module profile route scale ipv6-unicast connected-prefix high
Tue Aug 23 18:26:42.473 UTC
In order to activate/deactivate this Route Scale IPv6-ucast connected-prefix profile, you
must manually reload the chassis/all line cards
Router(config)# commit
Tue Aug 23 18:26:57.018 UTC
Router(config)# end
```

After configuring, you must reload the router for the feature to take effect.

## hw-module local-station-mac

To configure the local station MAC address for the router, use the **hw-module local-station-mac** command in the configuration mode.

**hw-module local-station-mac** *mac-address*

<b>Syntax Description</b>	<i>mac-address</i> Specify the 12-digit local station MAC address for router.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.9.1	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	network	read, write
	config-services	read, write

### Examples

This example configures the local station MAC address for the router:

```
Router# config
Router(config)# hw-module local-station-mac B03F.C98C.B948
Router(config)# commit
```

## icmp ipv4 rate-limit unreachable

To limit the rate that IPv4 Internet Control Message Protocol (ICMP) destination unreachable messages are generated, use the **icmp ipv4 rate-limit unreachable** command in XR Config mode. To remove the rate limit, use the **no** form of this command.

```
icmp ipv4 rate-limit unreachable [DF] milliseconds
no icmp ipv4 rate-limit unreachable [DF] milliseconds
```

<b>Syntax Description</b>	<b>DF</b>	(Optional) Limits the rate at which ICMP destination unreachable messages are sent when code 4 fragmentation is needed and data fragmentation is (DF) set, as specified in the IP header of the ICMP destination unreachable message.
	<i>milliseconds</i>	Time period (in milliseconds) between the sending of ICMP destination unreachable messages. Range is 1 to 4294967295.

**Command Default** The default value is one ICMP destination unreachable message every 500 milliseconds.

**Command Modes** XR Config mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The Cisco IOS XR software maintains two timers: one for general destination unreachable messages and one for DF destination unreachable messages. Both share the same time limits and defaults. If the **DF** option is not configured, the **icmp ipv4 rate-limit unreachable** command sets the time values for DF destination unreachable messages. If the **DF** option is configured, its time values remain independent from those of general destination unreachable messages.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv4	read, write
	network	read, write

### Examples

The following example shows how to set the time interval for the ICMP destination unreachable message to be generated at a minimum interval of 10 ms:

```
RP/0/RP0/CPU0:router(config)# icmp ipv4 rate-limit unreachable 10
```



## ipv4 address (network)

To set a primary or secondary IPv4 address for an interface, use the **ipv4 address** command in interface configuration mode. To remove an IPv4 address, use the **no** form of this command.

```
ipv4 address ipv4-address mask [secondary] [route-tag route-tag value]  
no ipv4 address ipv4-address mask [secondary] [route-tag route-tag value]
```

### Syntax Description

<b>ipv4-address</b>	IPv4 address.
<i>mask</i>	Mask for the associated IP subnet. The network mask can be specified in either of two ways: <ul style="list-style-type: none"> <li>The network mask can be a four-part dotted decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit belongs to the network address.</li> <li>The network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are ones, and the corresponding bits of the address are network address.</li> </ul>
<b>secondary</b>	(Optional) Specifies that the configured address is a secondary IPv4 address. If this keyword is omitted, the configured address is the primary IPv4 address.
<b>route-tag</b>	(Optional) Specifies that the configured address has a route tag to be associated with it.
<i>route-tag value</i>	(Optional) Value of the route tag. Range is 1 to 4294967295.

### Command Default

No IPv4 address is defined for the interface.

### Command Modes

Interface configuration

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

An interface can have one primary IPv4 address and multiple secondary IPv4 addresses. Packets generated by the software always use the primary IPv4 address. Therefore, all networking devices on a segment should share the same primary network number.



**Note** The same IPv4 address configured on two different interfaces causes an error message to display that indicates the conflict. The interface located in the highest rack, slot, module, instance, and port is disabled.

Hosts can determine subnet masks using the IPv4 Internet Control Message Protocol (ICMP) mask request message. Networking devices respond to this request with an ICMP mask reply message.

You can disable IPv4 processing on a particular interface by removing its IPv4 address with the **no ipv4 address** command. If the software detects another host using one of its IPv4 addresses, it will display an error message on the console.

The optional **secondary** keyword allows you to specify an unlimited number of secondary addresses. Secondary addresses are treated like primary addresses, except that the system never generates datagrams other than routing updates with secondary source addresses. IPv4 broadcasts and Address Resolution Protocol (ARP) requests are handled properly, as are interface routes in the IP routing table.

Secondary IPv4 addresses can be used in a variety of situations. The following are the most common applications:

- There may not be enough host addresses for a particular network segment. For example, your subnetting allows up to 254 hosts per logical subnet, but on one physical subnet you need to have 300 host addresses. Using secondary IPv4 addresses on the networking devices allows you to have two logical subnets using one physical subnet.
- Many older networks were built using Level 2 bridges. The judicious use of secondary addresses can aid in the transition to a subnetted, router-based network. Routers on an older, bridged segment can be easily made aware that there are many subnets on that segment.

The route-tag feature attaches a tag to all IPv4 addresses. The tag is propagated from the Management Agents (MA) to the Address Repository Managers (RPM) to routing protocols, thus enabling the user to control the redistribution of connected routes by looking at the route tags via RPL scripts.

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write

## Examples

The following example shows how to set 192.168.1.27 as the primary address and 192.168.7.17 and 192.168.8.17 as the secondary addresses on hundredGigE interface 0/0/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/0/0/1
RP/0/RP0/CPU0:router(config-if)# ipv4 address 192.168.1.27 255.255.255.0
RP/0/RP0/CPU0:router(config-if)# ipv4 address 192.168.7.17 255.255.255.0 secondary
RP/0/RP0/CPU0:router(config-if)# ipv4 address 192.168.8.17 255.255.255.0 secondary
```

## ipv4 assembler max-packets

To configure the maximum number of packets that are allowed in assembly queues, use the **ipv4 assembler max-packets** command in XR Config mode. To disable this feature, use the **no** form of this command.

**ipv4 assembler max-packets** *percentage value*  
**no ipv4 assembler max-packets** *percentage value*

<b>Syntax Description</b>	<i>percentage value</i> Percentage of total packets available in the system. The range is from 1 to 50.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR Config mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv4</td> <td>read, write</td> </tr> <tr> <td>network</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv4	read, write	network	read, write
Task ID	Operations						
ipv4	read, write						
network	read, write						

### Examples

The following example shows how to configure the maximum number of packets for the assembly queue:

```
Router(config)# ipv4 assembler max-packets 35
```

# ipv4 assembler timeout

To configure the number of seconds an assembly queue can hold before a timeout occurs, use the **ipv4 assembler timeout** command in XR Config mode. To disable this feature, use the **no** form of this command.

**ipv4 assembler timeout** *seconds*  
**no ipv4 assembler timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Number of seconds an assembly queue can hold before a timeout occurs. The range is from 1 to 120.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR Config mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv4</td> <td>read, write</td> </tr> <tr> <td>network</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv4	read, write	network	read, write
Task ID	Operations						
ipv4	read, write						
network	read, write						
<b>Examples</b>	<p>The following example shows how to configure an assembly queue before a timeout occurs:</p> <pre>RP/0/RP0/CPU0:router(config)# <b>ipv4 assembler timeout 88</b></pre>						

# ipv4 conflict-policy

To enable IP Address Repository Manager (IPARM) conflict resolution, use the **ipv4 conflict-policy** command in XR Config mode. To disable the IPARM conflict resolution, use the **no** form of the command.

```
ipv4 conflict-policy {highest-ip | longest-prefix | static}
no ipv4 conflict-policy {highest-ip | longest-prefix | static}
```

<b>Syntax Description</b>	<table border="1"> <tr> <td><b>highest-ip</b></td> <td>Keeps the highest ip address in the conflict set.</td> </tr> <tr> <td><b>longest-prefix</b></td> <td>Keeps the longest prefix match in the conflict set.</td> </tr> <tr> <td><b>static</b></td> <td>Keeps the existing interface running across new address configurations.</td> </tr> </table>	<b>highest-ip</b>	Keeps the highest ip address in the conflict set.	<b>longest-prefix</b>	Keeps the longest prefix match in the conflict set.	<b>static</b>	Keeps the existing interface running across new address configurations.
<b>highest-ip</b>	Keeps the highest ip address in the conflict set.						
<b>longest-prefix</b>	Keeps the longest prefix match in the conflict set.						
<b>static</b>	Keeps the existing interface running across new address configurations.						
<b>Command Default</b>	The precedence rule adopted is loopback > physical > other virtual interfaces. Within virtual interfaces, there is an alphabetical preference, for example, loopback1 > loopback2 > tunnel. Among physical interfaces, the lower rack or slot takes control.						
<b>Command Modes</b>	XR Config mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	Use <b>ipv4 conflict-policy</b> command to set an IPARM policy that resolves a conflict in the configured addresses. The policy tells IPARM what address to select from the addresses in conflict. The policy then forces the address in conflict to become inactive.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv4</td> <td>read, write</td> </tr> <tr> <td>ip-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv4	read, write	ip-services	read, write
Task ID	Operations						
ipv4	read, write						
ip-services	read, write						
<b>Examples</b>	<p>The following example shows how to enable the static policy for conflict resolution:</p> <pre>RP/0/RP0/CPU0:router(config)# ipv4 conflict-policy static</pre>						

# ipv4 directed-broadcast

To enable forwarding of IPv4 directed broadcasts on an interface, use the **ipv4 directed-broadcast** command in interface configuration mode. To disable forwarding of IPv4 directed broadcast on an interface, use the **no** form of this command.

**ipv4 directed-broadcast**  
**no ipv4 directed-broadcast**

**Syntax Description** This command has no keywords or arguments.

**Command Default** By default, directed broadcasts are dropped.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** A directed broadcast is a packet sent to a specific network. IPv4 directed broadcasts are dropped and not forwarded. Dropping IPv4 directed broadcasts makes routers less susceptible to denial-of-service (DoS) attacks.

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write

**Examples** The following example shows how to enable the forwarding of IPv4 directed broadcasts on interface 0/1/1/0:

```
RP/0/RP0/CPU0:router(config)# interface 0/1/1/0
RP/0/RP0/CPU0:router(config-if)# ipv4 directed-broadcast
```

## ipv4 helper-address

To configure the address to which the software forwards User Datagram Protocol (UDP) broadcasts, including BOOTP, received on an interface, use the **ipv4 helper-address** command in interface configuration mode. To remove an IPv4 helper address, use the **no** form of this command.

```
{ipv4 helper-address [vrf vrf-name][destination-address]}
{no ipv4 helper-address [vrf vrf-name][destination-address]}
```

Syntax Description	Parameter	Description
	<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
	<i>vrf-name</i>	(Optional) Name of a VRF.
	<i>destination-address</i>	Destination broadcast or host address to be used when UDP broadcasts are forwarded. There can be more than one helper address per interface.

**Command Default** IPv4 helper addresses are disabled. Default VRF is assumed if the VRF is not specified.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use this command with the **forward-protocol udp** command in mode, which specifies by port number the broadcast packets that are forwarded. UDP is enabled by default for well-known ports. The **ipv4 helper-address** command specifies the destination to which the UDP packets are forwarded.

One common application that requires IPv4 helper addresses is Dynamic Host Configuration Protocol (DHCP), which is defined in RFC 1531. DHCP protocol information is carried inside of BOOTP packets. To enable BOOTP broadcast forwarding for a set of clients, configure an IPv4 helper address on the networking device interface physically closest to the client. The IPv4 helper address should specify the address of the DHCP server. If you have multiple servers, you can configure one IPv4 helper address for each server. Because BOOTP packets are forwarded by default, DHCP information can now be forwarded by the networking device. The DHCP server now receives broadcasts from the DHCP clients.

A DHCP relay profile must be configured to perform DHCP Relay. The **ip helper-address** command is used to forward broadcast UDP (non-DHCP) packets.

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write

---

**Examples**

The following example shows how to specify that all UDP broadcast packets received on HundredGigEinterface 0/1/0/0 are forwarded to 192.168.1.0:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/0  
RP/0/RP0/CPU0:router(config-if)# ipv4 helper-address 192.168.1.0
```



# ipv4 mask-reply

To enable the software to respond to IPv4 Internet Control Message Protocol (ICMP) mask requests by sending ICMP mask reply messages, use the **ipv4 mask-reply** command in interface configuration mode. To restore the default, use the **no** form of this command.

**ipv4 mask-reply**  
**no ipv4 mask-reply**

**Syntax Description** This command has no keywords or arguments.

**Command Default** IPv4 mask replies are not sent.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This command enables the software to respond to IPv4 ICMP mask requests by sending ICMP mask reply messages.

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write

## Examples

The following example enables the sending of ICMP mask reply messages on HundredGigEinterface 0/1/0/0:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/0
RP/0/RP0/CPU0:router(config-if)# ipv4 mask-reply
```

## ipv4 mtu

To set the maximum transmission unit (MTU) size of IPv4 packets sent on an interface, use the **ipv4 mtu** command in interface configuration mode. To restore the default MTU size, use the **no** form of this command.

**ipv4 mtu** *bytes*  
**no ipv4 mtu**

<b>Syntax Description</b>	<i>bytes</i> MTU in bytes. Range is 68 to 65535 bytes for IPv4 packets. The maximum MTU size that can be set on an interface depends on the interface medium.
---------------------------	---

<b>Command Default</b>	If no MTU size is configured for IPv4 packets sent on an interface, the interface derives the MTU from the Layer 2 MTU.
------------------------	---

<b>Command Modes</b>	Interface configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The router punts the packets that needs fragmentation; whereas the software path drops the subscriber traffic that needs fragmentation.
-------------------------	---

The maximum MTU size that can be set on an interface depends on the interface medium. If the Layer 2 MTU is smaller than the Layer 3 MTU, the Cisco IOS XR software uses the Layer 2 MTU value for the Layer 3 MTU. Conversely, if the Layer 3 MTU is smaller than the Layer 2 MTU, the software uses Layer 3 MTU value. In other words the Cisco IOS XR software uses the lower of the two values for the MTU.

All devices on a physical medium must have the same protocol MTU to operate.



<b>Note</b>	Changing the MTU value (with the <b>mtu</b> interface configuration command) can affect the IPv4 MTU value. If the current IPv4 MTU value is the same as the MTU value, and you change the MTU value, the IPv4 MTU value will be modified automatically to match the new MTU. However, the reverse is not true; changing the IPv4 MTU value has no effect on the value for the <b>mtu</b> command.
-------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv4	read, write
	network	read, write
	config-services	read, write

---

**Examples**

This example shows how to set the maximum IPv4 packet size for HundredGigE interface 0/0/0/1 to 1500 bytes:

```
RP/0/(config)# interface HundredGigE0/0/0/1  
RP/0/(config-if)# ipv4 mtu 1500
```

## ipv4 redirects

To enable the sending of IPv4 Internet Control Message Protocol (ICMP) redirect messages if the software is forced to resend a packet through the same interface on which it was received, use the **ipv4 redirects** command in interface configuration mode. To restore the default, use the **no** form of this command.

**ipv4 redirects**

**no ipv4 redirects**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	ICMP redirect messages are disabled by default on the interface.				
<b>Command Modes</b>	Interface configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	ICMP redirect messages are disabled by default on the interface.				

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write

### Examples

The following example shows how to disable the sending of ICMP IPv4 redirect messages on &HundredGigE interface 0/1/1/0:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/1/0
RP/0/RP0/CPU0:router(config-if)# ipv4 redirects
```

## ipv4 source-route

To allow the processing of any IPv4 datagrams containing a source-route header option, use the **ipv4 source-route** command in XR EXEC mode. To have the software discard any IP datagram that contains a source-route option, use the **no** form of this command.

**ipv4 source-route**  
**no ipv4 source-route**

---

### Syntax Description

This command has no keywords or arguments.

---

### Command Default

The software discards any IPv4 datagrams containing a source-route header option.

---

### Command Modes

XR EXEC mode

---

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

---

### Usage Guidelines

By default, any IPv4 datagram which contains a source-route header option is discarded.

---

### Task ID

Task ID	Operations
ipv4	read, write
network	read, write

---

### Examples

The following example shows how to allow the processing of any IPv4 datagrams containing a source-route header option:

```
RP/0/RP0/CPU0:router(config)# ipv4 source-route
```

## ipv4 tcp-mss-adjust

To enable the transit traffic of TCP flows to be a Maximum Segment Size (MSS) below the GRE tunnel interface or VLAN sub-interface MTU so that traffic fragmentation is prevented when a session is established for IPv4 packets, use the **ipv4 tcp-mss-adjust** command in the interface configuration submode. To disable the transit traffic of TCP flows to be a Maximum Segment Size (MSS) below the GRE tunnel interface or VLAN sub-interface MTU, use the **no** form of this command.

**ipv4 tcp-mss-adjust enable**  
**no ipv4 tcp-mss-adjust enable**

<b>Syntax Description</b>	<b>enable</b> Enables Maximum Segment Size (MSS) adjustment for tcp flows on the interface.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface Configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

### Usage Guidelines

Task ID	Task ID	Operation
	mpls-te	read, write
	ipv4	read, write
	network	read, write
	acl	read, write

### Example

This example shows how to enable the transit traffic of TCP flows for IPv4 packets using the **ipv4 tcp-mss-adjust** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface HundredGigE 0/0/0/4.20
RP/0/RP0/CPU0:router(config-if)# ipv4 tcp-mss-adjust enable
```

**Related Commands**

Command	Description
<a href="#">ipv6 tcp-mss-adjust, on page 419</a>	Enables the transit traffic of TCP flows to be a Maximum Segment Size (MSS) below the GRE tunnel interface or VLAN sub-interface MTU so that traffic fragmentation is prevented when a session is established for IPv6 packets.

## ipv4 unnumbered (point-to-point)

To enable IPv4 processing on a point-to-point interface without assigning an explicit IPv4 address to that interface, use the **ipv4 unnumbered** command in an interface configuration mode. To disable this feature, use the **no** form of this command.

**ipv4 unnumbered** *interface-type interface-instance*  
**no ipv4 unnumbered** *interface-type interface-instance*

### Syntax Description

*interface-type* Interface type. For more information, use the question mark (?) online help function.

*interface-instance* Either a physical interface instance or a virtual interface instance as follows:

- Physical interface instance. Naming notation is *rack/slot/module/port* and a slash between values is required as part of the notation.
  - *rack*: Chassis number of the rack.
  - *slot*: Physical slot number of the modular services card or line card.
  - *module*: Module number. A physical layer interface module (PLIM) is always 0.
  - *port*: Physical port number of the interface.

**Note** In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0 ) and the module is CPU0. Example: interface MgmtEth0/RSP0 /CPU0/0.

- Virtual interface instance. Number range varies depending on interface type.

For more information about the syntax for the router, use the question mark (?) online help function.

### Command Default

IPv4 processing on a point-to-point interface is disabled unless an IPv4 address is assigned explicitly to that interface.

### Command Modes

Interface configuration

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

For release Release 4.2.0 onward, to enter the dynamic template configuration mode, run the **dynamic-template** command in the XR Config mode.

Whenever the unnumbered interface generates a packet (for example, for a routing update), it uses the address of the specified interface as the source address of the IPv4 packet. It also uses the IPv4 address of the specified interface in determining which routing processes are sending updates over the unnumbered interface.

Restrictions include the following:



- You cannot use the **ping** EXEC command to determine whether the interface is up because the interface has no address. Simple Network Management Protocol (SNMP) can be used to remotely monitor interface status.

The interface you specify by the *interface-type* and *interface-number* arguments must be enabled (listed as “up” in the **show interfaces** command display).

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write
	config-services	read, write

### Examples

This example shows how the HundredGigE interface 0/0/0/1 is assigned the loopback interface address 5:

```
RP/0/RP0/CPU0:router(config)# interface loopback 5
RP/0/RP0/CPU0:router(config-if)# ipv4 address 192.168.6.6 255.255.255.0
RP/0/RP0/CPU0:router(config)# interface HundredGigE 0/0/0/1
RP/0/RP0/CPU0:router(config-if)# ipv4 unnumbered loopback 5
```

# ipv4 unreachable disable

To disable the generation of IPv4 Internet Control Message Protocol (ICMP) unreachable messages, use the **ipv4 unreachable disable** command in an interface configuration mode. To re-enable the generation of ICMP unreachable messages, use the **no** form of this command.

**ipv4 unreachable disable**  
**no ipv4 unreachable disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** IPv4 ICMP unreachable messages are generated.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If the software receives a nonbroadcast packet destined for itself that uses a protocol it does not recognize, it sends an ICMP protocol unreachable message to the source.

If the software receives a datagram that it cannot deliver to its ultimate destination because it knows of no route to the destination address, it replies to the originator of that datagram with an ICMP host unreachable message.

This command affects a number of ICMP unreachable messages.

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write
	config-services	read, write

## Examples

This example shows how to disable the generation of ICMP unreachable messages on HundredGigE interface 0/0/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/0/0/1
RP/0/RP0/CPU0:router(config-if)# ipv4 unreachable disable
```

# ipv4 virtual address

To define an IPv4 virtual address for a network of management Ethernet interfaces, use the **ipv4 virtual interface** command in XR Config mode. To remove an IPv4 virtual address from the configuration, use the **no** form of this command.

```
ipv4 virtual address {[vrf vrf-name] ipv4-address/mask | use-as-src-addr}
no ipv4 virtual address {[vrf vrf-name] ipv4-address/mask | use-as-src-addr}
```

Syntax Description	
<b>vrf vrf-name</b>	(Optional) Configures the virtual address on a per VPN routing and forwarding (VRF) basis for the management interfaces. The <i>vrf-name</i> argument specifies the name of the VRF.
<i>ipv4 address</i>	Virtual IPv4 address and the mask that is to be unconfigured.
<i>mask</i>	Mask for the associated IP subnet. The network mask can be specified in either of two ways: <ul style="list-style-type: none"> <li>• The network mask can be a four-part dotted-decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit belongs to the network address.</li> <li>• The network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are ones, and the corresponding bits of the address are network address. A slash between numbers is required as part of the notation.</li> </ul>
<b>use-as-src-addr</b>	Enables the virtual address to be used as the default SRC address on sourced packets.

**Command Default** No IPv4 virtual address is defined for the configuration.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.5.2	This release supports virtual addresses for the hosted Linux networking stack.
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Configuring an IPv4 virtual address enables you to access the router from a single virtual address with a management network. An IPv4 virtual address persists across route processor (RP) failover situations.

Configuring an IPv4 virtual address enables you to access a dual RP router from a single address without prior knowledge of which RP is active. An IPv4 virtual address persists across RP failovers. For this to happen, the virtual IPv4 address must share a common IPv4 subnet with a Management Ethernet interface on both RPs.

If you disable the **ipv4 virtual address** command with the **vrf** keyword, the virtual IP address is unconfigured for the corresponding VRF or for the default if no VRF is specified. This results in the removal of the entry for the virtual IP address in the VRF table and in the ARP cache.

The default VRF is chosen when no VRF is specified. The virtual IP address is activated on a management interface that is attached to a default VRF.

The **use-as-src-addr** keyword eliminates the need for configuring a loopback interface as the source interface (that is, update source) for management applications. When an update source is not configured, management applications allow the transport processes (TCP, UDP, raw\_ip) to pick a suitable source address. The transport processes, in turn, consult the FIB to do so. If a Management Ethernet's IP address is picked as the source address and if the **use-as-src-addr keyword** is configured, then the transport processes replace the Management Ethernet's IP address with a relevant virtual IP address. This functionality works across RP switchovers.

Cisco IOS XR Software Release 7.5.2 and later also supports virtual addresses for the hosted Linux networking stack.

Task ID	Task ID	Operations
	ipv4	read, write
	network	read, write

## Examples

The following example shows how to define an IPv4 virtual address:

```
Router(config)# ipv4 virtual address 10.3.32.154/8
```

The following example show how to configure the virtual IP addresses for management interfaces on a per VRF basis:

```
Router(config)# ipv4 virtual address vrf ppp 10.26.3.4/16
```

# ipv6 address

To configure an IPv6 address for an interface and enable IPv6 processing on the interface using an EUI-64 interface ID in the low-order 64 bits of the address, use the **ipv6 address** command in interface configuration mode. To remove the address from the interface, use the **no** form of this command.

```
ipv6 address ipv6-prefix/prefix-length [eui-64] [route-tag route-tag value]  
no ipv6 address ipv6-prefix/prefix-length [eui-64] [route-tag route-tag value]
```

Syntax Description	
<i>ipv6-prefix</i>	The IPv6 network assigned to the interface.  This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
<i>/ prefix-length</i>	The length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.
<b>eui-64</b>	(Optional) Specifies an interface ID in the low-order 64 bits of the IPv6 address.
<b>route-tag</b>	(Optional) Specifies that the configured address has a route tag to be associated with it.
<i>route-tag value</i>	(Optional) Value of the route tag. Range is 1 to 4294967295.

**Command Default** No IPv6 address is defined for the interface.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If the value specified for the */ prefix-length* argument is greater than 64 bits, the prefix bits have precedence over the interface ID.

Using the **no ipv6 address** command without arguments removes all manually configured IPv6 addresses from an interface.

If the Cisco IOS XR software detects another host using one of its IPv6 addresses, it displays an error message on the console.

The route-tag feature attaches a tag to all IPv6 addresses. The tag is propagated from the Management Agents (MA) to the Address Repository Managers (RPM) to routing protocols, thus enabling the user to control the redistribution of connected routes by looking at the route tags via RPL scripts.

Task ID	Task ID	Operations
	ipv6	read, write

---

**Task ID Operations**

---

network read,  
write

---

---

**Examples**

The following example assigns IPv6 address 2001:0DB8:0:1::/64 to HundredGigE interface 0/0/0/1 and specifies an EUI-64 interface ID in the low-order 64 bits of the address:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/0/0/1  
RP/0/RP0/CPU0:router(config-if)# ipv6 address 2001:0DB8:0:1::/64 eui-64
```

## ipv6 address link-local

To configure an IPv6 link-local address for an interface and enable IPv6 processing on the interface, use the **ipv6 address link-local** command in interface configuration mode. The *ipv6-address* value specified with this command overrides the link-local address that is automatically generated for the interface. To remove the address from the interface, use the **no** form of this command.

```
ipv6 address ipv6-address link-local [route-tag route-tag value]
no ipv6 address ipv6-address link-local [route-tag route-tag value]
```

### Syntax Description

<i>ipv6-address</i>	The IPv6 address assigned to the interface.  This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
<b>link-local</b>	Specifies a link-local address. The <i>ipv6-address</i> value specified with this command overrides the link-local address that is automatically generated for the interface.
<b>route-tag</b>	(Optional) Specifies that the configured address has a route-tag to be associated with it.
<i>route-tag value</i>	(Optional) Displays the route-tag value. Range is 1 to 4294967295.

### Command Default

No IPv6 address is defined for the interface.

### Command Modes

Interface configuration

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

If the Cisco IOS XR software detects another host using one of its IPv6 addresses, the software displays an error message on the console.

The system automatically generates a link-local address for an interface when IPv6 processing is enabled on the interface, typically when an IPv6 address is configured on the interface. To manually specify a link-local address to be used by an interface, use the **ipv6 address link-local** command.

A double colon may be used as part of the *ipv6-address* argument when consecutive 16-bit values are denoted as zero. You can configure multiple IPv6 addresses per interfaces, but only one link-local address.

### Task ID

Task ID	Operations
ipv6	read, write
network	read, write

---

**Examples**

The following example shows how to assign FE80::260:3EFF:FE11:6770 as the link-local address for HundredGigE interface 0/0/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/0/0/1  
RP/0/RP0/CPU0:router(config-if)# ipv6 address FE80::260:3EFF:FE11:6770 link-local
```



# ipv6 assembler

To configure the maximum number of packets that are allowed in assembly queues or to configure the number of seconds an assembly queue will hold before timeout, use the **ipv6 assembler** command in the appropriate configuration mode. To disable this feature, use the **no** form of this command.

```
ipv6 assembler {max-packets value | timeout seconds}
no ipv6 assembler {max-packets value | timeout seconds}
```

Syntax Description	
<b>max-packets</b>	Maximum packets allowed in assembly queues.
<b>timeout</b>	Number of seconds an assembly queue will hold before timeout.

**Command Default** None

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operation
	ipv6	read, write

## Example

The following example shows how to configure the maximum number of packets that are allowed in assembly queues:

```
Router# config
Router(config)# ipv6 assembler max-packets 35
```

## ipv6 conflict-policy

To enable IP Address Repository Manager (IPARM) conflict resolution, use the **ipv6 conflict-policy** command in XR Config mode. To disable the IPARM conflict resolution, use the **no** form of the command.

```
ipv6 conflict-policy {highest-ip | longest-prefix | static}
no ipv6 conflict-policy {highest-ip | longest-prefix | static}
```

### Syntax Description

<b>highest-ip</b>	Keeps the highest IP address in the conflict set.
<b>longest-prefix</b>	Keeps the longest prefix match in the conflict set.
<b>static</b>	Keeps the existing interface running across new address configurations.

### Command Default

Default is the lowest rack/slot if no conflict policy is configured.

### Command Modes

XR Config mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

No specific guidelines impact the use of this command.

### Task ID

Task ID	Operations
ipv6	read, write
ip-services	read, write

### Examples

The following example shows how to enable the longest prefix policy for conflict resolution:

```
RP/0/RP0/CPU0:router(config)# ipv6 conflict-policy longest-prefix
```

# ipv6 enable

To enable IPv6 processing on an interface that has not been configured with an explicit IPv6 address, use the **ipv6 enable** command in an appropriate configuration mode. To disable IPv6 processing on an interface that has not been configured with an explicit IPv6 address, use the **no** form of this command.

**ipv6 enable**  
**no ipv6 enable**

<b>Syntax Description</b>	None
<b>Command Default</b>	IPv6 is disabled.
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **ipv6 enable** command automatically configures an IPv6 link-local unicast address on the interface while also enabling the interface for IPv6 processing. The **no ipv6 enable** command does not disable IPv6 processing on an interface that is configured with an explicit IPv6 address.

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR EXEC mode.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read, write
	network	read, write
	config-services	read, write

## Examples

This example (not applicable for BNG) shows how to enable IPv6 processing on HundredGigE interface 0/0/0/1:

```
Router(config)# interface HundredGigE0/0/0/1
Router(config-if)# ipv6 enable
```

# ipv6 hop-limit

To configure the maximum number of hops used in router advertisements and all IPv6 packets that are originated by the router, use the **ipv6 hop-limit** command in XR Config mode. To return the hop limit to its default value, use the **no** form of this command.

```
ipv6 hop-limit hops
no ipv6 hop-limit hops
```

<b>Syntax Description</b>	<i>hops</i> Maximum number of hops. Range is 1 to 255.
---------------------------	--

<b>Command Default</b>	<i>hops</i> : 64 hops
------------------------	-----------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read, write
	network	read, write

## Examples

The following example shows how to configure a maximum number of 15 hops for router advertisements and all IPv6 packets that are originated from the router:

```
RP/0/RP0/CPU0:router (config) # ipv6 hop-limit 15
```

# ipv6 icmp error-interval

To configure the interval and bucket size for IPv6 Internet Control Message Protocol (ICMP) error messages on all nodes, use the **ipv6 icmp error-interval** command in XR Config mode mode. To return the interval to its default setting, use the **no** form of this command.

```
ipv6 icmp error-interval milliseconds [bucketsize]  
no ipv6 icmp error-interval
```

<b>Syntax Description</b>	<i>milliseconds</i>	Time interval (in milliseconds) between tokens being placed in the bucket. Range is 0 to 2147483647.
	<i>bucketsize</i>	(Optional) The maximum number of tokens stored in the bucket. The acceptable range is 1 to 200 with a default of 10 tokens.
<b>Command Default</b>	ICMP rate limiting is enabled by default. To disable ICMP rate limiting, set the interval to zero. <i>milliseconds</i> : 100 milliseconds <i>bucketsize</i> : 10 tokens	
<b>Command Modes</b>	XR Config mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	<p>Use the <b>ipv6 icmp error-interval</b> command in XR Config mode mode to limit the rate at which IPv6 ICMP error messages are sent for each node. A token bucket algorithm is used with one token representing one IPv6 ICMP error message. Tokens are placed in the virtual bucket at a specified interval until the maximum number of tokens allowed in the bucket is reached.</p> <p>The <i>milliseconds</i> argument specifies the time interval between tokens being placed in the bucket. The optional <i>bucketsize</i> argument is used to define the maximum number of tokens stored in the bucket. Tokens are removed from the bucket when IPv6 ICMP error messages are sent, which means that if the <i>bucketsize</i> argument is set to 20, a rapid succession of 20 IPv6 ICMP error messages can be sent. When the bucket is empty of tokens, IPv6 ICMP error messages are not sent until a new token is placed in the bucket.</p> <p>Use the <b>show ipv6 traffic EXEC</b> command to display IPv6 ICMP rate-limited counters.</p>	
<b>Task ID</b>	<b>Task ID Operations</b>	
	ipv6	read, write
	network	read, write

---

**Examples**

The following example shows an interval of 50 milliseconds and a bucket size of 20 tokens being configured for IPv6 ICMP error messages:

```
RP/0/RP0/CPU0:router(config)# ipv6 icmp error-interval 50 20
```

# ipv6 mtu

To set the maximum transmission unit (MTU) size of IPv6 packets sent on an interface, use the **ipv6 mtu** command in an appropriate configuration mode. To restore the default MTU size, use the **no** form of this command.

**ipv6 mtu** *bytes*  
**no ipv6 mtu**

<b>Syntax Description</b>	<i>bytes</i> MTU in bytes. Range is 1280 to 65535 for IPv6 packets. The maximum MTU size that can be set on an interface depends on the interface medium.				
<b>Command Default</b>	If no MTU size is configured for IPv6 packets sent on an interface, the interface derives the MTU from the Layer 2 MTU.				
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	<p>If an IPv6 packet exceeds the MTU set for the interface, only the source router of the packet can fragment it. The maximum MTU size that can be set on an interface depends on the interface medium. If the Layer 2 MTU is smaller than the Layer 3 MTU, the Cisco IOS XR software uses the Layer 2 MTU value for the Layer 3 MTU. Conversely, if the Layer 3 MTU is smaller than the Layer 2 MTU, the software uses Layer 3 MTU value. In other words the Cisco IOS XR software uses the lower of the two values for the MTU.</p> <p>All devices on a physical medium must have the same protocol MTU to operate.</p> <p>For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run <b>dynamic-template</b> command in the XR Config mode.</p>				



**Note** Changing the MTU value (with the **mtu** interface configuration command) can affect the IPv6 MTU value. If the current IPv6 MTU value is the same as the MTU value, and you change the MTU value, the IPv6 MTU value will be modified automatically to match the new MTU. However, the reverse is not true; changing the IPv6 MTU value has no effect on the value for the **mtu** command.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write

Task ID	Operations
config-services	read, write

### Examples

This example (not applicable for BNG) shows how to set the maximum IPv6 packet size for HundredGigE interface 0/0/0/1 to 1350 bytes:

```
Router(config)# interface HundredGigE0/0/0/1  
Rrouter(config-if)# ipv6 mtu 1350
```



## ipv6 nd dad attempts

To configure the number of consecutive neighbor solicitation messages that are sent on an interface while duplicate address detection is performed on the unicast IPv6 addresses of the interface, use the **ipv6 nd dad attempts** command in an appropriate configuration mode. To return the number of messages to the default value, use the **no** form of this command.

**ipv6 nd dad attempts** *value*  
**no ipv6 nd dad attempts** *value*

<b>Syntax Description</b>	<i>value</i> Number of neighbor solicitation messages. Range is 0 to 600. Configuring a value of 0 disables duplicate address detection processing on the specified interface; a value of 1 configures a single transmission without follow-up transmissions.				
<b>Command Default</b>	Duplicate address detection on unicast IPv6 addresses with the sending of one neighbor solicitation message is enabled. The default is one message.				
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 6.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 6.0	This command was introduced.
Release	Modification				
Release 6.0	This command was introduced.				
<b>Usage Guidelines</b>	<p>Duplicate address detection verifies the uniqueness of new unicast IPv6 addresses before the addresses are assigned to interfaces (the new addresses remain in a tentative state while duplicate address detection is performed). Duplicate address detection uses neighbor solicitation messages to verify the uniqueness of unicast IPv6 addresses.</p> <p>The DupAddrDetectTransmits node configuration variable (as specified in RFC 2462, <i>IPv6 Stateless Address Autoconfiguration</i>) is used to automatically determine the number of consecutive neighbor solicitation messages that are sent on an interface while duplicate address detection is performed on a tentative unicast IPv6 address.</p> <p>The interval between the sending of duplicate address detection neighbor solicitation messages (the duplicate address detection timeout interval) is specified by the neighbor discovery-related variable RetransTimer (as specified in RFC 2461, <i>Neighbor Discovery for IP Version 6 [IPv6]</i>), which is used to determine the time between retransmissions of neighbor solicitation messages to a neighbor when the address is being resolved or when the reachability of a neighbor is being probed. This is the same management variable used to specify the interval for neighbor solicitation messages during address resolution and neighbor unreachability detection. Use the <b>ipv6 nd ns-interval</b> command to configure the interval between neighbor solicitation messages that are sent during duplicate address detection.</p> <p>Duplicate address detection is suspended on interfaces that are administratively down. While an interface is administratively down, the unicast IPv6 addresses assigned to the interface are set to a pending state. Duplicate address detection is automatically restarted on an interface when the interface returns to being administratively up.</p> <p>For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run <b>dynamic-template</b> command in the .</p>				



**Note** An interface returning to administratively up restarts duplicate address detection for all of the unicast IPv6 addresses on the interface. While duplicate address detection is performed on the link-local address of an interface, the state for the other IPv6 addresses is still set to tentative. When duplicate address detection is completed on the link-local address, duplicate address detection is performed on the remaining IPv6 addresses.

When duplicate address detection identifies a duplicate address, the state of the address is set to duplicate and the address is not used. If the duplicate address is the link-local address of the interface, the processing of IPv6 packets is disabled on the interface and an error message similar to the following is issued:

```
ipv6_nd[145]: %IPV6_ND-3-ADDRESS_DUPLICATE : Duplicate address 111::1 has been detected
```

If the duplicate address is a global address of the interface, the address is not used and an error message similar to the following is issued:

```
%IPV6-4-DUPLICATE: Duplicate address 3000::4 on &HundredGigE;
```

All configuration commands associated with the duplicate address remain as configured while the state of the address is set to duplicate.

If the link-local address for an interface changes, duplicate address detection is performed on the new link-local address and all of the other IPv6 address associated with the interface are regenerated (duplicate address detection is performed only on the new link-local address).

Task ID	Task ID	Operations
	ipv6	read, write
	config-services	read, write

## Examples

This example (not applicable for BNG) shows how to set the number of consecutive neighbor solicitation messages for interface 0/2/0/1 to 1 and then display the state (tentative or duplicate) of the unicast IPv6 address configured for an interface:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/2/0/1
RP/0/RP0/CPU0:router(config-if)# ipv6 nd dad attempts 1
RP/0/RP0/CPU0:router(config-if)# Uncommitted changes found, commit them before
exiting(yes/no/cancel)? [cancel]:y
```

```
RP/0/RP0/CPU0:router# show ipv6 interface
HundredGigE/2/0/0 is Up, line protocol is Up
  IPv6 is disabled, link-local address unassigned
  No global unicast address is configured
HundredGigE/2/0/1 is Up, line protocol is Up
  IPv6 is enabled, link-local address is fe80::203:fdff:fe1b:4501
  Global unicast address(es):
    1:4::1, subnet is 1:4::/64 [DUPLICATE]
  MTU is 1514 (1500 is available to IPv6)
```

```
ICMP redirects are disabled
ND DAD is enabled, number of DAD attempts 1
ND reachable time is 0 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND router advertisements are sent every 200 seconds
ND router advertisements live for 1800 seconds
Hosts use stateless autoconfig for addresses.
HundredGigE/2/0/2 is Shutdown, line protocol is Down
IPv6 is enabled, link-local address is fe80::200:11ff:fe11:1111 [TENTATIVE]
Global unicast address(es):
  111::2, subnet is 111::/64 [TENTATIVE]
MTU is 1514 (1500 is available to IPv6)
ICMP redirects are enabled
ND DAD is enabled, number of DAD attempts 1
ND reachable time is 0 milliseconds
ND advertised retransmit interval is 0 milliseconds
ND router advertisements are sent every 200 seconds
ND router advertisements live for 1800 seconds
Hosts use stateless autoconfig for addresses.
```

For BNG, this example shows how to display the state (tentative or duplicate) of the unicast IPv6 address on the dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd dad attempts 1
```

## ipv6 nd managed-config-flag

To set the managed address configuration flag in IPv6 router advertisements, use the **ipv6 nd managed-config-flag** command in an appropriate configuration mode. To clear the flag from IPv6 router advertisements, use the **no** form of this command.

```
ipv6 nd managed-config-flag
no ipv6 nd managed-config-flag
```

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	The managed address configuration flag is not set in IPv6 router advertisements.				
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

**Usage Guidelines**

Setting the managed address configuration flag in IPv6 router advertisements indicates to attached hosts whether they should use stateful autoconfiguration to obtain addresses. If the flag is set, the attached hosts should use stateful autoconfiguration to obtain addresses. If the flag is not set, the attached hosts should not use stateful autoconfiguration to obtain addresses.

Hosts may use stateful and stateless address autoconfiguration simultaneously.

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR EXEC mode.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

### Examples

This example (not applicable for BNG) shows how to configure the managed address configuration flag in IPv6 router advertisements on HundredGigE interface 0/1/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/1
RP/0/RP0/CPU0:router(config-if)# ipv6 nd managed-config-flag
```

For BNG, this example shows how to configure the managed address configuration flag in IPv6 router advertisements on dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1  
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd managed-config-flag
```

## ipv6 nd ns-interval

To configure the interval between IPv6 neighbor solicitation retransmissions on an interface, use the **ipv6 nd ns-interval** command in an appropriate configuration mode. To restore the default interval, use the **no** form of this command.

**ipv6 nd ns-interval** *milliseconds*  
**no ipv6 nd ns-interval**

<b>Syntax Description</b>	<i>milliseconds</i> Interval (in milliseconds) between IPv6 neighbor solicit transmissions. Range is 1000 to 3600000.								
<b>Command Default</b>	0 milliseconds (unspecified) is advertised in router advertisements, and the value 1000 is used for the neighbor discovery activity of the router itself.								
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)								
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.				
Release	Modification								
Release 7.0.12	This command was introduced.								
<b>Usage Guidelines</b>	<p>This value is included in all IPv6 router advertisements sent out from this interface. Very short intervals are not recommended in normal IPv6 operation. When a nondefault value is configured, the configured time is both advertised and used by the router itself.</p> <p>For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run <b>dynamic-template</b> command in the XR Config mode.</p>								
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv6</td> <td>read, write</td> </tr> <tr> <td>network</td> <td>read, write</td> </tr> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv6	read, write	network	read, write	config-services	read, write
Task ID	Operations								
ipv6	read, write								
network	read, write								
config-services	read, write								

### Examples

This example (not applicable for BNG) configures an IPv6 neighbor solicit transmission interval of 9000 milliseconds for HundredGigE interface 0/1/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/1
RP/0/RP0/CPU0:router(config-if)# ipv6 nd ns-interval 9000
```

For BNG, this example configures an IPv6 neighbor solicit transmission interval of 9000 milliseconds in the dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1  
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd ns-interval 9000
```

## ipv6 nd other-config-flag

To set the other stateful configuration flag in IPv6 router advertisements, use the **ipv6 nd other-config-flag** command in an appropriate configuration mode. To clear the flag from IPv6 router advertisements, use the **no** form of this command.

**ipv6 nd other-config-flag**  
**no ipv6 nd other-config-flag**

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	The other stateful configuration flag is not set in IPv6 router advertisements.				
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

**Usage Guidelines** The setting of the other stateful configuration flag in IPv6 router advertisements indicates to attached hosts how they can obtain autoconfiguration information other than addresses. If the flag is set, the attached hosts should use stateful autoconfiguration to obtain the other (nonaddress) information.



**Note** If the managed address configuration flag is set using the **ipv6 nd managed-config-flag** command, then an attached host can use stateful autoconfiguration to obtain the other (nonaddress) information regardless of the setting of the other stateful configuration flag.

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR Config mode.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

### Examples

This example (not applicable for BNG) configures the “other stateful configuration” flag in IPv6 router advertisements on HundredGigE interface 0/1/0/1:



```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/1
RP/0/RP0/CPU0:router(config-if)# ipv6 nd other-config-flag
```

For BNG, this example configures the “other stateful configuration” flag for IPv6 router advertisements in the dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd other-config-flag
```

## ipv6 nd prefix

To configure how IPv6 prefixes are advertised in IPv6 router advertisements, use the **ipv6 nd prefix** command in interface configuration mode. To advertise a prefix with default parameter values, use the **no** form of this command. To prevent a prefix (or prefixes) from being advertised, use the **no-adv** keyword.

**ipv6 nd prefix** {*ipv6prefix/prefix-length* | **default** [*valid-lifetime* | **at** | **infinite** | **no-adv** | **no-autoconfig** | **off-link**]}

**no ipv6 nd prefix** {*ipv6prefix/prefix-length* | **default** [*valid-lifetime* | **at** | **infinite** | **no-adv** | **no-autoconfig** | **off-link**]}

Syntax Description	
<b>ipv6-prefix</b>	The IPv6 network number to include in router advertisements.  This keyword must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
<b>/prefix-length</b>	The length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash (/) must precede the decimal value.
<b>default</b>	(Optional) Specifies all prefixes.
<b>valid-lifetime</b>	(Optional) The amount of time (in seconds) that the specified IPv6 prefix is advertised as being valid. The range of values is 0 to 4294967295 seconds.
<b>at</b>	(Optional) The date and time at which the lifetime and preference expire. The prefix is valid until this specified date and time are reached. Dates are expressed in the form <i>date-valid-expire month-valid-expire hh:mm-valid-expire date-prefer-expire month-prefer-expire hh:mm-prefer-expire</i> .
<b>infinite</b>	(Optional) The valid lifetime does not expire.
<b>no-adv</b>	(Optional) The prefix is not advertised.
<b>no-autoconfig</b>	(Optional) Indicates to hosts on the local link that the specified prefix cannot be used for IPv6 autoconfiguration.
<b>off-link</b>	(Optional) Indicates that the specified prefix is assigned to the link. Nodes sending traffic to such addresses that contain the specified prefix consider the destination to be locally reachable on the link. This prefix should not be used for <i>onlink</i> determination.

**Command Default** All prefixes configured on interfaces that originate IPv6 router advertisements are advertised with a valid lifetime of 2592000 seconds (30 days) and a preferred lifetime of 604800 seconds (7 days), and with both the “onlink” and “autoconfig” flags set.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines**

This command allows control over the individual parameters per prefix, including whether or not the prefix should be advertised.

To control how prefixes are advertised, use the **ipv6 nd prefix** command. By default, prefixes configured as addresses on an interface using the **ipv6 address** command are advertised with default values. If you configure prefixes for advertisement using the **ipv6 nd prefix** command, only the specified prefixes are advertised with the configured values, all other prefixes are advertised with default values.

The default keyword can be used to set default parameters for all prefixes.

A date can be set to specify the expiration of a prefix. The valid and preferred lifetimes are counted down in real time. When the expiration date is reached, the prefix is no longer advertised.

When onlink is “on” (by default), the specified prefix is assigned to the link. Nodes sending traffic to such addresses that contain the specified prefix consider the destination to be locally reachable on the link.

When autoconfig is “on” (by default), it indicates to hosts on the local link that the specified prefix can be used for IPv6 autoconfiguration.

**Task ID****Task ID Operations**

ipv6	read, write
------	----------------

network	read, write
---------	----------------

**Examples**

The following example includes the IPv6 prefix 2001:0DB8::/35 in router advertisements sent out HundredGigE interface 0/1/0/0 with a valid lifetime of 1000 seconds and a preferred lifetime of 900 seconds:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/0
RP/0/RP0/CPU0:router(config-if)# ipv6 nd prefix 2001:0DB8::/35 1000 900
```

## ipv6 nd ra dns server

To configure the IPv6 router advertisement of DNS server addresses on an interface, use the **ipv6 nd ra dns server** command in interface configuration mode. To remove the IPv6 router advertisement of DNS server addresses, use the **no** form of this command.

```

ipv6 nd ra dns server ipv6-address {seconds | infinite-lifetime | zero-lifetime }
no ipv6 nd ra dns server ipv6-address
no ipv6 nd ra dns server

```

Syntax Description	server <i>ipv6-address</i>	Specify the DNS server address to be advertised in an IPv6 router advertisement (RA).
	<i>seconds</i>   <b>infinite-lifetime</b>   <b>zero-lifetime</b>	The amount of time that the DNS server is advertised in an IPv6 RA. The range for seconds is from 200 to 4294967295. The lifetime can also be specified as infinite or zero.

**Command Default** The DNS server is not advertised in an IPv6 RA.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This configuration is not allowed for management interfaces.

You can use the **ipv6 nd ra dns server** command to configure up to five DNS server addresses in an RA.

If you configure a seconds value of zero, the DNS server will no longer be used.

Use the **no ipv6 nd ra dns server** *ipv6-address* command to delete a single DNS server under an interface. Use the **no ipv6 nd ra dns server** command to delete all DNS servers under an interface.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

**Examples** The following example configures a DNS server with an IPv6 address of 2001:DB8:1::1 to be advertised in an RA with a lifetime of 600 seconds:

```
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/2/0/0
RP/0/RP0/CPU0:router(config-if)# ipv6 nd ra dns server 2001:DB8:1::1 600
```

The following example configures a DNS server with an IPv6 address of 4::4 to be advertised in an RA with an infinite lifetime:

```
RP/0/RP0/CPU0:router(config)# interface GigabitEthernet 0/2/0/0
RP/0/RP0/CPU0:router(config-if)# ipv6 nd ra dns server 4::4 infinite-lifetime
```

**Related Commands**

Command	Description
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Configures the lifetime of an IPv6 router advertisement.
<a href="#">show ipv6 interface , on page 445</a>	Displays the usability status of interfaces configured for IPv6.

## ipv6 nd ra dns search list

To configure the IPv6 router advertisement of DNS search list on an interface, use the **ipv6 nd ra dns search list** command in interface configuration mode. To remove the IPv6 router advertisement of DNS search list, use the **no** form of this command.

```

ipv6 nd ra dns search list name {seconds | infinite-lifetime | zero-lifetime }
no ipv6 nd ra dns search list name
no ipv6 nd ra dns search list

```

Syntax Description		
	<i>name</i>	Specify the DNS search list to be advertised in an IPv6 router advertisement (RA).
	<i>seconds</i>   <b>infinite-lifetime</b>   <b>zero-lifetime</b>	The amount of time that the DNS search list is advertised in an IPv6 RA. The range for seconds is from 200 to 4294967295. The lifetime can also be specified as infinite or zero.

**Command Default** The DNS search list is not advertised in an IPv6 RA.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This configuration is not allowed for management interfaces.

You can use the **ipv6 nd ra dns search list** command to configure up to 50 DNS search lists in an RA.

If you configure a seconds value of zero, the DNS server will no longer be used.

Use the **no ipv6 nd ra dns search list** *name* command to delete a single DNS search list under an interface.

Use the **no ipv6 nd ra dns search list** command to delete all DNS search lists under an interface.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

**Examples** The following example configures a DNS search list with a name of aaa.cc.com to be advertised in an RA with an infinite lifetime:

```
Router(config)# interface GigabitEthernet 0/2/0/0
Router(config-if)# ipv6 nd ra dns search list aaa.cc.com infinite-lifetime
```

**Related Commands**

Command	Description
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Configures the lifetime of an IPv6 router advertisement.
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Displays the usability status of interfaces configured for IPv6.

# ipv6 nd ra-interval

To configure the interval between IPv6 router advertisement transmissions on an interface, use the **ipv6 nd ra-interval** command in an appropriate configuration mode. To restore the default interval, use the **no** form of this command.

```
ipv6 nd ra-interval seconds
no ipv6 nd ra-interval seconds
```

<b>Syntax Description</b>	<i>seconds</i> The interval (in seconds) between IPv6 router advertisement transmissions.
---------------------------	---

<b>Command Default</b>	<i>seconds</i> : 200 seconds
------------------------	------------------------------

<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)
----------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The interval between transmissions should be less than or equal to the IPv6 router advertisement lifetime if the router is configured as a default router by using the <b>ipv6 nd ra-lifetime</b> command. To prevent synchronization with other IPv6 nodes, randomly adjust the actual value used to within 20 percent of the specified value.
-------------------------	---

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR Config mode.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read, write
	network	read, write
	config-services	read, write

## Examples

This example (not applicable for BNG) configures an IPv6 router advertisement interval of 201 seconds on HundredGigE interface 0/1/0/1:

```
Router(config)# interface HundredGigE0/1/0/1
Router(config-if)# ipv6 nd ra-interval 201
```

For BNG, this example configures an IPv6 router advertisement interval of 201 seconds in the dynamic template configuration mode:



```
Router(config)# dynamic-template type ppp p1  
Router(config-dynamic-template-type)# ipv6 nd ra-interval 201
```

## ipv6 nd ra-lifetime

To configure the router lifetime value in IPv6 router advertisements on an interface, use the **ipv6 nd ra-lifetime** command in an appropriate configuration mode. To restore the default lifetime, use the **no** form of this command.

**ipv6 nd ra-lifetime** *seconds*  
**no ipv6 nd ra-lifetime**

<b>Syntax Description</b>	<i>seconds</i> The validity (in seconds) of this router as a default router on this interface.
---------------------------	--

<b>Command Default</b>	<i>seconds</i> : 1800 seconds
------------------------	-------------------------------

<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)
----------------------	--

<b>Usage Guidelines</b>	The router lifetime value is included in all IPv6 router advertisements sent out the interface. The value indicates the usefulness of the router as a default router on this interface. Setting the value to 0 indicates that the router should not be considered a default router on this interface. The router lifetime value can be set to a nonzero value to indicate that it should be considered a default router on this interface. The nonzero value for the router lifetime value should not be less than the router advertisement interval.
-------------------------	---

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR Config mode.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

### Examples

This example (not applicable for BNG) configures an IPv6 router advertisement lifetime of 1801 seconds on HundredGigE interface 0/1/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/1
RP/0/RP0/CPU0:router(config-if)# ipv6 nd ra-lifetime 1801
```

For BNG, this example configures an IPv6 router advertisement lifetime of 1801 seconds in the dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd ra-lifetime 1801
```

## ipv6 nd ra specific route

To configure specific route for a router on a specific interface, use the **ipv6 nd ra specific route** command in interface configuration mode. To delete a single or all specific routes, use the **no** form of this command.

```

ipv6 nd ra specific route prefix Lifetime {seconds | infinite-lifetime | zero-lifetime } [preference { high
| medium | low }]
no ipv6 nd ra specific route prefix
no ipv6 nd ra specific route

```

Syntax Description	route <i>prefix</i>	Variable-length field containing an IP address or a prefix of an IP address to identify a route.
	<b>Lifetime</b> { <i>seconds</i>   <b>infinite-lifetime</b>   <b>zero-lifetime</b> }	The length of time the route prefix is valid for route determination specified as seconds, infinite, or zero.
	[ <b>preference</b> { <b>high</b>   <b>medium</b>   <b>low</b> } ]	(Optional) Preference for the router specified on an interface specified as high, medium, or low.

**Command Default** Router advertisements (RAs) are sent with the medium preference.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This configuration is not allowed for management interfaces.

If the Lifetime is set to zero, then the host will no longer use the router for route aspect of the route information option.

If no preference is specified, then the default value for preference (medium) is used.

Use the **no ipv6 nd ra specific route** *prefix* command to delete a single specific route under an interface. Use the **no ipv6 nd ra specific route** command to delete all specific routes under an interface.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

**Examples** The following example configures a specific route for the router on gigabit Ethernet interface 0/2/0/0:

```
Router(config)# interface GigabitEthernet 0/2/0/0
Router(config-if)# ipv6 nd ra specific route 3::3/116 Lifetime 1112 preference low
```

**Related Commands**

Command	Description
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Configures the lifetime of an IPv6 router advertisement.
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Displays the usability status of interfaces configured for IPv6.

# ipv6 nd reachable-time

To configure the amount of time that a remote IPv6 node is considered reachable after some reachability confirmation event has occurred, use the **ipv6 nd reachable-time** command in an appropriate configuration mode. To restore the default time, use the **no** form of this command.

**ipv6 nd reachable-time** *milliseconds*  
**no ipv6 nd reachable-time**

<b>Syntax Description</b>	<i>milliseconds</i> The amount of time (in milliseconds) that a remote IPv6 node is considered reachable. The range is from 0 to 3600000.								
<b>Command Default</b>	0 milliseconds (unspecified) is advertised in router advertisements and 30000 (30 seconds) is used for the neighbor discovery activity of the router itself.								
<b>Command Modes</b>	Interface configuration (not applicable for BNG) Dynamic template configuration (for BNG)								
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.				
Release	Modification								
Release 7.0.12	This command was introduced.								
<b>Usage Guidelines</b>	<p>The configured time enables the router to detect unavailable neighbors. Shorter configured times enable the router to detect unavailable neighbors more quickly; however, shorter times consume more IPv6 network bandwidth and processing resources in all IPv6 network devices. Very short configured times are not recommended in normal IPv6 operation.</p> <p>The configured time is included in all router advertisements sent out of an interface so that nodes on the same link use the same time value. A value of 0 indicates that the configured time is unspecified by this router.</p> <p>For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run <b>dynamic-template</b> command in the XR Config mode.</p>								
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv6</td> <td>read, write</td> </tr> <tr> <td>network</td> <td>read, write</td> </tr> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv6	read, write	network	read, write	config-services	read, write
Task ID	Operations								
ipv6	read, write								
network	read, write								
config-services	read, write								

## Examples

This example (not applicable for BNG) shows how to configure an IPv6 reachable time of 1,700,000 milliseconds for HundredGigE interface 0/1/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/1
```

```
RP/0/RP0/CPU0:router(config-if)# ipv6 nd reachable-time 1700000
```

For BNG, this example shows how to configure an IPv6 reachable time of 1,700,000 milliseconds in the dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1  
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd reachable-time 1700000
```

# ipv6 nd redirects

To send Internet Control Message Protocol (ICMP) redirect messages, use the **ipv6 nd redirects** command in interface configuration mode. To restore the system default, use the **no** form of this command.

**ipv6 nd redirects**  
**no ipv6 nd redirects**

**Syntax Description** This command has no keywords or arguments.

**Command Default** The default value is disabled.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This command has no keywords or arguments.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write

## Examples

The following example shows how to redirect IPv6 nd-directed broadcasts on HundredGigE interface 0/2/0/2:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/2/0/2
RP/0/RP0/CPU0:router(config-if)# ipv6 nd redirects
```

## ipv6 nd router-preference

To configure a default router preference (DRP) for the router on a specific interface, use the **ipv6 nd router-preference** command in interface configuration mode. To return to the default DRP, use the **no** form of this command.

```
ipv6 nd router-preference {high | medium | low }
no ipv6 nd router-preference
```

Syntax Description	
<b>high</b>	Preference for the router specified on an interface is high.
<b>medium</b>	Preference for the router specified on an interface is medium.
<b>low</b>	Preference for the router specified on an interface is low.

**Command Default** Router advertisements (RAs) are sent with the medium preference.

**Command Modes** Interface configuration

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** This configuration is not allowed for management interfaces.

RA messages are sent with the DRP configured by the `ipv6 nd router-preference` command. If no DRP is configured, RAs are sent with a medium preference.

A DRP is useful when, for example, two routers on a link may provide equivalent, but not equal-cost, routing, and policy may dictate that hosts should prefer one of the routers.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

**Examples** The following example configures a DRP of high for the router on gigabit Ethernet interface 0/2/0/0:

```
Router(config)# interface GigabitEthernet 0/2/0/0
Router(config-if)# ipv6 nd router-preference high
```



**Related Commands**

Command	Description
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Configures the lifetime of an IPv6 router advertisement.
<a href="#">ipv6 nd ra-lifetime, on page 404</a>	Displays the usability status of interfaces configured for IPv6.

## ipv6 nd scavenge-timeout

To set the lifetime for neighbor entries in the stale state, use the **ipv6 nd scavenge-timeout** command in XR Config mode mode. To disable this feature, use the **no** form of this command.

**ipv6 nd scavenge-timeout** *seconds*  
**no ipv6 nd scavenge-timeout** *seconds*

<b>Syntax Description</b>	<i>seconds</i> RA lifetime in seconds. The range is from 0 to 43200.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	When the scavenge-timer for a neighbor entry expires, the entry is cleared.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read, write
	network	read, write

**Examples** The following example shows how to set the lifetime for the neighbor entry:

```
RP/0/RP0/CPU0:router(config)# ipv6 nd scavenge-timeout 3000
```

## ipv6 nd suppress-ra

To suppress IPv6 router advertisement transmissions on a LAN interface, use the **ipv6 nd suppress-ra** command in an appropriate configuration mode. To reenble the sending of IPv6 router advertisement transmissions on a LAN interface, use the **no** form of this command.

**ipv6 nd suppress-ra**  
**no ipv6 nd suppress-ra**

### Syntax Description

This command has no keywords or arguments.

### Command Default

IPv6 router advertisements are automatically sent on other types of interlaces if IPv6 unicast routing is enabled on the interfaces. IPv6 router advertisements are not sent on other types of interfaces.

### Command Modes

Interface configuration (not applicable for BNG)  
 Dynamic template configuration (for BNG)

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

Use the **no ipv6 nd suppress-ra** command to enable the sending of IPv6 router advertisement transmissions on non-LAN interface types (for example, serial or tunnel interfaces).

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR Config mode.

### Task ID

Task ID	Operations
ipv6	read, write
network	read, write
config-services	read, write

### Examples

This example (not applicable for BNG) shows how to suppress IPv6 router advertisements on HundredGigE interface 0/1/0/1:

```
RP/0/RP0/CPU0:router(config)# interface HundredGigE0/1/0/1
RP/0/RP0/CPU0:router(config-if)# ipv6 nd suppress-ra
```

For BNG, this example shows how to suppress IPv6 router advertisements in the dynamic template configuration mode:

```
RP/0/RP0/CPU0:router(config)# dynamic-template type ppp p1
RP/0/RP0/CPU0:router(config-dynamic-template-type)# ipv6 nd suppress-ra
```

# ipv6 neighbor

To configure a static entry in the IPv6 neighbor discovery cache, use the **ipv6 neighbor** command in XR Config mode. To remove a static IPv6 entry from the IPv6 neighbors discovery cache, use the **no** form of this command.

**ipv6 neighbor** *ipv6-address interface-type interface-instance hardware-address*  
**no ipv6 neighbor** *ipv6-address interface-type interface-instance hardware-address*

Syntax Description	
<i>ipv6-address</i>	The IPv6 address that corresponds to the local data-link address.  This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.
<i>interface-type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-instance</i>	Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0 ) and the module is CPU0. Example: interface MgmtEth0/RSP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<i>hardware-address</i>	The local data-link address (a 48-bit address).

**Command Default** Static entries are not configured in the IPv6 neighbor discovery cache.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **ipv6 neighbor** command is similar to the **arp** (global) command.

If an entry for the specified IPv6 address already exists in the neighbor discovery cache—learned through the IPv6 neighbor discovery process—the entry is automatically converted to a static entry.

Use the **show ipv6 neighbors** command to display static entries in the IPv6 neighbors discovery cache. A static entry in the IPv6 neighbor discovery cache has one state: reach (reachable)—The interface for this entry is up. If the interface for the entry is down, the **show ipv6 neighbors** command does not show the entry.



**Note** Reachability detection is not applied to static entries in the IPv6 neighbor discovery cache; therefore, the descriptions for the reach (reachable) state are different for dynamic and static cache entries. See the **show ipv6 neighbors** command for a description of the reach (reachable) state for dynamic cache entries.

The **clear ipv6 neighbors** command deletes all entries in the IPv6 neighbors discovery cache, except static entries. The **no ipv6 neighbor** command deletes a specified static entry from the neighbor discovery cache; the command does not remove dynamic entries—learned from the IPv6 neighbor discovery process—from the cache. Disabling IPv6 on an interface by using the **no ipv6 enable** or the **no ipv6 unnumbered** command deletes all IPv6 neighbor discovery cache entries configured for that interface, except static entries (the state of the entry changes to reach [reachable]).

Static entries in the IPv6 neighbor discovery cache are not modified by the neighbor discovery process.



**Note** Static entries for IPv6 neighbors can be configured only on IPv6-enabled LAN and ATM LAN Emulation interfaces.

## Task ID

### Task ID Operations

ipv6	read, write
------	----------------

network	read, write
---------	----------------

## Examples

The following example shows how to configure a static entry in the IPv6 neighbor discovery cache for a neighbor with the IPv6 address 2001:0DB8::45A and link-layer address 0002.7D1A.9472 on ethernet interface 0/RSP0/CPU0:

```
RP/0/RP0/CPU0:router(config)# ipv6 neighbor 2001:0DB8::45A 0002.7D1A.9472
```

## ipv6 path-mtu enable

To enable the command to configure path maximum transmission unit (MTU) discovery of IPv6 packets, use the **ipv6 path-mtu enable** command in the XR Config mode.

### ipv6 path-mtu enable

#### Command Default

None.

#### Command Modes

XR Config mode

#### Command History

Release	Modification
Release 7.0.12	This command was introduced.

#### Usage Guidelines

Path MTU discovery for IPv6 packets is supported only for applications using TCP and Ping protocol.

#### Task ID

Task ID	Operations
ipv6	read, write
network	read, write
config-services	read, write

#### Examples

This example shows how to enable path MTU discovery command of IPv6 packets:

```
RP/0/RP0/CPU0:router(config)# ipv6 path-mtu enable
```

# ipv6 path-mtu timeout

To set the maximum transmission unit (MTU) timeout value of IPv6 packets, use the **ipv6 path-mtu timeout** command in the XR Config mode.

**ipv6 path-mtu timeout** *minutes*

<b>Syntax Description</b>	<i>minutes</i> MTU timeout in minutes. Range is 1 to 15 minutes. Default timeout value is 10 minutes.								
<b>Command Default</b>	None.								
<b>Command Modes</b>	XR Config mode								
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.				
Release	Modification								
Release 7.0.12	This command was introduced.								
<b>Usage Guidelines</b>	Path MTU discovery for IPv6 packets is supported only for applications using TCP and Ping protocol.								
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv6</td> <td>read, write</td> </tr> <tr> <td>network</td> <td>read, write</td> </tr> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv6	read, write	network	read, write	config-services	read, write
Task ID	Operations								
ipv6	read, write								
network	read, write								
config-services	read, write								
<b>Examples</b>	<p>This example shows how to set path MTU timeout of IPv6 packets:</p> <pre>RP/0/RP0/CPU0:router(config)# ipv6 path-mtu timeout 15</pre>								

## ipv6 source-route

To enable processing of the IPv6 type source (type 0) routing header, use the **ipv6 source-route** command in XR EXEC mode. To disable the processing of this IPv6 extension header, use the **no** form of this command.

**ipv6 source-route**  
**no ipv6 source-route**

<b>Syntax Description</b>	This command has no keywords or arguments.
<b>Command Default</b>	The <b>no</b> version of the <b>ipv6 source-route</b> command is the default.
<b>Command Modes</b>	XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **no ipv6 source-route** command (which is the default) prevents hosts from performing source routing using your routers. When the **no ipv6 source-route** command is configured and the router receives a packet with a type 0 source routing header, the router drops the packet and sends an IPv6 ICMP error message back to the source and logs an appropriate debug message.

<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	network	read, write
	ipv6	read, write

### Example

The following example shows how to allow the processing of any IPv6 datagrams containing a source-route header option:

```
RP/0/RP0/CPU0:router# config
RP/0/RP0/CPU0:router(config)# ipv6 source-route
RP/0/RP0/CPU0:router(config)#
```



## ipv6 tcp-mss-adjust

To enable the transit traffic of TCP flows to be a Maximum Segment Size (MSS) below the GRE tunnel interface or VLAN sub-interface MTU so that traffic fragmentation is prevented when a session is established for IPv6 packets, use the **ipv6 tcp-mss-adjust** command in the interface configuration submode. To disable the transit traffic of TCP flows to be a Maximum Segment Size (MSS) below the GRE tunnel interface or VLAN sub-interface MTU, use the **no** form of this command.

```
ipv6 tcp-mss-adjust enable
no ipv6 tcp-mss-adjust enable
```

<b>Syntax Description</b>	<b>enable</b> Enables Maximum Segment Size (MSS) adjustment for tcp flows on the interface..
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Interface Configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	This command has no keywords or arguments.
-------------------------	--

<b>Task ID</b>	<b>Task</b>	<b>Operation</b>
	mpls-te	read, write
	ipv6	read, write

### Example

This example shows how to enable the transit traffic of TCP flows for IPv6 packets using the **ipv6 tcp-mss-adjust** command:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# interface HundredEthernet 0/0/0/4.20
RP/0/RP0/CPU0:router(config-if)# ipv6 tcp-mss-adjust enable
```

# ipv6 unreachable disable

To disable the generation of IPv6 Internet Control Message Protocol (ICMP) unreachable messages, use the **ipv6 unreachable disable** command in an appropriate configuration mode. To re-enable the generation of ICMP unreachable messages, use the **no** form of this command.

**ipv6 unreachable disable**  
**no ipv6 unreachable disable**

**Syntax Description** This command has no keywords or arguments.

**Command Default** IPv6 ICMP unreachable messages are generated.

**Command Modes** Interface configuration (not applicable for BNG)  
 Dynamic template configuration (for BNG)

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** If the software receives a nonbroadcast packet destined for itself that uses a protocol it does not recognize, it sends an ICMP protocol unreachable message to the source.

If the software receives a datagram that it cannot deliver to its ultimate destination because it knows of no route to the destination address, it replies to the originator of that datagram with an ICMP host unreachable message.

This command affects a number of ICMP unreachable messages.

For BNG, ensure you run this command in the dynamic template configuration mode. To enter the dynamic template configuration mode, run **dynamic-template** command in the XR EXEC mode.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write
	config-services	read, write

## Examples

This example (not applicable for BNG) shows how to disable the generation of ICMP unreachable messages on HundredGigE interface 0/6/0/0:

```
Router(config)# interface HundredGigE0/6/0/0
Router(config-if)# ipv6 unreachable disable
```

# ipv6 virtual address

To define an IPv6 virtual address for a network of management Ethernet interfaces, use the **ipv6 virtual address** command in XR Config mode. To remove an IPv6 virtual address from the configuration, use the **no** form of this command.

```
ipv6 virtual address {vrf vrf-name ipv6-address/prefix-length | use-as-src-addr}
no ipv6 virtual address {[vrf vrf-name] ipv6-address/prefix-length | use-as-src-addr}
```

Syntax Description		
<b>vrf</b> <i>vrf-name</i>	(Optional) Configures the virtual address on a per VPN routing and forwarding (VRF) basis for the management interfaces. The <i>vrf-name</i> argument specifies the name of the VRF.	
<i>ipv6 address</i>	The virtual IPv6 address to be used.	
<i>prefix-length</i>	The length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark must precede the decimal value.	
<b>use-as-src-addr</b>	Enables the virtual address to be used as the default SRC address on sourced packets.	

**Command Default** No IPv6 virtual address is defined for the configuration.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.5.2	This release supports virtual addresses for the hosted Linux networking stack.
	Release 7.0.12	This command was introduced.

**Usage Guidelines**

Configuring an IPv6 virtual address enables you to access the router from a single virtual address with a management network. An IPv6 virtual address persists across route processor (RP) failover situations.

Configuring an IPv6 virtual address enables you to access a dual RP router from a single address without prior knowledge of which RP is active. An IPv6 virtual address persists across RP failovers. For this to happen, the virtual IPv6 address must share a common IPv6 subnet with a Management Ethernet interface on both RPs.

If you disable the **ipv6 virtual address** command with the **vrf** keyword, the virtual IP address is unconfigured for the corresponding VRF or for the default if no VRF is specified. This results in the removal of the entry for the virtual IP address in the VRF table and in the ARP cache.

The default VRF is chosen when no VRF is specified. The virtual IP address is activated on a management interface that is attached to a default VRF.

The **use-as-src-addr** keyword eliminates the need for configuring a loopback interface as the source interface (that is, update source) for management applications. When an update source is not configured, management applications allow the transport processes (TCP, UDP, raw\_ip) to pick a suitable source address. The transport processes, in turn, consult the FIB to do so. If a Management Ethernet's IP address is picked as the source

address and if the **use-as-src-addr keyword** is configured, then the transport processes replace the Management Ethernet's IP address with a relevant virtual IP address. This functionality works across RP switchovers.

Cisco IOS XR Software Release 7.5.2 and later also supports virtual addresses for the hosted Linux networking stack.

Task ID	Task ID	Operations
	ipv6	read, write
	network	read, write

### Examples

The following example shows how to define an IPv6 virtual address:

```
RP/0/RP0/CPU0:router(config)# ipv6 virtual address 0:0:0:7272::72/64
```

The following example shows how to configure the virtual IP addresses for management interfaces on a per VRF basis:

```
RP/0/RP0/CPU0:router(config)# ipv6 virtual address vrf ppp 0:0:0:7272::72/64
```

# local pool

To create one or more local address pools from which IP addresses are assigned when a peer connects, use the **local pool** command in XR Config mode. To restore the default behavior, use the **no** form of this command.

```
local pool [ipv4] [vrf vrf_name] {poolname | default} first-ip-address [last-ip-address]
no local pool [ipv4] [vrf vrf_name] {poolname | default} first-ip-address [last-ip-address]
```

Syntax Description		
<b>vrf</b>		Specifies that a VRF name will be given. If is parameter is missing, the default VRF is assumed.
<i>vrf_name</i>		Specifies the name of the VRF to which the addresses of the pool belongs. If no name is given, the default VRF is assumed.
<b>default</b>		Creates a default local IPv4 address pool that is used if no other pool is named.
<i>poolname</i>		Specifies the name of the local IPv4 address pool.
<i>first-ip-address</i>		Specifies the first address in an IPv4 address range. If high-IP-address is not specified, the address range is considered to have only one address.
<i>last-ip-address</i>	(Optional)	Specifies the last address in an IPv4 address range. If high-IP-address is not specified, the address range is considered to have only one address.

**Command Default** Special default pool if VRF is not specified. By default, this functionality is disabled.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use this command to create local address pools to use in assigning IP addresses when a peer connects. You can also add range of IP addresses to an existing pool. If no pool name is specified, the pool with the name "default" is used.

The optional **vrf** keyword and associated *vrfname* allows the association of an IPv4 address pool with a named VRF. Any IPv4 address pool created without the **vrf** keyword automatically becomes a member of a default VRF. An IPv4 address pool name can be associated with only one VRF. Subsequent use of the same pool name, within a pool group, is treated as an extension of that pool, and any attempt to associate an existing local IPv4 address pool name with a different VRF is rejected. Therefore, each use of a pool name is an implicit selection of the associated VRF.



**Note** To reduce the chances of inadvertent generation of duplicate addresses, the system allows creation of the default pool only in the default VRF.

All IPv4 address pools within a VRF are checked to prevent overlapping addresses; however, addresses may overlap across different VRFs.

Task ID	Task ID	Operations
	ipv4	read, write
	ipv6	read, write
	network	read, write

## Examples

The following example creates a local IPv4 address pool named “pool2,” which contains all IPv4 addresses in the range 172.16.23.0 to 172.16.23.255:

```
RP/0/RP0/CPU0:router(config)# local pool ipv4 pool2 172.16.23.0 172.16.23.255
```

The following example configures a pool of 1024 IP addresses:

```
RP/0/RP0/CPU0:router(config)#no local pool ipv4 default
RP/0/RP0/CPU0:router(config)#local pool ipv4 default 10.1.1.0 10.1.4.255
```



**Note** It is good practice to precede local pool definitions with a **no** form of the command to remove any existing pool, because the specification of an existing pool name is taken as a request to extend that pool with the new IPv4 addresses. To extend the pool, the **no** form of the command is not applicable.

The following example configures multiple ranges of IPv4 addresses into one pool:

```
RP/0/RP0/CPU0:router(config)#local pool ipv4 default 10.1.1.0 10.1.9.255
RP/0/RP0/CPU0:router(config)#local pool ipv4 default 10.2.1.0 10.2.9.255
```

The following examples show how to configure two pool groups and IPv4 address pools in the base system group:

```
RP/0/RP0/CPU0:router(config)#local pool vrf grp1 ipv4 p1_g1 10.1.1.1 10.1.1.50
RP/0/RP0/CPU0:router(config)#local pool vrf grp1 ipv4 p2_g1 10.1.1.100 10.1.1.110
RP/0/RP0/CPU0:router(config)#local pool vrf grp2 ipv4 p1_g2 10.1.1.1 10.1.1.40
RP/0/RP0/CPU0:router(config)#local pool ipv4 lp1 10.1.1.1 10.1.1.10
RP/0/RP0/CPU0:router(config)#local pool vrf grp1 ipv4 p3_g1 10.1.2.1 10.1.2.30
RP/0/RP0/CPU0:router(config)#local pool vrf grp2 ipv4 p2_g2 10.1.1.50 10.1.1.70
RP/0/RP0/CPU0:router(config)#local pool ipv4 lp2 10.1.2.1 10.1.2.10
```

In this example:

- VRF grp1 consists of pools p1\_g1, p2\_g1, and p3\_g1.
- VRF grp2 consists of pools p1\_g2 and p2\_g2.
- Pools lp1 and lp2 are not explicitly associated with a vrf and are therefore members of the default vrf.




---

**Note** IPv4 address 10.1.1.1 overlaps in vrfs grp1, grp2 and the default vrf . There is no overlap within any vrf that includes the default vrf.

---

The following examples shows the configurations of IP address pools and groups for use by a VPN and VRF:

```
RP/0/RP0/CPU0:router(config)# local pool vrf vpn1 ipv4 p1_vpn1 10.1.1.1 10.1.1.50
RP/0/RP0/CPU0:router(config)# local pool vrf vpn1 ipv4 p2_vpn1 10.1.1.100 10.1.1.110
RP/0/RP0/CPU0:router(config)# local pool vrf vpn2 ipv4 p1_vpn2 10.1.1.1 10.1.1.40
RP/0/RP0/CPU0:router(config)# local pool ipv4 lp1 10.1.1.1 10.1.1.10
RP/0/RP0/CPU0:router(config)# local pool vrf vpn1 ipv4 p3_vpn1 10.1.2.1 10.1.2.30
RP/0/RP0/CPU0:router(config)# local pool vrf vpn2 ipv4 p2_vpn2 10.1.1.50 10.1.1.70 group
vpn2
RP/0/RP0/CPU0:router(config)# local pool ipv4 lp2 10.1.2.1 10.1.2.10
```

These examples show configuration of pools in two VRFs and the default VRF:

- VRF vpn1 consists of pools p1\_vpn1, p2\_vpn1, and p3\_vpn1.
- VRF vpn2 consists of pools p1\_vpn2 and p2\_vpn2.
- Pools lp1 and lp2 are not associated with a VRF and therefore belong to the default VRF.




---

**Note** IPv4 address 10.1.1.1 overlaps across VRFs vpn1, vpn2 and the default VRF . There is no overlap within any VRF.

---

The VPN requires a configuration that selects the proper vrf by selecting the proper pool based on remote user data. Each user in a given VPN can select an address space using the pool and associated vrf appropriate for that VPN. Duplicate addresses in other VPNs (other vrfs) are not a concern, because the address space of a VPN is specific to that VPN. In the example, a user in VRF vpn1 is associated with a combination of the pools p1\_vpn1, p2\_vpn1, and p3\_vpn1, and is allocated addresses from that address space. Addresses are returned to the same pool from which they were allocated.

# show arm conflicts

To display IPv4 or IPv6 address conflict information identified by the Address Repository Manager (ARM), use the **show arm conflicts** command in XR EXEC mode.

**show arm** {**ipv4** | **ipv6**} [**vrf** *vrf-name*] **conflicts** [**address** | **override** | **unnumbered**]

Syntax Description		
<b>ipv4</b>		Displays IPv4 address conflicts.
<b>ipv6</b>		Displays IPv6 address conflicts.
<b>vrf</b>		(Optional) Displays VPN routing and forwarding (VRF) instance information. Available for IPv4 only.
<i>vrf-name</i>		(Optional) Name of a VRF.
<b>address</b>		(Optional) Displays address conflict information.
<b>override</b>		(Optional) Displays address conflict override information.
<b>unnumbered</b>		(Optional) Displays unnumbered interface conflict information.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show arm conflicts** command to display information about IPv4 or IPv6 address conflicts. You can use address conflict information to identify misconfigured IPv4 or IPv6 addresses.

Conflict information is displayed for interfaces that are forced down and for interfaces that are up.

Issuing the **show arm conflicts** command without specifying any optional keywords displays the output generated from both the **address** and **unnumbered** keywords.

Task ID	Task ID	Operations
	network	read

## Examples

The following sample output is from the **show arm ipv4 conflicts** command:

```
RP/0/RP0/CPU0:router# show arm ipv4 conflicts

F Forced down
| Down interface & addr                               Up interface & addr

F Lo2 10.1.1.2/24                                     Lo1 10.1.1.1/24
```



```

Forced down interface      Up interface
tu2->tu1                  tu1->Lo1

```

The following is sample output from the **show arm ipv4 conflicts** command with the **address** keyword:

```

RP/0/RP0/CPU0:router# show arm ipv4 conflicts address

F Forced down
| Down interface & addr          Up interface & addr
F Lo2 10.1.1.2/24                Lo1 10.1.1.1/24

```

The following is sample output from the **show arm ipv4 conflicts** command with the **unnumbered** keyword:

```

RP/0/RP0/CPU0:router# show arm ipv4 conflicts unnumbered

Forced down interface      Up interface      VRF
tu2->tu1                  tu1->Lo1

```

This table describes the significant fields shown in the display.

**Table 50: show arm conflicts Command Field Descriptions**

Field	Description
Forced down	Legend defining a symbol that may appear in the output for this command.
Down interface & addr	Forced down interface name, type, and address.
Up interface & addr	List of interfaces that are up.
Forced down interface	Unnumbered interfaces that are in conflict and forced down.
Up interface	Unnumbered interfaces that are in conflict and are up.

# show arm registrations producers

To display producer registration information for the Address Repository Manager (ARM), use the **show arm registrations producers** command in XR EXEC mode.

**show arm {ipv4 | ipv6} registrations producers**

**Syntax Description** **ipv4** Displays IPv4 producer registration information.

**ipv6** Displays IPv6 producer registration information.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show arm registrations producers** command to display information on producers of IP ARM registrations. Registration information is displayed with the ID.

Task ID	Task ID	Operations
	network	read

**Examples** The following is sample output from the **show arm ipv4 registrations producers** command:

```
Routers# show arm ipv4 registrations producers

Id      Node           Producer Id    IPC Version  Connected?
0       0/0/0          ipv4_io        1.1          Y
4       0/1/0          ipv4_io        1.1          Y
3       0/2/0          ipv4_io        1.1          Y
2       0/4/0          ipv4_io        1.1          Y
1       0/6/0          ipv4_io        1.1          Y
```

This table describes the significant fields shown in the display.

**Table 51: show arm registrations producers Command Field Descriptions**

Field	Description
Id	An identifier used by the IP Address ARM (IP ARM) to keep track of the producer of the IP address.
Node	The physical node (RP/LC CPU) where the producer is running.
Producer Id	The string used by the producer when registering with IP ARM.

Field	Description
IPC Version	Version of the apis used by the producer to communicate with IP ARM.
Connected?	Status of whether the producer is connected or not.

# show arm database

To display IPv4 or IPv6 address information stored in the Address Repository Manager (ARM) database, use the **show arm database** command in XR EXEC mode.

```
show arm {ipv4 | ipv6} [vrf {vrf-name}] database [interface type interface-path-id | network
prefix / length]
```

Syntax Description	
<b>ipv4</b>	Displays IPv4 address information.
<b>ipv6</b>	Displays IPv6 address information.
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<b>interface</b>	(Optional) Displays the IPv4 or IPv6 address configured on the specified interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the show interfaces command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>network</b>	(Optional) Displays addresses that match a prefix.
<i>prefix / length</i>	(Optional) Network prefix and mask. A slash (/) must precede the specified mask. The range is from 0 to 128.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **show arm database** command should be used to display information in the IP ARM database. Database information is displayed with the IPv4 or IPv6 address, interface type and name, and producer information.

Task ID	Task ID	Operations
	network	read

## Examples

The following is sample output from the **show arm database** command:

```
RP/0/RP0/CPU0:router# show arm
ipv4 database interface loopback database
Fri Jul 25 10:54:52.304 PST DST

P = Primary, S = Secondary address
|U = Unnumbered
|| Address                Interface                Producer

VRF: default
P 172.29.52.75/24        MgmtEth0/RP0/CPU0/0    ipv4_ma 0/RP0/CPU0      100
P 10.2.2.2/32           Loopback0                ipv4_ma 0/RP1/CPU0
P 10.12.24.2/24         Bundle-POS24             ipv4_ma 0/RP1/CPU0
P 10.12.28.2/24         Bundle-Ether28           ipv4_ma 0/RP1/CPU0
P 10.12.29.2/24         Bundle-Ether28.1        ipv4_ma 0/RP1/CPU0
P 10.12.30.2/24         Bundle-Ether28.2        ipv4_ma 0/RP1/CPU0
P 10.12.31.2/24         Bundle-Ether28.3        ipv4_ma 0/RP1/CPU0
P 10
.1
.1
.s
/24 Loopback1 ipv4_io 0/0/0P 10.1
.1
.1
/24 Loopback1  ipv4_io 0/0/0

| Address                Interface                Producer
P 10.12.16.2/24          GigabitEthernet0/1/5/0  ipv4_ma 0/1/CPU0      1001
P 10.23.4.2/24           GigabitEthernet0/1/5/1  ipv4_ma 0/1/CPU0      1002
P 10.27.4.2/24           GigabitEthernet0/1/5/2  ipv4_ma 0/1/CPU0
P 10.12.8.2/24           POS0/1/0/1              ipv4_ma 0/1/CPU0
P 10.112.4.2/24          POS0/1/0/2              ipv4_ma 0/1/CPU0
P 10.112.8.2/24          POS0/1/0/3              ipv4_ma 0/1/CPU0
P 10.12.32.2/24          POS0/1/4/2              ipv4_ma 0/1/CPU0
P 10.12.32.2/24          POS0/1/4/3              ipv4_ma 0/1/CPU0
P 172.29.52.28/24        MgmtEth0/4/CPU1/0       ipv4_ma 0/4/CPU1
P 172.29.52.27/24        MgmtEth0/4/CPU0/0       ipv4_ma 0/4/CPU0
P 10.12.20.2/24          GigabitEthernet0/6/5/1  ipv4_ma 0/6/CPU0
P 10.4
.1
.4
/24 gigabitethernet 10/0 ipv4_io 1 10
S 10.4.2.4/24            gigabitethernet 10/0    ipv4_io 1 10
S 10.4.3.4/24            gigabitethernet 10/1    ipv4_io 1 10

P = Primary, S = Secondary address

|U = Unnumbered

|| Address                Interface                Producer
VRF: default
P 10.12.12.2/24          POS0/6/0/1              ipv4_ma 0/6/CPU0
P 10.23.8.2/24           POS0/6/4/4              ipv4_ma 0/6/CPU0
P 10.12.4.2/24           POS0/6/4/5              ipv4_ma 0/6/CPU0
P 10.24.4.2/24           POS0/6/4/6              ipv4_ma 0/6/CPU0
P 12
.25.12
.10/16 MgmtEth0/RSP0/CPU0/0  ipv4_ma 0/RSP0/CPU0
```

This table describes the significant fields shown in the display.

**Table 52: show arm database Command Field Descriptions**

<b>Field</b>	<b>Description</b>
Primary	Primary IP address.
Secondary	Secondary IP address.
Unnumbered Address	Interface is unnumbered and the address displayed is that of the referenced interface.
Interface	Interface that has this IP address.
Producer	Process that provides the IP address to the ARM.

## show arm router-ids

To display the router identification information with virtual routing and forwarding table information for the Address Repository Manager (ARM), use the **show arm router-ids** command in XR EXEC mode.

```
show arm [ipv4] router-ids
```

<b>Syntax Description</b>	<b>ipv4</b> (Optional) Displays IPv4 router information.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>show arm router-ids</b> command with the <b>ipv4</b> keyword to display the selected router ID information for the router.
-------------------------	---

<b>Task ID</b>	<b>Task ID Operations</b>
	network read

<b>Examples</b>	The following is sample output from the <b>show arm router-ids</b> command:
-----------------	---

```
RP/0/RP0/CPU0:router# show arm router-ids

Router-ID          Interface
10.10.10.10        Loopback0
```

This table describes the significant fields shown in the display.

**Table 53: show arm router-ids Command Field Descriptions**

Field	Description
Router-ID	Router identification.
Interface	Interface identification.

# show arm summary

To display summary information for the IP Address Repository Manager (ARM), use the **show arm summary** command in XR EXEC mode.

**show arm {ipv4 | ipv6} summary**

<b>Syntax Description</b>	<b>ipv4</b> Displays IPv4 summary information.
	<b>ipv6</b> Displays IPv6 summary information.

**Command Default** None

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show arm summary** command to display a summary of the number of producers, address conflicts, and unnumbered interface conflicts in the router.

<b>Task ID</b>	<b>Task ID Operations</b>
	network read

**Examples** The following is sample output from the **show arm summary** command:

```
Router# show arm ipv4 summary

IPv4 Producers                :          1
IPv4 address conflicts        :          0
IPv4 unnumbered interface conflicts :          0
IPv4 VRF known                :          0
IPv4 DB Master version       : 0x00000000
```

This table describes the significant fields shown in the display.

**Table 54: show arm summary Command Field Descriptions**

<b>Field</b>	<b>Description</b>
IPv4 Producers	Number of IPv4 producers on the router.
IPv4 address conflicts	Number of IPv4 address conflicts on the router.
IPv4 unnumbered interface conflicts	Number of IPv4 conflicts on unnumbered interfaces.



Field	Description
IPv4 DB Master version	IPv4 DB Master version

# show arm vrf-summary

To display a summary of VPN routing and forwarding (VRF) instance information identified by the Address Repository Manager (ARM), use the **show arm vrf-summary** command in XR EXEC mode.

**show arm {ipv4 | ipv6} vrf-summary**

Syntax Description	
<b>ipv4</b>	Displays IPv4 address information.
<b>ipv6</b>	Displays IPv6 address information.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show arm vrf-summary** command to display information about an IPv4 VPN routing and forwarding instance.

Task ID	Task ID	Operations
	network	read

**Examples** The following example is output from the **show arm vrf-summary** command:

```
RP/0/RP0/CPU0:router# show arm vrf-summary

VRF IDs:          VRF-Names:
0x60000000        default
0x60000001        vrf1
0x60000002        vrf2
```

This table describes the significant fields shown in the display.

**Table 55: show arm vrf-summary Command Field Descriptions**

Field	Description
VRF IDs	VPN routing and forwarding (VRF) identification (vrfid) number.
VRF-Names	Name given to the VRF.

# show clns statistics

To display Connectionless Network Service (CLNS) protocol statistics, use the **show clns statistics** command in XR EXEC mode.

**show clns statistics**

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use this command to display CLNS statistics.

Task ID	Task ID	Operations
	isis	read

## Examples

The following is sample output from the **show clns statistics** command:

```
RP/0/RP0/CPU0:router# show clns statistics

CLNS Statistics:
Last counter clear:                2868 seconds ago
Total number of packets sent:      0
Total number of packets received:  0
Send packets dropped, buffer overflow: 0
Send packets dropped, out of memory: 0
Send packets dropped, other:       0
Receive socket max queue size:     0
Class   Overflow/Max   Rate Limit/Max
IIH     0/0              0/0
LSP     0/0              0/0
SNP     0/0              0/0
OTHER  0/0              0/0
Total   0                0
```

This table describes the significant fields shown in the display.

**Table 56: show clns traffic Command Field Descriptions**

Field	Description
Class	Indicates the packet type. Packets types are as follows: <ul style="list-style-type: none"><li>• IIH—Intermediate System-to-Intermediate-System hello packets</li><li>• lsp—Link state packets</li><li>• snp—Sequence number packets</li><li>• other</li></ul>
Overflow/Max	Indicates the number of packet drops due to the socket queue being overflowed. The count displays in an $x/y$ format where $x$ indicates the total number of packet drops and $y$ indicates the maximum number of drops in a row.
Rate Limit/Max	Indicates the number of packet drops due to rate limitation. The count displays in an $x/y$ format where $x$ indicates the total number of packet drops and $y$ indicates the maximum number of drops in a row.

# show hw-module local-station-mac

To display status of local station MAC address in the router, use the **show hw-module local-station-mac** command in XR EXEC mode.

```
show hw-module local-station-mac
```

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

**Usage Guidelines** Use the **show hw-module local-station-mac** command to display status of the local station MAC address in the router..

Task ID	Task ID	Operations
	network	read

## Examples

The following example is output from the **show hw-module local-station-mac** command:

```
Router# show hw-module local-station-mac
-----
Knob                               Status      Applied    Action
-----
Local-Station-MAC                 Configured  Yes        None
```

# show ipv4 interface

To display the usability status of interfaces configured for IPv4, use the **show ipv4 interface** command in the XR EXEC mode.

**show ipv4** [**vrf** *vrf-name*] **interface** [*type interface-path-id*] [**brief** | **summary**]

## Syntax Description

<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0 ) and the module is CPU0. Example: interface MgmtEth0/RSP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>brief</b>	(Optional) Displays the primary IPv4 addresses configured on the router's interfaces and their protocol and line states.
<b>summary</b>	(Optional) Displays the number of interfaces on the router that are assigned, unassigned, or unnumbered.

## Command Default

If VRF is not specified, the software displays the default VRF.

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

**Usage Guidelines**

The **show ipv4 interface** command provides output similar to the **show ipv6 interface** command, except that it is IPv4-specific.

The interface name will be displayed only if the name belongs to the VRF instance. If the *vrf-name* is not specified then the interface instance will be displayed only if the interface belongs to the default VRF.

**Task ID****Task ID Operations**

ipv4	read
network	read

**Examples**

This is the sample output of the **show ipv4 interface** command:

```
RP/0/RP0/CPU0:router# show ipv4 interface

Bundle-Ether1 is Down, ipv4 protocol is Down
  Vrf is default (vrfid 0x60000000)
  Internet address is 40.30.1.2/24
  MTU is 1514 (1500 is available to IP)
  Helper address is not set
  Directed broadcast forwarding is disabled
  Outgoing access list is not set
  Inbound common access list is not set, access list is not set
  Proxy ARP is disabled
  ICMP redirects are never sent
  ICMP unreachable are always sent
  ICMP mask replies are never sent
  Table Id is 0xe0000000
Bundle-Ether2 is Down, ipv4 protocol is Down
  Vrf is default (vrfid 0x60000000)
  Internet address is 40.30.2.2/24
  MTU is 1514 (1500 is available to IP)
  Helper address is not set
  Directed broadcast forwarding is disabled
  Outgoing access list is not set
  Inbound common access list is not set, access list is not set
  Proxy ARP is disabled
  ICMP redirects are never sent
  ICMP unreachable are always sent
  ICMP mask replies are never sent
  Table Id is 0xe0000000
Bundle-Ether10 is Shutdown, ipv4 protocol is Down
  Vrf is default (vrfid 0x60000000)
  Internet protocol processing disabled
Bundle-Ether54 is Up, ipv4 protocol is Up
  Vrf is default (vrfid 0x60000000)
  Internet address is 10.0.9.0/31
  MTU is 1514 (1500 is available to IP)
  Helper address is not set
  Multicast reserved groups joined: 224.0.0.2 224.0.0.1 224.0.0.2
  Directed broadcast forwarding is disabled
  Outgoing access list is not set
  Inbound common access list is not set, access list is not set
  Proxy ARP is disabled
  ICMP redirects are never sent
  ICMP unreachable are always sent
  ICMP mask replies are never sent
  Table Id is 0xe0000000
Bundle-Ether1900 is Down, ipv4 protocol is Down
```

```

Vrf is default (vrfid 0x60000000)
Internet address is 10.0.54.1/30
MTU is 9000 (8986 is available to IP)
Helper address is not set
Directed broadcast forwarding is disabled
Outgoing access list is not set
Inbound common access list is not set, access list is not set
Proxy ARP is disabled
ICMP redirects are never sent
ICMP unreachable are always sent
ICMP mask replies are never sent
Table Id is 0xe0000000
Bundle-Ether1901 is Down, ipv4 protocol is Down
Vrf is default (vrfid 0x60000000)
Internet address is 10.0.55.1/30
MTU is 9000 (8986 is available to IP)

```

This table describes the significant fields shown in the display.

**Table 57: show ipv4 interface Command Field Descriptions**

Field	Description
Loopback0 is Up	If the interface hardware is usable, the interface is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.
line protocol is Up	If the interface can provide two-way communication, the line protocol is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.
Internet address	IPv4 Internet address and subnet mask of the interface.
Secondary address	Displays a secondary address, if one has been set.
MTU	Displays the IPv4 MTU <sup>8</sup> value set on the interface.
Multicast reserved groups joined	Indicates the multicast groups this interface belongs to.
Directed broadcast forwarding	Indicates whether directed broadcast forwarding is enabled or disabled.
Outgoing access list	Indicates whether the interface has an outgoing access list set.
Inbound access list	Indicates whether the interface has an incoming access list set.
Proxy ARP	Indicates whether proxy ARP <sup>9</sup> is enabled or disabled on an interface.
ICMP redirects	Specifies whether ICMPv4 <sup>10</sup> redirects are sent on this interface.
ICMP unreachable	Specifies whether unreachable messages are sent on this interface.
Internet protocol processing disabled	Indicates an IPv4 address has not been configured on the interface.

<sup>8</sup> MTU = maximum transmission unit

<sup>9</sup> ARP = Address Resolution Protocol address resolution protocol

<sup>10</sup> ICMPv4 = Internet Control Message Protocol internet control message protocol version 4



# show ipv4 traffic

To display the IPv4 traffic statistics, use the **show ipv4 traffic** command in the XR EXEC mode.

**show ipv4 traffic** [brief]

<b>Syntax Description</b>	<b>brief</b> (Optional) Displays only IPv4 and Internet Control Message Protocol version 4 (ICMPv4) traffic.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR EXEC mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	The <b>show ipv4 traffic</b> command provides output similar to the <b>show ipv6 traffic</b> command, except that it is IPv4-specific.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv4</td> <td>read</td> </tr> <tr> <td>network</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ipv4	read	network	read
Task ID	Operations						
ipv4	read						
network	read						

## Examples

This is the sample output of the **show ipv4 traffic** command:

```
RP/0/RP0/CPU0:router# show ipv4 traffic

IP statistics:
  Rcvd: 486522 total, 55292 local destination
        0 format errors, 0 bad hop count
        0 unknown protocol, 0 not a gateway
        0 security failures, 0 bad source, 0 bad header
        842 with options, 0 bad, 0 unknown
  Opts: 0 end, 0 nop, 0 basic security, 0 extended security
        0 strict source rt, 0 loose source rt, 0 record rt
        0 stream ID, 0 timestamp, 842 alert, 0 cipso
  Frags: 0 reassembled, 0 timeouts, 0 couldn't reassemble, 0 fragments received
        0 fragmented, 0 fragment count, 0 fragment max drop
  Bcast: 0 sent, 0 received
  Mcast: 13042 sent, 417434 received
  Lisp: 0 encapsulated in v4, 0 decapsulated from v4
        0 encapsulated in v6, 0 decapsulated from v6
        0 encapsulation errors, 0 decapsulation errors
  Drop: 0 encapsulation failed, 19 no route, 0 too big
  Sent: 446780 total

ICMP statistics:
  Sent: 0 admin unreachable, 190147 network unreachable
        0 host unreachable, 0 protocol unreachable
```

```

    0 port unreachable, 0 fragment unreachable
    0 time to live exceeded, 0 reassembly ttl exceeded
    0 echo request, 0 echo reply
    0 mask request, 0 mask reply
    0 parameter error, 0 redirects
    190147 total
Rcvd: 0 admin unreachable, 11 network unreachable
    0 host unreachable, 0 protocol unreachable
    0 port unreachable, 0 fragment unreachable
    0 time to live exceeded, 0 reassembly ttl exceeded
    0 echo request, 0 echo reply
    0 mask request, 0 mask reply
    0 redirect, 0 parameter error
    0 source quench, 0 timestamp, 0 timestamp reply
    0 router advertisement, 0 router solicitation
    11 total, 0 checksum errors, 0 unknown

UDP statistics:
    424354 packets input, 10881 packets output
    0 checksum errors, 13236 no port
    0 forwarded broadcasts

TCP statistics:
    53775 packets input, 56104 packets output
    0 checksum errors, 0 no port

```

This table describes the significant fields shown in the display.

**Table 58: show ipv4 traffic Command Field Descriptions**

Field	Description
bad hop count	Occurs when a packet is discarded because its TTL <sup>11</sup> field was decremented to zero.
encapsulation failed	Usually indicates that the router had no ARP request entry and therefore did not send a datagram.
format errors	Indicates a gross error in the packet format, such as an impossible Internet header length.
IP statistics Rcvd total	Indicates the total number of local destination and other packets received in the software plane. It does not account for the IP packets forwarded or discarded in hardware.
no route	Counted when the Cisco IOS XR software discards a datagram it did not know how to route.

<sup>11</sup> TTL = time-to-live

# show ipv6 interface

To display the usability status of interfaces configured for IPv6, use the **show ipv6 interface** command in the XR EXEC mode.

```
show ipv6 [vrf vrf-name] interface [summary | [type interface-path-id][brief [link-local | global]]]
```

Syntax Description	
<b>vrf</b>	(Optional) Displays VPN routing and forwarding (VRF) instance information.
<i>vrf-name</i>	(Optional) Name of a VRF.
<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	<p>(Optional) Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0) and the module is CPU0. Example: interface MgmtEth0/RSP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>brief</b>	(Optional) Displays the primary IPv6 addresses configured on the router interfaces and their protocol and line states.
<b>link-local</b>	(Optional) Displays the link local IPv6 address.
<b>global</b>	(Optional) Displays the global IPv6 address.
<b>summary</b>	(Optional) Displays the number of interfaces on the router that are assigned, unassigned, or unnumbered.
<b>Command Default</b>	None
<b>Command Modes</b>	XR EXEC mode

## show ipv6 interface

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **show ipv6 interface** command provides output similar to the **show ipv4 interface** command, except that it is IPv6-specific.

Use the **link-local** or **global** keywords along with the **brief** keyword to view the link local or global IPv6 addresses.

Task ID	Task ID	Operations
	ipv6	read

**Examples**

This is the sample output of the **show ipv6 interface** command:

```
RP/0/RP0/CPU0:router# show ipv6 interface
Bundle-Ether1 is Down, ipv6 protocol is Down, Vrfid is default (0x60000000)
IPv6 is enabled, link-local address is fe80::e448:5cff:fe10:b484 [TENTATIVE]
Global unicast address(es):
  40:30:1:1::2, subnet is 40:30:1:1::/64 [TENTATIVE]
Joined group address(es): ff02::2 ff02::1
MTU is 1514 (1500 is available to IPv6)
ICMP redirects are disabled
ICMP unreachable are enabled
ND DAD is enabled, number of DAD attempts 1
ND reachable time is 0 milliseconds
ND cache entry limit is 1000000000
ND advertised retransmit interval is 0 milliseconds
ND router advertisements are sent every 160 to 240 seconds
ND router advertisements live for 1800 seconds
Hosts use stateless autoconfig for addresses.
Outgoing access list is not set
Inbound common access list is not set, access list is not set
Table Id is 0xe0800000
Complete protocol adjacency: 0
Complete glean adjacency: 0
Incomplete protocol adjacency: 0
Incomplete glean adjacency: 0
Dropped protocol request: 0
Dropped glean request: 0
```

This table describes the significant fields shown in the display.

**Table 59: show ipv6 interface Command Field Descriptions**

Field	Description
Bundle-Ether1 is Down	Indicates whether the interface hardware is currently active (whether line signal is present) and whether it has been taken down by an administrator. If the interface hardware is usable, the interface is marked "Up." For an interface to be usable, both the interface hardware and line protocol must be up.

Field	Description
line protocol is Up (or down)	Indicates whether the software processes that handle the line protocol consider the line usable (that is, whether keepalives are successful). If the interface can provide two-way communication, the line protocol is marked “Up.” For an interface to be usable, both the interface hardware and line protocol must be up.
IPv6 is enabled, stalled, disabled (stalled and disabled are not shown in sample output)	Indicates that IPv6 is enabled, stalled, or disabled on the interface. If IPv6 is enabled, the interface is marked “enabled.” If duplicate address detection processing identified the link-local address of the interface as being a duplicate address, the processing of IPv6 packets is disabled on the interface and the interface is marked “stalled.” If IPv6 is not enabled, the interface is marked “disabled.”
link-local address	Displays the link-local address assigned to the interface.
TENTATIVE	The state of the address in relation to duplicate address detection. States can be any of the following: <ul style="list-style-type: none"> <li>• duplicate—The address is not unique and is not being used. If the duplicate address is the link-local address of an interface, the processing of IPv6 packets is disabled on that interface.</li> <li>• tentative—Duplicate address detection is either pending or under way on this interface.</li> </ul> <p><b>Note</b> If an address does not have one of these states (the state for the address is blank), the address is unique and is being used.</p>
Global unicast addresses	Displays the global unicast addresses assigned to the interface.
ICMP redirects	State of Internet Control Message Protocol (ICMP) IPv6 redirect messages on the interface (the sending of the messages is enabled or disabled).
ND DAD	State of duplicate address detection on the interface (enabled or disabled).
number of DAD attempts	Number of consecutive neighbor solicitation messages that are sent on the interface while duplicate address detection is performed.
ND reachable time	Displays the neighbor discovery reachable time (in milliseconds) assigned to this interface.

This is the sample output of the **show ipv6 interface brief link-local** command:

```
RP/0/RP0/CPU0:router#show ipv6 interface brief link-local
```

```
Interface           IPv6-Address           Status    Protocol
Bundle-Ether1      fe80::e448:5cff:fe10:b484  Down     Down
Bundle-Ether2      fe80::e448:5cff:fe10:b483  Down     Down
Bundle-Ether10     unassigned             Shutdown Down
Bundle-Ether54     fe80::e448:5cff:fe10:b481  Up       Up
Bundle-Ether1900   fe80::e448:5cff:fe10:b48a  Down     Down
Bundle-Ether1901   fe80::e448:5cff:fe10:b489  Down     Down
Bundle-Ether1902   fe80::e448:5cff:fe10:b488  Down     Down
```

## show ipv6 interface

Bundle-Ether1903	fe80::e448:5cff:fe10:b487	Down	Down
Bundle-Ether1904	fe80::e448:5cff:fe10:b486	Down	Down
Bundle-Ether1905	unassigned	Shutdown	Down
Bundle-Ether1906	fe80::e448:5cff:fe10:b48e	Down	Down
Loopback0	fe80::9d4c:a5ff:fe2f:2615	Up	Up
Loopback1	fe80::9d4c:a5ff:fe2f:2615	Up	Up
tunnel-te54	unassigned	Down	Down
tunnel-te718	unassigned	Up	Up
tunnel-te720	unassigned	Up	Up
tunnel-te5454	unassigned	Up	Up
MgmtEth0/RP0/CPU0/0	unassigned	Up	Up
HundredGigE0/2/0/0	unassigned	Shutdown	Down
HundredGigE0/2/0/1	unassigned	Shutdown	Down
HundredGigE0/2/0/2	unassigned	Shutdown	Down
HundredGigE0/2/0/3	unassigned	Shutdown	Down
HundredGigE0/2/0/4	fe80::e448:5cff:fe10:b130	Shutdown	Down
HundredGigE0/2/0/5	unassigned	Shutdown	Down
HundredGigE0/2/0/6	unassigned	Shutdown	Down
HundredGigE0/2/0/7	unassigned	Shutdown	Down
HundredGigE0/2/0/8	unassigned	Down	Down
HundredGigE0/2/0/9	unassigned	Shutdown	Down
HundredGigE0/2/0/10	unassigned	Shutdown	Down
HundredGigE0/2/0/11	unassigned	Shutdown	Down
HundredGigE0/2/0/12	unassigned	Shutdown	Down
HundredGigE0/2/0/13	unassigned	Shutdown	Down
HundredGigE0/2/0/15	unassigned	Shutdown	Down
HundredGigE0/2/0/16	unassigned	Shutdown	Down
HundredGigE0/2/0/17	unassigned	Shutdown	Down
HundredGigE0/2/0/18	unassigned	Shutdown	Down
HundredGigE0/2/0/19	unassigned	Shutdown	Down
HundredGigE0/2/0/20	unassigned	Shutdown	Down
HundredGigE0/2/0/21	unassigned	Shutdown	Down
HundredGigE0/2/0/22	unassigned	Shutdown	Down
HundredGigE0/2/0/23	unassigned	Shutdown	Down
HundredGigE0/2/0/25	fe80::e448:5cff:fe10:b184	Shutdown	Down
HundredGigE0/2/0/26	unassigned	Shutdown	Down
HundredGigE0/2/0/27	unassigned	Shutdown	Down
HundredGigE0/2/0/28	unassigned	Shutdown	Down
HundredGigE0/2/0/29	unassigned	Shutdown	Down
HundredGigE0/2/0/31	unassigned	Shutdown	Down
HundredGigE0/2/0/32	unassigned	Shutdown	Down
HundredGigE0/2/0/33	unassigned	Shutdown	Down
HundredGigE0/2/0/34	unassigned	Shutdown	Down
HundredGigE0/2/0/35	unassigned	Shutdown	Down
TenGigE0/2/0/14/0	unassigned	Up	Up
TenGigE0/2/0/14/1	unassigned	Up	Up
TenGigE0/2/0/14/2	unassigned	Up	Up
TenGigE0/2/0/14/3	unassigned	Up	Up
TenGigE0/2/0/24/0	fe80::e448:5cff:fe10:b180	Up	Up

This is the sample output of the **show ipv6 interface brief global** command:

```
RP/0/#show ipv6 interface brief global
```

Interface	IPv6-Address	Status	Protocol
Bundle-Ether54	10:0:9::2	Up	Up
Bundle-Ether1900	10:0:54::2	Up	Up
Bundle-Ether1901	10:0:55::2	Up	Up
Bundle-Ether1902	10:0:56::2	Up	Up
Bundle-Ether1903	10:0:84::2	Up	Up
Bundle-Ether1904	10:0:85::2	Up	Up
Bundle-Ether1906	10:0:86::2	Up	Up

This is the sample output of the **show ipv6 interface type interface-path-id brief link-local** command:

```
RP/0/RP0/CPU0:router#show ipv6 interface tenGigE 0/0/0/0 brief link-local
```

Interface	IPv6-Address	Status	Protocol
HundredGigE0/0/0/0	fe80::fe:8ff:feeb:26c5	Up	Up

This is the sample output of the **show ipv6 interface *type interface-path-id* brief global** command:

```
RP/0/RP0/CPU0:router#show ipv6 interface tenGigE 0/0/0/0 brief global
```

Interface	IPv6-Address	Status	Protocol
HundredGigE0/0/0/0	2001:db8::1	Up	Up

# show ipv6 neighbors

To display the IPv6 neighbor discovery cache information, use the **show ipv6 neighbors** command in the XR EXEC mode.

**show ipv6 neighbors** [*type interface-path-id* | **location node-id**]

<b>Syntax Description</b>	<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
	<i>interface-path-id</i>	(Optional) Physical interface instance or a virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.
	<b>location node-id</b>	(Optional) Designates a node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** All IPv6 neighbor discovery cache information is displayed.

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** When the *interface-type* and *interface-number* arguments are not specified, cache information for all IPv6 neighbors is displayed. Specifying the *interface-type* and *interface-number* arguments displays only cache information about the specified interface.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ipv6	read

## Examples

This is the sample output of the **show ipv6 neighbors** command when entered with an interface type and number:

```
RP/0/RP0/CPU0:router# show ipv6 neighbors HundredGigE0/0/0/2

IPv6 Address                               Age Link-layer Addr State Interface
2000:0:0:4::2                             0 0003.a0d6.141e REACH tenGigE
FE80::203:A0FF:FED6:141E                   0 0003.a0d6.141e REACH tenGigE
3001:1::45a                                - 0002.7d1a.9472 REACH tenGigE
```



This is the sample output of the **show ipv6 neighbors** command:

```
RP/0/RP0/CPU0:router# show ipv6 neighbors

IPv6 Address                               Age Link-layer Addr State Interface
Location
[Mcast adjacency]                          - 0000.0000.0000 DELETE Hu0/2/0/25
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE Hu0/2/0/4
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE Te0/2/0/30/3
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Te0/2/0/30/2
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Te0/2/0/30/1
0/2/CPU0
fe80::d66d:50ff:fe38:9544                  97  d46d.5038.9544 REACH Te0/2/0/30/0
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Te0/2/0/30/0
0/2/CPU0
10:0:8::2                                  89  10f3.114c.719c REACH Te0/2/0/24/0
0/2/CPU0
fe80::12f3:11ff:fe4c:719c                  135 10f3.114c.719c REACH Te0/2/0/24/0
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Te0/2/0/24/0
0/2/CPU0
10:0:9::2                                  150 e607.2b8d.3484 REACH BE54
0/2/CPU0
fe80::e407:2bff:fe8d:3484                  149 e607.2b8d.3484 REACH BE54
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH BE54
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1900
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1901
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1903
0/2/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1904
0/2/CPU0
1000::2                                    50  0010.9400.000d REACH Hu0/4/0/0
0/4/CPU0
fe80::1                                    153 0010.9400.000d REACH Hu0/4/0/0
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Hu0/4/0/0
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE Hu0/4/0/6
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE Hu0/4/0/18
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE Hu0/4/0/25
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Te0/4/0/30/0
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 REACH Te0/4/0/30/1
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1901
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1902
0/4/CPU0
[Mcast adjacency]                          - 0000.0000.0000 DELETE BE1903
0/4/CPU0
```

## show ipv6 neighbors

```

[Mcast adjacency]          - 0000.0000.0000 DELETE BE1906
0/4/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Hu0/6/0/35
0/6/CPU0
200:1::2                   157 0010.9400.0013 REACH Hu0/6/0/34
0/6/CPU0
fe80::1                    130 0010.9400.0013 REACH Hu0/6/0/34
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 REACH Hu0/6/0/34
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Hu0/6/0/16
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Hu0/6/0/18
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Hu0/6/0/19
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Hu0/6/0/20
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Hu0/6/0/21
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Te0/6/0/2/2
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE Te0/6/0/2/1
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE BE2
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE BE1900
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE BE1902
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE BE1904
0/6/CPU0
[Mcast adjacency]          - 0000.0000.0000 DELETE BE1906
0/6/CPU0

```

This is the sample output of the **show ipv6 neighbors** command when entered with a location:

```
RP/0/RP0/CPU0:router# show ipv6 neighbors location 0/2/CPU0
```

IPv6 Address	Age	Link-layer Addr	State	Interface	Location
2001:3::2	119	0013.9400.0002	REACH	BE3	0/2/CPU0
2001:3::3	179	0013.9400.0003	DELAY	BE3	0/2/CPU0
2001:3::4	166	0013.9400.0004	REACH	BE3	0/2/CPU0
2001:3::5	78	0013.9400.0005	REACH	BE3	0/2/CPU0
2001:3::6	19	0013.9400.0006	REACH	BE3	0/2/CPU0
2001:3::7	173	0013.9400.0007	REACH	BE3	0/2/CPU0
2001:3::8	140	0013.9400.0008	REACH	BE3	0/2/CPU0
2001:3::9	163	0013.9400.0009	REACH	BE3	0/2/CPU0
2001:3::a	40	0013.9400.000a	REACH	BE3	0/2/CPU0
2001:3::b	90	0013.9400.000b	REACH	BE3	0/2/CPU0
2001:3::c	35	0013.9400.000c	REACH	BE3	0/2/CPU0
2001:3::d	114	0013.9400.000d	REACH	BE3	0/2/CPU0
2001:3::e	117	0013.9400.000e	REACH	BE3	0/2/CPU0
2001:3::f	157	0013.9400.000f	REACH	BE3	0/2/CPU0
2001:3::10	9	0013.9400.0010	REACH	BE3	0/2/CPU0
2001:3::11	120	0013.9400.0011	REACH	BE3	0/2/CPU0
2001:3::12	87	0013.9400.0012	REACH	BE3	0/2/CPU0
2001:3::13	180	0013.9400.0013	DELAY	BE3	0/2/CPU0
2001:3::14	103	0013.9400.0014	REACH	BE3	0/2/CPU0
2001:3::15	132	0013.9400.0015	REACH	BE3	0/2/CPU0
2001:3::16	33	0013.9400.0016	REACH	BE3	0/2/CPU0
2001:3::17	150	0013.9400.0017	REACH	BE3	0/2/CPU0
2001:3::18	117	0013.9400.0018	REACH	BE3	0/2/CPU0

```

2001:3::19      48  0013.9400.0019 REACH BE3      0/2/CPU0
2001:3::1a      67  0013.9400.001a REACH BE3      0/2/CPU0
2001:3::1b      91  0013.9400.001b REACH BE3      0/2/CPU0
2001:3::1c      33  0013.9400.001c REACH BE3      0/2/CPU0
2001:3::1d     174 0013.9400.001d DELAY BE3      0/2/CPU0
2001:3::1e     144 0013.9400.001e REACH BE3      0/2/CPU0
2001:3::1f     121 0013.9400.001f REACH BE3      0/2/CPU0
2001:3::20      53  0013.9400.0020 REACH BE3      0/2/CPU0

```

This table describes significant fields shown in the display.

**Table 60: show ipv6 neighbors Command Field Descriptions**

Field	Description
IPv6 Address	IPv6 address of neighbor or interface.
Age	Time (in minutes) since the address was confirmed to be reachable. A hyphen (-) indicates a static entry.
Link-layer Addr	MAC address. If the address is unknown, a hyphen (-) is displayed.
State	<p>The state of the neighbor cache entry. These are the states for dynamic entries in the IPv6 neighbor discovery cache:</p> <ul style="list-style-type: none"> <li>• <b>INCMP (incomplete)</b>—Address resolution is being performed on the entry. A neighbor solicitation message has been sent to the solicited-node multicast address of the target, but the corresponding neighbor advertisement message has not yet been received.</li> <li>• <b>reach (reachable)</b>—Positive confirmation was received within the last ReachableTime milliseconds that the forward path to the neighbor was functioning properly. While in reach state, the device takes no special action as packets are sent.</li> <li>• <b>stale</b>—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. While in stale state, the device takes no action until a packet is sent.</li> <li>• <b>delay</b>—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. A packet was sent within the last DELAY_FIRST_PROBE_TIME seconds. If no reachability confirmation is received within DELAY_FIRST_PROBE_TIME seconds of entering the delay state, send a neighbor solicitation message and change the state to probe.</li> <li>• <b>probe</b>—A reachability confirmation is actively sought by resending neighbor solicitation messages every RetransTimer milliseconds until a reachability confirmation is received.</li> </ul> <p>These are the possible states for static entries in the IPv6 neighbor discovery cache:</p> <ul style="list-style-type: none"> <li>• <b>reach (reachable)</b>—The interface for this entry is up.</li> <li>• <b>INCMP (incomplete)</b>—The interface for this entry is down.</li> </ul> <p><b>Note</b> Reachability detection is not applied to static entries in the IPv6 neighbor discovery cache; therefore, the descriptions for the INCMP (incomplete) and reach (reachable) states are different for dynamic and static cache entries.</p>
Interface	Interface from which the address is reachable.

# show ipv6 neighbors summary

To display summary information for the neighbor entries, use the **show ipv6 neighbors summary** command in the XR EXEC mode.

**show ipv6 neighbors summary**

**Syntax Description** This command has no keywords or arguments.

**Command Default** The default value is disabled.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Task ID	Task ID	Operations
	ipv6	read

## Examples

This is the sample output of the **show ipv6 neighbors summary** command that shows the summary information for the neighbor entries:

```
XR EXEC mode# show ipv6 neighbors summary

Mcast nbr entries:
  Subtotal: 0
Static nbr entries:
  Subtotal: 0
Dynamic nbr entries:
  Subtotal: 0

Total nbr entries: 0
```

## show ipv6 path-mtu

To display path maximum transmission unit (MTU) details of IPv6 packets, use the **show ipv6 path-mtu** command in the XR Config mode.

```
show ipv6 path-mtu [ vrf { vrf-name | all} [ location node-id ] ] [ location node-id ]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) The designated node. The node-id argument is entered in the <i>rack/slot/module</i> notation.								
<b>Command Default</b>	None.								
<b>Command Modes</b>	XR Config mode								
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.				
Release	Modification								
Release 7.0.12	This command was introduced.								
<b>Usage Guidelines</b>	If the location option is specified, only the details of the node specified in the <b>location node-id</b> keyword and argument are displayed. Path MTU discovery for IPv6 packets is supported only for applications using TCP and Ping protocol.								
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv6</td> <td>read, write</td> </tr> <tr> <td>network</td> <td>read, write</td> </tr> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ipv6	read, write	network	read, write	config-services	read, write
Task ID	Operations								
ipv6	read, write								
network	read, write								
config-services	read, write								

### Examples

This example shows how to display path MTU details of IPv6 packets:

```
RP/0/RP0/CPU0:router(config)# show ipv6 pmtu

Destination      Ifhandle      Vrfid          Path Mtu      Time Left
bb::1            0x300         0x60000000     1300          00:01:27
cd::1            0x300         0x60000000     1300          00:01:42
```

# show ipv6 traffic

To display the IPv6 traffic statistics, use the **show traffic** command in the XR EXEC mode.

**show ipv6 traffic [brief]**

<b>Syntax Description</b>	<b>brief</b> (Optional) Displays only IPv6 and Internet Control Message Protocol version 6 (ICMPv6) traffic statistics.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR EXEC mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.		
Release	Modification						
Release 7.0.12	This command was introduced.						
<b>Usage Guidelines</b>	The <b>show ipv6 traffic</b> command provides output similar to the <b>show ipv4 traffic</b> command, except that it is IPv6-specific.						
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ipv6</td> <td>read</td> </tr> <tr> <td>network</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ipv6	read	network	read
Task ID	Operations						
ipv6	read						
network	read						

## Examples

This is the sample output of the **show ipv6 traffic** command:

```
RP/0/RP0/CPU0:router# show ipv6 traffic

IPv6 statistics:
  Rcvd: 0 total, 0 local destination
        0 source-routed, 0 truncated
        0 format errors, 0 hop count exceeded
        0 bad header, 0 unknown option, 0 bad source
        0 unknown protocol
        0 fragments, 0 total reassembled
        0 reassembly timeouts, 0 reassembly failures
        0 reassembly max drop
        0 sanity address check drops
  Sent: 0 generated, 0 forwarded
        0 fragmented into 0 fragments, 0 failed
        0 no route, 0 too big
  Mcast: 0 received, 0 sent

ICMP statistics:
  Rcvd: 0 input, 0 checksum errors, 0 too short
        0 unknown error type
  unreachable: 0 routing, 0 admin, 0 neighbor,
               0 address, 0 port, 0 unknown
```

```

parameter: 0 error, 0 header, 0 option,
           0 unknown
0 hopcount expired, 0 reassembly timeout,
0 unknown timeout, 0 too big,
0 echo request, 0 echo reply
Sent: 0 output, 0 rate-limited
unreach: 0 routing, 0 admin, 0 neighbor,
         0 address, 0 port, 0 unknown
parameter: 0 error, 0 header, 0 option
           0 unknown
0 hopcount expired, 0 reassembly timeout,
0 unknown timeout, 0 too big,
0 echo request, 0 echo reply

Neighbor Discovery ICMP statistics:
Rcvd: 0 router solicit, 0 router advert, 0 redirect
      0 neighbor solicit, 0 neighbor advert
Sent: 0 router solicit, 0 router advert, 0 redirect
      0 neighbor solicit, 0 neighbor advert

UDP statistics:
  0 packets input, 0 checksum errors
  0 length errors, 0 no port, 0 dropped
  0 packets output

TCP statistics:s
  0 packets input, 0 checksum errors, 0 dropped
  0 packets output, 0 retransmitted

```

This table describes the significant fields shown in the display.

**Table 61: show ipv6 traffic Command Field Descriptions**

Field	Description
Rcvd:	Statistics in this section refer to packets received by the router.
total	Total number of packets received by the software.
local destination	Locally destined packets received by the software.
source-routed	Packets seen by the software with RH.
truncated	Truncated packets seen by the software.
bad header	An error was found in generic HBH, RH, DH, or HA. Software only.
unknown option	Unknown option type in IPv6 header.
unknown protocol	Protocol specified in the IP header of the received packet is unreachable.
Sent:	Statistics in this section refer to packets sent by the router.
forwarded	Packets forwarded by the software. If the packet cannot be forwarded in the first lookup (for example, the packet needs option processing), then the packet is not included in this count, even if it ends up being forwarded by the software.
Mcast:	Multicast packets.

**show ipv6 traffic**

<b>Field</b>	<b>Description</b>
ICMP statistics:	Internet Control Message Protocol statistics.



# show linux networking interfaces address-only

To display virtual IP addresses and IP addresses for address-only interfaces, use the **show linux networking interfaces address-only** command in the XR EXEC mode. Address-only interfaces are those interfaces whose addresses are copied to the Linux loopback device by XLNC (XR Linux networking coordinator).

## show linux networking interfaces address-only

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.5.2	The virtual IP addresses are displayed in the output of the command.
	Release 7.3.2	This command was introduced.
<b>Usage Guidelines</b>	None	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	system	read

## Example

This is the sample output of the **show linux networking interfaces address-only** command:

```
Router# show linux networking interfaces address-only
The following interface addresses have been added to the Linux loopback device for L3
reachability.

VRF default
-----
MgmtEth0/RP0/CPU0/0
  IPv4: 10.0.0.3 (virtual address)
  IPv6: 10::3 (virtual address)
```

# show local pool

To display IPv4 local pool details, use the **show local pool** command in XR EXEC mode.

```
show {localother_pool_types} pool [vrf vrf_name] {ipv4 | ipv6} {defaultpoolname}
```

Syntax Description	local	Specifies that the address pool is local.
	vrf	Specifies that a VRF name will be given. If is parameter is missing, the default VRF is assumed.
	vrf_name	Specifies the name of the VRF to which the addresses of the pool belongs. If no name is given, the default VRF is assumed.
	default	Creates a default local IPv4 address pool that is used if no other pool is named.
	poolname	Specifies the name of the local IPv4 address pool.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Syntax Description** This command has no keywords or arguments.

Task ID	Task ID	Operations
	ipv4	read
	network	read

## Examples

The following is sample output from the **show ipv4 local pool** with a poolname of P1:

```
RP/0/RP0/CPU0:router# show ipv4 local pool P1

Pool Begin End FreeInUse
P1 172.30.228.11172.30.228.1660
Available addresses:
172.30.228.11
172.30.228.12
172.30.228.13
172.30.228.14
172.30.228.15
172.30.228.16
Inuse addresses:
None
```

This table describes the significant fields shown in the display.

**Table 62: show ipv4 local pool Command Descriptions**

<b>Field</b>	<b>Description</b>
Pool	Name of the pool.
Begin	First IP address in the defined range of addresses in this pool.
End	Last IP address in the defined range of addresses in this pool.
Free	Number of addresses available.
InUse	Number of addresses in use.

# show mpa client

To display information about the Multicast Port Arbitrator (MPA) clients, use the **show mpa client** command in XR EXEC mode.

**show mpa client** {consumers | producers}

Syntax Description	
<b>consumers</b>	Displays the clients for the consumers.
<b>producers</b>	Displays the clients for the producers.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Task ID	Task ID	Operations
	network	read

## Examples

The following sample output is from the **show mpa client** command:

```
RP/0/RP0/CPU0:router# show mpa client consumers
```

```
List of producer clients for ipv4 MPA
```

Location	Protocol	Process
0/1/CPU0	255	raw
0/1/CPU0	17	udp
0/4/CPU0	17	udp
0/4/CPU0	255	raw
0/4/CPU1	17	udp
0/4/CPU1	255	raw
0/6/CPU0	17	udp
0/6/CPU0	255	raw
0/RP1/CPU0	17	udp
0/RP1/CPU0	255	raw

# show mpa groups

To display Multicast Port Arbitrator (MPA) multicast group information, use the **show mpa groups** command in XR EXEC mode .

**show mpa groups** *type interface-path-id*

<b>Syntax Description</b>	<p><i>type</i> Interface type. For more information, use the question mark (?) online help function.</p> <hr/> <p><i>interface-path-id</i> Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>• Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li>• <i>rack</i>: Chassis number of the rack.</li> <li>• <i>slot</i>: Physical slot number of the modular services card or line card.</li> <li>• <i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li>• <i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0) and the module is CPU0. Example: interface MgmtEth0/RSP0 /CPU0/0.</p> <ul style="list-style-type: none"> <li>• Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>network</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	network	read
Task ID	Operations				
network	read				

**Examples** The following sample output is from the **show mpa groups** command:

```
RP/0/RP0/CPU0:router# show mpa groupsHundredGigE0/0/0/2
Mon Jul 27 04:07:19.802 DST
HundredGigE0/0/0/2 :-
```

```
224.0.0.1 : includes 0, excludes 1, mode EXCLUDE
<no source filter>
224.0.0.2 : includes 0, excludes 1, mode EXCLUDE
<no source filter>
224.0.0.5 : includes 0, excludes 1, mode EXCLUDE
<no source filter>
224.0.0.6 : includes 0, excludes 1, mode EXCLUDE
<no source filter>
224.0.0.13 : includes 0, excludes 1, mode EXCLUDE
<no source filter>
224.0.0.22 : includes 0, excludes 1, mode EXCLUDE
<no source filter>
```

# show mpa ipv4

To display information for Multicast Port Arbitrator (MPA) for IPv4, use the **show mpa ipv4** command in XR EXEC mode.

```
show mpa ipv4 {client {consumers | producers} | groups type interface-path-id | trace}
```

Syntax Description	
<b>client</b>	Displays information about the MPA clients.
<b>consumers</b>	Displays the clients for the consumers.
<b>producers</b>	Displays the clients for the producers.
<b>groups</b>	Displays information about the MPA multicast group.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	<p>Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RSP0) and the module is CPU0. Example: interface MgmtEth0/RSP0/CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>trace</b>	Displays MPA trace information

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID Operations
	network read

### Examples

The following sample output is from the **show mpa ipv4** command:

```
RP/0/RP0/CPU0:router# show mpa ipv4 client producers
```

List of producer clients for ipv4 MPA

Location	Protocol	Process
0/1/CPU0	17	udp
0/1/CPU0	255	raw
0/4/CPU0	17	udp
0/4/CPU0	255	raw
0/4/CPU1	17	udp
0/4/CPU1	255	raw
0/6/CPU0	17	udp
0/6/CPU0	255	raw
0/RP0/CPU0	17	udp
0/RP0/CPU0	255	raw
0/RP1/CPU0	255	raw
0/RP1/CPU0	17	udp



# show mpa ipv6

To display information for Multicast Port Arbitrator (MPA) for IPv6, use the **show mpa ipv6** command in XR EXEC mode.

```
show mpa ipv6 {client {consumers | producers} | groups type interface-path-id}
```

Syntax Description	
<b>client</b>	Displays information about the MPA clients.
<b>consumers</b>	Displays the clients for the consumers.
<b>producers</b>	Displays the clients for the producers.
<b>groups</b>	Displays information about the MPA multicast group.
<b>type</b>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	<p>Either a physical interface instance or a virtual interface instance as follows:</p> <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/module/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>module</i>: Module number. A physical layer interface module (PLIM) is always 0.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> </ul> <p><b>Note</b> In references to a Management Ethernet interface located on a route processor card, the physical slot number is alphanumeric (RP0 or RP1) and the module is CPU0. Example: interface MgmtEth0/RP1/CPU0/0.</p> <ul style="list-style-type: none"> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>

<b>Command Default</b>	None
------------------------	------

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

Task ID	Task ID	Operations
	network	read

---

**Examples**

The following sample output is from the **show mpa ipv6** command:

```
RP/0/RP0/CPU0:router# show mpa ipv6 client producers
```

```
List of producer clients for ipv6 MPA
```

Location	Protocol	Process
0/RP1/CPU0	17	udp
0/RP1/CPU0	255	raw

# show hw-module profile route-scale

To display the status of the configured IPv6 prefix scale expansion feature, run the **show hw-module profile route-scale** command in XR EXEC mode.

```
show hw-module profile route-scale
```

**Syntax Description** This command has no keywords or arguments.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.5.3	This command was introduced.

**Usage Guidelines** The chassis must be reloaded for the **hw-module** command to be functional.

Task ID	Task ID	Operations
	ipv6	read, write

After the configuration of the [hw-module profile route scale ipv6-unicast connected-prefix high](#) command is complete, reload the router for the feature to take effect. The **Applied** column in the **show hw-module profile route-scale** command displays *No* if the line card is not reloaded.

```
Router# show hw-module profile route-scale
Tue Aug 23 18:27:03.551 UTC
-----
Knob                               Status      Applied    Action
-----
Route-Scale                         Configured   No         Reload
```

After you reload the router for the feature to take effect, the **Applied** column displays *Yes*.

```
Router# reload location all
Tue Aug 23 18:27:56.482 UTC
Proceed with reload? [confirm] y

Router# show hw-module profile route-scale
Tue Aug 23 18:33:47.768 UTC
-----
Knob                               Status      Applied    Action
-----
Route-Scale                         Configured   Yes         None
```

```
show hw-module profile route-scale
```



## Transport Stack Commands

This chapter describes the Cisco IOS XR software commands used to configure and monitor features related to the transport stack ( Nonstop Routing, Stream Control Transmission Protocol (SCTP), NSR, TCP, User Datagram Protocol (UDP), and RAW. Any IP protocol other than TCP or UDP is known as a *RAW* protocol.

For detailed information about transport stack concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Command Reference for Cisco 8000 Series Routers*

- [clear nsr ncd client, on page 473](#)
- [clear nsr ncd queue, on page 475](#)
- [clear nsr npl, on page 477](#)
- [clear raw statistics pcb, on page 481](#)
- [clear tcp nsr client, on page 483](#)
- [clear tcp nsr pcb, on page 484](#)
- [clear tcp nsr session-set, on page 486](#)
- [clear tcp nsr statistics client, on page 487](#)
- [clear tcp nsr statistics pcb, on page 489](#)
- [clear tcp nsr statistics session-set, on page 491](#)
- [clear tcp nsr statistics summary, on page 493](#)
- [clear tcp pcb, on page 495](#)
- [clear tcp statistics, on page 498](#)
- [clear udp statistics, on page 500](#)
- [forward-protocol udp, on page 502](#)
- [nsr process-failures switchover, on page 504](#)
- [service tcp-small-servers, on page 505](#)
- [service udp-small-servers, on page 506](#)
- [show nsr ncd client, on page 507](#)
- [show nsr ncd queue, on page 509](#)
- [show raw brief, on page 511](#)
- [show raw detail pcb, on page 513](#)
- [show raw extended-filters, on page 515](#)
- [show raw statistics, on page 517](#)
- [show tcp brief, on page 519](#)
- [show tcp detail, on page 521](#)
- [show tcp dump-file, on page 522](#)
- [show tcp extended-filters, on page 523](#)

- [show tcp nsr brief](#), on page 525
- [show tcp nsr client brief](#), on page 527
- [show tcp nsr detail client](#), on page 528
- [show tcp nsr detail endpoint](#), on page 530
- [show tcp nsr detail pcb](#), on page 531
- [show tcp nsr detail session-set](#), on page 534
- [show tcp nsr session-set brief](#), on page 536
- [show tcp nsr statistics client](#), on page 538
- [show tcp nsr statistics npl](#), on page 540
- [show tcp nsr statistics pcb](#), on page 542
- [show tcp nsr statistics session-set](#), on page 544
- [show tcp nsr statistics summary](#), on page 546
- [show tcp packet-trace](#), on page 549
- [show tcp pak-rate](#), on page 551
- [show tcp statistics](#), on page 553
- [show udp brief](#), on page 555
- [show udp detail pcb](#), on page 557
- [show udp extended-filters](#), on page 559
- [show udp statistics](#), on page 560
- [tcp dump-file convert](#), on page 562
- [tcp mss](#), on page 564
- [tcp path-mtu-discovery](#), on page 565
- [tcp selective-ack](#), on page 566
- [tcp synwait-time](#), on page 567
- [tcp timestamp](#), on page 568
- [tcp window-size](#), on page 569

# clear nsr ncd client

To clear the counters of a specified client or all the clients of nonstop routing (NSR) Consumer Demuxer (NCD), use the **clear nsr ncd client** command in XR EXEC mode.

```
clear nsr ncd client {PID value | all} [location node-id]
```

Syntax Description		
	<i>PID value</i>	Process ID value of the client in which counters need to be cleared. The range is from 0 to 4294967295.
	<b>all</b>	Clears the counters for all NCD clients.
	<b>location node-id</b>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** The default value for the *node-id* argument is the current node in which the command is being executed. The *PID value* argument does not have a default value.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried. The active and standby instances of some NSR-capable applications communicate through two queues, and these applications are multiplexed onto these queues. NSR consumer demuxer (NCD) is a process that provides the demuxing services on the receiver side.

You can use the **clear nsr ncd client** command to troubleshoot traffic issues. If you clear the existing counters, it can help you to monitor the delta changes.

Task ID	Task ID	Operations
	transport	execute

**Examples** The following example shows how to clear all the counters for all NCD clients:

```
RP/0/RP0/CPU0:router# clear nsr ncd client all
RP/0/RP0/CPU0:router# show nsr ncd client all

Client PID                               : 3874979
Client Protocol                           : TCP
Client Instance                           : 1
Total packets received                    : 0
Total acks received                       : 0
Total packets/acks accepted               : 0
Errors in changing packet ownership       : 0
Errors in setting application offset      : 0
```

```
Errors in enqueueing to client      : 0
Time of last clear                  : Sun Jun 10 14:43:44 20
```

```
RP/0/RP0/CPU0:router# show nsr ncd client brief
```

Pid	Protocol	Instance	Total Packets	Total Acks	Accepted Packets/Acks
3874979	TCP	1	0	0	0



# clear nsr ncd queue

To clear the counters for the nonstop routing (NSR) Consumer Demuxer (NCD) queue, use the **clear nsr ncd queue** command in XR EXEC mode.

```
clear nsr ncd queue {all | high | low} [location node-id]
```

Syntax Description	all	Clears the counters for all the NCD queues.
	high	Clears the counters for the high-priority NCD queue.
	low	Clears the counters the low-priority NCD queue.
	<b>location node-id</b>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	execute

## Examples

The following example shows how to clear the counters for all the NCD queues:

```
RP/0/RP0/CPU0:router# clear nsr ncd queue all
RP/0/RP0/CPU0:router# show nsr ncd queue all

Queue Name                               : NSR_LOW
Total packets received                   : 0
Total packets accepted                   : 0
Errors in getting datagram offset        : 0
Errors in getting packet length          : 0
Errors in calculating checksum            : 0
Errors due to bad checksum                : 0
Errors in reading packet data             : 0
Errors due to bad NCD header              : 0
Drops due to a non-existent client        : 0
Errors in changing packet ownership       : 0
Errors in setting application offset      : 0
Errors in enqueueing to client            : 0
Time of last clear                        : Sun Jun 10 14:44:38 2007
```

## clear nsr ncd queue

```

Queue Name                : NSR_HIGH
Total packets received    : 0
Total packets accepted    : 0
Errors in getting datagram offset : 0
Errors in getting packet length : 0
Errors in calculating checksum : 0
Errors due to bad checksum : 0
Errors in reading packet data : 0
Errors due to bad NCD header : 0
Drops due to a non-existent client : 0
Errors in changing packet ownership : 0
Errors in setting application offset : 0
Errors in enqueueing to client : 0
Time of last clear       : Sun Jun 10 14:44:38 2007

```

```
RP/0/RP0/CPU0:router# show nsr ncd queue brief
```

Queue	Total Packets	Accepted Packets
NSR_LOW	0	0
NSR_HIGH	0	0

# clear nsr npl

To clear NSR NPL wheel statistics for a given client and instance, use the **clear nsr npl** command in XR EXEC mode.

```
clear nsr npl client client-name instance client-instance-number wheels
```

```
[ wheel-ID | [ location node-id ] ]
```

**Table 63: Syntax Description**

<b>npl</b>	Clear NSR NPL wheel statistics for a given client and instance as specified.
<b>wheels</b>	Displays client's wheel information.
<i>wheel-id</i>	(Optional) Displays client's wheel information with respect to the specified wheel-id.
<b>location</b> <i>node-id</i>	(Optional) Displays information for the designated node.

## Command Default

The location defaults to the current node in which the command is executing.

## Command Mode

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

Though this command is used to clear NSR NPL statistics for a given client instance and/or for a given wheel id, this command can also be used for debugging purpose to measure delta.

## Task ID

Task ID	Operations
transport	execute

Use the **show nsr npl client bgp instance 0 wheels** command for checking counters:

```
Router# show nsr npl client bgp instance 0 wheels
NPL wheel '1' information
-----
Wheel initialized, wheel ID: 1
Total msgs sent: 13, total acks received: 13
Last sequence number: 26
Total msgs received: 6, total acks sent: 6

Retransmission information
-----
```

```
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0
```

```
Out of order information
```

```
-----
ISN: 1, Next expected seq: 7, Max limit: 30
Last ISN update time: 'May 11 18:57:46.452.333'
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0
```

```
NPL wheel '2' information
```

```
-----
Wheel initialized, wheel ID: 2
Total msgs sent: 0, total acks received: 0
Last sequence number: 0
Total msgs received: 0, total acks sent: 0
```

```
Retransmission information
```

```
-----
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0
```

```
Out of order information
```

```
-----
ISN: 0, Next expected seq: 0, Max limit: 30
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0
```

```
NPL wheel '3' information
```

```
-----
Wheel initialized, wheel ID: 3
Total msgs sent: 0, total acks received: 0
Last sequence number: 0
Total msgs received: 0, total acks sent: 0
```

```
Retransmission information
```

```
-----
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0
```

```
Out of order information
```

```
-----
ISN: 0, Next expected seq: 0, Max limit: 30
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0
```

```
NPL wheel '4' information
```

```
-----
Wheel initialized, wheel ID: 4
Total msgs sent: 0, total acks received: 0
Last sequence number: 0
Total msgs received: 0, total acks sent: 0
```

```
Retransmission information
```

```
-----
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0
```

```

Out of order information
-----
ISN: 0, Next expected seq: 0, Max limit: 30
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0

```

Use the **clear nsr npl client bgp instance 0 wheels** command to clear counters.

```
Router# clear nsr npl client bgp instance 0 wheels
```

Now, use the show nsr npl client bgp instance 0 wheels command again for checking counters. You can see the cleared counters highlighted.

```
Router# show nsr npl client bgp instance 0 wheels
```

```

NPL wheel '1' information
-----
Wheel initialized, wheel ID: 1
Total msgs sent: 0, total acks received: 0
Last sequence number: 26
Total msgs received: 0, total acks sent: 0

Retransmission information
-----
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0

Out of order information
-----
ISN: 1, Next expected seq: 7, Max limit: 30
Last ISN update time: 'May 11 18:57:46.452.333'
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0

```

```

NPL wheel '2' information
-----
Wheel initialized, wheel ID: 2
Total msgs sent: 0, total acks received: 0
Last sequence number: 0
Total msgs received: 0, total acks sent: 0

```

```

Retransmission information
-----
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0

```

```

Out of order information
-----
ISN: 0, Next expected seq: 0, Max limit: 30
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0

```

```

NPL wheel '3' information
-----
Wheel initialized, wheel ID: 3
Total msgs sent: 0, total acks received: 0
Last sequence number: 0
Total msgs received: 0, total acks sent: 0

```

```

Retransmission information
-----

```

```
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0

Out of order information
-----
ISN: 0, Next expected seq: 0, Max limit: 30
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0

NPL wheel '4' information
-----
Wheel initialized, wheel ID: 4
Total msgs sent: 0, total acks received: 0
Last sequence number: 0
Total msgs received: 0, total acks sent: 0

Retransmission information
-----
Total msgs retransmitted: 0, timeouts: 0
Num of entries in the queue: 0

Out of order information
-----
ISN: 0, Next expected seq: 0, Max limit: 30
Total msgs reassembled: 0
Total msgs drops: 0
Num of entries in the queue: 0
```

# clear raw statistics pcb

To clear statistics for a single RAW connection or for all RAW connections, use the **clear raw statistics pcb** command in XR EXEC mode.

```
clear raw statistics pcb {allpcb-address} [locationnode-id]
```

Syntax Description	all	Clears statistics for all RAW connections.
	<i>pcb-address</i>	Clears statistics for a specific RAW connection.
	<b>location</b> <i>node-id</i>	(Optional) Clears statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **all** keyword to clear all RAW connections. To clear a specific RAW connection, enter the protocol control block (PCB) address of the RAW connection. Use the **show raw brief** command to obtain the PCB address.

Use the **location** keyword and *node-id* argument to clear RAW statistics for a designated node.

Task ID	Task ID	Operations
	transport	execute

## Examples

The following example shows how to clear statistics for a RAW connection with PCB address 0x80553b0:

```
RP/0/RP0/CPU0:router# clear raw statistics pcb 0x80553b0
RP/0/RP0/CPU0:router# show raw statistics pcb 0x80553b0

Statistics for PCB 0x80553b0
Send: 0 packets received from application
0 xipc pulse received from application
0 packets sent to network
0 packets failed getting queued to network
Rcvd: 0 packets received from network
0 packets queued to application
0 packets failed queued to application
```

The following example shows how to clear statistics for all RAW connections:

```
RP/0/RP0/CPU0:router# clear raw statistics pcb all
RP/0/RP0/CPU0:router# show raw statistics pcb all
```

```
Statistics for PCB 0x805484c
Send: 0 packets received from application
0 xipc pulse received from application
0 packets sent to network
0 packets failed getting queued to network
Rcvd: 0 packets received from network
0 packets queued to application
0 packets failed queued to application
```

```
Statistics for PCB 0x8054f80
Send: 0 packets received from application
0 xipc pulse received from application
0 packets sent to network
0 packets failed getting queued to network
Rcvd: 0 packets received from network
0 packets queued to application
0 packets failed queued to application
```

```
Statistics for PCB 0x80553b0
Send: 0 packets received from application
0 xipc pulse received from application
0 packets sent to network
0 packets failed getting queued to network
Rcvd: 0 packets received from network
0 packets queued to application
0 packets failed queued to application
```



# clear tcp nsr client

To bring the nonstop routing (NSR) down on all the sessions that are owned by the specified client, use the **clear tcp nsr client** command in XR EXEC mode.

```
clear tcp nsr client {ccb-address | all} [location node-id]
```

Syntax Description		
	<i>ccb-address</i>	Client Control Block (CCB) of the NSR client.
	<b>all</b>	Specifies all the clients.
	<b>location</b> <i>node-id</i>	(Optional) Displays client information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** The location defaults to the current node in which the command is executing.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried. The output of the **show tcp nsr client** command is used to locate the CCB of the desired client. Use the **clear tcp nsr client** command to gracefully bring down NSR session that are owned by one client or all clients. In addition, the **clear tcp nsr client** command is used as a work around if the activity on the sessions freezes.

Task ID	Task ID	Operations
	transport	execute

## Examples

The following example shows that the nonstop routing (NSR) client is cleared for 0x482afacc. The two sessions had NSR already up before executing the **clear tcp nsr client** command. NSR is no longer up after executing the **clear tcp nsr client** command.

```
RP/0/RP0/CPU0:router# show tcp nsr client brief

CCB          Proc Name   Instance   Sets      Sessions/NSR Up Sessions
0x482c10e0   mpls_ldp    1          2         3/1
0x482afacc   mpls_ldp    2          1         2/2

RP/0/RP0/CPU0:router# clear tcp nsr client 0x482afacc
RP/0/RP0/CPU0:router# show tcp nsr client brief

CCB          Proc Name   Instance   Sets      Sessions/NSR Up Sessions
0x482c10e0   mpls_ldp    1          2         3/1
0x482afacc   mpls_ldp    2          1         2/0
```

## clear tcp nsr pcb

To bring the nonstop routing (NSR) down on a specified connection or all connections, use the **clear tcp nsr pcb** command in XR EXEC mode.

```
clear tcp nsr pcb {pcb-address | all} [location node-id]
```

Syntax Description	
pcb-address	PCB address range for the specific connection information. 0 to ffffffff. For example, the address range can be 0x482a4e20.
all	Specifies all the connections.
location node-id	(Optional) Displays connection information for the designated node. The node-id argument is entered in the rack/slot/module notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried. The output of the **show tcp nsr brief** command is used to locate the Protocol Control Block (PCB) of a desired connection.

Task ID	Task ID	Operations
	transport	execute

**Examples** The following example shows that the information for TCP connections is cleared:

```
RP/0/RP0/CPU0:router# show tcp nsr brief

Wed Dec 2 20:35:47.467 PST
-----
Node: 0/RP0/CPU0
-----
PCB          VRF-ID      Local Address      Foreign Address  NSR(US/DS)
0x00007f9e3c028538 0x60000000 3.3.3.3:646       5.5.5.5:17931   NA/Up
0x00007f9e3c021fb8 0x60000000 3.3.3.3:646       4.4.4.4:29301   NA/Up
0x00007f9e3c007248 0x60000000 3.3.3.3:646       12.1.105.2:32877 NA/Up
0x00007f9e3c010c78 0x60000000 3.3.3.3:646       6.6.6.6:56296   NA/Up
0x00007f9de4001798 0x60000000 3.3.3.3:12888     2.2.2.2:646     NA/Up
0x00007f9e3c04a338 0x60000000 3.3.3.13:179      2.2.2.13:13021  NA/Up
0x00007f9e3c026c78 0x60000000 3.3.3.3:179       4.4.4.4:15180   NA/Up
0x00007f9e3c019b38 0x60000000 3.3.3.3:179       8.8.8.8:21378   NA/Up
0x00007f9e3c029df8 0x60000000 3.3.3.22:179      2.2.2.22:24482  NA/Up
0x00007f9e3c064538 0x60000000 3.3.3.14:179      2.2.2.14:27569  NA/Up
```

```
0x00007f9e3c041008 0x60000000 3.3.3.25:179 2.2.2.25:29654 NA/Up
```

```
RP/0/RP0/CPU0:router# clear tcp nsr pcb 0x00007f9e3c028538
```

```
RP/0/RP0/CPU0:router# clear tcp nsr pcb 0x00007f9e3c021fb8
```

```
RP/0/RP0/CPU0:router# show tcp nsr brief
```

```
Wed Dec 2 20:35:47.467 PST
```

```
-----  
Node: 0/RP0/CPU0  
-----
```

PCB	VRF-ID	Local Address	Foreign Address	NSR(US/DS)
0x00007f9e3c028538	0x60000000	3.3.3.3:646	5.5.5.5:17931	NA/Down
0x00007f9e3c021fb8	0x60000000	3.3.3.3:646	4.4.4.4:29301	NA/Down
0x00007f9e3c007248	0x60000000	3.3.3.3:646	12.1.105.2:32877	NA/Up
0x00007f9e3c010c78	0x60000000	3.3.3.3:646	6.6.6.6:56296	NA/Up
0x00007f9de4001798	0x60000000	3.3.3.3:12888	2.2.2.2:646	NA/Up
0x00007f9e3c04a338	0x60000000	3.3.3.13:179	2.2.2.13:13021	NA/Up
0x00007f9e3c026c78	0x60000000	3.3.3.3:179	4.4.4.4:15180	NA/Up
0x00007f9e3c019b38	0x60000000	3.3.3.3:179	8.8.8.8:21378	NA/Up
0x00007f9e3c029df8	0x60000000	3.3.3.22:179	2.2.2.22:24482	NA/Up
0x00007f9e3c064538	0x60000000	3.3.3.14:179	2.2.2.14:27569	NA/Up
0x00007f9e3c041008	0x60000000	3.3.3.25:179	2.2.2.25:29654	NA/Up

## clear tcp nsr session-set

To clear the nonstop routing (NSR) on all the sessions in the specified session-set or all session sets, use the **clear tcp nsr session-set** command in XR EXEC mode.

```
clear tcp nsr session-set { sscb-address | all } [location node-id]
```

Syntax Description	
<i>sscb-address</i>	Session-Set Control Block (SSCB) address range for the specific session set information. 0 to ffffffff. For example, the address range can be 0x482a4e20.
<b>all</b>	Specifies all the session sets.
<b>location</b> <i>node-id</i>	(Optional) Displays session set information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried. The output of the **show tcp nsr session-set brief** command is used to locate the SSCB of the desired session-set.

Task ID	Task ID	Operations
	transport	execute

### Examples

The following example shows that the information for the session sets is cleared:

```
RP/0/RP0/CPU0:router# show tcp nsr client brief

CCB          Proc Name      Instance  Sets      Sessions/NSR Up Sessions
0x482b5ee0   mpls_ldp       1         1         10/10

RP/0/RP0/CPU0:router# clear tcp nsr client 0x482b5ee0
RP/0/RP0/CPU0:router# show tcp nsr client brief

CCB          Proc Name      Instance  Sets      Sessions/NSR Up Sessions
0x482b5ee0   mpls_ldp       1         1         10/0
```

# clear tcp nsr statistics client

To clear the nonstop routing (NSR) statistics of the client, use the **clear tcp nsr statistics client** command in XR EXEC mode.

```
clear tcp nsr statistics client {ccb-address | all} [location node-id]
```

Syntax Description		
<i>ccb-address</i>		Client Control Block (CCB) of the desired client. For example, the address range can be 0x482a4e20.
<b>all</b>		Specifies all the clients.
<b>location</b> <i>node-id</i>	(Optional)	Displays client information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	execute

## Examples

The following example shows that the statistics for the NSR clients is cleared:

```
Router# show tcp nsr statistics client all
-----
Node: 0/0/CPU0
-----
=====
CCB: 0xed30cd58
Name: bgp, Job ID: 1085
Connected at: Mon May 11 17:29:20 2020

Notification Statistics :      Queued      Failed      Delivered      Dropped
Init-Sync Done          :          4          0          4          0
Replicated Session Ready:          0          0          0          0
Operational Down       :          3          0          3          0
Init-Sync Stop Reading  :          3          0          3          0
```

Last clear at: Never Cleared

Router# **clear tcp nsr statistics client all**

Router# **show tcp nsr statistics client all**

```
-----
Node: 0/0/CPU0
-----
```

```
=====
CCB: 0xed30cd58
```

Name: bgp, Job ID: 1085

Connected at: Mon May 11 17:29:20 2020

Notification Statistics :	Queued	Failed	Delivered	Dropped
Init-Sync Done :	0	0	0	0
Replicated Session Ready:	0	0	0	0
Operational Down :	0	0	0	0
Init-Sync Stop Reading :	0	0	0	0

Last clear at: Mon May 11 19:08:56 2020

# clear tcp nsr statistics pcb

To clear the nonstop routing (NSR) statistics for TCP connections, use the **clear tcp nsr statistics pcb** command in XR EXEC mode.

**clear tcp nsr statistics pcb** {*pcb-address* | **all**} [**location** *node-id*]

Syntax Description	
<i>pcb-address</i>	PCB address range for the specific connection information. 0 to ffffffff. For example, the address range can be 0x482a4e20.
<b>all</b>	Specifies all the connections.
<b>location</b> <i>node-id</i>	(Optional) Displays connection information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	execute

**Examples** The following example shows that the NSR statistics for TCP connections is cleared:

```
RP/0/RP0/CPU0:router# show tcp nsr statistics pcb 0x482d14c8
=====
PCB 0x482d14c8
Number of times NSR went up: 1
Number of times NSR went down: 0
Number of times NSR was disabled: 0
Number of times switch-over occurred : 0
IACK RX Message Statistics:
    Number of iACKs dropped because SSO is not up           : 0
    Number of stale iACKs dropped                           : 1070
    Number of iACKs not held because of an immediate match  : 98
TX Message Statistics:
    Data transfer messages:
        Sent 317, Dropped 0, Data (Total/Avg.) 2282700/7200
        Rcvd 0
        Success           : 0
        Dropped (Trim)    : 0
    Segmentation instructions:
        Sent 1163, Dropped 0, Units (Total/Avg.) 4978/4
```

## clear tcp nsr statistics pcb

```

Rcvd 0
  Success          : 0
  Dropped (Trim)  : 0
  Dropped (TCP)   : 0
NACK messages:
  Sent 0, Dropped 0
  Rcvd 0
    Success          : 0
    Dropped (Data snd): 0
Cleanup instructions :
  Sent 8, Dropped 0
  Rcvd 0
    Success          : 0
    Dropped (Trim)  : 0
Last clear at: Never cleared

```

```
RP/0/RP0/CPU0:router# clear tcp nsr statistics pcb 0x482d14c8
```

```
RP/0/RP0/CPU0:router# show tcp nsr statistics pcb 0x482d14c8
```

```

=====
PCB 0x482d14c8
Number of times NSR went up: 0
Number of times NSR went down: 0
Number of times NSR was disabled: 0
Number of times switch-over occurred : 0
IACK RX Message Statistics:
  Number of iACKs dropped because SSO is not up          : 0
  Number of stale iACKs dropped                          : 0
  Number of iACKs not held because of an immediate match : 0
TX Message Statistics:
  Data transfer messages:
    Sent 0, Dropped 0, Data (Total/Avg.) 0/0
    Rcvd 0
      Success          : 0
      Dropped (Trim)  : 0
  Segmentation instructions:
    Sent 0, Dropped 0, Units (Total/Avg.) 0/0
    Rcvd 0
      Success          : 0
      Dropped (Trim)  : 0
      Dropped (TCP)   : 0
  NACK messages:
    Sent 0, Dropped 0
    Rcvd 0
      Success          : 0
      Dropped (Data snd): 0
  Cleanup instructions :
    Sent 0, Dropped 0
    Rcvd 0
      Success          : 0
      Dropped (Trim)  : 0
Last clear at: Thu Aug 16 18:32:12 2007

```



# clear tcp nsr statistics session-set

To clear the nonstop routing (NSR) statistics for session sets, use the **clear tcp nsr statistics session-set** command in XR EXEC mode.

```
clear tcp nsr statistics session-set {sscb-address | all} [location node-id]
```

Syntax Description	
<i>sscb-address</i>	Session-Set Control Block (SSCB) address range for the specific session set information. 0 to ffffffff. For example, the address range can be 0x482a4e20.
<b>all</b>	Specifies all the session sets.
<b>location</b> <i>node-id</i>	(Optional) Displays session set information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes the proper task IDs. If you suspect user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	execute

## Examples

The following example shows that the NSR statistics for session sets is cleared:

```
RP/0/RP0/CPU0:router# show tcp nsr statistics session-set all

=====Session Set Stats =====
SSCB 0x482b6684, Set ID: 1
Number of times init-sync was attempted :3
Number of times init-sync was successful :3
Number of times init-sync failed       :0
Number of times switch-over occurred   :0
Last clear at: Never Cleared

RP/0/RP0/CPU0:router# clear tcp nsr statistics session-set all
RP/0/RP0/CPU0:router# show tcp nsr statistics session-set all

=====Session Set Stats =====
SSCB 0x482b6684, Set ID: 1
Number of times init-sync was attempted :0
```

```
Number of times init-sync was successful :0
Number of times init-sync failed       :0
Number of times switch-over occurred   :0
Last clear at: Thu Aug 16 18:37:00 2007
```

# clear tcp nsr statistics summary

To clear the nonstop routing (NSR) statistics summary, use the **clear tcp nsr statistics summary** command in XR EXEC mode.

```
clear tcp nsr statistics summary [location node-id]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays statistics summary information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.				
<b>Command Default</b>	If a value is not specified, the current RP in which the command is being executed is taken as the location.				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	The <b>location</b> keyword is used so that active and standby TCP instances are independently queried.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>execute</td> </tr> </tbody> </table>	Task ID	Operations	transport	execute
Task ID	Operations				
transport	execute				

## Examples

The following example shows how to clear the summary statistics:

```
Router# show tcp nsr statistics client all

-----
Node: 0/0/CPU0
-----

=====
CCB: 0xed30cd58
Name: bgp, Job ID: 1085
Connected at: Mon May 11 17:29:20 2020

Notification Statistics :      Queued      Failed  Delivered  Dropped
Init-Sync Done          :          4          0          0          0
Replicated Session Ready:          0          0          0          0
Operational Down        :          3          0          0          0
Init-Sync Stop Reading  :          3          0          0          0
Last clear at: Never Cleared

Router# clear tcp nsr statistics client all

Router# show tcp nsr statistics client all

-----
Node: 0/0/CPU0
-----
```

```
=====
CCB: 0xed30cd58
Name: bgp, Job ID: 1085
Connected at: Mon May 11 17:29:20 2020

Notification Statistics :      Queued      Failed  Delivered  Dropped
Init-Sync Done          :          0          0          0          0
Replicated Session Ready:          0          0          0          0
Operational Down        :          0          0          0          0
Init-Sync Stop Reading  :          0          0          0          0
Last clear at: Mon May 11 19:08:56 2020
```

# clear tcp pcb

To clear TCP protocol control block (PCB) connections, use the **clear tcp pcb** command in XR EXEC mode.

```
clear tcp pcb {pcb-address | all} [location node-id]
```

Syntax Description		
<i>pcb-address</i>		Clears the TCP connection at the specified PCB address.
<b>all</b>		Clears all open TCP connections.
<b>location</b> <i>node-id</i>	(Optional)	Clears the TCP connection for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **clear tcp pcb** command is useful for clearing hung TCP connections. Use the `show tcp brief` command to find the PCB address of the connection you want to clear.

If the **clear tcp pcb all** command is used, the software does not clear a TCP connection that is in the listen state. If a specific PCB address is specified, then a connection in listen state is cleared.

Task ID	Task ID	Operations
	transport	execute

## Examples

The following example shows that the TCP connection at PCB address 0x00007f7da4007eb8 is cleared:

```
Router# show tcp brief
```

PCB	State	VRF-ID	Recv-Q	Send-Q	Local Address	Foreign Address
0x00007f7d4c011d38	LISTEN	0x60000000	0	0	:::22	:::0
0x00007f7d4c00cf68	LISTEN	0x00000000	0	0	:::22	:::0
0x00007f7d4c00c6a8	LISTEN	0x60000000	0	0	:::179	:::0
0x00007f7d4c007db8	LISTEN	0x00000000	0	0	:::179	:::0
0x00007f7d7003fab8	CLOSED	0x60000000	0	0	:::0	:::0
0x00007f7d7003afa8	CLOSED	0x00000000	0	0	:::0	:::0

## clear tcp pcb

```

0x00007f7d4c035378      0x60000000      0      0      133.1.2.2:25032      133.1.2.1:179
    ESTAB
0x00007f7da4007eb8 0x60000000      0      0      10.86.188.84:179      10.86.188.99:28148
    ESTAB
0x00007f7d700405e8      0x60000000      0      0      32.32.32.32:54157
149.127.13.12:57000    SYNSENT
0x00007f7da400cfe8      0x60000000      0      0      10.86.188.84:23
173.39.52.160:60586    ESTAB
0x00007f7d4c011aa8      0x60000000      0      0      0.0.0.0:22           0.0.0.0:0
    LISTEN
0x00007f7d70030218      0x00000000      0      0      0.0.0.0:22           0.0.0.0:0
    LISTEN
0x00007f7d70021da8      0x60000000      0      0      0.0.0.0:23           0.0.0.0:0
    LISTEN
0x00007f7d4c006858      0x600000002     0      0      0.0.0.0:23           0.0.0.0:0
    LISTEN
0x00007f7d4c000fd8      0x00000000      0      0      0.0.0.0:23           0.0.0.0:0
    LISTEN
0x00007f7d7003a858      0x60000000      0      0      0.0.0.0:646          0.0.0.0:0
    LISTEN
0x00007f7d70035cd8      0x00000000      0      0      0.0.0.0:646          0.0.0.0:0
    LISTEN
0x00007f7d7002fa08      0x60000000      0      0      0.0.0.0:179          0.0.0.0:0
    LISTEN
0x00007f7d70028b28      0x00000000      0      0      0.0.0.0:179          0.0.0.0:0
    LISTEN
0x00007f7d70023188      0x00000000      0      0      0.0.0.0:0            0.0.0.0:0
    CLOSED

```

Router# **clear tcp pcb 0x00007f7da4007eb8**

Router# show tcp brief

PCB	State	VRF-ID	Recv-Q	Send-Q	Local Address	Foreign Address
0x00007f7d4c011d38	LISTEN	0x60000000	0	0	:::22	:::0
0x00007f7d4c00cf68	LISTEN	0x00000000	0	0	:::22	:::0
0x00007f7d4c00c6a8	LISTEN	0x60000000	0	0	:::179	:::0
0x00007f7d4c007db8	LISTEN	0x00000000	0	0	:::179	:::0
0x00007f7d7003fab8	CLOSED	0x60000000	0	0	:::0	:::0
0x00007f7d7003afa8	CLOSED	0x00000000	0	0	:::0	:::0
<b>0x00007f7d4c035378</b>	ESTAB	0x60000000	0	0	133.1.2.2:25032	133.1.2.1:179
<b>0x00007f7da400cfe8</b>	ESTAB	0x60000000	0	0	10.86.188.84:23	173.39.52.160:60586
0x00007f7d4c011aa8	LISTEN	0x60000000	0	0	0.0.0.0:22	0.0.0.0:0
0x00007f7d70030218	LISTEN	0x00000000	0	0	0.0.0.0:22	0.0.0.0:0
0x00007f7d70021da8	LISTEN	0x60000000	0	0	0.0.0.0:23	0.0.0.0:0
0x00007f7d4c006858	LISTEN	0x600000002	0	0	0.0.0.0:23	0.0.0.0:0
0x00007f7d4c000fd8	LISTEN	0x00000000	0	0	0.0.0.0:23	0.0.0.0:0
0x00007f7d7003a858	LISTEN	0x60000000	0	0	0.0.0.0:646	0.0.0.0:0
0x00007f7d70035cd8	LISTEN	0x00000000	0	0	0.0.0.0:646	0.0.0.0:0

```
LISTEN
0x00007f7d7002fa08      0x60000000      0      0      0.0.0.0:179      0.0.0.0:0
LISTEN
0x00007f7d70028b28      0x00000000      0      0      0.0.0.0:179      0.0.0.0:0
LISTEN
0x00007f7d70023188      0x00000000      0      0      0.0.0.0:0        0.0.0.0:0
CLOSED
```

# clear tcp statistics

To clear TCP statistics, use the **clear tcp statistics** command in XR EXEC mode.

```
clear tcp statistics { client | pcb { all | pcb-address } | summary} location node-id
```

## Syntax Description

<b>client</b>	(Optional) Clears statistics for all TCP clients.
<b>pcb all</b>	(Optional) Clears statistics for all TCP connections.
<b>pcb</b> <i>pcb-address</i>	Clears statistics for a specific TCP connection.
<b>summary</b>	Clears summary statistic for a specific node or connection.
<b>location</b> <i>node-id</i>	Clears TCP statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

No default behavior or values

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

Though this command is used to clear incoming and outgoing TCP packet statistics of all clients of given location, PCB, and summary statistics; this command can be used for debugging purpose to measure delta.

## Task ID

Task ID	Operations
transport	execute

## Examples

The following example shows that the statistics for the NSR clients is cleared:

```
Router# show tcp statistics client

Name      JID          IPv4-Stats          IPv6-Stats
          Sent-Packets Recv-Packets      Sent-Packets Recv-Packets
igmp      1151         5                   9                   0                   3
mld       1156         9                   4                   4                   0
pim       1157         8                   3                   5                   2
pim6     1158         9                   4                   6                   1
Router# clear tcp statistics client

Riuter# show nsr statistics client

Name      JID          IPv4-Stats          IPv6-Stats
          Sent-Packets Recv-Packets      Sent-Packets Recv-Packets
```



igmp	1151	0	0	0	0
mld	1156	0	0	0	0
pim	1157	0	0	0	0
pim6	1158	0	0	0	0

# clear udp statistics

To clear User Datagram Protocol (UDP) statistics, use the **clear udp statistics** command in XR EXEC mode.

```
clear udp statistics { client | pcb { all | pcb-address } | summary } location node-id
```

## Syntax Description

<b>client</b>	(Optional) Clears statistics for all TCP clients.
<b>pcb all</b>	Clears statistics for all UDP connections.
<b>pcb</b> <i>pcb-address</i>	Clears statistics for a specific UDP connection.
<b>summary</b>	Clears UDP summary statistics.
<b>location</b> <i>node-id</i>	(Optional) Clears UDP statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

## Command Default

No default behavior or values

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

Though this command is used to clear incoming and outgoing TCP packet statistics of all clients of given location, PCB, and summary statistics; this command can be used for debugging purpose to measure delta.

## Task ID

### Task ID Operations

```
transport execute
```

## Examples

The following example shows how to clear UDP summary statistics:

```
Router# show udp statistics summary
UDP statistics:
Rcvd: 121 Total, 121 drop, 0 no port
      0 checksum error, 0 too short
Sent: 121 Total, 0 error
0 Total forwarding broadcast packets
0 Cloned packets, 0 failed cloning
```

```
Router# clear udp statistics summary
```

```
Router# show udp statistics summary
UDP statistics:
Rcvd: 9 Total, 9 drop, 0 no port
      0 checksum error, 0 too short
Sent: 9 Total, 0 error
```

```
0 Total forwarding broadcast packets
0 Cloned packets, 0 failed cloning
```

# forward-protocol udp

To configure the system to forward any User Datagram Protocol (UDP) datagrams that are received as broadcast packets to a specified helper address, use the **forward-protocol udp** command in

XR Config mode.

To restore the system to its default condition with respect to this command, use the **no** form of this command.

**forward-protocol udp** {*port-number* | **disable** | **domain** | **nameserver** | **netbios-dgm** | **netbios-ns** | **tacacs** | **tftp**}

**no forward-protocol udp** {*port-number* | **disable** | **domain** | **nameserver** | **netbios-dgm** | **netbios-ns** | **tacacs** | **tftp**}

## Syntax Description

<b>port-number</b>	Forwards UDP broadcast packets to a specified port number. Range is 1 to 65535.
<b>disable</b>	Disables IP Forward Protocol UDP.
<b>domain</b>	Forwards UDP broadcast packets to Domain Name Service (DNS, 53).
<b>nameserver</b>	Forwards UDP broadcast packets to IEN116 name service (obsolete, 42).
<b>netbios-dgm</b>	Forwards UDP broadcast packets to NetBIOS datagram service (138).
<b>netbios-ns</b>	Forwards UDP broadcast packets to NetBIOS name service (137).
<b>tacacs</b>	Forwards UDP broadcast packets to TACACS (49).
<b>tftp</b>	Forwards UDP broadcast packets to TFTP (69).

## Command Default

**forward-protocol udp** is enabled.

## Command Modes

XR Config mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

Use the **forward-protocol udp** command to specify that UDP broadcast packets received on the incoming interface are forwarded to a specified helper address.

When you configure the **forward-protocol udp** command, you must also configure the **helper-address** command to specify a helper address on an interface. The helper address is the IP address to which the UDP datagram is forwarded. Configure the **helper-address** command with IP addresses of hosts or networking devices that can handle the service. Because the helper address is configured per interface, you must configure a helper address for each incoming interface that will be receiving broadcasts that you want to forward.

You must configure one **forward-protocol udp** command per UDP port you want to forward. The port on the packet is either port 53 (**domain**), port 69 (**tftp**), or a port number you specify.

Task ID	Task ID	Operations
	transport	read, write

### Examples

The following example shows how to specify that all UDP broadcast packets with port 53 or port 69 received on incoming HundredGigE interface 0/RP0/CPU0 are forwarded to 172.16.0.1. HundredGigE interface 0/RP0/CPU0 receiving the UDP broadcasts is configured with a helper address of 172.16.0.1, the destination address to which the UDP datagrams are forwarded.

```
RP/0/RP0/CPU0:router(config)# forward-protocol udp domain disable
RP/0/RP0/CPU0:router(config)# forward-protocol udp tftp disable
RP/0/RP0/CPU0:router(config)# interface HundredGigE 0/RP0/CPU0
RP/0/RP0/CPU0:router(config-if)# ipv4 helper-address 172.16.0.1
```

## nsr process-failures switchover

To configure failover as a recovery action for active instances to switch over to a standby route processor (RP) or a standby distributed route processor (DRP) to maintain nonstop routing (NSR), use the **nsr process-failures switchover** command in XR Config mode. To disable this feature, use the **no** form of this command.

**nsr process-failures switchover**  
**no nsr process-failures switchover**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	If not configured, a process failure of the active TCP or its applications (for example LDP, BGP, and so forth) can cause sessions to go down, and NSR is not provided.	
<b>Command Modes</b>	XR Config mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read, write
<b>Examples</b>	The following example shows how to use the <b>nsr process-failures switchover</b> command:	
	<pre>RP/0/RP0/CPU0:router(config)# nsr process-failures switchover</pre>	

## service tcp-small-servers

To enable small TCP servers such as the ECHO, use the **service tcp-small-servers** command in XR Config mode. To disable the TCP server, use the **no** form of this command.

```
service {ipv4 | ipv6} tcp-small-servers [max-servers number | no-limit] [access-list-name]
no service {ipv4 | ipv6} tcp-small-servers [max-servers number | no-limit] [access-list-name]
```

Syntax Description	Parameter	Description
	<b>ipv4</b>	Specifies IPv4 small servers.
	<b>ipv6</b>	Specifies IPv6 small servers.
	<b>max-servers</b>	(Optional) Sets the number of allowable TCP small servers.
	<i>number</i>	(Optional) Number value. Range is 1 to 2147483647.
	<b>no-limit</b>	(Optional) Sets no limit to the number of allowable TCP small servers.
	<i>access-list-name</i>	(Optional) The name of an access list.

**Command Default** TCP small servers are disabled.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The TCP small servers currently consist of three services: Discard (port 9), Echo (port 7), and Chargen (port 19). These services are used to test the TCP transport functionality. The Discard server receives data and discards it. The Echo server receives data and echoes the same data to the sending host. The Chargen server generates a sequence of data and sends it to the remote host.

Task ID	Task ID	Operations
	ipv4	read, write
	ip-services	read, write

### Examples

In the following example, small IPv4 TCP servers are enabled:

```
RP/0/RP0/CPU0:router(config)# service ipv4 tcp-small-servers max-servers 5 acl100
```

## service udp-small-servers

To enable small User Datagram Protocol (UDP) servers such as the ECHO, use the **service udp-small-servers** command in XR Config mode. To disable the UDP server, use the **no** form of this command.

```
service {ipv4 | ipv6} udp-small-servers [max-servers number | no-limit] [access-list-name]
no service {ipv4 | ipv6} udp-small-servers [max-servers number | no-limit] [access-list-name]
```

### Syntax Description

<b>ip4</b>	Specifies IPv4 small servers.
<b>ipv6</b>	Specifies IPv6 small servers.
<b>max-servers</b>	(Optional) Sets the number of allowable UDP small servers.
<i>number</i>	(Optional) Number value. Range is 1 to 2147483647.
<b>no-limit</b>	(Optional) Sets no limit to the number of allowable UDP small servers.
<i>access-list-name</i>	(Optional) Name of an access list.

### Command Default

UDP small servers are disabled.

### Command Modes

XR Config mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

The UDP small servers currently consist of three services: Discard (port 9), Echo (port 7), and Chargen (port 19). These services are used to test the UDP transport functionality. The discard server receives data and discards it. The echo server receives data and echoes the same data to the sending host. The chargen server generates a sequence of data and sends it to the remote host.

### Task ID

Task ID	Operations
ipv6	read, write
ip-services	read, write

### Examples

The following example shows how to enable small IPv6 UDP servers and set the maximum number of allowable small servers to 10:

```
RP/0/RP0/CPU0:router(config)# service ipv6 udp-small-servers max-servers 10
```



# show nsr ncd client

To display information about the clients for nonstop routing (NSR) Consumer Demuxer (NCD), use the **show nsr ncd client** command in XR EXEC mode.

```
show nsr ncd client {PID value | all | brief} [location node-id]
```

Syntax Description	
<i>PID value</i>	Process ID (PID) information for a specific client. The range is from 0 to 4294967295.
<b>all</b>	Displays detailed information about all the clients.
<b>brief</b>	Displays brief information about all the clients.
<b>location node-id</b>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

## Examples

The following sample output shows detailed information about all the clients:

```
RP/0/RP0/CPU0:router# show nsr ncd client all

Client PID                : 3874979
Client Protocol           : TCP
Client Instance           : 1
Total packets received    : 28
Total acks received       : 0
Total packets/acks accepted : 28
Errors in changing packet ownership : 0
Errors in setting application offset : 0
Errors in enqueueing to client : 0
Time of last clear        : Never cleared
```

The following sample output shows brief information about all the clients:

```
RP/0/RP0/CPU0:router# show nsr ncd client brief
```

```

Pid      Protocol  Instance  Total  Total  Accepted
                   3874979  TCP    1      28    0      28

```

This table describes the significant fields shown in the display.

**Table 64: show nsr ncd client Command Field Descriptions**

Field	Description
Client PID	Process ID of the client process.
Client Protocol	Protocol of the client process. The protocol can be either TCP, OSPF, or BGP.
Client Instance	Instance number of the client process. There can be more than one instance of a routing protocol, such as OSPF.
Total packets received	Total packets received from the partner stack on the partner route processor (RP).
Total acks received	Total acknowledgements received from the partner stack on the partner RP for the packets sent to the partner stack.
Total packets/acks accepted	Total packets and acknowledgements received from the partner stack on the partner RP.
Errors in changing packet ownership	NCD changes the ownership of the packet to that of the client before queueing the packet to the client. This counter tracks the errors, if any, in changing the ownership.
Errors in setting application offset	NCD sets the offset of the application data in the packet before queueing the packet to the client. This counter tracks the errors, if any, in setting this offset.
Errors in enqueueing to client	Counter tracks any queueing errors.
Time of last clear	Statistics last cleared by the user.

# show nsr ncd queue

To display information about the queues that are used by the nonstop routing (NSR) applications to communicate with their partner stacks on the partner route processors (RPs), use the **show nsr ncd queue** command in XR EXEC mode.

```
show nsr ncd queue {all | brief | high | low} [location node-id]
```

Syntax Description	all	Displays detailed information about all the consumer queues.
	<b>brief</b>	Displays brief information about all the consumer queues.
	<b>high</b>	Displays information about high-priority Queue and Dispatch (QAD) queues.
	<b>low</b>	Displays information about low-priority QAD queues.
	<b>location node-id</b>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows brief information about all the consumer queues:

```
RP/0/RP0/CPU0:router# show nsr ncd queue brief

      Queue          Total      Accepted
      NSR_LOW        992         992
      NSR_HIGH         0           0
```

This table describes the significant fields shown in the display.

**Table 65: show nsr ncd queue Command Field Descriptions**

Field	Description
Total Packets	Total number of packets that are received from the partner stack.

Field	Description
Accepted Packets	Number of received packets that were accepted after performing some validation tasks.
Queue	Name of queue. NSR_HIGH and NSR_LOW are the two queues. High priority packets flow on the NSR_HIGH queue. Low priority packets flow on the NSR_LOW queue.

# show raw brief

To display information about active RAW IP sockets, use the **show raw brief** command in XR EXEC mode.

```
show raw brief [location node-id]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	Protocols such as Open Shortest Path First (OSPF) and Protocol Independent Multicast (PIM) use long-lived RAW IP sockets. The <b>ping</b> and <b>traceroute</b> commands use short-lived RAW IP sockets. Use the <b>show raw brief</b> command if you suspect a problem with one of these protocols.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	transport	read
Task ID	Operations				
transport	read				

## Examples

The following is sample output from the **show raw brief** command:

```
RP/0/RP0/CPU0:router# show raw brief

PCB          Recv-Q  Send-Q  Local Address          Foreign Address  Protocol
0x805188c    0        0  0.0.0.0                0.0.0.0         2
0x8051dc8    0        0  0.0.0.0                0.0.0.0        103
0x8052250    0        0  0.0.0.0                0.0.0.0        255
```

This table describes the significant fields shown in the display.

**Table 66: show raw brief Command Field Descriptions**

Field	Description
PCB	Protocol control block address. This is the address to a structure that contains connection information such as local address, foreign address, local port, foreign port, and so on.
Recv-Q	Number of bytes in the receive queue.
Send-Q	Number of bytes in the send queue.
Local Address	Local address and local port.

Field	Description
Foreign Address	Foreign address and foreign port.
Protocol	Protocol that is using the RAW IP socket. For example, the number 2 is IGMP, 103 is PIM, and 89 is OSPF.

# show raw detail pcb

To display detailed information about active RAW IP sockets, use the **show raw detail pcb** command in XR EXEC mode.

```
show raw detail pcb {pcb-address | all} location node-id
```

Syntax Description		
	<i>pcb-address</i>	Displays statistics for a specified RAW connection.
	<b>all</b>	Displays statistics for all RAW connections.
	<b>location</b> <i>node-id</i>	Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **show raw detail pcb** command displays detailed information for all connections that use the RAW transport. Information that is displayed includes family type (for example, 2 for AF\_INET also known as IPv4), PCB address, Layer 4 (also known as transport) protocol, local address, foreign address, and any filter that is being used.

Task ID	Task ID	Operations
	transport	read

## Examples

The following is sample output from the **show raw detail pcb** command:

```
RP/0/RP0/CPU0:router# show raw detail pcb 0x807e89c
```

```
=====
PCB is 0x807e89c, Family: 2, PROTO: 89
  Local host: 0.0.0.0
  Foreign host: 0.0.0.0
```

```
Current send queue size: 0
Current receive queue size: 0
Paw socket: Yes
```

This table describes the significant fields shown in the display.

**Table 67: show raw detail pcb Command Field Descriptions**

Field	Description
JID	Job ID of the process that created the socket.
Family	Network protocol. IPv4 is 2; IPv6 is 26.
PCB	Protocol control block address.
L4-PROTO	Layer 4 (also known as transport) protocol.
LADDR	Local address.
FADDR	Foreign address.
ICMP error filter mask	If an ICMP filter is being set, output in this field has a nonzero value.
LPTS socket options	If an LPTS option is being set, output in this field has a nonzero value.
Packet Type Filters	Packet filters that are being set for a particular RAW socket, including the number of packets for that filter type. Multiple filters can be set.



## show raw extended-filters

To display information about active RAW IP sockets, use the **show raw extended-filters** command in XR EXEC mode.

```
show raw extended-filters {interface-filter location node-id | location node-id | paktype-filter
location node-id}
```

Syntax Description	Parameter	Description
	<b>interface-filter</b>	Displays the protocol control blocks (PCBs) with configured interface filters.
	<b>location</b> <i>node-id</i>	Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>paktype-filter</b>	Displays the PCBs with configured packet type filters.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **show raw extended-filters** command displays detailed information for all connections that use the RAW transport. Information that is displayed includes family type (for example, 2 for AF\_INET also known as IPv4), PCB address, Layer 4 (also known as transport) protocol, local address, foreign address, and any filter that is being used.

Task ID	Task ID	Operations
	transport	read

**Examples** The following is sample output from the **show raw extended-filters** command:

```
RP/0/RP0/CPU0:router# show raw extended-filters location 0/RP0/CPU0

Wed Dec 2 20:50:58.389 PST
-----
JID: 1102
Family: 10
VRF: 0x60000000
PCB: 0x7fc4c4001f18
L4-proto: 255
Lport: 0
Fport: 0
```

This table describes the significant fields shown in the display.

**Table 68: show raw extended-filters Output Command Field Descriptions**

Field	Description
JID	Job ID of the process that created the socket.
Family	Network protocol. IPv4 is 2; IPv6 is 26.
PCB	Protocol control block address.
L4-PROTO	Layer 4 (also known as transport) protocol.
LADDR	Local address.
FADDR	Foreign address.
ICMP error filter mask	If an ICMP filter is being set, output in this field has a nonzero value.
LPTS socket options	If an LPTS option is being set, output in this field has a nonzero value.
Packet Type Filters	Packet filters that are being set for a particular RAW socket, including the number of packets for that filter type. Multiple filters can be set.

## show raw statistics

To display statistics for a single RAW connection or for all RAW clients or connections, use the **show raw statistics pcb** command in XR EXEC mode.

```
show raw statistics { [ | pcb | { all | pcb-connection } ] | [ | clients | { location
node-id } ] }
```

Syntax Description	clients	Displays statistics for all RAW clients.
	pcb-address	Displays statistics for a specified RAW connection.
	all	Displays statistics for all the clients.
	location node-id	Displays RAW statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **show raw statistics pcb all** command to display all RAW connections. If a specific RAW connection is desired, then enter the protocol control block (PCB) address of that RAW connection. Use the **show raw brief** command to obtain the PCB address.

Use the **location** keyword and *node-id* argument to display RAW statistics for a designated node.

Use the **show raw statistics pcb clients** This command is used to display incoming and outgoing (IPv4 and IPv6) packet statistics of RAW clients

Task ID	Task ID	Operations
	transport	read

### Examples

In the following example, statistics for a RAW connection with PCB address 0x80553b0 are displayed:

```
Router# show raw statistics pcb 0x80553b0

Statistics for PCB 0x80553b0
Send: 0 packets received from application
0 xipc pulse received from application
0 packets sent to network
0 packets failed getting queued to network
Rcvd: 0 packets received from network
0 packets queued to application
```

```
0 packets failed queued to application
```

In the following example, statistics for all RAW connections are displayed:

```
Router# show raw statistics pcb all

Statistics for PCB 0x805484c
Send: 0 packets received from application
0 xipc pulse received from application
0 packets sent to network
0 packets failed getting queued to network
Rcvd: 0 packets received from network
0 packets queued to application
0 packets failed queued to application
```

In the following example, statistics for all RAW clients are displayed:

```
Router# show raw statistics clients location 0/RP0/CPU0

Name          JID          IPv4-Stats          IPv6-Stats
              Sent-Packets  Recv-Packets       Sent-Packets  Recv-Packets
igmp          1151         0                   0              0
mld           1156         0                   0              0
pim           1157         0                   0              0
pim6          1158         0                   0              0
```

This table describes the significant fields shown in the display.

**Table 69: show raw statistics pcb Command Field Descriptions**

Field	Description
Send:	Statistics in this section refer to packets sent from an application to RAW.
Vrfid	VPN routing and forwarding (VRF) identification (vrfid) number.
xipc pulse received from application	Number of notifications sent from applications to RAW.
packets sent to network	Number of packets sent to the network.
packets failed getting queued to network	Number of packets that failed to get queued to the network.
Rcvd:	Statistics in this section refer to packets received from the network.
packets queued to application	Number of packets queued to an application.
packets failed queued to application	Number of packets that failed to get queued to an application.

# show tcp brief

To display a summary of the TCP connection table, use the **show tcp brief** command in XR EXEC mode.

```
show tcp brief [location node-id]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read

## Examples

The following is sample output from the **show tcp brief** command:

```
Router# show tcp brief

TCP CB      Recv-Q  Send-Q  Local Address           Foreign Address         State
0x80572a8   0        0       0.0.0.0:513             0.0.0.0:0               LISTEN
0x8056948   0        0       0.0.0.0:23              0.0.0.0:0               LISTEN
0x8057b60   0        3       10.8.8.2:23            10.8.8.1:1025           ESTAB
```

This table describes the significant fields shown in the display.

**Table 70: show tcp brief Command Field Descriptions**

Field	Description
TCP CB	Memory address of the TCP control block.
Recv-Q	Number of bytes waiting to be read.
Send-Q	Number of bytes waiting to be sent.
Local Address	Source address and port number of the packet.
Foreign Address	Destination address and port number of the packet.

Field	Description
State	State of the TCP connection.

# show tcp detail

To display the details of the TCP connection table, use the **show tcp detail** command in XR EXEC mode.

**show tcp detail pcb** [*value* | **all**]

<b>Syntax Description</b>	<b>pcb</b>	Displays TCP connection information.
	<i>value</i>	Displays a specific connection information. Range is from 0 to ffffffff.
	<b>all</b>	Displays all connections information.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read

## Examples

The following is sample output from the **show tcp detail pcb all** command:

```
Router# show tcp detail pcb all location 0/RP0/CPU0
Wed Dec 2 20:52:40.256 PST

=====
Connection state is ESTAB, I/O status: 0, socket status: 0
Established at Wed Dec 2 20:25:42 2015

PCB 0x7f9dec013cc8, SO 0x7f9dec013858, TCPCB 0x7f9dec013f28, vrfid 0x60000000,
Pak Prio: Medium, TOS: 192, TTL: 1, Hash index: 506
Local host: 2011:1:120::1, Local port: 25093 (Local App PID: 5714)
Foreign host: 2011:1:120::2, Foreign port: 179

Current send queue size in bytes: 0 (max 24576)
Current receive queue size in bytes: 0 (max 32768) mis-ordered: 0 bytes
Current receive queue size in packets: 0 (max 0)

Timer      Starts   Wakeups   Next(msec)
Retrans    193      60        0
Sendwind   0        0         0
```

# show tcp dump-file

To display the details of the PCB state from a dump file, use the **show tcp dump-file** command in XR EXEC mode.

```
show tcp dump-file { dump-file-name | all | list | { ipv4-address-of-dumpfiles |
ipv6-address-of-dumpfiles | all } } { location node-id }
```

Syntax Description	all	Displays all connections information.
	<b>location</b> <i>node-id</i>	Displays RAW statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Although the basic use of this command is to provide information about list of all TCP dump files, details of a specific or all TCP dumpfile files, you can also use this command can be used for debugging purpose or to monitor flow of TCP packets for a TCP connection.

Task ID	Task ID	Operations
	transport	read

**Examples** The following is sample output from the **show tcp dumpfile all location 0/RP0/CPU0** command:

```
Router# show tcp dumpfile list all location 0/RP0/CPU0

total 4
-rw-r--r-- 1 rpathark eng 3884 May 11 20:16 80_80_80_80.26355.179.c1.15892
```



# show tcp extended-filters

To display the details of the TCP extended-filters, use the **show tcp extended-filters** command in XR EXEC mode.

```
show tcp extended-filters [location node-id]  
peer-filter [location node-id]
```

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.				
	<b>peer-filter</b> (Optional) Displays connections with peer filter configured.				
<b>Command Default</b>	No default behavior or values				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	transport	read
Task ID	Operations				
transport	read				

## Examples

The following is sample output from the **show tcp extended-filters** command for a specific location (0/RP0/CPU0):

```
RP/0/RP0/CPU0:router# show tcp extended-filters location 0/RP0/CPU0  
  
Total Number of matching PCB's in database: 3  
-----  
JID: 135  
Family: 2  
PCB: 0x4826c5dc  
L4-proto: 6  
Lport: 23  
Fport: 0  
Laddr: 0.0.0.0  
Faddr: 0.0.0.0  
ICMP error filter mask: 0x12  
  
Flow Type: n/s  
-----  
  
-----  
JID: 135  
Family: 2
```

## show tcp extended-filters

```
PCB: 0x4826dd8c
L4-proto: 6
Lport: 23
Fport: 59162
Laddr: 12.31.22.10
Faddr: 223.255.254.254
ICMP error filter mask: 0x12
```

```
Flow Type: n/s
-----
```

```
-----
JID: 135
Family: 2
PCB: 0x4826cac0
L4-proto: 6
Lport: 23
Fport: 59307
Laddr: 12.31.22.10
Faddr: 223.255.254.254
ICMP error filter mask: 0x12
```

```
Flow Type: n/s
-----
```

# show tcp nsr brief

To display the key nonstop routing (NSR) state of TCP connections on different nodes, use the **show tcp nsr brief** command in XR EXEC mode.

**show tcp nsr brief** [**location** *node-id*]

**Syntax Description** **location** *node-id* (Optional) Displays information for all TCP sessions for the designated node. The *node-id* argument is entered in the *rack/slot/module* notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows the administrative and operational NSR state of each TCP session in the NSR column:

```
RP/0/RP0/CPU0:router# show tcp nsr brief
Wed Dec 2 20:35:47.467 PST
-----
Node: 0/RP0/CPU0
-----
PCB                VRF-ID    Local Address    Foreign Address  NSR(US/DS)
0x00007f9e3c028538 0x60000000 3.3.3.3:646     5.5.5.5:17931   NA/Up
0x00007f9e3c021fb8 0x60000000 3.3.3.3:646     4.4.4.4:29301   NA/Up
0x00007f9e3c007248 0x60000000 3.3.3.3:646     12.1.105.2:32877 NA/Up
0x00007f9e3c010c78 0x60000000 3.3.3.3:646     6.6.6.6:56296   NA/Up
0x00007f9e4001798 0x60000000 3.3.3.3:12888   2.2.2.2:646     NA/Up
0x00007f9e3c04a338 0x60000000 3.3.3.13:179    2.2.2.13:13021  NA/Up
0x00007f9e3c026c78 0x60000000 3.3.3.3:179     4.4.4.4:15180   NA/Up
0x00007f9e3c019b38 0x60000000 3.3.3.3:179     8.8.8.8:21378   NA/Up
0x00007f9e3c029df8 0x60000000 3.3.3.22:179    2.2.2.22:24482  NA/Up
0x00007f9e3c064538 0x60000000 3.3.3.14:179    2.2.2.14:27569  NA/Up
0x00007f9e3c041008 0x60000000 3.3.3.25:179    2.2.2.25:29654  NA/Up
```

This table describes the significant fields shown in the display.

**Table 71: show tcp nsr brief Command Field Descriptions**

<b>Field</b>	<b>Description</b>
PCB	Protocol Control Block (PCB).
Local Address	Local address and port of the TCP connection.
Foreign Address	Foreign address and port of the TCP connection.
NSR	Current operational NSR state of this TCP connection.
RevOnly	If yes, the TCP connection is replicated only in the receive direction. Some applications may need to replicate a TCP connection that is only in the receive direction.

# show tcp nsr client brief

To display brief information about the state of nonstop routing (NSR) for TCP clients on different nodes, use the **show tcp nsr client brief** command in XR EXEC mode.

**show tcp nsr client brief** [**location** *node-id*]

**Syntax Description** **location** *node-id* (Optional) Displays brief client information for the designated node. The *node-id* argument is entered in the *rack/slot/module* notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output is from the **show tcp nsr client brief** command:

```
RP/0/RP0/CPU0:router# show tcp nsr client brief location 0/1/CPU0

CCB          Proc Name      Instance Sets Sessions/NSR Up Sessions
0x482bf378   mpls_ldp      1         1         1/1
0x482bd32c   mpls_ldp      2         1         0/0
```

This table describes the significant fields shown in the display.

**Table 72: show tcp nsr client brief Command Field Descriptions**

Field	Description
CCB	Client Control Block (CCB). Unique ID to identify the client.
Proc Name	Name of the client process.
Instance	Instance is identified as the instance number of the client process because there can be more than one instance for a routing application.
Sets	Set number is identified as the ID of the session-set.
Sessions/NSR Up Sessions	Total sessions in the set versus the number of the sessions in which NSR is up.

# show tcp nsr detail client

To display detailed information about the nonstop routing (NSR) clients, use the **show tcp nsr detail client** command in XR EXEC mode.

```
show tcp nsr detail client {ccb-address | all} [location node-id]
```

Syntax Description	
<i>ccb-address</i>	Client Control Block (CCB) address range for the specific client information. 0 to ffffffff. For example, the address range can be 0x482a4e20.
<b>all</b>	Displays nonstop routing (NSR) details all the clients.
<b>location</b> <i>node-id</i>	(Optional) Displays client information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows detailed information for all clients:

```
Router# show tcp nsr detail client all
```

```
=====
CCB 0x482b25d8, Proc Name mpls_ldp
Instance ID 1, Job ID 360
Number of session-sets 2
Number of sessions 3
Number of NSR Synced sessions 1
Connected at: Sun Jun 10 07:05:31 2007
Registered for notifications: Yes
```

```
=====
CCB 0x4827fd30, Proc Name mpls_ldp
Instance ID 2, Job ID 361
Number of session-sets 1
Number of sessions 2
Number of NSR Synced sessions 2
Connected at: Sun Jun 10 07:05:54 2007
Registered for notifications: Yes
```

```
=====  
Router# show tcp nsr detail client all location 1  
Router# show tcp nsr detail client all location 0/1/CPU0
```

```
=====  
CCB 0x482bf378, Proc Name mpls_ldp  
Instance ID 1, Job ID 360  
Number of session-sets 1  
Number of sessions 1  
Number of NSR Synced sessions 1  
Connected at: Sun Jun 10 07:05:41 2007  
Registered for notifications: Yes
```

```
=====  
CCB 0x482bd32c, Proc Name mpls_ldp  
Instance ID 2, Job ID 361  
Number of session-sets 1  
Number of sessions 2  
Number of NSR Synced sessions 2  
Connected at: Sun Jun 10 07:06:01 2007  
Registered for notifications: Yes
```

# show tcp nsr detail endpoint

To display detailed information about the nonstop routing (NSR) end-points, use the **show tcp nsr detail endpoint** command in XR EXEC mode.

```
show tcp nsr detail endpoint [ location { all | node-id } ]
```

Syntax Description	end-point	Displays detailed info about the SSO/NSR local and partner endpoints.
	location { all   node-id }	(Optional) Displays client information for the designated node or all the nodes.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Apart from using this command to show local and partner node end-point information in details, you can also use this command can be used in debugging of TCP NSR issues.

## Examples

The following sample output shows detailed information for all end-points:

```
Router# show tcp nsr detail endpoint

-----
                        Node: 0/RP0/CPU0
-----

Local endpoint:
  Node id: 0x2000
  Endp handl: 0x7f6f7400c6a8

  Endp len: 46
  Bytestream:
0xaf2f6465762f69702f7463705f73736f10804018b2080c8e4c0b3aa8daa80128abcb130b5f9138ac81808
  Service name: /dev/ip/tcp_sso/8192
```



# show tcp nsr detail pcb

To display detailed information about the nonstop routing (NSR) state of TCP connections, use the **show tcp nsr detail pcb** command in XR EXEC mode.

**show tcp nsr detail pcb** {*pcb-address* | **all**} [**location** *node-id*]

Syntax Description	
<i>pcb-address</i>	PCB address range for the specific connection information. 0 to ffffffff. For example, the address range can be 0x482c6b8c.
<b>all</b>	Specifies all the connections.
<b>location</b> <i>node-id</i>	(Optional) Displays connection information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows the complete details for NSR for all locations:

```
RP/0/RP0/CPU0:router# show tcp nsr detail pcb all location 0/0/cpu0

=====
PCB 0x482b6b0c, Client PID: 2810078
Local host: 5.1.1.1, Local port: 646
Foreign host: 5.1.1.2, Foreign port: 31466
SSCB 0x482bc80c, Client PID 2810078
Node Role: Active, Protected by: 0/1/CPU0, Cookie: 0x00001000

NSR State: Up, Rcv Path Replication only: No
Replicated to standby: Yes
Synchronized with standby: Yes
FSSN: 3005097735, FSSN Offset: 0

Sequence number of last or current initial sync: 1181461961
Initial sync started at: Sun Jun 10 07:52:41 2007
Initial sync ended at: Sun Jun 10 07:52:41 2007

Number of incoming packets currently held: 1
```

## show tcp nsr detail pcb

Pak#	SeqNum	Len	AckNum
1	3005097735	0	1172387202

Number of iACKS currently held: 0

```
=====
PCB 0x482c2920, Client PID: 2810078
Local host: 5.1.1.1, Local port: 646
Foreign host: 5.1.1.2, Foreign port: 11229
SSCB 0x482bb3bc, Client PID 2810078
Node Role: Active, Protected by: 0/1/CPU0, Cookie: 0x00001000
```

```
NSR State: Down, Rcv Path Replication only: No
Replicated to standby: No
Synchronized with standby: No
NSR-Down Reason: Initial sync was aborted
NSR went down at: Sun Jun 10 11:55:38 2007
```

```
Initial sync in progress: No
Sequence number of last or current initial sync: 1181476338
Initial sync error, if any: 'ip-tcp' detected the 'warning' condition 'Initial sync operation
timed out'
Source of initial sync error: Local TCP
Initial sync started at: Sun Jun 10 11:52:18 2007
Initial sync ended at: Sun Jun 10 11:55:38 2007
```

Number of incoming packets currently held: 0

Number of iACKS currently held: 0

```
=====
PCB 0x482baea0, Client PID: 2810078
Local host: 5.1.1.1, Local port: 646
Foreign host: 5.1.1.2, Foreign port: 41149
SSCB 0x482bb3bc, Client PID 2810078
Node Role: Active, Protected by: 0/1/CPU0, Cookie: 0x00001000
```

```
NSR State: Down, Rcv Path Replication only: No
Replicated to standby: No
Synchronized with standby: No
NSR-Down Reason: Initial sync was aborted
NSR went down at: Sun Jun 10 11:55:38 2007
```

```
Initial sync in progress: No
Sequence number of last or current initial sync: 1181476338
Initial sync error, if any: 'ip-tcp' detected the 'warning' condition 'Initial sync operation
timed out'
Source of initial sync error: Local TCP
Initial sync started at: Sun Jun 10 11:52:18 2007
Initial sync ended at: Sun Jun 10 11:55:38 2007
```

Number of incoming packets currently held: 0

Number of iACKS currently held: 0

```
=====
PCB 0x482c35ac, Client PID: 2859233
Local host: 5.1.1.1, Local port: 8889
Foreign host: 5.1.1.2, Foreign port: 14008
SSCB 0x4827fea8, Client PID 2859233
Node Role: Active, Protected by: 0/1/CPU0, Cookie: 0x0000001c
```

```
NSR State: Up, Rcv Path Replication only: No
```

Replicated to standby: Yes  
Synchronized with standby: Yes  
FSSN: 2962722865, FSSN Offset: 0

Sequence number of last or current initial sync: 1181474373  
Initial sync started at: Sun Jun 10 11:19:33 2007  
Initial sync ended at: Sun Jun 10 11:19:33 2007

Number of incoming packets currently held: 0

Number of iACKS currently held: 0

```
=====
PCB 0x482c2f10, Client PID: 2859233
Local host: 5:1::1, Local port: 8889
Foreign host: 5:1::2, Foreign port: 40522
SSCB 0x4827fea8, Client PID 2859233
Node Role: Active, Protected by: 0/1/CPU0, Cookie: 0x0000001b
```

NSR State: Up, Rcv Path Replication only: No  
Replicated to standby: Yes  
Synchronized with standby: Yes  
FSSN: 3477316401, FSSN Offset: 0

Sequence number of last or current initial sync: 1181474373  
Initial sync started at: Sun Jun 10 11:19:33 2007  
Initial sync ended at: Sun Jun 10 11:19:33 2007

Number of incoming packets currently held: 0

Number of iACKS currently held: 0

## show tcp nsr detail session-set

To display the detailed information about the nonstop routing (NSR) state of the session sets on different nodes, use the **show tcp nsr detail session-set** command in XR EXEC mode.

```
show tcp nsr detail session-set {sscb-address | all} [location node-id]
```

<b>Syntax Description</b>	<i>sscb-address</i>	Session-Set Control Block (SSCB) address range for the specific session set information. 0 to ffffffff. For example, the address range can be 0x482c6b8c.
	<b>all</b>	Specifies all the session sets.
	<b>location</b> <i>node-id</i>	(Optional) Displays information for session sets for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read

**Examples** The following sample output shows all the session sets:

```
RP/0/RP0/CPU0:router# show tcp nsr detail session-set all

=====
SSCB 0x482bc80c, Client PID: 2810078
Set Id: 1, Addr Family: IPv4
Role: Active, Protected by: 0/1/CPU0, Well known port: 646
Sessions: total 1, synchronized 1
Initial sync in progress: No
    Sequence number of last or current initial sync: 1181461961
    Number of sessions in the initial sync: 1
    Number of sessions already synced: 1
    Number of sessions that failed to sync: 0
    Initial sync started at: Sun Jun 10 07:52:41 2007
    Initial sync ended   at: Sun Jun 10 07:52:41 2007
=====

SSCB 0x482bb3bc, Client PID: 2810078
Set Id: 2, Addr Family: IPv4
Role: Active, Protected by: 0/1/CPU0, Well known port: 646
```

```
Sessions: total 2, synchronized 0
Initial sync in progress: Yes
  Sequence number of last or current initial sync: 1181476338
  Initial sync timer expires in 438517602 msec
  Number of sessions in the initial sync: 2
  Number of sessions already synced: 0
  Number of sessions that failed to sync: 0
  Initial sync started at: Sun Jun 10 11:52:18 2007
```

```
=====
SSCB 0x4827fea8, Client PID: 2859233
Set Id: 1, Addr Family: IPv6
Role: Active, Protected by: 0/1/CPU0, Well known port: 8889
Sessions: total 2, synchronized 2
Initial sync in progress: No
  Sequence number of last or current initial sync: 1181474373
  Number of sessions in the initial sync: 2
  Number of sessions already synced: 2
  Number of sessions that failed to sync: 0
  Initial sync started at: Sun Jun 10 11:19:33 2007
  Initial sync ended   at: Sun Jun 10 11:19:33 2007
```

## show tcp nsr session-set brief

To display brief information about the session sets for the nonstop routing (NSR) state on different nodes, use the **show tcp nsr session-set brief** command in XR EXEC mode.

**show tcp nsr session-set brief** [**location** *node-id*]

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) Displays information for session sets for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

<b>Command Default</b>	If a value is not specified, the current RP in which the command is being executed is taken as the location.
------------------------	--

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	The <b>location</b> keyword is used so that active and standby TCP instances are independently queried. A session set consists of a subset of the application's session in which the subset is protected by only one standby node. The TCP NSR state machine operates with respect to these session sets.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read

**Examples**

The following sample output shows all the session sets that are known to the TCP instance:

```
RP/0/RP0/CPU0:router# show tcp nsr session-set brief
-----
Node: 0/RP0/CPU0
-----
SSCB          Client      LocalAPP      Set-Id Family  State  Protect-Node  Total/US/DS
0x00007f9e14022508  4776    mpls_ldp#1    646   IPv4    SAYN   0/RP1/CPU0    5/0/5
0x00007f9e14022778  4776    mpls_ldp#1    647   IPv6    SAYN   0/RP1/CPU0    0/0/0
0x00007f9e14025018  5714      bgp#1         1     IPv4    SAYN   0/RP1/CPU0    58/0/58
0x00007f9e140257a8  5714      bgp#1         2     IPv6    SAYN   0/RP1/CPU0    2/0/2
```

The following sample output shows brief information about the session sets for location 0/RP0/CPU0:

```
RP/0/RP0/CPU0:router# show tcp nsr session-set brief location 0/RP0/CPU0
-----
Node: 0/RP0/CPU0
-----
SSCB          Client      LocalAPP      Set-Id Family  State  Protect-Node  Total/US/DS
0x00007f9e14022508  4776    mpls_ldp#1    646   IPv4    SAYN   0/RP1/CPU0    5/0/5
0x00007f9e14022778  4776    mpls_ldp#1    647   IPv6    SAYN   0/RP1/CPU0    0/0/0
```

```

0x00007f9e14025018 5714      bgp#1      1  IPv4  SAYN  0/RP1/CPU0  58/0/58
0x00007f9e140257a8 5714      bgp#1      2  IPv6  SAYN  0/RP1/CPU0   2/0/2

```

This table describes the significant fields shown in the display.

**Table 73: show tcp nsr session-set brief Command Field Descriptions**

Field	Description
SSCB	Unique ID for Session-Set Control Block (SSCB) to identify a session-set of a client.
Client	PID of the client process.
LocalAPP	Name and instance number of the client process.
Set-Id	ID of the session-set.
Family	Address family of the sessions added to the session set for IPv4 or IPv6.
Role	Role of the TCP stack for active or standby.
Protect-Node	Node that is offering the protection, for example, partner node.
Total/Synced	Total number of sessions in the set versus the sessions that have been synchronized.

# show tcp nsr statistics client

To display the nonstop routing (NSR) statistics for the clients, use the **show tcp nsr statistics client** command in XR EXEC mode.

**show tcp nsr statistics client** {*ccb-address* | **all**} [**location** *node-id*]

Syntax Description	
<i>ccb-address</i>	Client Control Block (CCB) address range for the specific statistics information for the client. 0 to ffffffff. For example, the address range can be 0x482c6b8c.
<b>all</b>	Specifies all the statistics for the clients.
<b>location</b> <i>node-id</i>	(Optional) Displays statistics for the client for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows all the statistics for the client:

```
RP/0/RP0/CPU0:router# show tcp nsr statistics client all

=====
CCB: 0x482b25d8
Name: mpls_ldp, Job ID: 360
Connected at: Thu Jan 1 00:00:00 1970

Notification Stats      : Queued  Failed  Delivered  Dropped
Init-Sync Done          :      0      0           0         0
Replicated Session Ready:      0      0           0         0
Operational Down        :      0      0           0         0
Last clear at: Sun Jun 10 12:19:12 2007

=====
CCB: 0x4827fd30
Name: mpls_ldp, Job ID: 361
Connected at: Sun Jun 10 07:05:54 2007
```



```
Notification Stats      : Queued  Failed  Delivered  Dropped
Init-Sync Done         :      1     0         1         0
Replicated Session Ready:      0     0         0         0
Operational Down       :      0     0         0         0
Last clear at: Never Cleared
```

# show tcp nsr statistics npl

To display the nonstop routing (NSR) summary statistics across all TCP sessions of NPL clients, use the **show tcp nsr statistics npl** command in XR EXEC mode.

```
show tcp nsr statistics npl [ location { all | node-id } ]
```

## Syntax Description

**location** *node-id* (Optional) Displays information for the summary statistics for the designated node. The *node-id* argument is entered in the *rack/slot/module* notation.

## Command Default

If a value is not specified, the current RP in which the command is being executed is taken as the location.

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 7.0.12	This command was introduced.

## Usage Guidelines

Although this command gives information about packet sent, received, dropped at NSR NPL based on queue priority, it is mostly used for debugging.

## Task ID

### Task ID Operations

transport read

## Examples

The following sample output shows the summary statistics across all TCP sessions of NPL clients:

```
Router# show tcp nsr statistics npl location all
-----
Node: 0/0/CPU0
-----

Prio Queue: Low
-----
Msg-type                               Number
-----
Sent Data                               :          74
Recv Data                               :           4

****Drop Stats****

Msg-type           Drop-reason           Number
-----
Send Drop:         <None>
Recv Drop:         <None>

Prio Queue: High
```

```

-----
Msg-type                                     Number
-----
Sent Data      :                               13
Sent Ack       :                               7

Recv Data      :                               11
Recv Ack       :                               11

```

\*\*\*\*Drop Stats\*\*\*\*

```

Msg-type           Drop-reason           Number
-----
Send Drop:        <None>
Recv Drop:        <None>

```

```

-----
Node: 0/2/CPU0
-----

```

Prio Queue: Low

```

-----
Msg-type                                     Number
-----
Sent Data      :                               4

Recv Data      :                               74

```

\*\*\*\*Drop Stats\*\*\*\*

```

Msg-type           Drop-reason           Number
-----
Send Drop:        <None>
Recv Drop:        <None>

```

Prio Queue: High

```

-----
Msg-type                                     Number
-----
Sent Data      :                               11
Sent Ack       :                               11

Recv Data      :                               13
Recv Ack       :                               7

```

\*\*\*\*Drop Stats\*\*\*\*

```

Msg-type           Drop-reason           Number
-----
Send Drop:        <None>
Recv Drop:        <None>

```

## show tcp nsr statistics pcb

To display the nonstop routing (NSR) statistics for a given Protocol Control Block (PCB), use the **show tcp nsr statistics pcb** command in XR EXEC mode.

```
show tcp nsr statistics pcb {pcb-address | all} [location node-id]
```

Syntax Description		
<i>pcb-address</i>	PCB address range for the specific connection information. 0 to ffffffff. For example, the address range can be 0x482c6b8c.	
<b>all</b>	Specifies all the connection statistics.	
<b>location</b> <i>node-id</i>	(Optional) Displays connection statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.	

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows all NSR statistics:

```
RP/0/RP0/CPU0:router# show tcp nsr statistics pcb all

-----
Node: 0/RP0/CPU0
-----

=====
PCB 0x7f9e3c028538
Number of times NSR went up: 1
Number of times NSR went down: 0
Number of times NSR was disabled: 0
Number of times switch-over occurred : 0
IACK RX Message Statistics:
Number of iACKs dropped because session is not replicated : 0
Number of iACKs dropped because init-sync is in 1st phase : 1
Number of stale iACKs dropped : 0
Number of iACKs not held because of an immediate match : 0
TX Message Statistics:
Data transfer messages:
Sent 47, Dropped 0, Data (Total/Avg.) 23021748224/489824430
```

```
IOVAllocs : 0
Rcvd 0
Success : 0
Dropped (Trim) : 0
Dropped (Buf. OOS): 0
Segmentation instructions:
Sent 105, Dropped 0, Units (Total/Avg.) 1862270976/17735914
Rcvd 0
Success : 0
Dropped (Trim) : 0
Dropped (TCP) : 0
NACK messages:
Sent 0, Dropped 0
Rcvd 0
Success : 0
Dropped (Data snd): 0
Cleanup instructions :
Sent 46, Dropped 0
Rcvd 0
Success : 0
Dropped (Trim) : 0
Last clear at: Never Cleared
```

## show tcp nsr statistics session-set

To display the nonstop routing (NSR) statistics for a session set, use the **show tcp nsr statistics session-set** command in XR EXEC mode.

```
show tcp nsr statistics session-set {sscb-address | all} [location node-id]
```

Syntax Description		
<i>sscb-address</i>	Session-Set Control Block (SSCB) address range for the specific session set information for the statistics. 0 to ffffffff. For example, the address range can be 0x482b3444.	
<b>all</b>	Specifies all the session sets for the statistics.	
<b>location</b> <i>node-id</i>	(Optional) Displays session set information for the statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.	

**Command Default** If a value is not specified, the current RP in which the command is being executed is taken as the location.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** The **location** keyword is used so that active and standby TCP instances are independently queried.

Task ID	Task ID	Operations
	transport	read

**Examples** The following sample output shows all session set information for the statistics:

```
RP/0/RP0/CPU0:router# show tcp nsr statistics session-set all
-----
Node: 0/RP0/CPU0
-----
=====Session Set Stats =====
SSCB 0x7f9e14022508, Set ID: 646
Number of times init-sync was attempted :0
Number of times init-sync was successful :0
Number of times init-sync failed :0
Number of times switch-over occurred :0
Number of times NSR has been reset :0
Last clear at: Wed Dec 2 20:44:48 2015

=====Session Set Stats =====
SSCB 0x7f9e14022778, Set ID: 647
Number of times init-sync was attempted :0
Number of times init-sync was successful :0
```

```
Number of times init-sync failed :0
Number of times switch-over occurred :0
Number of times NSR has been reset :0
Last clear at: Wed Dec 2 20:44:48 2015
```

```
=====  
=====Session Set Stats =====  
SSCB 0x7f9e14025018, Set ID: 1  
Number of times init-sync was attempted :0  
Number of times init-sync was successful :0  
Number of times init-sync failed :0  
Number of times switch-over occurred :0  
Number of times NSR has been reset :0  
Last clear at: Wed Dec 2 20:44:48 2015
```

```
=====  
=====Session Set Stats =====  
SSCB 0x7f9e140257a8, Set ID: 2  
Number of times init-sync was attempted :0  
Number of times init-sync was successful :0  
Number of times init-sync failed :0  
Number of times switch-over occurred :0  
Number of times NSR has been reset :0  
Last clear at: Wed Dec 2 20:44:48 2015
```

# show tcp nsr statistics summary

To display the nonstop routing (NSR) summary statistics across all TCP sessions, use the **show tcp nsr statistics summary** command in XR EXEC mode.

**show tcp nsr statistics summary** [**location** *node-id*]

<b>Syntax Description</b>	<b>location</b> <i>node-id</i> (Optional) Displays information for the summary statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.				
<b>Command Default</b>	If a value is not specified, the current RP in which the command is being executed is taken as the location.				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	The <b>location</b> keyword is used so that active and standby TCP instances are independently queried.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	transport	read
Task ID	Operations				
transport	read				

## Examples

The following sample output shows the summary statistics for all TCP sessions:

```
Router# show tcp nsr statistics summary

=====Summary Stats=====
Last clear at: Never Cleared
Notif Statistics:
Queued Failed Delivered Dropped
Init-sync Done : 7 0 7 0
Replicated Session Ready: 0 0 0 0
Operational Down : 0 0 0 0
Init-sync Stop Reading : 7 0 7 0
Clients Statistics:
Number of Connected Clients :2
Number of Disconnected Clients :0
Number of Current Clients :2
Session Sets Statistics:
Number of Created Session Sets :4
Number of Destroyed Session Sets:0
Number of Current Session Sets :4
Sessions Statistics:
Number of Added Sessions :65
Number of Deleted Sessions :0
Number of Current Sessions :65
InitSync Statistics:
Number of times init-sync was attempted :7
Number of times init-sync was successful :7
Number of times init-sync failed :0
```



```
Held packets and iacks Statistics:
Number of packets held by Active TCP :67
Number of held packets dropped by Active TCP :0
Number of iacks held by Active TCP :0
Number of held iacks dropped by Active TCP :0
Number of iacks sent by Standby TCP :0
Number of iacks received by Active TCP :0
QAD Msg Statistics:
Number of dropped messages from partner TCP stack(s) : 0
Number of unknown messages from partner TCP stack(s) : 0
Number of messages accepted from partner TCP stack(s) : 1341
Number of stale dropped messages from partner TCP stack(s) : 0
Number of messages sent to partner TCP stack(s) : 22480
Number of messages failed to be sent to partner TCP stack(s): 0
RX Msg Statistics:
Number of iACKs dropped because there is no PCB : 0
Number of iACKs dropped because there is no datapath SCB : 0
Number of iACKs dropped because session is not replicated : 0
Number of iACKs dropped because init-sync is in 1st phase : 1056
Number of stale iACKs dropped : 17
Number of iACKs not held because of an immediate match : 0
Number of held packets dropped because of errors : 0
TX Message Statistics:
Data transfer messages:
Sent 4533, Dropped 0
IOVAllocs : 0
Rcvd 0
Success : 0
Dropped (PCB) : 0
Dropped (SCB-DP) : 0
Dropped (Trim) : 0
Dropped (Buf. OOS): 0
Segmentation instructions:
Sent 14124, Dropped 0
Rcvd 0
Success : 0
Dropped (PCB) : 0
Dropped (SCB-DP) : 0
Dropped (Trim) : 0
Dropped (TCP) : 0
NACK messages:
Sent 0, Dropped 0
Rcvd 0
Success : 0
Dropped (PCB) : 0
Dropped (SCB-DP) : 0
Dropped (Data snd): 0
Cleanup instructions :
Sent 3608, Dropped 0
Rcvd 0
Success : 0
Dropped (PCB) : 0
Dropped (SCB-DP) : 0
Dropped (Trim) : 0
Audit Message Statistics:
Mark Session set messages:
Sent 0, Dropped 0
Rcvd 0
Dropped : 0
Audit Session messages:
Sent 0, Dropped 0
Rcvd 0
Dropped : 0
Sweep Session set messages:
```

```
Sent 0, Dropped 0
Rcvd 0
Dropped : 0
Session set audit response messages:
Sent 0, Dropped 0
Rcvd 0
Dropped : 0
Mark Session set ack messages:
Sent 0, Dropped 0
Rcvd 0
Dropped : 0
Mark Session set nack messages:
Sent 0, Dropped 0
Rcvd 0
Dropped : 0
Number of audit operations aborted: 0
```

# show tcp packet-trace

To display the details of the packet traces of a PCB, use the **show tcp packet-trace** command in XR EXEC mode.

```
show tcp packet-trace pcb-name location node-id
```

<b>Syntax Description</b>	<i>pcb-name</i>	Displays packet traces for the specified PCB.
	<b>location</b> <i>node-id</i>	(Optional) Clears the TCP connection for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Apart from using this command to provide packet trace of a particular TCP PCB, you can also use this command for debugging purposes or to monitor flow of TCP packets for a TCP connection if you configure the pak-rate for the TCP PCB.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read

## Examples

The following is sample output from the **show tcp packet-trace 0x00007f7d4c035378** command:

```
Router# show tcp packet-trace 0x00007f7d4c035378
=====
Packet traces for: PCB 0x7f7d4c035378, 133.1.2.2:25032 <-> 133.1.2.1:179, VRF 0x60000000

May 14 05:50:59.463>R --A--- SEQ 2125620474 ACK 3607271508 LEN      0 WIN 31533 (pak:
0x63bfeedb, line: 3855)
      snduna 3607271489 sndnxt 3607271508 sndmax 3607271508 sndwnd 31552
      rcvnxt 2125620474 rcvad  2125653242 rcvwnd 32768
      ao_option 0
May 14 05:50:59.463>D --A--- SEQ 2125620474 ACK 3607271508 LEN      0 WIN 31533 (pak:
0x63bfeedb, line: 932)
      snduna 3607271508 sndnxt 3607271508 sndmax 3607271508 sndwnd 31533
      rcvnxt 2125620474 rcvad  2125653242 rcvwnd 32768
      ao_option 0
May 14 05:51:15.719>R --A--- SEQ 2125620474 ACK 3607271508 LEN  1460 WIN 31533 (pak:
0x63bfeedb, line: 3855)
      snduna 3607271508 sndnxt 3607271508 sndmax 3607271508 sndwnd 31533
      rcvnxt 2125620474 rcvad  2125653242 rcvwnd 32768
.
.
```

## show tcp packet-trace

```
.  
. .  
May 14 05:57:45.953>R --A-P- SEQ 2125717138 ACK 3607271622 LEN 496 WIN 31419 (pak:  
0x63bffcbb, line: 3855)  
    snduna 3607271622 sndnxt 3607271622 sndmax 3607271622 sndwnd 31419  
    rcvnxt 2125717138 rcvadv 2125748446 rcvwnd 31308  
    ao_option 0  
May 14 05:57:45.953>S --A--- SEQ 3607271622 ACK 2125717634 LEN 0 WIN 128 (pak:  
0x63bffcbb, line: 2688)  
    snduna 3607271622 sndnxt 3607271622 sndmax 3607271622 sndwnd 31419  
    rcvnxt 2125717634 rcvadv 2125750402 rcvwnd 32768  
    ao_option 0  
May 14 05:57:45.953>R (app read)  
    snduna 3607271622 sndnxt 3607271622 sndmax 3607271622 sndwnd 31419  
    rcvnxt 2125717634 rcvadv 2125750402 rcvwnd 32768  
    ao_option 0
```

# show tcp pak-rate

To display the details of the packet rate of a PCB, for example, number of packets received, maximum packet-size in the last 30 seconds, number of packets allocated, and number of packets freed, use the **show tcp pak-rate** command in XR EXEC mode if 'pak-rate tcp stats-start is configured.

```
show tcp pak-rate { mem-summary | stats } { location node-id }
```

Syntax Description	mem-summary	stats	location node-id
	Displays the memory summary of the TCP packet rate of a PCB.	Displays the statistics of the TCP packet rate of a PCB.	(Optional) Clears the TCP connection for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

Task ID	Task ID	Operations
	transport	read

**Examples** The following is sample output from the **show tcp pak-rate mem-summary location 0/RP0/CPU0** command:

```
Router# show tcp pak-rate mem-summary location 0/0/CPU0
```

Family	Index	Num Allocs	Num frees
IPv4	0	0	0
IPv4	1	0	0
IPv4	2	0	0
IPv4	3	0	0
IPv4	4	0	0
IPv4	5	0	0
IPv4	6	0	0
IPv4	7	0	0
IPv4	8	0	0
IPv4	9	0	0
IPv6	0	0	0
IPv6	1	0	0
IPv6	2	0	0
IPv6	3	0	0
IPv6	4	0	0
IPv6	5	0	0

```
show tcp pak-rate
```

```
IPv6      6      0      0
IPv6      7      0      0
IPv6      8      0      0
IPv6      9      0      0
```

# show tcp statistics

To display TCP statistics, use the **show tcp statistics** command in XR EXEC mode.

```
show tcp statistics {client | pcb {all pcb-address} | summary } [location node-id]
```

Syntax Description		
<b>client</b>		Displays statistics of TCP clients.
<b>pcb</b> <i>pcb-address</i>		(Optional) Displays detailed statistics for a specified connection.
<b>pcb all</b>		(Optional) Displays detailed statistics for all connections.
<b>summary</b>		(Optional) Clears summary statistic for a specific node or connection.
<b>location</b> <i>node-id</i>		(Optional) Displays statistics for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	transport	read

**Examples** The following is sample output from the **show tcp statistics** command:

```
RP/0/RP0/CPU0:router# show tcp statistics pcb 0x08091bc8

Statistics for PCB 0x8091bc8 VRF Id 0x60000000
Send:  0 bytes received from application
       0 xipc pulse received from application
       0 bytes sent to network
       0 packets failed getting queued to network
Rcvd:  0 packets received from network
       0 packets queued to application
       0 packets failed queued to application
```

This table describes the significant fields shown in the display.

**Table 74: show tcp statistics Command Field Descriptions**

<b>Field</b>	<b>Description</b>
vrfid	VPN routing and forwarding (VRF) identification (vrfid) number.
Send	Statistics in this section refer to packets sent by the router.
Rcvd:	Statistics in this section refer to packets received by the router.



# show udp brief

To display a summary of the User Datagram Protocol (UDP) connection table, use the **show udp brief** command in XR EXEC mode.

**show udp brief** [*location node-id*]

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport read	

**Examples** The following is sample output from the **show udp brief** command:

```
RP/0/RP0/CPU0:router# show udp brief

PCB          VRF-ID Recv-Q Send-Q Local Address Foreign Address
0x7fb44c029678 0x60000000 0      0      0 :::35333      :::0
0x7fb44c028fa8 0x00000000 0      0      0 :::35333      :::0
0x7fb43000b708 0x60000000 0      0      0 :::49270      :::0
0x7fb43000b038 0x00000000 0      0      0 :::49270      :::0
0x7fb43001fbb8 0x60000000 0      0      0 :::123        :::0
0x7fb430010f28 0x00000000 0      0      0 :::123        :::0
0x7fb430009ea8 0x60000000 0      0      0 :::41092      :::0
0x7fb4300096b8 0x00000000 0      0      0 :::41092      :::0
0x7fb44c025008 0x60000000 0      0      0 :::161        :::0
0x7fb43000cda8 0x60000001 0      0      0 :::161        :::0
0x7fb43000d2d8 0x60000002 0      0      0 :::161        :::0
0x7fb43000d938 0x60000003 0      0      0 :::161        :::0
0x7fb43000df98 0x60000004 0      0      0 :::161        :::0
0x7fb43000e5f8 0x60000005 0      0      0 :::161        :::0
0x7fb43000ec58 0x60000006 0      0      0 :::161        :::0
0x7fb43000f2b8 0x60000007 0      0      0 :::161        :::0
0x7fb43000f918 0x60000008 0      0      0 :::161        :::0
0x7fb43000ff78 0x60000009 0      0      0 :::161        :::0
0x7fb4300046c8 0x00000000 0      0      0 :::161        :::0
0x7fb44c025f78 0x60000000 0      0      0 :::162        :::0
0x7fb44c02b1f8 0x60000001 0      0      0 :::162        :::0
```

```

0x7fb44c02b848 0x60000002 0 0 :::162 :::0
0x7fb44c02bea8 0x60000003 0 0 :::162 :::0
0x7fb44c02c508 0x60000004 0 0 :::162 :::0
0x7fb44c02cb68 0x60000005 0 0 :::162 :::0
0x7fb44c02d1c8 0x60000006 0 0 :::162 :::0
0x7fb44c02d828 0x60000007 0 0 :::162 :::0
0x7fb44c02de88 0x60000008 0 0 :::162 :::0
0x7fb44c02e4e8 0x60000009 0 0 :::162 :::0
0x7fb44c0258e8 0x00000000 0 0 :::162 :::0
0x7fb4300024d8 0x60000000 0 0 :::3503 :::0
0x7fb44c028628 0x60000000 0 0 :::32958 :::0
0x7fb44c028018 0x00000000 0 0 :::32958 :::0
0x7fb44c02a9e8 0x60000000 0 0 :::3799 :::0
0x7fb44c02a258 0x00000000 0 0 :::3799 :::0
0x7fb4300012e8 0x00000000 0 0 :::0 :::0
0x7fb44c023258 0x60000000 0 0 0.0.0.0:514 0.0.0.0:0
0x7fb44c027848 0x60000000 0 0 0.0.0.0:27202 0.0.0.0:0
0x7fb4300077e8 0x00000000 0 0 0.0.0.0:27202 0.0.0.0:0
0x7fb44c03cf48 0x60000000 0 0 0.0.0.0:123 0.0.0.0:0
0x7fb4300107e8 0x00000000 0 0 0.0.0.0:123 0.0.0.0:0
0x7fb430000c18 0x60000000 0 0 0.0.0.0:646 0.0.0.0:0
0x7fb44c022158 0x00000000 0 0 0.0.0.0:646 0.0.0.0:0
0x7fb44c0274e8 0x60000000 0 0 0.0.0.0:30613 0.0.0.0:0
0x7fb430006bf8 0x00000000 0 0 0.0.0.0:30613 0.0.0.0:0
0x7fb44c0270f8 0x60000000 0 0 0.0.0.0:50589 0.0.0.0:0
0x7fb430006008 0x00000000 0 0 0.0.0.0:50589 0.0.0.0:0

```

This table describes the significant fields shown in the display.

**Table 75: show udp brief Command Field Descriptions**

Field	Description
PCB	Protocol control block address. This is the address to a structure that contains connection information such as local address, foreign address, local port, foreign port, and so on.
Recv-Q	Number of bytes in the receive queue.
Send-Q	Number of bytes in the send queue.
Local Address	Local address and local port.
Foreign Address	Foreign address and foreign port.

# show udp detail pcb

To display detailed information of the User Datagram Protocol (UDP) connection table, use the **show udp detail pcb** command in XR EXEC mode.

```
show udp detail pcb {pcb-address | all} [location node-id]
```

Syntax Description		
	<i>pcb-address</i>	Address of a specified UDP connection.
	<b>all</b>	Provides statistics for all UDP connections.
	<b>location</b> <i>node-id</i>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	transport	read

## Examples

The following is sample output from the **show udp detail pcb all** command:

```
RP/0/RP0/CPU0:router# show udp detail pcb all location 0/RP0/CPU0
=====
PCB is 0x4822fea0, Family: 2, VRF: 0x60000000
  Local host: 0.0.0.0:3784
  Foreign host: 0.0.0.0:0

Current send queue size: 0
Current receive queue size: 0
=====
PCB is 0x4822d0e0, Family: 2, VRF: 0x60000000
  Local host: 0.0.0.0:3785
  Foreign host: 0.0.0.0:0

Current send queue size: 0
Current receive queue size: 0
```

This table describes the significant fields shown in the display.

**Table 76: show raw pcb Command Field Descriptions**

<b>Field</b>	<b>Description</b>
PCB	Protocol control block address.
Family	Network protocol. IPv4 is 2; IPv6 is 26.
VRF	VPN routing and forwarding (VRF) instance name.
Local host	Local host address.
Foreign host	Foreign host address.
Current send queue size	Size of the send queue (in bytes).
Current receive queue size	Size of the receive queue (in bytes).

# show udp extended-filters

To display the details of the UDP extended-filters, use the **show udp extended-filters** command in XR EXEC mode.

```
show udp extended-filters {location node-id | peer-filter {location node-id}}
```

<b>Syntax Description</b>	<b>location node-id</b> Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
	<b>peer-filter</b> Displays connections with peer filter configured.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** No specific guidelines impact the use of this command.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read

## Examples

The following is sample output from the **show udp extended-filters** command for a specific location (0/RP0/CPU0):

```
RP/0/RP0/CPU0:router# show udp extended-filters location 0/RP0/CPU0
```

```
JID: 1111
Family: 10
VRF: 0x60000000
PCB: 0x7fb44c029678
L4-proto: 17
Lport: 35333
Fport: 0
Laddr: 70:8653:f7f:0:303d:40ba:3200:0
Faddr: e297:ba:3200:0:3208::
ICMP error filter mask: 0x0
LPTS options: 0x0 / 0x5 / 0x0 / BOUND /
Flow Type: RADIUS
```

## show udp statistics

To display User Datagram Protocol (UDP) statistics, use the **show udp statistics** command in XR EXEC mode.

```
show udp statistics { clients | pcb { all | pcb-address } | summary } [location node-id]
```

### Syntax Description

<b>clients</b>	(Optional) Clears statistics for all TCP clients.
<b>pcb</b> <i>pcb-address</i>	Displays detailed statistics for each connection.
<b>pcb</b> <i>all</i>	Displays detailed statistics for all connections.
<b>location</b> <i>node-id</i>	(Optional) Displays information for the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>summary</b>	Displays summary statistics.

### Command Default

No default behavior or values

### Command Modes

XR EXEC mode

### Command History

Release	Modification
Release 7.0.12	This command was introduced.

### Usage Guidelines

UDP clones the received packets if there are multiple multicast applications that are interested in receiving those packets.

### Task ID

Task ID	Operations
transport	read

### Examples

The following is sample output from the **show udp statistics summary** command:

```
Router# show udp statistics summary

UDP statistics:
Rcvd: 121 Total, 121 drop, 0 no port
      0 checksum error, 0 too short
Sent: 121 Total, 0 error
      0 Total forwarding broadcast packets
      0 Cloned packets, 0 failed cloning
```

This table describes the significant fields shown in the display.

**Table 77: show udp Command Field Descriptions**

<b>Field</b>	<b>Description</b>
Rcvd: Total	Total number of packets received.
Rcvd: drop	Total number of packets received that were dropped.
Rcvd: no port	Total number of packets received that have no port.
Rcvd: checksum error	Total number of packets received that have a checksum error.
Rcvd: too short	Total number of packets received that are too short for UDP packets.
Sent: Total	Total number of packets sent successfully.
Sent: error	Total number of packets that cannot be sent due to errors.
Total forwarding broadcast packets	Total number of packets forwarded to the helper address.
Cloned packets	Total number of packets cloned successfully.
failed cloning	Total number of packets that failed cloning.

## tcp dump-file convert

To convert the TCP dump packet traces files to other readable formats such as pcap, text, or both, use **tcp dump-file convert** command in XR EXEC mode.

```
tcp dump-file convert { pcap | text | all-formats } { all | binary_file_name | ipaddress } location
{ node-id } file { absolute file path }
```

### Syntax Description

<b>pcap</b>	Converts TCP dump packet traces files to pcap format.
<b>text</b>	Converts TCP dump packet traces files to text format.
<b>all-format</b>	Converts TCP dump packet traces files to both pcap and text format.
<b>all</b>	Collects TCP dump file data from all peers and nodes.
<b>binary_file_name</b>	Specifies the name of the dump file to be converted.
<b>ipaddress</b>	Specifies the IP address of the peer node.
<b>location</b> { <i>node-id</i> }	(Optional) Specifies the node to store the converted TCP dump file. The <i>node-id</i> is entered in the <i>rack/slot/module</i> notation, for example <b>location 0/RP0/CPU0</b> . By default, the files are stored in the current node where the CLI command is executed.
<b>file</b> { <i>absolute file path</i> }	(Optional) Specifies the absolute file path where you want to store the converted TCP dump files. The file path is entered in the <i>node/filename</i> notation, for example <i>/harddisk:/demo1</i> . By default, the converted files are stored inside the file "decoded_dumpfiles" in the current node where the CLI command is executed or if you have provided the location the files are stored in that location.

### Command Default

No default behavior or values.

### Command Modes

XR EXEC mode

### Command History

Release	Modification
Release 24.2.11	This command was introduced.

### Usage Guidelines

Use this command to convert TCP dump packet traces files into text, pcap, or both readable formats.

### Examples

The following example shows how to convert TCP packet traces files into text and pcap readable formats:

```
Router# tcp dump-file convert all-formats all
ascii file is saved at :
/harddisk:/decoded_dumpfiles/text_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_10_8_53.462070.txt
pcap file is saved at :
/harddisk:/decoded_dumpfiles/pcap_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_10_8_40.154838.pcap
[OK]
```



The following example shows how to filter TCP dump packet traces by ip address and convert them into text and pcap readable format:

```
Router# tcp dump-file convert all-formats ipaddress 1.1.1.2
ascii file is saved at :
/harddisk:/decoded_dumpfiles/text_tcpdump_peer_1_1_1_2_node0_RSP0_CPU0_2024_3_19_10_9_20.539021.txt
pcap file is saved at :
/harddisk:/decoded_dumpfiles/pcap_tcpdump_peer_1_1_1_2_node0_RSP0_CPU0_2024_3_19_10_9_20.539021.pcap
[OK]
```

The following example specifies a location where you want to store the converted TCP dump file:

```
Router# tcp dump-file convert all-formats all location 0/RP0/CPU0
ascii file is saved at :
/harddisk:/decoded_dumpfiles/text_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_12_53_35.12323.txt
pcap file is saved at :
/harddisk:/decoded_dumpfiles/pcap_tcpdump_peer_all_node0_RP0_CPU0_2024_3_19_12_53_35.12323.pcap
[OK]
```

The following example specifies the absolute file path where you want to store the converted TCP dump files:

```
Router# tcp dump-file convert text all file /harddisk:/demo2
ascii file is saved at : /harddisk:/demo2.txt
[OK]
```

## tcp mss

To configure the TCP maximum segment size that determines the size of the packet that TCP uses for sending data, use the **tcp mss** command in XR Config mode.

**tcp mss** *segment-size*

<b>Syntax Description</b>	<i>segment-size</i> Size, in bytes, of the packet that TCP uses to send data. Range is 68 to 10000 bytes.				
<b>Command Default</b>	If this configuration does not exist, TCP determines the maximum segment size based on the settings specified by the application process, interface maximum transfer unit (MTU), or MTU received from Path MTU Discovery.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was introduced.
Release	Modification				
Release 7.0.12	This command was introduced.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	transport	read, write
Task ID	Operations				
transport	read, write				

### Examples

This example shows how to configure the TCP maximum segment size:

```
RP/0/RSP0/CPU0:router(config)# tcp mss 1460
RP/0/RSP0/CPU0:router(config)# exit

Uncommitted changes found, commit them? [yes]:
RP/0/RSP0/CPU0:router:Sep  8 18:29:51.084 : config[65700]: %LIBTARCFG-6-COMMIT :

Configuration committed by user 'lab'.  Use 'show commit changes 1000000596' to view the
changes.
Sep  8 18:29:51.209 : config[65700]: %SYS-5-CONFIG_I : Configured from console by lab
```

## tcp path-mtu-discovery

To allow TCP to automatically detect the highest common maximum transfer unit (MTU) for a connection, use the **tcp path-mtu-discovery** in XR Config mode. To reset the default, use the **no** form of this command.

```
tcp path-mtu-discovery [age-timer minutes | infinite]
no tcp path-mtu-discovery
```

<b>Syntax Description</b>	<b>age-timer</b> <i>minutes</i> (Optional) Specifies a value in minutes. Range is 10 to 30.
	<b>infinite</b> (Optional) Turns off the age timer.

<b>Command Default</b>	<b>tcp path-mtu-discovery</b> is disabled <b>age-timer</b> default is 10 minutes
------------------------	---

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was introduced.

**Usage Guidelines** Use the **tcp path-mtu-discovery** command to allow TCP to automatically detect the highest common MTU for a connection, such that when a packet traverses between the originating host and the destination host the packet is not fragmented and then reassembled.

The age timer value is in minutes, with a default value of 10 minutes. The age timer is used by TCP to automatically detect if there is an increase in MTU for a particular connection. If the **infinite** keyword is specified, the age timer is turned off.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport	read, write

**Examples** The following example shows how to set the age timer to 20 minutes:

```
RP/0/RP0/CPU0:router(config)# tcp path-mtu-discovery age-timer 20
```

## tcp selective-ack

To enable TCP selective acknowledgment (ACK) and identify which segments in a TCP packet have been received by the remote TCP, use the **tcp selective-ack** command in XR Config mode. To reset the default, use the **no** form of this command.

**tcp selective-ack**  
**no tcp selective-ack**

<b>Syntax Description</b>	XR Config mode This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	TCP selective ACK is disabled.
------------------------	--------------------------------

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.12	This command was supported.

<b>Usage Guidelines</b>	If TCP Selective ACK is enabled, each packet contains information about which segments have been received by the remote TCP. The sender can then resend only those segments that are lost. If selective ACK is disabled, the sender receives no information about missing segments and automatically sends the first packet that is not acknowledged and then waits for the other TCP to respond with what is missing from the data stream. This method is inefficient in Long Fat Networks (LFN), such as high-speed satellite links in which the bandwidth * delay product is large and valuable bandwidth is wasted waiting for retransmission.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	transport read, write	

<b>Examples</b>	In the following example, the selective ACK is enabled:
-----------------	---

```
RP/0/RP0/CPU0:router(config)# tcp selective-ack
```

## tcp synwait-time

To set a period of time the software waits while attempting to establish a TCP connection before it times out, use the **tcp synwait-time** command in XR Config mode. To restore the default time, use the **no** form of this command.

**tcp synwait-time** *seconds*  
**no tcp synwait-time** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Time (in seconds) the software waits while attempting to establish a TCP connection. Range is 5 to 30 seconds.				
<b>Command Default</b>	The default value for the synwait-time is 30 seconds.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was supported.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was supported.
Release	Modification				
Release 7.0.12	This command was supported.				
<b>Usage Guidelines</b>	No specific guidelines impact the use of this command.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	transport	read, write
Task ID	Operations				
transport	read, write				

### Examples

The following example shows how to configure the software to continue attempting to establish a TCP connection for 18 seconds:

```
RP/0/RP0/CPU0:router(config)# tcp synwait-time 18
```

# tcp timestamp

To more accurately measure the round-trip time of a packet, use the **tcp timestamp** command in XR Config mode. To reset the default, use the **no** form of this command.

**tcp timestamp**  
**no tcp timestamp**

**Syntax Description** This command has no keywords or arguments.

**Command Default** A TCP time stamp is not used.

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 7.0.12	This command was supported.

**Usage Guidelines** Use the **tcp timestamp** command to more accurately measure the round-trip time of a packet. If a time stamp is not used, a TCP sender deduces the round-trip time when an acknowledgment of its packet is received, which is not a very accurate method because the acknowledgment can be delayed, duplicated, or lost. If a time stamp is used, each packet contains a time stamp to identify packets when acknowledgments are received and the round-trip time of that packet.

This feature is most useful in Long Fat Network (LFN) where the bandwidth \* delay product is long.

Task ID	Task ID	Operations
	transport read, write	

**Examples** The following example shows how to enable the timestamp option:

```
RP/0/RP0/CPU0:router(config)# tcp timestamp
```

# tcp window-size

To alter the TCP window size, use the **tcp window-size** command in XR Config mode. To restore the default value, use the **no** form of this command.

**tcp window-size** *bytes*  
**no tcp window-size**

<b>Syntax Description</b>	<i>bytes</i> Window size in bytes. Range is 2048 to 65535 bytes.				
<b>Command Default</b>	The default value for the window size is 16k.				
<b>Command Modes</b>	XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 7.0.12</td> <td>This command was supported.</td> </tr> </tbody> </table>	Release	Modification	Release 7.0.12	This command was supported.
Release	Modification				
Release 7.0.12	This command was supported.				
<b>Usage Guidelines</b>	Do not use this command unless you clearly understand why you want to change the default value.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>transport</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	transport	read, write
Task ID	Operations				
transport	read, write				
<b>Examples</b>	<p>The following example shows how to set the TCP window size to 3000 bytes:</p> <pre>RP/0/RP0/CPU0:router(config)# tcp window-size 3000</pre>				







## VRRP Commands

---

This chapter describes the commands used to configure and monitor Virtual Router Redundancy Protocol (VRRP) features.

For detailed information about VRRP concepts, configuration tasks, and examples, refer to the *IP Addresses and Services Configuration Guide for Cisco 8000 Series Routers*.

- [clear vrrp statistics, on page 572](#)
- [show vrrp, on page 573](#)
- [show vrrp statistics, on page 579](#)
- [unicast-peer, on page 581](#)

## clear vrrp statistics

To reset the Virtual Router Redundancy Protocol (VRRP) statistics (to zero or default value), use the **clear vrrp statistics** command in XR EXEC mode.

```
clear vrrp statistics [ ipv4 | ipv6 ] [ interface type interface-path-id | vrid ]
```

Syntax Description	
<b>ipv4</b>	(Optional) Resets the IPv4 VRRP statistics.
<b>ipv6</b>	(Optional) Resets the IPv6 VRRP statistics.
<b>interface type</b>	(Optional) Specifies the Interface type.
<i>interface-path-id</i>	(Optional) Specify a physical interface instance or a virtual interface instance for which VRRP statistics is cleared.
<i>vrid</i>	(Optional) Specify the virtual router identifier, which is the number identifying the virtual router for which VRRP statistics is cleared.

**Command Default** No default behavior or values

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

**Usage Guidelines** If no interface is specified, the statistics for all virtual routers on all interfaces are cleared.  
If no value for vrid is specified, the statistics for all virtual routers on the specified interface are cleared.

Task ID	Task ID	Operations
	ip-services	execute

**Examples** The following example shows how to clear vrrp statistics:

```
RP/0/RP0/CPU0:router# clear vrrp statistics
```

# show vrrp

To display a brief or detailed status of one or all Virtual Router Redundancy Protocol (VRRP) virtual routers, use the **show vrrp** command in XR EXEC mode.

**show vrrp** [**ipv4** | **ipv6**] [**interface** *type interface-path-id* ] [**brief** | **detail** | **statistics** [**all**]]

Syntax	Description
<b>ipv4</b>	(Optional) Displays the IPv4 information.
<b>ipv6</b>	(Optional) Displays the IPv6 information.
<b>interface</b>	(Optional) Displays the status of the virtual router interface.
<i>type</i>	Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or virtual interface.  <b>Note</b> Use the show interfaces command to see a list of all interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>brief</b>	(Optional) Provides a summary view of the virtual router information.
<b>detail</b>	(Optional) Displays detailed running state information.
<b>statistics</b>	(Optional) Displays total statistics.
<b>all</b>	(Optional) Displays statistics for each virtual router.

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 3.7.2	This command was introduced.

Release	Modification
Release 7.11.1	This command was modified. The fields <b>Mcast packet in Ucast mode</b> , <b>IPv4 Unicast Peer</b> , and <b>IPv4 Unicast Peer</b> were added.

**Usage Guidelines**

If no interface is specified, all virtual routers on all interfaces are displayed. If no vrid is specified, all vrids on the given interface are displayed.

**Task ID**

Task ID	Operations
vrrp	read

**Examples**

The following sample output is from the **show vrrp** command:

```
Router# show vrrp

                A indicates IP address owner
                | P indicates configured to preempt
                | |
Interface   vrID Prio A P State   Master addr   VRouter addr
Te0/3/0/0   1  100 P Init   unknown      192.168.18.10
Te0/3/0/2   7  100 P Init   unknown      192.168.19.1
```

This table describes the significant fields shown in the display.

**Table 78: show vrrp Command Field Descriptions**

Field	Description
Interface	Interface of the virtual router.
vrID	ID of the virtual router.
Prio	Priority of the virtual router.
A	Indicates whether the VRRP router is the IP address owner.
P	Indicates whether the VRRP router is configured to preempt (default).
State	State of the virtual router.
Master addr	IP address of the IP address owner router.
VRouter addr	Virtual router IP address of the virtual router.

The following sample output is from the **show vrrp** command with the **detail** keyword:

```
Router# show vrrp detail
Fri Sep  8 15:02:35.268 IST
GigabitEthernet0/0/0/0 - IPv4 vrID 1
  State is Master
```

```

    2 state changes, last state change 04:00:02
    State change history:
    Sep  8 11:02:29.518 IST  Init    -> Backup  Virtual IP configured
    Sep  8 11:02:33.127 IST  Backup -> Master  Master down timer expired
    Last resign sent:      Never
    Last resign received: Never
    Virtual IP address is 10.0.0.100
    Virtual MAC address is 0000.5E00.0101, state is active
    Master router is local
    Version is 2
    Advertise time 1 secs
      Master Down Timer 3.609 (3 x 1 + (156 x 1/256))
    Minimum delay 1 sec, reload delay 5 sec
    Current priority 100
      Configured priority 100, may preempt
      minimum delay 0 secs
IPv4 Unicast Peer: 10.0.1.1 --> IPv4 unicast transport is enabled on VRRP.

GigabitEthernet0/0/0/0 - IPv6 vrID 2
    State is Init
      0 state changes, last state change never
      State change history:
      Last resign sent:      Never
      Last resign received: Never
      Virtual IP address is ::
      Virtual MAC address is 0000.5E00.0202, state is stored
      Master router is unknown
      Version is 3
      Advertise time 1 secs
        Master Down Timer 3.609 (3 x 1 + (156 x 1/256))
      Minimum delay 1 sec, reload delay 5 sec
      Current priority 100
        Configured priority 100, may preempt
        minimum delay 0 secs
IPv6 Unicast Peer: FE80::260:3EFF:FE11:6770 --> IPv6 unicast transport is enabled on VRRP.

```

This table describes the significant fields shown in the displays.

**Table 79: show vrrp detail Command Field Descriptions**

Field	Description
0/3/0/0 - vrID 1	Interface type and number, and VRRP group number.
State is	Role this interface plays within VRRP (IP address owner router or backup router).
Virtual IP address is	Virtual IP address for this virtual router.
Virtual MAC address is	Virtual MAC address for this virtual router.
Master router is	Location of the IP address owner router.
Advertise time	Interval (in seconds) at which the router sends VRRP advertisements when it is the IP address owner virtual router. This value is configured with the <b>vrrp timer</b> command.

Field	Description
Master Down Timer	Time the backup router waits for the IP address owner router advertisements before assuming the role of IP address owner router.
Minimum delay	Time that the state machine start-up is delayed when an interface comes up, giving the network time to settle. The minimum delay is the delay that is applied after any subsequent interface up event (if the interface flaps) and the reload delay is the delay applied after the first interface up event.
Current priority	Priority of the virtual router.
Configured priority	Priority configured on the virtual router.
may preempt	Indication of whether preemption is enabled or disabled.
minimum delay	Delay time before preemption (default) occurs.
Tracked items	Section indicating the items being tracked by the VRRP router.
Interface	Interface being tracked.
State	State of the tracked interface.
Priority Decrement	Priority to decrement from the VRRP priority when the interface is down.
IPv4 Unicast Peer	IPv4 address of the unicast peer.
IPv6 Unicast Peer	IPv6 address of the unicast peer.

The following sample output is from the **show vrrp** command with the **statistics** .

```

show vrrp statistics
Fri Sep  8 15:03:03.521 IST
Invalid packets:
  Invalid checksum:                0
  Unknown/unsupported versions:    0
  Invalid vrID:                    0
  Too short:                        0
Protocol:
  Transitions to Master            1
Packets:
  Total received:                  0
  Adverts sent:                    14476
  Bad TTL:                         0
  Short Packets:                   0
  Failed authentication:           0
  Unknown authentication:          0
  Conflicting authentication:      0
  Unknown Type field:              0
  Conflicting Advertise time:      0
  Conflicting Addresses:           0
  Received with zero priority:     0
  Sent with zero priority:         0
  Mcast packet in Ucast mode:     0

```

This table describes the significant fields shown in the displays.

**Table 80: show vrrp statistics Command Field Descriptions**

Field	Description
Invalid packets	Number of invalid packets.
Invalid checksum	Number of packets with checksum errors.
Unknown/unsupported versions	Number of packets with unknown/unsupported versions.
Invalid vrID	Number of packets with invalid VRRP ID
Too short	Number of packets that are too short.
Protocol	Role of the VRRP routers.
Transitions to Master	Number of VRRP routers that have taken over the master.
Packets	Number of packets received.
Total received	Cumulative number of packets received.
Adverts sent	Number of times the router has advertised its VRRP status.
Bad TTL	Number of packets with incorrect Time-to-Live values.
Short Packets	Number of packets with a size shorter than expected.
Failed authentication	Number of packets that failed authentication during VRRP operation.
Unknown authentication	Number of packets that failed authentication because the authentication was not recognized.
Conflicting authentication	Number of packets that failed authentication due to conflicts.
Conflicting IP addresses	Number of packets where conflicting IP addresses are detected within the VRRP configuration.
Received with zero priority	Number of packets received with zero priority.
Sent with zero priority	Number of packets sent by a VRRP router with a priority of zero.
Mcast packet in Ucast mode	Number of multicast packets received in a specific VRRP instance when it's configured to function in unicast mode.

The following sample output is from the **show vrrp** command with the **interface** for Ethernet interface 0/3/0/0:

```
Router# show vrrp interface Ethernet0/3/0/0

          A indicates IP address owner
          | P indicates configured to preempt
          | |
Interface  vrID Prio A P State   Master addr   VRouter addr
```

**show vrrp**

```
Te0/3/0/0    1 100 P Init    unknown    192.168.10.20
Te0/3/0/2    7 100 P Init    unknown    192.168.20.0
```



## show vrrp statistics

To display statistics of one or all Virtual Router Redundancy Protocol (VRRP) virtual routers, use the **show vrrp statistics** command in the XR EXEC mode.

```
show vrrp [ ipv4 | ipv6 ] [ interface type interface-path-id | vrid ] statistics [ all ]
```

Syntax Description	
<b>ipv4</b>	(Optional) Displays the IPv4 information.
<b>ipv6</b>	(Optional) Displays the IPv6 information.
<b>interface type</b>	(Optional) Specifies the Interface type.
<i>interface-path-id</i>	(Optional) Specify a physical interface instance or a virtual interface instance.
<i>vrid</i>	(Optional) Specify the virtual router identifier, which is the number identifying the virtual router for which statistics is displayed.
<b>all</b>	(Optional) Displays statistics for each virtual router.

**Command Default** No default behavior or values

Command History	Release	Modification
	Release 7.9.1	This command was introduced.

**Usage Guidelines** If no interface is specified, the statistics for all VRRP groups or VRIDs on all interfaces are displayed.  
If no value for vrid is specified, the statistics for all virtual routers on the specified interface are displayed.

Task ID	Task ID	Operations
	ip-services	read

### Examples

The following is sample output from the **show vrrp statistics** command:

```
Router# show vrrp statistics
Invalid packets:
  Invalid checksum:                0
  Unknown/unsupported versions:    3
  Invalid vrID:                    1
  Too short:                        7
Protocol:
  Transitions to Master            4
Packets:
  Total received:                  54
  Adverts sent:                    0
  Bad TTL:                         0
  Short Packets:                   6
  Failed authentication:           0
  Unknown authentication:          2
```

## show vrrp statistics

```
Conflicting authentication:      0
Unknown Type field:            1
Conflicting Advertise time:     0
Conflicting Addresses:         0
Received with zero priority:    9
Sent with zero priority:        0
```

## unicast-peer

To enable IPv4 and IPv6 layer 3 unicast transport on Virtual Router Redundancy Protocol (VRRP), use the command in VRRP virtual router submode. To disable unicast transport, use the **no** form of this command.

**unicast-peer** { *ipv4-address* | *ipv6-link-local-address* }

<b>Syntax Description</b>	<i>ipv4-address</i>	IPv4 address
	<i>ipv6-link-local-address</i>	IPv6 link-local address
<b>Command Default</b>	VRRP transmits multicast traffic.	
<b>Command Modes</b>	VRRP virtual router configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.11.1	This command was introduced.
<b>Usage Guidelines</b>	You can configure the unicast-peer command only once, allowing for the participation of only two physical routers in a unicast VRRP session.	
	When you configure the unicast-peer command, the router neither sends nor receives multicast packets	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	vrrp	read,write

### Example

This example shows how to configure IPv4 Layer 3 unicast transport on VRRP.

```
Router(config)# router vrrp
Router(config-vrrp)# interface GigabitEthernet0/0/0/0
Router(config-vrrp-if)# address-family ipv4
Router(config-vrrp-address-family)# vrrp 1

Router(config-vrrp-virtual-router)# address 10.0.1.100

Router(config-vrrp-virtual-router)# unicast-peer 10.0.1.1
```

This example shows how to configure IPv6 Layer 3 unicast transport on VRRP.

```
Router(config)# router vrrp
Router(config-vrrp)# interface GigabitEthernet0/0/0/0
Router(config-vrrp-if)# address-family ipv6
Router(config-vrrp-address-family)# vrrp 2

Router(config-vrrp-virtual-router)# unicast-peer FE80::260:3EFF:FE11:6770
```

 unicast-peer