



Multiple Spanning Tree Protocol Commands

This module describes the commands used to configure multiple spanning tree protocol. For detailed information about MSTP concepts, configuration tasks, and examples, see the *L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers*.

- [allow-legacy-bpdu](#), on page 2
- [instance \(MSTP\)](#), on page 3
- [interface \(MSTP\)](#), on page 4
- [name \(MSTP\)](#), on page 5
- [portfast](#), on page 6
- [show spanning-tree mst](#), on page 7
- [spanning-tree mst](#), on page 9
- [vlan-id \(MSTP\)](#), on page 10

allow-legacy-bpdu

To enable MSTP to accept legacy TCN notifications and allow it to prompt a flush rather than putting the interface into an error-disabled state, use the **allow-legacy-bpdu** command in the MSTP interface configuration submode.

allow-legacy-bpdu

Syntax Description This command has no keywords or arguments.

Command Default allow-legacy-bpdu is disabled.

Command Modes MSTP interface configuration

Command History	Release	Modification
	Release 7.1.1	This command was introduced.

Usage Guidelines No specific guidelines impact the use of this command.

Task ID	Task ID	Operations
	ethernet-services	read, write

Examples

The following example shows how to enable **allow-legacy-bpdu** command:

```
Router# config
Router(config)# spanning-tree MST test
Router(config-mstp)# allow-legacy-bpdu
```

instance (MSTP)

To enter the multiple spanning tree instance (MSTI) configuration submode, use the **instance** command in MSTP configuration submode.

instance *id*

Syntax Description	<i>id</i> MSTI ID. Range is 0 to 4094.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	MSTP configuration
----------------------	--------------------

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines



Note An instance ID of 0 represents the CIST for the region.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to enter the MSTI configuration submode:

```
Router# configure
Router(config)#spanning-tree mst a
Router(config-mstp)# instance 101
Router(config-mstp-inst)#
```

Related Commands	Command	Description
	show spanning-tree mst, on page 7	Displays the multiple spanning tree protocol status information.
	spanning-tree mst, on page 9	Enters the MSTP configuration submode
	vlan-id (MSTP), on page 10	Associates a set of VLAN IDs with the current MSTI.

interface (MSTP)

To enter the MSTP interface configuration submode, and to enable STP for the specified port, use the **interface** command in MSTP configuration submode.

interface interface-type interface-path-id

Syntax Description	interface	Interface type. For more information, use the question mark (?) online help function.
	interface-path-id	Physical interface. Use the show interfaces command to see a list of all possible interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default None

Command Modes MSTP configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines A given port may only be enabled with one of MSTP, MSTAG, REPAG, PVSTAG or PVRSTAG.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to enter the MSTP interface configuration submode:

```
Router# configure
Router(config)# spanning-tree mst M0
Router(config-mstp)# interface hundredGigE 0/0/0/1
Router(config-mstp-if)#
```

Related Commands	Command	Description
	show spanning-tree mst, on page 7	Displays the multiple spanning tree protocol status information.
	spanning-tree mst, on page 9	Enters the MSTP configuration submode

name (MSTP)

To set the name of the MSTP region, use the **name** command in MSTP configuration submode.

name *name*

Syntax Description

name Specifies the name of the mstp region.

String of a maximum of 32 characters conforming to the definition of SnmpAdminString in RFC 2271.

Command Default

The MAC address of the switch, formatted as a text string using the hexadecimal representation specified in IEEE Std 802.

Command Modes

MSTP configuration

Command History

Release	Modification
Release 7.2.12	This command was introduced.

Task ID

Task ID	Operations
interface	read, write

Examples

The following example shows how to set the name of the MSTP region to m1:

```
Router# configure
RP/0/RP0/CPU0:ios(config)#spanning-tree mst M0
Router(config-mstp)# name m1
```

Related Commands

Command	Description
show spanning-tree mst, on page 7	Displays the multiple spanning tree protocol status information.
spanning-tree mst, on page 9	Enters the MSTP configuration submode

portfast

To enable Port Fast on the port, and optionally enable BPDU guard, use the **portfast** command in MSTP interface configuration submenu.

portfast [**bpduguard**]

Syntax Description This command has no keywords or arguments.

Command Default PortFast is disabled.

Command Modes MSTP interface configuration

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines You must disable and re-enable the port for Port Fast configuration to take effect. Use **shutdown** and **no shutdown** command (in interface configuration mode) to disable and re-enable the port.

This command enables the Port Fast feature (also known as edge port). When this is enabled, MSTP treats the port as an edge port, i.e., it keeps it in forwarding state and does not generate topology changes if the port goes down or comes up. It is not expected to receive MSTP BPDUs on an edge port. BPDU guard is a Cisco extension that causes the interface to be shut down using error-disable if an MSTP BPDU is received. For more information on Port Fast feature, refer to the *Multiple Spanning Tree Protocol* module in the *L2VPN and Ethernet Services Configuration Guide for Cisco 8000 Series Routers*

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to enable PortFast and BPDU guard on the port:

```
Router# configure
Router(config)# spanning-tree mst a
Router(config-mstp)# interface HundredGigE0/0/0/2
Router(config-mstp-if)# portfast
Router(config-mstp-if)# portfast bpduguard
```

Related Commands	Command	Description
	interface (MSTP), on page 4	Enters the MSTP interface configuration submenu, and enables STP for the specified port.
	show spanning-tree mst, on page 7	Displays the multiple spanning tree protocol status information.
	spanning-tree mst, on page 9	Enters the MSTP configuration submenu

show spanning-tree mst

To display the multiple spanning tree protocol status information, use the **show spanning-tree mst** command in EXEC mode.

show spanning-tree mst *protocol instance identifier* [**instance** *instance-id*] [**blocked-ports** | **brief**]

Syntax Description	
<i>protocol instance identifier</i>	String of a maximum of 25 characters that identifies the protocol instance.
instance <i>instance-id</i>	Forward interface in rack/slot/instance/port format.
brief	Displays a summary of MST information only.
blocked-ports	Displays MST information for blocked ports only.

Command Default None

Command Modes EXEC

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Task ID	Task ID	Operations
	interface	read

Examples

The following example shows the output from the **show spanning-tree mst** command, which produces an overview of the spanning tree protocol state:

```
Router# show spanning-tree mst a instance 0
Operating in Provider Bridge mode
MSTI 0 (CIST):

  VLANs Mapped: 1-100, 500-1000, 1017

  Root ID      Priority    4097
  Address      0004.9b78.0800
  This bridge is the root
  Hello Time   2 sec    Max Age 20 sec    Forward Delay 15 sec

  Bridge ID    Priority    4097    (priority 4096 sys-id-ext 1)
  Address      0004.9b78.0800
  Hello Time   2 sec    Max Age 20 sec    Forward Delay 15 sec

Interface      Port ID          Designated          Port ID
Name           Prio.Nbr Cost   Role State   Cost Bridge ID      Prio.Nbr
```

show spanning-tree mst

```

-----
HundredGigEthernet0/0/0/1  128.65  20000  DSGN FWD  0  4097 0004.9b78.0800 128.65
HundredGigEthernet0/0/0/2  128.66  20000  DSGN FWD  0  4097 0004.9b78.0800 128.66
...

```

The following example shows the output from the **show spanning-tree mst** command when the **brief** and **blocked-ports** keywords are used:

```

Router# show spanning-tree mst a brief
MSTI 0 (CIST):
  VLAN IDs: 1-100, 500-1000, 1017
  This is the Root Bridge
MSTI 1:
  VLAN IDS: 101-499
  Root Port HundredGigEthernet0/0/0/2 , Root Bridge ID 0002.9b78.0812
...
Router# show spanning-tree mst blocked-ports
MSTI 0 (CIST):

Interface          Port ID          Designated          Port ID
Name               Prio.Nbr Cost    Role State    Cost Bridge ID          Prio.Nbr
-----
HundredGigEthernet0/0/0/4  128.196 200000 ALT BLK  0  4097 0004.9b78.0800 128.195
...

```

Related Commands

Command	Description
spanning-tree mst, on page 9	Enters the MSTP configuration submenu

spanning-tree mst

To enter the MSTP configuration submode, use the **spanning-tree mst** command in global configuration mode.

spanning-tree mst *protocol instance identifier*

Syntax Description	<i>protocol instance identifier</i> String of a maximum of 25 characters that identifies the protocol instance.
---------------------------	---

Command Default	None
------------------------	------

Command Modes	Global configuration
----------------------	----------------------

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Usage Guidelines



Note In MSTP configuration, only one protocol instance can be configured at a time.

Task ID	Task ID	Operations
	interface	read, write

Examples

The following example shows how to enter the MSTP configuration submode:

```
Router(config)# spanning-tree mst a
Router(config-mst)#
```

Related Commands	Command	Description
	instance (MSTP), on page 3	Enters the multiple spanning tree instance (MSTI) configuration submode.
	interface (MSTP), on page 4	Enters the MSTP interface configuration submode, and enables STP for the specified port.
	show spanning-tree mst, on page 7	Displays the multiple spanning tree protocol status information.

vlan-id (MSTP)

To associate a set of VLAN IDs with the current MSTI, use the **vlan-id** command in MSTI configuration submode.

```
vlan-id vlan-range [vlan-range] [vlan-range] [vlan-range]
```

Syntax Description	<i>vlan-range</i> List of VLAN ranges in the form a-b, c, d, e-f, g etc.
---------------------------	--

Command Default	None
------------------------	------

Command Modes	MSTI configuration
----------------------	--------------------

Command History	Release	Modification
	Release 7.2.12	This command was introduced.

Task ID	Task ID	Operations
	interface	read, write

Examples The following example shows how to use the vlan-id command:

```
Router(config-mstp-inst)# vlan-id 2-1005
```

Related Commands	Command	Description
	instance (MSTP), on page 3	Enters the multiple spanning tree instance (MSTI) configuration submode.
	spanning-tree mst, on page 9	Enters the MSTP configuration submode
	show spanning-tree mst, on page 7	Displays the multiple spanning tree protocol status information.