

# **Segment Routing Commands**

This chapter describes the commands used to configure and use Segment Routing.

- egress-engineering, on page 2
- ping mpls nil-fec labels, on page 3
- prefix-sid, on page 5
- segment-routing global-block, on page 7
- segment-routing mapping-server, on page 8
- segment-routing mpls, on page 10
- segment-routing prefix-sid-map advertise-local, on page 11
- segment-routing prefix-sid-map receive disable, on page 13
- show bgp egress-engineering, on page 15
- show isis segment-routing prefix-sid-map, on page 16
- show ospf segment-routing prefix-sid-map, on page 18
- show segment-routing mapping-server prefix-sid-map, on page 20
- traceroute mpls nil-fec labels, on page 22

# egress-engineering

To configure segment routing egress peer engineering (EPE) on the egress node, use the **egress-engineering** command.

#### egress-engineering

Syntax Description	This command has no keywords or arguments.		
Command Default	No default behavior or values		
Command Modes	Neighbor configuration		
Command History	Release Modification		
	ReleaseThis command was introduced.6.1.2		
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.		
Task ID	Task IDOperationsmpls-teread, write		
Examples	This example shows how to configure segment routing EPE on the egress node:		
	RP/0/RSP0/CPU0:router <b># configure</b> RP/0/RSP0/CPU0:router(config) <b># router bgp 1</b> RP/0/RSP0/CPU0:router(config-bgp) <b># neighbor 192.168.1.3</b> RP/0/RSP0/CPU0:router(config-bgp-nbr) <b># remote-as 3</b> RP/0/RSP0/CPU0:router(config-bgp-nbr) <b># egress-engineering</b>		

L

# ping mpls nil-fec labels

To check network connectivity and identify LSP breakages, use the **ping mpls nil-fec labels** command.

**ping mpls nil-fec labels** {*label*[,*label*...] } [**output** {**interface** *tx-interface* } [**nexthop** *next-hop-ip-address*]]

Syntax Description	labels label,label	Specifies the label stack. Use commas to separate the each <i>label</i> .
	ouput interface tx-interface	Specifies the output interface.
	<b>nexthop</b> next-hop-ip-address	(Optional) Causes packets to go through the specified next-hop address.
Command Default	None	
Command Modes	EXEC	
Usage Guidelines		ist be in a user group associated with a task group that includes appropriate task nent is preventing you from using a command, contact your AAA administrator
Task ID	Task Operation ID	
	mpls-te read, write	
	Example	
	This around charge hours to a	had connectivity for a known label stack using a specific output

This example shows how to check connectivity for a known label stack using a specific output interface and next-hop address:

```
RP/0/RSP0/CPU0:router# ping mpls nil-fec labels 16005,16007 output interface GigabitEthernet
0/2/0/1 nexthop 10.1.1.4 repeat 1
Sending 1, 72-byte MPLS Echos with Nil FEC labels 16005,16007,
     timeout is 2 seconds, send interval is 0 msec:
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no label entry,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'd' - see DDMAP for return code,
  'X' - unknown return code, 'x' - return code 0
Type escape sequence to abort.
1
Success rate is 100 percent (1/1), round-trip min/avg/max = 1/1/1 ms
Total Time Elapsed 0 ms
```

Related Commands	Command	Description	
		Checks network connectivity and identifying LSP breakages.	

# prefix-sid

To specify or advertise prefix (node) segment ID (SID) on all routers, use the **prefix-sid** command in IS-IS interface address family or OSPF interface configuration mode. To stop advertising prefix SID, use the **no** form of this command.

prefix-sid [strict-spf] { index sid-index | absolute sid-value } [ n-flag-clear ] [ explicit-null
]

**no prefix-sid** [**strict-spf**] { **index** *sid-index* | **absolute** *sid-value* } [**n-flag-clear**] [ **explicit-null** ]

Syntax Description	strict-spf	Specifies that the prefix-SID should use the SPF path instead of the SR-TE policy.		
	index sid-index	Specifies the prefix SID based on the lower boundary of the SRGB + the index.		
	absolute sid-value	Specifies the specific prefix SID value within the SRGB.		
	n-flag-clear	Specifies that the prefix-SID is not a node-SID by setting the N flag in the prefix-SID sub Type Length Value (TLV) to 0.		
	explicit-null	Adds an explicit-Null label by setting the E flag in the prefix-SID sub TLV to 1. Automatically disables penultimate-hop-popping (PHP) by setting the P flag (IS-IS) or NP flag (OSPF) to 1.		
Command Default	Prefix SID is a nod	le SID (N-flag is set to 1).		
	Explicit-Null label	is not set (E-flag is set to 0).		
Command Modes	IS-IS interface address-family configuration			
	OSPF interface cor	nfiguration		
Usage Guidelines	Segment routing m configuring prefix	nust be configured on the ISIS instance or on the OSPF process, area, or interface before SID value.		
	SR-TE policies. IS- SubTLV) to includ Strict-SPF TE-capa	e used to forward traffic strictly along the SPF path. Strict-SPF SIDs are not forwarded to IS advertises the SR Algorithm sub Type Length Value (TLV) (in the SR Router Capability e both algorithm 0 (SPF) and algorithm 1 (Strict-SPF). When the IS-IS area or level is able, Strict-SPF SIDs are used to build the SR-TE Strict-SPF policies. Strict-SPF SIDs are m the backup paths for prefixes, node SIDs, and adjacency SIDs.		

Note

The same SRGB is used for both regular SIDs and strict-SPF SIDs.

Examples T	is read, write spf his example show	- - rs how to configure a prefix SID.		
<b>Examples</b> T		- rs how to configure a prefix SID.		
	nis example show	s how to configure a prefix SID.		
R				
11	/0/RSP0/CPU0:r	outer # <b>configure</b>		
R	RP/0/RSP0/CPU0:router(config)# router isis 100			
		<pre>outer(config-isis)# interface loopback0</pre>		
		<pre>outer(config-isis-if)# address-family ipv4 unicast outer(config-isis-if-af)# prefix-sid index 1001</pre>		
Т	is example show	rs how to configure an absolute prefix SID on an OSPF interface		
R	/0/RSP0/CPU0:r	outer # <b>configure</b>		
R	/0/RSP0/CPU0:r	outer(config) # router ospf 1		
		outer(config-ospf)# <b>router area 0</b>		
		<pre>outer(config-ospf-ar)# interface loopback0</pre>		
R	/0/RSP0/CPU0:ro	<pre>outer(config-ospf-ar-if)# prefix-sid absolute 16041</pre>		

Related Commands	Command	Description
	segment-routing global-block	Configures the segment routing global block (SRGB).

# segment-routing global-block

To configure the segment routing global block (SRGB), use the segment-routing global-block command.

**segment-routing global-block** *starting\_value ending\_value* 

 Syntax Description
 starting\_value ending\_value
 Specifies the block of segment routing IDs that are allocated for the routers in the network. Ranges from 16000 to 1048574.

 Command Default
 Default SRGB range is 16000 to 23999.

 Command Modes
 Global Configuration mode

 Usage Guidelines
 To use this command, you must be in a user group associated with a task group that includes appropriate task

**Suidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

To keep the segment routing configuration simple and to make it easier to troubleshoot segment routing issues, we recommend that you use the default SRGB range on each node in the domain. However, there are instances when you might need to define a different range:

- The nodes of another vendor support a label range that is different from the default SRGB, and you want to use the same SRGB on all nodes.
- The default range is too small.
- To specify separate SRGBs for IS-IS and OSPF protocols, as long as the ranges do not overlap.

Because the values assigned from the range have domain-wide significance, we recommend that all routers within the domain be configured with the same range of values.

ID	Operation
mpls-te	read, write
	ID

#### Example

This example shows how to configure the SRGB range:

RP/0/RSP0/CPU0:router(config)# segment-routing global-block 17000 20000

Related Commands	Command	Description
	prefix-sid	Configures the segment ID (SID).

# segment-routing mapping-server

To configure the segment routing mapping server (SRMS), use the **segment-routing mapping-server** command.

**segment-routing mapping-server prefix-sid-map address-family** { **ipv4** | **ipv6** } *ip\_address/subnet\_mask* SID\_start\_value **range** range

Syntax Description	addres	ss-family { ip	v4   ipv6}	Configures the address family for IS-IS.	
	ip_ada	lress/subnet_	_mask	Specifies the prefix and mask.	
	SID_st	tart_value		Specifies the first prefix SID in the range.	
	range	range		Specifies the size of the range.	
Command Default	None				
Command Modes	Global	Configuratio	n mode		
Usage Guidelines		the user group		e in a user group associated with a task grou is preventing you from using a command, c	1 11 1
	are dist		P using the re	in the network is not important. However, singular IGP advertisement mechanism, the m	
		e of the mapp in the netwo	U	crucial. For redundancy purposes, you shou	Id configure multiple mapping
Task ID	Task ID	Operation			
	mpls-te	read, write			
	Exampl	e			

This example shows how to configure the mapping server and add prefix-SID mapping entries in the active local mapping policy:

RP/0/RSP0/CPU0:router(config)# segment-routing mapping-server prefix-sid-map address-family ipv4 10.1.1.1/32 17000 range 100

#### Related Commands

Command	Description
segment-routing prefix-sid-map advertise-local	Enables the router to advertise the SRMS entries that are locally configured.
segment-routing prefix-sid-map receive disable	Disables mapping client functionality.
show isis segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for IS-IS.
show ospf segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for OSPF.
show segment-routing mapping-server prefix-sid-map	Displays the locally configured prefix-to-SID mappings.

# segment-routing mpls

To enable segment routing for IPv4 addresses with MPLS data plane, use the **segment-routing mpls** command in IPv4 address family configuration mode. To disable segment routing, use the **no** form of this command.

#### segment-routing mpls

Syntax Description	<b>mpls</b> Enables segment routing for IPv4 addresses with MPLS data plane.
Command Default	No default behavior or values.
Command Modes	IPv4 address family configuration
	Router configuration
	Area configuration
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

# Task ID Task ID Operation ID mpls-te read, write

#### Example

This example shows how to enable segment routing with MPLS data plane.

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router isis 100
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# segment-routing mpls
```

# segment-routing prefix-sid-map advertise-local

To enable the router to advertise the segment routing mapping server (SRMS) entries that are locally configured, use the **segment-routing prefix-sid-map advertise-local** command. In addition to advertising these local SRMS entries, these mapping entries are also used to calculate segment ID (SID).

segment-routing prefix-sid-map advertise-local

Syntax Description	advertise-local Advertises the SRMS mapping entries that are locally configured.
Command Default	Disabled.
Command Modes	IPv4 address family configuration
	Router configuration
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
Task ID	Task Operation ID
	ospf read,

Example

isis

write

This example shows how to enable the router to advertise the locally configured SRMS entries:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# router ospf 1
RP/0/RSP0/CPU0:router(config-ospf)# segment-routing prefix-sid-map advertise-local
```

Related Commands	Command	Description
	segment-routing mapping-server, on page 8	Configures the segment routing mapping server (SRMS).
	segment-routing prefix-sid-map receive disable	Disables mapping client functionality.
	show isis segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for IS-IS.
	show ospf segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for OSPF.

Command	Description
show segment-routing mapping-server prefix-sid-map	Displays the locally configured prefix-to-SID mappings.

I

# segment-routing prefix-sid-map receive disable

To disable mapping client functionality, use the **segment-routing prefix-sid-map receive disable** command. To reenable client functionality, use the **segment-routing prefix-sid-map receive** command.

segment-routing prefix-sid-map receive [disable]

Syntax Description	receive Only remote SRMS mapping entries are used for SID calculation.
	disable Disable remote SRMS mapping entries received by flooding.
Command Default	Enabled.
Command Modes	IPv4 address family configuration
	Router configuration
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
	The mapping client functionality is enabled by default. When you disable client functionality, the SRMS active policy is calculated without remote SRMS entries.
	You can use this command with the <b>segment-routing prefix-sid-map advertise-local</b> command simultaneously.
Task ID	Task Operation ID
	ospf read,
	isis write
	Example
	This example shows how to disable the mapping server client functionality:
	RP/0/RSP0/CPU0:router(config)# router isis 1 RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast RP/0/RSP0/CPU0:router(config-isis-af)# segment-routing prefix-sid-map receive disable

Related Commands	Command	Description
	segment-routing mapping-server, on page 8	Configures the segment routing mapping server (SRMS).
	segment-routing prefix-sid-map advertise-local	Enables the router to advertise the SRMS entries that are locally configured.

Command	Description
show isis segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for IS-IS.
show ospf segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for OSPF.
show segment-routing mapping-server prefix-sid-map	Displays the locally configured prefix-to-SID mappings.

# show bgp egress-engineering

To display BGP egress peer engineering (EPE) information, use the **show bgp egress-engineering** command.

show bgp e	gress-engineering	
This command has no keywords or arguments.		
None		
EXEC		
Release	Modification	
Release 6.1.2	This command was introduced	
	This comma None EXEC Release Release	

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

#### Task ID Task Operation ID bgp read

#### Example

This example shows how to display BGP egress peer engineering (EPE) information:

```
RP/0/RSP0/CPU0:router2# show bgp egress-engineering
Egress Engineering Peer Set: 1.1.1.5/32 (10b48fec)
     Nexthop: 1.1.1.5
     Version: 2, rn version: 2
      Flags: 0x0000006
  Local ASN: 1
  Remote ASN: 5
   Local RID: 1.1.1.2
  Remote RID: 1.1.1.5
   First Hop: 10.1.1.9
       NHID: 0, 0
      Label: 30025, Refcount: 3
     rpc set: 10c34c24
 . .
```

# show isis segment-routing prefix-sid-map

To verify the active and backup prefix-to-SID mappings for IS-IS, use the **show isis segment-routing prefix-sid-map** command.

	show isis segment-routing prefix-sid-map [active-policy   backup-policy]
Syntax Description	<b>active-policy</b> (Optional) Specifies the active mapping policy.
	<b>backup-policy</b> (Optional) Specifies the backup mapping policy.
Command Default	None
Command Modes	EXEC
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
Task ID	Task Operation

Task ID Task Operation ID isis read

#### Example

The example shows how to verify the active mapping policy on IS-IS:

RP/0/0/CPU0:router# show isis segment-routing prefix-sid-map active-policy

IS-IS 1 active policy	7		
Prefix	SID Index	Range	Flags
1.1.1.100/32	100	20	
1.1.1.150/32	150	10	
Number of mapping en	tries: 2		

The example shows how to verify the backup mapping policy on IS-IS:

RP/0/0/CPU0:router# show isis segment-routing prefix-sid-map backup-policy

IS-IS 1 backup poli	сy		
Prefix	SID Index	Range	Flags
1.1.1.100/32	100	20	
1.1.1.150/32	150	10	
Number of mapping en	ntries: 2		

Related Commands	Command	Description
	segment-routing mapping-server, on page 8	Configures the segment routing mapping server (SRMS).
	segment-routing prefix-sid-map advertise-local	Enables the router to advertise the SRMS entries that are locally configured.
	segment-routing prefix-sid-map receive disable	Disables mapping client functionality.
	show ospf segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for OSPF.
	show segment-routing mapping-server prefix-sid-map	Displays the locally configured prefix-to-SID mappings.

# show ospf segment-routing prefix-sid-map

To verify the active and backup prefix-to-SID mappings for OSPF, use the **show ospf segment-routing prefix-sid-map** command.

show ospf segment-routing prefix-sid-map [active-policy | backup-policy]

Syntax Description	active-policy (Optional) Specifies the active mapping policy.
	<b>backup-policy</b> (Optional) Specifies the backup mapping policy.
Command Default	None
Command Modes	EXEC
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.
Task ID	Task Operation



#### Example

The example shows how to verify the active mapping policy on OSPF:

RP/0/0/CPU0:router# show ospf segment-routing prefix-sid-map active-policy

**SRMS active policy** for Process ID 1

Prefix	SID Index	Range	Flags
1.1.1.100/32	100	20	
1.1.1.150/32	150	10	

Number of mapping entries: 2

The example shows how to verify the backup mapping policy on OSPF:

RP/0/0/CPU0:router# show ospf segment-routing prefix-sid-map backup-policy

SRMS backup policyfor Process ID 1PrefixSID IndexRangeFlags1.1.1.100/32100201.1.1.150/3215010Number of mapping entries: 2

Related Commands	Command	Description
	segment-routing mapping-server, on page 8	Configures the segment routing mapping server (SRMS).
	segment-routing prefix-sid-map advertise-local	Enables the router to advertise the SRMS entries that are locally configured.
	segment-routing prefix-sid-map receive disable	Disables mapping client functionality.
	show isis segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for IS-IS.
	show segment-routing mapping-server prefix-sid-map	Displays the locally configured prefix-to-SID mappings.

### show segment-routing mapping-server prefix-sid-map

To verify the locally configured prefix-to-SID mappings, use the **show segment-routing mapping-server prefix-sid-map** command.

show segment-routing mapping-server prefix-sid-map [ipv4 | ipv6] [prefix] [detail]

Syntax Description	ipv4 (Optional) Specifies an IPv4 address family.	
	<b>ipv6</b> (Optional) Specifies an IPv6 address family.	
	prefix (Optional) Specifies a prefix.	
	detail (Optional) Displays detailed information on the prefix-to-SID mappings.	
Command Default	None	
Command Modes	EXEC	
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.	
Task ID	Task Operation ID	
	read	

#### Example

The example shows how to verify the IPv4 prefix-to-SID mappings:

RP/0/0/CPU0:router# show segment-routing mapping-server prefix-sid-map ipv4PrefixSID IndexRangeFlags20.1.1.0/2440030010.1.1.1/3210200Number of mapping entries: 2

The example shows how to display detailed information on the IPv4 prefix-to-SID mappings:

```
RP/0/0/CPU0:router# show segment-routing mapping-server prefix-sid-map ipv4 detail
Prefix
20.1.1.0/24
SID Index: 400
Range: 300
Last Prefix: 20.2.44.0/24
Last SID Index: 699
Flags:
10.1.1.1/32
SID Index: 10
Range: 200
```

Last Prefix: 10.1.1.200/32 Last SID Index: 209 Flags: Number of mapping entries: 2

#### **Related Commands**

Command	Description
segment-routing mapping-server, on page 8	Configures the segment routing mapping server (SRMS).
segment-routing prefix-sid-map advertise-local	Enables the router to advertise the SRMS entries that are locally configured.
segment-routing prefix-sid-map receive disable	Disables mapping client functionality.
show isis segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for IS-IS.
show ospf segment-routing prefix-sid-map	Displays the active and backup prefix-to-SID mappings for OSPF.

#### traceroute mpls nil-fec labels

To check network connectivity and identify LSP breakages, use the traceroute mpls nil-fec labels command.

**traceroute mpls nil-fec labels** {*label*[,*label*...]} [**output** {**interface** *tx-interface*} [**nexthop** *next-hop-ip-address*]]

Syntax Description	lahels	label,label	Specifies the label stack. Use commas to separate the each <i>label</i> .
-,			
	ouput	tinterface tx-interf	face Specifies the output interface.
	nexth next-h	<b>op</b> op-ip-address	(Optional) Causes packets to go through the specified next-hop address.
Command Default	None		
Command Modes	EXEC		
Usage Guidelines	To use this command, you must be in a user group associated with a task group that includes appropriate tas IDs. If the user group assignment is preventing you from using a command, contact your AAA administrate for assistance.		
Task ID	Task ID	Operation	
	mpls-te	e read, write	

#### Example

This example shows how to check connectivity for a known label stack using a specific output interface and next-hop address:

```
RP/0/RSP0/CPU0:router# traceroute mpls nil-fec labels 16005,16007 output interface
GigabitEthernet 0/2/0/1 nexthop 10.1.1.4
Tracing MPLS Label Switched Path with Nil FEC labels 16005,16007, timeout is 2 seconds
Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no label entry,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'd' - see DDMAP for return code,
  'X' - unknown return code, 'x' - return code 0
Type escape sequence to abort.
 0 10.1.1.3 MRU 1500 [Labels: 16005/16007/explicit-null Exp: 0/0/0]
L 1 10.1.1.4 MRU 1500 [Labels: implicit-null/16007/explicit-null Exp: 0/0/0] 1 ms
L 2 10.1.1.5 MRU 1500 [Labels: implicit-null/explicit-null Exp: 0/0] 1 ms
! 3 10.1.1.7 1 ms
```

#### Related Commands

s	Command	Description	
	ping mpls nil-fec labels	Checks network connectivity and identifying LSP breakages.	