



## **Command Reference for Cisco NCS 1020**

**First Published:** 2024-09-04

### **Americas Headquarters**

Cisco Systems, Inc.  
170 West Tasman Drive  
San Jose, CA 95134-1706  
USA  
<http://www.cisco.com>  
Tel: 408 526-4000  
800 553-NETS (6387)  
Fax: 408 527-0883





## CONTENTS

---

### CHAPTER 1

#### List of Commands 1

apc	4
apc-local	5
apc-pause	6
automatic-link-bringup	7
bfr-pause	8
bridge-port routed-interface	9
cdp	10
cdp advertise	11
cdp holdtime	12
cdp timer	13
commit	14
connector-loss	15
controller dfb	16
controller oms	19
controller osc	20
controller ots	22
controller ots-och	26
drop-psd	28
dual-band-psd	29
environment chassis-door-alarm	30
fiber-type	31
fpd auto-upgrade	32
gain-estimator	33
http client connection	34
http client response	35

http client secure-verify-host	36
http client secure-verify-peer	37
http client source interface	38
http client ssl	39
http client tcp-window-scale	40
http client version	41
http client vrf	42
hw-module	43
interface	44
ipv4-access-group	45
ipv6-access-group	46
ipv4-access-list	47
ipv6-access-list	48
ipv4 address	49
ipv6 address	50
link-tuner	51
license smart deregister	52
license smart register	53
license smart renew	54
license smart reservation install file	55
license smart transport	56
ntp	57
olc bfr-initialize	58
olc bfr-pause	59
olc start-gain-estimation	60
olc start-raman-tuning	61
optical-line-control	62
otdr auto-scan	63
otdr start	64
otdr stop	65
partner-band-port	66
pm	67
process restart	75
psd	76

psd-min	77
reload	78
server	82
show access-lists-ipv4	84
show access-lists ipv6	86
show alarms	88
show cdp	89
show configuration commit changes	92
show controllers	98
show controllers raman-info	103
show environment	105
show fpd package	112
show hw-module fpd	114
show inventory	116
show license all	120
show license summary	121
show logging onboard	124
show license platform detail	125
show license platform summary	127
show license summary	128
show license udi	129
show license usage	130
show ntp associations	131
show ntp status	135
show olc apc	137
show olc apc-local	138
show olc band-status	142
show olc gain-estimator	146
show olc link-tuner	147
show olc otdr-status	149
show olc raman-tuning	150
show olc span-loss	151
show platform	152
show version	154

span-length 156

span-loss 157

tone-pattern controller 158

tone-pattern-detect controller 159

upgrade hw-module 161

ztp clean 162

ztp initiate 163

ztp terminate 164



# List of Commands

---

This guide describes the commands supported in NCS 1020.

- [apc](#), on page 4
- [apc-local](#), on page 5
- [apc-pause](#), on page 6
- [automatic-link-bringup](#), on page 7
- [bfr-pause](#), on page 8
- [bridge-port routed-interface](#), on page 9
- [cdp](#), on page 10
- [cdp advertise](#), on page 11
- [cdp holdtime](#), on page 12
- [cdp timer](#), on page 13
- [commit](#), on page 14
- [connector-loss](#), on page 15
- [controller dfb](#), on page 16
- [controller oms](#), on page 19
- [controller osc](#), on page 20
- [controller ots](#), on page 22
- [controller ots-och](#), on page 26
- [drop-psd](#), on page 28
- [dual-band-psd](#), on page 29
- [environment chassis-door-alarm](#), on page 30
- [fiber-type](#), on page 31
- [fpd auto-upgrade](#), on page 32
- [gain-estimator](#), on page 33
- [http client connection](#), on page 34
- [http client response](#), on page 35
- [http client secure-verify-host](#), on page 36
- [http client secure-verify-peer](#), on page 37
- [http client source interface](#), on page 38
- [http client ssl](#), on page 39
- [http client tcp-window-scale](#), on page 40
- [http client version](#), on page 41
- [http client vrf](#), on page 42

- hw-module, on page 43
- interface, on page 44
- ipv4-access-group, on page 45
- ipv6-access-group, on page 46
- ipv4-access-list, on page 47
- ipv6-access-list, on page 48
- ipv4 address, on page 49
- ipv6 address, on page 50
- link-tuner, on page 51
- license smart deregister, on page 52
- license smart register, on page 53
- license smart renew , on page 54
- license smart reservation install file , on page 55
- license smart transport, on page 56
- ntp, on page 57
- olc bfr-initialize, on page 58
- olc bfr-pause, on page 59
- olc start-gain-estimation, on page 60
- olc start-raman-tuning, on page 61
- optical-line-control, on page 62
- otdr auto-scan, on page 63
- otdr start, on page 64
- otdr stop, on page 65
- partner-band-port, on page 66
- pm, on page 67
- process restart, on page 75
- psd, on page 76
- psd-min, on page 77
- reload, on page 78
- server, on page 82
- show access-lists-ipv4, on page 84
- show access-lists ipv6, on page 86
- show alarms, on page 88
- show cdp, on page 89
- show configuration commit changes, on page 92
- show controllers, on page 98
- show controllers raman-info, on page 103
- show environment, on page 105
- show fpd package, on page 112
- show hw-module fpd, on page 114
- show inventory, on page 116
- show license all, on page 120
- show logging onboard, on page 124
- show license platform detail, on page 125
- show license platform summary, on page 127
- show license summary, on page 128



- [show license udi](#), on page 129
- [show license usage](#), on page 130
- [show ntp associations](#), on page 131
- [show ntp status](#), on page 135
- [show olc apc](#), on page 137
- [show olc apc-local](#), on page 138
- [show olc band-status](#), on page 142
- [show olc gain-estimator](#), on page 146
- [show olc link-tuner](#), on page 147
- [show olc otdr-status](#), on page 149
- [show olc raman-tuning](#), on page 150
- [show olc span-loss](#), on page 151
- [show platform](#), on page 152
- [show version](#), on page 154
- [span-length](#), on page 156
- [span-loss](#), on page 157
- [tone-pattern controller](#), on page 158
- [tone-pattern-detect controller](#), on page 159
- [upgrade hw-module](#), on page 161
- [ztp clean](#), on page 162
- [ztp initiate](#), on page 163
- [ztp terminate](#), on page 164

## apc

To enable or disable APC at the link level, use the **apc** command on an OLT node.

**apc** { **disable** | **enable** }

### Syntax Description

**disable** Disable APC

**enable** Enable APC

### Command Default

(config-olc-ots)

### Command Modes

### Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

### Usage Guidelines

Use this command on an OLT node. APC can be disabled and enabled at a link level only from the APC Manager for the link.

### Example

The following is a sample configuration that disables APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

The following is a sample configuration that enables APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc enable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# apc-local

Use the **apc-local disable** command to disable APC on an agent node.

**apc-local** { **RX** | **TX** } **disable**

Syntax Description	RX	TX
	Disable APC agent in RX direction	
		Disable APC agent in TX direction
	<b>disable</b> Disable APC on APC agent.	

**Command Modes** (config-olc-ots)

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following is a sample configuration that disables APC locally.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-local RX disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

## apc-pause

Use the **apc-pause** command to pause APC.

### apc-pause

---

#### Command Modes

(config-olc-ots)

---

#### Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

---

#### Usage Guidelines

If you run the **apc-pause** command when APC is in idle state, APC remains in the idle state until APC detects changes in the network that requires power correction. APC changes the status to paused after it detects changes, but does not perform power correction.

Running the **apc-pause** command, does not pause channel startup.

#### Example

The following is a sample configuration that pauses APC.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#apc-pause
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# automatic-link-bringup

To enable automatic link bring up, use the **automatic-link-bringup** command. To disable automatic link bring up, use the no form of the command.

**automatic-link-bringup**

**no automatic-link-bringup**

---

**Command Modes** (config-olc)

---

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

---

## Example

The following sample configuration enables automatic link bring up.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#automatic-link-bringup
RP/0/RP0/CPU0:ios(config-olc)#commit
RP/0/RP0/CPU0:ios(config-olc)#end
```

The following sample configuration disables automatic link bring up.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#no automatic-link-bringup
RP/0/RP0/CPU0:ios(config-olc)#commit
RP/0/RP0/CPU0:ios(config-olc)#end
```

# bfr-pause

Use the **bfr-pause** command to pause Band Failure Recovery(BFR). When BFR is paused, the recovery and failure procedures are not initiated in case of band failure. To resume BFR, use the **no** form of this command.

**bfr-pause**

**no bfr-pause**

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Modes</b>	Controller configuration mode
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example 1

The following is a sample output to pause BFR on the controller 0/0/0/0.

```
RP/0/RP0/CPU0:#configure
RP/0/RP0/CPU0: (config)#optical-line-control
RP/0/RP0/CPU0: (config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0: (config-olc-ots)#bfr-pause
RP/0/RP0/CPU0: (config-olc-ots)#commit
```

## Example 2

The following is a sample output to resume BFR on the controller 0/0/0/0.

```
RP/0/RP0/CPU0:#configure
RP/0/RP0/CPU0: (config)#optical-line-control
RP/0/RP0/CPU0: (config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0: (config-olc-ots)#no bfr-pause
RP/0/RP0/CPU0: (config-olc-ots)#commit
```

# bridge-port routed-interface

Use the **bridge-port routed-interface** command to bridge traffic between two interfaces. For example, when connecting multiple NCS 1010 device in a Daisy Chain topology, use this command to bridge traffic between a NCS 1010 management interface and a TOR switch interface.

**bridge-port routed-interface** *type interface-path-id*

<b>Syntax Description</b>	<i>type</i>	Specify the Management Ethernet interface.
	<i>interface-path-id</i>	Specify the physical or virtual interface.
<b>Command Default</b>	None	
<b>Command Modes</b>	Interface Configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None	
<b>Task ID</b>	<b>Task ID</b>	<b>Operation</b>
	Ethernet-services	read, write

## Example

The following example shows how to bridge traffic between a NCS 1010 management port and TOR switch port:

```
RP/0/RP0/CPU0:Box(config)#interface mgmtEth0/RP0/CPU0/1
RP/0/RP0/CPU0:Box(config-if)# no ipv4 address
RP/0/RP0/CPU0:Box(config-if)# no ipv6 address
RP/0/RP0/CPU0:Box(config-if)# bridge-port routed-interface mgmtEth 0/RP0/CPU0/0
```

# cdp

To enable Cisco Discovery Protocol (CDP) globally or on an interface, use the **cdp** command in global configuration mode or in interface configuration mode. To disable CDP, use the **no** form of this command.

**cdp**

**no cdp**

---

**Syntax Description** This command has no arguments or keywords.

---



---

**Command Default** This command is enabled both at the global configuration level and at the interface configuration level.

---



---

**Command Modes** Global configuration (config) and Interface configuration (config-if)

---



---

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

---

## Example

The following example enables CDP globally.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#cdp
RP/0/RP0/CPU0:ios(config)#commit
```

The following example enables CDP on the management interface.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#interface mgmtEth 0/RP0/CPU0/1
RP/0/RP0/CPU0:ios(config-if)#cdp
RP/0/RP0/CPU0:ios(config-if)#commit
```



# cdp advertise

To enable CDP Version 1 advertising functionality on a device, use the **cdp advertise** command in global configuration mode. To disable CDP Version 1 functionality, use the **no** form of this command.

**cdp advertise v1**

**no cdp advertise v1**

<b>Syntax Description</b>	This command has no arguments or keywords.	
<b>Command Default</b>	Enabled	
<b>Command Modes</b>	Global configuration (config)	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	When CDP is enabled, the device sends CDPv2 packets by default. CDP sends and receives CDPv1 packets if the device with which CDP is interacting does not process CDPv2 packets.	

## Example

The following example configures CDP to use CDP Version 1 in communicating with neighboring devices.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#cdp advertise v1
RP/0/RP0/CPU0:ios(config)#commit
```

# cdp holdtime

To specify the amount of time the receiving device must hold a CDP packet sent from another device before discarding it, use the **cdp holdtime** command in global configuration mode. To revert to the default setting, use the **no** form of this command.

**cdp holdtime** *seconds*

**no cdp holdtime**

<b>Syntax Description</b>	<i>seconds</i> Specifies the hold time to be sent in the CDP update packets. The default is 180 seconds. The range is 10 to 255 seconds.
---------------------------	--

<b>Command Default</b>	180 seconds
------------------------	-------------

<b>Command Modes</b>	Global configuration (config)
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Usage Guidelines</b>	<p>CDP packets are sent with a time to live, or hold time, value. The receiving device will discard the CDP information in the CDP packet after the hold time has elapsed.</p> <p>You can set the hold time lower than the default setting of 180 seconds if you want the receiving devices to update their CDP information more rapidly.</p> <p>The CDP hold time must be set to a higher number of seconds than the time between CDP transmissions, which is set using the <b>cdp timer</b> command.</p>
-------------------------	--

## Example

The following example configures CDP holdtime to 120 seconds.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#cdp holdtime 120
RP/0/RP0/CPU0:ios(config)#commit
```

# cdp timer

To specify the frequency at which CDP update packets are sent., use the **cdp timer** command in global configuration mode. To revert to the default setting, use the **no** form of this command.

**cdp timer** *seconds*

**no cdp timer**

<b>Syntax Description</b>	<i>seconds</i> Specifies the frequency at which CDP update packets are sent. The default is 60 seconds. The range is 5 to 254 seconds.				
<b>Command Default</b>	60 seconds				
<b>Command Modes</b>	Global configuration (config)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	A lower timer setting causes CDP update packets to be sent more frequently.				

## Example

The following example configures CDP timer to 65 seconds.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#cdp timer 65
RP/0/RP0/CPU0:ios(config)#commit
```

# commit

To commit the target configuration to the active (running) configuration, use the **commit** command in any configuration mode.

**commit** [ **replace** ]

<b>Syntax Description</b>	<b>replace</b> Replaces the entire running configuration with the contents of the target configuration.
---------------------------	---

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Cisco IOS XR Configuration
----------------------	----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Usage Guidelines</b>	None
-------------------------	------

## Example

To remove the entire running configuration on the NCS 1010 node, use the following command:

```
Fri Apr 29 06:48:46.236 UTC
RP/0/RP0/CPU0:P2B_DT_02(config)#commit replace
Fri Apr 29 06:48:53.199 UTC
This commit will replace or remove the entire running configuration. This
operation can be service affecting.
Do you wish to proceed? [no]: yes
RP/0/RP0/CPU0:ios(config)#
RP/0/RP0/CPU0:ios(config)#end
```

# connector-loss

To configure connector loss, use the **connector-loss** command.

**connector-loss** { **rx** | **tx** } *value*

Syntax Description	rx	Connector loss at receive point
	tx	Connector loss at transmit point
	value	Connector loss in range 0–20. Unit: 1 dB

Command Default	The default connector loss is: <ul style="list-style-type: none"> <li>• 0.25 dB for ports without Raman module</li> <li>• 0.3 dB for ports with Raman module</li> </ul>
-----------------	---

Command Modes	(config-olc-ots)
---------------	------------------

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example is a sample configuration that configures rx and tx connector losses to 0.1 dB.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#connector-loss rx 1
RP/0/RP0/CPU0:ios(config-olc-ots)#connector-loss tx 1
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# controller dfb

To configure the DFB controller, use the **controller dfb** command in the controller configuration mode.

```
controller dfb R/S/I/P [ tx-voa-attenuation value | tx-low-threshold value | sec-admin-state
{normal | maintenance} | transmit-shutdown | shutdown ]
```

Syntax Description		
<b>R/S/I/P</b>		Rack/Slot/Instance/Port of the DFB controller.
<b>tx-voa-attenuation</b> <i>value</i>		Configures the DFB TX VoA attenuation set point.
<b>tx-low-threshold</b> <i>value</i>		Configures the low transmit power threshold.
<b>sec-admin-state</b>		Configures the administrative state of the controller. The values are maintenance or normal.
<b>transmit-shutdown</b>		Shuts down the DFB laser.
<b>shutdown</b>		Disables the configuration of the controller.

**Command Default** None

**Command Modes** controller configuration mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** None

## Example

In the following sample, the tx-voa-attenuation is set to 2 dB.

```
RP/0/RP0/CPU0:ios#config
Thu Apr 21 17:00:57.654 UTC
RP/0/RP0/CPU0:ios(config)#
RP/0/RP0/CPU0:ios(config)#controller dfb 0/0/0/0 tx-voa-attenuation 20
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

To view the configured value, use the following command:

```
RP/0/RP0/CPU0:ios#sh controller dfb 0/0/0/0
Thu Apr 21 17:02:06.316 UTC
Controller State: Up
Transport Admin State: In Service
Laser State: On
Alarm Status:
-----
Detected Alarms: None
Alarm Statistics:
-----
```

```

RX-LOS-P = 0
TX-POWER-FAIL-LOW = 0
Parameter Statistics:
-----
Total TX Power = 20.00 dBm
Total RX Power = 10.00 dBm
TX Voa Attenuation = 2.0 dB
Configured Parameters:
-----
TX Voa Attenuation = 2.0 dB

```

The DFB laser attenuates based on the updated value and the TX power changes accordingly.

In the following sample, the sec-admin-state is set to maintenance.

```

RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller dfb 0/0/0/0 sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
RP/0/RP0/CPU0:ios#sh controllers dfb 0/0/0/0
Thu Apr 21 17:05:41.311 UTC
Controller State: Up
Transport Admin State: Maintenance
Laser State: On
Alarm Status:
-----
Detected Alarms: None
Alarm Statistics:
-----
RX-LOS-P = 0
TX-POWER-FAIL-LOW = 0
Parameter Statistics:
-----
Total TX Power = 20.00 dBm
Total RX Power = 10.00 dBm
TX Voa Attenuation = 2.0 dB
Configured Parameters:
-----
TX Voa Attenuation = 2.0 dB

```

In the following sample, the DFB controller is shut down.

```

RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller dfb 0/0/0/0 shutdown
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
RP/0/RP0/CPU0:ios#sh controllers dfb 0/0/0/0
Thu Apr 21 17:08:40.211 UTC
Controller State: Administratively Down
Transport Admin State: Out Of Service
Laser State: Off
Alarm Status:
-----
Detected Alarms: None
Alarm Statistics:
-----
RX-LOS-P = 0
TX-POWER-FAIL-LOW = 0
Parameter Statistics:
-----
Total TX Power = -50.00 dBm
Total RX Power = 10.00 dBm
TX Voa Attenuation = 2.0 dB
Configured Parameters:

```

```
-----  
TX Voa Attenuation = 2.0 dB
```



## controller-oms

To configure the OMS controller, use the **controller oms** command in the controller OTS configuration mode.

Use the following parameters to configure different configurations for an OMS controller on breakout or multiplexer/demultiplexer module.

**controller oms** *R/S/I/P* [ **tone-rate** ] [ **tone-pattern-expected** ] [ **tone-detect-oob** ]

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OMS controller.
	<b>tone-rate</b> <i>value</i>	Configures the tone rate for tone generation.
	<b>tone-pattern-expected</b> <i>value</i>	Checks for the transmitted tone pattern from the OTS controller or terminal device.
	<b>tone-detect-oob</b> <i>value</i>	Detects the out-of-band (OOB) frequency transmitted from the OTS controller or the terminal device.
<b>Command Default</b>	None	
<b>Command Modes</b>	controller configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.1	Introduced this command.

### Example

The following output is a sample of configuring various tone generation parameters using the **controller oms 0/0/0/0** command.

```
RP/0/RP0/CPU0:(config)#controller oms 0/2/0/0
RP/0/RP0/CPU0:(config-Oms)#tone-rate 25
RP/0/RP0/CPU0:(config-Oms)#tone-pattern-expected abcd1234
RP/0/RP0/CPU0:(config-Oms)#tone-detect-oob
RP/0/RP0/CPU0:(config-Oms)#commit
```

# controller osc

To configure the OSC controller, use the **controller osc** command in the controller configuration mode.

```
controller osc R/S/I/P [ transmit-power value | sec-admin-state {normal | maintenance} | tx-low-threshold value | shutdown ]
```

Syntax Description		
<b>R/S/I/P</b>		Rack/Slot/Instance/Port of the OSC controller.
<b>transmit-power</b> <i>value</i>		Configures the transmit power.
<b>sec-admin-state</b>		Configures the administrative state of the controller. The values are maintenance or normal.
<b>tx-low-threshold</b> <i>value</i>		Configures low transmit power threshold
<b>shutdown</b>		Disables the configuration of the controller.

**Command Default** None

**Command Modes** Controller configuration mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** None

## Example

In the following sample, the transmit-power is set to 2 dBm. The transmit power can be changed only after the OSC laser probing loop is closed and the OSC transmit power is stable. The OSC transmit power depends on the span length. If the span loss is high, the OSC Tx power is low and vice versa.

```
RP/0/RP0/CPU0:ios(config)#controller osc 0/0/0/0 transmit-power 20
Fri May 13 11:26:53.445 UTC
WARNING! Changing TX power can impact traffic
RP/0/RP0/CPU0:ios(config)#commit
Fri May 13 11:26:55.127 UTC
RP/0/RP0/CPU0:ios(config)#end
RP/0/RP0/CPU0:ios#sh controllers osc 0/0/0/0
Fri May 13 11:26:59.542 UTC
Controller State: Up
Transport Admin State: In Service
Laser State: On
Alarm Status:
-----
Detected Alarms: None
Alarm Statistics:
-----
RX-LOS-P = 0
```

```

TX-POWER-FAIL-LOW = 0
Parameter Statistics:
-----
Total TX Power = 1.89 dBm
Total RX Power = -17.30 dBm

```

```

Configured Parameters:
-----

```

In the following sample, the sec-admin-state is set to maintenance.

```

RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller osc 0/0/0/0 sec-admin-state maintenance
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
RP/0/RP0/CPU0:ios#sh controllers osc 0/0/0/0
Fri Apr 22 15:55:36.324 UTC
Controller State: Up
Transport Admin State: Maintenance
Laser State: On
Alarm Status:
-----
Detected Alarms: None
Alarm Statistics:
-----
RX-LOS-P = 0
TX-POWER-FAIL-LOW = 0
Parameter Statistics:
-----
Total TX Power = -10.00 dBm
Total RX Power = -30.00 dBm
Configured Parameters:
-----

```

In the following sample, the OSC controller is shut down.

```

RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller osc 0/0/0/0 shutdown
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
RP/0/RP0/CPU0:ios#sh controllers os 0/0/0/0
Tue Apr 12 17:33:12.998 UTC
Controller State: Administratively Down
Transport Admin State: Out Of Service
Laser State: Off
Alarm Status:
-----
Detected Alarms: None
Alarm Statistics:
-----
RX-LOS-P = 0
TX-POWER-FAIL-LOW = 0
Parameter Statistics:
-----
Total TX Power = -50.00 dBm
Total RX Power = -30.00 dBm
Configured Parameters:
-----

```

## controller ots

To configure the OTS controller, use the **controller ots** command in the controller OTS configuration mode.

Use the following parameters to configure different configurations for an OTS controller on an NCS 1020 node.

```

controller ots R/S/I/P [ tx-voa-attenuation value ] [ egress-ampli-gain-range {normal | extended} ]
[ egress-ampli-gain value ] [ egress-ampli-tilt value ] [ egress-ampli-osri {on | off} ] [
egress-ampli-safety-control-mode {auto | disabled} ] [ egress-ampli-force-apr {on | off} ] [
ingress-ampli-gain-range {normal | extended} ] [ ingress-ampli-gain value ] [ raman-tx-power
Raman-transmit-pump-instance ] [ power power-value ] [ raman-tx-power-disable
Raman-transmit-pump-instance ] [ raman-force-apr {on | off} ] [ raman-osri {on | off} ] [ ] [ otdr
scan-mode expert ] [ otdr rx auto reflectance-threshold value ] [ otdr rx auto splice-loss-threshold
value ] [ otdr rx expert pulse-width value ] [ otdr tx auto reflectance-threshold value ] [ otdr tx
auto splice-loss-threshold value ] [ raman-tx-power <1-N> value value ] [ otdr rx auto raman-setpoint
value ] [ otdr tx auto raman-setpoint value ] [ otdr rx auto excess-reflection-threshold value ] [
otdr tx auto excess-reflection-threshold value ] [ otdr rx back-scattering value ] [ otdr tx
back-scattering value ] [ otdr rx refractive-index value ] [ otdr tx refractive-index value ] [ otdr
rx expert pulse-width value ] [ otdr tx expert pulse-width value ] [ otdr rx expert capture-end value
] [ otdr tx expert capture-end value ] [ otdr rx expert capture-start value ] [ otdr tx expert
capture-start value ] [ otdr rx expert scan duration value ] [ otdr tx expert scan duration value ] [
otdr rx auto excess-orl-threshold value ] [ otdr tx auto excess-orl-threshold value ] [ otdr rx auto
excess-attenuation-threshold value ] [ otdr tx auto excess-attenuation-threshold value ]

```

```

controller ots R/S/I/P [ tone-rate ] [ tone-pattern-expected ] [ tone-frequency ]

```

Syntax Description	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.
<b>tx-voa-attenuation</b> <i>value</i>		Configures the TX VoA attenuation set point.
<b>egress-ampli-gain-range</b> { <b>normal</b>   <b>extended</b> }		Configures egress amplification gain range to normal or extended.
<b>egress-ampli-gain</b> <i>value</i>		Configures egress amplification gain.
<b>egress-ampli-tilt</b> <i>value</i>		Configures egress amplifier tilt.
<b>egress-ampli-osri</b> { <b>on</b>   <b>off</b> }		Enables or disables egress optical safety remote interlock (OSRI).
<b>egress-ampli-safety-control-mode</b> { <b>auto</b>   <b>disabled</b> }		Configure egress amplification safety control mode to auto or disables it.
<b>egress-ampli-force-apr</b> { <b>on</b>   <b>off</b> }		Enables or disables egress amplification force automatic power reduction.
<b>raman-tx-power</b> <i>Raman-transmit-pump-instance</i> <b>power</b> <i>power-value</i>		Configures Raman transmit power parameters.

<b>raman-tx-power-disable</b> <i>Raman-transmit-pump-instance</i>	Disables Raman transmit power.
<b>raman-force-apr {on   off}</b>	Enables or disables Raman force APR.
<b>raman-osri {on   off}</b>	Enables or disables Raman optical safety remote interlock (OSRI).
<b>ingress-ampli-gain-range {normal   extended}</b>	Configure ingress amplification safety control mode to auto or disables it.
<b>ingress-ampli-gain</b> <i>value</i>	Configures ingress amplification gain.
<b>otdr rx auto reflectance-threshold</b> <i>value</i>	Configures OTDR reflectance threshold in RX direction in auto mode.
<b>otdr rx auto splice-loss-threshold</b> <i>value</i>	Configures OTDR splice loss threshold in RX direction in auto mode.
<b>otdr rx expert pulse-width</b> <i>value</i>	Configures OTDR pulse width threshold in RX direction in expert mode.
<b>otdr tx auto reflectance-threshold</b> <i>value</i>	Configures OTDR reflectance threshold in TX direction in auto mode.
<b>otdr tx auto splice-loss-threshold</b> <i>value</i>	Configures OTDR splice loss threshold in TX direction in auto mode.
<b>otdr scan-mode expert</b>	Configures OTDR scan in expert.
<b>raman-tx-power &lt;1-N&gt; value</b> <i>value</i>	Configures the target Raman transmit power value for multiple instances.
<b>otdr rx auto raman-setpoint</b> <i>value</i>	Configures OTDR Raman in RX direction in auto mode.
<b>otdr tx auto raman-setpoint</b> <i>value</i>	Configures OTDR Raman in TX direction in auto mode.
<b>otdr rx auto excess-reflection-threshold</b> <i>value</i>	Configures OTDR excess reflection threshold in RX direction in auto mode.
<b>otdr tx auto excess-reflection-threshold</b> <i>value</i>	Configures OTDR excess reflection threshold in TX direction in auto mode.
<b>otdr rx back- scattering</b> <i>value</i>	Configures OTDR back scattering in RX direction.
<b>otdr tx back- scattering</b> <i>value</i>	Configures OTDR back scattering in TX direction.
<b>otdr rx refractive-index</b> <i>value</i>	Configures OTDR refractive index in RX direction in auto mode.
<b>otdr tx refractive-index</b> <i>value</i>	Configures OTDR refractive index in TX direction in auto mode.
<b>otdr rx expert pulse-width</b> <i>value</i>	Configures OTDR pulse width in RX direction in expert mode.

<b>otdr tx expert pulse-width</b> <i>value</i>	Configures OTDR pulse width in TX direction in expert mode.
<b>otdr rx expert capture-end</b> <i>value</i>	Configures OTDR capture end time in RX direction in expert mode.
<b>otdr tx expert capture-end</b> <i>value</i>	Configures OTDR capture end time in TX direction in expert mode.
<b>otdr rx expert capture-start</b> <i>value</i>	Configures OTDR capture start time in RX direction in expert mode.
<b>otdr tx expert capture-start</b> <i>value</i>	Configures OTDR capture start time in TX direction in expert mode.
<b>otdr rx expert scan duration</b> <i>value</i>	Configures OTDR scan duration in RX direction in expert mode.
<b>otdr tx expert scan duration</b> <i>value</i>	Configures OTDR scan duration in TX direction in expert mode.
<b>otdr rx auto excess-orl-threshold</b> <i>value</i>	Configures OTDR excess Optical Return Loss (ORL) threshold in RX direction in auto mode.
<b>otdr tx auto excess-orl-threshold</b> <i>value</i>	Configures OTDR excess ORL threshold in TX direction in auto mode.
<b>otdr rx auto excess-attenuation-threshold</b> <i>value</i>	Configures OTDR excess attenuation threshold in RX direction in auto mode.
<b>otdr tx auto excess-attenuation-threshold</b> <i>value</i>	Configures OTDR excess attenuation threshold in TX direction in auto mode.
<b>tone-rate</b> <i>value</i>	Configures the tone rate for tone generation.
<b>tone-pattern</b> <i>value</i>	Configures the tone pattern for tone generation.
<b>tone-frequency</b> <i>value</i>	Configures the tone frequency for tone generation.

<b>Command Default</b>	None				
<b>Command Modes</b>	controller configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				

### Example

The following output is a sample of configuring various `otdr` parameters using the `controller ots 0/0/0/0` command.

```
RP/0/RP0/CPU0:ios#RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-Ots)#otdr scan-mode expert
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto reflectance-threshold -50
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto splice-loss-threshold 200
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx expert pulse-width 6000
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto excess-orl-threshold 600
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto excess-reflection-threshold -35
RP/0/RP0/CPU0:ios(config-Ots)#otdr rx auto excess-attenuation-threshold 5
RP/0/RP0/CPU0:ios(config-Ots)#otdr tx auto reflectance-threshold -50
RP/0/RP0/CPU0:ios(config-Ots)#otdr tx auto splice-loss-threshold 200
RP/0/RP0/CPU0:ios(config-Ots)#otdr tx auto excess-orl-threshold 600
RP/0/RP0/CPU0:ios(config-Ots)#otdr tx auto excess-reflection-threshold -50
RP/0/RP0/CPU0:ios(config-Ots)#otdr tx auto excess-attenuation-threshold 5
RP/0/RP0/CPU0:ios(config-Ots)#commit
```

The following output is a sample of configuring various tone generation parameters using the **controller ots 0/0/0/4** command.

```
RP/0/RP0/CPU0:(config)#controller ots 0/0/0/4
RP/0/RP0/CPU0:(config-Ots)#tone-rate 25
RP/0/RP0/CPU0:(config-Ots)#tone-frequency 191.175 ( OOB frequency )
RP/0/RP0/CPU0:(config-Ots)#tone-pattern abcd1234
RP/0/RP0/CPU0:(config-Ots)#commit
```

# controller ots-och

To configure the OTS-OCH controller on the add-drop port to which the cross-connection is made on the COM side, use the **controller ots-och** command in the controller configuration mode.

**controller ots-och** *R/S/I/P/channel-id* **add-drop-channel ots-och** *R/S/I/P/channel-id*

<b>Syntax Description</b>	<i>R/S/I/P/channel-id</i> Rack/Slot/Instance/Port/Channel-id of the OTS-OCH controller.				
	<b>add-drop-channel</b> Creates the add/drop channel on the COM side.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Controller configuration mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	None				

## Example

To configure the optical cross-connect, use the following commands:

```
Mon Apr 4 14:54:32.834 UTC
RP/0/RP0/CPU0:ios(config)#controller ots-och 0/0/0/0/1 add-drop-channel ots-och 0/0/0/33/1
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)
```

To view the OTS-OCH controllers, use the following command:

```
RP/0/RP0/CPU0:ios#sh controller ots-och ?
0/0/0/0/1 Ots-Och Interface Instance
0/0/0/33/1 Ots-Och Interface Instance
R/S/I/P/B or R/S/I/P Forward interface in Rack/Slot/Instance/Port/Breakout format or
R/S/I/P format
```

To view the parameters of the OTS-OCH controller (LINE side), use the following command:

```
RP/0/RP0/CPU0:ios#sh controllers ots-och 0/0/0/0/1
Tue Apr 5 06:32:29.696 UTC
```

```
Controller State: Up
```

```
Transport Admin State: In Service
```

```
Alarm Status:
-----
Detected Alarms: None
```

```
Alarm Statistics:
-----
RX-LOS-P = 0
```



```
TX-POWER-FAIL-LOW = 0
```

```
Parameter Statistics:
```

```
-----
```

```
Total RX Power = -10.50 dBm
```

```
Total TX Power = -10.50 dBm
```

```
Cross Connect Info:
```

```
-----
```

```
Add-Drop Channel = Ots-Och0/0/0/33/1
```

```
Configured Parameters:
```

```
-----
```

```
RP/0/RP0/CPU0:ios#
```



---

**Note** The Add/Drop channel that is cross connected to the line port, 0/0/0/1 is displayed in the output.

---

# drop-psd

Use the **drop-psd** command to set the target PSD for drop ports.

**drop-psd** *value*

<b>Syntax Description</b>	<i>value</i> PSD in range -30.0 dBm per 12.5 GHz to 23.0 dBm per 12.5 GHz in increments of 0.1 dBm per 12.5 GHz.
---------------------------	--

<b>Command Default</b>	The default target PSD for drop ports is -9.4 dB.
------------------------	---

<b>Command Modes</b>	(config-olc-ots)
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Usage Guidelines</b>	The NCS 1010 applies drop PSD configuration for channels with cross connect configurations.
-------------------------	---

## Example

The following is a sample configuration that sets the target PSD at drop ports to -25 dB.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#drop-psd -250
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# dual-band-psd

Use the **dual-band-psd** command to set the target dual-band PSDs when using C+L band configuration.

**dual-band-psd** *index* *value*

## Syntax Description

*index* PSD index 1–33.

*value* PSD in range -50.0 dBm per 12.5 GHz to -32.0 dBm per 12.5 GHz in increments of 0.1 dBm per 12.5 GHz.

## Command Modes

(config-olc-ots)

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example shows how to set the dual band psd values -50 and -49 on setpoints 1 and 2 respectively, on the 0/0/0/0 controller .

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#dual-band-psd 1 -50
RP/0/RP0/CPU0:ios(config-olc-ots)#dual-band-psd 2 -49
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# environment chassis-door-alarm

Use the **environment chassis-door-alarm** command to report the door alarm when closing and opening the door.

Enable Chassis Door Alarm Command  
**Enable Chassis Door Alarm Command**  
**environment chassis-door-alarm enable**

Disable Chassis Door Alarm Command  
**Disable Chassis Door Alarm Command**  
**no environment chassis-door-alarm enable**

Syntax Description	environment chassis-door-alarm enable	Enables chassis door alarm.
	no environment chassis-door-alarm enable	Disables chassis door alarm.

**Command Default** The chassis door alarm is disabled.

**Command Modes** Global configuration (config)

Command History	Release	Modification
	Cisco IOS XR Release 24.3.1	This command was introduced.

**Usage Guidelines** Use this command to enable or disable the chassis door alarm.

## Example

The following example shows how to enable the chassis door alarm:

```
RP/0/RP0/CPU0:ios(config)#environment chassis-door-alarm enable
RP/0/RP0/CPU0:ios(config)#commit
Fri May 24 11:26:14.715 UTC
```

The following example shows how to disable the chassis door alarm:

```
RP/0/RP0/CPU0:ios(config)#no environment chassis-door-alarm enable
RP/0/RP0/CPU0:ios(config)#commit
Fri May 24 11:26:14.715 UTC
RP/0/RP0/CPU0:May 24 11:26:14.880 UTC: envmon[190]: %PKT_INFRA-FM-4-FAULT_MINOR : ALARM_MINOR
:Chassis Door alarm :CLEAR :0:
```

# fiber-type

To configure fiber type, use **fiber-type** command.

**fiber-type** *type*

<b>Syntax Description</b>	<p><i>type</i> Fiber type. Possible fiber types are:</p> <ul style="list-style-type: none"> <li>• E-LEAF</li> <li>• FREE-LIGHT</li> <li>• METRO-CORE</li> <li>• SMF</li> <li>• SMF-28E</li> <li>• TERA-LIGHT</li> <li>• TW-RS</li> <li>• TW-Reach</li> <li>• TW-minus</li> <li>• TW-plus</li> <li>• ULL-SMF28</li> </ul>				
<b>Command Default</b>	SMF is the default fiber-type.				
<b>Command Modes</b>	(config-olc-ots)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				

## Example

The following example is a sample configuration that configures fiber-type to SMF.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#fiber-type SMF
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# fpd auto-upgrade

To enable or disable automatic FPD upgrade, use the **fpd auto-upgrade** command in Cisco IOS XR Configuration mode.

```
fpd auto-upgrade { enable | disable }
```

<b>Syntax Description</b>	<b>enable   disable</b>	Enables or disables automatic FPD upgrade
<b>Command Default</b>	Automatic FPD upgrade is enabled.	
<b>Command Modes</b>	Cisco IOS XR Configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example shows how to disable automatic FPD upgrade.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#fpd auto-upgrade disable
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

# gain-estimator

To enable or disable Gain Estimator, use the **gain-estimator** command.

```
gain-estimator { disable | enable }
```

## Syntax Description

**disable** Disable Gain Estimator

**enable** Enable Gain Estimator

## Command Modes

(config-olc-ots)

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following output is a sample configuration that disables Gain Estimator.

```
RP/0/RP0/CPU0:ios#configure terminal
Mon Jun 13 05:35:20.510 UTC
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#gain-estimator disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
```

The following output is a sample configuration that enables Gain Estimator.

```
RP/0/RP0/CPU0:ios#configure terminal
Mon Jun 13 05:35:27.511 UTC
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#gain-estimator enable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
```

# http client connection

To configure the connection for http client, use the **http client connection** command in XR Config mode. To restore the default value, use the **no** form of this command.

```
http client connection { retry count | timeout seconds }
```

Syntax Description	retry count	timeout seconds
	Specifies how many times HTTP Client resends a connection request. Range is from 1 to 5. The default value is 0.	The time interval (in seconds) that HTTP client waits for a server connection to establish before giving up. Range is from 1 to 60 seconds. The default value is 10 seconds.

**Command Default** The connection retry is not configured by default. The default connection timeout is set to 10 seconds.

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Command Modes** HTTP configuration

**Usage Guidelines** Use this command to set the connection timeout or connection retry count.

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to configure the connection request retry to two times:

```
RP/0/RP0/CPU0:router(config)#http client connection retry 2
```

The following example shows how to configure the connection request timeout to 20 seconds:

```
RP/0/RP0/CPU0:router(config)#http client connection timeout 20
```



# http client response

To configure the time interval (in seconds) for HTTP Client to wait for a response from the server before giving up, use the **http client response** command in XR Config mode. To restore the default value, use the **no** form of this command.

```
http client response { timeout seconds }
```

<b>Syntax Description</b>	<b>timeout</b> <i>seconds</i>	The time interval (in seconds) that HTTP client waits for a response from the server before giving up. Range is from 1 to 300 seconds. The default value is 30 seconds.
<b>Command Default</b>	The response timeout is 30 seconds by default.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Command Modes</b>	HTTP configuration	
<b>Usage Guidelines</b>	Use this command to configure the response timeout.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to configure the response timeout to 40 seconds:

```
RP/0/RP0/CPU0:router(config)#http client response timeout 40
```

# http client secure-verify-host

To enable verifying host in peer's certificate, use the **http client secure-verify-host** command in XR Config mode. To restore the default value, use the **no** form of this command.

## http client secure-verify-host

<b>Syntax Description</b>	<b>secure-verify-host</b> Verifies the host in peer's certificate. This is enabled by default. To disable, use the command <b>http client secure-verify-host <i>disable</i></b>	
<b>Command Default</b>	Host verification is enabled by default.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Command Modes</b>	HTTP configuration	
<b>Usage Guidelines</b>	Use the <b>http client secure-verify-host</b> command to disable the host verification.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to disable host verification :

```
RP/0/RP0/CPU0:router (config) #http client secure-verify-host disable
```

# http client secure-verify-peer

To enable verifying authenticity of the peer certificate, use the **http client secure-verify-peer** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client secure-verify-peer**

<b>Syntax Description</b>	<b>secure-verify-peer</b> Verifies authenticity of the peer certificate. This is enabled by default. To disable, use the command <b>http client secure-verify-peer disable</b>				
<b>Command Default</b>	Peer verification is enabled by default.				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Command Modes</b>	HTTP configuration				
<b>Usage Guidelines</b>	Use the <b>http client secure-verify-peer</b> command to disable the peer verification.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>config-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	config-services	read, write
Task ID	Operations				
config-services	read, write				

The following example shows how to disable peer verification :

```
RP/0/RP0/CPU0:router (config) #http client secure-verify-peer disable
```

# http client source interface

To specify the interface for source address for Hypertext Transfer Protocol (HTTP) connections, use the **http client source-interface** command in XR Config mode. To remove the **http client source-interface** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

**http client source-interface** { **ipv4** | **ipv6** }

<b>Syntax Description</b>	<b>ipv4</b>	Enter ipv4 address from interface. <i>ip-address</i>
	<b>ipv6</b>	Enter ipv6 address from interface. <i>ip-address</i>
<b>Command Default</b>	No default behavior or values.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Command Modes</b>	HTTP configuration	
<b>Usage Guidelines</b>	Use the <b>http client source-interface</b> command to configure ipv4 and ipv6 source interfaces. If both the source interfaces are configured, then the source interface is selected depending on the host DNS resolution.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to configure ipv4 source interface for HTTP connection:

```
RP/0/RP0/CPU0:router(config)#http client source-interface ipv4 gigabitEthernet 0/0/0/0
```

The following example shows how to configure ipv6 source interface for HTTP connection:

```
RP/0/RP0/CPU0:router(config)#http client source-interface ipv6 gigabitEthernet 0/0/0/0
```

# http client ssl

To configure Secure Socket Layer (SSL) version to be used for HTTPS requests, use the **http client ssl** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client ssl** *version*

<b>Syntax Description</b>	<p><b>ssl version</b> Specify the SSL version to be used for HTTPS requests. Select one of the following versions:</p> <ul style="list-style-type: none"> <li>• <b>tls1.0</b> - Forces TLSv1.0 to be used for HTTPS requests.</li> <li>• <b>tls1.1</b> - Forces TLSv1.1 to be used for HTTPS requests.</li> <li>• <b>tls1.2</b> - Forces TLSv1.2 to be used for HTTPS requests.</li> </ul> <p>By default libcurl does not force the TLS version.</p>
---------------------------	--

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Command Default** By default, the SSL version is not configured.

**Command Modes** HTTP configuration

**Usage Guidelines** Use this command to configure the ssl version to be used in HTTPS requests.

Task ID	Task ID	Operations
	config-servicess	read, write

The following example shows how to configure the SSL version to tls1.1:

```
RP/0/RP0/CPU0:router(config)#http client ssl tls1.1
```

# http client tcp-window-scale

To configure the TCP window scale factor for high latency links, use the **http client tcp-window-scale** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client tcp-window-scale** *scale*

<b>Syntax Description</b>	<i>scale</i> Specify the TCP window scale for HTTP requests. Range is 1 to 14.
---------------------------	--

<b>Command Default</b>	By default, TCP window scale is disabled.
------------------------	---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Command Modes</b>	HTTP configuration
----------------------	--------------------

<b>Usage Guidelines</b>	Use this command to configure the TCP window scale for HTTP requests.
-------------------------	---



<b>Note</b>	Currently, this is enabled for copying of files using HTTP.
-------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows how to set the TCP window scale to 10:

```
RP/0/RP0/CPU0:router (config) #http client tcp-window-scale 10
```

# http client version

To configure the HTTP version to be used for HTTP requests, use the **http client version** command in XR Config mode. To restore the default value, use the **no** form of this command.

**http client version** *version*

<b>Syntax Description</b>	<p><b>version</b><i>version</i> Specify the HTTP version to be used for HTTP requests. Select one of the following versions:</p> <ul style="list-style-type: none"> <li>• <b>1.0</b> - Forces HTTP1.0 to be used for all HTTP requests.</li> <li>• <b>1.1</b> - Forces HTTP1.1 to be used for all HTTP requests.</li> <li>• <b>default</b> - libcurl picks up HTTP version automatically.</li> </ul>
---------------------------	--

<b>Command Default</b>	By default, libcurl does not force the HTTP version.
------------------------	--



<b>Note</b>	HTTP Client uses libcurl version 7.30
-------------	---------------------------------------

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Command Modes</b>	HTTP configuration
----------------------	--------------------

<b>Usage Guidelines</b>	Use this command to configure the HTTP version to be used in HTTP requests.
-------------------------	---

Task ID	Task ID	Operations
	config-services	read, write

The following example shows how to configure the HTTP version to 1.1:

```
Router(config)#http client version 1.1
```

# http client vrf

To configure a new VRF to be used by the HTTP client, use the **http client vrf** command. To remove the specified vrf, use the **no** form of this command.

**http client vrf** *vrf-name*

<b>Syntax Description</b>	<i>vrf-name</i> Specifies the name of the VRF to be used by the HTTP client.
---------------------------	--

<b>Command Default</b>	If not configured, the default VRF "default-vrf" will be used.
------------------------	--

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Command Modes</b>	HTTP configuration
----------------------	--------------------

<b>Usage Guidelines</b>	A HTTP client can have only one VRF. If a specific VRF is not configured for the HTTP client, the default VRF is assumed.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	config-services	read, write

The following example shows the HTTP client being configured to start with the specified VRF:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# http client vrf green
```



# hw-module

To create the OTS-OCH controller, use the **hw-module location** command in IOS XR configuration mode.

**hw-module location** *location* **terminal-ampli** | **inline-ampli** **grid-mode** *mode* **channel-id** *channel-id*  
**centre-freq** *frequency* **width** *channel width*

Syntax Description	
<i>location</i>	Specifies the location of the hardware module. The location is 0/0/NXR0.
<b>terminal-ampli</b>   <b>inline-ampli</b>	terminal-ampli is used for OLT nodes and inline-ampli is used for ILA nodes.
<b>grid-mode</b> <i>value</i>	Specifies the optical spectrum on the interfaces.
<b>centre-freq</b> <i>frequency</i>	Defines the central frequency of the channel.
<b>width</b> <i>channel-width</i>	Defines the width of the channel.

**Command Default** None

**Command Modes** Cisco IOS XR Configuration

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** None

## Example

To create the OTS-OCH controller on the LINE side of an ILA-C node, use the following commands:

```
RP/0/RP0/CPU0:ios#config
Thu Apr 7 13:14:49.841 UTC
RP/0/RP0/CPU0:ios(config)#
RP/0/RP0/CPU0:ios(config)#hw-module location 0/0/NXR0 inline-ampli grid-mode flex
RP/0/RP0/CPU0:ios(config-hwmod-ila-flexi)#channel-id 1 centre-freq 196.1 width 75
RP/0/RP0/CPU0:ios(config-hwmod-ila-flexi)# commit
```

To create the OTS-OCH controller on the LINE side of an OLT-R-C node, use the following commands:

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#hw-module location 0/0/nxr0 terminal-ampli grid-mode flex
RP/0/RP0/CPU0:ios(config-hwmod-olt-flexi)#channel-id 1 centre-freq 196.1 width 75
RP/0/RP0/CPU0:ios(config-hwmod-olt-flexi)#commit
```

# interface

Use the **interface** command in the config mode to enter the configuration mode of a management interface. To delete the configuration, use the **no** form of this command.

```
interface type interface-path-id
no interface type interface-path-id
```

<b>Syntax Description</b>	<i>type</i>	Interface type.
	<i>interface-path-id</i>	Physical interface or virtual interface.

**Command Default** None

**Command Modes** Configuration Mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 24.2.1	This command was introduced.

**Usage Guidelines** To use this command, you must be in a user group associated with a task group that includes appropriate task ID's. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	otn	write

**Examples** This example shows how to enter the configuration mode of *mgmtEth* interface:

```
RP/0/RP0/CPU0:Box(config)#interface mgmtEth0/RP0/CPU0/1
```

# ipv4-access-group

To control access to an interface, use the **ipv4 access-group** command in interface configuration mode. To remove the specified access group, use the **no** form of this command.

**ipv4 access-group** *access-list-name* { **ingress** | **egress** } [ **compress level** *compression-level* ]

Syntax Description		
<i>access-list-name</i>	Name of an IPv4 access list as specified by an <b>ipv4 access-list</b> command.	
<b>ingress</b>	Filters on inbound packets.	
<b>egress</b>	Filters on outbound packets.	
<b>compress level</b> <i>compression-level</i>	Configures compression level for interface ACLs. Compression level values range from zero and two.	

**Command Default** The interface does not have an IPv4 access list applied to it.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** Use the **ipv4 access-group** command to control access to an interface. To remove the specified access group, use the **no** form of the command. Use the *access-list-name* argument to specify a particular IPv4 access list.

If the access list permits the addresses, the software continues to process the packet. If the access list denies the address, the software discards the packet and returns an Internet Control Message Protocol (ICMP) host unreachable message.

If the specified access list does not exist, all packets are passed.

Task ID	Task ID	Operations
	acl	read, write

**Examples** The following example shows how to apply the access list named IPV4-ACL to the management interface:

```
RP/0/RP0/CPU0:ios(config)# interface mgmtEth 0/RP0/CPU0/0
RP/0/RP0/CPU0:ios(config-if)# ipv4 access-group IPV4-ACL ingress
RP/0/RP0/CPU0:ios(config-if)# commit
```

# ipv6-access-group

To control access to an interface, use the **ipv6 access-group** command in interface configuration mode. To remove the specified access group, use the **no** form of this command.

**ipv6 access-group** *access-list-name* { **ingress** | **egress** } [ **compress level** *compression-level* ]

Syntax Description		
	<i>access-list-name</i>	Name of an IPv6 access list as specified by an <b>ipv6 access-list</b> command.
	<b>ingress</b>	Filters on inbound packets.
	<b>egress</b>	Filters on outbound packets.
	<b>compress level</b> <i>compression-level</i>	Configures compression level for interface ACLs. Compression level values range from zero and two.

**Command Default** The interface does not have an IPv6 access list applied to it.

**Command Modes** Interface configuration

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** Use compression level two to create Hybrid ACLs with an ACE that uses IPv6 extension headers to filter ingress and egress IPv6 packets.

Task ID	Task ID	Operations
	acl	read, write

**Examples** The following example shows how to apply the access list named IPV6-ACL to the management interface:

```
RP/0/RP0/CPU0:ios(config)# interface mgmtEth 0/RP0/CPU0/0
RP/0/RP0/CPU0:ios(config-if)# ipv6 access-group IPV6-ACL ingress
RP/0/RP0/CPU0:ios(config-if)# commit
```

## ipv4-access-list

To define an IPv4 access list by name, use the **ipv4 access-list** command in IOS XR Config mode. To remove all entries in an IPv4 access list, use the **no** form of this command.

```
ipv4 access-list name
no ipv4 access-list name
```

<b>Syntax Description</b>	<i>name</i> Name of the access list. Names cannot contain a space or quotation marks.				
<b>Command Default</b>	No IPv4 access list is defined.				
<b>Command Modes</b>	IOS XR Config mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	<p>Use the <b>ipv4 access-list</b> command to configure an IPv4 access list. This command places the system in access list configuration mode, in which the denied or permitted access conditions must be defined with the <b>deny</b> or <b>permit</b> command.</p> <p>Use the <b>ipv4 access-group</b> command to apply the access list to an interface.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>acl</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	acl	read, write
Task ID	Operations				
acl	read, write				

### Examples

This example shows how to define a standard access list named ACL:

```
RP/0/RP0/CPU0:ios(config)# ipv4 access-list ACL
RP/0/RP0/CPU0:ios(config-ipv4-acl)# 10 permit tcp 192.0.2.2 255.255.255.0 any
RP/0/RP0/CPU0:ios(config-ipv4-acl)# 20 deny udp any any
RP/0/RP0/CPU0:ios(config-ipv4-acl)# 30 permit ipv4 192.0.2.64 255.255.255.0 any
RP/0/RP0/CPU0:ios(config-ipv4-acl)# commit
```

# ipv6-access-list

To define an IPv6 access list by name, use the **ipv6 access-list** command in IOS XR Config mode. To remove all entries in an IPv6 access list, use the **no** form of this command.

```

ipv6 access-list name
no ipv6 access-list name

```

<b>Syntax Description</b>	<i>name</i> Name of the access list. Names cannot contain a space or quotation mark, or begin with a numeric.
---------------------------	---

<b>Command Default</b>	No IPv6 access list is defined.
------------------------	---------------------------------

<b>Command Modes</b>	IOS XR Config mode
----------------------	--------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Usage Guidelines</b>	<p>The IPv6 access lists are used for traffic filtering based on source and destination addresses, IPv6 option headers, and optional, upper-layer protocol type information for finer granularity of control. IPv6 access lists are defined by using the <b>ipv6 access-list</b> command in XR Config mode and their permit and deny conditions are set by using the <b>deny</b> and <b>permit</b> commands in IPv6 access list configuration mode. From IPv6 access list configuration mode, permit and deny conditions can be set for the defined IPv6 access list.</p>
-------------------------	---

The **ipv6 access-list** command is similar to the **ipv4 access-list** command, except that it is IPv6-specific.

Use the **ipv6 access-group** command to apply the access list to an interface.

Every IPv6 access list has an implicit **deny ipv6 any any** statement as its last match condition. An IPv6 access list must contain at least one entry for the implicit **deny ipv6 any any** statement to take effect.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read, write

<b>Examples</b>	This example shows how to define a standard access list named ACL:
-----------------	--

```

RP/0/RP0/CPU0:ios(config)# ipv6 access-list ACL
RP/0/RP0/CPU0:ios(config-ipv6-acl)# 10 permit ipv6 any any
RP/0/RP0/CPU0:ios(config-ipv6-acl)# 20 deny udp any any
RP/0/RP0/CPU0:ios(config-ipv6-acl)# commit

```

# ipv4 address

Use the **ipv4 address** command in the interface configuration mode to configure IPv4 address for an interface. To remove the IPv4 address from an interface, use the **no** form of this command.

**ipv4 address**  
**no ipv4 address**

## Command Default

None

## Command Modes

Interface Configuration mode

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

## Task ID

Task ID	Operation
otn	write

## Example

This example shows how to configure IPv4 address on an interface.

```
RP/0/RP0/CPU0:Box(config-if)# ipv4 address 192.0.2.6/24
```

## Example

This example shows how to remove IPv4 address from an interface.

```
RP/0/RP0/CPU0:Box(config-if)# no ipv4 address
```

# ipv6 address

Use the **ipv6 address** command in the interface configuration mode to configure IPv6 address for an interface. To remove the IPv6 address from an interface, use the **no** form of this command.

**ipv6 address**  
**no ipv6 address**

---

**Command Default**

None

---

**Command Modes**

Interface Configuration mode

---

**Command History**

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

---

**Usage Guidelines**

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

---

**Task ID**

Task ID	Operation
otn	write

**Example**

This example shows how to configure IPv6 address on an interface.

```
RP/0/RP0/CPU0:Box(config-if)# ipv6 address 0:0:0:7272::72/64
```

**Example**

This example shows how to remove IPv6 address from an interface.

```
RP/0/RP0/CPU0:Box(config-if)# no ipv6 address
```



# link-tuner

To enable and disable link tuner and to configure the spectrum density, use the **link-tuner** command.

**link-tuner** { **enable** | **disable** | **spectrum-density** *value* }

Syntax Description	enable	Enable Link-Tuner
	<b>disable</b>	Disable Link-Tuner
	<b>spectrum-density</b>	Configure spectrum density
	<i>value</i>	Spectrum density in range 1–100 in increments of 1

**Command Default** The default spectrum density is 81.

**Command Modes** (config-olc-ots)

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following is a sample configuration that enables link tuner.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner enable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

The following is a sample configuration that disables link tuner.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner disable
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

The following example is a sample configuration that configures the spectrum density to 80%.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#link-tuner spectrum-density 80
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# license smart deregister

To cancel the registration of your device, use the **license smart deregister** command.

## license smart deregister

---

<b>Command Default</b>	None
------------------------	------

---

<b>Command Modes</b>	None
----------------------	------

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	R7.7.1	This command was introduced.

---

---

<b>Usage Guidelines</b>	When your device is taken off the inventory, shipped elsewhere for redeployment or returned to Cisco for replacement using the return merchandise authorization (RMA) process, you can use this command to cancel the registration on your device. All smart licensing entitlements and certificates on the platform are removed.
-------------------------	---

The following example deregisters NCS 1010.

```
RP/0/RP0/CPU0:ios#license smart deregister
```

# license smart register

To register the device instance with Cisco licensing cloud, use the **license smart register idtoken *token-id* force** command.

**license smart register idtoken *token-id* [ force ]**

## Syntax Description

*token\_id* Specifies the token generated in smart manager.

**force** If the registration fails due to communication failure between the device and the portal, the system waits for 24 hours before attempting to register the device again. Use this option to force the registration.

## Command Default

None

## Command Modes

None

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

Use this command to register the device instance with Cisco licensing cloud.

The following example registers and sets the token ID required for registration of NCS 1004.

```
RP/0/RP0/CPU0:ios#license smart register
YzY2ZjYyNjktY2NlOS00NTc4LWlxNTAtMjZkNmNiNzMxMTY1LlTE2NjAzNjQ3
%0ANzY4Nj18ZVJSckxKN2pFV2tIeHVomUkxbGxTazFDVm9kc1B5MGlHQmlFWUJi%0Ac3VNRT0%3D%0A
```

# license smart renew

To manually renew the ID certification or authorization, use the **license smart renew** command.

**license smart renew** { **ID** | **auth** }

## Syntax Description

**ID** ID certificates are renewed automatically after six months. In case, the renewal fails, the product instance goes into unidentified state. You can manually renew the ID certificate using this option.

**auth** Authorization periods are renewed by the Smart Licensing system every 30 days. As long as the license is in an 'Authorized' or 'Out-of-compliance' (OOC), the authorization period is renewed. Use this command to make an on-demand manual update of your registration. Thus, instead of waiting 30 days for the next registration renewal cycle, you can use this option to instantly find out the status of your license.

After 90 days, the authorization period expires and the status of the associated licenses display "AUTH EXPIRED". Use this option to retry the authorization period renewal. If the retry is successful, a new authorization period begins.

## Command Default

None

## Command Modes

None

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

None

The following example manually renews the ID certificate for the NCS 1010:

```
RP/0/RP0:ios#license smart renew id
```

The following example manually renews the authorization for the NCS 1010:

```
RP/0/RP0:ios#license smart renew auth
```

# license smart reservation install file

To register the device using the authorization code that is copied as a file, and to activate smart licensing reservation for your device, use the **license smart reservation install file** command.

**license smart reservation install file** *file name*

<b>Syntax Description</b>	file name	Name of the file where the authorization code is saved.
<b>Command Default</b>	None	
<b>Command Modes</b>	None	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None	

The following example registers and activates the registration and license for NCS 1010:

```
RP/0/RP0/CPU0:ios#license smart reservation install file /disk0:/smart1
Tue Jul 19 13:46:22.877 UTC
RP/0/RP0/CPU0:Jul 19 13:46:22.946 UTC: plat_sl_client[368]:
%LICENSE-PLAT_CLIENT-6-STATE_CHANGE :
Licensing platform state changing from UNREGISTERED to REGISTERED
RP/0/RP0/CPU0:Jul 19 13:46:22.946 UTC: smartlicserver[247]:
%LICENSE-SMART_LIC-6-AGENT_REG_SUCCESS
: Smart Agent for Licensing Registration successful. udi PID:NCS1010-SA,SN:FCB2546B08T
Reservation install file successful
Last Confirmation code 8572aa81
```

# license smart transport

To configure the smart transport as an alternative option to Call Home, use the **license smart transport** command.

## license smart transport smart

---

**Command Default** None

---

**Command Modes** None

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

---



---

**Usage Guidelines** None

The following example configures the smart transport option to connect to the CSSM.

```
RP/0/RP0/CPU0:ios#license smart transport smart
Thu Jul 19 13:34:47.251 UTC
RP/0/RP0/CPU0:ios#commit
```

# ntp

To enter Network Time Protocol (NTP) configuration mode and run NTP configuration commands, use the **ntp** command in global configuration mode.

## ntp

### Syntax Description

This command has no keywords or arguments.

### Command Default

No default behavior or values.

### Command Modes

Global configuration

### Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

### Task ID

Task ID	Operations
ip-services	read, write

The following example shows how to enter NTP configuration mode:

```
RP/0/RP0/CPU0:ios(config)#ntp
RP/0/RP0/CPU0:ios(config-ntp)#
```

# olc bfr-initialize

Use the **olc bfr-initialize** command to initialize the Band Failure Recovery(BFR) feature.

**olc bfr-initialize controller ots** *R/S/I/P*

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.
	<b>controller Ots</b>	Use this parameter to choose a particular controller.

<b>Command Modes</b>	Privileged EXEC mode
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following is a sample output of the **olc bfr-initialize** command that initializes BFR.

```
RP/0/RP0/CPU0:ios#olc bfr-initialize controller ots 0/0/0/0
```



## olc bfr-pause

Use the **olc bfr-pause** command to enable or disable Band Failure Recovery(BFR) pause. In case of band failure, when BFR pause is enabled, the recovery procedure is not initiated and the surviving band is not switched to single-band PSD profile.

**olc bfr-pause controller ots** *Rack/Slot/Instance/Port* { **enable** | **disable** }

Syntax Description	controller Ots	Use this parameter to choose a particular controller.
	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.
	<b>enable</b>	Use this keyword to temporarily pause BFR.
	<b>disable</b>	Use this keyword to disable BFR pause.

**Command Modes** Privileged EXEC mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

The following is a sample output of the **olc bfr-pause** command that enables the BFR pause feature and temporarily pauses BFR.

```
RP/0/RP0/CPU0:ios#olc bfr-pause controller ots 0/0/0/0 enable
```

The following is a sample output of the **olc bfr-pause** command that disables the BFR pause feature.

```
RP/0/RP0/CPU0:ios#olc bfr-pause controller ots 0/0/0/0 disable
```

# olc start-gain-estimation

Use the **olc start-gain-estimation** command to trigger the gain estimation operation.

**olc start-gain-estimation controller ots** *R/S/I/P*

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OSC controller.
	<b>controller Ots</b>	Use this parameter to choose a particular controller.

**Command Modes** Privileged EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following output is a sample of the **olc start-gain-estimation controller ots 0/0/0/0** command.

```
RP/0/RP0/CPU0:ios#olc start-gain-estimation controller ots 0/0/0/0
```

## olc start-raman-tuning

Use the **olc start-raman-tuning** command to trigger Raman tuning.

**olc start-raman-tuning controller ots** *R/S/I/P*

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OSC controller.
	<b>controller Ots</b>	Use this parameter to choose a particular controller.

<b>Command Modes</b>	Privileged EXEC mode
----------------------	----------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

# optical-line-control

To use the optical applications configuration mode, use the **optical-line-control** command.

## **optical-line-control**

---

<b>Command Modes</b>	Global configuration mode (config)
----------------------	------------------------------------

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

---

## otdr auto-scan

Use the **otdr auto-scan** command to enable or disable the auto otdr scan

**otdr auto-scan** [ **enable** | **disable** ]

Syntax Description	enable	disable
	Enables OTDR auto scan.	Disables OTDR auto scan.

**Command Modes** Controller configuration mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

### Example

The following are sample configurations that enable and disable automatic OTDR scan.

```
RP/0/RP0/CPU0:ios#configure
Mon Sep 18 13:11:53.812 UTC
RP/0/RP0/CPU0:IOS(config)#optical-line-control controller Ots 0/0/0/0
RP/0/RP0/CPU0:IOS(config-olc-ots)#otdr auto-scan enable
RP/0/RP0/CPU0:IOS(config-olc-ots)#commit

RP/0/RP0/CPU0:ios#configure
Mon Sep 3 13:28:34.631 UTC
RP/0/RP0/CPU0:IOS(config)#optical-line-control controller Ots 0/0/0/0
RP/0/RP0/CPU0:IOS(config-olc-ots)#otdr auto-scan disable
RP/0/RP0/CPU0:IOS(config-olc-ots)#commit
```

## otdr start

Use the **otdr-start controller ots** command to start the otdr operation.

**otdr-start controller ots** *R/S/I/P direction*

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.
	<b>otdr-start controller ots</b>	Use this parameter to start the otdr operation in a particular direction.
	<i>direction</i>	Scan direction (RX or TX)

**Command Modes** Privileged EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

### Example

The following output is a sample of enabling and disabling automatic OTDR scan.

# otdr stop

Use the **otdr-stop controller ots** command to stop the otdr operation.

**otdr-stop controller ots** *R/S/I/P direction*

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.
	<b>otdr-stop controller ots</b>	Use this parameter to stop the otdr operation in a particular direction.
	<i>direction</i>	Scan direction (RX or TX)

**Command Modes** Privileged EXEC mode

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

```
RP/0/RP0/CPU0:ios#otdr-stop controller ots 0/0/0/0 tx
OTS OTDR Scan Stopped at TX
```

# partner-band-port

Use the **partner-band-port** command to establish a connection between C and L-band nodes by configuring the L-band peer IP on C-band node and C-band peer IP on L-band node.

**partner-band-port** **ipv4** *address* **controller** **ots** *Rack/Slot/Instance/Port*

Syntax Description		
	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.
	<b>ipv4</b> <i>address</i>	Specify the IP address of the peer node.
	<b>controller</b> <b>Ots</b>	Use this parameter to choose a particular controller.
	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OTS controller.

**Command Modes** Privileged EXEC mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example 1

The following is a sample output of the **partner-band-port** command that configures the peer node IP address 192.0.2.1 on the C-band node.

```
RP/0/RP0/CPU0:ios# optical-line-control controller Ots0/0/0/0
RP/0/RP0/CPU0:ios# partner-band-port ipv4 address 192.0.2.1 controller Ots0/0/0/0
```



# pm

To configure the performance monitoring parameters of the OTS, OTS-OCH, OSC, and DFB controllers, use the **pm** command in the controller configuration mode.

For more information about PM threshold values for the controllers, see the section, Monitor performance.

```
pm [ flex-bin | 15-min | 30-sec | 24-hour ] [ ots | ots-och | osc | dfb ] [ report | threshold ] [ eagn
| eatl | iagn | iatl | slr-cl | slt-cl | opbr | opr | opr-cl | opt | opt-s | raman-1
| raman-2 | raman-3 | raman-4 | raman-5 | raman-tot ] [ max-tca | min-tca ] [
enable | value ]
```

## Syntax Description

<b>flex-bin   15-min   30-sec   24-hour</b>	Configures performance monitoring parameters for 10 seconds, 15 minutes, 30 seconds, or 24-hour intervals.
<b>ots   ots-och   osc   dfb</b>	Specifies whether to configure performance monitoring parameters for the OTS, OTS-OCH, OSC, or DFB controllers.
<b>history</b>	Displays the historical values of the <b>pm</b> command.
<b>report</b>	Configures the TCA reporting status for optics (OTS-OCH, OSC, or DFB) or OTS parameters.
<b>threshold</b>	Configures thresholds on optics (OTS-OCH, OSC, or DFB) or OTS parameters.
<b>iagn   eagn</b>	Configures thresholds for ingress or egress amplifier gain.
<b>iatl   eatl</b>	Configures the thresholds for ingress or egress amplifier tilt.
<b>slr-cl   slt-cl</b>	Configures the thresholds for span loss in Rx or Tx direction.
<b>opr   opr-cl   opr-s</b>	Configures thresholds for total Rx power, total Rx power for C and L band, or total C band signal power.
<b>opbr</b>	Configures thresholds for back reflection power.
<b>opt   opt-s</b>	Configures thresholds for total Tx power or total C band signal power.
<b>raman-1   raman-2   raman-3   raman-4   raman-5   raman-tot</b>	Configures thresholds for Raman power (1, 2, 3, 4, or 5) or total Raman pump power.
<b>max-tca   min-tca enable</b>	Enable the maximum or minimum TCA reporting status.
<i>value</i>	Value of the thresholds.

## Command Default

None

## Command Modes

Controller configuration

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** None

### Examples

The following examples shows how to view the configured maximum and minimum threshold values and the current span loss values for both Tx and Rx direction.

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/0 pm current 15-min optics 1
Optics in the current interval [06:30:00 - 06:37:00 Tue May 17 2022]
Optics current bucket type : Valid
Configured TCA
```

	MIN	AVG	MAX	Operational	Configured	TCA	Operational
Threshold (max)				Threshold (min)	Threshold (min)		
OPT [dBm]	: 20.00	20.00	20.00	-20.00	NA	NO	40.00
NO							
OPR [dBm]	: 20.00	20.00	20.00	-30.00	NA	NO	18.00
NO							
OPT (C+L) [dBm]	: 20.00	20.00	20.00	-20.00	NA	NO	60.85
NO							
OPR (C+L) [dBm]	: -10.00	-10.00	-10.00	-30.00	NA	NO	36.00
NO							
OPT (S) [dBm]	: 20.00	20.00	20.00	-5.00	NA	NO	28.00
NO							
OPR (S) [dBm]	: 20.00	20.00	20.00	-30.00	NA	NO	18.00
NO							
OPBR [dBm]	: -30.00	-30.00	-30.00	-30.00	NA	NO	-14.09
NO							
EAGN [dB]	: 30.00	30.00	30.00	16.00	NA	NO	20.00
YES							
<b>SLR (C+L) [dB]</b>	<b>: 4.46</b>	<b>4.49</b>	<b>4.50</b>	<b>0.00</b>	<b>NA</b>	<b>NO</b>	<b>42.00</b>
NO							
<b>SLT (C+L) [dB]</b>	<b>: 0.09</b>	<b>0.09</b>	<b>0.09</b>	<b>0.00</b>	<b>NA</b>	<b>NO</b>	<b>42.00</b>
NO							
EATL [dB]	: -4.80	-4.80	-4.80	-5.00	NA	NO	5.00
NO							
IAGN [dB]	: 25.00	25.00	25.00	12.00	NA	NO	25.00
NO							
IATL [dB]	: -2.40	-2.40	-2.40	-5.00	NA	NO	5.00
NO							
RAMAN-TOT [mW]	: 300.00	300.00	300.00	200.00	NA	NO	1410.00
NO							
RAMAN-1 [mW]	: 45.00	45.00	45.00	45.00	NA	NO	390.00
NO							
RAMAN-2 [mW]	: 40.00	40.00	40.00	40.00	NA	NO	390.00
NO							
RAMAN-3 [mW]	: 40.00	40.00	40.00	40.00	NA	NO	220.00
NO							
RAMAN-4 [mW]	: 40.00	40.00	40.00	40.00	NA	NO	220.00
NO							
RAMAN-5 [mW]	: 35.00	35.00	35.00	35.00	NA	NO	190.00
NO							

Last clearing of "show controllers OPTICS" counters never

The following sample sets the reporting status to maximum TCA for the eagn parameter of the OTS controller for a 15-minute interval.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller ots 0/0/0/0 pm 15-min ots report eagn max-tca enable
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

The following sample configures the maximum threshold for the eagn parameter of the OTS controller to 20 dB.

```
RP/0/RP0/CPU0:ios#config
RP/0/RP0/CPU0:ios(config)#controller ots 0/0/0/0 pm 15-min ots threshold eagn max 2000
RP/0/RP0/CPU0:ios(config)#commit
RP/0/RP0/CPU0:ios(config)#end
```

To view the current PM parameters on an OTS controller for a 15 minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#sh controllers ots 0/0/0/0 pm current 15-min optics 1
Tue May 17 06:37:00.529 UTC
```

Optics in the current interval [06:30:00 - 06:37:00 Tue May 17 2022]

```
Optics current bucket type : Valid
          MIN          AVG          MAX          Operational Configured      TCA      Operational
Configured TCA
          Threshold(max) Threshold(max(max)
OPT [dBm] : 20.00      20.00      20.00      -20.00      NA          NO      40.00      NA
          NO
OPR [dBm] : 20.00      20.00      20.00      -30.00      NA          NO      18.00      NA
          NO
OPT (C+L) [dBm] : 20.00      20.00      20.00      -20.00      NA          NO      60.85      NA
          NO
OPR (C+L) [dBm] : -10.00      -10.00      -10.00      -30.00      NA          NO      36.00      NA
          NO
OPT (S) [dBm] : 20.00      20.00      20.00      -5.00      NA          NO      28.00      NA
          NO
OPR (S) [dBm] : 20.00      20.00      20.00      -30.00      NA          NO      18.00      NA
          NO
OPBR [dBm] : -30.00      -30.00      -30.00      -30.00      NA          NO      -14.09      NA
          NO
EAGN [dB] : 30.00      30.00      30.00      16.00      NA          NO      20.00      20.00
YES
EATL [dB] : -4.80      -4.80      -4.80      -5.00      NA          NO      5.00      NA
          NO
IAGN [dB] : 25.00      25.00      25.00      12.00      NA          NO      25.00      NA
          NO
IATL [dB] : -2.40      -2.40      -2.40      -5.00      NA          NO      5.00      NA
          NO
RAMAN-TOT [mW] : 300.00      300.00      300.00      200.00      NA          NO      1410.00      NA
          NO
RAMAN-1 [mW] : 45.00      45.00      45.00      45.00      NA          NO      390.00      NA
          NO
RAMAN-2 [mW] : 40.00      40.00      40.00      40.00      NA          NO      390.00      NA
          NO
RAMAN-3 [mW] : 40.00      40.00      40.00      40.00      NA          NO      220.00      NA
          NO
RAMAN-4 [mW] : 40.00      40.00      40.00      40.00      NA          NO      220.00      NA
```

```

NO
RAMAN-5 [mW] : 35.00      35.00      35.00      35.00      NA          NO      190.00      NA
NO

```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters on an OTS controller for a 15 minute interval, use the following command:

```

RP/0/RP0/CPU0:ios#sh controllers ots 0/0/0/0 pm history 15-min optics 1 bucket 1
Tue May 17 07:02:26.911 UTC

```

Optics in interval 1 [06:45:00 - 07:00:00 Tue May 17 2022]

Optics history bucket type : Valid

	MIN	AVG	MAX
OPT [dBm] :	20.00	20.00	20.00
OPR [dBm] :	20.00	20.00	20.00
OPT (C+L) [dBm]:	20.00	20.00	20.00
OPR (C+L) [dBm]:	-10.00	-10.00	-10.00
OPT (S) [dBm] :	20.00	20.00	20.00
OPR (S) [dBm] :	20.00	20.00	20.00
OPBR [dBm] :	-30.00	-30.00	-30.00
EAGN [dB] :	30.00	30.00	30.00
EATL [dB] :	-4.80	-4.80	-4.80
IAGN [dB] :	25.00	25.00	25.00
IATL [dB] :	-2.40	-2.40	-2.40
RAMAN-TOT [mW]:	300.00	300.00	300.00
RAMAN-1 [mW] :	45.00	45.00	45.00
RAMAN-2 [mW] :	40.00	40.00	40.00
RAMAN-3 [mW] :	40.00	40.00	40.00
RAMAN-4 [mW] :	40.00	40.00	40.00
RAMAN-1 [mW] :	35.00	35.00	35.00

To view the current PM parameters on an OTS-OCH controller for a 15 minute interval, use the following command:

```

P/0/RP0/CPU0:ios#sh controllers ots-och 0/0/0/0/1 pm current 15-min optics 1
Tue May 17 10:27:20.387 UTC

```

Optics in the current interval [10:15:00 - 10:27:20 Tue May 17 2022]

Optics current bucket type : Valid

	MIN	AVG	MAX	Operational Threshold(min)	Configured Threshold(min)	TCA (min)	Operational Threshold(max)	Configured Threshold(max)	TCA (max)
OPT [dBm] :	1.20	1.30	1.30	-30.00	NA	NO	15.00	NA	NO
OPR [dBm] :-	12.31	12.25	12.20	-30.00	NA	NO	15.00	NA	NO

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters on an OSC controller for a 15 minute interval, use the following command:

```

RP/0/RP0/CPU0:ios#sh controller osc 0/0/0/0 pm current 15-min optics 1
Tue May 17 08:24:32.642 UTC

```

Optics in the current interval [08:15:00 - 08:24:32 Tue May 17 2022]

Optics current bucket type : Valid

	MIN	AVG	MAX	Operational Threshold(min)	Configured Threshold(min)	TCA (min)	Operational Threshold(max)	Configured Threshold(max)	TCA (max)
OPT [dBm] :	-10.00	-10.00	-10.00	-20.00	NA	NO	12.00	NA	NO
OPR [dBm] :	-30.00	-30.00	-30.00	-30.00	NA	NO	0.00	NA	NO

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters on an DFB controller for a 15 minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#sh controller dfb 0/0/0/0 pm current 15-min optics 1
Tue May 17 08:28:37.455 UTC
```

```
Optics in the current interval [08:15:00 - 08:28:37 Tue May 17 2022]
```

```
Optics current bucket type : Valid
```

	MIN	AVG	MAX	Operational Threshold (min)	Configured Threshold (min)	TCA (min)	Operational Threshold (max)	Configured Threshold (max)	TCA (max)
OPT[dBm]:	20.00	20.00	20.00	-25.23	NA	NO	18.00	NA	NO
OPR[dBm]:	10.00	10.00	10.00	-30.00	NA	NO	12.00	NA	NO

```
Last clearing of "show controllers OPTICS" counters never
```

To view the current PM parameters for an OCH controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm current 30-sec optics 1
```

```
Tue May 10 11:28:29.896 UTC
```

```
Optics in the current interval [11:28:00 - 11:28:29 Tue May 10 2022]
```

```
Optics current bucket type : Valid
```

Configured	MIN	AVG	MAX	Operational Threshold(min)	Configured Threshold(min)	TCA (min)	Operational Threshold(max)	
Threshold(max)	(max)							
OPT[dBm]	-50.00	-50.00	-50.00	-30.00	NA	NO	15.00	NA
OPR[dBm]	-50.00	-50.00	-50.00	-30.00	NA	NO	15.00	NA

```
Last clearing of "show controllers OPTICS" counters never
```

To view the historical PM parameters on an OCH controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm history 30-sec optics 1 bucket 1
```

```
Mon Jul 25 05:35:52.176 UTC
```

```
Optics in interval 1 [05:35:00 - 05:35:30 Mon Jul 25 2022]
```

```
Optics history bucket type : Valid
```

	MIN	AVG	MAX
OPT[dBm]	-50.00	-50.00	-50.00
OPR[dBm]	-50.00	-50.00	-50.00

```
Last clearing of "show controllers OPTICS" counters never
```

To view the current PM parameters for an OCH controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm current 15-min optics 1
```

```
Tue May 10 11:28:50.952 UTC
```

```
Optics in the current interval [11:15:00 - 11:28:50 Tue May 10 2022]
```

```
Optics current bucket type : Valid
```

Configured	MIN	AVG	MAX	Operational Threshold(min)	Configured Threshold(min)	TCA (min)	Operational Threshold(max)
Threshold(max)	(max)						

```

OPT[dBm]      : -50.00   -50.00   -50.00   -30.00           NA           NO   15.00           NA
                NO
OPR[dBm]      : -50.00   -50.00   -50.00   -30.00           NA           NO   15.00           NA
                NO

```

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters for an OCH controller for a 15-minute interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm history 15-min optics 1 bucket 1
```

Mon Jul 25 05:36:12.167 UTC

Optics in interval 1 [05:15:00 - 05:30:00 Mon Jul 25 2022]

Optics history bucket type : Valid

```

                MIN      AVG      MAX
OPT[dBm]      : -50.00   -50.00   -50.00
OPR[dBm]      : -50.00   -50.00   -50.00

```

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters on an OCH controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm current 24-hour optics 1
```

Tue May 10 11:29:09.270 UTC

Optics in the current interval [00:00:00 - 11:29:09 Tue May 10 2022]

Optics current bucket type : Invalid

```

                MIN      AVG      MAX      Operational      Configured      TCA      Operational
Configured      TCA
                Threshold(min)  Threshold(min)  (min)  Threshold(max)
Threshold(max) (max)
OPT[dBm]      : -50.00   -50.00   -50.00   -30.00           NA           NO   15.00           NA
                NO
OPR[dBm]      : -50.00   -50.00   -50.00   -30.00           NA           NO   15.00           NA
                NO

```

Last clearing of "show controllers OPTICS" counters never

```
RP/0/RP0/CPU0:ios#
```

To view the historical PM parameters on an OCH controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers och 0/1/0/0 pm history 24-hour optics 1
```

Mon Jul 25 05:36:35.165 UTC

Optics in interval 1 [00:00:00 - 24:00:00 Sun Jul 24 2022]

Optics history bucket type : Valid

```

                MIN      AVG      MAX
OPT[dBm]      : -50.00   -50.00   -50.00
OPR[dBm]      : -50.00   -50.00   -50.00

```

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters for an OMS controller for a 30-second interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm current 30-sec optics 1
```

Mon Jul 25 07:24:38.319 UTC

Optics in the current interval [07:24:30 - 07:24:38 Mon Jul 25 2022]

Optics current bucket type : Valid  
 MIN AVG MAX Operational Configured TCA Operational Configured TCA  
 Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)  
 OPT[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO  
 OPR[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters on an OMS controller for a 30-second interval, use the following command:

RP/0/RP0/CPU0:ios#**show controllers oms 0/3/0/8 pm history 30-sec optics 1 bucket 1**

Mon Jul 25 07:13:51.228 UTC

Optics in interval 1 [07:13:00 - 07:13:30 Mon Jul 25 2022]

Optics history bucket type : Valid  

	MIN	AVG	MAX
OPT[dBm]	-50.00	-50.00	-50.00
OPR[dBm]	-50.00	-50.00	-50.00

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters for an OMS controller for a 15-minute interval, use the following command:

RP/0/RP0/CPU0:ios#**show controllers oms 0/3/0/8 pm current 15-min optics 1**

Mon Jul 25 07:25:00.183 UTC

Optics in the current interval [07:15:00 - 07:25:00 Mon Jul 25 2022]

Optics current bucket type : Valid  
 MIN AVG MAX Operational Configured TCA Operational Configured TCA  
 Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)  
 OPT[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO  
 OPR[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO

Last clearing of "show controllers OPTICS" counters never

To view the historical PM parameters for an OMS controller for a 15-minute interval, use the following command:

RP/0/RP0/CPU0:ios#**show controllers oms 0/3/0/8 pm history 15-min optics 1 bucket 1**

Mon Jul 25 07:14:03.090 UTC

Optics in interval 1 [06:45:00 - 07:00:00 Mon Jul 25 2022]

Optics history bucket type : Valid  

	MIN	AVG	MAX
OPT[dBm]	-50.00	-50.00	-50.00
OPR[dBm]	-50.00	-50.00	-50.00

Last clearing of "show controllers OPTICS" counters never

To view the current PM parameters on an OMS controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm current 24-hour optics 1
```

```
Mon Jul 25 07:26:09.817 UTC
```

```
Optics in the current interval [00:00:00 - 07:26:09 Mon Jul 25 2022]
```

```
Optics current bucket type : Valid
```

```
MIN AVG MAX Operational Configured TCA Operational Configured TCA
Threshold(min) Threshold(min) (min) Threshold(max) Threshold(max) (max)
OPT[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
OPR[dBm] : -50.00 -50.00 -50.00 -30.00 NA NO 15.00 NA NO
```

```
Last clearing of "show controllers OPTICS" counters never
```

To view the historical PM parameters on an OMS controller for a 24-hour interval, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers oms 0/3/0/8 pm history 24-hour optics 1
```

```
Mon Jul 25 07:18:13.532 UTC
```

```
Optics in interval 1 [00:00:00 - 24:00:00 Sun Jul 24 2022]
```

```
Optics history bucket type : Valid
```

```
MIN AVG MAX
OPT[dBm] : -50.00 -50.00 -50.00
OPR[dBm] : -50.00 -50.00 -50.00
```

```
Last clearing of "show controllers OPTICS" counters never
```



## process restart

To restart the license registration process, use the **license smart reservation** command.

**process restart smartlicserver location** *location*

---

### Syntax Description

**location** Specifies the node-id.

---



---

### Command Default

None

---

### Command Modes

None

---

### Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

---



---

### Usage Guidelines

None

The following example restarts the smart licensing process:

```
RP/0/RP0/CPU0:ios#RP/0/RP0/CPU0:ios(config)#process restart smartlicserver location
0/RP0/CPU0
```

# psd

Use the **psd** command to set the target PSDs.

**psd** *index value*

## Syntax Description

*index* PSD index 1–33.

*value* PSD in range -30.0 dBm per 12.5 GHz to 23.0 dBm per 12.5 GHz in increments of 0.1 dBm per 12.5 GHz.

## Command Modes

(config-olc-ots)

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

You can configure the target power spectral densities for 33 points across the band. The 33 PSD values divide the entire spectrum into 150-GHz steps. APC uses the corresponding PSD value if the channel frequency corresponds to a configured point. If the central frequency is not on a configured position, APC computes the target PSD for a channel by extrapolating from the two adjacent steps.

## Example

The following is a sample configuration that sets the psd to 15 dB for the setpoints 1 and 2.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#psd 1 150
RP/0/RP0/CPU0:ios(config-olc-ots)#psd 2 150
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# psd-min

Use the **psd-min** command to set the desired minimum PSD.

**psd-min** *value*

<b>Syntax Description</b>	<i>value</i> PSD in range -40.0 dBm per 12.5 GHz to 23.0 dBm per 12.5 GHz in increments of 0.1 dBm per 12.5 GHz.				
<b>Command Default</b>	The default minimum PSD is -24 dB.				
<b>Command Modes</b>	(config-olc-ots)				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				

## Example

The following is a sample configuration that sets the minimum PSD to -25 dB.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#psd-min -250
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
Tue Apr 26 09:50:12.055 UTC
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# reload

To perform the reload operation on the NCS 1010 unit and its modules, use the **reload** command.

**reload location** *location*

<b>Syntax Description</b>	<b>location</b>   <i>location</i>	(Optional) Enter the location for the unit or module which you want to reload.
<b>Command Default</b>	All slots are reloaded.	
<b>Command Modes</b>	Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None	

## Example

To reboot the Cisco NCS 1010 system, use the following command.

```
RP/0/RP0/CPU0:ios#reload
Fri Apr 29 06:50:12.312 UTC
Proceed with reload? [confirm]
RP/0/RP0/CPU0:ios#
Preparing system for backup. This may take a few minutes especially for large configurations.
Status report: node0_RP0_CPU0: BACKUP INPROGRESS
Status report: node0_RP0_CPU0: BACKUP HAS COMPLETED SUCCESSFULLY
[Done]
```

To reboot the entire Cisco NCS 1010 system along with its modules, use the following command.

```
RP/0/RP0/CPU0:ios#reload location all noprompt
Fri Jul 15 14:53:25.775 UTC
RP/0/RP0/CPU0:ios#yes
% Invalid input detected at '^' marker.
RP/0/RP0/CPU0:ios#
*****Completed Card Reload of all *****
##### Rack reload : all#####
##### Iteration under Test : 7 #####
Waiting for 1000 seconds...
Waiting for 990 seconds...
Waiting for 980 seconds...
Waiting for 970 seconds...
.
.
output snipped
.
.
Waiting for 110 seconds...
Waiting for 100 seconds...
Waiting for 90 seconds...
Waiting for 80 seconds...
```

```

Waiting for 70 seconds...
Waiting for 60 seconds...
Waiting for 50 seconds...
Waiting for 40 seconds...
Waiting for 30 seconds...
Waiting for 20 seconds...
Waiting for 10 seconds...
XR Prompt = RP/0/RP0/CPU0:P2A_DT_08#
Login sucessfull

type is <class 'telnetlib.Telnet'>
clear logging
Fri Jul 15 15:10:17.840 UTC
Clear logging buffer [confirm]
[y/n] :y
RP/0/RP0/CPU0:ios#
*****XR Logging Cleared*****
*****Started Sanity Verification Tests *****
The term length 0 op is term length 0
Fri Jul 15 15:10:17.925 UTC

```

To reboot the Cisco NCS 1010 RP, use the following command.

```

RP/0/RP0/CPU0:ios#reload location 0/RP0 noprompt
Fri Jul 15 18:21:13.785 UTC
RP/0/RP0/CPU0:ios#yes
% Invalid input detected at '^' marker.
RP/0/RP0/CPU0:ios#
*****Completed Card Reload of 0/RP0 *****
##### Rack reload : 0/RP0#####
##### Iteration under Test : 1 #####
Waiting for 900 seconds...
Waiting for 890 seconds...
.
.
output snipped
.
.
Waiting for 110 seconds...
Waiting for 100 seconds...
Waiting for 90 seconds...
Waiting for 80 seconds...
Waiting for 70 seconds...
Waiting for 60 seconds...
Waiting for 50 seconds...
Waiting for 40 seconds...
Waiting for 30 seconds...
Waiting for 20 seconds...
Waiting for 10 seconds...
XR Prompt = RP/0/RP0/CPU0:ios#
Login sucessfull

type is <class 'telnetlib.Telnet'>
clear logging
Fri Jul 15 18:36:25.996 UTC
Clear logging buffer [confirm]
[y/n] :y
RP/0/RP0/CPU0:ios#
*****XR Logging Cleared*****
*****Started Sanity Verification Tests *****
The term length 0 op is term length 0
Fri Jul 15 18:36:26.062 UTC

RP/0/RP0/CPU0:ios#reload location 0/0/NXR0 noprompt
Sat Jul 16 05:03:51.547 UTC

```

```

RP/0/RP0/CPU0:ios#yes
% Invalid input detected at '^' marker.
RP/0/RP0/CPU0:ios#
*****Completed Card Reload of 0/0/NXR0 *****
##### Rack reload : 0/0/NXR0#####
##### Iteration under Test : 1 #####
Waiting for 900 seconds...
Waiting for 890 seconds...
Waiting for 880 seconds...
Waiting for 870 seconds...
.
.
output snipped
.
.
Waiting for 40 seconds...
Waiting for 30 seconds...
Waiting for 20 seconds...
Waiting for 10 seconds...
XR Prompt = RP/0/RP0/CPU0:ios#
Login sucessfull

type is <class 'telnetlib.Telnet'>
clear logging
Sat Jul 16 05:19:03.274 UTC
Clear logging buffer [confirm]
[y/n] :y\
RP/0/RP0/CPU0:ios#
*****XR Logging Cleared*****
*****Started Sanity Verification Tests *****
The term length 0 op is term length 0
Sat Jul 16 05:19:03.350 UTC

```

To warm reboot the Cisco NCS 1010 line card, use the following command.

```

RP/0/RP0/CPU0:ios#reload location 0/0 noprompt
Fri Jul 15 23:42:33.536 UTC
RP/0/RP0/CPU0:ios#yes
% Invalid input detected at '^' marker.
RP/0/RP0/CPU0:ios#
*****Completed Card Reload of 0/0 *****
##### Rack reload : 0/0#####
##### Iteration under Test : 1 #####
Waiting for 900 seconds...
Waiting for 890 seconds...
Waiting for 880 seconds...
Waiting for 870 seconds...
.
.
output snipped
.
.
Waiting for 80 seconds...
Waiting for 70 seconds...
Waiting for 60 seconds...
Waiting for 50 seconds...
Waiting for 40 seconds...
Waiting for 30 seconds...
Waiting for 20 seconds...
Waiting for 10 seconds...
XR Prompt = RP/0/RP0/CPU0:ios#
Login sucessfull

type is <class 'telnetlib.Telnet'>
clear logging

```

```

Fri Jul 15 23:57:45.284 UTC
Clear logging buffer [confirm]
[y/n] :y
RP/0/RP0/CPU0:ios#
*****XR Logging Cleared*****
*****Started Sanity Verification Tests *****
The term length 0 op is term length 0
Fri Jul 15 23:57:45.348 UTC

```

To warm reboot the Cisco NCS 1010 RP card, use the following command.

```

RP/0/RP0/CPU0:ios#reload location 0/RP0/CPU0 noprompt
Sat Jul 16 10:25:10.102 UTC
RP/0/RP0/CPU0:ios#yes
% Invalid input detected at '^' marker.
RP/0/RP0/CPU0:ios#
*****Completed Card Reload of 0/RP0/CPU0 *****
##### Rack reload : 0/RP0/CPU0#####
##### Iteration under Test : 1 #####
Waiting for 900 seconds...
Waiting for 890 seconds...
Waiting for 880 seconds...
Waiting for 870 seconds...
Waiting for 860 seconds...

.
.
output snipped
.
.
Waiting for 70 seconds...
Waiting for 60 seconds...
Waiting for 50 seconds...
Waiting for 40 seconds...
Waiting for 30 seconds...
Waiting for 20 seconds...
Waiting for 10 seconds...
XR Prompt = RP/0/RP0/CPU0:P2A_DT_08#
Login successfull

type is <class 'telnetlib.Telnet'>
clear logging
Sat Jul 16 10:40:22.211 UTC
Clear logging buffer [confirm]
[y/n] :y
RP/0/RP0/CPU0:ios#
*****XR Logging Cleared*****
*****Started Sanity Verification Tests *****
The term length 0 op is term length 0
Sat Jul 16 10:40:22.292 UTC

```

## server

To allow the system clock to be synchronized by a NTP time server, use the **server** command in one of the NTP configuration modes. To remove the **server** command from the configuration file and restore the system to its default condition with respect to this command, use the **no** form of this command.

### server

```
[ ipv4 | ipv6 ] ip-address [ version number ] [ key key-id ] [ minpoll interval ] [ maxpoll interval ] [ source type interface-path-id ] [prefer] [burst] [iburst]
```

### no server

```
[ ipv4 | ipv6 ] ip-address
```

Syntax Description	
<b>ipv4</b>	(Optional) Specifies an IPv4 IP address.
<b>ipv6</b>	(Optional) Specifies an IPv6 IP address.
<i>ip-address</i>	IPv4 or IPv6 address of the time server providing the clock synchronization.
<b>version number</b>	(Optional) Defines the Network Time Protocol (NTP) version number, where the <i>number</i> argument is a value from 1 to 4. The default is 4.
<b>key key-id</b>	(Optional) Defines the authentication key, where the <i>key-id</i> argument is the authentication key to use when packets are sent to this peer. By default, no authentication key is used.
<b>minpoll interval</b>	(Optional) Defines the shortest polling interval, where the <i>interval</i> argument is specified in powers of two seconds. Range is from 4 to 17. The default value is 6.
<b>maxpoll interval</b>	(Optional) Defines the longest polling interval, where the <i>interval</i> argument is specified in powers of two seconds. Range is from 4 to 17. The default value is 10.
<b>source</b>	(Optional) Specifies the IP source address. The default is the outgoing interface.
<i>type</i>	(Optional) Interface type. For more information, use the question mark ( ? ) online help function.
<i>interface-path-id</i>	(Optional) Physical interface or virtual interface.
	<b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the device.
<b>prefer</b>	(Optional) Makes this peer the preferred server that provides synchronization.
<b>burst</b>	(Optional) Sends a series of packets instead of a single packet within each synchronization interval to achieve faster synchronization.
<b>iburst</b>	(Optional) Sends a series of packets instead of a single packet within the initial synchronization interval to achieve faster initial synchronization.

**Command Default** No servers are configured by default.

**Command Modes** NTP configuration



Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines**

The value for the **minpoll** keyword must be less than or equal to the value for the **maxpoll** keyword. If this is not the case, the system issues an error message.

Using the **prefer** keyword reduces switching back and forth among servers.

**Task ID**

Task ID	Operations
ip-services	read, write

The following example shows how to configure the device to allow its system clock to be synchronized with the clock of the peer at IP address 203.0.113.51 using NTP.

```
RP/0/RP0/CPU0:ios(config)#ntp
RP/0/RP0/CPU0:ios(config-ntp)#server 203.0.113.51 minpoll 8 maxpoll 12 prefer iburst
```

## show access-lists-ipv4

To display the contents of current IPv4 access lists, use the **show access-lists ipv4** command in IOS XR EXEC mode.

```
show access-lists ipv4 [ access-list-name hardware { ingress | egress } [ interface type
interface-path-id ] { sequence number | location node-id | [ usage pfilter { location node-id
} ] ] ]
```

Syntax Description		
<i>access-list-name</i>		(Optional) Name of a particular IPv4 access list. The name cannot contain spaces or quotation marks, but can include numbers.
<b>hardware</b>		(Optional) Identifies the access list as an access list for an interface.
<b>ingress</b>		(Optional) Specifies an inbound interface.
<b>interface</b>		(Optional) Displays interface statistics.
<i>type</i>		(Optional) Interface type.
<i>interface-path-id</i>		Physical interface or virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all interfaces currently configured on the router.
<b>sequence number</b>		(Optional) Sequence number of a particular IPv4 access list. Range is 1 to 2147483644.
<b>location node-id</b>		(Optional) Location of a particular IPv4 access list. The <i>node-id</i> argument is entered in the <i>rack/slot/module</i> notation.
<b>summary</b>		(Optional) Displays a summary of all current IPv4 access lists.
<i>sequence-number</i>		(Optional) Sequence number of a particular IPv4 access list. Range is 1 to 2147483644.
<b>usage</b>		(Optional) Displays the usage of the access list on a given line card.

<b>pfilter</b>	(Optional) Displays the packet filtering usage for the specified line card.
----------------	---

**Command Default** The default displays all IPv4 access lists.

**Command Modes** IOS XR EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** Use the **show access-lists ipv4** command to display the contents of all IPv4 access lists. To display the contents of a specific IPv4 access list, use the *name* argument. Use the *sequence-number* argument to specify the sequence number of the access list.

Use the **hardware**, **ingress** and **location** keywords to display the access list hardware contents and counters for all interfaces that use the specified access list in a given direction. To display the contents of a specific access list entry, use the **sequence number** keyword and argument. The access group for an interface must be configured using the **ipv4 access-group** command for access list hardware counters to be enabled.

Use the **show access-lists ipv4 summary** command to display a summary of all current IPv4 access lists. To display a summary of a specific IPv4 access list, use the *name* argument.

Use the **show access-list ipv4 usage** command to display a summary of all interfaces and access lists programmed on the specified line card.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	acl	read

### Examples

In the following example, the contents of all IPv4 access lists are displayed:

```
RP/0/RP0/CPU0:ios# show access-lists ipv4 acl_1
Fri Oct 20 06:22:17.223 UTC
ipv4 access-list acl_1
10 permit ipv4 172.16.0.0 0.0.255.255 any
20 deny ipv4 192.168.34.0 0.0.0.255 any
```

## show access-lists ipv6

To display the contents of current IPv6 access lists, use the **show access-lists ipv6** command in IOS XR EXEC mode.

```
show access-lists ipv6 [ access-list-name hardware { ingress | egress } [ interface type
interface-path-id ] { sequence number | location node-id | [ usage pfilter { location node-id
} ] } ]
```

Syntax Description	
<i>access-list-name</i>	(Optional) Name of a particular IPv6 access list. The name cannot contain a spaces or quotation marks, but can include numbers.
<b>hardware</b>	(Optional) Identifies the access list as an access list for an interface.
<b>ingress</b>	(Optional) Specifies an inbound interface.
<b>interface</b>	(Optional) Displays interface statistics.
<i>type</i>	(Optional) Interface type.
<i>interface-path-id</i>	(Optional) Either a physical interface instance or a virtual interface instance as follows: <ul style="list-style-type: none"> <li>Physical interface instance. Naming notation is <i>rack/slot/instance/port</i> and a slash between values is required as part of the notation. <ul style="list-style-type: none"> <li><i>rack</i>: Chassis number of the rack.</li> <li><i>slot</i>: Physical slot number of the modular services card or line card.</li> <li><i>instance</i>: Module number.</li> <li><i>port</i>: Physical port number of the interface.</li> </ul> </li> <li>Virtual interface instance. Number range varies depending on interface type.</li> </ul>
<b>sequence number</b>	(Optional) Sequence number of a particular IPv6 access list. Range is 1 to 2147483644.
<b>location node-id</b>	(Optional) Location of a particular IPv6 access list. The <i>node-id</i> argument is entered in the <i>rack/slot/instance</i> notation.
<b>summary</b>	(Optional) Displays a summary of all current IPv6 access lists.
<i>sequence-number</i>	(Optional) Sequence number of a particular IPv6 access list. Range is 1 to 2147483644.
<b>usage</b>	(Optional) Displays the usage of the access list on a given line card.
<b>pfilter</b>	(Optional) Displays the packet filtering usage for the specified line card.
all	(Optional) Displays the location of all the line cards.

**Command Default** Displays all IPv6 access lists.

**Command Modes** IOS XR EXEC

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** The **show access-lists ipv6** command is similar to the **show access-lists ipv4** command, except that it is IPv6 specific.

Use the **show access-lists ipv6** command to display the contents of all IPv6 access lists. To display the contents of a specific IPv6 access list, use the *name* argument. Use the *sequence-number* argument to specify the sequence number of the access list.

Use the **hardware**, **ingress** and **location** keywords to display the access list hardware contents and counters for all interfaces that use the specified access list in a given direction. To display the contents of a specific access list entry, use the **sequence number** keyword and argument. The access group for an interface must be configured using the **ipv6 access-group** command for access list hardware counters to be enabled.

Use the **show access-lists ipv6 summary** command to display a summary of all current IPv6 access lists. To display a summary of a specific IPv6 access list, use the *name* argument.

Use the **show access-list ipv6 usage** command to display a summary of all interfaces and access lists programmed on the specified line card.

Task ID	Task ID	Operations
	acl	read

### Examples

In the following example, the contents of all IPv6 access lists are displayed:

```
RP/0/RP0/CPU0:ios# show access-lists ipv6
Fri Oct 20 05:29:01.125 UTC
ipv6 access-list V6-INGRESS-ACL
10 permit ipv6 any any
20 deny udp any any
```

# show alarms

To view alarm information, use the **show alarms** command in XR EXEC mode or Administration EXEC mode.

```
show alarms [ brief ] [ system ] [ active ]
```

Syntax Description	
<b>brief</b>	Displays alarms in brief.
<b>system</b>	Displays system scope alarms related data.
<b>active</b>	Displays active alarms.

**Command Default** None

**Command Modes** XR EXEC  
Administration EXEC

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** This command displays the alarm information. The command displays only the administration alarms in admin EXEC mode and all the alarms in XR EXEC mode.

## Example

The following example shows the output of the **show alarms brief system active** command.

```
RP/0/RPO/CPUO:P1AL 05#show alarms brief system active
Thu Feb 9 11:33:03.137 UTC
-----
Active Alarms
-----
Location          Severity      Group        Set time          Description
-----
0/PM1             Major        Environ      01/25/2023 05:21:37 UTC  Power Module
Error (PM VIN VOLT 00R)

0/PM1 DISABLED)  Major        Environ      01/25/2023 05:21:37 UTC  Power Module
Output Disabled (PM OUTPUT_DISABLED)

RP/0/RPO/CPUO:P1AL 05#RP/0/RPO/CPU:Feb 9 11:33:05.115 UTC: phyl mgmt [152]: %PKT INFRA-FM-2
-FAULT CRITICAL : AL
ARM CRITICAL : PHYI-MDIO-ACCESS-ERROR : DECLARE : 0: Phyl MDIO access failure detected
```

# show cdp

To display global CDP information (including timer and hold-time information, information about neighboring devices, interfaces on which CDP is enabled, traffic between devices), use the **show cdp** command in EXEC mode.

```
show cdp { traffic | neighbors [ type number | detail ] | interface [ type number ] | entry { * | device-name [ * ] } [ version ] [ protocol ] }
```

Syntax Description	
<i>type</i>	(Optional) Interface type that is connected to the neighbors about which you want information.
<i>number</i>	(Optional) Number of the interface connected to the neighbors about which you want information.
<b>detail</b>	(Optional) Displays detailed information about a neighbor (or neighbors) including network address, enabled protocols, hold time, and software version.
*	Displays all CDP neighbors.
<i>device-name</i> *	Name of the neighbor about which you want information. You can enter an optional asterisk (*) at the end of a <i>device-name</i> as a wildcard. For example, entering <b>show cdp entry dev*</b> will match all device names that begin with <b>dev</b> .
<b>version</b>	(Optional) Limits the display to information about the software version running on the device.
<b>protocol</b>	(Optional) Limits the display to information about the protocols enabled on the device.

**Command Default** No default behavior or values.

**Command Modes** EXEC

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

Use the **show cdp** command to display global CDP information.

```
RP/0/RP0/CPU0:ios#show cdp
Tue Feb 14 16:59:38.255 UTC
Global CDP information:
  Sending CDP packets every 60 seconds
  Sending a holdtime value of 180 seconds
  Sending CDPv2 advertisements is enabled
```

Use the **show cdp neighbors** command to display detailed information about neighboring devices discovered using CDP.

```
RP/0/RP0/CPU0:R2#show cdp neighbors mgmtEth 0/RP0/CPU0/1
```

```

Mon Apr 10 12:30:30.902 UTC
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

Device ID      Local Intrfce  Holdtme Capability Platform  Port ID
R1             Mg0/RP0/CPU0/1  172      R          NCS1010  Mg0/RP0/CPU0/1
RP/0/RP0/CPU0:R2#show cdp neighbors
Mon Apr 10 12:30:39.251 UTC
Capability Codes: R - Router, T - Trans Bridge, B - Source Route Bridge
                  S - Switch, H - Host, I - IGMP, r - Repeater

Device ID      Local Intrfce  Holdtme Capability Platform  Port ID
R1             Mg0/RP0/CPU0/1  164      R          NCS1010  Mg0/RP0/CPU0/1

```

```

RP/0/RP0/CPU0:R2#show cdp neighbors mgmtEth 0/RP0/CPU0/1 detail
Mon Apr 10 12:31:23.622 UTC

```

```

-----
Device ID: R1
SysName : R1
Entry address(es):
  IPv4 address: 192.168.0.2
  IPv6 address: 2000:110::1
Platform: cisco NCS1010, Capabilities: Router
Interface: MgmtEth0/RP0/CPU0/1
Port ID (outgoing port): MgmtEth0/RP0/CPU0/1
Holdtime : 120 sec

```

```

Version :
7.10.1.19I

```

```

advertisement version: 2
Duplex: full

```

Use the **show cdp entry *entry-name*** command to display information about a specific neighboring device or all the neighboring devices discovered using CDP.

```

RP/0/RP0/CPU0:R2#show cdp entry R1
Mon Apr 10 12:22:22.564 UTC

```

```

-----
Device ID: R1
SysName : R1
Entry address(es):
  IPv4 address: 192.168.0.2
  IPv6 address: 2000:110::1
Platform: cisco NCS1010, Capabilities: Router
Interface: MgmtEth0/RP0/CPU0/1
Port ID (outgoing port): MgmtEth0/RP0/CPU0/1
Holdtime : 121 sec

```

```

Version :
7.10.1.19I

```

```

advertisement version: 2
Duplex: full

```

```

RP/0/RP0/CPU0:R2#show cdp entry *
Mon Apr 10 12:24:59.927 UTC

```

```

-----
Device ID: R1

```



```
SysName : R1
Entry address(es):
  IPv4 address: 192.168.0.2
  IPv6 address: 2000:110::1
Platform: cisco NCS1010, Capabilities: Router
Interface: MgmtEth0/RP0/CPU0/1
Port ID (outgoing port): MgmtEth0/RP0/CPU0/1
Holdtime : 143 sec
```

```
Version :
7.10.1.19I
```

```
advertisement version: 2
Duplex: full
```

Use the **show cdp interface** [*interface-name*] command to display information about the interfaces on which CDP is enabled.

```
RP/0/RP0/CPU0:R2#show cdp interface Mg0/RP0/CPU0/1
Mon Apr 10 12:24:27.253 UTC
MgmtEth0/RP0/CPU0/1 is Up
  Encapsulation ether
  Sending CDP packets every 60 seconds
  Holdtime is 180 seconds
```

Use the **show cdp traffic** command to display information about the traffic gathered between devices using CDP.

```
RP/0/RP0/CPU0:ios#show cdp traffic
Mon Apr 10 12:32:09.247 UTC

CDP counters :
  Packets output: 11, Input: 5
  Hdr syntax: 0, Chksum error: 0, Encaps failed: 0
  No memory: 0, Invalid packet: 0, Truncated: 0
  CDP version 1 advertisements output: 0, Input: 0
  CDP version 2 advertisements output: 11, Input: 5
  Unrecognize Hdr version: 0, File open failed: 0
```

# show configuration commit changes

To display the changes made to the running configuration by previous configuration commits, a configuration commit, or for a range of configuration commits, use the **show configuration commit changes** command in EXEC, administration EXEC, administration configuration, or global configuration mode.

```
show configuration commit changes { commit-id | since commit-id | last number-of-commits
| original last-modified | all } [diff]
```

Syntax Description		
	<b>since</b>	Displays all changes committed to the running configuration since (and including) a specific configuration commit.
	<i>commit-id</i>	Displays configuration changes for a specific configuration commit.
	<b>last</b> <i>number-of-commits</i>	Displays the changes made to the running configuration during the last number of configuration commits specified for the <i>number-of-commits</i> argument.
	<b>original</b> <i>last-modified</i>	Displays the original content of the actual commit operation before policy modifications by commit scripts.
	<b>all</b>	Displays commit ID and configurations completed for last 100 commits.
	<b>diff</b>	(Optional) Displays added lines, changed lines, and deleted lines.

**Command Default** None

**Command Modes** EXEC  
Administration EXEC  
Administration configuration  
Global configuration

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

Each time a configuration is committed with the **commit** command, the configuration commit operation is assigned a commit ID. The **show configuration commit changes** command displays the configuration changes made since the specified commit.

To display a list of the available commit IDs, enter the **show configuration commit list** command. You can also display the commit IDs by entering the **show configuration commit changes** command with the online help function (?).

You cannot view commit IDs from a different release if the syntax or semantics of the configuration changed in the current release.



**Note** Syntax of a configuration refers to its structure and format, while the semantics of a configuration refers to its backend interpretation.

The following example shows sample output from the **show configuration commit changes** command with the *commit-id* argument. In this example, the output displays the changes made in the configuration commit assigned commit ID 1000000006.

```
RP/0/RP0/CPU0:ios#show configuration commit changes 1000000006
Building configuration...

controller Ots0/0/0/0
  raman-osri off
  raman-force-apr off
  raman-tx-power 1 value 22300
  raman-tx-power 2 value 26800
  raman-tx-power 3 value 6400
  raman-tx-power 4 value 12900
  raman-tx-power 5 value 19000
  raman-safety-control-mode auto
!
end
```

The following example shows sample output from the **show configuration commit changes** command with the **since** *commit-id* keyword and argument. In this example, the output displays the configuration changes made since the configuration commit assigned commit ID 1000000006 was committed.

```
RP/0/RP0/CPU0:ios#show configuration commit changes since 1000000006
Tue Feb 28 11:41:04.643 UTC
Building configuration...
controller Ots0/0/0/0
  otdr rx auto reflectance-threshold -45
  otdr rx auto splice-loss-threshold 200
  otdr rx auto excess-reflection-threshold -20
  otdr rx expert capture-end 8000000
  otdr rx expert pulse-width 20000
  otdr rx expert capture-start 5000000
  otdr rx expert scan-duration 160
  otdr rx back-scattering -8200
  otdr rx refractive-index 1468000
  otdr tx auto reflectance-threshold -48
  otdr tx auto splice-loss-threshold 250
  otdr tx auto excess-reflection-threshold -22
  otdr tx expert capture-end 9000000
  otdr tx expert pulse-width 5000
```

```

otdr tx expert capture-start 6000000
otdr tx back-scattering -8300
otdr tx refractive-index 1468200
otdr scan-mode expert
raman-osri off
raman-force-apr off
raman-tx-power 1 value 22300
raman-tx-power 2 value 26800
raman-tx-power 3 value 6400
raman-tx-power 4 value 12900
raman-tx-power 5 value 19000
raman-safety-control-mode auto
!
end

```

The following example shows sample output from the **show configuration commit changes** command with the **diff** keyword. In the display, the following symbols signify changes:

+ indicates an added line.

– indicates a deleted line.

# indicates a modified line.

```

RP/0/RP0/CPU0:R1#show configuration commit changes since 1000000006 diffBuilding
configuration...
+ controller Ots0/0/0/0
+ otdr rx auto reflectance-threshold -45
+ otdr rx auto splice-loss-threshold 200
+ otdr rx auto excess-reflection-threshold -20
+ otdr rx expert capture-end 8000000
+ otdr rx expert pulse-width 20000
+ otdr rx expert capture-start 5000000
+ otdr rx expert scan-duration 160
+ otdr rx back-scattering -8200
+ otdr rx refractive-index 1468000
+ otdr tx auto reflectance-threshold -48
+ otdr tx auto splice-loss-threshold 250
+ otdr tx auto excess-reflection-threshold -22
+ otdr tx expert capture-end 9000000
+ otdr tx expert pulse-width 5000
+ otdr tx expert capture-start 6000000
+ otdr tx back-scattering -8300
+ otdr tx refractive-index 1468200
+ otdr scan-mode expert
+ raman-osri off
+ raman-force-apr off
+ raman-tx-power 1 value 22300
+ raman-tx-power 2 value 26800
+ raman-tx-power 3 value 6400
+ raman-tx-power 4 value 12900
+ raman-tx-power 5 value 19000
+ raman-safety-control-mode auto
+ !
end

```

The following example shows sample output from the **show configuration commit changes** command with the **all** keyword. In this example, the output displays the list of configurations that are committed in last 100 commits along with their commit-ID.

```
RP/0/RP0/CPU0:ios#show configuration commit changes all
Tue Feb 28 11:38:42.876 UTC
```

```
Commit ID : 1000000001
```

```
-----
Building configuration...
username cisco
 group root-lr
 group cisco-support
 secret 10
$6$PAYio/1d9RuG5o/.$daupPZwNJCuPsJqAGa8IlhAq8U1O2Qa8UdtVszjh4MaRwixFfGvNfFq/FPB36DH07v77oCOssLTZ4LUxN88QT.
!
end
```

```
Commit ID : 1000000002
```

```
-----
Building configuration...
call-home
 service active
 contact smart-licensing
 profile CiscoTAC-1
  active
  destination transport-method email disable
  destination transport-method http
!
!
end
```

```
Commit ID : 1000000003
```

```
-----
Building configuration...

hostname R1
logging console disable
line console
 exec-timeout 0 0
 absolute-timeout 0
 session-timeout 0
!
line default
 exec-timeout 0 0
 absolute-timeout 0
 session-timeout 0
!
end
```

```
Commit ID : 1000000004
```

```
-----
Building configuration...

line console
 exec-timeout 0 0
 absolute-timeout 0
 session-timeout 0
!
line default
 exec-timeout 0 0
 absolute-timeout 0
 session-timeout 0
!
end
```

```
Commit ID : 1000000005
```

```
-----
Building configuration...
```

```
controller Ots0/0/0/0
  egress-ampli-br enable
  egress-ampli-force-apr off
  egress-ampli-osri off
  egress-ampli-tilt 11
  egress-ampli-br-high-threshold -170
  ingress-ampli-force-apr off
  egress-ampli-gain 190
  ingress-ampli-osri off
  ingress-ampli-tilt -11
  ingress-ampli-gain 200
  ingress-ampli-gain-range normal
  egress-ampli-safety-control-mode auto
  ingress-ampli-safety-control-mode auto
!
end
```

```
Commit ID : 1000000006
```

```
-----
Building configuration...
```

```
controller Ots0/0/0/0
  raman-osri off
  raman-force-apr off
  raman-tx-power 1 value 22300
  raman-tx-power 2 value 26800
  raman-tx-power 3 value 6400
  raman-tx-power 4 value 12900
  raman-tx-power 5 value 19000
  raman-safety-control-mode auto
!
end
```

```
Commit ID : 1000000007
```

```
-----
Building configuration...
```

```
controller Ots0/0/0/0
  otdr rx auto reflectance-threshold -45
  otdr rx auto splice-loss-threshold 200
  otdr rx auto excess-reflection-threshold -20
  otdr rx expert capture-end 8000000
  otdr rx expert pulse-width 20000
  otdr rx expert capture-start 5000000
  otdr rx expert scan-duration 160
  otdr rx back-scattering -8200
  otdr rx refractive-index 1468000
  otdr tx auto reflectance-threshold -48
  otdr tx auto splice-loss-threshold 250
  otdr tx auto excess-reflection-threshold -22
  otdr tx expert capture-end 9000000
  otdr tx expert pulse-width 5000
  otdr tx expert capture-start 6000000
  otdr tx back-scattering -8300
  otdr tx refractive-index 1468200
  otdr scan-mode expert
```

```
!  
end
```

# show controllers

To display status and configuration information about the interfaces on a specific node, use the **show controllers** command in XR EXEC mode.

**Show controllers** [ **description** ] [ *Controller-type R/S/I/P* ] [ **spectrum-info** ] [ **otdr-info** *direction* ] [ **tone-info** ] [ **channel-slice-attenuation-info** ]

Syntax Description	description	Displays the controller status.
	<i>Controller-type R/S/I/P</i>	Rack/Slot/Instance/Port of the controller.
	<b>spectrum-info</b>	Displays the Optical Channel Monitoring (OCM) raw data at slice level, such as Tx-power and Rx-power.
	<b>otdr-info</b>	Displays the OTDR scan status and location of the SOR file, and the OTDR events.
	<b>direction</b>	Scan direction (RX or TX)
	<b>channel-slice-attenuation-info</b>	Displays the attenuation data for each channel slice
	<b>tone-info</b>	Displays the Tone Generation parameters that are set for connection verification and the status of the connection verification operation.

**Command Default** None

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** None

## Example

To view the OTS controller status on the ILA cards, use the sh controller description command.

```
RP/0/RP0/CPU0:ios#sh controller description
Fri Mar 25 09:24:53.386 UTC
Interface Status Description
-----
Osc0/0/0/0 up
Osc0/0/0/2 up
Ots0/0/0/0 up
Ots0/0/0/1 up
Ots0/0/0/2 up
Ots0/0/0/3 up
RP/0/RP0/CPU0:ios#
```

To view the parameters of the LINE 0 OTS controller, use the following command:



```

RP/0/RP0/CPU0:ios#sh controllers ots 0/0/0/0
Wed Mar 23 06:00:37.097 UTC
Controller State: Up
Transport Admin State: In Service
LED State: Red
Alarm Status:
-----
Detected Alarms:
RX-LOS-P
EGRESS-AUTO-LASER-SHUT
HIGH-RX-BR-PWR
Alarm Statistics:
-----
LOW-TX-PWR = 0
RX-LOS-P = 1
RX-LOC = 1
TX-POWER-FAIL-LOW = 1
INGRESS-AUTO-LASER-SHUT = 0
INGRESS-AUTO-POW-RED = 0
INGRESS-AMPLI-GAIN-LOW = 0
INGRESS-AMPLI-GAIN-HIGH = 0
EGRESS-AUTO-LASER-SHUT = 1
EGRESS-AUTO-POW-RED = 0
EGRESS-AMPLI-GAIN-LOW = 0
EGRESS-AMPLI-GAIN-HIGH = 0
HIGH-TX-BR-PWR = 0
HIGH-RX-BR-PWR = 1
SPAN-TOO-SHORT-TX = 0
SPAN-TOO-SHORT-RX = 0
Parameter Statistics:
-----
Total RX Power(C+L) = -50.00 dBm
Total TX Power(C+L) = -50.00 dBm
Total RX Power = -50.00 dBm
Total TX Power = -50.00 dBm
RX Signal Power = -50.00 dBm
TX Signal Power = -50.00 dBm
TX Voa Attenuation = 0.0 dB
Ingress Ampli Gain = -1.1 dB
Ingress Ampli Tilt = 0.0 dB
Ingress Ampli Gain Range = Normal
Ingress Ampli Safety Control mode = auto
Ingress Ampli Osri = OFF
Ingress Ampli Force Apr = OFF
Egress Ampli Gain = -0.7 dB
Egress Ampli Tilt = 0.0 dB
Egress Ampli Safety Control mode = auto
Egress Ampli Osri = OFF
Egress Ampli Force Apr = OFF
Configured Parameters:
-----
TX Voa Attenuation = 0.0 dB
Ingress Ampli Gain = 10.9 dB
Ingress Ampli Tilt = 0.0 dB
Ingress Ampli Gain Range = Normal
Ingress Ampli Safety Control mode = auto
Ingress Ampli Osri = OFF
Ingress Ampli Force Apr = OFF
Egress Ampli Gain = 15.3 dB
Egress Ampli Tilt = 0.0 dB
Egress Ampli Safety Control mode = auto
Egress Ampli Osri = OFF
Egress Ampli Force Apr = OFF
RP/0/RP0/CPU0:ios#

```

**Example**

To view the raw OCM data (slice level channel power) use the following commands:

```
RP/0/RP0/CPU0:ios#sh controllers ots 0/0/0/0 spectrum-info
Fri Feb 4 13:12:49.841UTC
Spectrum Slices spacing      :          3.125 GHz
Spectrum Slices Range       :          1 - 1548
Slice start wavelength      :          1566.82 nm
Slice start frequency       :          191337.50 GHz
Spectrum power information :
Rx power :
-----
spectrum-slice num          Rx-power values (dBm)
-----
  1 - 12                    -88.8 -88.8 -88.8 -88.8    -88.8 -88.8 -88.8 -88.8
-88.8 -88.8 -88.8 -88.8
 13 - 24                    -88.8 -88.8 -88.8 -88.8    -88.8 -88.8 -88.8 -88.8
-88.8 -88.8 -88.8 -88.8
.....
.....
.....
1537 - 1548                -88.8 -88.8 -88.8 -88.8    -88.8 -88.8 -88.8 -88.8
-88.8 -88.8 -88.8 -88.8
-----
Tx power :
-----
spectrum-slice num          Tx-power values (dBm)
-----
 1 - 12                    -9.5 -7.3 -6.0 -5.2    -4.9 -4.8 -4.6 -4.4    -4.4
-4.4 -4.4 -4.4
 13 - 24                    -4.4 -4.5 -4.6 -4.8    -5.1 -5.5 -6.4 -7.7    -9.6
-12.0 -13.2 -11.4
 25 - 36                    -9.2 -7.7 -6.7 -6.2    -6.0 -5.9 -5.7 -5.6    -5.6
-5.5 -5.4 -5.4
 37 - 48                    -5.3 -5.3 -5.4 -5.5    -5.8 -6.1 -6.6 -7.3    -8.6
-10.4 -12.2 -11.8
.....
.....
.....
1525 - 1536                -2.4 -2.4 -2.4 -2.4    -2.4 -2.3 -2.3 -3.0
-4.2 -6.5 -10.3 -14.9
1537 - 1548                -19.3 -22.6 -24.3 -25.3    -26.1 -26.6 -27.1 -27.6
-27.9 -28.2 -28.4 -28.6

To view the OTDR scan status and events use the following commands:

RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/0 otdr-info rx
Wed Feb 9 05:55:19.791 UTC
Scan Direction: RX
Scan Status: Data Ready
SOR file: /harddisk:/otdr/P1D_DT_01_NCS1010_OTDR_Ots0_0_0_RX_20220209-055045.sor

Total Events detected: 11
Scan Timestamp: Wed Feb 9 05:50:45 2022 UTC
Event Type Legend: NR:Non-Reflective R:Reflective FE:Fiber-End
ER:Excess-Reflection
Event# | Detected Event (s) | Location (km) | Accuracy (m) | Magnitude (dB) | Attenuation/km (dB)
1      | R                  | 50.4709      | 52.47        | -39.87         | 0.18
2      | NR                 | 50.4709      | 52.47        | 1.17           | 0.18
3      | R                  | 100.9261     | 102.92       | -37.73         | 0.21
4      | NR                 | 100.9261     | 102.92       | 1.01           | 0.21
5      | R                  | 105.9500     | 107.94       | -38.52         | 0.24
```

6	NR	105.9500	107.94	0.85	0.24
7	R	112.7458	114.74	-40.56	0.00
8	NR	112.7458	114.74	1.48	0.00
9	NR	117.9873	119.98	0.66	-0.02
10	R FE	120.1206	122.12	-35.55	0.00
11	NR FE	120.1206	122.12	21.65	0.00

The following sample displays the Optical Return Loss as part of the OTDR status:

```
RP/0/RP0/CPU0:NCS1010#show controllers Ots 0/0/0/2 otdr-info rx
Mon Oct  2 11:55:48.552 UTC
  Scan Direction: RX
  Scan Status: Data Ready
Optical Return Loss: 39.0 dB
  SOR file: /harddisk:/otdr/NCS1010_NCS1010_OTDR_Ots0_0_0_2_RX_20231001-110754.sor
  Total Events detected: 8
  Scan Timestamp: Sun Oct  1 11:07:54 2023 UTC
  Event Type Legend: NR:Non-Reflective R:Reflective FE:Fiber-End
  ER:Excess-Reflection EA:Excess-Attenuation
```

Event#	Detected Event(s)	Location(m)	Accuracy(m)	Magnitude(dB)	Attenuation/km(dB)
1	NR EA	4.4100	2.00	0.69	0.00
2	NR	664.3200	2.66	0.21	0.00
3	R ER	18222.3900	20.22	-33.78	0.19
4	NR	18222.3900	20.22	0.35	0.19
5	R ER	68674.4800	70.67	-32.25	0.20
6	NR	68674.4800	70.67	0.36	0.20
7	R FE ER	118765.2600	120.76	-28.55	0.23
8	NR FE	118765.2600	120.76	25.86	0.23

To view the parameter values set for Tone Generation and the status of connection verification on port 4 OTS controller, use the following command:

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/4 tone-info
Fri Sep 15 14:53:22.579 UTC
Tone Info:
Tone Frequency : 191.3750000 THz
Tone Rate : 2 bits/second
Tone Pattern(Hex value) : abcd1234
Tone Pattern Expected(Hex value) : abcd1234
Tone Pattern Received(Hex value) : 00000000
Tone Detected OOB : Enabled
  Detection State: Inprogress
```

To view the parameter values set for Tone Generation and the status of connection verification on the OMS controller, use the following command:

```
RP/0/RP0/CPU0:#show controllers oms 0/2/0/0 tone-info
Tue May 10 11:41:18.847 UTC
Tone Info:
Tone Rate : 25 bits/second
Tone Pattern Expected(Hex value) : abcd1234
Tone Pattern Received(Hex value) : abcd1234
```

```
Tone Detected OOB : Enabled  
Detection State: Success
```

# show controllers raman-info

To view the individual Raman pump information and other parameters, use the **show controllers ots r/s/i/p raman-info** command.

**show controllers ots** *R/S/I/P* **raman-info**

<b>Syntax Description</b>	<i>R/S/I/P</i> Rack/Slot/Instance/Port of the OSC controller.				
<b>Command Modes</b>	User EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				

## Example

The following sample shows the output of the **show controllers ots r/s/i/p raman-info** command.

```
RP/0/RP0/CPU0:ios#show controllers ots 0/0/0/0 raman-info
Fri Apr 1 06:40:33.849 UTC
```

```
Alarm Status:
-----
Detected Alarms: None
```

```
Alarm Statistics:
-----
RAMAN-AUTO-POW-RED = 0
RAMAN-1-LOW-POW = 0
RAMAN-2-LOW-POW = 0
RAMAN-3-LOW-POW = 0
RAMAN-4-LOW-POW = 0
RAMAN-5-LOW-POW = 0
RAMAN-1-HIGH-POW = 1
RAMAN-2-HIGH-POW = 0
RAMAN-3-HIGH-POW = 0
RAMAN-4-HIGH-POW = 0
RAMAN-5-HIGH-POW = 0
```

```
Parameter Statistics:
-----
Raman Safety Control mode = auto
Raman Osri = OFF
Raman Force Apr = OFF
Composite Raman Power = 886.60 mW
```

```
RAMAN Pump Info:
-----
Instance      Wavelength (nm)  Power (mW)
1              1424.00          257.60
2              1438.00          255.10
3              1457.00          71.60
4              1470.00          127.50
```

```
5                1495.00                170.10
```

```
Configured Parameters:
```

```
-----
```

```
Raman Safety Control mode = auto
```

```
Raman Osri = OFF
```

```
Raman Force Apr = OFF
```

```
RAMAN Pump Info:
```

```
-----
```

Instance	Power (mW)
1	45.00
2	40.00
3	40.00
4	40.00
5	35.00

# show environment

To display environmental monitor parameters for the system, use the **show environment** command.

```
show environment [ alarm-contact | all | altitude | current | fan | humidity | power
| voltages [ location | location ] | temperature [ location | location ] ]
```

## Syntax Description

<b>alarm-contact</b>	(Optional) Displays information about the alarm ports.
<b>all</b>	(Optional) Displays information for all the environmental monitor parameters.
<b>altitude</b>	(Optional) Displays information about the altitude.
<b>current</b>	(Optional) Displays current sensor information.
<b>fan</b>	(Optional) Displays information about the fans.
<b>humidity</b>	(Optional) Displays information about the humidity.
<b>power</b>	(Optional) Displays power supply voltage and current information.
<b>temperature</b>	(Optional) Displays system temperature information.
<b>voltages</b>	(Optional) Displays system voltage information.
<b>location</b>   <i>location</i>	(Optional) Enter the location for which the environmental information needs to be displayed.

## Command Default

All environmental monitor parameters are displayed.

## Command Modes

Cisco IOS XR

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

The **show environment** command displays information about the hardware that is installed in the system, including fans, power supply voltage, current information, and temperatures.

## Example

The following example shows sample output from the **show environment** command with the **fan** keyword.

```
sysadmin-vm:0_RP0# show environment fan
```

```
Thu May 26 04:15:37.765 UTC
```

```
=====
Location      FRU Type                               Fan speed (rpm)
                                     FAN_0   FAN_1   FAN_2
-----
```

## show environment

```

0/PM0      NCS1010-AC-PSU      5368
0/PM1      NCS1010-AC-PSU      5336
0/FT0      NCS1010-FAN         10020  10020  10020
0/FT1      NCS1010-FAN         10020  10020  9960

```

The following example shows sample output from the **show environment** command with the **temperature** keyword.

```
sysadmin-vm:0_RP0# show environment temperature location 0/RP0
```

```
Thu May 26 04:16:39.832 UTC
```

```

=====
Location  TEMPERATURE          Value  Crit  Major  Minor  Minor  Major
Crit
(Hi)      Sensor                (deg C)  (Lo)  (Lo)   (Lo)   (Hi)   (Hi)
-----
0/RP0/CPU0
80        RP_TEMP_PCB            30      -10   -5     0     70     75
80        RP_TEMP_HOT_SPOT      33      -10   -5     0     70     75
90        RP_TEMP_LTM4638       49      -10   -5     0     80     85
90        RP_TEMP_LTM4644_0     36      -10   -5     0     80     85
90        RP_TEMP_LTM4644_1     39      -10   -5     0     80     85
90        RP_JMAC_1V0_VCCP_TMON 33      -10   -5     0     80     85
90        RP_JMAC_1V0_VNN_TMON 33      -10   -5     0     80     85
90        RP_JMAC_1V0_VCC_RAM_TMON 32     -10   -5     0     80     85
90        RP_JMAC_1V2_DDR_VDDQ_TMON 33     -10   -5     0     80     85
=====

```

The following example shows sample output from the **show environment** command with the **power** keyword.

```
sysadmin-vm:0_RP0# show environment power
```

```
Thu May 26 04:17:55.592 UTC
```

```
=====
CHASSIS LEVEL POWER INFO: 0
=====
```

```

Total output power capacity (Group 0 + Group 1) : 1050W + 1050W
Total output power required                    : 700W
Total power input                              : 228W
Total power output                             : 140W

```

```
Power Group 0:
```

```

=====
Power      Supply      -----Input-----  -----Output---  Status
Module     Type          Volts    Amps    Volts    Amps
-----
0/PM0      NCS1010-AC-PSU 228.5    0.5    12.1    5.6    OK

```

```
Total of Group 0: 114W/0.5A 67W/5.6A
```

```
Power Group 1:
```

```

=====
Power      Supply      -----Input-----  -----Output---  Status
Module     Type          Volts    Amps    Volts    Amps

```



```

=====
0/PM1      NCS1010-AC-PSU  228.5    0.5    12.1    6.1    OK
Total of Group 1:          114W/0.5A      73W/6.1A
=====
Location      Card Type          Power      Power      Status
                Allocated      Used
                Watts          Watts
=====
0/RP0/CPU0    NCS1010-CNTRLR-K9  90         14         ON
0/FT0         NCS1010-FAN        110        17         ON
0/FT1         NCS1010-FAN        110        15         ON
0/0/NXR0      NCS1K-OLT-C        350        61         ON
0/Rack        NCS1010-SA         40         19         ON
=====

```

The following example shows sample output from the **show environment** command with the **voltages** keyword.

```
sysadmin-vm:0_RP0# show environment voltages location 0/RP0
```

```
Thu May 26 04:19:16.636 UTC
```

```

=====
Location  VOLTAGE          Value      Crit      Minor      Minor      Crit
          Sensor              (mV)      (Lo)      (Lo)      (Hi)      (Hi)
-----
0/RP0/CPU0
RP_ADM1266_12V0      12094      10800     11280     12720     13200
RP_ADM1266_1V8_CPU  1806       1670      1750      1850      1930
RP_ADM1266_1V24_VCCREF  1238       1150      1200      1280      1330
RP_ADM1266_1V05_CPU   1047       980       1020      1080      1120
RP_ADM1266_1V2_DDR_VDDQ  1204       1120      1160      1240      1280
RP_ADM1266_1V0_VCC_RAM   988        650       700       1250      1300
RP_ADM1266_1V0_VNN       869        550       600       1250      1300
RP_ADM1266_1V0_VCCP     1018       450       500       1250      1300
RP_ADM1266_0V6_DDR_VTT   599        560       580       620       640
RP_ADM1266_3V3_STAND_BY  3301       3070      3200      3400      3530
RP_ADM1266_5V0         5004       4650      4850      5150      5350
RP_ADM1266_3V3         3325       3070      3200      3400      3530
RP_ADM1266_2V5_PLL     2489       2330      2430      2580      2680
RP_ADM1266_2V5_FPGA     2502       2330      2430      2580      2680
RP_ADM1266_1V2_FPGA     1202       1120      1160      1240      1280
RP_ADM1266_3V3_CPU     3332       3070      3200      3400      3530
RP_ADM1266_2V5_CPU     2498       2330      2430      2580      2680
=====

```

The following example shows a sample output of the **show environment current** command.

```
RP/0/RP0/CPU0:P2C_DT_02#show environment current
```

```
Tue Jul 5 08:36:22.132 UTC
```

```

=====
Location  CURRENT          Value
          Sensor              (mA)
-----
0/RP0/CPU0
RP_CURRMON_LTM4638      395
RP_CURRMON_LTM4644_0    179
RP_CURRMON_LTM4644_1    307
RP_JMAC_1V0_VCCP_IMON   187
RP_JMAC_1V0_VNN_IMON    62
RP_JMAC_1V0_VCC_RAM_IMON  0
RP_JMAC_1V2_DDR_VDDQ_IMON 187
0/Rack
SA_ADM1275_12V_MOD0_IMON 4154
=====

```

```

SA_ADM1275_12V_MOD1_IMON          43
SA_ADM1275_12V_MOD2_IMON          18
SA_ADM1275_12V_FAN0_IMON         1356
SA_ADM1275_12V_FAN1_IMON         1517
SA_INA230_5V0_IMON                129
SA_INA230_3V3_IMON                2998
SA_INA230_1V0_XGE_CORE_IMON       2464
SA_INA230_1V0_FPGA_CORE_IMON      787
SA_ADM1275_12V_SA_IMON            1668
SA_ADM1275_12V_CPU_IMON           1147

```

The following example shows a sample output from the **show environment altitude** command.

```

RP/0/RP0/CPU0:P2C_DT_02#show environment altitude
Tue Jul  5 08:36:51.710 UTC

```

```

=====
Location      Altitude Value (Meters)      Source
-----
0              760                          sensor

```

The following example shows sample output from the **show environment** command.

```

sysadmin-vm:0_RP0# show environment

```

```

Thu May 26 04:20:09.507 UTC

```

```

-----
Location      TEMPERATURE                      Value      Crit      Major      Minor      Minor
Major        Crit                               (deg C)    (Lo)      (Lo)      (Lo)      (Hi)
(Hi)         Sensor                             (Hi)
-----
0/RP0/CPU0
    75      RP_TEMP_PCB                        30        -10       -5         0         70
           80
    75      RP_TEMP_HOT_SPOT                   33        -10       -5         0         70
           80
    85      RP_TEMP_LTM4638                     49        -10       -5         0         80
           90
    85      RP_TEMP_LTM4644_0                   36        -10       -5         0         80
           90
    85      RP_TEMP_LTM4644_1                   39        -10       -5         0         80
           90
    85      RP_JMAC_1V0_VCCP_TMON               33        -10       -5         0         80
           90
    85      RP_JMAC_1V0_VNN_TMON               33        -10       -5         0         80
           90
    85      RP_JMAC_1V0_VCC_RAM_TMON            32        -10       -5         0         80
           90
    85      RP_JMAC_1V2_DDR_VDDQ_TMON           34        -10       -5         0         80
           90
0/PM0
    60      Ambient Temp                       30        -10       -5         0         55
           65
    70      Secondary HotSpot Temp              49        -10       -5         0         65
           75
    90      Primary HotSpot Temp                40        -10       -5         0         85
           95
0/PM1
    60      Ambient Temp                       29        -10       -5         0         55
           65
    70      Secondary HotSpot Temp              48        -10       -5         0         65
           75
    90      Primary HotSpot Temp                40        -10       -5         0         85
           95
0/0/NXR0

```

31	OLTC_LT_P0_iEDFA0	24	18	19	20	30
31	32					
31	OLTC_LT_P0_iEDFA1	25	18	19	20	30
31	32					
31	OLTC_LT_P0_iEDFA2	24	18	19	20	30
31	32					
31	OLTC_LT_P2_iEDFA0	25	18	19	20	30
31	32					
31	OLTC_LT_P3_iEDFA0	25	18	19	20	30
31	32					
31	OLTC_LT_P0_eEDFA0	24	18	19	20	30
31	32					
77	OLTC_CT_1	32	-10	-7	-5	75
77	80					
31	OLTC_LT_P0_eEDFA1	24	18	19	20	30
31	32					
73	OLTC_CT_2	27	-10	-7	-5	70
73	75					
73	OLTC_CT_3	30	-10	-7	-5	70
73	75					
73	OLTC_CT_4	30	-10	-7	-5	70
73	75					
64	OLTC_FT_P0_iEDFA0	60	55	57	58	62
64	65					
64	OLTC_FT_P2_iEDFA0	60	55	57	58	62
64	65					
64	OLTC_FT_P3_iEDFA0	60	55	57	58	62
64	65					
64	OLTC_FT_P0_eEDFA0	60	55	57	58	62
64	65					
0/Rack						
55	SA_TEMP_AIR_INLET0	27	-10	-5	0	45
55	60					
55	SA_TEMP_AIR_INLET1	28	-10	-5	0	45
55	60					
85	SA_TEMP_AIR_EXAUST0	30	-10	-5	0	75
85	90					
85	SA_TEMP_AIR_EXAUST1	28	-10	-5	0	75
85	90					
85	SA_TEMP_PCB_HOT_SPOT0	31	-10	-5	0	80
85	90					
85	SA_TEMP_PCB_HOT_SPOT1	34	-10	-5	0	80
85	90					
85	SA_TEMP_PCB_HOT_SPOT2	31	-10	-5	0	80
85	90					
85	SA_TEMP_PCB_HOT_SPOT3	32	-10	-5	0	80
85	90					

Location	VOLTAGE Sensor	Value (mV)	Crit (Lo)	Minor (Lo)	Minor (Hi)	Crit (Hi)
----------	-------------------	---------------	--------------	---------------	---------------	--------------

0/RP0/CPU0

RP_ADM1266_12V0	12094	10800	11280	12720	13200
RP_ADM1266_1V8_CPU	1806	1670	1750	1850	1930
RP_ADM1266_1V24_VCCREF	1238	1150	1200	1280	1330
RP_ADM1266_1V05_CPU	1052	980	1020	1080	1120
RP_ADM1266_1V2_DDR_VDDQ	1204	1120	1160	1240	1280
RP_ADM1266_1V0_VCC_RAM	988	650	700	1250	1300
RP_ADM1266_1V0_VNN	871	550	600	1250	1300
RP_ADM1266_1V0_VCCP	1018	450	500	1250	1300
RP_ADM1266_0V6_DDR_VTT	599	560	580	620	640
RP_ADM1266_3V3_STAND_BY	3301	3070	3200	3400	3530
RP_ADM1266_5V0	5004	4650	4850	5150	5350
RP_ADM1266_3V3	3325	3070	3200	3400	3530

## show environment

	RP_ADM1266_2V5_PLL	2489	2330	2430	2580	2680
	RP_ADM1266_2V5_FPGA	2502	2330	2430	2580	2680
	RP_ADM1266_1V2_FPGA	1197	1120	1160	1240	1280
	RP_ADM1266_3V3_CPU	3332	3070	3200	3400	3530
	RP_ADM1266_2V5_CPU	2498	2330	2430	2580	2680
0/Rack	SA_ADM1266_12V_BUS_EITU	12065	10800	11280	12720	13200
	SA_ADM1266_5V0	5033	4650	4800	5200	5350
	SA_ADM1266_1V8_ZARLINK_DPLL	1808	1670	1730	1870	1930
	SA_ADM1266_1V0_PHY	1009	930	960	1040	1070
	SA_ADM1266_1V0_ALDRIN_CORE	981	910	930	1070	1090
	SA_ADM1266_1V0_ALDRIN_SERDES	1006	930	960	1040	1070
	SA_ADM1266_1V0_FPGA	1010	930	960	1040	1070
	SA_ADM1266_1V2_FPGA	1211	1120	1150	1250	1280
	SA_ADM1266_1V8	1804	1670	1730	1870	1930
	SA_ADM1266_2V5	2498	2330	2400	2600	2680
	SA_ADM1266_3V3	3308	3070	3170	3430	3530
	SA_ADM1275_12V_SA_BP	12073	10800	11280	12720	13200
	SA_ADM1275_12V_CPU_BP	12058	10800	11280	12720	13200
	SA_ADM1275_12V_MOD0_BP	12063	10800	11280	12720	13200
	SA_ADM1275_12V_MOD1_BP	12037	10800	11280	12720	13200
	SA_ADM1275_12V_MOD2_BP	12053	10800	11280	12720	13200
	SA_ADM1275_12V_FAN0_BP	12037	10800	11280	12720	13200
	SA_ADM1275_12V_FAN1_BP	12063	10800	11280	12720	13200

Location	CURRENT Sensor	Value (mA)
----------	----------------	------------

-----

0/RP0/CPU0

	RP_CURRMON_LTM4638	395
	RP_CURRMON_LTM4644_0	179
	RP_CURRMON_LTM4644_1	311
	RP_JMAC_1V0_VCCP_IMON	62
	RP_JMAC_1V0_VNN_IMON	93
	RP_JMAC_1V0_VCC_RAM_IMON	62
	RP_JMAC_1V2_DDR_VDDQ_IMON	187

0/Rack

	SA_ADM1275_12V_MOD0_IMON	5495
	SA_ADM1275_12V_MOD1_IMON	6
	SA_ADM1275_12V_MOD2_IMON	6
	SA_ADM1275_12V_FAN0_IMON	1146
	SA_ADM1275_12V_FAN1_IMON	1381
	SA_INA230_5V0_IMON	323
	SA_INA230_3V3_IMON	2584
	SA_INA230_1V0_XGE_CORE_IMON	2459
	SA_INA230_1V0_FPGA_CORE_IMON	784
	SA_ADM1275_12V_SA_IMON	1603
	SA_ADM1275_12V_CPU_IMON	1222

Location	FRU Type	Fan speed (rpm)		
		FAN_0	FAN_1	FAN_2
0/PM0	NCS1010-AC-PSU	5456		
0/PM1	NCS1010-AC-PSU	5336		
0/FT0	NCS1010-FAN	10020	10020	10020
0/FT1	NCS1010-FAN	9960	10020	9960

Location	Altitude Value (Meters)	Source
0	772	sensor

CHASSIS LEVEL POWER INFO: 0

```

=====
Total output power capacity (Group 0 + Group 1) : 1050W + 1050W
Total output power required : 700W
Total power input : 206W
Total power output : 138W

Power Group 0:
=====
Power      Supply      -----Input-----  -----Output---  Status
Module     Type          Volts    Amps    Volts    Amps
=====
0/PM0      NCS1010-AC-PSU  229.0    0.4    12.1    5.5    OK

Total of Group 0:                91W/0.4A                66W/5.5A

Power Group 1:
=====
Power      Supply      -----Input-----  -----Output---  Status
Module     Type          Volts    Amps    Volts    Amps
=====
0/PM1      NCS1010-AC-PSU  229.0    0.5    12.1    6.0    OK

Total of Group 1:                114W/0.5A                72W/6.0A

=====
Location    Card Type          Power      Power      Status
              Allocated    Used
              Watts      Watts
=====
0/RP0/CPU0  NCS1010-CNTRLR-K9  90         14         ON
0/FT0       NCS1010-FAN        110        16         ON
0/FT1       NCS1010-FAN        110        16         ON
0/0/NXR0    NCS1K-OLT-C        350        71         ON
0/Rack      NCS1010-SA         40         19         ON
=====
=====

```

# show fpd package

To determine the FPDs that are supported with the current software release and the minimum hardware requirements for each FPD, use the **show fpd package** command in Cisco IOS XR mode.

**show fpd package** [ **detail** ]

**Syntax Description** **detail** (Optional) Displays detailed information about FPD upgrade.

**Command Default** Firmware information of all the hardware components is displayed.

**Command Modes** Cisco IOS XR EXEC

**Command History**

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example shows sample output from the **show fpd package** command.

```
RP/0/RP0/CPU0:ios#show fpd package
Wed Jun 29 08:50:21.057 UTC
=====
                                Field Programmable Device Package
                                =====
Card Type                FPD Description                Req  SW   Min Req  Min Req
                                Reload Ver   SW Ver   Board Ver
=====
NCS1010-AC-PSU          AP-PrimMCU                      NO   1.03   1.03     0.0
                          AP-SecMCU                       NO   2.01   2.01     0.0
-----
NCS1010-CNTRLR-K9      ADMConfig                       NO   2.30   2.30     0.0
                          ADMConfig                       NO   2.30   2.30     0.0
                          ADMConfig                       NO   3.40   3.30     1.0
                          BIOS                            YES   4.10   4.10     0.0
                          BIOS                            YES   4.10   4.10     0.0
                          BIOS-Golden                     YES   4.10   4.10     0.0
                          BIOS-Golden                     YES   4.10   4.10     0.0
                          CpuFpga                         YES   1.02   1.02     0.0
                          CpuFpga                         YES   1.02   1.02     0.0
                          CpuFpgaGolden                   YES   1.01   1.01     0.0
                          CpuFpgaGolden                   YES   1.01   1.01     0.0
                          SsdIntelS4510                  YES  11.32  11.32     0.0
                          SsdIntelS4510                  YES  11.32  11.32     0.0
                          SsdMicron5300                  YES   0.01   0.01     0.0
                          SsdMicron5300                  YES   0.01   0.01     0.0
                          SsdSmartModular                YES  13.06  13.06     0.0
                          SsdSmartModular                YES  13.06  13.06     0.0
                          TamFw                          YES   6.13   6.13     0.0
                          TamFw                          YES   6.13   6.13     0.0
                          TamFwGolden                    YES   6.11   6.11     0.0
                          TamFwGolden                    YES   6.11   6.11     0.0
-----
```

NCS1010-SA	EITU-ADMConfig	NO	1.04	1.04	0.0
	EITU-ADMConfig	NO	2.10	2.10	1.0
	EITU-ADMConfig	NO	1.04	1.04	0.0
	EITU-ADMConfig	NO	2.10	2.10	1.0
	IoFpga	NO	1.04	1.04	0.0
	IoFpga	NO	1.04	1.04	0.0
	IoFpgaGolden	NO	1.01	1.01	0.0
	IoFpgaGolden	NO	1.01	1.01	0.0
	SsdIntelS4510	YES	11.32	11.32	0.0
	SsdIntelS4510	YES	11.32	11.32	0.0
	SsdMicron5300	YES	0.01	0.01	0.0
	SsdMicron5300	YES	0.01	0.01	0.0
	SsdSmartModular	YES	13.06	13.06	0.0
	SsdSmartModular	YES	13.06	13.06	0.0
-----					
NCS1K-ILA-2R-C	ILA	NO	1.00	1.00	0.1
	ILA	NO	0.23	0.23	99.1
	Raman-1	NO	1.00	1.00	0.1
	Raman-1	NO	0.23	0.23	99.1
	Raman-2	NO	1.00	1.00	0.1
	Raman-2	NO	0.23	0.23	99.1
-----					
NCS1K-ILA-C	ILA	NO	1.00	1.00	0.1
	ILA	NO	0.23	0.23	99.1
-----					
NCS1K-ILA-R-C	ILA	NO	1.00	1.00	0.1
	ILA	NO	0.23	0.23	99.1
	Raman-1	NO	1.00	1.00	0.1
	Raman-1	NO	0.23	0.23	99.1
-----					
NCS1K-OLT-C	OLT	NO	1.00	1.00	0.1
	OLT	NO	0.23	0.23	99.1
-----					
NCS1K-OLT-R-C	OLT	NO	1.00	1.00	0.1
	OLT	NO	0.23	0.23	99.1
	Raman-1	NO	1.00	1.00	0.1
	Raman-1	NO	0.23	0.23	99.1

# show hw-module fpd

To display the firmware information of various hardware components of NCS 1010, use the **show hw-module fpd** command in Cisco IOS XR mode.

**show hw-module fpd** [ *fpd-name* ]

<b>Syntax Description</b>	<i>fpd-name</i> (Optional) Name of the FPD.
---------------------------	---

<b>Command Default</b>	Firmware information of all the hardware components is displayed.
------------------------	---

<b>Command Modes</b>	Cisco IOS XR EXEC
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example shows sample output from the **show hw-module fpd** command.

```
RP/0/RP0/CPU0:ios# show hw-module fpd
```

```
Wed Jun 29 08:50:21.057 UTC
```

```
Auto-upgrade:Disabled
```

Location Reload Loc	Card type	HWver	FPD device	ATR Status	FPD Versions	
					Running	Programd
0/RP0/CPU0 NOT REQ	NCS1010-CNTRLR-K9	1.0	ADMConfig	CURRENT	3.40	3.40
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	BIOS	S CURRENT	4.10	4.10
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	BIOS-Golden	BS CURRENT		4.10
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	CpuFpga	S CURRENT	1.02	1.02
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	CpuFpgaGolden	BS CURRENT		1.01
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	SsdIntelS4510	S CURRENT	11.32	11.32
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	TamFw	S CURRENT	6.13	6.13
0/RP0/CPU0 0/RP0	NCS1010-CNTRLR-K9	1.0	TamFwGolden	BS CURRENT		6.11
0/PM0 NOT REQ	NCS1010-AC-PSU	0.0	AP-PrimMCU	CURRENT	1.03	1.03
0/PM0 NOT REQ	NCS1010-AC-PSU	0.0	AP-SecMCU	CURRENT	2.01	2.01
0/PM1 NOT REQ	NCS1010-AC-PSU	0.0	AP-PrimMCU	CURRENT	1.03	1.03



0/PM1	NCS1010-AC-PSU	0.0	AP-SecMCU	CURRENT	2.01	2.01
NOT REQ						
0/0/NXR0	NCS1K-ILA-C	1.0	ILA	S CURRENT	1.00	1.00
NOT REQ						
0/Rack	NCS1010-SA	1.0	EITU-ADMConfig	CURRENT	2.10	2.10
NOT REQ						
0/Rack	NCS1010-SA	1.0	IoFpga	S CURRENT	1.04	1.04
NOT REQ						
0/Rack	NCS1010-SA	1.0	IoFpgaGolden	BS CURRENT		1.01
NOT REQ						
0/Rack	NCS1010-SA	1.0	SsdIntelS4510	S CURRENT	11.32	11.32
0/Rack						

# show inventory

To retrieve and display the physical inventory information of the system, use the **show inventory** command in Cisco IOS XR mode.

```
show inventory [ WORD | all | chassis | details | fan | location | power ] [
raw | vendor-type ]
```

## Syntax Description

<b>WORD</b>	(Optional) Displays partially qualified location specification.
<b>all</b>	(Optional) Displays inventory information for all the physical entities.
<b>chassis</b>	(Optional) Displays inventory information for the entire chassis.
<b>details</b>	(Optional) Displays detailed entity information.
<b>fan</b>	(Optional) Displays inventory information for the fans.
<b>location</b>   <i>location</i>	(Optional) Displays inventory information for a specific node, or for all nodes in the chassis.
<b>power</b>	(Optional) Displays inventory information for the power supply.
<b>raw</b>	(Optional) Displays raw information about the chassis for diagnostic purposes.
<b>vendor-type</b>	(Optional) Displays vendor-type information.

## Command Default

All hardware inventory information is displayed.

## Command Modes

Cisco IOS XR EXEC

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Usage Guidelines

Enter the **show inventory** command with the **raw** keyword to display every RFC 2737 entity installed in NCS 1020, including those without a PID, unique device identifier (UDI), or other physical identification. The **raw** keyword is primarily intended for troubleshooting problems with the **show inventory** command itself.

## Example

The following examples show sample output from the show inventory command in both EXEC and Administration EXEC modes.

```
sysadmin-vm:0_RP0# show inventory
```

```
RP/0/RP0/CPU0:ios#show inventory
```

```
Mon May 6 16:38:33.857 IST
```

```
NAME: "Rack 0", DESCR: "NCS 1020 Shelf Assembly"
PID: NCS1020-SA          , VID: V00, SN: FCB2749B0FD

NAME: "0/RP0/CPU0", DESCR: "NCS 1010, 1012, 1020 Controller with 9600bps console rate"
PID: NCS1010-CTR2-B-K9 , VID: V00, SN: FCB2748B01S

NAME: "0/RP0-PTP0", DESCR: "Cisco Pluggable Optics Module"
PID: ONS-SI-GE-LX      , VID: V01, SN: AGC1703UE1M

NAME: "0/RP0-PTP1", DESCR: "Cisco Pluggable Optics Module"
PID: GLC-SX-MMD        , VID: V01, SN: OPM221407E5

NAME: "0/RP0-PTP2", DESCR: "Cisco Pluggable Optics Module"
PID: SFP-GE-S          , VID: V01, SN: FNS17040APG

NAME: "0/RP0-PTP3", DESCR: "Cisco Pluggable Optics Module"
PID: ONS-SI-GE-LX      , VID: V02, SN: FNS19170MGZ

NAME: "0/0/NXR0", DESCR: "NCS 1010 Optical Line Terminal - C-band, enhanced"
PID: NCS1K-E-OLT-C     , VID: V01, SN: FCB2721B1DP

NAME: "0/9/NXR0", DESCR: "Network Convergence System 1014 Filler"
PID: NCS1K14-BLANK     , VID: V01, SN: N/A

NAME: "0/1/NXR0", DESCR: "Network Convergence System 1010 Passive Filler"
PID: NCS1010-FLR-P     , VID: V01, SN: N/A

NAME: "0/2/NXR0", DESCR: "NCS 1014 16 port Colorless Direct attach LC with EDFA C-band"
PID: NCS1K14-CCMD-16-C , VID: V01, SN: FCB2749B06U

NAME: "0/3/NXR0", DESCR: "NCS 1014 16 port Colorless Direct attach LC with EDFA C-band"
PID: NCS1K14-CCMD-16-C , VID: V00, SN: FCB2744B0FA
```

NAME: "0/4/NXR0", DESCR: "Network Convergence System 1014 Filler"  
PID: NCS1K14-BLANK , VID: V01, SN: N/A

NAME: "0/5/NXR0", DESCR: "Network Convergence System 1014 Filler"  
PID: NCS1K14-BLANK , VID: V01, SN: N/A

NAME: "0/6/NXR0", DESCR: "Network Convergence System 1014 Filler"  
PID: NCS1K14-BLANK , VID: V01, SN: N/A

NAME: "0/7/NXR0", DESCR: "Network Convergence System 1014 Filler"  
PID: NCS1K14-BLANK , VID: V01, SN: N/A

NAME: "0/8/NXR0", DESCR: "Network Convergence System 1014 Filler"  
PID: NCS1K14-BLANK , VID: V01, SN: N/A

NAME: "0/FT0", DESCR: "NCS1010 - Shelf Fan"  
PID: NCS1010-FAN , VID: V01, SN: FCB2719B0WP

NAME: "0/FT1", DESCR: "NCS1010 - Shelf Fan"  
PID: NCS1010-FAN , VID: V01, SN: FCB2720B2H2

NAME: "0/FT4", DESCR: "NCS 1020 FAN Tray"  
PID: NCS1020-FAN , VID: V00, SN: FCB2752B05V

NAME: "0/FT5", DESCR: "NCS 1020 FAN Tray"  
PID: NCS1020-FAN , VID: V00, SN: FCB2752B05W

NAME: "0/FT6", DESCR: "NCS 1020 FAN Tray"  
PID: NCS1020-FAN , VID: V00, SN: FCB2752B08C

NAME: "0/FT7", DESCR: "NCS 1020 FAN Tray"

PID: NCS1020-FAN , VID: V00, SN: FCB2752B072

NAME: "0/PM0", DESCR: "Network Convergence System 1004 AC Power Supply Unit 2.5KW"

PID: NCS1K4-AC-PSU-2 , VID: V01, SN: POG27430N29

NAME: "0/PM1", DESCR: "Network Convergence System 1004 AC Power Supply Unit 2.5KW"

PID: NCS1K4-AC-PSU-2 , VID: V01, SN: POG27430N1P

# show license all

To display all licensing information, use the **show license all** command. This command displays status, authorization, UDI, and usage information, all combined.

## show license all

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Administration for Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None.	

This example shows you how to use the **show license all** command, and the sample output.

```
RP/0/RP0/CPU0:ios#show license all
Fri Jul 15 05:32:02.678 UTC
Smart Licensing Status
=====
Smart Licensing is ENABLED
Registration:
Status: REGISTERED
Smart Account: InternalTestDemoAccount8.cisco.com
Virtual Account: NCS1010-PROD
Export-Controlled Functionality: ALLOWED
Initial Registration: SUCCEEDED on Jul 15 2022 04:58:24 UTC
Last Renewal Attempt: None
Next Renewal Attempt: Jan 11 2023 04:58:23 UTC
Registration Expires: Jul 15 2023 04:53:20 UTC
License Authorization:
Status: AUTHORIZED on Jul 15 2022 04:58:40 UTC
Last Communication Attempt: SUCCEEDED on Jul 15 2022 04:58:40 UTC
Next Communication Attempt: Aug 14 2022 04:58:40 UTC
Communication Deadline: Oct 13 2022 04:53:41 UTC
Export Authorization Key:
Features Authorized:
<none>
Utility:
Status: DISABLED
Data Privacy:
Sending Hostname: yes
Callhome hostname privacy: DISABLED
Smart Licensing hostname privacy: DISABLED
Version privacy: DISABLED
Transport:
Type: Callhome
Miscellaneous:
Smart Licensing
10
```

```

Smart Licensing
Verify Smart Licensing Configuration
REVIEW DRAFT - CISCO CONFIDENTIAL
Custom Id: <empty>
License Usage
=====
NCS1010 - Essentials - OLT RTU (NCS1010_ESS_OLT_RTU):
Description: NCS1010 - Essentials Tier - Optical Line Terminal RTU (Per Port)
Count: 2
Version: 1.0
Status: AUTHORIZED
Export status: NOT RESTRICTED
NCS1010 - Essentials - OLT SIA (NCS1010_ESS_OLT_SIA):
Description: NCS1010 - Essentials Subscription - Optical Line Terminal - SIA
(Per Port)
Count: 2
Version: 1.0
Status: AUTHORIZED
Export status: NOT RESTRICTED
Product Information
=====
UDI: PID:NCS1010-SA,SN:FCB2546B08T
Agent Version
=====
Smart Agent for Licensing: 5.4.16_rel/63
Reservation Info
=====
License reservation: DISABLED

```

## show license summary

To display the license summary, use the **show license summary** command.

### show license summary

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Administration for Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None.	

This example shows you how to use the **show license summary** command, and the sample output.

```

RP/0/RP0/CPU0:ios#show license summary

Tue Jul 19 15:21:49.227 UTC

Smart Licensing is ENABLED
License Reservation is ENABLED

```

```

Registration:
Status: REGISTERED - SPECIFIC LICENSE RESERVATION
Export-Controlled Functionality: ALLOWED

License Authorization:
Status: AUTHORIZED - RESERVED

License Usage:
License                               Entitlement Tag                               Count Status
-----
NCS1010 - Essentials... (NCS1010_ESS_OLT_RTU)           3 AUTHORIZED
NCS1010 - Essentials... (NCS1010_ESS_OLT_SIA)           3 AUTHORIZED
RP/0/RP0/CPU0:P2A_DT_08#show license usage
Tue Jul 19 15:22:11.234 UTC

License Authorization:
Status: AUTHORIZED - RESERVED on Jul 19 2022 15:21:24 UTC

NCS1010 - Essentials - OLT RTU (NCS1010_ESS_OLT_RTU):
Description: NCS1010 - Essentials Tier - Optical Line Terminal RTU (Per
Port)
Count: 3
Version: 1.0
Status: AUTHORIZED
Export status: NOT RESTRICTED
Reservation:
Reservation status: SPECIFIC INSTALLED
Total reserved count: 3

NCS1010 - Essentials - OLT SIA (NCS1010_ESS_OLT_SIA):
Description: NCS1010 - Essentials Subscription - Optical Line Terminal
- SIA
(Per Port)
Count: 3
Version: 1.0
Status: AUTHORIZED
Export status: NOT RESTRICTED
Reservation:
Reservation status: SPECIFIC INSTALLED
Total reserved count: 3
RP/0/RP0/CPU0:P2A_DT_08#show license platform summary
Tue Jul 19 15:22:35.859 UTC
Collection: LAST: (unavailable)
NEXT: (pending in 1 minute(s))
Reporting: LAST: (unavailable)
NEXT: (pending in 1 minute(s))

*****IMPORTANT*****
SIA Status: Out of Compliance(Remaining Grace Period: 89 days, 23 hours)

SIA license(s) status is Not Authorized.
SW Upgrade will still be allowed as SIA Grace Period is remaining

*****
Count
Feature/Area      Entitlement                                         Last
Next
=====
0                FCM          NCS1010 - Essentials Tier - Optical Line Terminal R  3
                FCM          NCS1010 - Essentials Subscription - Optical Line Te  3

```



0

# show logging onboard

Use the **show logging onboard** command to view the Onboard Failure Logs (OBFL).

**show logging onboard** { **alarm** | | **location** *location* }

Syntax Description	
<b>alarm</b>	Displays the alarm events.
<b>location</b> <i>location</i>	Specify the location of the hardware module.

**Command Modes** User EXEC mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example shows how to display the Onboard Failure Logs (OBFL) details for the **show logging onboard** command.

```
RP/0/RPO/CPU0:PIAL 05#show logging onboard alarm location 0/ rp0/CPU0
Thu Feb 9 11:34:25.158 UTC
OBFL alarm information for: 0/RPO/CPU0

2022-12-09 09:50:31 DECLARE      ALARM MAJOR      Power Group redundancy lost
2022-12-14 11:25:41 DECLARE      ALARM MAJOR      Power Group redundancy lost
2022-12-09 09:50:31 DECLARE      ALARM MAJOR      Power Group redundancy lost
2022-12-14 11:25:41 DECLARE      ALARM MAJOR      Power Group redundancy lost
2023-02-09 11:33:05 DECLARE      ALARM CRITICAL  PHY1-MDIO-ACCESS-ERROR  Phy1 MDIO access
failure detected
```

# show license platform detail

To display the detailed summary of all Flexible Consumption Models (FCM) licenses in the NCS 1010 platform, use the **show license platform detail** command.

## show license platform detail

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Administration for Cisco IOS XR				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	None.				

This example shows you how to use the **show license platform detail** command, and the sample output.

```
RP/0/RP0/CPU0:ios#show license platform detail
Mon Jul 18 10:52:46.333 UTC
Collection: LAST: Mon Jul 18 2022 10:52:07 UTC
           NEXT: Mon Jul 18 2022 10:54:07 UTC
Reporting: LAST: Mon Jul 18 2022 10:52:07 UTC
           NEXT: Mon Jul 18 2022 10:54:07 UTC
SIA Status: In Compliance
Parameters: Collection interval:          2 minute(s)
           Reporting interval:           2 minute(s)
           Throughput gauge:             1000000 Kbps

=====
Feature/Area 'FCM'
  Name: FCM
  Status: ACTIVE
  Flags:

  [ 1] Name: NCS1010 - Essentials Tier - In-Line Amplifier RTU
        Entitlement Tag:
        regid.2022-05.com.cisco.NCS1010_ESS_ILA_RTU,1.0_9b4322b1-bff3-4ddf-944c-16ec9aaab1cc
        Count: Last reported: 0
              Next report: 0
  [ 2] Name: NCS1010 - Essentials Subscription - In-Line Amplifier - SIA
        Entitlement Tag:
        regid.2022-05.com.cisco.NCS1010_ESS_ILA_SIA,1.0_67243ac7-1a7c-41e4-a160-f13df80fd0e4
        Count: Last reported: 0
              Next report: 0
  [ 3] Name: NCS1010 - Essentials Tier - Optical Line Terminal RTU (Per Port)
        Entitlement Tag:
        regid.2022-05.com.cisco.NCS1010_ESS_OLT_RTU,1.0_e4309530-2085-40e6-9aa6-5f3137ff49b2
        Count: Last reported: 9
```

```

        Next report:      0
  [ 4] Name:  NCS1010 - Essentials Subscription - Optical Line Terminal - SIA (Per Port)
        Entitlement Tag:
regid.2022-05.com.cisco.NCS1010_ESS_OLT_SIA,1.0_b3c976c1-e509-474f-8cac-b9db62f28f2b
        Count: Last reported:  9
        Next report:      0
  [ 5] Name:  NCS1010 - Advantage Tier- In-Line Amplifier RTU
        Entitlement Tag:
regid.2022-05.com.cisco.NCS1010_ADV_ILA_RTU,1.0_cf1746b7-def4-4c0e-ab90-de30614507d8
        Count: Last reported:  0
        Next report:      0
  [ 6] Name:  NCS1010 - Advantage Subscription - In-Line Amplifier - SIA
        Entitlement Tag:
regid.2022-05.com.cisco.NCS1010_ADV_ILA_SIA,1.0_ea769b05-9363-47dd-9991-2122c37479eb
        Count: Last reported:  0
        Next report:      0
  [ 7] Name:  NCS1010 - Advantage Tier - Optical Line Terminal RTU (Per Port)
        Entitlement Tag:
regid.2022-05.com.cisco.NCS1010_ADV_OLT_RTU,1.0_7a6ce8f3-3336-4ce2-8803-431227dabfff
        Count: Last reported:  0
        Next report:      0
  [ 8] Name:  NCS1010 - Advantage Subscription - Optical Line Terminal - SIA (Per Port)
        Entitlement Tag:
regid.2022-05.com.cisco.NCS1010_ADV_OLT_SIA,1.0_5f283f1c-143e-4c6e-9af7-73e088fb77a5
        Count: Last reported:  0
        Next report:      0
```

# show license platform summary

To display the summary of FCM licenses in the NCS 1010 platform, use the **show license platform summary** command.

## show license platform summary

<b>Syntax Description</b>	This command has no keywords or arguments.				
<b>Command Default</b>	None				
<b>Command Modes</b>	Administration for Cisco IOS XR				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	None.				

This example shows you how to use the **show license platform summary** command, and the sample output.

```
RP/0/RP0/CPU0:ios#show license platform summary
Mon Jul 18 10:50:59.263 UTC
Collection: LAST: Mon Jul 18 2022 10:50:07 UTC
           NEXT: Mon Jul 18 2022 10:52:07 UTC
Reporting: LAST: Mon Jul 18 2022 10:50:07 UTC
           NEXT: Mon Jul 18 2022 10:52:07 UTC
*****IMPORTANT*****
SIA Status: Out of Compliance(Remaining Grace Period: 89 days, 23 hours)
            Device is in Authorization Expired state.
            SW Upgrade will still be allowed as SIA Grace Period is remaining
*****
Feature/Area      Entitlement                                     Count
                Last Next
=====
FCM               NCS1010 - Essentials Tier - Optical Line Terminal R   9   0
FCM               NCS1010 - Essentials Subscription - Optical Line Te  9   0
```

# show license summary

To display the license summary, use the **show license summary** command.

## show license summary

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Administration for Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None.	

This example shows you how to use the **show license summary** command, and the sample output.

```
RP/0/RP0/CPU0:ios#show license summary
Tue Jul 19 15:21:49.227 UTC
Smart Licensing is ENABLED
License Reservation is ENABLED

Registration:
  Status: REGISTERED - SPECIFIC LICENSE RESERVATION
  Export-Controlled Functionality: ALLOWED

License Authorization:
  Status: AUTHORIZED - RESERVED

License Usage:
  License                               Entitlement Tag                Count Status
  -----
  NCS1010 - Essentials... (NCS1010_ESS_OLT_RTU)      3 AUTHORIZED
  NCS1010 - Essentials... (NCS1010_ESS_OLT_SIA)      3 AUTHORIZED
R
```

# show license udi

To display the smart licensing UDI, use the **show license udi** command.

## show license udi

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	None	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None.	

This example shows you how to use the **show license udi** command, and the sample output.

```
RP/0/RP0/CPU0:ios#show license udi
Tue Jul 19 13:43:19.731 UTC
UDI: PID:NCS1010-SA, SN:FCB2546B08T
```

# show license usage

To display the license usage count, use the **show license usage** command.

## show license usage

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Administration for Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None.	

This example shows you how to use the **show license usage** command, and the sample output.

```
RP/0/RP0/CPU0:iso#show license usage
Fri Jul 15 08:17:40.048 UTC
License Authorization:
Status: OUT OF COMPLIANCE on Jul 15 2022 07:01:00 UTC
NCS1010 - Essentials - OLT RTU (NCS1010_ESS_OLT_RTU):
Description: NCS1010 - Essentials Tier - Optical Line Terminal RTU (Per Port)
Count: 32
Version: 1.0
Status: OUT OF COMPLIANCE
Export status: NOT RESTRICTED
NCS1010 - Essentials - OLT SIA (NCS1010_ESS_OLT_SIA):
Description: NCS1010 - Essentials Subscription - Optical Line Terminal - SIA
Smart Licensing
13
Smart Licensing
Verify Smart Licensing Configuration
REVIEW DRAFT - CISCO CONFIDENTIAL
(Per Port)
Count: 32
Version: 1.0
Status: OUT OF COMPLIANCE
Export status: NOT RESTRICTED
```



# show ntp associations

To display the status of Network Time Protocol (NTP) associations, use the **show ntp associations** command in privileged EXEC mode.

```
show ntp associations [detail] [location node-id]
```

<b>Syntax Description</b>	<b>detail</b> (Optional) Displays detailed information about each NTP association.				
	<b>location node-id</b> (Optional) Displays the status of NTP associations from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.				
<b>Command Default</b>	None				
<b>Command Modes</b>	EXEC				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	Output for the <b>show ntp associations</b> command is displayed only if NTP is configured.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read
Task ID	Operations				
ip-services	read				

This example shows sample output from the **show ntp associations** command:

```
RP/0/RP0/CPU0:ios#show ntp associations
Sun Nov 5 15:14:44.128 UTC

address ref clock st when poll reach delay offset disp
*~203.0.113.51 10.64.58.50 2 81 128 377 1.84 7.802 2.129
* sys_peer, # selected, + candidate, - outlayer, x falseticker, ~ configured
```

**Table 1: show ntp associations Field Descriptions**

Field	Description
*	Peer has been declared the system peer and lends its variables to the system variables.

Field	Description
#	<p>A pound sign (#) displayed next to a configured peer indicates that the router does not synchronize with the peer even though NTP request and response packets are exchanged.</p> <p>In this case, check the output of the <b>show ntp associations detail</b> command or the NTP debugs to see why the clocks are not synchronized.</p> <p>Use the <b>show ntp associations detail</b> and <b>show ntp status</b> commands to obtain additional information about the state of NTP.</p> <p>One possible reason for the # sign is that the NTP client clock differs by more than 4000 seconds from the NTP server clock. On Cisco routers, a time difference of greater than 4000 seconds is considered out of range and prevents the router from synchronization to the server. This does not apply when you first configure an NTP peer on a Cisco router or on reload. In this case, the NTP client clock is changed to match the NTP server clock. Verify the time zone of the client clock; local time is displayed, but time values in NTP messages are in UTC (GMT) time zone. You can manually change the client clock to within a few minutes of the NTP server clock.</p>
+	Peer is a survivor and a candidate for the combining algorithm.
-	Peer is discarded by the clustering algorithm as an outlier.
x	Peer is discarded by the intersection algorithm as a falseticker.
~	Indicates peer is statically configured.
address	IPv4 or IPv6 address of the peer. If a nondefault VRF is configured for the peer, the VRF follows the address.
ref clock	Reference clock type or address for the peer.
st	Stratum setting for the peer.
when	Time since last NTP packet was received from peer, in milliseconds.
poll	Polling interval between NTP poll packets, in seconds. As the NTP server and client are better synced (and there are no dropped packets), this number increases to a maximum of 1024.
reach	<p>Peer reachability (bit string, in octal).</p> <p>The reach field is a circular bit buffer. It gives you the status of the last eight NTP messages (eight bits in octal is 377, so you want to see a reach field value of 377).</p> <p>If an NTP response packet is lost, the lost packet is tracked over the next eight NTP update intervals in the reach field.</p>
delay	Round-trip delay to peer, in milliseconds.

Field	Description
offset	Relative time difference between the client time and server time, in milliseconds. The client slows down or speeds up its clock to match the server time value.  The offset decreases toward zero over time. It likely never reaches zero since the packet delay between the client and server is never exactly the same. Therefore, the client NTP cannot ever exactly match its clock with the server.  If there is an asterisk (*) next to a configured peer, then you are synchronized to this peer and use them as the primary clock.
disp	Dispersion.

This example shows sample output from the **show ntp associations** command with the **detail** keyword:

```
RP/0/RP0/CPU0:ios#show ntp associations detail
Sun Nov 5 15:14:48.763 UTC

203.0.113.51 configured, our_master, stratum 2
ref ID 10.64.58.50, time E8F22BB9.79D4A841 (14:56:57.475 UTC Sun Nov 5 2023)
our mode client, peer mode server, our poll intvl 128, peer poll intvl 128
root delay 0.6866 msec, root disp 1.04, reach 377, sync dist 6.2590
delay 1.84 msec, offset 7.802 msec, dispersion 2.129
precision 2**23, version 4
org time E8F22F92.B647E8FC (15:13:22.712 UTC Sun Nov 5 2023)
rcv time E8F22F92.B88F303C (15:13:22.720 UTC Sun Nov 5 2023)
xmt time E8F22F92.B88F303C (15:13:22.720 UTC Sun Nov 5 2023)
filtdelay = 1.844 1.772 1.983 1.954 1.945 2.000 1.902 1.778
filtoffset = 7.857 7.802 8.065 8.063 8.332 8.397 8.664 8.684
filtererror = 0.000 0.060 1.995 2.055 4.050 4.110 6.060 6.120
```

**Table 2: show ntp associations detail Field Descriptions**

Field	Descriptions
vrf	Nondefault VRF, if specified for this peer.
configured	Statically configured peer.
dynamic	Dynamically discovered peer.
our_master	Synchronization of the local machine to this peer.
sane	Passing of basic sanity checks by this peer.
ref ID	Address of machine to which the peer is synchronized.
time	Last time stamp that the peer received from its master.
our mode	Mode relative to peer (active/passive/client/server/bdcast/bdcast client).
peer mode	Mode of peer relative.
our poll intvl	Poll interval to peer.

Field	Descriptions
peer poll intvl	Poll interval of interval.
root delay	Delay along path to root (ultimate stratum 1 time source).
root disp	Dispersion of path to root.
reach	Peer reachability (bit string in octal).
sync dist	Peer synchronization distance.
delay	Round-trip delay to peer.
offset	Offset of peer clock relative to this clock.
dispersion	Dispersion of peer clock.
precision	Precision of peer clock in (Hertz) Hz.
version	NTP version number that peer is using.
org time	Originate time stamp.
rcv time	Receive time stamp.
xmt time	Transmit time stamp.
filtdelay	Round-trip delay of each sample, in milliseconds.
filtoffset	Clock offset of each sample, in milliseconds.
filtererror	Approximate error of each sample.

# show ntp status

To display the status of Network Time Protocol (NTP), use the **show ntp status** command in XR EXEC mode.

```
show ntp status [ location node-id ]
```

<b>Syntax Description</b>	<b>location node-id</b> (Optional) Displays the status of NTP from the designated node. The <i>node-id</i> argument is entered in the <i>rack/slot</i> notation.				
<b>Command Default</b>	None				
<b>Command Modes</b>	XR EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				
<b>Usage Guidelines</b>	None				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ip-services</td> <td>read</td> </tr> </tbody> </table>	Task ID	Operations	ip-services	read
Task ID	Operations				
ip-services	read				

This example shows sample output from the **show ntp status** command:

```
RP/0/RP0/CPU0:ios#show ntp status
Sun Nov 5 15:14:36.949 UTC

Clock is synchronized, stratum 3, reference is 203.0.113..51
nominal freq is 1000000000.0000 Hz, actual freq is 44881851.3383 Hz, precision is 2**24
reference time is E8F22D7A.AB020D97 (15:04:26.668 UTC Sun Nov 5 2023)
clock offset is 9.690 msec, root delay is 2.553 msec
root dispersion is 24.15 msec, peer dispersion is 2.13 msec
loopfilter state is 'CTRL' (Normal Controlled Loop), drift is 0.0000212807 s/s
system poll interval is 128, last update was 610 sec ago
authenticate is disabled, panic handling is disabled,
hostname resolution retry interval is 1440 minutes.
```

**Table 3: show ntp status Field Descriptions**

Field	Description
synchronized	Synchronized system to an NTP peer.
stratum	NTP stratum of this system.
reference	IPv4 address or first 32 bits of the MD5 hash of the IPv6 address of the peer to which clock is synchronized.

Field	Description
nominal freq	Nominal frequency in Hertz (Hz) of the system hardware clock.
actual freq	Measured frequency in Hz of the system hardware clock.
precision	Precision of the clock of this system in Hz.
reference time	Reference time stamp.
clock offset	Offset of clock to synchronized peer, in milliseconds.
root delay	Total delay along path to root clock, in milliseconds.
root dispersion	Dispersion of root path.
peer dispersion	Dispersion of synchronized peer.
loopfilter state	The state of the clock state machine transition function.
drift	Drift of the hardware clock.
system poll interval	Poll interval of the peer.
last update	Time the router last updated its NTP information.

# show olc apc

Use the **show olc apc** command to view APC status.

```
show olc apc { controller Ots R/S/I/P }
```

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OSC controller.
	<b>controller Ots</b>	Use this parameter to view the information for a particular controller.
<b>Command Modes</b>	User EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following sample is an output of **show olc apc** command.

```
RP/0/RP0/CPU0:OLT1#show olc apc
```

```
Controller      : Ots0/0/0/0
APC Status     : WORKING
```

```
Node RID       : 10.1.1.1
Internal State : IDLE
```

```
Node RID       : 10.99.1.2
Internal State : IDLE
```

```
Node RID       : 10.99.2.2
Internal State : IDLE
```

```
Node RID       : 10.99.4.1
Internal State : IDLE
```

```
Node RID       : 10.1.1.5
Internal State : DISCREPANCY
```

# show olc apc-local

To view the local status of APC on each node, use the **show olc apc-local** command.

```
show olc apc-local { regulation-info { controller Ots R/S/I/P | { tx | rx } } | target-psd-profile } {
controller Ots R/S/I/P }
```

## Syntax Description

<b>regulation-info</b>	Displays APC regulation information.
<b>target-psd-profile</b>	Displays target PSD profile information
<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OSC controller.
<b>controller Ots</b>	Use this parameter to view the information for a particular controller.

## Command Modes

User EXEC mode

## Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following sample is an output of **show olc apc-local** command.

```
RP/0/RP0/CPU0:ios#show olc apc-local
Mon Apr 11 06:59:14.679 UTC
```

```
Controller : Ots0/0/0/0
```

```
TX Status : ENABLED
```

```
RX Status : ENABLED
```

The following sample is an output of **show olc apc-local target-psd-profile** command.

```
RP/0/RP0/CPU0:ios#show olc apc-local target-psd-profile
Tue Apr 26 10:19:24.910 UTC
Controller           : Ots0/0/0/0
Target PSD source    : Configuration
```

Setpoint	Frequency (THz)	Target PSD (dBm/12.5 GHz)
01	191.337494	15.0
02	191.488678	15.0
03	191.639847	-4.1
04	191.791016	-4.1
05	191.942184	-4.1
06	192.093353	-4.1
07	192.244537	-4.1
08	192.395706	-4.1
09	192.546875	-4.1
10	192.698044	-4.1
11	192.849213	-4.1
12	193.000397	-4.1



```

13          193.151566          -4.1
14          193.302734          -4.1
15          193.453903          -4.1
16          193.605072          -4.1
17          193.756256          -4.1
18          193.907425          -4.1
19          194.058594          -4.1
20          194.209763          -4.1
21          194.360931          -4.1
22          194.512115          -4.1
23          194.663284          -4.1
24          194.814453          -4.1
25          194.965622          -4.1
26          195.116791          -4.1
27          195.267975          -4.1
28          195.419144          -4.1
29          195.570312          -4.1
30          195.721481          -4.1
31          195.872650          -4.1
32          196.023834          -4.1
33          196.175003          -4.1

```

The following sample is an output of **show olc apc-local regulation-info controller ots 0/0/0/0 tx** command.

```

RP/0/RP0/CPU0:ios#show olc apc-local regulation-info controller ots 0/0/0/0 tx
Wed Jul  6 05:01:45.177 UTC
Controller          : Ots0/0/0/0
Domain Manager     : 10.1.1.1
Internal Status    : OOR
Direction         : TX
PSD Minimum       : -24.0 (dBm/12.5 GHz)
Gain Range        : Normal
Last Correction    : 2022-07-06 05:01:28

```

Device Parameters	Min	Max	Configuration	Operational
Egress Ampli Gain (dB)	:15.4	29.4	19.5	19.5
Egress Ampli Tilt (dB)	:-5.0	3.1	-2.2	-2.2
TX Ampli Power (dBm)	: -	22.4	-	21.4
TX VOA Attenuation (dB)	:0.0	20.0	0.0	0.0
Egress WSS/DGE Attenuation (dB)	:0.0	25.0	-	-

Channel Discrepancy	Center Frequency	Channel Width	Channel Slice	Channel ID	Channel Source	Spectrum Slice Num	Ampli-Input PSD	Target PSD	Current PSD
	(THz)	(GHz)	Attn Config				(dBm/12.5 GHz)	(dBm/12.5 GHz)	(dBm/12.5 GHz)
	(dB)	(dB)							
	191.375000	75.00	1	OCh	13	-23.2	-4.6	-4.9	
	0.2	7.1							
	191.449997	75.00	-	ASE	37	-23.0	-4.6	-4.7	
	0.1	9.2							
	191.524994	75.00	-	ASE	61	-23.1	-4.6	-4.7	
	0.1	9.3							
	191.600006	75.00	4	OCh	85	-23.1	-4.5	-4.7	
	0.1	8.0							
	191.675003	75.00	-	ASE	109	-23.0	-4.5	-4.5	
	0.0	9.1							
	191.750000	75.00	6	OCh	133	-23.0	-4.4	-4.6	
	0.1	8.0							

## show olc apc-local

191.824997	75.00	-	ASE	157	-23.1	-4.4	-4.6
0.1	9.3						
191.899994	75.00	8	OCh	181	-23.0	-4.4	-4.4
0.0	8.0						
191.975006	75.00	-	ASE	205	-23.0	-4.3	-4.5
0.1	9.1						
192.050003	75.00	10	OCh	229	-23.0	-4.3	-4.5
0.1	8.2						
192.125000	75.00	-	ASE	253	-22.9	-4.3	-4.3
0.0	9.0						
192.199997	75.00	12	OCh	277	-22.8	-4.2	-4.3
0.0	8.3						
192.274994	75.00	-	ASE	301	-22.9	-4.2	-4.4
0.1	9.0						
192.350006	75.00	14	OCh	325	-22.6	-4.2	-4.2
0.0	8.3						
192.425003	75.00	-	ASE	349	-22.8	-4.2	-4.3
0.1	8.7						
192.500000	75.00	16	OCh	373	-22.4	-4.1	-3.9
-0.2	8.1						
192.574997	75.00	-	ASE	397	-22.7	-4.1	-4.2
0.1	8.6						
192.649994	75.00	18	OCh	421	-22.6	-4.1	-4.2
0.1	8.1						
192.725006	75.00	-	ASE	445	-22.7	-4.0	-4.2
0.1	8.6						
192.800003	75.00	20	OCh	469	-22.7	-4.0	-4.1
0.1	7.9						
192.875000	75.00	-	ASE	493	-22.6	-4.0	-4.0
0.0	8.4						
192.949997	75.00	22	OCh	517	-22.6	-3.9	-4.1
0.1	7.6						
193.024994	75.00	-	ASE	541	-22.5	-3.9	-4.0
0.1	8.2						
193.100006	75.00	24	OCh	565	-22.7	-3.8	-4.0
0.1	7.5						
193.175003	75.00	-	ASE	589	-22.7	-3.8	-4.0
0.1	8.2						
193.250000	75.00	26	OCh	613	-22.5	-3.8	-3.9
0.1	7.2						
193.324997	75.00	-	ASE	637	-22.6	-3.8	-4.0
0.2	8.1						
193.399994	75.00	28	OCh	661	-22.7	-3.7	-3.9
0.1	7.2						
193.475006	75.00	-	ASE	685	-22.5	-3.7	-3.8
0.1	8.0						
193.550003	75.00	30	OCh	709	-22.7	-3.7	-3.8
0.1	7.0						
193.625000	75.00	-	ASE	733	-22.7	-3.6	-3.8
0.1	8.1						
193.699997	75.00	32	OCh	757	-22.7	-3.6	-3.7
0.1	6.7						
193.774994	75.00	-	ASE	781	-22.7	-3.5	-3.7
0.1	8.2						
193.850006	75.00	34	OCh	805	-22.7	-3.5	-3.7
0.1	6.6						
193.925003	75.00	-	ASE	829	-22.7	-3.5	-3.6
0.1	8.1						
194.000000	75.00	36	OCh	853	-22.8	-3.5	-3.7
0.2	6.6						
194.074997	75.00	-	ASE	877	-22.8	-3.4	-3.6
0.1	8.3						
194.149994	75.00	38	OCh	901	-22.7	-3.4	-3.5
0.1	10.9						

194.225006	75.00	-	ASE	925	-22.8	-3.3	-3.5
0.1	8.2						
194.300003	75.00	40	OCh	949	-22.9	-3.3	-3.5
0.1	7.1						
194.375000	75.00	-	ASE	973	-22.8	-3.3	-3.4
0.1	8.4						
194.449997	75.00	42	OCh	997	-22.9	-3.2	-3.5
0.2	7.3						
194.524994	75.00	-	ASE	1021	-22.9	-3.2	-3.4
0.1	8.4						
194.600006	75.00	44	OCh	1045	-22.8	-3.2	-3.3
0.1	7.2						
194.675003	75.00	-	ASE	1069	-22.8	-3.2	-3.3
0.1	8.4						
194.750000	75.00	46	OCh	1093	-22.9	-3.1	-3.4
0.2	7.3						
194.824997	75.00	-	ASE	1117	-22.8	-3.1	-3.2
0.1	8.2						
194.899994	75.00	48	OCh	1141	-22.8	-3.0	-3.3
0.2	6.9						
194.975006	75.00	-	ASE	1165	-22.9	-3.0	-3.2
0.1	8.3						
195.050003	75.00	50	OCh	1189	-22.8	-3.0	-3.1
0.1	6.6						
195.125000	75.00	-	ASE	1213	-22.9	-3.0	-3.1
0.1	8.3						
195.199997	75.00	52	OCh	1237	-22.9	-2.9	-3.1
0.1	6.3						
195.274994	75.00	-	ASE	1261	-23.0	-2.9	-3.0
0.1	8.1						
195.350006	75.00	54	OCh	1285	-23.1	-2.8	-3.0
0.1	6.4						
195.425003	75.00	-	ASE	1309	-23.2	-2.8	-3.0
0.1	8.3						
195.500000	75.00	56	OCh	1333	-23.1	-2.8	-2.9
0.1	6.2						
195.574997	75.00	-	ASE	1357	-23.4	-2.8	-3.0
0.2	8.2						
195.649994	75.00	58	OCh	1381	-23.4	-2.7	-2.9
0.1	6.4						
195.725006	75.00	-	ASE	1405	-23.4	-2.7	-2.8
0.1	8.5						
195.800003	75.00	60	OCh	1429	-23.6	-2.7	-2.8
0.1	6.6						
195.875000	75.00	-	ASE	1453	-23.7	-2.6	-2.9
0.2	8.7						
195.949997	75.00	62	OCh	1477	-23.7	-2.6	-2.8
0.2	6.9						
196.024994	75.00	-	ASE	1501	-23.6	-2.5	-2.7
0.1	9.0						
196.100006	75.00	64	OCh	1525	-23.7	-2.5	-2.7
0.1	7.1						

ASE - Noise Loaded Channel

OCh - Optical Channel

# show olc band-status

Use the **show olc band-status** command to display the status of all the nodes in the controller.

## show olc band-status

**Table 4: Syntax Description**

This command has no keywords or arguments.
--

### Command Modes

(config-olc-ots)

### Command History

Release	Modification
Cisco IOS XR Release 24.2.11	This command was introduced.

### Example

The following example shows how to view the status of BFR on each node.

```
RP/0/RP0/CPU0#sh olc band-status
Tue Dec 13 10:45:30.594 UTC

Controller          : Ots0/0/0/0
Self-Band           : C-Band
BFR status          : Running

Node RID            : 10.1.1.1
Self IP Address     : 192.0.2.1
Self Controller     : Ots0/0/0/0
Partner IP address  : 192.0.2.2
Partner Controller  : Ots0/0/0/0
Partner link status : UP
C-Band status       : ACTIVE
C-Band PSD          : Dual Band
L-Band status       : ACTIVE
L-Band PSD          : Dual Band

Node RID            : 10.1.1.2
Self IP Address     : 192.0.2.6
Self Controller     : Ots0/0/0/0
Partner IP address  : 192.0.2.7
Partner Controller  : Ots0/0/0/2
Partner link status : UP
C-Band status       : ACTIVE
C-Band PSD          : Dual Band
L-Band status       : ACTIVE
L-Band PSD          : Dual Band

Node RID            : 10.1.1.3
Self IP Address     : 198.51.100.1
Self Controller     : Ots0/0/0/0
Partner IP address  : 198.51.100.2
Partner Controller  : Ots0/0/0/2
Partner link status : UP
```

```

C-Band status      : ACTIVE
C-Band PSD        : Dual Band
L-Band status     : ACTIVE
L-Band PSD        : Dual Band

Node RID          : 10.1.1.4
Self IP Address   : 203.0.113.1
Self Controller   : Ots0/0/0/0
Partner IP address : 203.0.113.2
Partner Controller : Ots0/0/0/0
Partner link status : UP
C-Band status     : ACTIVE
C-Band PSD        : Dual Band
L-Band status     : ACTIVE
L-Band PSD        : Dual Band

Node RID          : 10.1.1.5
Self IP Address   : 203.0.113.45
Self Controller   : Ots0/0/0/0
Partner IP address : 203.0.113.46
Partner Controller : Ots0/0/0/0
Partner link status : UP
C-Band status     : ACTIVE
C-Band PSD        : Dual Band
L-Band status     : ACTIVE
L-Band PSD        : Dual Band

```

The following table describes the different fields that are displayed in the output of the *show olc band-status* command.

Status	Description
Controller	Name of the controller.
Self-Band	Name of the band. Values: <ul style="list-style-type: none"> <li>• C-Band</li> <li>• L-Band</li> <li>• None</li> </ul>
BFR status	Status of BFR. Values: <ul style="list-style-type: none"> <li>• Running</li> <li>• Paused</li> <li>• NA</li> </ul>
Node RID	Node router ID.
Self IP Address	IP address of the current node on which the command is running. <b>Note</b> This field displays <i>NA</i> if BFR is paused.

Status	Description
Self Controller	Controller details of the current node on which the command is running. <b>Note</b> This field displays <i>NA</i> if BFR is paused.
Partner IP address	IP address of the partner node that is connected to the self node in the <i>Node RID</i> . This IP address is used to communicate between the L-band and C-band device. <b>Note</b> This field displays <i>NA</i> if BFR is paused.
Partner Controller	Controller details of the partner node. <b>Note</b> This field displays <i>NA</i> if BFR is paused.
Partner link status	Connection status of the C and L band nodes. Values: <ul style="list-style-type: none"> <li>• UP</li> <li>• DOWN</li> </ul> <b>Note</b> This field displays <i>NA</i> if BFR is paused.
C-Band status	C band node status. Valid values: <ul style="list-style-type: none"> <li>• ACTIVE</li> <li>• FAILED</li> <li>• RECOVERING</li> <li>• NA</li> </ul> <b>Note</b> This field displays <i>NA</i> if BFR is paused.
C-Band PSD	The active PSD profile on the C-Band node. Valid values: <ul style="list-style-type: none"> <li>• Dual Band</li> <li>• Single Band</li> </ul> <b>Note</b> This field displays <i>NA</i> if BFR is paused.

Status	Description
L-Band status	L band node status. Valid values: <ul style="list-style-type: none"><li>• ACTIVE</li><li>• FAILED</li><li>• RECOVERING</li><li>• NA</li></ul> <b>Note</b> This field displays <i>NA</i> if BFR is paused.
L-Band PSD	The active PSD profile on the L-Band node. Valid values: <ul style="list-style-type: none"><li>• Dual Band</li><li>• Single Band</li></ul> <b>Note</b> This field displays <i>NA</i> if BFR is paused.

# show olc gain-estimator

Use the **show olc gain-estimator** command to view the gain estimation details.

**show olc gain-estimator** { **controller Ots** *R/S/I/P* }

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OSC controller.
	<b>controller Ots</b>	Use this parameter to view the information for a particular controller.
<b>Command Modes</b>	User EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following output is a sample of the **show olc gain-estimator** command.

```
RP/0/RP0/CPU0:ios#show olc gain-estimator
Thu May 12 09:30:39.987 UTC
Controller                               : Ots0/0/0/0
Egress Gain Estimator Status             : IDLE
Egress Estimated Gain                     : 25.9 dB
Egress Estimated Gain Mode                : Extended
Egress Gain Estimation Timestamp         : 2022-05-07 09:16:53

Controller                               : Ots0/0/0/2
Egress Gain Estimator Status             : IDLE
Egress Estimated Gain                     : 11.7 dB
Egress Estimated Gain Mode                : Normal
Egress Gain Estimation Timestamp         : 2022-05-07 10:13:53
```

The following output is a sample of the **show olc gain-estimator controller ots R/S/I/P** command.

```
RP/0/RP0/CPU0:ios#show olc gain-estimator controller Ots 0/0/0/0
Fri Jun 10 05:47:21.119 UTC
Controller                               : Ots0/0/0/0
Ingress Gain Estimator Status             : IDLE
Ingress Estimated Gain                    : 21.7 dB
Ingress Estimated Gain Mode               : Normal
Ingress Gain Estimation Timestamp         : 2022-06-10 05:46:48
```



## show olc link-tuner

To view link tuner status and PSD computation information, use **show olc link-tuner** command.

```
show olc link-tuner { detail } { { controller Ots R/S/I/P } }
```

Syntax Description	detail	Displays link tuner status, PSD computation information, and computed total noise.
	R/S/I/P	Rack/Slot/Instance/Port of the OSC controller.
	controller Ots	Use this parameter to view the information for a particular controller.

**Command Modes** User EXEC mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

### Example

The following sample is an output of **show olc link-tuner** command.

```
RP/0/RP0/CPU0:ios#show olc link-tuner
Controller      : Ots0/0/0/0
Link Tuner Status : OPERATIONAL
Last PSD computation: 2022-05-06 10:59:51
```

```
-----S-----
Setpoint      : Computed PSD
                (dBm/12.5 GHz)
```

```
-----S-----
01             -5.7
02             -5.6
03             -5.6
04             -5.5
05             -5.5
06             -5.4
07             -5.4
08             -5.3
09             -5.3
10             -5.2
11             -5.2
12             -5.1
13             -5.1
14             -5.0
15             -5.0
16             -4.9
17             -4.9
18             -4.8
19             -4.8
20             -4.7
21             -4.7
22             -4.6
23             -4.6
24             -4.5
25             -4.4
```

```

26             -4.4
27             -4.3
28             -4.3
29             -4.2
30             -4.2
31             -4.1
32             -4.1
33             -4.0

```

The following sample is an output of **show olc link-tuner detail** command.

```

RP/0/RP0/CPU0:ios#show olc link-tuner detail
Controller      : Ots0/0/0/0
Link Tuner Status : OPERATIONAL
Last PSD computation: 2022-05-06 10:59:51
Computed Total Noise: -35.4 dB
-----

```

```

Setpoint          : Computed PSD
                   (dBm/12.5 GHz)
-----

```

```

01             -5.7
02             -5.6
03             -5.6
04             -5.5
05             -5.5
06             -5.4
07             -5.4
08             -5.3
09             -5.3
10             -5.2
11             -5.2
12             -5.1
13             -5.1
14             -5.0
15             -5.0
16             -4.9
17             -4.9
18             -4.8
19             -4.8
20             -4.7
21             -4.7
22             -4.6
23             -4.6
24             -4.5
25             -4.4
26             -4.4
27             -4.3
28             -4.3
29             -4.2
30             -4.2
31             -4.1
32             -4.1
33             -4.0

```

# show olc otdr-status

Use the **show olc otdr-status** command to display the status of OTDR scan.

**show olc otdr-status [ details ]**

<b>Syntax Description</b>	<b>details</b> Displays detailed OTDR scan status information.
---------------------------	--

<b>Command Modes</b>	Controller configuration mode
----------------------	-------------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following samples display the various status of OTDR automatic scan during span fault:

```
RP/0/RP0/CPU0:ios#show olc otdr-status details
Mon Sep 18 13:16:16.461 UTC
Controller                               : Ots0/0/0/0
Auto-scan Start Time                     : NA
OTDR Auto-scan Status                   : RUNNING
Status Detail                            : Starting on Span Down
Optical Span Status                       : Down
Trigger Event                             : Span Fault
Last Trigger Event                        : Span Restore
```

```
RP/0/RP0/CPU0:ios#show olc otdr-status details
Mon Sep 18 13:16:33.304 UTC
Controller                               : Ots0/0/0/0
Auto-scan Start Time                     : 2023-09-18 13:16:27
OTDR Auto-scan Status                   : RUNNING
Status Detail                            : Waiting Scan Completion on Span Down
Optical Span Status                       : Down
Trigger Event                           : Span Fault
Last Trigger Event                        : Span Restore
```

```
RP/0/RP0/CPU0:ios#show olc otdr-status details
Mon Sep 18 13:18:54.154 UTC
Controller                               : Ots0/0/0/0
Auto-scan Start Time                     : 2023-09-18 13:16:27
OTDR Auto-scan Status                   : COMPLETED
Status Detail                            : Completed on Span Down
Optical Span Status                       : Down
Trigger Event                           : Span Fault
Last Trigger Event                        : Span Fault
```

# show olc raman-tuning

To view the Raman tuning status using **show olc raman-tuning** command.

```
show olc raman-tuning { controller Ots R/S/I/P }
```

<b>Syntax Description</b>	<i>R/S/I/P</i>	Rack/Slot/Instance/Port of the OSC controller.
	<b>controller Ots</b>	Use this parameter to view the information for a particular controller.
<b>Command Modes</b>	User EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following sample is an output of the **show olc raman-tuning** command.

```
RP/0/RP0/CPU0:ios#sh olc raman-tuning
Fri Apr 1 06:38:34.330 UTC

Controller                : Ots0/0/0/0
Raman-Tuning Status      : TUNED
Tuning Complete Timestamp : 2022-04-01 05:49:30.407029
Estimated Max Possible Gain : 21.7 dB
Raman Gain Target        : 14.7 dB
Gain Achieved on Tuning Complete : 14.6 dB
```

The following sample is an output of the **show olc raman-tuning controller ots r/s/i/p** command.

```
RP/0/RP0/CPU0:ios#sh olc raman-tuning controller ots 0/0/0/0
Fri Apr 1 06:42:49.538 UTC

Controller                : Ots0/0/0/0
Raman-Tuning Status      : TUNED
Tuning Complete Timestamp : 2022-04-01 05:50:19.934044
Estimated Max Possible Gain : 21.1 dB
Raman Gain Target        : 18.0 dB
Gain Achieved on Tuning Complete : 18.1 dB
```

## show olc span-loss

Use the **show olc span-loss** command to view the Tx span loss and Rx span loss.

```
show olc span-loss { controller Ots R/S/I/P }
```

<b>Syntax Description</b>	<i>R/S/I/P</i> Rack/Slot/Instance/Port of the OSC controller.				
<b>controller Ots</b>	Use this parameter to view the span loss for a particular controller.				
<b>Command Modes</b>	User EXEC mode				
<b>Command History</b>	<table border="1"> <thead> <tr> <th style="border-bottom: 1px solid black;">Release</th> <th style="border-bottom: 1px solid black;">Modification</th> </tr> </thead> <tbody> <tr> <td style="border-bottom: 1px solid black;">Cisco IOS XR Release 24.2.11</td> <td style="border-bottom: 1px solid black;">This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.
Release	Modification				
Cisco IOS XR Release 24.2.11	This command was introduced.				

### Example

The following sample shows the output of the **show olc span-loss** command on a Raman span with Raman tuning enabled.

```
RP/0/RP0/CPU0:ios#show olc span-loss
Mon Apr 11 09:33:00.398 UTC

Controller name                : Ots0/0/0/0
Neighbour RID                  : 10.1.1.2
Apparent Rx Span Loss          : 7.7 dB
Rx Span Loss (with pumps off)  : 23.2 dB
Rx Span Loss (with pumps off) measured at : 2022-04-11 07:42:26
Estimated Rx Span Loss        : 23.5 dB
Apparent Tx Span Loss          : 17.5 dB
Tx Span Loss (with pumps off)  : 33.3 dB
Tx Span Loss (with pumps off) measured at : 2022-04-11 07:42:56
Estimated Tx Span Loss        : 33.5 dB
```

# show platform

To display information and status for each node in the network, use the **show platform** command in the XR EXEC mode.

Node Status and Information Command  
**Node Status and Information Command**  
**Show platform**

Chassis Door Status Command  
**Chassis Door Status Command**

**show platform chassis-door**

<b>Syntax Description</b>	<b>show platform</b> Displays the status of the node						
	<b>show platform chassis-door</b> Displays the status of the chassis front door.						
<b>Command Default</b>	None						
<b>Command Modes</b>	XR EXEC mode						
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Cisco IOS XR Release 24.2.11</td> <td>This command was introduced.</td> </tr> <tr> <td>Cisco IOS XR Release 24.3.1</td> <td>This <b>show platform chassis-door</b> command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Cisco IOS XR Release 24.2.11	This command was introduced.	Cisco IOS XR Release 24.3.1	This <b>show platform chassis-door</b> command was introduced.
Release	Modification						
Cisco IOS XR Release 24.2.11	This command was introduced.						
Cisco IOS XR Release 24.3.1	This <b>show platform chassis-door</b> command was introduced.						
<b>Usage Guidelines</b>	None						

## Example

To view the information of the node, use the following command:

```
RP/0/RP0/CPU0:ios#show platform
```

```
Mon May 6 16:38:13.609 IST
```

Node	Type	State	Config state
0/RP0/CPU0	NCS1010-CTR2-B-K9 (Active)	IOS XR RUN	NSHUT, NMON
0/FT0	NCS1010-FAN	OPERATIONAL	NSHUT, NMON
0/FT1	NCS1010-FAN	OPERATIONAL	NSHUT, NMON
0/FT4	NCS1020-FAN	OPERATIONAL	NSHUT, NMON
0/FT5	NCS1020-FAN	OPERATIONAL	NSHUT, NMON

0/FT6	NCS1020-FAN	OPERATIONAL	NSHUT, NMON
0/FT7	NCS1020-FAN	OPERATIONAL	NSHUT, NMON
0/0/NXR0	NCS1K-E-OLT-C	OPERATIONAL	NSHUT, NMON
0/1/NXR0	NCS1010-FLR-P	PRESENT	NSHUT, NMON
0/2/NXR0	NCS1K14-CCMD-16-C	OPERATIONAL	NSHUT, NMON
0/3/NXR0	NCS1K14-CCMD-16-C	OPERATIONAL	NSHUT, NMON
0/4/NXR0	NCS1K14-BLANK	PRESENT	NSHUT, NMON
0/5/NXR0	NCS1K14-BLANK	PRESENT	NSHUT, NMON
0/6/NXR0	NCS1K14-BLANK	PRESENT	NSHUT, NMON
0/7/NXR0	NCS1K14-BLANK	PRESENT	NSHUT, NMON
0/8/NXR0	NCS1K14-BLANK	PRESENT	NSHUT, NMON
0/9/NXR0	NCS1K14-BLANK	PRESENT	NSHUT, NMON
0/PM0	NCS1K4-AC-PSU-2	OPERATIONAL	NSHUT, NMON
0/PM1	NCS1K4-AC-PSU-2	OPERATIONAL	NSHUT, NMON

To view the status of the chassis door, use the following command:

```
RP/0/RP0/CPU0:ios#show platform chassis-door
Mon Jul 1 05:54:59.600 UTC
Chassis door present: Yes
```




---

**Note** When there is no door installed on the chassis, the Chassis door present status shows **No**.

---

# show version

To display the software version and details such as system uptime, use the **show version** command.

## show version

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	The software version and details such as system uptime are displayed for all the nodes in the system.	
<b>Command Modes</b>	Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	Enter the <b>show version</b> command to display the software version, build information and system uptime.	

## Example

The following example shows a sample output from the **show version** command.

```

sysadmin-vm:0_RP0# show version
RP/0/RP0/CPU0:ios#show version

Mon May  6 16:38:47.424 IST

Cisco IOS XR Software, Version 24.2.1.32I LNT

Copyright (c) 2013-2024 by Cisco Systems, Inc.

Build Information:

Built By      : cisco
Built On     : Thu Apr 11 02:06:44 UTC 2024
Build Host   : iox-ucs-033
Workspace    : /auto/iox-ucs-033-san1/prod/24.2.1.32I.SIT_IMAGE/ncs1010/ws/
Version     : 24.2.1.32I
Label       : 24.2.1.32I-MSFT_PILOT

cisco NCS1010 (C3758R @ 2.40GHz)

cisco NCS1020-SA (C3758R @ 2.40GHz) processor with 32GB of memory

NCS1020_P1B_DT_10 uptime is 4 days, 5 hours, 9 minutes

```



NCS 1020 Chassis

# span-length

To configure span length, use the **span-length** command.

**span-length** *length*

<b>Syntax Description</b>	<i>length</i> Span length in 0.1 km. Range: 1-2000
---------------------------	--

<b>Command Modes</b>	(config-olc-ots)
----------------------	------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example is a sample configuration that configures span-length to 10 km.

```
RP/0/RP0/CPU0:ios#configure
RP/0/RP0/CPU0:ios (config)#optical-line-control
RP/0/RP0/CPU0:ios (config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios (config-olc-ots)#span-length 100
RP/0/RP0/CPU0:ios (config-olc-ots)#commit
RP/0/RP0/CPU0:ios (config-olc-ots)#end
```

# span-loss

To configure the span loss thresholds, use the **span-loss** command.

```
span-loss min | max threshold
```

Syntax Description	max	Maximum threshold
	min	Minimum threshold
	threshold	Threshold in range 0.0 to 42.0 dB in increments of 0.1 dB.

Command Modes	(config-olc-ots)
---------------	------------------

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following configuration example sets the span loss minimum threshold to 14 dB and maximum threshold to 35 dB.

```
RP/0/RP0/CPU0:ios#conf
RP/0/RP0/CPU0:ios(config)#optical-line-control
RP/0/RP0/CPU0:ios(config-olc)#controller ots 0/0/0/0
RP/0/RP0/CPU0:ios(config-olc-ots)#span-loss max 350
RP/0/RP0/CPU0:ios(config-olc-ots)#span-loss min 140
RP/0/RP0/CPU0:ios(config-olc-ots)#commit
RP/0/RP0/CPU0:ios(config-olc-ots)#end
```

# tone-pattern controller

Use the **tone-pattern controller** command to start or stop initiating the tone pattern from the OTS controller.

**tone-pattern controller ots** *R/S/I/P* [ **start** | **stop** ]

Syntax Description	Parameter	Description
<b>tone-pattern controller ots</b>		Use this parameter to stop or start the tone pattern operation in the OTS controller.
<i>R/S/I/P</i>		Rack/Slot/Instance/Port of the OTS controller.
<b>start</b>		Use this parameter to start the tone-pattern operation in the OTS controller.
<b>stop</b>		Use this parameter to stop the tone-pattern operation in the OTS controller.

**Command Default** None

**Command Modes** controller configuration mode

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

**Usage Guidelines** None

## Example

The following is a sample configuration of the **tone-pattern controller ots** command that starts the tone pattern on port 2 OTS controller.

```
RP/0/RP0/CPU0:ios#tone-pattern controller ots 0/0/0/4 start
Wed May 25 12:00:03.271 UTC
Tone pattern started
```

The following is a sample configuration of the **tone-pattern controller ots** command that stops the tone pattern on port 2 OTS controller.

```
RP/0/RP0/CPU0:ios#tone-pattern controller ots 0/0/0/4 stop
Wed May 25 12:00:03.271 UTC
Tone pattern detect started
```

# tone-pattern-detect controller

Use the **tone-pattern-detect controller** command to start or stop detecting the tone pattern that is initiated from the OTS controller.

**tone-pattern-detect controller** *controllertype R/S/I/P* [ **start** | **stop** ]

<b>Syntax Description</b>	<b>tone-pattern-detect controller</b>	Use this parameter to stop or start the tone-pattern detect operation in a particular controller.
	<i>controllertype R/S/I/P</i>	Rack/Slot/Instance/Port of the controller.
	<b>start</b>	Use this parameter to start the tone-pattern detect operation in a particular controller.
	<b>stop</b>	Use this parameter to stop the tone-pattern detect operation in a particular controller.
<b>Command Default</b>	None	
<b>Command Modes</b>	controller configuration mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None	

## Example

The following is a sample configuration of the **tone-pattern-detect controller** command that starts the tone pattern detection on the OTS controller.

```
RP/0/RP0/CPU0:ios#tone-pattern-detect controller ots 0/0/0/4 start
Wed May 25 12:00:03.271 UTC
Tone pattern detect started
```

The following is a sample configuration of the **tone-pattern-detect controller** command that starts the tone pattern detection on the OMS controller.

```
RP/0/RP0/CPU0:ios#tone-pattern-detect controller oms 0/2/0/0 start
Wed May 25 12:00:03.271 UTC
Tone pattern detect started
```

The following is a sample configuration of the **tone-pattern-detect controller** command that stops the tone pattern detection on the OTS controller.

```
RP/0/RP0/CPU0:ios#tone-pattern-detect controller ots 0/0/0/4 stop
Wed May 25 12:00:03.271 UTC
Tone pattern detect started
```

The following is a sample configuration of the **tone-pattern-detect controller** command that stops the tone pattern detection on the OMS controller.

**tone-pattern-detect controller**

```
RP/0/RP0/CPU0:ios#tone-pattern-detect controller oms 0/2/0/0 stop  
Wed May 25 12:00:03.271 UTC  
Tone pattern detect started
```

# upgrade hw-module

To upgrade a specific FPD, all the FPDs, or the FPDs belonging to a specific location, use the **upgrade-hw-module** command in Cisco IOS XR mode.

**upgrade hw-module** [**location** [ *location-id* | **all**]] [**fpd** [ *fpd-name* ] | **all**]

<b>Syntax Description</b>	<b>location</b> [ <i>location-id</i>   <b>all</b> ]	Upgrades the FPDs belonging to a specific location.
	<b>fpd</b> [ <i>fpd-name</i>   <b>all</b> ]	Upgrades a specific FPD or all the FPDs.
<b>Command Default</b>	None	
<b>Command Modes</b>	Cisco IOS XR	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

## Example

The following example shows how to upgrade IoFpga FPD.

```
RP/0/RP0/CPU0:ios# upgrade hw-module location 0/Rack fpd IoFpga
```

# ztp clean

To remove all Zero Touch Provisioning (ZTP) logs and settings that are saved on the node, use the ztp clean command in EXEC mode.

## ztp clean

---

**Syntax Description** This command has no keywords or arguments.

---



---

**Command Default** None

---

**Command Modes** Cisco IOS XR Configuration

---

Command History	Release	Modification
	Cisco IOS XR Release 24.2.11	This command was introduced.

---



---

**Usage Guidelines** None

To remove all the ZTP logs and saved settings use the following command.

```
RP/0/RP0/CPU0:ios#ztp clean
Fri Apr 29 06:49:29.760 UTC
This would remove all ZTP temporary files.
Would you like to proceed? [no]: yes
All ZTP operation files have been removed.
ZTP logs are present in /var/log/ztp*.log for logrotate.
Please remove manually if needed.
If you now wish ZTP to run again from boot, do 'conf t/commit replace' followed by reload.
```



## ztp initiate

To remove all Zero Touch Provisioning (ZTP) logs and settings that are saved on the node, use the `ztp clean` command in EXEC mode.

### `ztp clean`

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	Cisco IOS XR Configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.
<b>Usage Guidelines</b>	None	

### Example

To initiate the ZTP use the following command.

```
RP/0/RP0/CPU0:ios#ztp initiate
Fri Jun 17 11:44:08.791 UTC
Initiating ZTP may change your configuration.
Interfaces might be brought up if they are in shutdown state
Would you like to proceed? [no]: yes
ZTP will now run in the background.
Please use "show logging" or look at /var/log/ztp.log to check progress.
RP/0/RP0/CPU0:ios#
```

# ztp terminate

To terminate all existing Zero Touch Provisioning (ZTP) processes, use the `ztp terminate` command in EXEC mode.

## `ztp terminate`

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	Cisco IOS XR Configuration
----------------------	----------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Cisco IOS XR Release 24.2.11	This command was introduced.

<b>Usage Guidelines</b>	None
-------------------------	------

## Example

To terminate the ZTP process use the following command.

```
RP/0/RP0/CPU0:ios#ztp terminate
Fri Apr 29 06:38:59.238 UTC
This would terminate active ZTP session if any (this may leave your system in a partially
configured
state)
Would you like to proceed? [no]: yes
Terminating ZTP
No ZTP process running
```