



## PTP Commands

---

This chapter describes the commands used to configure the Precision Time Protocol (PTP).

- [announce, on page 2](#)
- [clock profile, on page 3](#)
- [clock, on page 4](#)
- [delay-request, on page 5](#)
- [domain, on page 6](#)
- [log, on page 7](#)
- [profile, on page 8](#)
- [ptp, on page 9](#)
- [sync, on page 10](#)
- [transport, on page 11](#)

# announce

To configure options for configuring PTP profile announcement messages, use the **announce** command in PTP profile configuration mode.

**announce frequency *frequency***

<b>Syntax Description</b>	<b>frequency <i>frequency</i></b> Use to specify multiple announce messages per second (2, 4, 8, 16, 32, 64, or 128). Frequency of 4 means that four messages are sent per second.				
<b>Command Default</b>	No default behavior or values.				
<b>Command Modes</b>	PTP profile configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>6.5.31</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	6.5.31	This command was introduced.
Release	Modification				
6.5.31	This command was introduced.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	ethernet-services	read, write
Task ID	Operations				
ethernet-services	read, write				

## Example

The following example shows how to sets the announcement frequency to 8 seconds in the PTP configuration profile.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# profile pl
RP/0/RP0/CPU0:router(config-ptp-profile)# announce frequency 8
```

# clock profile

To configure the ITU-T Telecom profile and clock type that can be used in all local PTP sessions, use the **clock profile** command in the PTP configuration mode.

## clock profile g.8275.1 clock-type T-BC

<b>Syntax Description</b>	<b>clock-type T-BC</b> Indicates the clock type for G.8275.1 profile. G.8275.1 profile supports T-BC (Telecom Boundary Clock)				
<b>Command Default</b>	The default PTP profile defined in the IEEE-1588 standard is used if this configuration is not used.				
<b>Command Modes</b>	PTP configuration				
<b>Command History</b>	<table> <thead> <tr> <th><b>Release</b></th> <th><b>Modification</b></th> </tr> </thead> <tbody> <tr> <td>6.5.31</td> <td>This command was introduced.</td> </tr> </tbody> </table>	<b>Release</b>	<b>Modification</b>	6.5.31	This command was introduced.
<b>Release</b>	<b>Modification</b>				
6.5.31	This command was introduced.				
<b>Task ID</b>	<table> <thead> <tr> <th><b>Task ID</b></th> <th><b>Operations</b></th> </tr> </thead> <tbody> <tr> <td>ethernet-services</td> <td>read, write</td> </tr> </tbody> </table>	<b>Task ID</b>	<b>Operations</b>	ethernet-services	read, write
<b>Task ID</b>	<b>Operations</b>				
ethernet-services	read, write				

## Example

The following example shows configuring G.8275.1 profile with T-BC clock type:

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# clock
RP/0/RP0/CPU0:router(config-ptp-clock)# domain 24
RP/0/RP0/CPU0:router(config-ptp-clock)# profile g.8275.1 clock-type T-BC
RP/0/RP0/CPU0:router(config-ptp-clock)# exit
```

# clock

To enter Precision Time Protocol (PTP) clock configuration mode and run PTP clock configuration command, use the **clock** command in PTP configuration mode.

## clock

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	Global PTP configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.5.31	This command was introduced.
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	read, write

## Example

The following example shows how to enter PTP clock configuration mode from global configuration mode.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# clock
RP/0/RP0/CPU0:router(config-ptp-clock)#
```

# delay-request

To configure settings for the PTP delay request message, use the **delay-request** command in PTP profile configuration mode.

**delay-request frequency *frequency***

<b>Syntax Description</b>	<b>frequency <i>frequency</i></b> Specifies multiple announce messages per second (2, 4, 8, 16, 32, 64, or 128). Frequency of 4 means that four messages are sent per second.				
<b>Command Default</b>	The default is one second between messages.				
<b>Command Modes</b>	PTP configuration mode				
<b>Command History</b>	<table><thead><tr><th><b>Release</b></th><th><b>Modification</b></th></tr></thead><tbody><tr><td>6.5.31</td><td>This command was introduced.</td></tr></tbody></table>	<b>Release</b>	<b>Modification</b>	6.5.31	This command was introduced.
<b>Release</b>	<b>Modification</b>				
6.5.31	This command was introduced.				
<b>Task ID</b>	<table><thead><tr><th><b>Task ID</b></th><th><b>Operations</b></th></tr></thead><tbody><tr><td>ethernet-services</td><td>read, write</td></tr></tbody></table>	<b>Task ID</b>	<b>Operations</b>	ethernet-services	read, write
<b>Task ID</b>	<b>Operations</b>				
ethernet-services	read, write				

## Example

The following example sets the delay request frequency in the PTP configuration profile to 16 seconds.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# profile p1
RP/0/RP0/CPU0:router(config-ptp-profile)# delay-request frequency 16
```

# domain

To specify the domain number for the PTP clock, use the **domain** command in PTP clock configuration mode.

**domain** *number*

<b>Syntax Description</b>	<i>number</i> Specifies the domain number to use for this clock (0-255).
---------------------------	--

<b>Command Default</b>	Default is 0.
------------------------	---------------

<b>Command Modes</b>	PTP clock configuration
----------------------	-------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.5.31	This command was introduced.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	read, write

## Example

The following example sets the domain to 24.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# clock
RP/0/RP0/CPU0:router(config-ptp-clock)# domain 24
```

# log

To enable logging of changes to the best master clock for Precision Time Protocol (PTP), use the **log best-master-clock changes** command in PTP configuration mode.

## log best-master-clock changes

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	None	
<b>Command Modes</b>	PTP configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.5.31	This command was introduced.
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	logging	read, write

## Example

The following example sets up PTP to log the best master clock changes.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# log best-master-clock changes
```

# profile

To enter Precision Time Protocol (PTP) profile configuration mode and run PTP profile configuration commands, use the **profile** command in PTP configuration mode.

**profile name**

<b>Syntax Description</b>	<b>profile name</b> Enters PTP profile configuration mode for the specified profile name.
---------------------------	---

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

<b>Command Modes</b>	PTP configuration
----------------------	-------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.5.31	This command was introduced.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	read, write

## Example

The following example shows how to configure the profile tp128.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# profile tp128
```

# ptp

To enter Precision Time Protocol (PTP) configuration mode and run PTP configuration commands, use the **ptp** command in global configuration mode.

**ptp**

<b>Syntax Description</b>	This command has no keywords or arguments.	
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	Global configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.5.31	This command was introduced.
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	read, write

## Example

The following example shows how to enter PTP configuration mode from global configuration mode.

```
RP/0/RP0/CPU0:router# config terminal  
RP/0/RP0/CPU0:router(config)# ptp  
RP/0/RP0/CPU0:router(config-ptp)#
```

# sync

To configure settings for PTP sync messages, use the **sync** command in PTP profile configuration mode.

**sync frequency *frequency***

<b>Syntax Description</b>	<b>frequency</b> <i>frequency</i> Use to specify multiple sync messages per second (2, 4, 8, 16, 32, 64, or 128). Frequency of 4 means that four messages are sent per second.
---------------------------	--

<b>Command Default</b>	No default behavior or values.
------------------------	--------------------------------

<b>Command Modes</b>	PTP profile configuration
----------------------	---------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 6.5.31	This command was introduced.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	read, write

## Example

The following example sets the PTP sync timeout to 16 milliseconds.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# profile p1
RP/0/RP0/CPU0:router(config-ptp-profile)# sync frequency 2000
```

# transport

To specify the PTP transport type, use the **transport** command in PTP profile configuration mode.

## **transport ethernet**

<b>Syntax Description</b>	<b>ethernet</b> Specifies that Ethernet is used as the transport type on the interface.	
<b>Command Default</b>	No default behavior or values.	
<b>Command Modes</b>	PTP profile configuration	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.5.31	This command was introduced.
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	ethernet-services	read, write

## **Example**

The following example sets the transport type to be Ethernet.

```
RP/0/RP0/CPU0:router# config terminal
RP/0/RP0/CPU0:router(config)# ptp
RP/0/RP0/CPU0:router(config-ptp)# profile p1
RP/0/RP0/CPU0:router(config-ptp-profile)# transport ethernet
```

transport