



## MPLS Label Distribution Protocol Commands

This module describes the commands used to configure Label Distribution Protocol (LDP) in a Multiprotocol Label Switching (MPLS) network on Cisco NCS 6000 Series Routers.

LDP provides a standard methodology for hop-by-hop (or dynamic label) distribution in an MPLS network by assigning labels to routes that have been chosen by the underlying Interior Gateway Protocol (IGP) routing protocols. The resulting labeled paths, called *label switch paths* (LSPs), forward labeled traffic across an MPLS backbone.

LDP also provides the means for label switching routers (LSRs) to request, distribute, and release label prefix binding information to peer routers in a network. LDP enables LSRs to discover potential peers and establish LDP sessions with those peers to exchange label binding information.

For detailed information about MPLS concepts, configuration tasks, and examples, see *MPLS Configuration Guide for Cisco NCS 6000 Series Routers*.

- [backoff](#), on page 3
- [clear mpls ldp msg-counters neighbor](#), on page 4
- [clear mpls ldp neighbor](#), on page 5
- [default-route](#), on page 6
- [discovery hello](#), on page 7
- [discovery instance-tlv disable](#), on page 8
- [discovery targeted-hello](#), on page 9
- [discovery transport-address](#), on page 11
- [entropy-label](#), on page 13
- [explicit-null](#), on page 15
- [graceful-restart \(MPLS LDP\)](#), on page 17
- [session holdtime \(MPLS LDP\)](#), on page 19
- [hw-module 13 feature mpls-over-udp-decap enable](#), on page 20
- [igp auto-config disable](#), on page 21
- [igp sync delay](#), on page 22
- [igp sync delay on-proc-restart](#), on page 23
- [interface \(MPLS LDP\)](#), on page 25
- [l2vpn neighbor all ldp flap](#), on page 27
- [label accept](#), on page 28
- [label advertise](#), on page 30
- [label allocate](#), on page 33
- [log graceful-restart](#), on page 35

- [log neighbor](#), on page 37
- [log nsr](#), on page 38
- [log session-protection](#), on page 39
- [mpls ldp](#), on page 40
- [mpls lsd app-reg-delay disable](#), on page 41
- [neighbor password](#), on page 42
- [neighbor password disable](#), on page 44
- [neighbor targeted](#), on page 45
- [nsr \(MPLS-LDP\)](#), on page 46
- [router-id \(MPLS LDP\)](#), on page 48
- [session protection](#), on page 50
- [show mpls ldp backoff](#), on page 52
- [show mpls ldp bindings](#), on page 54
- [show mpls ldp discovery](#), on page 60
- [show mpls ldp forwarding](#), on page 64
- [show mpls ldp graceful-restart](#), on page 68
- [show mpls ldp igp sync](#), on page 70
- [show mpls ldp interface](#), on page 73
- [show mpls ldp neighbor](#), on page 76
- [show mpls ldp parameters](#), on page 82
- [show mpls ldp statistics msg-counters](#), on page 85
- [show mpls ldp summary](#), on page 87
- [signalling dscp \(LDP\)](#), on page 89
- [snmp-server traps mpls ldp](#), on page 90

# backoff

To configure the parameters for the Label Distribution Protocol (LDP) backoff mechanism, use the **backoff** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**backoff** *initial maximum*

## Syntax Description

*initial* Initial backoff delay, in seconds. Range is 5 to 50331.

*maximum* Maximum backoff delay, in seconds. Range is 5 to 50331.

## Command Default

*initial* : 15

*maximum* : 120

## Command Modes

MPLS LDP configuration

## Command History

Release	Modification
Release 5.0.0	This command was introduced.

## Usage Guidelines

The LDP backoff mechanism prevents two incompatibly configured label switch routers from engaging in an unthrottled sequence of session setup failures. If a session setup attempt fails (due to incompatibility), each Label Switching Router (LSR) delays the next attempt, increasing the delay exponentially with each successive failure until the maximum backoff delay is reached.

## Task ID

### Task ID Operations

mpls-ldp read,  
write

## Examples

The following example shows how to configure the initial backoff delay to 30 seconds and the maximum backoff delay to 240 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# backoff 30 240
```

## Related Commands

Command	Description
show mpls ldp backoff	Displays information about the configured session setup backoff parameters and LDP peers.
show mpls ldp parameters	Displays current LDP parameter settings.

# clear mpls ldp msg-counters neighbor

To clear the Label Distribution Protocol (LDP) message counters, use the **clear mpls ldp msg-counters neighbor** command in XR EXEC mode.

**clear mpls ldp msg-counters neighbor** [*{lsr-id ldp-id}*]

<b>Syntax Description</b>	<i>lsr-id</i>	LSR ID of neighbor in A.B.C.D format.
	<i>ldp-id</i>	LDP ID of neighbor in A.B.C.D: format.
<b>Command Default</b>	No default behavior or values	
<b>Command Modes</b>	XR EXEC mode	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.
<b>Usage Guidelines</b>	Use the <b>clear mpls ldp msg-counters neighbor</b> command to clear the statistics on message counters for a specific neighbor (IP address) or for all neighbors. These message counters count the number of LDP protocol messages sent to and received from LDP neighbors.	
<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write
<b>Examples</b>	The following example shows how to clear message counters for neighbor 10.20.20.20:  RP/0/RP0/CPU0:router# <b>clear mpls ldp msg-counters neighbor 10.20.20.20</b>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">show mpls ldp statistics msg-counters, on page 85</a>	Displays statistics about the type and count of the messages sent and received from neighbors.

# clear mpls ldp neighbor

To force Label Distribution Protocol (LDP) session restart, use the **clear mpls ldp neighbor** command in XR EXEC mode.

```
clear mpls ldp neighbor [{ip-address ldp-id}]
```

<b>Syntax Description</b>	<i>ip-address</i>	(Optional) Neighbor IP address.
---------------------------	-------------------	---------------------------------

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	XR EXEC mode
----------------------	--------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

<b>Usage Guidelines</b>	Use the <b>clear mpls ldp neighbor</b> command to restart a single LDP session or all LDP sessions (without restarting the LDP process itself).
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write

<b>Examples</b>	The following example shows how to force an unconditional LDP session restart:
-----------------	--

```
RP/0/RP0/CPU0:router# clear mpls ldp neighbor 10.20.20.20
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
		<a href="#">show mpls ldp neighbor, on page 76</a>

# default-route

To enable Multiprotocol Label Switching (MPLS) switching for IP default route by allocating and advertising non-null label, use the **default-route** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

## default-route

### Syntax Description

This command has no arguments or keywords.

### Command Default

Allocates null (implicit or explicit) local label for IP default route prefix 0.0.0.0/0.

### Command Modes

MPLS LDP configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

When the IP default route 0.0.0.0/0 is configured on an egress router, it is advertised through Interior Gateway Protocol (IGP) to other routers to enable default IP forwarding. When MPLS LDP is configured and establishing label switch paths (LSPs) for other prefixes, you can emulate default forwarding and switching for MPLS in the same way as IP forwarding. To do so, allocate a non-null local label and advertise this label to its peers.

### Task ID

Task ID	Operations
mpls-ldp	read, write

### Examples

The following example shows how to enable default MPLS switching for default prefix:

```
RP/0/RP0/CPU0:router(config-ldp)# default-route
```

### Related Commands

Command	Description
<a href="#">show mpls ldp bindings, on page 54</a>	Displays LDP label bindings.
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays LDP installed forwarding state.

# discovery hello

To configure the interval between transmission of consecutive Label Distribution Protocol (LDP) discovery hello messages and the holdtime for a discovered LDP neighbor, use the **discovery hello** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**discovery hello** {**holdtime** *seconds* | **interval** *seconds*}

## Syntax Description

**holdtime** Sets the time, in seconds, a discovered LDP neighbor is remembered without receipt of an LDP hello message from the neighbor. Default is 15.

**interval** Sets the time, in seconds, between consecutive hello messages. Default is 5.

*seconds* Time value, in seconds. Range is 1 to 65535 (65535 means infinite).

## Command Default

**holdtime:** 15

**interval:** 5

## Command Modes

MPLS LDP configuration

## Command History

Release	Modification
Release 5.0.0	This command was introduced.

## Usage Guidelines

No specific guidelines impact the use of this command.

## Task ID

Task ID	Operations
mpls-ldp	read, write

## Examples

The following example shows how to configure the link hello holdtime to 30 seconds:

```
RP/0/RP0/CPU0:router(config-ldp)# discovery hello holdtime 30
```

The following example shows how to configure the link hello interval to 10 seconds:

```
RP/0/RP0/CPU0:router(config-ldp)# discovery hello interval 10
```

## Related Commands

Command	Description
<a href="#">#unique_14</a>	Configures targeted-hello messages.

# discovery instance-tlv disable

To disable transmit and receive processing for Type-Length-Value (TLV), use the **discovery instance-tlv disable** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

## discovery instance-tlv disable

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Task ID	Task ID	Operations
	mpls-ldp	read, write

**Examples** The following example shows how to disable transmit and receive processing for TLV:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# discovery instance-tlv disable
```

Related Commands	Command	Description
	<a href="#">#unique_14</a>	Configures targeted-hello messages.



# discovery targeted-hello

To configure the interval between transmission of consecutive Label Distribution Protocol (LDP) discovery targeted-hello messages, the hold time for a discovered targeted LDP neighbor, and to accept targeted hello from peers, use the **discovery targeted-hello** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**discovery targeted-hello address-family** {} {**accept** | [**from** *acl*] | **holdtime** *seconds* | **interval** *seconds*}

Syntax Description	
<b>accept</b>	Accepts targeted hellos from any source.
<b>from</b> <i>acl</i>	(Optional) Accepts targeted hellos from LDP peers as permitted by the access-list.
<b>holdtime</b>	Configures the time a discovered LDP neighbor is remembered without receipt of an LDP hello message from a neighbor.
<b>interval</b>	Displays time between consecutive hello messages.
<i>seconds</i>	Time value, in seconds. Range is 1 to 65535.

Command Default	
<b>accept</b>	Targeted hello messages are not accepted from any source (neighbor).
<b>holdtime</b>	: 90
<b>interval</b>	: 10

Command Modes	
	MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Usage Guidelines	
	LDP supports IPv4 standard access lists only.

Task ID	Task ID	Operations
	mpls-ldp	read, write

**Examples** The following example shows how to configure the targeted-hello holdtime to 45 seconds:

```
RP/0/RP0/CPU0:router(config-ldp)# discovery targeted-hello holdtime 45
```

The following example shows how to configure the targeted-hello interval to 5 seconds:

```
RP/0/RP0/CPU0:router(config-ldp)# discovery targeted-hello interval 5
```

The following example shows how to configure acceptance of targeted hellos from all peers:

```
RP/0/RP0/CPU0:router(config-ldp)# discovery targeted-hello accept
```

The following example shows how to configure acceptance of targeted hello from peers 10.1.1.1 and 10.2.2.2 only:

```
RP/0/RP0/CPU0:router(config)# ipv4 access-list peer_acl_10
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.1.1.1
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.2.2.2
RP/0/RP0/CPU0:router(config-ldp)# discovery targeted-hello accept from peer_acl_10
```

### Related Commands

Command	Description
<a href="#">show mpls ldp discovery, on page 60</a>	Displays LDP discovery information.
<a href="#">show mpls ldp parameters, on page 82</a>	Displays LDP parameters information.

# discovery transport-address

To provide an alternative address for a TCP connection, use the **discovery transport-address** command in MPLS LDP interface configuration mode. To return to the default behavior, use the **no** form of this command.

**discovery transport-address** {*ip-address* | **interface**}

Syntax Description		
	<i>ip-address</i>	IP address to be advertised as the transport address in discovery hello messages.
	<b>interface</b>	Advertises the IP address of the interface as the transport address in discovery hello messages.

**Command Default** LDP advertises its LDP router ID as the transport address in LDP discovery hello messages.

**Command Modes** MPLS LDP interface configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** Establishing an LDP session between two routers requires a session TCP connection. To establish the session TCP connection, each router must know the transport address (IP address) of the other router.

The LDP discovery mechanism provides the means for a router to advertise transport addresses. Transport address is implicit or explicit. Implicit addresses do not appear as part of the contents of the discovery hello messages sent to the peer. If explicit, the advertisement appears as part of the contents of discovery hello messages sent to the peer.

The **discovery transport-address** command modifies the default behavior described above. Using the **interface** keyword, LDP advertises the IP address of the interface in LDP discovery hello messages sent from the interface. Using the *ip-address* argument, LDP advertises the IP address in LDP discovery hello messages sent from the interface.



**Note** When a router has multiple links connecting it to its peer device, the router must advertise the same transport address in the LDP discovery hello messages it sends on all such interfaces.

Task ID	Task ID	Operations
	mpls-ldp	read, write

## Examples

The following example shows how to specify an exiting address (10.10.3.1) as the transport address on an interface POS 0/1/0/0:

```
RP/0/RP0/CPU0:router(config-ldp)# interface POS 0/1/0/0
RP/0/RP0/CPU0:router(config-ldp-if)# address-family ipv4
RP/0/RP0/CPU0:router(config-ldp-if-af)#discovery transport-address 10.10.3.1

RP/0/RP0/CPU0:router# show mpls ldp neighbor

Peer LDP Identifier: 10.44.44.44:0
TCP connection: 10.44.44.44:65520 - 10.10.3.1:646
Graceful Restart: Yes (Reconnect Timeout: 15 sec, Recovery: 180 sec)
State: Oper; Msgs sent/rcvd: 13/9
Up time: 00:00:11
LDP Discovery Sources:
    POS 0/1/0/0
Addresses bound to this peer:
    10.10.3.2      10.44.44.44
```

## Related Commands

Command	Description
<a href="#">show mpls ldp discovery, on page 60</a>	Displays the status of the LDP discovery process.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.

# entropy-label

To enable entropy label LDP signaling on the ingress LSR in an MPLS network, use the **entropy-label** command in MPLS LDP configuration mode.

To remove this configuration, use the **no** form of the command.

**entropy-label** [ **add-el** ]

**no entropy-label** [ **add-el** ]

<b>Syntax Description</b>	<b>add-el</b>	(Optional) Specifies that the entropy label and indicator be added to the MPLS label stack. Enable the <b>add-el</b> keyword on the ingress router.
<b>Command Default</b>	None	
<b>Command Modes</b>	MPLS LDP configuration mode.	
<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.3.2	This command was introduced.
	Release 7.2.2	The <b>add-el</b> option was added as an ingress router configuration.

## Usage Guidelines

Entropy labels are used by the ingress LSR for efficient load balancing of traffic through the MPLS network. An entropy label is inserted on top of the MPLS label stack at the ingress LSR. Entropy labels help the smooth operation of the transit LSRs by relieving them of the task of deep packet inspection.

The **entropy-label** command supports an orderly method for routers to signal entropy label capability (ELC) in the network. When enabled, the Cisco routers wait for the ELC signal from all downstream routers before passing their ELC to the next upstream routers in the chain. This eliminates the confusion that can occur when routers report their status randomly. If just one router in the chain does not support entropy label (EL), then the network will not use EL for load balancing. Random reporting could result in a lot of back and forth signaling before ELC is firmly established in the network.

Enable the **add-el** option on the ingress MPLS LDP router where the entropy label has to be added to the MPLS label stack. On the ingress router, use the **show mpls ldp forwarding** command to verify that the egress router has communicated its entropy label capability.

## Example

The following example shows how you can configure entropy label LDP signaling on transit LSR for load balancing.

```
RP/0/RP0/CPU0:router(config)# cef load-balancing fields mpls entropy-label
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# entropy-label
```

```
RP/0/RP0/CPU0:router(config-ldp)# commit  
RP/0/RP0/CPU0:router(config-ldp)# end
```

This following example shows how to enable MPLS entropy label encapsulation on the ingress router.

```
Router(config)# mpls ldp entropy-label add-el  
Router(config)# commit
```

# explicit-null

To configure a router to advertise explicit null labels instead of implicit null labels, use the **explicit-null** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

```
explicit-null [{to peer-acl | for prefix-acl [to peer-acl]]}
```

<b>Syntax Description</b>	<b>to peer-acl</b>	(Optional) Specifies LDP peers for which explicit-null is advertised instead of implicit-null. Range is 1 to 99.
	<b>for prefix-acl</b>	(Optional) Specifies prefixes for which explicit-null is advertised instead of implicit-null. Range is 1 to 99.

**Command Default** Implicit null is advertised as default null label for routes, such as directly connected routes.

**Command Modes** MPLS LDP configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

**Usage Guidelines** Normally, LDP advertises an implicit null label for directly connected routes. The implicit null label causes the previous hop router to perform next to last router hop popping.

The **explicit-null** command advertises the explicit-null labels in place of implicit null labels for directly connected prefixes.

LDP supports IPv4 standard access lists only.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write

## Examples

The following command shows how to advertise explicit null for all directly connected routes to all LDP peers:

```
RP/0/RP0/CPU0:router(config-ldp)# explicit-null
```

The following command sequence shows how to advertise explicit-null for directly connected route 192.168.0.0 to all LDP peers and implicit-null for all other directly connected routes:

```
RP/0/RP0/CPU0:router(config)# ipv4 access-list pfx_acl_192_168
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 192.168.0.0
RP/0/RP0/CPU0:router(config-ldp)# explicit-null for pfx_acl_192_168
```

The following command sequence shows how to send explicit-null for all directly connected routes to peers 10.1.1.1 and 10.2.2.2 and implicit-null to all other peers:

```
RP/0/RP0/CPU0:router(config)# ipv4 access-list peer_acl_10
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.1.1.1
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.2.2.2

RP/0/RP0/CPU0:router(config-ldp)# explicit-null to peer_acl_10
```

The following command shows how to advertise explicit-null for prefix 192.168.0.0 to peers 10.1.1.1 and 10.2.2.2 and advertise implicit-null for all other applicable routes to all other peers:

```
RP/0/RP0/CPU0:router(config-ldp)# explicit-null for pfx_acl_192_168 to peer_acl_10
```

#### Related Commands

Command	Description
<a href="#">show mpls ldp bindings, on page 54</a>	Displays the contents of LDP LIB.
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays the contents of the LDP forwarding database.
<a href="#">show mpls ldp parameters, on page 82</a>	Displays current LDP parameter settings.



## graceful-restart (MPLS LDP)

To configure graceful restart, use the **graceful-restart** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**graceful-restart** [{**reconnect-timeout** *seconds* | **forwarding-state-holdtime** *seconds*}]

Syntax Description		
	<b>reconnect-timeout</b> <i>seconds</i>	(Optional) Configures the time that the local LDP sends to its graceful restartable peer, indicating how long its neighbor should wait for reconnection in the event of a LDP session failure, in seconds. Range is 60 to 1800.
	<b>forwarding-state-holdtime</b> <i>seconds</i>	(Optional) Configures the time the local forwarding state is preserved (without being reclaimed) after the local LDP control plane restarts, in seconds. Range is 60 to 1800.

**Command Default** By default, graceful restart is disabled.

**reconnect-timeout:** 120

**forwarding-state-holdtime:** 180

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** Use the LDP graceful restart capability to achieve nonstop forwarding (NSF) during an LDP control plane communication failure or restart. To configure graceful restart between two peers, enable LDP graceful restart on both label switch routers (LSRs).

When an LDP graceful restart session is established and there is control plane failure, the peer LSR starts graceful restart procedures, initially keeps the forwarding state information pertaining to the restarting peer, and marks this state as stale. If the restarting peer does not reconnect within the reconnect timeout, the stale forwarding state is removed. If the restarting peer reconnects within the reconnect time period, it is provided recovery time to resynchronize with its peer. After this time, any unsynchronized state is removed.

The value of the forwarding state hold time keeps the forwarding plane state associated with the LDP control-plane in case of a control-plane restart or failure. If the control plane fails, the forwarding plane retains the LDP forwarding state for twice the forwarding state hold time. The value of the forwarding state hold time is also used to start the local LDP forwarding state hold timer after the LDP control plane restarts. When the LDP graceful restart sessions are renegotiated with its peers, the restarting LSR sends the remaining value of this timer as the recovery time to its peers. Upon local LDP restart with graceful restart enabled, LDP does not replay forwarding updates to MPLS forwarding until the forwarding state hold timer expires.



**Note** In the presence of a peer relationship, any change to the LDP graceful restart configuration will restart LDP sessions. If LDP configuration changes from nongraceful restart to graceful restart, all the sessions are restarted. Only graceful restart sessions are restarted upon graceful restart to nongraceful restart configuration changes.

**Task ID****Task ID Operations**

mpls-ldp read,  
write

**Examples**

The following example shows how to configure an existing session for graceful restart:

```
RP/0/RP0/CPU0:router(config-ldp)# graceful-restart

RP/0/RP0/CPU0:router:Apr  3 10:56:05.392 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
172.16.0.1:0, DOWN
RP/0/RP0/CPU0:router:Apr  3 10:56:05.392 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
192.168.0.1:0, DOWN
RP/0/RP0/CPU0:router:Apr  3 10:56:09.525 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
192.168.0.1:0, UP
RP/0/RP0/CPU0:router:Apr  3 10:56:11.114 : mpls_ldp[336]: %ROUTING-LDP-5-NBR_CHANGE : Nbr
172.16.0.1:0, UP

RP/0/RP0/CPU0:router# show mpls ldp neighbor brief

Peer                GR Up Time                Discovery Address
-----
192.168.0.1:0      Y 00:01:04                3          8
172.16.0.1:0      N 00:01:02                2          5

RP/0/RP0/CPU0:router# show mpls ldp graceful-restart

Forwarding State Hold timer : Not Running
GR Neighbors                : 1

Neighbor ID    Up    Connect Count    Liveness Timer    Recovery Timer
-----
192.168.0.1   Y      1                -                  -
```

**Related Commands**

Command	Description
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays the contents of the LDP forwarding database.
<a href="#">show mpls ldp graceful-restart, on page 68</a>	Displays information related to graceful restart.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.
<a href="#">show mpls ldp parameters, on page 82</a>	Displays current LDP parameter settings.
<a href="#">show mpls ldp summary, on page 87</a>	Displays summarized information regarding the LDP process.

## session holdtime (MPLS LDP)

To change the time for which an Label Distribution Protocol (LDP) session is maintained in the absence of LDP messages from the session peer, use the **session holdtime** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**session holdtime** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Time, in seconds, that an LDP session is maintained in the absence of LDP messages from the session peer. Range is 15 to 65535.				
<b>Command Default</b>	<i>seconds</i> : 180				
<b>Command Modes</b>	MPLS LDP configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td>mpls-ldp</td> <td>read, write</td> </tr> </tbody> </table>	Task ID	Operations	mpls-ldp	read, write
Task ID	Operations				
mpls-ldp	read, write				

### Examples

The following example shows how to change the hold time of LDP sessions to 30 seconds:

```
RP/0/RP0/CPU0:router(config-ldp)# session holdtime 30
```

Related Commands	Command	Description
	<a href="#">show mpls ldp parameters, on page 82</a>	Displays current LDP parameter settings.

## hw-module l3 feature mpls-over-udp-decap enable

To enable UDP decapsulation of UDP-encapsulated MPLS traffic on the ASR 9000 Series router, configure the **hw-module l3 feature mpls-over-udp-decap enable** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

### hw-module l3 feature mpls-over-udp-decap enable

This command has no keywords or arguments.

<b>Command Default</b>	UDP decapsulation function is disabled.
------------------------	---

<b>Command Modes</b>	XR Config mode
----------------------	----------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 7.0.1	This command was introduced.

<b>Usage Guidelines</b>	When you enable this command on a WAN edge ASR 9000 Series router, the UDP header is removed from UDP-encapsulated MPLS traffic. Based on the MPLS label, the traffic is forwarded towards the destination. If you don't enable this function, the WAN edge router drops the UDP-encapsulated MPLS traffic it receives.
-------------------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write

<b>Examples</b>	The following example shows how to configure UDP decapsulation function:
-----------------	--

```
Router# configure
Router(config)# hw-module l3 feature mpls-over-udp-decap enable
Router(config)# commit
```

# igp auto-config disable

To disable Label Distribution Protocol (LDP) auto-configuration, use the **igp auto-config disable** command in MPLS LDP interface configuration mode. To return to the default behavior, use the **no** form of this command.

## igp auto-config disable

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP interface configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** IGP auto-configuration can be enabled on ISIS and OSPF. Configuration details are described in .

Task ID	Task ID	Operations
	mpls-ldp	read, write

**Examples** The following example shows how to disable LDP auto-configuration on POS 0/1/0/3:

```
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# interface pos 0/1/0/3
RP/0/RP0/CPU0:router(config-ldp-if)# igp auto-config disable
```

Related Commands	Command	Description
	<a href="#">show mpls ldp interface, on page 73</a>	Displays information about LDP-enabled interfaces.

## igp sync delay

To enable Label Distribution Protocol (LDP) Interior Gateway Protocol (IGP) sync delay timer feature, use the **igp sync delay** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**igp sync delay** *seconds*

### Syntax Description

*seconds* Time, in seconds, that declaration of LDP sync state being up is delayed after session establishment upon link coming up. Range is 5 to 300.

### Command Default

LDP does not delay declaration of sync up and notifies IGP as soon as sync up conditions are met for a link.

### Command Modes

MPLS LDP configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

- By default, LDP declares LDP sync up as soon as all the requisite conditions are met, namely:
  - LDP session is up.
  - LDP has sent all its label bindings to at least one peer.
  - LDP has received at least one label binding from a peer.

This minimizes traffic loss on link up but can still lead to substantial traffic loss under certain circumstances (for example, when interoperating with an LSR with ordered mode operation). It may be necessary to delay declaration of sync up after the session comes up by configuring a timeout period.

- When the graceful-restart event is configured, the IGP sync delay timer does not take effect.

### Task ID

Task ID	Operations
mpls-ldp	read, write

### Examples

The following example shows how to configure LDP to delay declaration of sync-up to 30 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# igp sync delay 30
```

### Related Commands

Command	Description
<a href="#">show mpls ldp igp sync, on page 70</a>	Displays LDP IGP sync information for link(s).

# igp sync delay on-proc-restart

To delay the declaration of synchronization events to the Interior Gateway Protocol (IGP) when the label distribution protocol (LDP) fails or restarts, use the **igp sync delay on-proc restart** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**igp sync delay on-proc restart** *seconds*

<b>Syntax Description</b>	<i>seconds</i> Time, in seconds, duration of process-level delay for synchronization events when the LDP fails or restarts. Range is from 60 to 600.
---------------------------	--

<b>Command Default</b>	This command is disabled by default.
------------------------	--------------------------------------

<b>Command Modes</b>	MPLS LDP configuration
----------------------	------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

<b>Usage Guidelines</b>	The <b>igp sync delay on-proc restart</b> command enables a process-level delay for synchronization events when the LDP fails or restarts. This delay defers the sending of sync-up events to the IGP until most or all the LDP sessions converge and also allows the LDP to stabilize. This allows the LDP process failure to be less stressful because IGP's receive all the sync-up events in bulk. This means that the IGP is required to run the shortest path first (SPF) and link-state advertisements (LSAs) only one time with an overall view of the sync-up events.
-------------------------	--

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write

## Examples

The following example shows how to configure LDP to delay the declaration of synchronization events to IGP by 60 seconds:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# igp sync delay on-proc restart 60
```

The following example shows the status following execution of the command:

```
RP/0/RP0/CPU0:router# show mpls ldp igp sync

Process Restart Sync Delay: 60 sec, Gloal timer running (15 sec remaining)
GigabitEthernet0/3/0/2:
Sync status: Deferred
...
```

When the timer is not running, the output displays the following:

**igp sync delay on-proc-restart**

Process Restart Sync Delay: 60 sec, Global timer not running

**Related Commands**

Command	Description
<a href="#">show mpls ldp igp sync, on page 70</a>	Displays LDP IGP sync information for link(s).



## interface (MPLS LDP)

To configure or enable Multiprotocol Label Switching (MPLS) Label Distribution Protocol (LDP) on an interface, use the **interface** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

```
interface type interface-path-id
```

Syntax Description	type	Interface type. For more information, use the question mark (?) online help function.
	interface-path-id	Physical interface or a virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** When you configure LDP on an interface, the LDP process begins neighbor discovery, sending link hello messages on the interface. This can result in a session setup with discovered neighbors. When LDP is enabled on tunnel-te interfaces, targeted discovery procedures apply.

LDP interface configuration supports forward reference; accordingly, it is possible to configure a nonexistent interface under LDP.



**Note** You cannot enable LDP on loopback interfaces.

MPLS LDP is supported over Generic Route Encapsulation (GRE) tunnels by configuring the tunnel-ip interface. LDP establishes a link session (as opposed to a targeted LDP session) over the GRE tunnel.

**Task ID****Task ID Operations**


---

```
mpls-ldp read,
write
```

---

**Examples**

The following example shows how to configure LDP on POS interface 0/1/0/0:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# mpls ldp
RP/0/RP0/CPU0:router (config-ldp)# interface POS 0/1/0/0
RP/0/RP0/CPU0:router (config-ldp-if)#
```

The following example shows how to configure LDP on an MPLS TE tunnel:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router (config)# mpls ldp
RP/0/RP0/CPU0:router (config-ldp)# interface tunnel-te 123
RP/0/RP0/CPU0:router (config-ldp-if)#
```

**Related Commands**

Command	Description
<a href="#">show mpls ldp parameters, on page 82</a>	Displays current LDP parameter settings.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays LDP neighbor session parameters.

## l2vpn neighbor all ldp flap

To flap the LDP sessions in order to enable interoperability with the peer router which does not support label request, use the **l2vpn neighbor all ldp flap** command in XR Config mode.

To return to the default behavior, use the **no** form of this command.

### l2vpn neighbor all ldp flap

**Syntax Description** This command has no arguments or keywords.

**Command Default** None

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 4.3.4	This command was introduced.

**Usage Guidelines** Configuring the **l2vpn neighbor all ldp flap** command flaps all the LDP sessions when a route processor fail over (RPFO) occurs.

Task ID	Task ID	Operation
	l2vpn	read, write

The following example shows how to flap the LDP sessions:

```
RP/0/RP0/CPU0:router#config
RP/0/RP0/CPU0:router#l2vpn neighbor all ldp flap
RP/0/RP0/CPU0:router#commit
```

# label accept

To control the receipt of labels (remote bindings) for a set of prefixes from a peer, use the **label accept** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**label accept for** *prefix-acl* **from** *ip-address*

<b>Syntax Description</b>	<b>for</b> <i>prefix-acl</i>	Accepts and retains remote bindings for prefixes that are permitted by the prefix access list <i>prefix-acl</i> argument.
	<b>from</b> <i>ip-address</i>	Displays the peer IP address.

**Command Default** LDP accepts and retains label bindings for all prefixes from all peers.

**Command Modes** MPLS LDP configuration

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

**Usage Guidelines** By default, LDP accepts labels (as remote bindings) for all prefixes from all its peers. To save resources (such as memory) configure the access list to specify label and binding acceptance for a set of prefixes from a peer.

If the inbound label filtering policy changes such that it now allows previously denied prefixes from a peer, you must reset the LDP session with the peer using the **clear mpls ldp neighbor** command.

LDP supports IPv4 standard access lists only.



**Note** Label acceptance control is also referred to as LDP inbound label filtering.

<b>Task ID</b>	<b>Task ID</b> <b>Operations</b>
	mpls-ldp read, write

## Examples

The following example shows how to configure inbound label filtering policy. In this example, an LSR is configured to accept and retain label bindings for prefixes 192.168.1.1 (*pfx\_acl\_1*) from peer 10.0.0.1, prefix 192.168.2.2 (*pfx\_acl\_2*) from peer 172.16.0.1, and prefixes 192.168.1.1, 192.168.2.2, 192.168.3.3 (*pfx\_acl\_3*) from peer 209.165.201.1:

```
RP/0/RP0/CPU0:router(config-ldp)# label accept
RP/0/RP0/CPU0:router(config-ldp-lbl-acpt)# for pfx_acl_1 from 10.0.0.1
RP/0/RP0/CPU0:router(config-ldp-lbl-acpt)# for pfx_acl_2 from 172.16.0.1
RP/0/RP0/CPU0:router(config-ldp-lbl-acpt)# for pfx_acl_3 from 209.165.201.1
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">label advertise, on page 30</a>	Controls advertisement of LDP local label bindings (outbound label filtering).
<a href="#">show mpls ldp bindings, on page 54</a>	Displays LDP binding information.

# label advertise

To control the advertisement of local labels, use the **label advertise** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**label advertise** [{**disable** | **for** *prefix-acl* [**to** *peer-acl*] | **interface** *type interface-path-id*}]

Syntax Description		
<b>disable</b>	(Optional)	Disables label advertisement to all peers for all prefixes.
<b>for</b> <i>prefix-acl</i>	(Optional)	Specifies prefix destinations for which labels will be advertised.
<b>to</b> <i>peer-acl</i>	(Optional)	Specifies which LDP neighbors will receive label advertisements.
<b>interface</b>	(Optional)	Specifies an interface for label allocation and advertisement of its interface IP address.
<i>type</i>		Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		Physical interface or a virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.

**Command Default** LDP advertises labels for all known prefixes to all peers. LDP does not advertise labels for local interfaces addresses other than Loopback interfaces.

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **label advertise** command determines how the label switch router (LSR) advertises local labels. The following rules describe the effects of running multiple commands:

- Every command has a prefix-acl or peer-acl pair associated with it, as follows:
  - In the absence of the **for** or **to** keywords, the access list pair is (none, none).
  - When using the **for** keyword without the **to** keyword, the access list is (prefix-acl, none).
- A prefix can have a maximum of one (prefix-acl, peer-acl) pair, as follows:
  - A (prefix-acl, peer-acl) pair applies to a prefix only if the prefix-acl matches the prefix. A match occurs if the prefix-acl permits the prefix.
  - If more than one (prefix-acl, peer-acl) pair from multiple **label advertise** commands matches a prefix, the (prefix-acl, peer-acl) pair in the first command applies to the prefix. The order in which

the **label advertise** commands are processed is sorted based on the ACL names in a MIB-lexicographical way (shorter ACL name length will be processed first, if two ACLs are of equal length, then dictionary ordering is used).

- When an LSR is ready to advertise a label for a prefix, the LSR determines whether a (prefix-acl, peer-acl) pair applies to the prefix.
  - If none applies, and if the **disable** keyword has been configured for the command, the label for the prefix is not advertised to any peer; otherwise, the label is advertised to all peers.
  - If a (prefix-acl, peer-acl) pair applies to the prefix, and if the prefix-acl denies the prefix, the label is not advertised to the peers defined in the peer-acl. Nevertheless, the prefix may be matched in subsequent (prefix-acl, peer-acl) entries and advertised to other peers.
  - If (prefix-acl, peer-acl) pair applies to the prefix and if the prefix-acl denies the prefix, the label is not advertised to peers defined in the peer-acl. Nevertheless, the prefix may be matched in subsequent (prefix-acl, peer-acl) entries and advertised to other peers.
  - If the prefix-acl permits the prefix and there is a peer-acl, the label is advertised to all peers permitted by the peer-acl.

Normally, LDP advertises labels for non-BGP routes present in the routing table. Additionally, LDP advertises labels from /32 IP addresses on Loopback interfaces and does not advertise /32 addresses for other non-Loopback interfaces. To control advertisement of labels for /32 IP addresses on these interfaces, use the **label advertise interface** command.

LDP supports IPv4 standard access lists only.




---

**Note** Label advertisement control is also referred to as LDP outbound label filtering.

---

## Task ID

### Task ID Operations

---

mpls-ldp read,  
write

---

## Examples

The following example shows how to disable advertisement of all locally assigned labels to all peers:

```
RP/0/RP0/CPU0:router(config-ldp)# label advertise
RP/0/RP0/CPU0:router(config-ldp-lbl-adv)# disable
```

The following example shows how to send labels only for prefixes 10.1.1.0 and 20.1.1.0 to all peers:

```
RP/0/RP0/CPU0:router(config)# ipv4 access-list pfx_acl_1
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.1.1.0
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 20.1.1.0

RP/0/RP0/CPU0:router(config-ldp)# label advertise
RP/0/RP0/CPU0:router(config-ldp-lbl-adv)# disable
RP/0/RP0/CPU0:router(config-ldp-lbl-adv)# for pfx_acl_1
```

The following example shows how to send labels for prefix 10.0.0.0 to peers 10.1.1.1 and 10.2.2.2, labels for prefix 20.0.0.0 to peer 20.1.1.1, and labels for all other prefixes to all other peers:

```
RP/0/RP0/CPU0:router(config)# ipv4 access-list pfx_acl_10
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.0.0.0

RP/0/RP0/CPU0:router(config)# ipv4 access-list pfx_acl_20
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 20.0.0.0

RP/0/RP0/CPU0:router(config)# ipv4 access-list peer_acl_10
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.1.1.1
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 10.2.2.2

RP/0/RP0/CPU0:router(config)# ipv4 access-list peer_acl_20
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 20.1.1.1

RP/0/RP0/CPU0:router(config-ldp)# label advertise
RP/0/RP0/CPU0:router(config-ldp-lbl-advt)# for pfx_acl_10 to peer_acl_10
RP/0/RP0/CPU0:router(config-ldp-lbl-advt)# for pfx_acl_20 to peer_acl_20
```



**Note** To advertise pfx\_acl\_10 to peer\_acl\_10 and pfx\_acl\_20 to peer\_acl\_20 and disable all other advertisements to all other peers, include the **disable** keyword with the **label advertise** command.

The following example shows how to use the **interface** keyword to advertise /32 IP address for POS 0/1/0/0:

```
RP/0/RP0/CPU0:router(config-ldp)# label advertise
RP/0/RP0/CPU0:router(config-ldp-lbl-advt)# interface POS 0/1/0/0
```

#### Related Commands

Command	Description
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.
<a href="#">show mpls ldp bindings, on page 54</a>	Displays information about LDP label bindings.



# label allocate

To control allocation of local label only for a set of prefixes, use the **label allocate** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**label allocate for** {*prefix-acl* | **host-routes**}

## Syntax Description

**for** Specifies set of prefixes for which local label needs to be allocated.

*prefix-acl* IP access-list name or number. Range is from 1 to 99.

**host-routes** Allocates the label for host routes only.

## Command Default

LDP allocates local label for all learned routes (prefixes).

## Command Modes

MPLS LDP configuration

## Command History

Release	Modification
Release 5.0.0	This command was introduced.

## Usage Guidelines

Local label allocation control lets you override the default label allocation policy and provides many benefits, including reduced memory usage and fewer forwarding and network updates.

By default, LDP allocates local labels for all learned routes. There are times when you may want to limit label allocation for a given set of prefixes; for example, when using LDP in the core network to provide MPLS transport from one edge to another edge. In such cases, it is necessary to set up label switch packets (LSPs) for Loopback /32 addresses for provider edge (PE) routers (rendering it unnecessary to allocate and advertise local labels for other Interior Gateway Protocol (IGP) prefixes).

LDP supports IPv4 standard access lists only.

## Task ID

Task ID	Operations
mpls-ldp	read, write

## Examples

The following example shows how to configure LDP to limit allocation of local labels to prefixes 192.168.1.1, 192.168.2.2, and 192.168.3.3 only:

```
RP/0/RP0/CPU0:router(config)# ipv4 access-list pfx_acl_1
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 192.168.1.1
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 192.168.2.2
RP/0/RP0/CPU0:router(config-ipv4-acl)# permit 192.168.3.3

RP/0/RP0/CPU0:router(config-ldp)# label allocate for pfx_acl_1
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">show mpls ldp bindings, on page 54</a>	Displays information about LDP label bindings.
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays the contents of the LDP forwarding database.

# log graceful-restart

To set up notification describing graceful-restart (GR) session events, use the **log graceful-restart** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

## log graceful-restart

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** Use the **log graceful-restart** command to receive a syslog/console message when a graceful restart-related session event occurs, including LDP graceful restart session disconnection, reconnection, and timeout.



**Note** A logging message is issued upon graceful restart session events.

Task ID	Task ID	Operations
	mpls-ldp	read, write

## Examples

The following example shows how to enable logging messages for graceful restart session events:

```
RP/0/RP0/CPU0:router(config-ldp)# log graceful-restart
```

The following sample output shows the logging events that can be displayed on the console:

```
RP/0/RP0/CPU0:router: mpls_ldp[340]: %ROUTING-LDP-5-GR : GR session 4.4.4.4:0 (instance 1)
disconnected
RP/0/RP0/CPU0:router: mpls_ldp[340]: %ROUTING-LDP-5-GR : GR session 4.4.4.4:0 (instance 2)
reconnected
RP/0/RP0/CPU0:router: mpls_ldp[340]: %ROUTING-LDP-5-GR : GR session 5.5.5.5:0 (instance 3)
timed out
RP/0/RP0/CPU0:router: mpls_ldp[336]: %ROUTING-LDP-5-GR_RESTART_COMPLETE : GR forwarding
state hold timer has expired
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.
<a href="#">show mpls ldp graceful-restart, on page 68</a>	Displays information about LDP GR sessions.

# log neighbor

To enable logging of notices describing session changes, use the **log neighbor** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

## log neighbor

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** Use the **log neighbor** command to receive a syslog or console message when a neighbor goes up or down.

Task ID	Task ID	Operations
	mpls-ldp	read, write

## Examples

The following example shows how to enable logging messages for neighbor session up and down events:

```
RP/0/RP0/CPU0:router(config-ldp)# log neighbor
```



**Note** A logging message is issued when an LDP session state changes from up to down (and down to up).

The following shows sample output of logging events that can be displayed on the console:

```
RP/0/RP0/CPU0:router:10 21:11:32.111:mpls_ldp[113]:%LDP-5-NBR_CHANGE: Nbr 10.44.44.44:0, DOWN
```

## Related Commands

Command	Description
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.

# log nsr

To enable logging of nonstop routing (NSR) synchronization events, use the **log nsr** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

## log nsr

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Task ID	Task ID	Operations
	mpls-ldp	read, write

## Examples

The following example shows how to enable logging of NSR synchronization events:

```
RP/0/RP0/CPU0:router(config-ldp)# log nsr
```

# log session-protection

To enable logging of notices describing LDP session protection events, use the **log session-protection** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

## log session-protection

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** Use the **log session-protection** command to receive a syslog or console message when LDP session protection event occurs. These events include LDP session protection initiation, recovery, and timeout.

Task ID	Task ID	Operations
	mpls-ldp	read, write

## Examples

The following example shows how to enable logging messages for session protection events:

```
RP/0/RP0/CPU0:router(config-ldp)# log session-protection
```



**Note** Logging messages are issued when session protection events occur.

The following sample output shows the logging events that are displayed on the console:

```
RP/0/RP0/CPU0:router:Apr 21 12:15:01.742: mpls_ldp[315]:%ROUTING-LDP-5-SESSION_PROTECTION:
Session hold up initiated for peer 4.4.4.4:0

RP/0/RP0/CPU0:router:Apr 21 12:18:04.987: mpls_ldp[315]:%ROUTING-LDP-5-SESSION_PROTECTION:
Session recovery succeeded for peer 4.4.4.4:0
```

## Related Commands

Command	Description
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.

# mpls ldp

To enter MPLS Label Distribution Protocol (LDP) configuration mode, use the **mpls ldp** command in XR Config mode.

## mpls ldp

**Syntax Description** This command has no arguments or keywords.

**Command Default** No default behavior or values

**Command Modes** XR Config mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Task ID	Task ID	Operations
	mpls-ldp	read, write

## Examples

The following example shows how to MPLS LDP configuration mode:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)
```



## mpls lsd app-reg-delay disable

Allows LDP to allocate labels with out any delay if segment routing will not be configured. By default, MPLS Label Switching Database (LSD) waits for segment routing enabled IGPs to allocate labels first because of their global significance. LSD allows LDP to allocate labels only after segment routing enabled IGPs complete label allocation. If segment routing will not be configured, this leads to additional delay and may cause traffic drops after router reload. This command avoids the delay in label allocation.

### **mpls lsd app-reg-delay disable**

This command has no arguments or keywords.

### **Command Default:**

No default behavior or values

### **Command Modes:**

XR Config mode

Release	Modification
Release 5.3.3	This command was introduced.

### **Usage Guidelines**

No specific guidelines impact the use of this command.

Task ID	Operations
mpls-ldp	read, write

The following example shows how to configure **mpls lsd app-reg-delay disable** command:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mpls lsd app-reg-delay disable
```

# neighbor password

To configure password authentication using the TCP Message Digest 5 (MD5) option for a neighbor, use the **neighbor password** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

```
[vrf vrf-name] neighbor ldp-id password {clear | disable | encrypted} password
no [vrf vrf-name] neighbor ldp-id password
```

Syntax Description		
	<i>ldp-id</i>	LDP ID of neighbor in A.B.C.D:0 format.
	<b>clear</b>	Clears the password for the encryption parameter to specify that an unencrypted password will follow.
	<b>encrypted</b>	Specifies that an encrypted password will follow.
	<i>password</i>	(Clear text) Encrypted or unencrypted password string.

**Command Default** LDP sessions are negotiated without any password (and MD5).

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** This security feature is enabled per neighbor, so that a session establishment attempt is allowed only when a password match has been configured. This option must be configured so that both peer passwords match.

To override the default password for a specific neighbor, use the **neighbor ldp-id password** command, where the *ldp-id* argument is the LDP ID of the neighbor.



**Note** The global default password must be configured before being able to override the default password for a specific neighbor.

Task ID	Task ID	Operations
	mpls-ldp	read, write

---

**Examples**

The following example shows how to configure the password *abc* for neighbor 10.20.20.20:

```
RP/0/RP0/CPU0:router(config-ldp)# neighbor 10.20.20.20:0 password clear abc
```

---

**Related Commands**

Command	Description
<a href="#">neighbor targeted, on page 45</a>	Configures transmission of targeted hellos towards a neighbor.

# neighbor password disable

To override an individual neighbor which requires no password, use the **neighbor password disable** command in MPLS LDP configuration mode.

**neighbor** *IP-address* **password disable**

<b>Syntax Description</b>	<i>IP-address</i> Neighbor IP address.
---------------------------	--

<b>Command Default</b>	LDP sessions are negotiated without any password (and MD5).
------------------------	---

<b>Command Modes</b>	MPLS LDP configuration
----------------------	------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

<b>Usage Guidelines</b>	The system uses the global password to compute each neighbor's effective password and overrides the global password with the individual neighbor password, if configured. The session remains stable if you shift from an individual neighbor password to an equal global password. However, if the effective password changes during configuration, the session might be rendered unstable.
-------------------------	--



<b>Note</b>	You must configure the password for an individual neighbor using the neighbor's LSR ID.
-------------	---

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write

<b>Examples</b>	The following example shows how to override the individual password <i>abc</i> , for the neighbor:
-----------------	--

```
RP/0/RP0/CPU0:router (config-ldp) # neighbor 10.20.20.20 password disable abc
RP/0/RP0/CPU0:router (config-ldp) #
```

# neighbor targeted

To configure transmission of targeted hellos toward a neighbor for setting up an LDP session, use the **neighbor targeted** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

```
address-family {} neighbor IP address targeted
no address-family {} neighbor IP address targeted
```

<b>Syntax Description</b>	<i>IP address</i> Neighbor IP address.
---------------------------	--

<b>Command Default</b>	No default behavior or values
------------------------	-------------------------------

<b>Command Modes</b>	MPLS LDP configuration
----------------------	------------------------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read, write

## Examples

The following example shows how to set up a targeted discovery session for neighbor 200.1.1.1:

```
RP/0//CPU0:router(config-ldp)# neighbor 200.1.1.1 targeted
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<a href="#">neighbor password, on page 42</a>	Configures password authentication using MD5.
	<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.
	<a href="#">show mpls ldp discovery, on page 60</a>	Displays information about LDP discovery sources.

## nsr (MPLS-LDP)

To configure nonstop routing for LDP protocols in the event of a disruption in service, use the **nsr** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**nsr**  
**no nsr**

**Syntax Description** This command has no arguments or keywords.

**Command Default** By default, MPLS LDP NSR is disabled.

**Command Modes** MPLS LDP configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** A disruption in service may include any of the following events:

- LDP process restart
- In-service system upgrade (ISSU)
- Minimum disruption restart (MDR)

Enabling NSR causes events such as these to be invisible to the routing peers and provide minimal service disruption.



**Note** The LDP Process restart is supported by NSR only if the NSR process-failures switchover is configured, else the process restart causes the session to be unstable.

Task ID	Task ID Operations
	mpls-ldp read, write

### Examples

The following example shows how to enable MPLS LDP NSR:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls ldp
RP/0/RP0/CPU0:router(config-ldp)# nsr
```

**Related Commands**

<b>Command</b>	<b>Description</b>
<b>nsr process-failures switchover</b>	Configures switchover as a recovery action for active instances to switch over to a standby RP or a DRP, to maintain NSR. For more information, see <i>IP Addresses and Services Command Reference</i> .
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays standby node specific information.

## router-id (MPLS LDP)

To specify an IPv4 address to act as the router ID, use the **router-id** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

```
router-id lsr-id
no router-id
```

### Syntax Description

*lsr-id*

LSR ID in A.B.C.D format.

### Command Default

LDP uses router ID as determined by global router ID agent, IP Address Repository Manager (IP ARM).

### Command Modes

MPLS LDP configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

LDP uses the router ID from different sources in the following order:

1. Configured LDP router ID.
2. Global router ID (if configured).
3. Calculated (computed) using the primary IPv4 address of the highest numbered configured loopback address. We recommend configuring at least one loopback address.



**Note** We recommend that you configure an IP address for the LDP router-id to avoid unnecessary session flaps.

### Task ID

#### Task ID Operations

mpls-ldp read,  
write

### Examples

The following example shows how to specify an LSR ID as the router ID:

```
RP/0/RP0/CPU0:router (config-ldp) #router-id 10.0.0.1
```

### Related Commands

Command	Description
<a href="#">show mpls ldp discovery, on page 60</a>	Displays the status of the LDP discovery process.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.



Command	Description
<a href="#">show mpls ldp parameters, on page 82</a>	Displays current LDP parameter settings.

## session protection

To enable the LDP session protection feature for keeping LDP peer session up by means of targeted discovery following the loss of link discovery with a peer, use the **session protection** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

```
session protection [{duration seconds | infinite}] [for peer-acl]
no session protection
```

<b>Syntax Description</b>	<p><b>duration</b> <i>seconds</i> (Optional) Specifies the protection duration, that is, the number of seconds that targeted discovery should continue following the loss of link discovery to a neighbor. Range is 30 to 2147483.</p> <p><b>infinite</b> (Optional) Specifies session protection to last forever after loss of link discovery.</p> <p><b>for</b> <i>peer-acl</i> (Optional) Specifies set of LDP peers for which session protection is to be enabled.</p>				
<b>Command Default</b>	By default, session protection is disabled. When enabled without peer-acl and duration, session protection is provided for all LDP peers and continues for 24 hours after a link discovery loss.				
<b>Command Modes</b>	MPLS LDP configuration				
<b>Command History</b>	<table border="1"> <thead> <tr> <th>Release</th> <th>Modification</th> </tr> </thead> <tbody> <tr> <td>Release 5.0.0</td> <td>This command was introduced.</td> </tr> </tbody> </table>	Release	Modification	Release 5.0.0	This command was introduced.
Release	Modification				
Release 5.0.0	This command was introduced.				
<b>Usage Guidelines</b>	<p>LDP session protection feature allows you to enable the automatic setup of targeted hello adjacencies with all or a set of peers and specify the duration for which session needs to be maintained using targeted hellos after loss of link discovery.</p> <p>LDP supports only IPv4 standard access lists.</p>				
<b>Task ID</b>	<table border="1"> <thead> <tr> <th>Task ID</th> <th>Operations</th> </tr> </thead> <tbody> <tr> <td></td> <td>mpls-ldp read, write</td> </tr> </tbody> </table>	Task ID	Operations		mpls-ldp read, write
Task ID	Operations				
	mpls-ldp read, write				
<b>Examples</b>	<p>The following example shows how to enable session protection for all discovered peers with unlimited duration to maintain the session after link discovery loss:</p> <pre>RP/0/RP0/CPU0:router(config-ldp)# session protection</pre> <p>The following example shows how to enable session protection for a set of peers (as permitted by a peer ACL) with duration of 30 seconds to maintain the session after link discovery loss:</p> <pre>RP/0/RP0/CPU0:router(config-ldp)# session protection for peer_acl duration 30</pre>				

**Related Commands**

Command	Description
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.

# show mpls ldp backoff

To display information about the configured session setup backoff parameters and any potential LDP peers with which session setup attempts are being throttled, use the **show mpls ldp backoff** command in XR EXEC mode.

```
show mpls ldp backoff [{location node-id | standby}]
```

## Syntax Description

**location node-id** (Optional) Displays location information for the specified node ID.

**standby** (Optional) Displays standby-node-specific information.

## Command Default

No default behavior or values

## Command Modes

XR EXEC mode

## Command History

Release	Modification
Release 5.0.0	This command was introduced.

## Usage Guidelines

You must enable the MPLS LDP application to use the **show mpls ldp backoff** command.

## Task ID

### Task ID Operations

mpls-ldp read

## Examples

The following shows a sample output from the **show mpls ldp backoff** command:

```
RP/0/RP0/CPU0:router# show mpls ldp backoff

Backoff Time:
  Initial:15 sec, Maximum:120 sec

Backoff Table: (2 entries)

  LDP Id                Backoff (sec)  Waiting (sec)
  -----
  33.33.33.33:0         15             15
  11.11.11.11:0         30             30
```

This table describes the significant fields shown in the display.

**Table 1: show mpls ldp backoff Command Field Descriptions**

Field	Description
Backoff Time	Initial and maximum backoff time parameters, in seconds.

Field	Description
Backoff Table	<p>List of discovered LDP neighbors for which session setup is being delayed because of previous failures to establish a session due to incompatible configuration. The backoff table incorporates the following information:</p> <p><b>LDP Id</b> Identifies the LDP neighbors.</p> <p><b>Backoff (sec)</b> Specifies the time that the session setup is delayed.</p> <p><b>Waiting (sec)</b> Specifies an approximate time the session setup has been delayed.</p>

**Related Commands**

Command	Description
<a href="#">#unique_50</a>	Configures LDP backoff parameters.
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays the contents of MPLS forwarding table.
<a href="#">show mpls ldp bindings, on page 54</a>	Displays the contents of LDP LIB.

## show mpls ldp bindings

To display the contents of the Label Information Base (LIB), use the **show mpls ldp bindings** command in EXEC command.

```
show mpls ldp [{} ] bindings [prefix/length ] [advertisement-acls] [brief] [detail] [local]
[local-label label [to label]] [local-only] [neighbor address] [remote-only][remote-label label [to
label]] [summary] [{location node-id | standby}]
```

Syntax Description		
	<i>prefix</i>	(Optional) Destination prefix, written in A.B.C.D format.
	<i>length</i>	(Optional) Network mask length, in bits. Range is 0 to 32.
	<b>advertisement-acls</b>	(Optional) Displays the label bindings as applied for (advertisement) outbound label filtering ACLs.
	<b>brief</b>	(Optional) Displays all the prefixes in the LDP database.
	<b>detail</b>	(Optional) Displays the total counts of advertised-to and remote-binding peers in IP address sort order, with remote bindings in tabular format.
	<b>local</b>	(Optional) Displays the local label bindings.
	<b>local-label</b> <i>label</i> [ <b>to</b> <i>label</i> ]	(Optional) Displays entries matching local label values. Add the <i>label to label</i> argument to indicate the label range.
	<b>local-only</b>	(Optional) Displays binding matches with a local label only.
	<b>neighbor</b> <i>address</i>	(Optional) Displays the label bindings assigned by the selected neighbor.
	<b>remote-only</b>	(Optional) Displays bindings matches with a remote label only.

<b>remote-label</b> <i>label</i> [ <b>to</b> <i>label</i> ]	(Optional) Displays entries matching the label values assigned by a neighbor router. Add the <i>label tolabel</i> argument to indicate the label range. Range is from 0 to 2147483647.
<b>summary</b>	(Optional) Displays a summary of the contents of the Label Information Base (LIB).
<b>location</b> <i>node-id</i>	(Optional) Displays location information for the specified node ID.
<b>standby</b>	(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp bindings** command displays local and remote label bindings learned from neighbors for non-BGP routes (such as IGP prefixes and static routes).

You can choose to view the entire database or a subset of entries according to the following criteria:

- Prefix
- Input or output label values or ranges
- Neighbor advertising the label



**Note** The **show mpls ldp bindings summary** command displays summarized information from the LIB and is used when testing scalability or when deployed in a large scale network.

Task ID	Task ID Operations
	mpls-ldp read

**Examples** The following sample output displays the contents of the LIB for the default routing domain:

```
RP/0/RP0/CPU0:router# show mpls ldp bindings
5.41.0.0/16 , rev 4
```

## show mpls ldp bindings

```

        local binding: label:IMP-NULL
        No remote bindings
5.43.9.98/32 , rev 6
        local binding: label:IMP-NULL
        No remote bindings
10.10.2.0/24 , rev 12
        local binding: label:IMP-NULL
        remote bindings :
            lsr:10.255.255.255:0, label:16
            lsr:10.256.256.256:0, label:IMP-NULL
10.10.3.0/24 , rev 10
        local binding: label:IMP-NULL
        remote bindings :
            lsr:10.255.255.255:0, label:IMP-NULL
            lsr:10.256.256.256:0, label:22
22.22.22.22/32 , rev 14
        local binding: label:16
        remote bindings :
            lsr:10.255.255.255:0, label:17
            lsr:10.256.256.256:0, label:IMP-NULL
33.33.33.33/32 , rev 2
        local binding: label:IMP-NULL
        remote bindings :
            lsr:10.255.255.255:0, label:18
            lsr:10.256.256.256:0, label:23

```

The following sample output shows detailed information for the total counts of advertised-to and remote-binding peers in IP address sort order, with remote bindings for 150.150.150.150/32:

```

RP/0/RP0/CPU0:router# show mpls ldp bindings 150.150.150.150/32 detail

150.150.150.150/32, rev 2
  Local binding: label: IMP-NULL
  Advertised to: (6 peers)
    120.120.120.120:0  130.130.130.130:0  150.150.150.1:0  150.150.150.2:0
    150.150.150.3:0   150.150.150.4:0
  Remote bindings:   (3 peers)
    Peer             Label
  -----
    120.120.120.120:0  27018
    130.130.130.130:0  26017
    160.160.160.160:0  27274

```

The following sample output specifies a network number and displays labels learned from label switched router (LSR) 10.255.255.255 for all networks. The **neighbor** keyword is used to suppress the output of remote labels learned from other neighbors:

```

RP/0/RP0/CPU0:router# show mpls ldp bindings neighbor 10.255.255.255

10.10.2.0/24 , rev 12
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255, label:16
10.10.3.0/24 , rev 10
  local binding: label:IMP-NULL
  remote bindings :
    lsr:10.255.255.255:0, label:IMP-NULL
22.22.22.22/32 , rev 14
  local binding: label:16
  remote bindings :

```



```

        lsr:10.255.255.255:0, label:17
33.33.33.33/32 , rev 2
    local binding: label:IMP-NULL
    remote bindings :
        lsr:10.255.255.255:0, label:18
44.44.44.44/32 , rev 16
    local binding: label:17
    remote bindings :
        lsr:10.255.255.255:0, label:IMP-NULL

```

This table describes the significant fields shown in the display.

**Table 2: show mpls ldp bindings and show mpls ldp bindings neighbor Command Field Descriptions**

Field	Description
a.b.c.d/n	IP prefix and mask for a particular destination (network/mask).
rev	Revision number (rev) that is used internally to manage label distribution for this destination.
local binding	Locally assigned label for a prefix.
remote bindings	Outgoing labels for this destination learned from other LSRs. <sup>1</sup> Each item in this list identifies the LSR from which the outgoing label was learned and reflects the label associated with that LSR. Each LSR in the transmission path is identified by its LDP identifier.

<sup>1</sup> Label switched routers.

The following sample output summarizes the content by using the **summary** keyword:

```

RP/0/RP0/CPU0:router# show mpls ldp bindings summary

LIB Summary:
  Total Prefix   : 20
  Revision No   : Current:34, Advertised:34
  Local Bindings : 14
    NULL       : 10 (implicit:10, explicit:0)
    Non-NULL   : 4 (lowest:48, highest:51)
  Remote Bindings: 24

```

This table describes the significant fields shown in the display.

**Table 3: show mpls ldp bindings summary Command Field Descriptions**

Field	Description
Total Prefix	Number of prefixes (routes) known to LDP LIB. All invalid and timed-out routes display as no-routes.

Field	Description
Revision No	Current revision number of LIB entries as well as the minimum revision number that has been advertised to all peers.
Local Bindings	Total number of local bindings, with information on how many of them are Null, non-null, and lowest/highest label assigned or allocated by LDP.
Remote Bindings	Number of remote bindings.

The following sample output shows the access-list advertisement:

```
RP/0/RP0/CPU0:router# show mpls ldp bindings advertisement-acls

Advertisement Spec:
  Prefix ACL = 'pfx_11'
  Prefix ACL = 'pfx_22'
  Prefix ACL = 'pfx_40_1'; Peer ACL = 'peer_11'

5.41.0.0/16 , rev 82
11.11.11.11/32 , rev 69
  Advert ACL(s): Prefix ACL 'pfx_11'
20.20.20.20/32 , rev 83
22.22.22.22/32 , rev 78
  Advert ACL(s): Prefix ACL 'pfx_22'
40.1.1.0/24 , rev 79
  Advert ACL(s): Prefix ACL 'pfx_40_1'; Peer ACL 'peer_11'
```

This table describes the significant fields shown in the display.

**Table 4: show mpls ldp bindings advertisement-acls Command Field Descriptions**

Field	Description
Advertisement Spec	Lists all prefix and peer access-lists used as outbound label advertisement control.
Advert ACL(s)	Lists the first matching rule (if any) for the prefix entry for outbound label advertisement control (for prefix-acl).

The following sample output shows all the prefixes in the LDP database using the **brief** keyword:

```
RP/0/RP0/CPU0:router# show mpls ldp bindings brief

Prefix                               Local Advertised Remote Bindings
Label (peers)                        (peers)
-----
10.1.2.2/32                          -           0           1
10.2.3.4/32                          16010       396         0
209.165.201.1/32                     16004       396         3
10.0.0.0/24                          19226       396         395
```

The following sample output shows that the binding matches with a local label:

```
RP/0/RP0/CPU0:router# show mpls ldp bindings local-only
```

```
10.12.32.2/32, rev 4
  Local binding: label: IMP-NULL
  No remote bindings
```

The following sample output shows that the binding matches with a remote label:

```
RP/0/RP0/CPU0:router# show mpls ldp bindings remote-only
```

```
10.26.4.0/24, rev 0
  No local binding
  Remote bindings: (1 peers)
    Peer             Label
    -----
    10.6.6.6:0      IMP-NULL
10.43.4.0/24, rev 0
  No local binding
  Remote bindings: (1 peers)
    Peer             Label
    -----
    10.4.4.4:0      IMP-NULL
10.46.4.0/24, rev 0
  No local binding
  Remote bindings: (2 peers)
    Peer             Label
    -----
    10.4.4.4:0      IMP-NULL
    10.6.6.6:0      IMP-NULL
```

#### Related Commands

Command	Description
<a href="#">label accept, on page 28</a>	Configures the LDP remote label acceptance.
<a href="#">label advertise, on page 30</a>	Configures the LDP local label advertisement control.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information on the LDP neighbors.
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays the contents of the LDP forwarding database.

# show mpls ldp discovery

To display the status of the LDP discovery process, use the **show mpls ldp discovery** command in XR EXEC mode.

```
show mpls ldp [{}] discovery [{type interface-path-id | brief | link | targeted | summary [all]}]
[detail] [{location node-id | standby}]
```

## Syntax Description

<i>type</i>	(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>	Physical interface or a virtual interface.  <b>Note</b> Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.  For more information about the syntax for the router, use the question mark (?) online help function.
<b>brief</b>	(Optional) Displays concise information about a specified LDP-enabled interface.
<b>link</b>	(Optional) Displays link information for LDP discovery.
<b>targeted</b>	(Optional) Displays targeted information for LDP discovery.
<b>summary</b>	(Optional) Displays summarized information for LDP discovery.
<b>detail</b>	(Optional) Displays detailed information (including, inbound label filtering, session KAs, and session protection state) for an LDP session.
<b>location</b> <i>node-id</i>	(Optional) Displays location information for the specified node ID.
<b>standby</b>	(Optional) Displays standby node-specific information.

**Command Default** No default behavior or values

**Command Modes** XR EXEC mode

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp discovery** command shows both link discovery and targeted discovery. When no interface filter is specified, this command generates a list of interfaces running the LDP discovery process. This command also displays neighbor discovery information for the default routing domain.

Task ID	Task ID	Operations
	mpls-ldp	read

### Examples

The following sample output is from the **show mpls ldp discovery** command:

```
RP/0/RP0/CPU0:router# show mpls ldp discovery

Local LDP Identifier: 10.44.44.44:0
Discovery Sources:
  Interfaces:
    POS 0/1/0/0 : xmit/recv
      LDP Id: 10.33.33.33:0, Transport address: 10.33.33.33
      Hold time: 15 sec (local:15 sec, peer:15 sec)
```

This table describes the significant fields shown in the display.

**Table 5: show mpls ldp discovery Command Field Descriptions**

Field	Description
Local LDP Identifier	LDP identifier for the local router. An LDP identifier is a 6-byte construct displayed in the form IP address:number. By convention, the first 4 bytes of the LDP identifier constitute the router ID; integers, starting with 0, constitute the final two bytes of the IP address:number construct.
Interfaces	Interfaces engaged in LDP discovery activity, as follows: <b>xmit field</b> Indicates that the interface is transmitting LDP discovery hello packets. <b>recv field</b> indicates that the interface is receiving LDP discovery hello packets. The LDP identifiers indicate the LDP neighbors discovered on the interface.
Transport Address	Address associated with this LDP peer (advertised in hello messages).
LDP Id	LDP identifier of the LDP peer.

Field	Description
Hold time	State of the forwarding hold timer and its current value.

The following sample output summarizes information for LDP discovery by using the **summary** keyword:

```
RP/0/RP0/CPU0:router# show mpls ldp discovery summary

LDP Identifier: 139.0.0.1:0
Interfaces:
  Configured: 2
  Enabled   : 1
Discovery:
  Hello xmit: 1 (1 link)
  Hello rcv: 1 (1 link)
```

This table describes the significant fields shown in the display.

**Table 6: show mpls ldp discovery summary Command Field Descriptions**

Field	Description
LDP Identifier	The LDP identifier for the local router.
Interfaces	Summary of interfaces engaged in LDP activity. <b>Configured</b> Number of interfaces configured for LDP. <b>Enabled</b> Number of interfaces on which LDP is actively enabled and is thus sending LDP hellos. An interface configured for LDP is enabled only if running IP and not in the down state.
Discovery	Summary of LDP discovery process. <b>Hello xmit</b> Number of local LDP discovery sources (including link and targeted hellos) emitting LDP hellos. <b>Hello rcv</b> Number of discovered hello sources via link or targeted hello mechanics.

The following sample output shows the MPLS LDP discovery hello information in brief form:

```
RP/0/RP0/CPU0:router# show mpls ldp discovery brief

Local LDP Identifier: 192.168.0.3:0

Discovery Source      VRF Name      Peer LDP Id      Holdtime      Session
-----
PO0/3/0/2            default       192.168.0.1:0   15            Y
```

The following sample shows the MPLS LDP afi-all discovery brief command output:

```
RP/0/0/CPU0:router#show mpls ldp afi-all discovery brief
```

```
Local LDP Identifier: 192.168.0.1:0
```

Discovery Source	AFI	VRF Name	Peer LDP Id	Holdtime	Session
PO0/3/0/0	IPv6	default	192.168.0.2:0	15	Y
	IPv4	default	192.168.0.2:0	15	Y
PO0/3/0/1	IPv4	default	192.168.0.3:0	15	Y
PO0/3/0/2	IPv4	default	192.168.0.4:0	15	Y
PO0/3/0/3	IPv6	default	192.168.0.3:0	15	Y
PO0/3/0/4	IPv6	default	192.168.0.5:0	15	Y

### Related Commands

Command	Description
<a href="#">#unique_51</a>	Configures LDP link hello parameters.
<a href="#">#unique_14</a>	Configures LDP targeted-hello parameters.
<a href="#">neighbor targeted, on page 45</a>	Configures LDP targeted neighbor.
<a href="#">session protection, on page 50</a>	Configures LDP session protection.
<a href="#">interface (MPLS LDP), on page 25</a>	Configures LDP on an interface.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.

## show mpls ldp forwarding

To display the Label Distribution Protocol (LDP) forwarding state installed in MPLS forwarding, use the **show mpls ldp forwarding** command in EXEC mode.

```
show mpls ldp [{}] forwarding [prefix/length] [fast-reroute] [detail] [next-hop {address
ip-address | interface interface-path-id | label label-value | neighbor ldp-id | unlabelled}] [local-label
label-value] [{location node-id | summary | standby}]
```

Syntax Description		
	<i>prefix</i>	(Optional) Destination prefix, written in A.B.C.D format.
	<i>length</i>	(Optional) Network mask length, in bits. Range is 0 to 32.
	<b>detail</b>	(Optional) Displays detailed information for the LDP timestamp that is used for the routing and forwarding update.
	<b>fast-reroute</b>	(Optional) Displays the prefix that is LFA FRR protected in nature.
	<b>next-hop</b>	Matches prefixes by next-hop IP address.
	<b>local-label</b> <i>label-value</i>	(Optional) Displays the prefix with the specified local label. Range is from 0 to 1048575.
	<b>neighbor</b>	Matches prefixes with a path through specified LDP neighbor.
	<b>unlabelled</b>	Matches prefixes containing unlabelled paths.
	<b>location</b> <i>node-id</i>	(Optional) Displays location information for the specified node ID.
	<b>summary</b>	(Optional) Displays the summary information for the LDP forwarding information base (LFIB).
	<b>standby</b>	(Optional) Displays standby-node specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC



Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp forwarding** command displays the LDP forwarding entries and provides LDP view of its installed forwarding entries.

Task ID	Task ID	Operations
	mpls-ldp	read

### Examples

This is a sample output from the **show mpls ldp forwarding** command:

```
RP/0/RP0/CPU0:router# show mpls ldp forwarding

Prefix          Label In  Label Out  Outgoing Interface  Next Hop  GR Stale
-----
172.16.0.1/32   22     ImpNull PO0/2/0/1  12.0.0.2    N  N
3.0.0.1/32     24     20      PO0/2/0/1  12.0.0.2    N  N
3.0.0.2/32     25     21      PO0/2/0/1  12.0.0.2    N  N
3.0.0.3/32     26     22      PO0/2/0/1  12.0.0.2    N  N
4.4.4.4/32     20     ExpNullv4 tt10      4.4.4.4     N  N
4.4.4.5/32     21     ExpNullv4 tt10      4.4.4.4     N  N
123.0.0.0/24   23     ImpNull PO0/2/0/1  12.0.0.2    N  N
192.168.0.1/32 16000 16001   PO0/2/0/3.1 131.1.1.4   Y  N
                16002  PO0/2/0/3.2 131.1.2.4   Y  N
                16003  PO0/2/0/3.3 131.1.3.4   N  N
                16002  PO0/2/0/1   192.11.1.1 (!) Y  N
                Unlabelled PO0/2/0/2   192.11.2.1 (!) N  N
```



**Note** The (!) symbol refers to a non-primary LFA backup path.

This sample output shows detailed information for the LDP timestamp that is used for routing and forwarding update from the **detail** keyword:

```
RP/0/RP0/CPU0:router# show mpls ldp forwarding 10.0.0.1/32 detail

Prefix          Label In  Label Out  Outgoing Interface  Next Hop  GR Stale
-----
192.168.0.1/32 16000 16001   PO0/2/0/3.1 131.1.1.4   N  N
                [ Protected; path-id 1 backup-path-id 33;
                [peer 13.13.13.1:0 ]
                16002  PO0/2/0/3.2 131.1.2.4   Y  N
                [ Protected; path-id 2 backup-path-id 33;
                peer 13.13.13.1:0 ]
                16003  PO0/2/0/3.3 131.1.3.4   N  N
                [ Protected; path-id 3 backup-path-id 34;
                peer 13.13.13.2:0 ]
                16002  PO0/2/0/1   192.11.1.1 (!) Y  N
```

```
[ Backup; path-id 33; peer 14.14.14.1:0 ]
Unlabelled PO0/2/0/2 192.11.2.1 (!) N N
[ Backup; path-id 34 ]
```

```
Routing update : Mar 31 13:35:25.348 (00:55:32 ago)
Forwarding update: Mar 31 13:35:25.349 (00:55:32 ago)
```



**Note** The (!) symbol refers to a non-primary LFA backup path.

This sample output shows only LDP prefixes with protection (ECMP or secondary LFA backups) update from the **fast-reroute** keyword:

This sample output shows the statistics of protected prefixes and protected paths from the **summary** keyword:

```
RP/0/RP0/CPU0:router# show mpls ldp forwarding summary
Forwarding Server (LSD):
  Connected: Yes
  Forwarding State Holdtime: 360 sec
Forwarding States:
  Interfaces: 10
  Local labels: 8
  Rewrites:
  Prefix:
    Total: 8 (0 with ECMP, 8 FRR protected)
  Labelled:
    Primary pathset : 8 labelled (0 partial), 0 unlabelled
    Backup pathset  : 8 labelled (0 partial), 0 unlabelled
    Complete pathset: 8 labelled (0 partial), 0 unlabelled
  Paths:
    Total: 16 (8 backup, 8 FRR protected)
    Labelled: 16 (8 backup)
```

This table describes the significant fields shown in the display.

**Table 7: show mpls ldp forwarding Command Field Descriptions**

Field	Description
Prefix/mask	Prefix on the FEC <sup>2</sup> for an MPLS forwarding entry.
Label In	Local label assigned to the prefix/mask.
Label Out	Outgoing label for the prefix/mask.
Outgoing Interface	Outgoing physical interface.
Next Hop	Next Hop address.
GR	Graceful restart status (Y or N).
Stale	Status of the entry, stale or not stale. An entry is marked stale when the next-hop graceful restart neighbor disconnects and is unmarked when neighbor reconnects and refreshes the label.

Field	Description
Chkpt	Status of the entry, checkpointed or not checkpointed.
path-id	Primary Path-id.
Backup-path-id	The backup path-id is the path-id of the path protecting a given primary path. A protecting path can be primary path or a non-primary path.
Peer	Displays next-hop LDP peer's LDP identifier.
Connected	Displays LDP connection state with LSD forwarding server.
Forwarding State Holdtime	Displays time that LDP has registered with LSD server to keep LDP forwarding state intact upon LDP disconnect event.
Interfaces	Number of LDP enabled MPLS interfaces.
Local Labels	Number of LDP allocated local labels from LSD.
Rewrites	Counts of Forwarding rewrites. Displays total number of known IPv4 prefixes along with information on number of prefixes with more than one ECMP path. This also displays number of prefixes with LFA-FRR protection. The labelled set prints the counts related to prefixes with none, all, partial labelled paths as shown by unlabeled, labelled, and partial keywords. This information is available for primary, backup, and complete path set.
Paths	Forwarding path counts. Displays count of total number of known forwarding paths, along with number of backup paths and number of FRR protected paths. It also displays the count of labelled paths indicating how many of non-primary paths are labelled.

<sup>2</sup> Forwarding Equivalence Class.

#### Related Commands

Command	Description
<a href="#">graceful-restart (MPLS LDP), on page 17</a>	Configures the LDP graceful restart feature.
<a href="#">show mpls ldp bindings, on page 54</a>	Displays the contents of LDP LIB.

# show mpls ldp graceful-restart

To display the status of the Label Distribution Protocol (LDP) graceful restart, use the **show mpls ldp graceful-restart** command in EXEC mode.

```
show mpls ldp graceful-restart [{location node-id}] [{standby}]
```

<b>Syntax Description</b>	<b>location</b> <i>node-id</i>	(Optional) Displays location information for the specified node ID.
	<b>standby</b>	(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp graceful-restart** command displays LDP graceful-restart-related information when the **graceful-restart** command is enabled.

<b>Task ID</b>	<b>Task ID</b>	<b>Operations</b>
	mpls-ldp	read

## Examples

The following shows a sample output from the **show mpls ldp graceful-restart** command:

```
RP/0/RP0/CPU0:router# show mpls ldp graceful-restart

Forwarding State Hold timer : Not Running
GR Neighbors                : 1

Neighbor ID      Up    Connect Count  Liveness Timer  Recovery Timer
-----
10.0.0.2        Y      1              -                -
```

This table describes the significant fields shown in the display.

**Table 8: show mpls ldp graceful-restart Command Field Descriptions**

<b>Field</b>	<b>Description</b>
Forwarding State Hold timer	State of the hold timer—running or not running.

Field	Description
GR Neighbors	Number of graceful restartable neighbors.
Neighbor ID	Router ID of each neighbor.
Up	Neighbor up or down.
Connect Count	Number of times the same neighbor has reconnected.
Liveness Timer	State of the liveness timer (running or not running) and its expiration time, if running.
Recovery Timer	State of the recovery timer (running or not running) and its expiration time, if running.

**Related Commands**

Command	Description
<a href="#">graceful-restart (MPLS LDP), on page 17</a>	Configures the LDP graceful restart feature.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays information about LDP neighbors.

# show mpls ldp igp sync

To display Label Distribution Protocol (LDP) Interior Gateway Protocol (IGP) synchronization information on interface(s), use the **show mpls ldp igp sync** command in EXEC mode.

**show mpls ldp** [{}] **igp sync** [**interface** *type interface-path-id*] [{**location** *node-id*}] [{**standby**}]

Syntax Description		
<b>interface</b>		(Optional) Displays the interface type.
<i>type</i>		(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		(Optional) Physical interface or a virtual interface.
		<p><b>Note</b> Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.</p> <p>For more information about the syntax for the router, use the question mark (?) online help function.</p>
<b>location</b> <i>node-id</i>		(Optional) Displays location information for the specified node ID.
<b>standby</b>		(Optional) Displays standby node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** LDP IGP synchronization addresses traffic loss issues as a result of synchronization between MPLS LDP and IP (IGP). For instance, upon a link up, IGP can advertise a link before MPLS converges on the link. Also, the IGP link is still used even when MPLS session goes down and MPLS LSP is broken on this link. The use of IGP link is determined based on MPLS LDP convergence synchronization status on the link.

Use the **show mpls ldp igp sync** command to display MPLS convergence status. The configuration for LDP IGP synchronization resides in IGP (OSPF, ISIS); accordingly, LDP displays and advertises this information for all LDP-enabled interfaces (regardless if the interface is configured for LDP IGP).

Task ID	Task ID	Operations
	mpls-ldp	read

### Examples

The following shows a sample output from the **show mpls ldp igp sync** command:

```
RP/0/RP0/CPU0:router# show mpls ldp igp sync

POS0/3/0/2:
  VRF: 'default' (0x60000000)
  Sync delay: Disabled
  Sync status: Ready
  Peers:
    192.168.0.1:0    (GR)
```

This table describes the significant fields shown in the display.

**Table 9: show mpls ldp igp sync Command Field Descriptions**

Field	Description
VRF	VRF of the interface.
Sync status	MPLS LDP convergence status on a given link. Ready indicates that the link is converged and is ready to be used by IGP. Not Ready with Deferred means that the link fulfills LDP IGP synchronization requirements but is deferred by LDP IGP synchronization delay timeout configuration setting. Not Ready means that the link is not ready to be used by IGP.
Peers	List of peers converged on the given link. If the peer session is GR <sup>3</sup> -enabled, output is tagged as GR. If GR-only reachability is indicated due to a GR neighbor record recovered from checkpoint after local start, then Chkpt-created flag is also set.

<sup>3</sup> Graceful Restart.

 show mpls ldp igp sync

---

**Related Commands**

Command	Description
<a href="#">igp sync delay, on page 22</a>	Configures LDP IGP sync delay timeout.



# show mpls ldp interface

To display information about LDP-enabled interfaces, use the **show mpls ldp interfaces** command in EXEC mode.

```
show mpls ldp [{}] interface [{type interface-path-id | summary}] [brief] [{location node-id | standby}]
```

Syntax Description		
<i>type</i>		(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		Physical interface or a virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.
<b>summary</b>		(Optional) Displays summary information about a specified LDP-enabled interface.
<b>brief</b>		(Optional) Displays concise information about a specified LDP-enabled interface.
<b>detail</b>		(Optional) Displays detailed information about a specified LDP-enabled interface.
<b>location</b> <i>node-id</i>		(Optional) Displays location information for the specified node ID.
<b>standby</b>		(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

Task ID	Task ID	Operations
	mpls-ldp	read

## Examples

The following shows a sample output from the **show mpls ldp interface** command:

```
RP/0/RP0/CPU0:router# show mpls ldp interface
```

## show mpls ldp interface

```

Interface GigabitEthernet0/3/0/3
  No LDP config
Interface POS0/2/0/0
  No LDP config
  Auto-config items:
    ospf/100/0
Interface POS0/2/0/1
  No LDP config
  Auto-config items:
    ospf/100/0
Interface POS0/2/0/2
  No LDP config
  Auto-config items:
    ospf/100/0
Interface POS0/2/0/3
  No LDP config
  Auto-config items:
    ospf/100/0

```

This table describes the significant fields shown in the display.

**Table 10: show mpls ldp interface Command Field Descriptions**

Field	Description
Auto-config items	Lists IGP that specify an interface for MPLS LDP auto-configuration: <b>OSPF</b> <i>ospf instance area</i> <b>ISIS</b> <i>isis instance</i>

The following shows a sample output from the **show mpls ldp interface detail** command for the mesh groups:

```

RP/0/RP0/CPU0:router# show mpls ldp interface detail

Interface GigabitEthernet0/2/0/0 (0x20200040)
  Enabled via config: LDP interface
Interface GigabitEthernet0/2/0/1 (0x20200060)
  Disabled via config: IGP Auto-config disable
  Ignoring: LDP interface
Interface GigabitEthernet0/2/0/2 (0x20200080)
  Disabled via config: IGP Auto-config disable
  Ignoring: LDP interface
Interface tunnel-te1 (0x200000f0)
  Disabled
Interface tunnel-te100 (0x20000110)
  Enabled via config: TE Mesh-group 123, TE Mesh-group all
Interface tunnel-te101 (0x20000130)
  Enabled via config: TE Mesh-group 123, TE Mesh-group all

```

**Related Commands**

Command	Description
<a href="#">igp auto-config disable, on page 21</a>	Disables LDP auto-configuration.

## show mpls ldp neighbor

To display the status of Label Distribution Protocol (LDP) sessions, use the **show mpls ldp neighbor** command in EXEC mode.

**show mpls ldp neighbor** [{*ip-address*}] [*type interface-path-id*] [**brief**] [**detail**] [**gr**] [**location node-id**] [**non-gr**] [**sp**] [**standby**]

Syntax Description		
<i>ip-address</i>		(Optional) Neighbor IP address.
<i>type</i>		(Optional) Interface type. For more information, use the question mark (?) online help function.
<i>interface-path-id</i>		Physical interface or a virtual interface.
	<b>Note</b>	Use the <b>show interfaces</b> command to see a list of all possible interfaces currently configured on the router.
		For more information about the syntax for the router, use the question mark (?) online help function.
<b>brief</b>		(Optional) Displays the existing LDP sessions in brief format.
<b>detail</b>		(Optional) Displays detailed information (including, inbound label filtering, session KAs, and session protection state) for an LDP session.
<b>gr</b>		(Optional) Displays graceful restartable neighbors.
<b>location node-id</b>		(Optional) Displays location information for the specified node ID.
<b>non-gr</b>		(Optional) Displays non-graceful restartable neighbors.
<b>sp</b>		(Optional) Displays neighbors with session protection.
<b>standby</b>		(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp neighbor** command provides information about all LDP neighbors in the entire routing domain—conversely, the show output is filtered to display:

- LDP neighbors with specific IP addresses
- LDP neighbors on a specific interface
- LDP neighbors that are graceful restartable
- LDP neighbors that are nongraceful restartable
- LDP neighbors enabled with session protection

Task ID	Task ID	Operations
	mpls-ldp	read

## Examples

The following shows a sample output from the **show mpls ldp neighbor** command using an IP address:

```
RP/0/RP0/CPU0:router# show mpls ldp neighbor 4.4.4.4

Peer LDP Identifier: 4.4.4.4:0
TCP connection: 14.1.0.41:38022 - 10.0.0.1:646
Graceful Restart: Yes (Reconnect Timeout: 120 sec, Recovery: 96 sec)
Session Holdtime: 180 sec
State: Oper; Msgs sent/rcvd: 1721/1716; Downstream-Unsolicited
Up time: 1d00h
LDP Discovery Sources:
  IPv4: (1)
    GigabitEthernet0/1/0/0
  IPv6: (0)
Addresses bound to this peer:
  IPv4: (3)
    4.4.4.4          14.1.0.41        24.1.0.4
  IPv6: (0)
```

The following shows a sample output from the **show mpls ldp neighbor** command using the **non-gr** keyword:

```
RP/0/RP0/CPU0:router# show mpls ldp neighbor non-gr

Peer LDP Identifier: 10.44.44.44:0
TCP connection: 10.44.44.44:65535 - 10.33.33.33:646
Graceful Restart: No
State: Oper; Msgs sent/rcvd: 49/46
Up time: 00:33:33
LDP Discovery Sources:
  POS 0/1/0/0
```

## show mpls ldp neighbor

```

Addresses bound to this peer:
  10.44.44.44    10.10.3.2
Peer LDP Identifier: 10.22.22.22:0
TCP connection: 10.22.22.22:646 - 10.33.33.33:65530
Graceful Restart: No
State: Oper; Msgs sent/rcvd: 48/45
Up time: 00:33:11
LDP Discovery Sources:
  POS 0/2/0/0
Addresses bound to this peer:
  10.22.22.22    10.10.2.1

```

This table describes the significant fields shown in the display.

**Table 11: show mpls ldp neighbor Command Field Descriptions**

Field	Description
Peer LDP Identifier	LDP identifier of the neighbor (peer) for this session.
TCP connection	TCP connection used to support the LDP session, shown in the following format: <b>neighbor IP address</b> peer port <b>local IP address</b> local port
Graceful Restart	Graceful-restart status (Y or N).
State	State of the LDP session. Generally this is Oper (operational), but transient is another possible state.
Msgs sent/rcvd	Number of LDP messages sent to and received from the session peer. The count includes the transmission and receipt of periodic keepalive messages, which are required for maintenance of the LDP session.
Up time	The length of time that this session has been up for (in <i>hh:mm:ss</i> format).
LDP Discovery Sources	The source(s) of LDP discovery activity leading to the establishment of the LDP session.
Addresses bound to this peer	The known interface addresses of the LDP session peer. These are addresses that might appear as “next hop” addresses in the local routing table. They are used to maintain the LFIB <sup>4</sup> .

<sup>4</sup> LFIB = Label Forwarding Information Base.

The following shows a sample output from the **show mpls ldp neighbor** command using the **brief** keyword:

```

RP/0/RP0/CPU0:router# show mpls ldp neighbor brief

Peer                GR  NSR  Up Time      Discovery  Addresses  Labels
                   ipv4  ipv6  ipv4  ipv6  ipv4  ipv6

```

4.4.4.4:0	Y	N	1d00h	1	0	3	0	5	0
46.46.46.2:0	N	N	1d00h	1	1	3	3	5	5
46.46.46.46:0	Y	N	1d00h	2	2	4	4	5	5
6.6.6.1:0	Y	N	23:25:50	0	1	0	2	0	5

This table describes the significant fields shown in the display.

**Table 12: show mpls ldp neighbor brief Command Field Descriptions**

Field	Description
Peer	LDP identifier of the neighbor (peer) for this session.
GR	Graceful-restart status (Y or N).
Up Time	Time the session has been up (in hh:mm:ss format).
Discovery	Number of LDP discovery sources corresponding to the neighbor.
Address	Number of addresses bound to this peer.

The following shows a sample output from the **show mpls ldp neighbor** command using the **detail** keyword:

```
RP/0/RP0/CPU0:router# show mpls ldp neighbor detail

Peer LDP Identifier: 172.16.0.1:0
TCP connection: 172.16.0.1:11707 - 10.0.0.1:646
Graceful Restart: No
Session Holdtime: 180 sec
State: Oper; Msgs sent/rcvd: 33/29
Up time: 00:13:37
LDP Discovery Sources:
  POS0/2/0/1
  Targeted Hello (10.0.0.1 ->172.16.0.1, active)
Addresses bound to this peer:
  23.0.0.2 2.0.0.2          123.0.4.2          10.42.37.119
  10.2.2.2
Peer holdtime: 180 sec; KA interval: 60 sec; Peer state: Estab
Clients: Dir Adj Client
Inbound label filtering: accept acl 'pfx_acl2'
Session Protection:
  Enabled, state: Ready
  Duration: 30 seconds
```

This table describes the significant fields shown in the display.

**Table 13: show mpls ldp neighbor detail Command Field Descriptions**

Field	Description
Peer LDP Identifier	LDP identifier of the neighbor (peer) for this session.

Field	Description
TCP connection	TCP connection used to support the LDP session, shown in the following format: <b>neighbor IP address</b> peer port <b>local IP address</b> local port
Graceful Restart	Graceful-restart status (Y or N).
Session Holdtime	Session hold time, in seconds.
State	State of the LDP session (operational or transient).
Msgs sent/rcvd	Number of LDP messages sent to and received from the session peer. The count includes the transmission and receipt of periodic keepalive messages, which are required for maintenance of the LDP session.
Up time	Time the session has been up for (in <i>hh:mm:ss</i> format).
Peer holdtime	Time to keep LDP peer session up without receipt of LDP protocol message from a peer.
Peer state	Peer session state.
Peer holdtime	Time to keep LDP peer session up without receipt of LDP protocol message from a peer.
Clients	LDP (internal) clients requesting session with a neighbor.
Inbound label filtering	LDP neighbor inbound filtering policy.
Session Protection	State of the session protection: <b>Incomplete</b> Targeted discovery requested but not yet up. <b>Ready</b> Targeted discovery and at least one link hello adjacency to the peer are up. <b>Protecting</b> Targeted discovery is up and there is no link hello adjacency to the peer. Targeted discovery is protecting and backing up link discoveries.
Duration	Maximum time to maintain session through targeted discovery upon loss of primary link discovery.
Holdtimer	When in “protecting” state, time to keep LDP peer session up without receipt of LDP protocol message from a peer.



**Related Commands**

<b>Command</b>	<b>Description</b>
<a href="#">graceful-restart (MPLS LDP), on page 17</a>	Configures the LDP graceful restart feature.
<a href="#">label accept, on page 28</a>	Configures the LDP inbound label filtering feature.
<a href="#">session protection, on page 50</a>	Configures the LDP session protection feature.
<a href="#">show mpls ldp discovery, on page 60</a>	Displays the status of the LDP discovery process.

# show mpls ldp parameters

To display current LDP parameters, use the **show mpls ldp parameters** command in EXEC mode.

**show mpls ldp parameters** [{**location** *node-id* | **standby**}]

Syntax Description		
	<b>location</b> <i>node-id</i>	(Optional) Displays location information for the specified node ID.
	<b>standby</b>	(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp parameters** command displays all LDP operational and configuration parameters.

Task ID	Task ID	Operations
	mpls-ldp	read
	network	read

## Examples

The following shows a sample output from the **show mpls ldp parameters** command:

```
RP/0/RP0/CPU0:router# show mpls ldp parameters

LDP Parameters:
  Protocol Version: 1
  Router ID: 10.11.11.11
  Null Label: Implicit
  Session:
    Hold time: 180 sec
    Keepalive interval: 60 sec
    Backoff: Initial:15 sec, Maximum:120 sec
  Discovery:
    Link Hellos:      Holdtime:15 sec, Interval:5 sec
    Targeted Hellos: Holdtime:90 sec, Interval:10 sec
                    (Accepting peer ACL 'peer_acl_10')
  Graceful Restart:
    Enabled (Configured)
    Reconnect Timeout:120 sec, Forwarding State Holdtime:180 sec
  Timeouts:
    Binding with no-route: 300 sec
```

```

LDP application recovery (with LSD): 360 sec
OOR state
Memory: Normal

```

This table describes the significant fields shown in the display.

**Table 14: show mpls ldp parameters Command Field Descriptions**

Field	Description
Protocol Version	Version of LDP running on the platform.
Router ID	Currently used router ID.
Null Label	LDP use of implicit-null or explicit-null as label for prefixes where it has to use a null label.
Session Hold time	Time LDP session is to be maintained with an LDP peer without receiving LDP traffic or an LDP keepalive message from the peer.
Session Keepalive interval	Time interval between consecutive transmissions of LDP keepalive messages to an LDP peer.
Session Backoff	Initial maximum backoff time for sessions.
Discovery Link Hellos	Time to remember that a neighbor platform wants an LDP session without receiving an LDP hello message from the neighbor (hold time), and the time interval between the transmission of consecutive LDP hello messages to neighbors (interval).
Discovery Targeted Hellos	Indicates the time: <ul style="list-style-type: none"> <li>To remember that a neighbor platform wants an LDP session when the neighbor platform is not directly connected to the router or the neighbor platform has not sent an LDP hello message. This intervening interval is known as <i>hold time</i>.</li> <li>Interval between the transmission of consecutive hello messages to a neighbor not directly connected to the router and if targeted hellos are being accepted, displaying peer-acl (if any).</li> </ul>
Graceful Restart	Status of graceful-restart status (Y or N).
Timeouts	Various timeouts (of interest) that the LDP is using. One timeout is <i>binding no route</i> , which indicates how long the LDP waits for an invalid route before deleting it. It also shows restart recovery time for LSD and LDP.
OOR state	Out of resource memory state: Normal, Major, or Critical.

#### Related Commands

Command	Description
<a href="#">#unique_50</a>	Configures the parameters for the LDP backoff mechanism.

Command	Description
<a href="#">#unique_51</a>	Configures the interval between transmission of LDP discovery messages.
<a href="#">explicit-null, on page 15</a>	Configures a router to advertise an explicit-null label.
<a href="#">graceful-restart (MPLS LDP), on page 17</a>	Configures the LDP graceful restart feature.
<a href="#">session holdtime (MPLS LDP), on page 19</a>	Configures keepalive message hold time for LDP sessions.
<a href="#">neighbor targeted, on page 45</a>	Specifies the preferred interface or IP address of a Loopback interface for determining the LDP router ID.

# show mpls ldp statistics msg-counters

To display statistics of the messages exchanged between neighbors, use the **show mpls ldp statistics msg-counters** command in EXEC mode.

```
show mpls ldp statistics msg-counters [{ lsr-id ldp-id }] [{ location node-id | standby }]
```

Syntax Description		
<i>lsr-id</i>		(Optional) LSR ID of neighbor in A.B.C.D format.
<i>ldp-id</i>		(Optional) LDP ID of neighbor in A.B.C.D: format.
<b>location</b> <i>node-id</i>		(Optional) Displays location information for the specified node ID.
<b>standby</b>		(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp statistics msg-counters** command can provide counter information about different types of messages sent and received between neighbors.

Task ID	Task ID	Operations
	mpls-ldp	read

**Examples** The following shows a sample output from the **show mpls ldp statistics msg-counters** command:

```
RP/0/RP0/CPU0:router# show mpls ldp statistics msg-counters
```

```
Peer LDP Identifier: 10.33.33.33:0
Msg Sent: (80)
  Init           : 1
  Address        : 1
  Address_Withdraw : 0
  Label_Mapping  : 5
  Label_Withdraw : 0
  Label_Release  : 0
  Notification   : 0
  KeepAlive      : 73
```

## show mpls ldp statistics msg-counters

```

Msg Rcvd: (81)
  Init           : 1
  Address        : 1
  Address_Withdraw : 0
  Label_Mapping  : 8
  Label_Withdraw : 0
  Label_Release  : 0
  Notification   : 0
  KeepAlive      : 71

```

Table 15: [show mpls ldp statistics msg-counters Command Field Descriptions, on page 86](#) describes the significant fields shown in the display.

**Table 15: show mpls ldp statistics msg-counters Command Field Descriptions**

Field	Description
Peer LDP Identifier	LDP identifier of the neighbor (peer).
Msg Sent	Summary of messages sent to the LDP peer.
Msg Rcvd	Summary of messages received from the LDP peer.

---

**Related Commands**

Command	Description
<a href="#">#unique_52</a>	Clears MPLS LDP message counter values.
<a href="#">show mpls ldp bindings, on page 54</a>	Displays the contents of LDP LIB.
<a href="#">show mpls ldp neighbor, on page 76</a>	Displays LDP neighbor information.

# show mpls ldp summary

To display a summary of LDP information, use the **show mpls ldp summary** command in EXEC mode.

```
show mpls ldp summary [{location node-id | standby}]
```

Syntax Description	location node-id	(Optional) Displays location information for the specified node ID.
	standby	(Optional) Displays standby-node-specific information.

**Command Default** No default behavior or values

**Command Modes** EXEC

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **show mpls ldp summary** command can provide information about the number of LDP neighbors, interfaces, forwarding state (rewrites), servers connection/registration, and graceful-restart information.

Task ID	Task ID	Operations
	mpls-ldp	read

## Examples

The following example shows a sample output from the **show mpls ldp summary** command:

```
RP/0/RP0/CPU0:router# show mpls ldp summary

AFIs      : IPv4
Routes    : 4
Neighbors : 1 (1 GR)
Hello Adj : 1
Addresses : 3
Interfaces: 4 LDP configured
```

The following example shows a sample output from the **show mpls ldp summary all** command:

```
RP/0/RP0/CPU0:router# show mpls ldp summary all

VRFs      : 1 (1 oper)
AFIs      : IPv4
Routes    : 4
Neighbors : 1 (1 GR)
Hello Adj : 1
```

## show mpls ldp summary

```

Addresses      : 3
Interfaces     : 4 (1 forward reference, 2 LDP configured)
Collaborators:

```

	Connected -----	Registered -----
SysDB	Y	Y
IM	Y	Y
RSI	Y	-
IP-ARM	Y	-
IPv4-RIB	Y	Y (1/1 tables)
LSD	Y	Y
LDP-NSR-Partner	Y	-
L2VPN-AToM	Y	-
mLDP	-	N

This table describes the significant fields shown in the display.

**Table 16: show mpls ldp summary Command Field Descriptions**

Field	Description
Routes	Number of known IP routes (prefixes).
Neighbors	Number of LDP neighbors, including targeted and graceful restartable neighbors.
Hello Adj	Number of discovered LDP discovery sources.
Interfaces	Number of known IP interfaces and number of LDP configured interfaces. LDP is configured on a forward-referenced interface which may not exist or for which no IP address is configured.
Addresses	Number of known local IP addresses.

## Related Commands

Command	Description
<a href="#">show mpls ldp bindings, on page 54</a>	Displays the contents of LDP LIB.
<a href="#">show mpls ldp discovery, on page 60</a>	Displays the status of the LDP discovery process.
<a href="#">show mpls ldp forwarding, on page 64</a>	Displays the contents of the LDP forwarding database.
<a href="#">show mpls ldp graceful-restart, on page 68</a>	Displays the status of the LDP graceful restart.
<a href="#">show mpls ldp parameters, on page 82</a>	Displays current LDP parameter settings.



## signalling dscp (LDP)

To assign label distribution protocol (LDP) signaling packets a differentiated service code point (DSCP) to assign higher priority to the control packets while traversing the network, use the **signalling dscp** command in MPLS LDP configuration mode. To return to the default behavior, use the **no** form of this command.

**signalling dscp** *dscp*  
**no signalling dscp**

### Syntax Description

*dscp* DSCP priority value. Range is 0 to 63.

### Command Default

LDP control packets are sent with precedence 6 (*dscp*: 48)

### Command Modes

MPLS LDP configuration

### Command History

Release	Modification
Release 5.0.0	This command was introduced.

### Usage Guidelines

DSCP marking improves signaling setup and teardown times.

Ordinarily, when LDP sends hello discovery or protocol control messages, these are marked using the default control packet precedence value (6, or *dscp* 48). You can use the **signalling dscp** command to override that DSCP value to ensure that all control messages sent are marked with a specified DSCP.



**Note** While the **signalling dscp** command controls LDP signaling packets (Discovery hellos and protocol messages), it has no effect on ordinary IP or MPLS data packets.

### Task ID

Task ID	Operations
mpls-ldp	read, write

### Examples

The following example shows how to assign LDP packets a DSCP value of 56:

```
RP/0/RP0/CPU0:router(config-ldp)# signalling dscp 56
```

## snmp-server traps mpls ldp

To inform a network management system of session and threshold cross changes, use the **snmp-server traps mpls ldp** command in global configuration mode.

**snmp-server traps mpls ldp** {**up** | **down** | **threshold**}

Syntax Description	
<b>up</b>	Displays the session-up notification.
<b>down</b>	Displays the session-down notification.
<b>threshold</b>	Displays the session-backoff-threshold crossed notification.

**Command Default** LDP does not send SNMP traps.

**Command Modes** Global configuration

Command History	Release	Modification
	Release 5.0.0	This command was introduced.

**Usage Guidelines** The **snmp-server traps mpls ldp** command sends notifications to the SNMP server. There are three types of traps sent by LDP:

### Session up

Generated when sessions go up.

### Session down

Generated when sessions go down.

### Threshold

Generated when attempts to establish a session fails. The predefined value is 8.

Task ID	Task ID	Operations
	mpls-ldp	read, write
	mpls-te	read, write
	snmp	read, write

### Examples

The following example shows how to enable LDP SNMP trap notifications for Session up:

```
RP/0/RP0/CPU0:router(config)# snmp-server traps mpls ldp up
```

```
snmp-server traps mpls ldp
```